

FACTORY AUTOMATION

Mitsubishi Electric Programmable Controller MELSEC iQ-F Series

Quick Connection Guide

Predefined Protocol Support For Positioning Function Block Library (IAI Corporation)



INTRODUCTION

Thank you for purchasing the MELSEC iQ-F series.

This manual describes Predefined Protocol Support Tool For Positioning and FBs for Predefined Protocol Support for Positioning, which enable positioning operation of the IAI ROBO Cylinder easier than before. Positioning operation is performed by connecting the FX5U CPU module or FX5UC CPU module and the IAI controller.

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the specifications to handle the product correctly.

When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Regarding use of this product

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, please contact Mitsubishi Electric sales office.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions into the system.

Note

- If in doubt at any stage during the installation of the product, always consult a professional electrical engineer who is qualified and trained to the local and national standards. If in doubt about the operation or use, please contact your local Mitsubishi Electric representative.
- Mitsubishi Electric will not accept responsibility for actual use of the product based on these illustrative examples. Please use it after confirming the function and safety of the equipment and system.
- The content, specifications etc. of this manual may be changed, for improvement, without notice.
- The information in this manual has been carefully checked and is believed to be accurate; however, if you notice a doubtful point, an error, etc., please contact your local Mitsubishi Electric representative. When doing so, please provide the manual number given at the end of this manual.



Quick and satisfying browsing

e-Manual Viewer

e-Manual Viewer allows users to browse optimized FA-related documents such as Mitsubishi Electric FA product manuals. e-Manual Viewer can be downloaded for free from the Mitsubishi Electric FA website.

Easy on-demand download of latest documents

All necessary documents can be easily downloaded with one click. The latest documents are available at any time.

Quick cross document search for necessary information

Refine search and fuzzy search are available for all downloaded documents. Intuitive search using illustrations is available for hardware specifications of the product.

Copying program examples to an engineering tool

Program examples contained in a document can be directly copied to an engineering tool, eliminating the need of inputting the programs.

Sharing information among multiple users

The documents can be customized by adding useful information as a note freely. Latest documents and notes can be shared with multiple users using the document sharing function.



■ Introduction for the concept and features of e-Manual Viewer is available on the following website.

www.mitsubishielectric.com/fa/ref/ref.html?k=plceng&smerit=emaviewer_win

■ The installation file for Windows® can be downloaded from the following website.

www.mitsubishielectric.com/fa/ref/ref.html?k=plceng&software=emaviewer_en

CONTENTS

INTRODUCTION	1
RELEVANT MANUALS	4
GENERIC TERMS AND ABBREVIATIONS	4
KEY FEATURES	5
CHAPTER 1 APPLICABLE MODELS	7
CHAPTER 2 PREPARATION	9
2.1 System Configuration	9
2.2 Required Products	10
2.3 Wiring	11
Wiring an IAI controller	11
Wiring the programmable controller	13
2.4 Operation Flow Diagram	14
CHAPTER 3 IAI CONTROLLER SETTINGS	15
3.1 Part Names	15
3.2 Setting Switches	16
3.3 Parameter Settings	16
CHAPTER 4 PROGRAMMABLE CONTROLLER SETTINGS	17
4.1 Part Names	17
4.2 Parameter Settings	18
4.3 Communication Test for the Programmable Controller	24
4.4 Writing Data to the Programmable Controller	26
4.5 Positioning Test	29
CHAPTER 5 PROGRAM EXAMPLE	33
5.1 Operation	33
5.2 FB Library	35
Downloading the FB library	35
Importing the FB library	36
How to use the FB library	38
5.3 Program Details	40
CHAPTER 6 TROUBLESHOOTING	53
6.1 Checking Procedure	53
6.2 Checking the Programmable Controller	54
6.3 Checking the IAI Controller	55
APPENDIX	56
Appendix 1 List of FBs for Predefined Protocol Support for Positioning	56
Appendix 2 How to Use the Program Copy Function of e-Manual	57
Appendix 3 GOT2000 Series Connection Sample Windows	59
REVISIONS	61
WARRANTY	62
SAFETY PRECAUTIONS	62
TRADEMARKS	62

RELEVANT MANUALS

The following relevant manuals can be downloaded from the Mitsubishi Electric FA site.

www.mitsubishielectric.co.jp/fa/ref/ref.html?kisyu=plcf&manual=download_all

[○: Available, —: Not available]

Manual name <manual number>	Available form	
	e-Manual	PDF
MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware) <SH-082452ENG>	○	○
MELSEC iQ-F FX5 User's Manual (Application) <JY997D55401>	○	○
MELSEC iQ-F FX5 User's Manual (Serial Communication) <JY997D55901>	○	○
MELSEC iQ-F FX5 User's Manual (MODBUS Communication) <JY997D56101>	○	○
MELSEC iQ-F FX5 Predefined Protocol Support for Positioning Function Block Reference (for IAI) <SH-082262ENG>	○	○
GX Works3 Operating Manual <SH-081215ENG>	○	○
Predefined Protocol Support Tool For Positioning Operating Manual <SH-082176ENG>	○	○
PCON, ACON, SCON, RCP6 (PLC Unit) ERC2, ERC3 Serial Communication [Modbus Version] Operation Manual <ME0162-10>	—	—
PCON-CB Series Controller Instruction Manual <ME0342-4B>	—	—

GENERIC TERMS AND ABBREVIATIONS

Unless otherwise specified, this manual uses the following generic terms and abbreviations.


Generic term/abbreviation	Description
FB	An abbreviation for Function Block. The FB is a ladder block that is repeatedly used in a sequence program and designed to be diverted in the sequence program. This improves the efficiency of the program development and reduces the programming errors, resulting in the improvement in the program quality.
IAI	An abbreviation for IAI CORPORATION

KEY FEATURES

Point1

Easy programming using the FB library for Predefined Protocol Support for Positioning^{*1}

FB (function block) library is a collection of FBs that are used in GX Works3. Various settings (position table settings, servo ON/OFF, positioning operation) required to operate the IAI controller or ROBO Cylinder can be configured easily by dragging and dropping FBs from the FB library to a program editor and inputting devices. This can reduce programming cost and time.



*1 FB libraries can be downloaded for free from the Mitsubishi Electric FA website.
www.mitsubishielectric.co.jp/fa/ref/ref.html?kisyu=plcf&samplelibrary=download_all


Point2

Easy settings with Predefined Protocol Support Tool For Positioning

Writing positioning data and wiring were required for each controller.

Predefined Protocol Support Tool For Positioning enables a system construction only by wiring the programmable controller to each controller (it is also possible to wire one programmable controller to multiple controllers). This feature reduces the cost and time required for wiring each controller.


Additionally, communication protocols can be set automatically just with simple settings related to the system configuration. This reduces the cost and time for the protocol specifications of each controller.



Point3




Reduced debugging time thanks to no need for a program

The status of positioning control, alarms occurred, and other information can be checked in a window of Predefined Protocol Support Tool For Positioning without a dedicated HMI (Human Machine Interface) or a program. Therefore, debugging efficiency is dramatically improved.



1 APPLICABLE MODELS

The following models can be used for a series of operations described in this manual.

Programmable controller		IAI controller
 <p>FX5U CPU module</p>	 <p>FX5UC CPU module</p>	 <p>The model shown in the figure is of the PCON-CB/CGB/CBP/CGBP type.</p> <ul style="list-style-type: none"> ■PCON series C/CA/CB/CFA/CFB/CF/CY/CYB/SE ■ACON series C/CA/CB/CY/CYB/SE ■SCON series C/CA/CAL/CB (not including servo press specifications) ■DCON series CA/CB/CYB ■RCP6S RCP6S^{*1} ■ERC2 series Controller-integrated ROBO Cylinder ■ERC3 series^{*2} Controller-integrated ROBO Cylinder


*1 For the RCP6S series, the specifications do not allow the MODBUS RTU to read or write the position table information register (positioning data). Therefore, positioning data cannot be read or written. When using the RCP6S, use a Teaching Pendant or computer software manufactured by IAI Corporation.

*2 For the ERC3 series with the controller type set to the MEC mode, connection is not available.

2 PREPARATION

2.1 System Configuration

This section describes the system configuration in which two IAI controllers are connected to one programmable controller.






2.2 Required Products

This manual describes the system configuration for positioning operation performed by connecting two IAI controllers (PCON-CB) to a programmable controller (FX5U CPU module).

To use applicable products other than the above, refer to the following manuals.

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)




📖 Manuals for the IAI controller and ROBO Cylinder being used

One programmable controller*1	Two IAI controllers	Personal computer and software
 <p>Use an FX5U CPU module that meets the following conditions.</p> <ul style="list-style-type: none"> • Serial number: 17X**** or later • Firmware version: 1.200 or later <p>Set the termination resistor selector switch to 110Ω.</p>	 <p>■ IAI controller (PCON) model list</p> <ul style="list-style-type: none"> • PCON-CB 	 <p>GX Works3*2</p> <ul style="list-style-type: none"> • Applicable software version: 1.065T or later • Predefined Protocol Support Tool For Positioning*2 • Applicable software version: 1.002C or later

*1 To perform serial communication (MODBUS RTU) using a communication board (FX5-485-BD) or communication adapter (FX5-485ADP), settings different from the parameter settings described in this manual are required. Refer to the following for details.

📖 MELSEC iQ-F FX5 User's Manual (Serial Communication), Section 7.5 Communication Settings

*2 To obtain the latest version, please contact your local Mitsubishi Electric representative.

24VDC power supply	Two IAI ROBO Cylinders	One Ethernet cable
 <p>Used for supplying power to the IAI controllers.</p>	 <p>■ Motor straight type (coupling type) model list</p> <ul style="list-style-type: none"> • RCP2 series • RCP3 series • RCP4 series • RCP5 series • RCP6 series 	 <p>Used for connecting a personal computer and the programmable controller.</p> <p>Use an Ethernet cable compliant with the following standards.</p> <ul style="list-style-type: none"> • Category 5 or higher, straight cable (double shielded / STP) • IEEE 802.3 (100BASE-TX) • ANSI/TIA/EIA-568-B (Category 5)

Four e-CON connectors	One terminating resistor	One branch adapter	Two connection cables
Used for connecting the programmable controller and IAI controllers.	Used for the e-CON connector. 📖 Page 13 Wiring the IAI controllers	Used for wiring multiple IAI controllers.	A cable that connects to the PIO connector of an IAI controller. • CB-RCB-CTL002

Software

GX Works3 must import the following.

Item	File name	Reference
FB library	PositioningSupportIAI_F.mslm	Page 17 PROGRAMMABLE CONTROLLER SETTINGS


2.3 Wiring

Wiring an IAI controller

This section shows how to wire an IAI controller.

Wiring the power connector

Wire the power connector.



1. Check that the MPI terminal and MPO terminal of the power connector have been short-circuited, and insert the connector into the IAI controller.
2. Connect the S1 terminal of the power connector and the +24V terminal of the 24VDC power supply.

Point

The emergency stop state occurs when +24V power supplied to the S1 terminal is cut.

To wire the emergency stop switch, add a dry contact (b contact) to the wired part of the S1 terminal. (24VDC, 10mA or less)

3. Connect (short-circuit) the S2 terminal and EMG- terminal of the power connector.
4. Connect the 24V terminal of the power connector and the +24V terminal of the 24VDC power supply.
5. Connect the 0V terminal of the power connector and the 0V terminal of the 24VDC power supply.


■ Installing cables

Treat the sheath of the cable as follows.

- Stripped wire length: 10mm

Insert a cable whose end has been processed fully into the insertion slot.

If the wire cannot be inserted by this method, insert the wire fully while pressing the orange retaining pin using a screwdriver with a 2.0mm to 2.5mm wide flat blade. When the wire is inserted fully, remove the flathead screwdriver.




Point

Pull the wire or bar solderless terminal lightly to check that the wire is securely clamped.

Wiring the IAI ROBO Cylinder

Wire the IAI ROBO Cylinder.



1. Check the direction of each connector of the motor encoder cable, and push the corresponding connectors into the IAI controller and the IAI ROBO Cylinder until the connectors click.

Point

When wiring a ROBO Cylinder, check that the combination of the controller and the ROBO Cylinder is compatible.

ROBO Cylinder types that can be connected are written on the serial number label on the left side of the controller.

Wiring the programmable controller

For the power supply wiring of the programmable controller, refer to the following.


📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware), Section 13.4 Power Supply Wiring

Point

Set the terminating resistor by using the programmable controller. Set 110Ω with the termination resistor selector switch of the programmable controller.

Wiring the IAI controllers



Wire the IAI controllers.



1. Wire e-CON connectors to the programmable controller. Wire two sets of e-CON connectors on the external device communication cable side in the same manner.
2. Connect a cable for communicating with an external device to the SIO connector of each IAI controller. (2 sets)
3. Using the branch adapter, connect the programmable controller and two IAI controllers.


2.4 Operation Flow Diagram

- 1. Preparing the required products (wiring)
- 2. Setting the IAI controllers




2


- 3. Setting the programmable controller



- 4. Checking the communication status




- 5. Program examples and checking the operation



3 IAI CONTROLLER SETTINGS

3.1 Part Names

This section shows the part names of an IAI controller (PCON-CB).




No.	Name	Description
[1]	Controller status LED	Shows the operating status of the controller. SV on (green): Servo ON SV flashing (green): Automatic Servo OFF ALM on (red): Alarm (operation release level or higher), motor driving power supply OFF, emergency stop Both SV and ALM on (orange): Initialization at power-on in progress Off: Control power supply OFF, Servo OFF
[2]	PIO connector/Field network connector	Connector for I/O signal connections for control in the PIO specifications. Connector for each field network in the field network specifications.
[3]	Current/alarm monitoring LED	Normally indicates the command current ratio. When an alarm occurs, the alarm code will be indicated. For details on the command current ratio (ratio against the rated value) according to each LED combination, refer to the following. Manual for the IAI controller being used
[4]	Axis number setting switch	Switch for setting an axis number when operating multiple axes through serial communication or when performing gateway operations. When an SIO converter is used, multiple axes can be controlled without removing/reinserting the communication cable connector from/into the teaching tool. Settings for a maximum of 16 axes can be made using hexadecimal numbers from 0 to F. To change the axis number, rotate the arrow by using a flathead screwdriver. The setting of the axis number setting switch is loaded when the controller is powered on. Switching the setting at other times is invalid.
[5]	Operation mode setting switch	Switch for interlocking. • AUTO: Automatic operation by the PIO signal becomes possible. Only monitoring operation is possible from the teaching tool. • MANU: Operation from the teaching tool is possible.
[6]	SIO connector	Connector for connecting a communication cable for a teaching tool, gateway unit, etc. Used for connecting to a programmable controller.
[7]	Motor encoder connector	Connector for connecting a motor encoder cable for a ROBO Cylinder.
[8]	Brake release switch ^{*1}	Switch for forcibly releasing the brakes of a ROBO Cylinder with brakes. • BK RLS: Forcibly release brakes. • NOM: Normal operation (brakes enabled)

No.	Name	Description
[9]	Power connector	Connector for supplying each type of power (controller control power, Robo Cylinder power, brake control power) and inputting emergency stop status signals.

- *1 For normal operation, make sure to set the brake release switch to the NOM side. (Set the switch to the BK RLS side only when necessary, such as adjustment at start-up.)
 If the switch remains set to the BK RLS side, even when the Servo OFF state arises, the brakes do not activate.
 In vertical installations, a workpiece may drop, causing injury or damage to the workpiece.

Point

For details on IAI controllers other than the PCON-CB, refer to the following.
 Manual for the IAI controller being used

3.2 Setting Switches


The following table shows the switches of IAI controllers that are required to be set.

Name	Setting details
Axis number setting switch	Set this switch to any axis number.
Operation mode setting switch	Set this switch to the AUTO side.
Brake release switch	Set this switch to the NOM side.

3.3 Parameter Settings

Set the parameters for IAI controllers with Predefined Protocol Support Tool For Positioning.

Refer to the following for details.

 Page 21 Parameter settings of Predefined Protocol Support Tool For Positioning

4 PROGRAMMABLE CONTROLLER SETTINGS

4.1 Part Names

For the part names of the programmable controller, refer to the following.

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware), Chapter 3 PART NAMES

4.2 Parameter Settings

This section describes how to set parameters required for the programmable controller using GX Works3 and Predefined Protocol Support Tool For Positioning.


GX Works3 parameter settings

This section describes how to set parameters required for the programmable controller using GX Works3. Connect the personal computer and the programmable controller with an Ethernet cable.



4


1. In the "Navigation" window of GX Works3, select [Parameter] ⇒ [FX5UCPU] ⇒ [Module Parameter] ⇒ [485 Serial Port].




Point

If the "Navigation" window is not displayed, select [View] on the toolbar ⇒ [Docking Window] ⇒ [Navigation] to open the window.


2. In "Communication Protocol Type", select "Predefined Protocol Support Function".



3. When the confirmation window appears, click the [Yes] button.



4. Set "Advanced Settings" as follows, and click the [Apply] button.



4

Item	Setting value
Data Length	8 (Default value: 7)
Parity Bit	None (Default value: Odd)
Stop Bit	1bit (Default value: 1bit)
Baud Rate	38400bps (Default value: 115200bps)




For the settings in "Advanced Settings" except "Baud Rate", be sure to set the above values.


Parameter settings of Predefined Protocol Support Tool For Positioning

This section describes how to set parameters required for the programmable controller using Predefined Protocol Support Tool For Positioning.


1. Select [Tool] ⇒ [Module Tool List] from the menu of GX Works3.




2. For "Module Series Selection" in the "Module Tool List" window, select "iQ-F Series" and "Predefined Protocol Support Tool For Positioning", and click the [OK] button.




3. The "Predefined Protocol Support Tool For Positioning" window opens.



4. Select [Project] on the toolbar ⇨ [New].



5. Select "IAI" under "Select Manufacturer", select the checkbox of "CH1" under "The channel to be used", then click the [OK] button.




Point

The channel used is determined as follows.

- Built-in RS-485 communication terminal block of the CPU module: CH1
- Expansion board: CH2
- Expansion adapter: CH3, CH4

6. Configure settings as shown in the following window, and click the [Apply] button.



7. To save the protocol setting data, select [Project] ⇒ [Save As], and save it using any name.

8. Select [Project] ⇒ [Exit] to close the window.


Precautions

The following devices are used to write predefined protocol information. Make sure not to overlap with the devices used for other controls.


Device type	Device number
File register	R0 to R1801

4.3 Communication Test for the Programmable Controller


Directly connect the Ethernet ports as shown below.



1. Select [Online] ⇒ [Current Connection Destination].




2. Select "Direct Coupled Setting".




3. Specify an Ethernet adapter of the personal computer which is used when the personal computer is directly connected to the CPU module.


When "Not Specified" is set, select an adapter to be used from the drop-down list.



4. After the adapter is selected, click the [Communication Test] button.



For the connection via a hub, refer to the following.

 MELSEC iQ-F FX5 User's Manual (Ethernet Communication), Section 4.2 Connection Via a Hub

4.4 Writing Data to the Programmable Controller


This section describes how to write each parameter setting and program to the programmable controller. For details on programs, refer to the following.

☞ Page 33 PROGRAM EXAMPLE


Writing GX Works3 parameter settings

1. Perform the operation to determine the programs and the parameters before writing them to the programmable controller.


Select [Convert] ⇒ [Rebuild All].




2. Click the [OK] button.




3. Select [Online] ⇒ [Write to PLC].



4. Click "Parameter + Program", and click [Execute].



5. When the following window appears, click [Yes to all].




6. After the writing is complete, reset or power off and on the programmable controller.


Writing the parameter settings of Predefined Protocol Support Tool For Positioning

1. Write protocol setting data to the CPU module.

Select [Online] on the toolbar ⇒ [Write the Predefined Protocol Information].




2. Select "CPU built-in memory" under "Target memory", and click the [Execute] button.




3. Reset or power off and on the programmable controller to reflect the settings.

4.5 Positioning Test


After the writing process, perform a test for communication with the IAI controllers.




1. In the menu bar of "Predefined Protocol Support Tool For Positioning", select [Debug] ⇒ [Positioning Test].



2. Select a channel number and an axis number for the test target in the "Select test target" window, and click the [OK] button.




3. The "Positioning test" window appears.




Point

To change the test target, use the [Test Target Selection] button.



4. When the [Modbus Command Enable] button is displayed, click the button.
5. When the [Servo ON] button is displayed, click the button.
6. Click the [Home Position Return] button.

7. When the preparation is completed, both lamps of "Servo" and "Home position" are ON in the monitor area.



Positioning start

Specify a number and execute positioning data.

1. Select the [Positioning start] tab.




2. Enter a positioning data number to be executed in "Positioning Data No.".
3. Click the [Start] button.
4. By clicking the [Stop] button, the positioning control being performed is decelerated and stopped.


JOG/Inching

Set the speed or movement amount, and move the current position of the axis.

1. Select the [JOG/Inching] tab, then click the [JOG/Inching Setting] button.




2. Enter the JOG operation speed or the amount of movement at inching operation in the "JOG/Inching setting" window.



Item	Description
JOG speed	Enter the JOG operation speed.
Inching movement amount	Enter the travel distance of inching operation per time.

3. Click the [Setting] button in the "JOG/Inching setting" window.
4. When the confirmation window appears, click the [Yes] button.



5. Click the [Servo ON] button.
6. Select "JOG" or "Inching" in the [JOG/Inching] tab.
 - JOG: The current position moves at the set speed while the [Forward Rotation] or [Reverse Rotation] button is being pressed.
 - Inching: The current position moves by the set movement amount each time the [Forward Rotation] or [Reverse Rotation] button is clicked.
7. Click the [Forward Rotation] or [Reverse Rotation] button.
 - Forward Rotation: The current position moves in the positive direction.
 - Reverse Rotation: The current position moves in the negative direction.

Point

When "Inching" is selected, an inching is performed by the following key input.

- Forward Rotation:
- Reverse Rotation:

When "JOG" is selected, JOG operation is not performed even if the and keys are pressed.

5 PROGRAM EXAMPLE

5.1 Operation



The following shows an example of using this FB library for configuring the position table setting and performing the home position return and positioning operation for the IAI controller. The following FBs are used in this example.

- M+IAIMonitoring_F (Operation monitor)
- M+IAIWritePositioningTable_F (Position table setting)
- M+IAIStartHomePositioning_F (Home position return)
- M+IAIStartPositioning_F (Positioning operation)
- M+IAIServoControl_F (Servo ON/OFF)

Overview of program example

Perform monitoring to check the status of the IAI controller. Then, write the position table information to the position table No.0 of axis 1 and the position table No.0 of axis 2 of the IAI controller with the following settings. After writing information, perform a home position return, and move the ROBO Cylinder to the position which is 100mm away from the home position. If the error code 203H occurs during the operation, reset the alarm that has occurred in the IAI controller.

- Target position: 100mm ($0.01\text{mm} \times 10000$)
- Positioning width: 1mm ($0.01\text{mm} \times 100$)
- Acceleration: 0.01G
- Command speed: 10mm/s
- Deceleration: 0.01G



5.2 FB Library

Downloading the FB library

In this manual, the Predefined Protocol Support for Positioning Function Block Reference (for IAI) is used.
To obtain the FB library, please contact your local Mitsubishi Electric representative.


Importing the FB library

This section describes how to register the obtained FB library to GX Works3. Decompress the FB library folder (zip file) before registering the FB library.


1. Start GX Works3, and select [Project] on the toolbar ⇒ [New].

In this manual, the following settings are used.


Item	Description
Series	FX5CPU
Type	FX5U
Program Language	Ladder




2. Select [Project] on the toolbar ⇒ [Library Operation] ⇒ [Register to Library List] ⇒ [Library].



3. Select the "PositioningSupportAI_F.mslm" file in the decompressed FB library folder, and click [Open].



4. The selected file is added to [Library] in the "Element Selection" window.




If the "Element Selection" window is not displayed, select [View] on the toolbar ⇒ [Docking Window] ⇒ [Element Selection] to open the window.

How to use the FB library


Select an FB registered in the library from the "Element Selection" window, and drag and drop it to the program editor. Create an input ladder and an output ladder of the pasted FB to create a program.

Arrange the FB input ladder to the left side, and output ladder to the right side of the window in the same manner as standard ladder programs.


1. Go to the "Element Selection" window ⇒ the [Library] tab ⇒ [Library]. Then, select an FB to be used and drop it in the program editor. When the "FB Instance Name" window appears, click the [OK] button.




2. The FB is pasted to the program editor.




3. Insert a contact and input to B:i_BEN.



4. Insert an FB Word device input to the left side of the FB. Insert an FB Word device output to the right side of the FB.



5. Repeat these steps to create the ladder.




5.3 Program Details

When using e-Manual Viewer, the program copy function is available to perform programming. For details, refer to the following.

☞ Page 57 How to Use the Program Copy Function of e-Manual


Target channel setting



Target axis setting



Position table No. setting




IAI controller monitoring

By turning on `i_bEN` (Execution command), the status of the IAI controller is monitored by `M+IAIMonitoring_F` (Operation monitoring).

When `o_bMonitorOK` (Monitoring status) is on, the monitoring table information of the IAI controller is stored in `o_stMonitoringTable` (Monitoring table).

For details on how to access `stLabel4` and `stLabel5`, which are local labels of the structure type (`stMonitoringTable`), refer to the following.

☞ Page 50 Acquiring the alarm that has occurred in the IAI controller



For details on `o_stMonitoringTable` (Monitoring table), refer to the following.

☞ MELSEC iQ-F FX5 Predefined Protocol Support for Positioning Function Block Reference (for IAI), Section 2.1 Common Specifications

■Redefining local labels


When the above program examples are copied and pasted, the function blocks and local labels stLabel4 and stLabel5 become undefined.

For details on how to redefine function blocks, refer to the following.


☞ Page 57 How to Use the Program Copy Function of e-Manual

The method for redefining local labels stLabel4 and stLabel5 is explained in the following.


1. Double-click the undefined local label stLabel4, and click the [OK] button.




2. Click the See More button for "Data Type".



3. Go to "Type Category" ⇒ select "Structured Data Type" and "stMonitoringTable", then click the [OK] button.




4. Select the [Navigation] window ⇒ "Program" ⇒ "Scan" ⇒ "MAIN" ⇒ "ProgPou" ⇒ "Local Label", and check that local label stLabel4 is defined.



5. Define local label stLabel5 in the same way.


Position table (input label) setting

The following shows an example of setting the input labels for axes 1 and 2 of M+IAIsetPositioningTable_F (Position table setting) by turning on M19 and M119.



Setting the position table


By turning on `i_bEN` (Execution command), the information on the positioning operation is set in the positioning table of the target axis by `M+IAISetPositioningTable_F` (Position table setting).



		M+IAIsetPositioningTable_F_00A.2 (M+IAIsetPositioningTable_F_00A) Positioning data setting FB			
M120		B: i_bEN		o_bENO :B	M123
Target channel:1	[D0]	UW: i_uCh		o_bOK :B	M124
Target axis: 2	[D2]	UW: i_uAxis		o_bErr :B	M125
Position table No.: 0	[D4]	UW: i_uTableNo		o_uErrId :UW [D120]	
M121		B: i_bCurrentRead		o_bUnitErr :B	M126
Target position: 10000	[D300]	D: i_dPosition		o_uUnitErrId :UW [D121]	
Positioning width: 100	[D302]	UD: i_udWide			
Speed: 10	[D304]	UD: i_udSpeed			
Individual zone boundary plus side: 0	[D306]	D: i_dPulsZone			
Individual zone boundary minus side: 0	[D308]	D: i_dMinusZone			
Acceleration: 1	[D310]	UW: i_uUpSpeed			
Deceleration: 1	[D311]	UW: i_uDownSpeed			
Current limit value when pushed: 0033H	[D312]	UW: i_uElecLimit			
Load current threshold value: 0	[D313]	UW: i_uLoadCurrentThreshold			
M122		B: i_bControlFlag			


Point 

The positioning table can be configured by using Predefined Protocol Support Tool For Positioning as well. In that case, setting by M+IAIsetPositioningTable_F (Position table setting) is not required. For details on the settings by tools, refer to the following.

 Predefined Protocol Support Tool For Positioning Operating Manual, Section 7.2 Setting and Editing Positioning Data


Performing the home position return

By turning on `i_bEN` (Execution command), the home position return is performed by `M+IAIStartHomePositioning_F` (Home position return). When the home position return is performed, the servo is automatically turned on.




Performing the positioning operation

By turning on i_bEN (Execution command), the positioning operation of the set position table No. is performed by M+IAIStartPositioning_F (Positioning operation). When the positioning operation is performed, the servo is automatically turned on.



Servo OFF

When performing maintenance of the target axis, turn off the servo by M+IAIServoControl_F (Servo ON/OFF).
After normal completion, turn off i_bEN (Execution command).



Acquiring the alarm that has occurred in the IAI controller


If the 203H error occurs in the home position return or positioning operation, an alarm has occurred in the IAI controller. The following shows an example of storing the data in the local labels stLabel4 and stLabel5 of the structure type (stMonitoringTable) in the data register (D) by turning on M60 and M160.





Resetting the alarm that has occurred in the IAI controller

When an alarm code is stored in D62 or D162, the alarm that has occurred in the IAI controller is reset by M+IAIMonitoring_FB (Operation monitor) by turning on i_bAlmReset (Alarm reset).



■Redefining local labels

When the above program examples are copied and pasted, the function blocks and local labels stLabel4 and stLabel5 become undefined.

For details on how to redefine function blocks, refer to the following.

☞ Page 57 How to Use the Program Copy Function of e-Manual

The method for redefining local labels stLabel4 and stLabel5 is explained in the following.

☞ Page 42 Redefining local labels

6 TROUBLESHOOTING

6.1 Checking Procedure

This section describes how to check the status of the programmable controller and the IAI controller.


Checking the LED status

Check the communication status with the LEDs of the programmable controller and IAI controller.

Item	Reference
Programmable controller	Page 54 Checking the LED status
IAI controller	Page 55 Checking the LED status

Checking the error code

Check the following depending on the error code of the error that has occurred in the programmable controller or the IAI controller.

Item	Reference
Programmable controller	Page 54 Checking the error details
IAI controller	 Manual for the IAI controller being used

■Checking the wiring

Check that the Ethernet cables are fully inserted.

 Page 9 System Configuration

■Checking the communication settings

Check the content of the parameter settings on GX Works3 against the parameter settings of the IAI controller.

Item	Reference
Programmable controller	Page 18 Parameter Settings
IAI controller	Page 16 Parameter Settings

■Checking the programs


Check that the programs are created as shown in the program examples.

 Page 33 PROGRAM EXAMPLE

6.2 Checking the Programmable Controller

Checking the LED status


Check the programmable controller status with the LED.



Normal communications: Flashes at high speed.
Faulty communications: ON (Flicks at regular interval.)
Disconnection of Ethernet cable of the programmable controller: OFF

Checking the error details

On the toolbar of GX Works3, select [Diagnostics] ⇒ [Module Diagnostics (CPU Diagnostics)]. The error details of the programmable controller can be checked.




For details on troubleshooting and error codes, refer to the following.

📖 MELSEC iQ-F FX5 User's Manual (Application), Appendix 3 Error Code

6.3 Checking the IAI Controller

Checking the LED status

Check the LED status of the IAI controller.



For the LED indications of the IAI controller, refer to the following.

📖 Page 15 Part Names

For details on error codes, refer to the following.

📖 Manual for the IAI controller being used

APPENDIX

Appendix 1 List of FBs for Predefined Protocol Support for Positioning


The following table lists the FBs included in the FB library for Predefined Protocol Support for Positioning. Programs are created by combining FBs according to each application.

Name	Description
M+IAIStartHomePositioning_F	Executes the home position return.
M+IAIJogInching_F	Performs the JOG operation or inching operation.
M+IAIReadPositioningTable_F	Reads the specified position table data.
M+IAISetPositioningTable_F	Sets the specified position table data.
M+IAIStartPositioning_F	Starts the positioning operation.
M+IAIMonitoring_F	Monitors the current position and alarms, and performs the alarm reset.
M+IAIServoControl_F	Controls the servo ON/OFF.


Appendix 2 How to Use the Program Copy Function of e-Manual

Program examples in e-Manual can be copied and pasted to GX Works3.


1. Click "Copy Ladder Program (for GX Works3)" in e-Manual.



2. Right-click the mouse on the ladder editor of GX Works3, and select [Paste].



3. The copied program is pasted in undefined state. Select the FB used in the program example from [Library] on the "Element Selection" window, and drag and drop it to the FB area on the ladder editor.



Point

When an FB is used in the program example, the definition of the FB will be unclear immediately after the program is pasted to the ladder editor. Drag and drop the FB from the "Element Selection" window to define the FB properly.


Unclear definition of FB	
M_INVERTER_CC_IEF_Basic_Running_F_00A_1 (M-INVERTER-CC-IEF-Basic_Running_F_	
L_BEN	o_BENO
L_wStationNo	o_BOKB
L_BForward	o_BErB
L_BReverse	o_wErrIDW
L_BHigh	
L_BMiddle	
L_BLow	

Properly defined FB	
M_INVERTER_CC_IEF_Basic_Running_F_00A_1 (M-INVERTER-CC-IEF-Basic_Running_F_	
B_LBEN	o_BENO B
B_LwStationNo	o_BOKB B
B_LBForward	o_BErB B
B_LBReverse	o_wErrIDW B
B_LBHigh	
B_LBMiddle	
B_LBLOW	

4. Click the [OK] button on the "FB Instance Name" window.



5. When the FB is properly defined, the FB instance name is highlighted in gray.



Point

Label items (label name, data type, and others) are copied in the order defined as an example in this manual. Therefore, define label items in the same order as shown on the label editor of the engineering tool.

■ **Labels to be defined**
Define global labels as follows.

	Label Name	Data Type	Class	Assign (Device/Label)
1	bStartDirection_1	Bit	VAR_GLOBAL	M200
2	bStartDirection_2	Bit	VAR_GLOBAL	M201

[Copy labels \(for GX Works3\)](#)

Simple display

Switch simple display and detailed display using the [Easy Display] and [Show Details] buttons.

■ **Same label item order**

■ **Different label item order**

If the label items copied are different order from the order used at the pasting destination, incorrect items are pasted or some items will not be defined.

A


Appendix 3 GOT2000 Series Connection Sample Windows

Making a direct connection with GOT and using a sample window for monitoring and changing the current values or setting values of an IAI controller reduces the working hours for creating a GOT display window and contributes to the connection with an IAI controller.

The applicable models are as follows.

- PCON series
- ACON series
- SCON series

For information on sample windows for connecting GOT2000 and each controller, please contact your local Mitsubishi Electric representative.



MEMO

A

REVISIONS

Revision date	Version	Description
October 2022	A	First edition

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2022 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware), WARRANTY

📖 Manuals for the IAI controller and ROBO Cylinder being used, Warranty

SAFETY PRECAUTIONS

- Before using the product introduced in this manual, please read the manuals for the product carefully to handle the product correctly.
- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, please contact Mitsubishi Electric sales office.
- The product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions into the system.
- For design, wiring, and other precautions, read "SAFETY PRECAUTIONS" in the relevant manuals.

TRADEMARKS

Microsoft® and Windows® are trademarks of the Microsoft group of companies.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as "™" or "®" are not specified in this manual.

Country/Region	Sales office	Tel/Fax
USA	<p> MITSUBISHI ELECTRIC AUTOMATION, INC. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A. </p>	<p> Tel : +1-847-478-2100 Fax : +1-847-478-2253 </p>
Mexico	<p> MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch Boulevard Miguel de Cervantes Saavedra 301, Torre Norte Piso 5, Ampliacion Granada, Miguel Hidalgo, Ciudad de Mexico, Mexico, C.P.115200 </p>	<p> Tel : +52-55-3067-7512 </p>
Brazil	<p> MITSUBISHI ELECTRIC DO BRASIL COMERCIO E SERVICOS LTDA. Avenida Adelino Cardana, 293, 21 andar, Bethaville, Barueri SP, Brasil </p>	<p> Tel : +55-11-4689-3000 Fax : +55-11-4689-3016 </p>
Germany	<p> MITSUBISHI ELECTRIC EUROPE B.V. German Branch Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany </p>	<p> Tel : +49-2102-486-0 Fax : +49-2102-486-7780 </p>
UK	<p> MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K. </p>	<p> Tel : +44-1707-28-8780 Fax : +44-1707-27-8695 </p>
Ireland	<p> MITSUBISHI ELECTRIC EUROPE B.V. Irish Branch Westgate Business Park, Ballymount, Dublin 24, Ireland </p>	<p> Tel : +353-1-4198800 Fax : +353-1-4198890 </p>
Italy	<p> MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Centro Direzionale Colleoni - Palazzo Sirio, Viale Colleoni 7, 20864 Agrate Brianza (MB), Italy </p>	<p> Tel : +39-039-60531 Fax : +39-039-6053-312 </p>
Spain	<p> MITSUBISHI ELECTRIC EUROPE, B.V. Spanish Branch Carretera de Rubi, 76-80-Apdo. 420, E-08190 Sant Cugat del Valles (Barcelona), Spain </p>	<p> Tel : +34-935-65-3131 Fax : +34-935-89-1579 </p>
France	<p> MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets, 92741 Nanterre Cedex, France </p>	<p> Tel : +33-1-55-68-55-68 Fax : +33-1-55-68-57-57 </p>
Czech Republic	<p> MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch, Prague Office Pekarska 621/7, 155 00 Praha 5, Czech Republic </p>	<p> Tel : +420-255-719-200 </p>
Poland	<p> MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch ul. Krakowska 48, 32-083 Balice, Poland </p>	<p> Tel : +48-12-347-65-00 </p>
Sweden	<p> MITSUBISHI ELECTRIC EUROPE B.V. (Scandinavia) Hedvig Mollersgata 6, 223 55 Lund, Sweden </p>	<p> Tel : +46-8-625-10-00 Fax : +46-46-39-70-18 </p>
Russia	<p> MITSUBISHI ELECTRIC (RUSSIA) LLC St. Petersburg Branch Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; 195027 St. Petersburg, Russia </p>	<p> Tel : +7-812-633-3497 Fax : +7-812-633-3499 </p>
Turkey	<p> MITSUBISHI ELECTRIC TURKEY A.S. Umraniye Branch Serifali Mah. Kale Sok. No:41 34775 Umraniye - Istanbul, Turkey </p>	<p> Tel : +90-216-969-2500 Fax : +90-216-661-4447 </p>
UAE	<p> MITSUBISHI ELECTRIC EUROPE B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E. </p>	<p> Tel : +971-4-3724716 Fax : +971-4-3724721 </p>
South Africa	<p> ADROIT TECHNOLOGIES 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa </p>	<p> Tel : +27-11-658-8100 Fax : +27-11-658-8101 </p>
China	<p> MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China </p>	<p> Tel : +86-21-2322-3030 Fax : +86-21-2322-3000 </p>
Taiwan	<p> SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan </p>	<p> Tel : +886-2-2299-2499 Fax : +886-2-2299-2509 </p>
Korea	<p> MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. 7F to 9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea </p>	<p> Tel : +82-2-3660-9569 Fax : +82-2-3664-8372 </p>
Singapore	<p> MITSUBISHI ELECTRIC ASIA PTE. LTD. 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943 </p>	<p> Tel : +65-6473-2308 Fax : +65-6476-7439 </p>
Thailand	<p> MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand </p>	<p> Tel : +66-2682-6522-31 Fax : +66-2682-6020 </p>
Vietnam	<p> MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam </p>	<p> Tel : +84-28-3910-5945 Fax : +84-28-3910-5947 </p>
Indonesia	<p> PT. MITSUBISHI ELECTRIC INDONESIA Gedung Jaya 8th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia </p>	<p> Tel : +62-21-31926461 Fax : +62-21-31923942 </p>
India	<p> MITSUBISHI ELECTRIC INDIA PVT. LTD. Pune Branch Emerald House, EL-3, J Block, M.I.D.C., Bhosari, Pune-411026, Maharashtra, India </p>	<p> Tel : +91-20-2710-2000 Fax : +91-20-2710-2100 </p>
Australia	<p> MITSUBISHI ELECTRIC AUSTRALIA PTY. LTD. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia </p>	<p> Tel : +61-2-9684-7777 Fax : +61-2-9684-7245 </p>

MITSUBISHI ELECTRIC CORPORATION
HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
www.MitsubishiElectric.com