




for a greener tomorrow



## MITSUBISHI ELECTRIC SERVO SYSTEM CONTROLLER

# Migration Guide from Positioning Module to Simple Motion Module [QD75M(H) ⇒ QD77MS]

QD75MH1/QD75M1  
QD75MH2/QD75M2  
QD75MH4/QD75M4



**SSCNET III/H**  
SERVO SYSTEM CONTROLLER NETWORK

**QD77MS2**  
**QD77MS4**



# ● SAFETY PRECAUTIONS ●

(Please read these instructions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

In this manual, the safety instructions are ranked as "DANGER" and "CAUTION".




**DANGER**

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



**CAUTION**

Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on circumstances, procedures indicated by  CAUTION may also be linked to serious results. In any case, it is important to follow the directions for usage.

Please save this manual to make it accessible when required and always forward it to the end user.

## For Safe Operations

### 1. Prevention of electric shocks

#### DANGER

- Never open the front case or terminal covers while the power is ON or the unit is running, as this may lead to electric shocks.
- Never run the unit with the front case or terminal cover removed. The high voltage terminal and charged sections will be exposed and may lead to electric shocks.
- Never open the front case or terminal cover at times other than wiring work or periodic inspections even if the power is OFF. The insides of the module and servo amplifier are charged and may lead to electric shocks.
- Completely turn off the externally supplied power used in the system before mounting or removing the module, performing wiring work, or inspections. Failing to do so may lead to electric shocks.
- When performing wiring work or inspections, turn the power OFF, wait at least ten minutes, and then check the voltage with a tester, etc. Failing to do so may lead to electric shocks.
- Be sure to ground the module, servo amplifier and servomotor (Ground resistance: 100  $\Omega$  or less). Do not ground commonly with other devices.
- The wiring work and inspections must be done by a qualified technician.
- Wire the units after installing the module, servo amplifier and servomotor. Failing to do so may lead to electric shocks or damage.
- Never operate the switches with wet hands, as this may lead to electric shocks.
- Do not damage, apply excessive stress, place heavy things on or sandwich the cables, as this may lead to electric shocks.
- Do not touch the module, servo amplifier, servomotor connector or terminal blocks while the power is ON, as this may lead to electric shocks.
- Do not touch the built-in power supply, built-in grounding or signal wires of the module and servo amplifier, as this may lead to electric shocks.

### 2. For fire prevention

#### CAUTION

- Install the module, servo amplifier, servomotor and regenerative resistor on incombustible. Installing them directly or close to combustibles will lead to fire.
- If a fault occurs in the module or servo amplifier, shut the power OFF at the servo amplifier's power source. If a large current continues to flow, fire may occur.
- When using a regenerative resistor, shut the power OFF with an error signal. The regenerative resistor may abnormally overheat due to a fault in the regenerative transistor, etc., and may lead to fire.
- Always take heat measures such as flame proofing for the inside of the control panel where the servo amplifier or regenerative resistor is installed and for the wires used. Failing to do so may lead to fire.
- Do not damage, apply excessive stress, place heavy things on or sandwich the cables, as this may lead to fire.

### 3. For injury prevention

#### CAUTION

- Do not apply a voltage other than that specified in the instruction manual on any terminal. Doing so may lead to destruction or damage.
- Do not mistake the terminal connections, as this may lead to destruction or damage.
- Do not mistake the polarity (+ / -), as this may lead to destruction or damage.
- Do not touch the heat radiating fins of module or servo amplifier, regenerative resistor and servomotor, etc., while the power is ON and for a short time after the power is turned OFF. In this timing, these parts become very hot and may lead to burns.
- Always turn the power OFF before touching the servomotor shaft or coupled machines, as these parts may lead to injuries.
- Do not go near the machine during test operations or during operations such as teaching. Doing so may lead to injuries.

### 4. Various precautions

Strictly observe the following precautions. Mistaken handling of the unit may lead to faults, injuries or electric shocks.

#### (1) System structure

#### CAUTION

- Always install a leakage breaker on the module and servo amplifier power source.
- If installation of an electromagnetic contactor for power shut off during an error, etc., is specified in the instruction manual for the servo amplifier, etc., always install the electromagnetic contactor.
- Install the emergency stop circuit externally so that the operation can be stopped immediately and the power shut off.
- Use the module, servo amplifier, servomotor and regenerative resistor with the correct combinations listed in the instruction manual. Other combinations may lead to fire or faults.
- Use the CPU module, base unit, and Simple Motion module with the correct combinations listed in the instruction manual. Other combinations may lead to faults.
- If safety standards (ex., robot safety rules, etc.) apply to the system using the module, servo amplifier and servomotor, make sure that the safety standards are satisfied.
- Construct a safety circuit externally of the module or servo amplifier if the abnormal operation of the module or servo amplifier differs from the safety directive operation in the system.
- In systems where coasting of the servomotor will be a problem during the forced stop, emergency stop, servo OFF or power supply OFF, use the dynamic brake.
- Make sure that the system considers the coasting amount even when using the dynamic brake.
- In systems where perpendicular shaft dropping may be a problem during the forced stop, emergency stop, servo OFF or power supply OFF, use both the dynamic brake and electromagnetic brake.
- The dynamic brake must be used only on errors that cause the forced stop, emergency stop, or servo OFF. This brake must not be used for normal braking.
- The brake (electromagnetic brake) assembled into the servomotor are for holding applications, and must not be used for normal braking.

## CAUTION

- The system must have a mechanical allowance so that the machine itself can stop even if the stroke limits switch is passed through at the max. speed.
- Use wires and cables that have a wire diameter, heat resistance and bending resistance compatible with the system.
- Use wires and cables within the length of the range described in the instruction manual.
- The ratings and characteristics of the parts (other than module, servo amplifier and servomotor) used in a system must be compatible with the module, servo amplifier and servomotor.
- Install a cover on the shaft so that the rotary parts of the servomotor are not touched during operation.
- There may be some cases where holding by the electromagnetic brake is not possible due to the life or mechanical structure (when the ball screw and servomotor are connected with a timing belt, etc.). Install a stopping device to ensure safety on the machine side.

### (2) Parameter settings and programming

## DANGER

- Set the parameter values to those that are compatible with the module, servo amplifier, servomotor and regenerative resistor model and the system application. The protective functions may not function if the settings are incorrect.
- The regenerative resistor model and capacity parameters must be set to values that conform to the operation mode and servo amplifier. The protective functions may not function if the settings are incorrect.
- Set the mechanical brake output and dynamic brake output validity parameters to values that are compatible with the system application. The protective functions may not function if the settings are incorrect.
- Set the stroke limit input validity parameter to a value that is compatible with the system application. The protective functions may not function if the setting is incorrect.
- Set the servomotor encoder type (increment, absolute position type, etc.) parameter to a value that is compatible with the system application. The protective functions may not function if the setting is incorrect.
- Use the program commands for the program with the conditions specified in the instruction manual.
- Set the sequence function program capacity setting, device capacity, latch validity range, I/O assignment setting, and validity of continuous operation during error detection to values that are compatible with the system application. The protective functions may not function if the settings are incorrect.
- The input devices and data registers assigned to the link will hold the data previous to when communication is terminated by an error, etc. Thus, an error correspondence interlock program specified in the instruction manual must be used.
- Use the interlock program specified in the intelligent function module's instruction manual for the program corresponding to the intelligent function module.

(3) Transportation and installation

**⚠ CAUTION**

- Transport the product with the correct method according to the mass.
- Use the servomotor suspension bolts only for the transportation of the servomotor. Do not transport the servomotor with machine installed on it.
- Do not stack products past the limit.
- When transporting the module or servo amplifier, never hold the connected wires or cables.
- When transporting the servomotor, never hold the cables, shaft or detector.
- When transporting the module or servo amplifier, never hold the front case as it may fall off.
- When transporting, installing or removing the module or servo amplifier, never hold the edges.
- Install the unit according to the instruction manual in a place where the mass can be withstood.
- Do not get on or place heavy objects on the product.
- Always observe the installation direction.
- Keep the designated clearance between the module or servo amplifier and control panel inner surface or the module and servo amplifier, module or servo amplifier and other devices.
- Do not install or operate modules, servo amplifiers or servomotors that are damaged or that have missing parts.
- Do not block the intake/outtake ports of the servo amplifier and servomotor with cooling fan.
- Do not allow conductive matter such as screw or cutting chips or combustible matter such as oil enter the module, servo amplifier or servomotor.
- The module, servo amplifier and servomotor are precision machines, so do not drop or apply strong impacts on them.
- Securely fix the module, servo amplifier and servomotor to the machine according to the instruction manual. If the fixing is insufficient, these may come off during operation.
- Always install the servomotor with reduction gears in the designated direction. Failing to do so may lead to oil leaks.
- Store and use the unit in the following environmental conditions.

Environment	Conditions	
	Module/Servo amplifier	Servomotor
Ambient temperature	According to each instruction manual.	0°C to +40°C (With no freezing) (32°F to +104°F)
Ambient humidity	According to each instruction manual.	80% RH or less (With no dew condensation)
Storage temperature	According to each instruction manual.	-20°C to +65°C (-4°F to +149°F)
Atmosphere	Indoors (where not subject to direct sunlight). No corrosive gases, flammable gases, oil mist or dust must exist	
Altitude	According to each instruction manual	
Vibration	According to each instruction manual	

- When coupling with the servomotor shaft end, do not apply impact such as by hitting with a hammer. Doing so may lead to detector damage.
- Do not apply a load larger than the tolerable load onto the servomotor shaft. Doing so may lead to shaft breakage.

## CAUTION


- When not using the module for a long time, disconnect the power line from the module or servo amplifier.
- Place the module and servo amplifier in static electricity preventing vinyl bags and store.
- When storing for a long time, please contact with our sales representative.  
Also, execute a trial operation.
- Make sure that the connectors for the servo amplifier and peripheral devices have been securely installed until a click is heard.  
Not doing so could lead to a poor connection, resulting in erroneous input and output.
- When fumigants that contain halogen materials such as fluorine, chlorine, bromine, and iodine are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products.  
Please take necessary precautions to ensure that remaining materials from fumigant do not enter our products, or treat packaging with methods other than fumigation (heat method). Additionally, disinfect and protect wood from insects before packing products.
- The module and the servo amplifier must not be used with parts which contain halogen-series flame retardant materials (such as bromine) under coexisting conditions.



#### (4) Wiring

### ⚠ CAUTION

- Correctly and securely wire the wires. Reconfirm the connections for mistakes and the terminal screws for tightness after wiring. Failing to do so may lead to run away of the servomotor.
- After wiring, install the protective covers such as the terminal covers to the original positions.
- Do not install a phase advancing capacitor, surge absorber or radio noise filter (option FR-BIF) on the output side of the servo amplifier.
- Correctly connect the output side (terminal U, V, W). Incorrect connections will lead the servomotor to operate abnormally.
- Do not connect a commercial power supply to the servomotor, as this may lead to trouble.
- Do not mistake the direction of the surge absorbing diode installed on the DC relay for the control signal output of brake signals, etc. Incorrect installation may lead to signals not being output when trouble occurs or the protective functions not functioning.



- Do not connect or disconnect the connection cables between each unit, the encoder cable or PLC expansion cable while the power is ON.
- Securely tighten the cable connector fixing screws and fixing mechanisms. Insufficient fixing may lead to the cables coming off during operation.
- Do not bundle the power line or cables.
- Use applicable solderless terminals and tighten them with the specified torque.  
If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.

(5) Trial operation and adjustment

**⚠ CAUTION**

- Confirm and adjust the program and each parameter before operation. Unpredictable movements may occur depending on the machine.
- Extreme adjustments and changes may lead to unstable operation, so never make them.
- When using the absolute position system function, on starting up, and when the module or absolute position motor has been replaced, always perform a home position return.
- Before starting test operation, set the parameter speed limit value to the slowest value, and make sure that operation can be stopped immediately by the forced stop, etc. if a hazardous state occurs.
- Before starting the operation, confirm the brake function.

(6) Usage methods

**⚠ CAUTION**


- Immediately turn OFF the power if smoke, abnormal sounds or odors are emitted from the module, servo amplifier or servomotor.
- Always execute a test operation before starting actual operations after the program or parameters have been changed or after maintenance and inspection.
- Do not attempt to disassemble and repair the units excluding a qualified technician whom our company recognized.
- Do not make any modifications to the unit.
- Keep the effect or electromagnetic obstacles to a minimum by installing a noise filter or by using wire shields, etc.  
Electromagnetic obstacles may affect the electronic devices used near the module or servo amplifier.
- When using the CE Mark-compliant equipment design, refer to the "EMC Installation Guidelines" (data number IB(NA)-67339) and refer to the corresponding EMC guideline information for the servo amplifiers and other equipment.
- Note that when the reference axis speed is designated for interpolation operation, the speed of the partner axis (2nd axis, 3rd axis and 4th axis) may be larger than the set speed (larger than the speed limit value).
- Use the units with the following conditions.

Item	Conditions
Input power	According to each instruction manual.
Input frequency	According to each instruction manual.
Tolerable momentary power failure	According to each instruction manual.

(7) Corrective actions for errors

## ⚠ CAUTION

- If an error occurs in the self diagnosis of the module or servo amplifier, confirm the check details according to the instruction manual, and restore the operation.
- If a dangerous state is predicted in case of a power failure or product failure, use a servomotor with an electromagnetic brake or install a brake mechanism externally.
- Use a double circuit construction so that the electromagnetic brake operation circuit can be operated by emergency stop signals set externally.



- If an error occurs, remove the cause, secure the safety and then resume operation after alarm release.
- The unit may suddenly resume operation after a power failure is restored, so do not go near the machine. (Design the machine so that personal safety can be ensured even if the machine restarts suddenly.)

## (8) Maintenance, inspection and part replacement

### CAUTION

- Perform the daily and periodic inspections according to the instruction manual.
- Perform maintenance and inspection after backing up the program and parameters for the module and servo amplifier.
- Do not place fingers or hands in the clearance when opening or closing any opening.
- Periodically replace consumable parts such as batteries according to the instruction manual.
- Do not touch the lead sections such as ICs or the connector contacts.
- Before touching the module, always touch grounded metal, etc. to discharge static electricity from human body. Failure to do so may cause the module to fail or malfunction.
- Do not directly touch the module's conductive parts and electronic components. Touching them could cause an operation failure or give damage to the module.
- Do not place the module or servo amplifier on metal that may cause a power leakage or wood, plastic or vinyl that may cause static electricity buildup.
- Do not perform a megger test (insulation resistance measurement) during inspection.
- When replacing the module or servo amplifier, always set the new module settings correctly.
- When the module or absolute position motor has been replaced, carry out a home position return operation using the following method, otherwise position displacement could occur.
  - After writing the servo data to the Simple Motion module using programming software, switch on the power again, then perform a home position return operation.
- After maintenance and inspections are completed, confirm that the position detection of the absolute position detector function is correct.
- Do not drop or impact the battery installed to the module. Doing so may damage the battery, causing battery liquid to leak in the battery. Do not use the dropped or impacted battery, but dispose of it.
- Do not short circuit, charge, overheat, incinerate or disassemble the batteries.
- The electrolytic capacitor will generate gas during a fault, so do not place your face near the module or servo amplifier.
- The electrolytic capacitor and fan will deteriorate. Periodically replace these to prevent secondary damage from faults. Please contact with our sales representative.
- Lock the control panel and prevent access to those who are not certified to handle or install electric equipment.
- Do not mount/remove the module and base or terminal block more than 50 times (IEC61131-2-compliant), after the first use of the product. Failure to do so may cause malfunction.
- Do not burn or break a module and servo amplifier. Doing so may cause a toxic gas.

#### (9) About processing of waste

When you discard module, servo amplifier, a battery (primary battery) and other option articles, please follow the law of each country (area).

### CAUTION

- This product is not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to install safety devices to forestall serious accidents when it is used in facilities where a breakdown in the product is likely to cause a serious accident.

#### (10) General cautions

- All drawings provided in the instruction manual show the state with the covers and safety partitions removed to explain detailed sections. When operating the product, always return the covers and partitions to the designated positions, and operate according to the instruction manual.



## INTRODUCTION

Please read this manual carefully so that equipment is used to its optimum.

## CONTENTS

Safety Precautions .....	A- 1
Revision .....	A-12
Contents.....	A-13

### 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS 1- 1 to 1-20

1.1 Benefits of Migration.....	1- 1
1.2 Main Target Models for Migration.....	1- 2
1.3 System Configuration .....	1- 6
1.3.1 System configuration using QD75M before migration .....	1- 6
1.3.2 System configuration using QD75MH before migration .....	1- 6
1.3.3 System configuration using QD77MS after migration .....	1- 7
1.4 Case Study on Migration .....	1- 8
1.4.1 Case study for QD75M.....	1- 8
1.4.2 Case study for QD75MH .....	1-12
1.5 Project Diversion .....	1-17
1.6 Introduction of QD77MS16 .....	1-18
1.7 Relevant Documents .....	1-19
1.7.1 Relevant catalogs .....	1-19
1.7.2 Relevant manuals .....	1-20

### 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS 2- 1 to 2- 20

2.1 Table of Components and Software .....	2- 1
2.1.1 Servo amplifiers and servo motors.....	2- 2
2.1.2 Engineering environment (required) .....	2- 3
2.2 Differences Between QD75M and QD77MS.....	2- 4
2.3 Connection of Manual Pulse Generator.....	2-11
2.3.1 Comparison of pin layout .....	2-11
2.3.2 External input signal cable replacement .....	2-12
2.4 Project Diversion .....	2-15
2.4.1 Project diversion procedures by engineering environment .....	2-15

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS 3- 1 to 3- 22

3.1 Table of Components and Software .....	3- 1
3.1.1 Servo amplifiers and servo motors.....	3- 2
3.1.2 Engineering environment (required) .....	3- 3
3.2 Differences Between QD75MH and QD77MS .....	3- 4
3.3 Connection of Manual Pulse Generator.....	3-10
3.3.1 Comparison of pin layout .....	3-10
3.3.2 External input signal cable replacement .....	3-11
3.4 Project Diversion .....	3-17
3.4.1 Project diversion procedures by engineering environment .....	3-17

Appendix1 List of Buffer Memory Addresses ..... App- 1



## 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

### 1.1 Benefits of Migration


Migrating from the existing system using QD75M/QD75MH Positioning modules to a new system using MELSEC-Q series Simple Motion module QD77MS4/QD77MS2 (hereinafter called QD77MS), which support the programs on the QD75M/QD75MH, is recommended. We also recommend migrating servo amplifiers to the MR-J4 series at the same time.

Migrating not only allows the system to run for longer periods, but also has the following advantages.

- (1) High-speed operation and high functionality of Positioning module (Simple Motion module)  
The Simple Motion module QD77MS achieves the operation cycle of 0.88 ms/4 axes, enabling a dramatically fast operation.


The controller also achieves further advanced motion control with a wide variety of motion control functions.

→ Increased productivity from higher speeds and functionality of the controller

- (2) High-speed communication by SSCNETIII/H 

Speeding up and improving noise tolerance of servo system network communications are achieved by optical communication. A long distance cable of 100 m can be also used.

→ Increased speeds over the entire facility

- (3) Servo amplifier MR-J4 and servo motor 

The servo amplifier MR-J4 series achieves high performance operation with a variety of functions including one-touch tuning, a 22-bit high resolution encoder (4194304 pulse/rev), and 2.5 kHz speed frequency response. The product line includes multi-axis servo amplifiers that contribute to energy saving, space saving, and reduced wiring of a machine. The MR-J4 series compatible rotary servo motor, HG series enables to output high torque at high speed. Linear servo motors and direct drive motors are also available. Select the motor type according to your application from our extensive product lines.

→ Increase of applications, improved performance, energy saving, downsizing, and reduced wiring of drive systems

- (4) Lower maintenance cost

After 5 years of usage, the products will need maintenance, such as replacement of the whole circuit board due to the life of components including electrolytic capacitors and memories.

To use the system the longest possible, an early migration to the latest model is recommended in terms of performance and quality.

→ Increased equipment longevity


# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

---

## 1.2 Main Target Models for Migration

The main target models for replacement described in this section are as follows.

### (1) Positioning modules

Product name	Model before migration		Model after migration
SSCNET Positioning module	QD75M1		QD77MS2 <sup>(Note-1)</sup>
	QD75M2		
	QD75M4		QD77MS4
SSCNETIII Positioning module	QD75MH1		QD77MS2 <sup>(Note-1)</sup>
	QD75MH2		
	QD75MH4		QD77MS4

(Note-1): The number of control axes is increased from 1 to 2.

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (2) Servo amplifiers and servo motors (a) For QD75M


Before migration from QD75M			After migration to QD77MS		
Servo amplifier		Servo motor	Servo amplifier		Servo motor
MR-J2S series	MR-J2S-□B	HC-KFS□	MR-J4 series	MR-J4-□B(-RJ) MR-J4W2-□B MR-J4W3-□B	HG-KR□
		HC-MFS□			HG-MR□
		HC-SFS□			HG-SR□
		HC-LFS□			HG-RR□
		HC-RFS□			HG-UR□
HA-LFS□	HG-JR□				
HC-UFS□					
MR-J2M series	MR-J2M-□DU	HC-KFS□			
		HC-MFS□			
		HC-UFS□			
MR-H series	MR-H□B(N)	HA-FF□			
		HA-FH□			
		HA-LH□			
		HA-MH□			
		HA-SH□			
		HA-UH□			
		HC-KF□			
		HC-MF□			
		HC-RF□			
		HC-SF□			
		HC-UF□			
		HA-LF□			
		HA-LH□K			
		MR-J2 series	MR-J2-□B	HC-MF□	
HA-FF□					
HC-SF□					
HA-RF□					
HC-UF□					
MR-J2-Jr series	MR-J2-03B5	HC-AQ□(B)D	MR-J4W2-0303B6	HG-AK□(B)D	
		HC-AQ□(B)S		HG-AK□(B)	

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS


(b) For QD75MH

The existing MR-J3 series servo amplifiers can be used in the migrated system with QD77MS, however, it is strongly recommended to replace them with the MR-J4 series.


1) Servo amplifiers/Rotary servo motors

Before migration from QD75MH				After migration to QD77MS		
Servo amplifier		Rotary servo motor		Servo amplifier		Rotary servo motor
MR-J3 series	MR-J3-□B	HF-KP□		MR-J4 series	MR-J4-□B(-RJ)	HG-KR□
	MR-J3W-□B	HF-MP□			MR-J4W2-□B	HG-MR□
	MR-J3-□BS	HF-SP□			MR-J4W3-□B	HG-SR□
	MR-J3-□B-RJ006	HF-JP□				HG-RR□
		HC-LP□				HG-UR□
HC-RP□		HG-JR□				
	HC-UP□					
	HA-LP□					

2) Servo amplifiers/Linear servo motors

Before migration from QD75MH				After migration to QD77MS		
Servo amplifier		Linear servo motor		Servo amplifier		Linear servo motor
MR-J3 series	MR-J3-□B-RJ004	LM-H2□		MR-J4 series	MR-J4-□B(-RJ)	LM-H3□
		LM-F□			MR-J4W2-□B	LM-F□
		LM-K2□			MR-J4W3-□B	LM-K2□
		LM-U2□				LM-U2□



3) Servo amplifiers/Direct drive motors

Before migration from QD75MH				After migration to QD77MS		
Servo amplifier		Direct drive motor		Servo amplifier		Direct drive motor
MR-J3 series	MR-J3-□B-RJ080W	TM-RFM□		MR-J4 series	MR-J4-□B(-RJ)	TM-RFM□
					MR-J4W2-□B	
					MR-J4W3-□B	



# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (3) Servo system network

### (a) For QD75M

Item			
Communications medium		Metal cable	Optical fiber cable
Communications speed		5.6 Mbps	150 Mbps
Communications cycle	Send	0.88 ms/1.77 ms/3.55 ms	0.22 ms/0.44 ms/0.88 ms
	Receive	3.55 ms	0.22 ms/0.44 ms/0.88 ms
Number of control axes		Up to 8 axes/line	Up to 16 axes/line
Transmission distance		Maximum overall distance: 30 m	[Standard code for inside panel and standard cable for outside panel] Up to 20 m between stations Maximum overall distance: 320 m (20 m × 16 axes)  [Long distance cable] Up to 100 m between stations Maximum overall distance: 1600 m (100 m × 16 axes)

### (b) For QD75MH

Item			
Communications medium		Optical fiber cable	← (same as SSCNETIII)
Communications speed		50 Mbps	150 Mbps
Communications cycle	Send	0.44 ms/0.88 ms	0.22 ms/0.44 ms/0.88 ms
	Receive	0.44 ms/0.88 ms	0.22 ms/0.44 ms/0.88 ms
Number of control axes		Up to 16 axes/line	← (same as SSCNETIII)
Transmission distance		[Standard code for inside panel] Up to 3 m between stations Maximum overall distance: 48 m (3 m × 16 axes)  [Standard cable for outside panel] Up to 20 m between stations Maximum overall distance: 320 m (20 m × 16 axes)  [Long distance cable] Up to 50 m between stations Maximum overall distance: 800 m (50 m × 16 axes)	[Standard code for inside panel and standard cable for outside panel] Up to 20 m between stations Maximum overall distance: 320 m (20 m × 16 axes)  [Long distance cable] Up to 100 m between stations Maximum overall distance: 1600 m (100 m × 16 axes)

## (4) Engineering environment (required)


Product name	Model	Version
MELSOFT GX Works2	SW1DND-GXW2-E	Ver. 1.576A or later
MELSOFT MR Configurator2 <sup>(Note-1)</sup>	SW1DNC-MRC2-E	Ver. 1.12N or later

(Note-1): The Servo Setup Software MRZJW3-SETUP161E is required when a combination of MR-J4-B-RJ020 and MR-J4-T20 is used as MR-J2S-B.


# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## 1.3 System Configuration

### 1.3.1 System configuration using QD75M before migration




### 1.3.2 System configuration using QD75MH before migration



# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## 1.3.3 System configuration using QD77MS after migration




# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## 1.4 Case Study on Migration

### 1.4.1 Case study for QD75M

The following describes a case study for migrating the existing system using QD75M.



#### (1) Whole system migration (recommended)

The controller, servo amplifiers, servo motors, and servo system network are replaced simultaneously. Although a large-scale installation is required, the whole system migration allows the system to operate for longer periods. (Refer to section 1.4.1(1).)

#### (2) Phased migration (When the whole system migration is difficult due to the installation period and cost.)

The MR-J2S-B servo amplifiers are gradually replaced with the MR-J4-B servo amplifiers, and then the controller is eventually replaced with QD77MS in the final phase. (Refer to section 1.4.1(2).)

#### (3) Separate repair


This is a replacement method for when the servo amplifier or the servo motor malfunctions. (Refer to section 1.4.1(3).)



# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (1) Whole system migration (recommended) [QD75M]

The following shows the system when the whole system migration takes place.



### [Changes in the system]


Product name	Model before migration	Model after migration
Positioning module	QD75M	QD77MS
Servo amplifier	MR-J2S-B	MR-J4-B
Servo motor	HC/HA series	HG series

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (2) Phased migration [QD75M]


The following shows the procedure for the phased migration in which the MR-J2S-B servo amplifiers are gradually replaced with the MR-J4-B servo amplifiers, and eventually the controller with QD77MS in the final phase.

### [Current system]



### [Replacement - Phase 1]


Servo amplifier and servo motor replacement for only one axis



(Note): For replacing the servo amplifier or the servo motor, refer to "1.4.1(3) Separate repair".

### [Replacement - Phase 2]

Servo amplifier and servo motor replacement for all axes




(Note): MR-J4-B-RJ020 + MR-J4-T20

↓  
MR-J4-B-RJ020 connected to MR-J4-T20 operates as MR-J2S-B. In addition, MR-J4-B-RJ020 can drive both MR-J4 compatible HG servo motors and MR-J2S compatible HC/HA servo motors.

### [Replacement - Phase 3]

Controller and servo system network replacement



(Note): When replacing the servo system network, change the operation mode of MR-J4-B-RJ020 from the J2S mode to the J4 mode.

(Note): Remove MR-J4-T20.


# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (3) Separate repair [QD75M]

The following shows the procedure for the separate repair.


### (a) When the MR-J2S-B servo amplifier has malfunctioned

Replace only the servo amplifier.




### (b) When the HC/HA servo motor has malfunctioned

Simultaneously replace the servo amplifier and the malfunctioned servo motor.



## 1.4.2 Case study for QD75MH

The following describes a case study for migrating the existing system using QD75MH.



### (1) Whole system migration (recommended)

The controller, servo amplifiers, servo motors, and servo system network are replaced simultaneously. Although a large-scale installation is required, the whole system migration allows the system to operate for longer periods. (Refer to section 1.4.2(1).)

### (2) Phased migration (When the whole system migration is difficult due to the installation period and cost.)

The controller is replaced with QD77MS in the first phase, and then the MR-J3-B servo amplifiers are gradually replaced with MR-J4-B. (Refer to section 1.4.2(2).)


### (3) Separate repair

This is a replacement method for when the controller, the servo amplifier, or the servo motor malfunctions. (Refer to section 1.4.2(3).)

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (1) Whole system migration (recommended) [QD75MH]

The following shows the system when the whole system migration takes place.



### [Changes in the system]


Product name	Model before migration	Model after migration
Positioning module	QD75MH	QD77MS
Servo amplifier	MR-J3-B	MR-J4-B
Servo motor	HC/HA/HF series	HG series

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS


## (2) Phased migration [QD75MH]

The following shows the procedure for the phased migration in which the controller is replaced with QD77MS in the first phase, and then the MR-J3-B servo amplifiers are gradually replaced with MR-J4-B in the following phases.


### [Current model]




### [Replacement - Phase 1] Replacement of the controller



### [Replacement - Phase 2] Servo amplifier and servo motor replacement for only one axis



### [Replacement - Phase 3] Servo amplifier and servo motor replacement for all axes, and servo system network replacement



(Note): For replacing the servo amplifier or the servo motor, refer to "1.4.2(3) Separate repair".

(Note): For details of the J3 compatibility mode, refer to "Transition from MELSERVO-J3/J3W Series to J4 Series Handbook".

(Note): When replacing all the servo amplifiers with MR-J4-B, the operation mode can be switched from "J3 compatibility mode" to "J4 mode". The servo system network is also changed from SSCNET III to SSCNET III/H.


# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## (3) Separate repair [QD75MH]

The following shows the procedure for the separate repair.


### (a) When the controller has malfunctioned.

Replace only the controller.



### (b) When the MR-J3-B servo amplifier has malfunctioned.


Replace only the servo amplifier.



# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

---

- (c) When the HC/HA/HF servo motor has malfunctioned  
Simultaneously replace the servo amplifier and the malfunctioned servo motor.





### 1.5 Project Diversion

MELSOFT GX Works2 can convert the projects of QD75M/QD75MH into those of QD77MS.  
For the procedure for project diversion, refer to the section below.

- QD75M ... “2.4 Project Diversion”
- QD75MH ... “3.4 Project Diversion”

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

---

## 1.6 Introduction of QD77MS16

The Simple Motion module QD77MS16 (up to 16 control axes) is also available.

	QD77MS16	QD77MS4	QD77MS2
Maximum number of control axes	16 axes	4 axes	2 axes
Command interface	SSCNETIII/H, SSCNETIII		
Maximum distance between stations [m]	100 (SSCNETIII/H), 50 (SSCNETIII)		
Maximum overall cable distance [m]	1600 (SSCNETIII/H)  800 (SSCNETIII)	400 (SSCNETIII/H)  200 (SSCNETIII)	200 (SSCNETIII/H)  100 (SSCNETIII)
Operation cycle [ms]	0.88, 1.77		

### [Precaution at selection of QD77MS16]

The specification of I/O signals and the buffer memory address are different between QD77MS16 and QD75M1/QD75M2/QD75M4/QD75MH1/QD75MH2/QD75MH4. The I/O signals and the addresses in the sequence programs, etc., need to be replaced considering the differences.






For details, refer to section 3.3 and chapter 5 of "QD77MS Simple Motion Module User's Manual (Positioning Control)".

# 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

## 1.7 Relevant Documents

Refer to the following relevant documents for the replacement.

### 1.7.1 Relevant catalogs

<p>MITSUBISHI ELECTRIC SERVO SYSTEM CONTROLLERS</p>  <p>L(NA)03062</p>	<p>SERVO AMPLIFIERS &amp; MOTORS MELSERVO-J4</p>  <p>L(NA)03058</p>
<p>MELSERVO-J2-Super Transition Guide</p>  <p>L(NA)03091</p>	<p>Transition from MELSERVO-J2-Super/J2M Series to J4 Series Handbook</p>  <p>L(NA)03093</p>
<p>Transition from MELSERVO-J3/J3W Series to J4 Series Handbook</p>  <p>L(NA)03127</p>	

## 1. OVERVIEW OF MIGRATION FROM QD75M/QD75MH TO QD77MS

---

### 1.7.2 Relevant manuals

#### (1) Simple Motion module

Manual title	Manual No.
MELSEC-Q QD77MS Simple Motion Module User's Manual (Positioning Control)	IB-0300185
QD77MS/QD77GF/LD77MS/LD77MH Simple Motion Module User's Manual (Synchronous Control)	IB-0300174
QD77MS2/QD77MS4/QD77MS16 Before Using the Product	BCN-B62008-300E

#### (2) Servo amplifier

Manual title	Manual No.
MR-J4-_B_(-RJ) SERVO AMPLIFIER INSTRUCTION MANUAL	SH-030106
MR-J4 Servo amplifier Instructions and Cautions for Safe Use of AC Servos	IB-0300175E
MELSERVO-J4 Servo amplifier INSTRUCTION MANUAL TROUBLE SHOOTING	SH-030109ENG
MR-J4W2-_B_/MR-J4W3-_B_/MR-J4W2-0303B6 SERVO AMPLIFIER INSTRUCTION MANUAL	SH-030105

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

#### 2.1 Table of Components and Software

Prepare modules, servo amplifiers, and an engineering environment according to the following tables in this section.

Product name	Model before migration		Model after migration
Positioning module	QD75M1	➔	[Simple Motion module]
	QD75M2		QD77MS2 <sup>(Note-1)</sup>
	QD75M4		QD77MS4
External device connector	A6CON1, A6CON2, A6CON3, A6CON4		← (same as the left)
Manual pulse generator	MR-HDP01		MR-HDP01 <sup>(Note-2)</sup>
SSCNET cable <sup>(Note-3)</sup>	MR-HBUS□M MR-J2HBUS□M		[SSCNETIII cable]
			MR-J3BUS□M
			MR-J3BUS□M-A
			MR-J3BUS□M-B <sup>(Note-4)</sup>

(Note-1): The number of control axes is increased from 1 to 2.

(Note-2): The existing MR-HDP01 can be used continuously with QD77MS.

In addition, Mitsubishi Electric has also confirmed the operation of the following manual pulse generator. Contact the manufacturer for details.

Product name	Model name	Description	Manufacturer
Manual pulse generator	UFO-M2-0025-2Z1-B00E	Number of pulses per revolution: 25 pulse/rev (100 pulse/rev after magnification by 4)	Nemicon Corporation

(Note-3): "□" indicates the cable length.

(015: 0.15m, 03: 0.3m, 05: 0.5m, 1: 1m, 5: 5m, 10: 10m, 20: 20m, 30: 30m, 40: 40m, 50: 50m)

(Note-4): For a long distance cable of up to 100 m or an ultra-long bending life cable, contact Mitsubishi Electric System & Service Co., Ltd.

OVERSEAS SERVICE SECTION (Email: [osb.webmaster@melsc.jp](mailto:osb.webmaster@melsc.jp))

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### 2.1.1 Servo amplifiers and servo motors



The servo system network is changed from SSCNET to SSCNETIII/H.

Select a SSCNETIII/H compatible servo amplifier and a servo motor connectable to the selected servo amplifier.

Before migration from QD75M			After migration to QD77MS		
Servo amplifier		Servo motor	Servo amplifier		Servo motor
MR-J2S series	MR-J2S-□B	HC-KFS□ HC-MFS□ HC-SFS□ HC-LFS□ HC-RFS□ HA-LFS□ HC-UFS□	MR-J4 series	MR-J4-□B(-RJ) MR-J4W2-□B MR-J4W3-□B	HG-KR□ HG-MR□ HG-SR□ HG-RR□ HG-UR□ HG-JR□
MR-J2M series	MR-J2M-□DU	HC-KFS□ HC-MFS□ HC-UFS□			
MR-H series	MR-H□B(N)	HA-FF□ HA-FH□ HA-LH□ HA-MH□ HA-SH□ HA-UH□ HC-KF□ HC-MF□ HC-RF□ HC-SF□ HC-UF□ HA-LF□ HA-LH□K			
MR-J2 series	MR-J2-□B	HC-MF□ HA-FF□ HC-SF□ HA-RF□ HC-UF□			
MR-J2-Jr series	MR-J2-03B5	HC-AQ□(B)D HC-AQ□(B)S		MR-J4W2-0303B6	HG-AK□(B)D HG-AK□(B)

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

[Comparison of servo system network]

Item		 SSCNET SERVO SYSTEM CONTROLLER NETWORK	 SSCNET III/H SERVO SYSTEM CONTROLLER NETWORK
Communications medium		Metal cable	Optical fiber cable
Communications speed		5.6 Mbps	150 Mbps
Communications cycle	Send	0.88 ms/1.77 ms/3.55 ms	0.22 ms/0.44 ms/0.88 ms
	Receive	3.55 ms	0.22 ms/0.44 ms/0.88 ms
Number of control axes		Up to 8 axes/line	Up to 16 axes/line
Transmission distance		Maximum overall distance: 30 m	[Standard code for inside panel and standard cable for outside panel] Up to 20 m between stations Maximum overall distance: 320 m (20 m × 16 axes) [Long distance cable] Up to 100 m between stations Maximum overall distance: 1600 m (100 m × 16 axes)

### 2.1.2 Engineering environment (required)

The engineering environment that supports QD77MS is as follows.

Product name	Model	Version
MELSOFT GX Works2	SW1DND-GXW2-E	Ver.1.576A or later
MELSOFT MR Configurator2 <sup>(Note-1)</sup>	SW1DNC-MRC2-E	Ver.1.12N or later

(Note-1): The Servo Setup Software MRZJW3-SETUP161E is required when a combination of MR-J4-B-RJ020 and MR-J4-T20 is used as MR-J2S-B.

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### 2.2 Differences Between QD75M and QD77MS

#### (1) Performance and specifications

▶ An item that requires a setting change at migration.

Item		Model					Points for migration
		QD75M1	QD75M2	QD75M4	QD77MS2	QD77MS4	
Maximum number of control axes		1	2	4	2	4	-
Operation cycle		3.55 ms			0.88 ms/1.77 ms		▶ The change in the operation cycle may change program execution timing. Revise the programs as needed.
Control method	Speed-torque	Not provided			Provided		-
	Synchronous	Not provided			Provided		-
Starting time (1-axis linear control)	Trapezoidal acceleration/ deceleration	6.0 ms			0.88 ms		-
	S-curve acceleration/ deceleration	6.5 ms					
Servo system network		SSCNET			SSCNETIII/H or SSCNETIII		▶ Select a servo system network which is compatible with the devices to be connected such as servo amplifiers.  Pr.97 0: SSCNETIII 1: SSCNETIII/H
Servo amplifier		MR-J2S-□B/MR-J2M-□DU/ MR-H-□B(N)/ MR-J2-□B/MR-J2-03B5			MR-J4-□B(-RJ)/ MR-J4W2-□B/MR-J4W3-□B/ MR-J4W2-0303B6		-
Refresh cycle for monitor data		56.8ms	Feed machine value, Feed speed, Axis feedrate, External input signal, Forced stop input		Operation cycle		-
		3.55ms	Except for above				
Maximum frequency for manual pulse generator/ incremental synchronous encoder input	Signal input form	Voltage output/open collector type			Differential output type, Voltage output/open collector type		-
	1 pulse input magnification	1 to 100			1 to 10000		-
Machine home position return (Home position return method)		4 types (Proximity dog method, Count method1, Count method2, Data set method)			6 types (Proximity dog method, Count method1, Count method2, Data set method, Scale home position signal detection method, Driver home position return method <sup>(Note-1)</sup> )		-



## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS




(Continued)

Item		Model			QD77MS2	QD77MS4	Points for migration
		QD75M1	QD75M2	QD75M4			
External signal selection function		Not provided (External input signal of QD75M only)			<ul style="list-style-type: none"> <li>External input signal of QD77MS (FLS, RLS, DOG, STOP, DI)</li> <li>External input signal of servo amplifier (FLS, RLS, DOG)</li> <li>External input signal via CPU (Buffer memory: FLS, RLS, DOG)</li> </ul>	▶ Confirm there is no problem with the connection of external input signals if the manual pulse generator in use is other than MR-HDP01. (Refer to section 2.3.2.)	
Torque change function		Forward/reverse torque limit value same setting			Forward/reverse torque limit value same setting, individual setting	No need to change the setting since the default setting is "0: Forward/reverse torque limit value same setting".	
Amplifier-less operation function		Not provided			Provided	-	
Virtual servo amplifier function		Not provided			Provided	-	
Mark detection function		Not provided			Provided	-	
Optional data monitor function		Not provided			Provided	-	
Module error collection function		Not provided			Provided	-	
Connect/disconnect of SSCNET communication		Not provided (No need to set)			Provided	-	
History data (start, error, warning)		Time (hour, minute, second)			Date and time (year, month, day, hour, minute, second)	-	
External command signal	Switching signal	CHG signal (Select whether the signal starts positioning or performs speed-position switching with parameter settings)			DI signal (Select whether the signal starts positioning or performs speed-position switching with parameter settings)	The signal name has been changed.	
Speed-position/position-speed switching control		Switched by external command signal (CHG)			Switched by the external command signal (DI) or the proximity dog signal (DOG), which is set with "[Pr.42] External command function selection"	The signal name has been changed.	
Engineering environment		MELSOFT GX Works2 MELSOFT GX Developer MELSOFT GX Configurator-QP			MELSOFT GX Works2 MELSOFT MR Configurator2	-	

(Note-1): The home position return set in driver (servo amplifier) is used.

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### (2) Exterior dimensions and mass

	QD75M1	QD75M2	QD75M4	QD77MS2	QD77MS4	
Exterior dimensions [mm]						
	98.0[H]×27.4[W]×90.0[D]			98.0[H]×27.4[W]×90.0[D]		
Mass [kg]	0.15		0.16		0.15	
Internal current consumption (5 VDC) [A]	0.4			0.6		

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### (3) Parameter setting

▶ An item that requires a setting change at migration.

Function	Specification		Points for migration
	QD75M	QD77MS	
<a href="#">Pr.24</a> Manual pulse generator/ incremental synchronous encoder input selection	Input selection for the manual pulse generator	Input selection for the manual pulse generator/incremental synchronous encoder	The parameter name has been changed.
<a href="#">Pr.55</a> Operation setting for incompletion of home position return	– (Positioning control can be executed without completion of home position return.)	0: Positioning control is not executed. 1: Positioning control is executed.	▶ The default setting is “0: Positioning control is not executed”. Change it to “1: Positioning control is executed”.
<a href="#">Pr.80</a> External input signal selection	– (External input signals of QD75M are used)	0: External input signal of QD77MS 1: External input signal of servo amplifier 2: Buffer memory of QD77MS	–
<a href="#">Pr.82</a> Forced stop valid/invalid selection	– (Forced stop is not available)	0: Valid (External input signal) 1: Invalid 2: Valid (Buffer memory)	▶ The default setting is “0: Valid (External input signal)”. Change it to “1: Invalid”.
<a href="#">Pr.84</a> Restart allowable range when servo OFF to ON	<a href="#">Pr.201</a> Restart allowable range when servo OFF to ON	<a href="#">Pr.84</a> Restart allowable range when servo OFF to ON	The parameter No. has been changed.
<a href="#">Pr.96</a> Operation cycle setting	–	0: 0.88ms 1: 1.77ms	▶ The change in the operation cycle may change program execution timing. Revise the programs as needed.
<a href="#">Pr.97</a> SSCNET setting		0: SSCNETIII 1: SSCNETIII/H	–
Start history	Indicates the start time by hour, minute, and second. <a href="#">Md.5</a> Start (Hour) <a href="#">Md.6</a> Start (Minute: second)	Indicates the start time by year, month, day, hour, minute, and second. <a href="#">Md.54</a> Start (Year: month) <a href="#">Md.5</a> Start (Day: hour) <a href="#">Md.6</a> Start (Minute: second)	More time information ( <a href="#">Md.54</a> ) Year: month and <a href="#">Md.5</a> Day) is added. Review the program as needed.
Axis error occurrence time	Indicates the axis error occurrence time by hour, minute, and second. <a href="#">Md.11</a> Axis error occurrence (Hour) <a href="#">Md.12</a> Axis error occurrence (Minute: second)	Indicates the axis error occurrence time by year, month, day, hour, minute, and second. <a href="#">Md.55</a> Axis error occurrence (Year: month) <a href="#">Md.11</a> Axis error occurrence (Day: hour) <a href="#">Md.12</a> Axis error occurrence (Minute: second)	More time information ( <a href="#">Md.55</a> ) Year: month and <a href="#">Md.11</a> Day) is added. Revise the program as needed.

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

(Continued)

Function	Specification		Points for migration
	QD75M	QD77MS	
Axis warning occurrence time	<p>Indicates the axis warning occurrence time by hour, minute, and second.</p> <p><a href="#">Md.16</a> Axis warning occurrence (Hour)</p> <p><a href="#">Md.17</a> Axis warning occurrence (Minute: second)</p>	<p>Indicates the axis warning occurrence time by year, month, day, hour, minute, and second.</p> <p><a href="#">Md.56</a> Axis warning occurrence (Year: month)</p> <p><a href="#">Md.16</a> Axis warning occurrence (Day: hour)</p> <p><a href="#">Md.17</a> Axis warning occurrence (Minute: second)</p>	<p>More time information (<a href="#">Md.56</a> Year: month and <a href="#">Md.16</a> Day) is added.</p> <p>Review the program as needed.</p>
<a href="#">Md.105</a> Servo parameter	This area stores the parameters currently used by the servo amplifier.	No monitor data for the servo parameters. (The parameters are reflected in the buffer memory for servo parameter settings.)	-
<a href="#">Md.107</a> Parameter error No.	When a servo error occurs, the corresponding bit turns ON, and the error is stored in the buffer memory.	When a servo error occurs, the value corresponding to the parameter No. is stored in <a href="#">Md.107</a> .	The monitoring method of servo error has been changed.
<a href="#">Md.108</a> Servo status	<p>1-word data</p> <p>b0 : READY ON</p> <p>b1 : Servo ON</p> <p>b4 : Zero point pass</p> <p>b5 : In-position</p> <p>b6 : Zero speed</p> <p>b7 : Torque limit</p> <p>b13: Servo alarm</p> <p>b14: Servo warning</p>	<p>2-word data</p> <p>[Low-order buffer memory]</p> <p>b0 : Zero point pass</p> <p>b3 : Zero speed</p> <p>b4 : Speed limit</p> <p>b8 : PID control</p> <p>[High-order buffer memory]</p> <p>b0 : READY ON</p> <p>b1 : Servo ON</p> <p>b2,b3: Control mode</p> <p>b4 : Gain switching</p> <p>b5 : Fully closed loop control</p> <p>b7 : Servo alarm</p> <p>b12 : In-position</p> <p>b13 : Torque limit</p> <p>b14 : Absolute position lost</p> <p>b15 : Servo warning</p>	<p>► The servo status has been changed from 1-word to 2-word data.</p> <p>Review the program as needed.</p>
<a href="#">Cd.24</a> Speed-position switching enable flag	<p>0: Speed control will not be taken over by position control even when the external command signal [CHG] comes ON.</p> <p>1: Speed control will be taken over by position control when the external command signal [CHG] comes ON.</p>	<p>0: Speed control will not be taken over by position control even when the signal set in "<a href="#">Cd.45</a> Speed-position switching device selection" comes ON.</p> <p>1: Speed control will be taken over by position control even when the signal set in "<a href="#">Cd.45</a> Speed-position switching device selection" comes ON.</p>	<p>► The external command signal name has been changed from "CHG" to "DI".</p> <p>In order to use the external command signal [DI] for speed-position switching, set "<a href="#">Cd.45</a> Speed-position switching device selection" to [0: Use the external command signal for switching from speed control to position control].</p>

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

(Continued)

Function	Specification		Points for migration
	QD75M	QD77MS	
<p><b>Cd.26</b> Position-speed switching enable flag</p>	<p>0: Position control will not be taken over by speed control even when the external command signal [CHG] comes ON.</p> <p>1: Position control will be taken over by speed control when the external command signal [CHG] comes ON.</p>	<p>0: Position control will not be taken over by speed control even when the signal set in "<b>Cd.45</b> Speed-position switching device selection" comes ON.</p> <p>1: Position control will be taken over by speed control when the signal set in "<b>Cd.45</b> Speed-position switching device selection" comes ON.</p>	<p>► The external command signal name has been changed from "CHG" to "DI".</p> <p>In order to use the external command signal [DI] for position-speed switching, set "<b>Cd.45</b> Speed-position switching device selection" to [0: Use the external command signal for switching from position control to speed control].</p>
<p><b>Cd.45</b> Speed-position switching device selection</p>	-	<p>[Speed-position switching control]</p> <p>0: Use the external command signal for switching from speed control to position control.</p> <p>1: Use the proximity dog signal for switching from speed control to position control</p> <p>2: Use "<b>Cd.46</b> Speed-position switching command" for switching from speed control to position control</p> <p>[Position-speed switching control]</p> <p>0: Use the external command signal for switching from position control to speed control.</p> <p>1: Use the proximity dog signal for switching from position control to speed control</p> <p>2: Use "<b>Cd.46</b> Speed-position switching command" for switching from position control to speed control</p>	-
<p><b>Cd.46</b> Speed-position switching command</p>	-	<p>[Speed-position switching control]</p> <p>0: Not switch from speed control to position control</p> <p>1: Switch from speed control to position control</p> <p>[Position-speed switching control]</p> <p>0: Not switch from position control to speed control</p> <p>1: Switch from position control to speed control</p>	-

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

(Continued)

Function	Specification		Points for migration
	QD75M	QD77MS	
[Cd.102] SSCNET control command	[Cd.102] Servo amplifier data read 0: Servo amplifier read complete 1: Servo amplifier read request	[Cd.102] SSCNET control command The connect/disconnect command of SSCNET communication is executed.	A change in control data function ▶ QD77MS automatically reads parameters in the servo amplifier, and the read parameters can be checked with the buffer memory.

### (4) Items that need a review or a change following the servo system network change

Items	Differences		Change/revision
	QD75M	QD77MS	
Electronic gear	-	-	Change “[Pr.2] Number of pulses per rotation” and “[Pr.3] Movement amount per rotation” of the basic parameter 1 according to the resolution per the connected servo motor rotation.
Positioning data	-	-	Review the positioning data while taking into account the differences in resolution per the connected servo motor rotation and the setting changes in the electronic gear above.
Powering OFF a servo amplifier in the same network line	If a servo amplifier in SSCNET line is turned OFF, there is no influence on the servo amplifiers on subsequent axes.	If a servo amplifier in SSCNET line is turned OFF, the servo amplifiers on subsequent axes cannot be used.	Use the connect/disconnect function of SSCNET communication to turn OFF/ON the servo amplifier's power supply in SSCNET communication.
Main circuit OFF warning	If the main circuit is turned OFF while “[Cd.100] Servo OFF command” is ON, the main circuit OFF warning 2149(E9) will not occur.	If the main circuit is turned OFF while “[Cd.100] Servo OFF command” is ON, the main circuit OFF warning 2149(E9) will occur.	The warning occurs when the main circuit is turned OFF while “[Cd.100] Servo OFF command” is ON. In order not to turn ON the main circuit OFF warning 2149(E9), change the PC18 servo parameter from “0□□□(H)” to “1□□□(H)”.

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS


---

### 2.3 Connection of Manual Pulse Generator

#### 2.3.1 Comparison of pin layout

The signal layout of the external device connection connector differs between QD75M and QD77MS. Since QD77MS is provided with a 5 VDC power supply output for manual pulse generator, the internal connection of the external input signal cable needs to be changed at replacement.


The following shows the differences in pin layout between QD75M and QD77MS.

QD75M					QD77MS			
Pin No.	Signal name	Pin No.	Signal name		Pin No.	Signal name	Pin No.	Signal name
1B20	PULSER B-	1A20	PULSER B+		1B20	HB	1A20	5V
1B19	PULSER A-	1A19	PULSER A+		1B19	HA	1A19	5V
1B18	No connect	1A18	No connect		1B18	HBL	1A18	HBH
1B17	No connect	1A17	No connect		1B17	HAL	1A17	HAH
1B15	No connect	1A15	No connect		1B15	5V	1A15	5V
1B14	No connect	1A14	No connect		1B14	SG	1A14	SG

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### 2.3.2 External input signal cable replacement

Replace the external input signal cable by following the flowchart below.



#### **[Precaution at replacement of the external input signal cable]**

Set "1: Voltage-output/open-collector type" in "[Pr.89] Manual pulse generator/Incremental synchronous encoder input type selection" if the manual pulse generator/incremental synchronous encoder of voltage-output/open-collector type is used.

The default value is "1: Voltage-output/open-collector type".

Set the signal input form according to the program with "[Pr.24] Manual pulse generator/Incremental synchronous encoder input selection".

**The 5 VDC power supply from the Simple Motion module must not be used** if a separate power supply is applied to the manual pulse generator/incremental synchronous encoder.

If a separate power supply is used, use a stabilized power supply of voltage 5 VDC ( $\pm 5\%$  recommended). Use of a power supply with different voltage may cause a failure.

The connection terminals for the manual pulse generator of QD77MS Simple Motion module (1A20 to 1A17, 1B20 to 1B17) are not electrically isolated. Therefore, **be sure to connect the 0 V (-) of the manual pulse generator/incremental synchronous encoder and the SG of QD77MS when using a separate power supply. Failure to do so may result in malfunction.**



Refer to "MELSEC-Q QD77MS Simple Motion Module User's Manual (Positioning Control)" for details of wiring of the external input signal cable.



## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS



(1) Wiring example for external input signal cable

(a) When the signal input form is A-phase/B-phase



## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

(b) When the signal input form is PULSE/SIGN



## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

### 2.4 Project Diversion

#### 2.4.1 Project diversion procedures by engineering environment


The contents of this document are based on the specifications of the engineering environment (MELSOFT GX Works2 Ver.1.576A). Update to the latest version when replacing.

(1) Procedures for QD75M projects diversion by MELSOFT GX Works2

MELSOFT GX Works2 (Simple Motion module setting tool) cannot directly read QD75M data. Therefore, the diversion is carried out after the data is saved in MELSOFT GX Configurator-QP format.

The following shows the diversion procedure.


- 1) Start MELSOFT GX Works2. Read the project to be diverted.
- 2) Select “QD75M” from “Intelligent function module” in project view of the navigation window, and right-click on it.
- 3) Select “Save GX Configurator-QP Data” from the context menu to open “Save GX Configurator-QP Data” screen.



## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

---

4) Enter the project name, and click [Save].



Saving in MELSOFT GX Configurator-QP format is complete.

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS


### (2) Procedures for QD77MS project creation by MELSOFT GX Works2

The following shows the project creation procedure.


1) Start MELSOFT GX Works2.

2) Create a new Q-series project. Select [Project] → [Intelligent function module] → [New Module] to open [New Module] window.

3) Select “Simple Motion Module” for “Module Type” and the replaced Simple Motion module model for “Module Name” (the setting example below: QD77MS4), and then set “Mount Position” and “Title setting” according to your system.  
Click “OK”.




4) Select [Project] → [Intelligent function module], and double click [Simple Motion module setting] to start up the “Simple Motion Module Setting Tool”.




## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

The following shows the diversion procedure by the Simple Motion Module Setting Tool.

5) Select [Project] → [Import Other Format Data].




6) Select the project files to be diverted in GX Configurator-QP format, and click "Open".



## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

- 7) Set “Module Name”, “Mount Position” and “Title Setting” on [New Module] screen, and click “OK”.

Match the settings in 3) for the “Module Name” and “Mount Position”.




The screenshot shows the 'New Module' dialog box with the following settings:

- Module Selection:**
  - Module Type: Simple Motion Module
  - Module Name: QD77MS4
- Mount Position:**
  - Specify Start X/Y Address: 0000 (H)
  - 1 Slot Occupy [32 points]
- Title Setting:**
  - Title: (empty field)

The 'OK' button is highlighted with a red box.

- 8) Execute the series conversion of the servo amplifier. Select the network to be used for the replaced servo amplifiers, and click [OK].



The screenshot shows the 'MELSOFT Simple Motion Module Setting Tool' dialog box with the following settings:

- Conversion Target Servo Amplifier Setting:**
  - SSCNET Setting:
    - SSCNET III/H
    - SSCNET III
  - MR-J4 Series
- Warning:**
  - Reconsider the following data.
    - Parameter
    - Servo Parameter
    - Input Axis Parameter of Synchronous Control Parameter
  - For details on replace, press F1 key and refer to the help.

The 'OK' button is highlighted with a red box.

(Note): Refer to “MELSEC-Q QD77MS Simple Motion Module User's Manual (Positioning Control)” for the servo system networks supported by the replaced servo amplifiers and SSCNETIII compatible devices (SSCNETIII or SSCNETIII/H).


(Note): When servo parameters settings are changed from “MR-J2S series” to “MR-J4 series”, the parameter conversion is carried out based on conversion rules. However, when converting parameters of the models older than MR-J2S series (MR-H-B, MR-H-BN, MR-J-B, MR-J2-B, MR-J2Jr-B), the servo parameters are initialized.

Refer to “Simple Motion Module Setting Help [Appendix] - [Servo parameter conversion]” for the conversion rules.

## 2. DETAILS OF MIGRATION FROM QD75M TO QD77MS

---

- 9) When the project diversion completion message appears, click “OK”. Be sure to check the imported data.



The diversion is completed.

**Before writing to the Simple Motion module, be sure to confirm the validity of the diverted parameters.**




### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### 3.1 Table of Components and Software

Prepare modules, servo amplifiers, and an engineering environment according to the following tables in this section.

Product name	Model before migration		Model after migration
Positioning module	QD75MH1		[Simple Motion module]
	QD75MH2		QD77MS2 <sup>(Note-1)</sup>
	QD75MH4		QD77MS4
External device connector	A6CON1, A6CON2, A6CON3, A6CON4		← (same as the left)
Manual pulse generator	MR-HDP01		MR-HDP01 <sup>(Note-2)</sup>
SSCNETIII cable <sup>(Note-3)</sup>	MR-J3BUS□M		← (same as the left)
	MR-J3BUS□M-A		
	MR-J3BUS□M-B <sup>(Note-4)</sup>		

(Note-1): The number of control axes is increased from 1 to 2.

(Note-2): The existing MR-HDP01 can be used continuously with QD77MS.

In addition, Mitsubishi Electric has also confirmed the operation of the following manual pulse generator. Contact the manufacturer for details.

Product name	Model name	Description	Manufacturer
Manual pulse generator	UFO-M2-0025-2Z1-B00E	Number of pulses per revolution: 25 pulse/rev (100 pulse/rev after magnification by 4)	Nemicon Corporation

(Note-3): "□" indicates the cable length.

(015: 0.15m, 03: 0.3m, 05: 0.5m, 1: 1m, 5: 5m, 10: 10m, 20: 20m, 30: 30m, 40: 40m, 50: 50m)

(Note-4): For a long distance cable of up to 100 m or an ultra-long bending life cable, contact Mitsubishi Electric System & Service Co., Ltd.

OVERSEAS SERVICE SECTION (Email: [osb.webmaster@melsc.jp](mailto:osb.webmaster@melsc.jp))

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### 3.1.1 Servo amplifiers and servo motors

The servo system network is changed from SSCNETIII to SSCNETIII/H.

Select a SSCNETIII/H compatible servo amplifier and a servo motor connectable to the selected servo amplifier.

##### (1) Servo amplifiers/Rotary servo motors

Before migration from QD75MH				After migration to QD77MS		
Servo amplifier		Rotary servo motor		Servo amplifier		Rotary servo motor
MR-J3 series	MR-J3-□B	HF-KP□	➔	MR-J4 series	MR-J4-□B(-RJ)	HG-KR□
	MR-J3W-□B	HF-MP□			MR-J4W2-□B	HG-MR□
	MR-J3-□BS	HF-SP□			MR-J4W3-□B	HG-SR□
	MR-J3-□B-RJ006	HF-JP□				HG-RR□
		HC-LP□				HG-UR□
		HC-RP□				HG-JR□
HC-UP□						
	HA-LP□					

##### (2) Servo amplifiers/Linear servo motors



Before migration from QD75MH				After migration to QD77MS		
Servo amplifier		Linear servo motor		Servo amplifier		Linear servo motor
MR-J3 series	MR-J3-□B-RJ004	LM-H2□	➔	MR-J4 series	MR-J4-□B(-RJ)	LM-H3□
		LM-F□			MR-J4W2-□B	LM-F□
		LM-K2□			MR-J4W3-□B	LM-K2□
		LM-U2□				LM-U2□

##### (3) Servo amplifiers/Direct drive motors

Before migration from QD75MH				After migration to QD77MS		
Servo amplifier		Direct drive motor		Servo amplifier		Direct drive motor
MR-J3 series	MR-J3-□B-RJ080W	TM-RFM□	➔	MR-J4 series	MR-J4-□B(-RJ)	TM-RFM□
					MR-J4W2-□B	
					MR-J4W3-□B	

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### (4) Comparison of servo system network

Item			
Communications medium		Optical fiber cable	← (same as SSCNETIII)
Communications speed		50 Mbps	150 Mbps
Communications cycle	Send	0.44 ms/0.88 ms	0.22 ms/0.44 ms/0.88 ms
	Receive	0.44 ms/0.88 ms	0.22 ms/0.44 ms/0.88 ms
Number of control axes		Up to 16 axes/line	← (same as SSCNETIII)
Transmission distance		[Standard code for inside panel] Up to 3 m between stations Maximum overall distance: 48 m (3 m × 16 axes)	[Standard code for inside panel and standard cable for outside panel] Up to 20 m between stations Maximum overall distance: 320 m (20 m × 16 axes)
		[Standard cable for outside panel] Up to 20 m between stations Maximum overall distance: 320 m (20 m × 16 axes)	
		[Long distance cable] Up to 50 m between stations Maximum overall distance: 800 m (50 m × 16 axes)	
			[Long distance cable] Up to 100 m between stations Maximum overall distance: 1600 m (100 m × 16 axes)

#### 3.1.2 Engineering environment (required)

The engineering environment that supports QD77MS is as follows.

Product name	Model	Version
MELSOFT GX Works2	SW1DND-GXW2-E	Ver.1.576A or later
MELSOFT MR Configurator2	SW1DNC-MRC2-E	Ver.1.12N or later

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### 3.2 Differences Between QD75MH and QD77MS

##### (1) Performance and specifications

▶ An item that requires a setting change at migration.

Item		Model				Points for migration	
		QD75MH1	QD75MH2	QD75MH4	QD77MS2		QD77MS4
Maximum number of control axes		1	2	4	2	4	-
Operation cycle		1.77 ms			0.88 ms/1.77 ms		▶ The change in the operation cycle may change program execution timing. Revise the programs as needed.
Control method	Speed-torque	Not provided			Provided		-
	Synchronous	Not provided			Provided		-
Starting time (1-axis linear control)	Trapezoidal acceleration/ deceleration	3.5ms			0.88 ms		-
	S-curve acceleration/ deceleration	4.0ms					
Servo system network		SSCNETIII			SSCNETIII/H or SSCNETIII		▶ Select a servo system network which is compatible with the devices to be connected such as servo amplifiers.  [Pr.97] 0: SSCNETIII 1: SSCNETIII/H
Servo amplifier		MR-J3-□B/MR-J3W-□B/ MR-J3-□BS/MR-J3W-□B-RJ006/ MR-J3-□B-RJ004/ MR-J3-□B-RJ080W			MR-J4-□B(-RJ)/ MR-J4W2-□B/MR-J4W3-□B		-
Servo parameter group	SSCNETIII/H	Not provided			PA, PB, PC, PD, PE, PS, PF, Po, PL		-
	SSCNETIII	PA, PB, PC, PD, PE, PS			PA, PB, PC, PD, PE, PS, PF, Po		-
Refresh cycle for monitor data		56.8ms	Feed machine value, Feed speed, Axis feedrate, External input signal, Forced stop input		Operation cycle		-
		1.77ms	Except for above				
Maximum frequency for manual pulse generator/ incremental synchronous encoder input	Signal input form	Voltage output/open collector type			Differential output type, Voltage output/open collector type		-
	1 pulse input magnification	1 to 1000			1 to 10000		-

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS




(Continued)

Item		Model			QD77MS2	QD77MS4	Points for migration
		QD75MH1	QD75MH2	QD75MH4			
Machine home position return (Home position return method)		4 types (Proximity dog method, Count method1, Count method2, Data set method)			6 types (Proximity dog method, Count method1, Count method2, Data set method, Scale home position signal detection method, Driver home position return method (Note-1))		-
External signal selection function		<ul style="list-style-type: none"> <li>External input signal of QD75MH (FLS, RLS, DOG, STOP, DI, CHG)</li> <li>External input signal of servo amplifier (FLS, RLS, DOG)</li> </ul>			<ul style="list-style-type: none"> <li>External input signal of QD77MS (FLS, RLS, DOG, STOP, DI)</li> <li>External input signal of servo amplifier (FLS, RLS, DOG)</li> <li>External input signal via CPU (Buffer memory: FLS, RLS, DOG)</li> </ul>		▶ Confirm there is no problem with the connection of external input signals if the manual pulse generator in use is other than MR-HDP01. (Refer to section 3.3.2.)
Torque change function		Forward/reverse torque limit value same setting			Forward/reverse torque limit value same setting, individual setting		No need to change the setting since the default setting is "0: Forward/reverse torque limit value same setting".
Amplifier-less operation function		Not provided			Provided		-
Virtual servo amplifier function		Not provided			Provided		-
Mark detection function		Not provided			Provided		-
Optional data monitor function		Not provided			Provided		-
Module error collection function		Not provided			Provided		-
Connect/disconnect of SSCNET communication		Not provided (No need to set)			Provided		-
History data (start, error, warning)		Time (hour, minute, second)			Date and time (year, month, day, hour, minute, second)		-
External command signal	Switching signal	CHG signal (Select whether the signal starts positioning or performs speed-position switching with parameter settings)			DI signal (Select whether the signal starts positioning or performs speed-position switching with parameter settings)		The signal name has been changed.
Speed-position/ position-speed switching control		Switched by external command signal (CHG)			Switched by the external command signal (DI) or the proximity dog signal (DOG), which is set with "[Pr.42] External command function selection"		The signal name has been changed.
Engineering environment		MELSOFT GX Works2 MELSOFT GX Developer MELSOFT GX Configurator-QP			MELSOFT GX Works2 MELSOFT MR Configurator2		-

(Note-1): The home position return set in driver (servo amplifier) is used.

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### (2) Exterior dimensions and mass

	QD75MH1	QD75MH2	QD75MH4	QD77MS2	QD77MS4	
Exterior dimensions [mm]						
	98.0[H]×27.4[W]×90.0[D]			98.0[H]×27.4[W]×90.0[D]		
Mass [kg]	0.15		0.16		0.16	
Internal current consumption (5 VDC) [A]	0.6			0.6		

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### (3) Parameter setting

▶ An item that requires a setting change at migration.

Function	Specification		Points for migration
	QD75MH	QD77MS	
<a href="#">Pr.24</a> Manual pulse generator/ incremental synchronous encoder input selection	Input selection for the manual pulse generator	Input selection for the manual pulse generator/incremental synchronous encoder	The parameter name has been changed.
<a href="#">Pr.96</a> Operation cycle setting	-	0: 0.88ms 1: 1.77ms	▶ The change in the operation cycle may change program execution timing. Revise the programs as needed.
<a href="#">Pr.97</a> SSCNET setting	-	0: SSCNETIII 1: SSCNETIII/H	-
Start history	Indicates the start time by hour, minute, and second. <a href="#">Md.5</a> Start (Hour) <a href="#">Md.6</a> Start (Minute: second)	Indicates the start time by year, month, day, hour, minute, and second. <a href="#">Md.54</a> Start (Year: month) <a href="#">Md.5</a> Start (Day: hour) <a href="#">Md.6</a> Start (Minute: second)	More time information ( <a href="#">Md.54</a> ) Year: month and ( <a href="#">Md.5</a> ) Day) has been added. Review the program as needed.
Axis error occurrence time	Indicates the axis error occurrence time by hour, minute, and second. <a href="#">Md.11</a> Axis error occurrence (Hour) <a href="#">Md.12</a> Axis error occurrence (Minute: second)	Indicates the axis error occurrence time by year, month, day, hour, minute, and second. <a href="#">Md.55</a> Axis error occurrence (Year: month) <a href="#">Md.11</a> Axis error occurrence (Day: hour) <a href="#">Md.12</a> Axis error occurrence (Minute: second)	More time information ( <a href="#">Md.55</a> ) Year: month and ( <a href="#">Md.11</a> ) Day) is added. Review the program as needed.
Axis warning occurrence time	Indicates the axis warning occurrence time by hour, minute, and second. <a href="#">Md.16</a> Axis warning occurrence (Hour) <a href="#">Md.17</a> Axis warning occurrence (Minute: second)	Indicates the axis warning occurrence time by year, month, day, hour, minute, and second. <a href="#">Md.56</a> Axis warning occurrence (Year: month) <a href="#">Md.16</a> Axis warning occurrence (Day: hour) <a href="#">Md.17</a> Axis warning occurrence (Minute: second)	More time information ( <a href="#">Md.56</a> ) Year: month and ( <a href="#">Md.16</a> ) Day) is added. Review the program as needed.
<a href="#">Md.113</a> Semi/Fully closed loop status	[Buffer memory address] Axis 1: 881 Axis 2: 981 Axis 3: 1081 Axis 4: 1181	[Buffer memory address] Axis 1: 887 Axis 2: 987 Axis 3: 1087 Axis 4: 1187	The buffer memory address has been changed. The status is also checked with <a href="#">Md.113</a> . Review the program as needed.

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

(Continued)

Function	Specification		Points for migration
	QD75MH	QD77MS	
<p><b>Cd.24</b> Speed-position switching enable flag</p>	<p>0: Speed control will not be taken over by position control even when the external command signal [CHG] comes ON. 1: Speed control will be taken over by position control when the external command signal [CHG] comes ON.</p>	<p>0: Speed control will not be taken over by position control even when the signal set in "<b>Cd.45</b> Speed-position switching device selection" comes ON. 1: Speed control will be taken over by position control even when the signal set in "<b>Cd.45</b> Speed-position switching device selection" comes ON.</p>	<p>▶ The external command signal name has been changed from "CHG" to "DI". In order to use the external command signal [DI] for speed-position switching, set "<b>Cd.45</b> Speed-position switching device selection" to [0: Use the external command signal for switching from speed control to position control].</p>
<p><b>Cd.26</b> Position-speed switching enable flag</p>	<p>0: Position control will not be taken over by speed control even when the external command signal [CHG] comes ON. 1: Position control will be taken over by speed control when the external command signal [CHG] comes ON.</p>	<p>0: Position control will not be taken over by speed control even when the signal set in "<b>Cd.45</b> Speed-position switching device selection" comes ON. 1: Position control will be taken over by speed control when the signal set in "<b>Cd.45</b> Speed-position switching device selection" comes ON.</p>	<p>▶ The external command signal name has been changed from "CHG" to "DI". In order to use the external command signal [DI] for position-speed switching, set "<b>Cd.45</b> Speed-position switching device selection" to [0: Use the external command signal for switching from position control to speed control].</p>



### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

(Continued)

Function	Specification		Points for migration
	QD75MH	QD77MS	
<p>[Cd.45] Speed-position switching device selection</p>	-	<p>[Speed-position switching control] 0: Use the external command signal for switching from speed control to position control. 1: Use the proximity dog signal for switching from speed control to position control 2: Use "[Cd.46] Speed-position switching command" for switching from speed control to position control</p> <p>[Position-speed switching control] 0: Use the external command signal for switching from position control to speed control. 1: Use the proximity dog signal for switching from position control to speed control 2: Use "[Cd.46] Speed-position switching command" for switching from position control to speed control</p>	-
<p>[Cd.46] Speed-position switching command</p>	-	<p>[Speed-position switching control] 0: Not switch from speed control to position control 1: Switch from speed control to position control</p> <p>[Position-speed switching control] 0: Not switch from position control to speed control 1: Switch from position control to speed control</p>	-

#### (4) Items that need a review or a change following the servo system network change

Items	Differences		Change/revision
	QD75MH	QD77MS	
Electronic gear	-	-	Change "[Pr.2] Number of pulses per rotation" and "[Pr.3] Movement amount per rotation" of the basic parameter 1 according to the resolution per the connected servo motor rotation.
Positioning data	-	-	Review the positioning data while taking into account the differences in resolution per the connected servo motor rotation and the setting changes in the electronic gear above.

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS


---

#### 3.3 Connection of Manual Pulse Generator

##### 3.3.1 Comparison of pin layout

The signal layout of the external device connection connector differs between QD75MH and QD77MS. Since QD77MS is provided with a 5 VDC power supply output for manual pulse generator, the internal connection of the external input signal cable needs to be changed at replacement.


The following shows the differences in pin layout between QD75MH and QD77MS.

QD75MH					QD77MS			
Pin No.	Signal name	Pin No.	Signal name		Pin No.	Signal name	Pin No.	Signal name
1B20	PULSER B-	1A20	PULSER B+	1B20	HB	1A20	5V	
1B19	PULSER A-	1A19	PULSER A+	1B19	HA	1A19	5V	
1B18	No connect	1A18	No connect	1B18	HBL	1A18	HBH	
1B17	No connect	1A17	No connect	1B17	HAL	1A17	HAH	

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### 3.3.2 External input signal cable replacement

Replace the external input signal cable by following the flowchart below.



#### [Precaution at replacement of the external input signal cable]

Set "1: Voltage-output/open-collector type" in "[Pr.89] Manual pulse generator/Incremental synchronous encoder input type selection" if the manual pulse generator/incremental synchronous encoder of voltage-output/open-collector type is used.

The default value is "1: Voltage-output/open-collector type".

Set the signal input form according to the program with "[Pr.24] Manual pulse generator/Incremental synchronous encoder input selection".

**The 5 VDC power supply from the Simple Motion module must not be used** if a separate power supply is applied to the manual pulse generator/incremental synchronous encoder.

If a separate power supply is used, use a stabilized power supply of voltage 5 VDC ( $\pm 5\%$  recommended). Use of a power supply with different voltage may cause a failure.


The connection terminals for the manual pulse generator of QD77MS Simple Motion module (1A20 to 1A17, 1B20 to 1B17) are not electrically isolated. Therefore, **be sure to connect the 0 V (-) of the manual pulse generator/incremental synchronous encoder and the SG of QD77MS when using a separate power supply. Failure to do so may result in malfunction.**

Refer to "MELSEC-Q QD77MS Simple Motion Module User's Manual (Positioning Control)" for details of wiring of the external input signal cable.

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS



(1) When the signal input form is A-phase/B-phase (internal power supply use)

(a) 5 V common





### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

(b) 0 V common





### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

(2) When the signal input form is A-phase/B-phase (an external power supply is used for manual pulse generator)





### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

(3) When the signal input form is PULSE/SIGN (internal power supply use)



### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

- (4) When the signal input form is PULSE/SIGN (an external power supply is used for manual pulse generator power)





### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

#### 3.4 Project Diversion


##### 3.4.1 Project diversion procedures by engineering environment

The contents of this document are based on the specifications of the engineering environment (MELSOFT GX Works2 Ver.1.576A). Update to the latest version when replacing.

- (1) Procedures for QD75MH projects diversion by MELSOFT GX Works2  
MELSOFT GX Works2 (Simple Motion module setting tool) cannot directly read QD75MH data. Therefore, the diversion is carried out after the data is saved in MELSOFT GX Configurator-QP format.

The following shows the diversion procedure.


- 1) Start MELSOFT GX Works2. Read the project to be diverted.
- 2) Select “QD75MH” from “Intelligent function module” in project view of the navigation window, and right-click on it.
- 3) Select “Save GX Configurator-QP Data” from the context menu to open “Save GX Configurator-QP Data” screen.



### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

---

4) Enter the project name, and click [Save].



Saving in MELSOFT GX Configurator-QP format is complete.

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS


#### (2) Procedures for QD77MS project creation by MELSOFT GX Works2

The following shows the project creation procedure.


1) Start MELSOFT GX Works2.

2) Create a new Q-series project. Select [Project] → [Intelligent function module] → [New Module] to open [New Module] window.

3) Select “Simple Motion Module” for “Module Type” and the replaced Simple Motion module model for “Module Name” (the setting example below: QD77MS4), and then set “Mount Position” and “Title setting” according to your system.  
Click “OK”.




4) Select [Project] → [Intelligent function module], and double click [Simple Motion module setting] to start up the “Simple Motion Module Setting Tool”.




### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

The following shows the diversion procedure by the Simple Motion Module Setting Tool.

5) Select [Project] → [Import Other Format Data].




6) Select the project files to be diverted in GX Configurator-QP format, and click "Open".



### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

- 7) Set “Module Name”, “Mount Position” and “Title Setting” on [New Module] screen, and click “OK”.

Match the settings in 3) for the “Module Name” and “Mount Position”.




The screenshot shows the 'New Module' dialog box with the following settings:

- Module Selection:**
  - Module Type: Simple Motion Module
  - Module Name: QD77MS4
- Mount Position:**
  - Specify Start X/Y Address: 0000 (H)
  - 1 Slot Occupy [32 points]
- Title Setting:**
  - Title: (empty field)

The 'OK' button is highlighted with a red box.

- 8) Execute the series conversion of the servo amplifier. Select the network to be used for the replaced servo amplifiers, and click [OK].



The screenshot shows the 'MELSOFT Simple Motion Module Setting Tool' dialog box with the following settings:

- Conversion Target Servo Amplifier Setting:**
  - SSCNET Setting:
    - SSCNET III/H
    - SSCNET III
  - MR-J4 Series
- Warning:**
  - Reconsider the following data.
  - Parameter
  - Servo Parameter
  - Input Axis Parameter of Synchronous Control Parameter
  - For details on replace, press F1 key and refer to the help.

The 'OK' button is highlighted with a red box.

(Note): Refer to “MELSEC-Q QD77MS Simple Motion Module User's Manual (Positioning Control)” for the servo system networks supported by the replaced servo amplifiers and SSCNETIII compatible devices (SSCNETIII or SSCNETIII/H).


(Note): When servo parameters settings are changed from “MR-J3 series” to “MR-J4 series”, the parameter conversion is carried out based on conversion rules.

Refer to “Simple Motion Module Setting Help [Appendix] - [Servo parameter conversion]” for the conversion rules.

### 3. DETAILS OF MIGRATION FROM QD75MH TO QD77MS

---

- 9) When the project diversion completion message appears, click “OK”. Be sure to check the imported data.



The diversion is completed.

**Before writing to the Simple Motion module, be sure to confirm the validity of the diverted parameters.**

## APPENDICES

### Appendix 1 List of Buffer Memory Addresses

This section shows buffer memory address lists and the calculation method of the addresses.

- 1) Do not use the buffer memory addresses not described in the lists because they are for manufacturer setting.
- 2) Refer to “Simple Motion Moduel Setting Tool Help” of MELSOFT GX Works2 for buffer memory addresses of positioning data.
- 3) Refer to “MELSEC-Q/L QD77MS/QD77GF/LD77MS/LD77MH Simple Motion Moduel User’s Manual (Synchronous Control)” for the buffer memory addresses for synchronous control.

[Caluculation method of buffer memory address]

(a) “n” such as “1+150n” in the table indicates the numerical value corresponding to the axis No.

Ex.) For axis No. 16A-1

$$1+150n \text{ ([Pr.4] Unit magnification (AM))} = 1+150 \times 15 = 2251$$

(b) “p” such as “4012+5p” in the table indicates the pointer No.

Ex.) For pointer No.15

$$4012+5p \text{ ([Md.3] Start information)} = 4012+5 \times 15 = 4087$$

(c) “k” such as “54002+20k” in the table indicates the mark detection setting No.

Ex.) For mark detection setting No. 16

$$54002+20k \text{ ([Pr.802] Mark detection data type)} = 54002+20 \times 15 = 54302$$

# APPENDICES

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area	
QD77MS2 QD77MS4	QD77MS16				
0+150n		○	[Pr.1] Unit setting	Basic parameters 1	Positioning parameters
1+150n		○	[Pr.4] Unit magnification (AM)		
2+150n 3+150n		○	[Pr.2] Number of pulses per rotation (AP)		
4+150n 5+150n		○	[Pr.3] Movement amount per rotation (AL)		
6+150n 7+150n		○	[Pr.7] Bias speed at start		
10+150n 11+150n		○	[Pr.8] Speed limit value	Basic parameters 2	
12+150n 13+150n		○	[Pr.9] Acceleration time 0		
14+150n 15+150n		○	[Pr.10] Deceleration time 0		
17+150n		○	[Pr.11] Backlash compensation amount	Detailed parameters 1	
18+150n 19+150n		○	[Pr.12] Software stroke limit upper limit value		
20+150n 21+150n		○	[Pr.13] Software stroke limit lower limit value		
22+150n		○	[Pr.14] Software stroke limit selection		
23+150n		○	[Pr.15] Software stroke limit valid/invalid setting		
24+150n 25+150n		○	[Pr.16] Command in-position width		
26+150n		○	[Pr.17] Torque limit setting value		
27+150n		○	[Pr.18] M code ON signal output timing		
28+150n		○	[Pr.19] Speed switching mode		
29+150n		○	[Pr.20] Interpolation speed designation method		
30+150n		○	[Pr.21] Feed current value during speed control		
31+150n		○	[Pr.22] Input signal logic selection		
32+150n		△	[Pr.80] External input signal selection		
33		○	[Pr.24] Manual pulse generator/Incremental synchronous encoder input selection		
34+150n		○	[Pr.81] Speed-position function selection		
35		○	[Pr.82] Forced stop valid/invalid selection		



# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area	
QD77MS2 QD77MS4	QD77MS16			Detailed parameters 2	Positioning parameters
36+150n 37+150n		○	[Pr.25] Acceleration time 1		
38+150n 39+150n		○	[Pr.26] Acceleration time 2		
40+150n 41+150n		○	[Pr.27] Acceleration time 3		
42+150n 43+150n		○	[Pr.28] Deceleration time 1		
44+150n 45+150n		○	[Pr.29] Deceleration time 2		
46+150n 47+150n		○	[Pr.30] Deceleration time 3		
48+150n 49+150n		○	[Pr.31] JOG speed limit value		
50+150n		○	[Pr.32] JOG operation acceleration time selection		
51+150n		○	[Pr.33] JOG operation deceleration time selection		
52+150n		○	[Pr.34] Acceleration/deceleration process selection		
53+150n		○	[Pr.35] S-curve ratio		
54+150n 55+150n		○	[Pr.36] Rapid stop deceleration time		
56+150n		○	[Pr.37] Stop group 1 rapid stop selection		
57+150n		○	[Pr.38] Stop group 2 rapid stop selection		
58+150n		○	[Pr.39] Stop group 3 rapid stop selection		
59+150n		○	[Pr.40] Positioning complete signal output time		
60+150n 61+150n		○	[Pr.41] Allowable circular interpolation error width		
62+150n		○	[Pr.42] External command function selection		
63+150n		○	[Pr.83] Speed control 10 x multiplier setting for degree axis		
64+150n 65+150n		○	[Pr.84] Restart allowable range when servo OFF to ON		
67		○	[Pr.89] Manual pulse generator/incremental synchronous encoder input type selection		
68+150n		○	[Pr.90] Operation setting for speed-torque control mode		
	69+150n	×	[Pr.95] External command signal selection		

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area	
QD77MS2 QD77MS4	QD77MS16			HPR basic parameters	HPR parameters
70+150n		○	[Pr.43] HPR method		
71+150n		○	[Pr.44] HPR direction		
72+150n 73+150n		○	[Pr.45] HP address		
74+150n 75+150n		○	[Pr.46] HPR speed		
76+150n 77+150n		○	[Pr.47] Creep speed		
78+150n		○	[Pr.48] HPR retry		
80+150n 81+150n		○	[Pr.50] Setting for the movement amount after proximity dog ON	HPR detailed parameters	
82+150n		○	[Pr.51] HPR acceleration time selection		
83+150n		○	[Pr.52] HPR deceleration time selection		
84+150n 85+150n		○	[Pr.53] HP shift amount		
86+150n		○	[Pr.54] HPR torque limit value		
87+150n		○	[Pr.55] Operation setting for incompleteness of HPR		
88+150n		○	[Pr.56] Speed designation during HP shift		
89+150n		○	[Pr.57] Dwell time during HPR retry	Expansion parameter	
100+150n		○	[Pr.91] Optional data monitor: Data type setting 1		
101+150n		○	[Pr.92] Optional data monitor: Data type setting 2		
102+150n		○	[Pr.93] Optional data monitor: Data type setting 3		
103+150n		×	[Pr.94] Optional data monitor: Data type setting 4		
147	105	○	[Pr.96] Operation cycle setting		
106		○	[Pr.97] SSCNET setting		
114		○	[Pr.114] External command signal compensation valid/invalid setting		

# APPENDICES

(continued)

p: Pointer No., ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area		
QD77MS2 QD77MS4	QD77MS16					
1200	4000	○	[Md.1] In test mode flag	System monitor data Monitor data		
1206	4006	○	[Md.130] OS version			
1207	4007					
1208	4008	○	[Md.134] Operation time			
1209	4009	○	[Md.135] Maximum operation time			
1211	4011	○	[Md.131] Digital oscilloscope running flag			
1212+5p	4012+5p	○	[Md.3] Start information		Start history	
1213+5p	4013+5p		[Md.4] Start No.			
1440+p	4240+p		[Md.54] Start Year: month			
1214+5p	4014+5p		[Md.5] Start Day: hour			
1215+5p	4015+5p		[Md.6] Start Minute: second			
1216+5p	4016+5p		[Md.7] Error judgment			
1292	4092		[Md.8] Start history pointer			
1293+4p	4093+4p	○	[Md.9] Axis in which the error occurred		Error history	
1294+4p	4094+4p		[Md.10] Axis error No.			
31300+p		○	[Md.57] Servo alarm			
31333+p		○	[Md.61] Driver operation alarm number			
1456+p	4256+p	○	[Md.55] Axis error occurrence (Year: month)			
1295+4p	4095+4p	○	[Md.11] Axis error occurrence (Day: hour)			
1296+4p	4096+4p	○	[Md.12] Axis error occurrence (Minute: second)			
1357	4157	○	[Md.13] Error history pointer			
1358+4p	4158+4p	○	[Md.14] Axis in which the warning occurred			Warning history
1359+4p	4159+4p	○	[Md.15] Axis warning No.			
31316+p		○	[Md.58] Servo warning			
1472+p	4272+p	○	[Md.56] Axis warning occurrence (Year: month)			
1360+4p	4160+4p	○	[Md.16] Axis warning occurrence (Day: hour)			
1361+4p	4161+4p	○	[Md.17] Axis warning occurrence (Minute: second)			
1422	4222	○	[Md.18] Warning history pointer			
1424	4224	○	[Md.19] Number of write accesses to flash ROM			
1425	4225					
1431	4231	○	[Md.50] Forced stop input			
1432	4232	○	[Md.51] Amplifier-less operation mode status			
1433	4233	○	[Md.53] SSCNET control status			
1434	4234	○	[Md.52] Communication between amplifiers axes searching flag			
1435	4235	○	[Md.59] Module information			
1438	4238	○	[Md.132] Operation cycle setting			
1439	4239	○	[Md.133] Operation cycle over flag			

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area	
QD77MS2 QD77MS4	QD77MS16				
800+100n 801+100n	2400+100n 2401+100n	○	[Md.20] Feed current value	Axis monitor data	
802+100n 803+100n	2402+100n 2403+100n	○	[Md.21] Feed machine value		
804+100n 805+100n	2404+100n 2405+100n	○	[Md.22] Feedrate		
806+100n	2406+100n	○	[Md.23] Axis error No.		
807+100n	2407+100n	○	[Md.24] Axis warning No.		
808+100n	2408+100n	○	[Md.25] Valid M code		
809+100n	2409+100n	○	[Md.26] Axis operation status		
810+100n 811+100n	2410+100n 2411+100n	○	[Md.27] Current speed		
812+100n 813+100n	2412+100n 2413+100n	○	[Md.28] Axis feedrate		
814+100n 815+100n	2414+100n 2415+100n	○	[Md.29] Speed-position switching control positioning movement amount		
816+100n	2416+100n	○	[Md.30] External input signal		
817+100n	2417+100n	△	[Md.31] Status		
818+100n 819+100n	2418+100n 2419+100n	○	[Md.32] Target value		
820+100n 821+100n	2420+100n 2421+100n	○	[Md.33] Target speed		
824+100n 825+100n	2424+100n 2425+100n	○	[Md.34] Movement amount after proximity dog ON		
826+100n	2426+100n	○	[Md.35] Torque limit stored value/forward torque limit stored value		
827+100n	2427+100n	○	[Md.36] Special start data instruction code setting value		
828+100n	2428+100n	○	[Md.37] Special start data instruction parameter setting value		
829+100n	2429+100n	○	[Md.38] Start positioning data No. setting value.		
830+100n	2430+100n	○	[Md.39] In speed limit flag		
831+100n	2431+100n	○	[Md.40] In speed change processing flag		
832+100n	2432+100n	○	[Md.41] Special start repetition counter		
833+100n	2433+100n	○	[Md.42] Control system repetition counter		
834+100n	2434+100n	○	[Md.43] Start data pointer being executed		
835+100n	2435+100n	○	[Md.44] Positioning data No. being executed		
836+100n	2436+100n	○	[Md.45] Block No. being executed		
837+100n	2437+100n	○	[Md.46] Last executed positioning data No.		
838+100n	2438+100n	△	[Md.47] Positioning data being executed		
839+100n	2439+100n	○			Positioning identifier
840+100n	2440+100n	○			M code
					Dwell time
842+100n 843+100n	2442+100n 2443+100n	○			Axis to be interpolated
					Command speed
844+100n 845+100n	2444+100n 2445+100n	○			Positioning address
846+100n 847+100n	2446+100n 2447+100n	○	Arc address		
848+100n 849+100n	2448+100n 2449+100n	○	[Md.100] HPR re-travel value		Monitor data

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
850+100n 851+100n	2450+100n 2451+100n	○	[Md.101] Real current value	Axis monitor data Monitor data
852+100n 853+100n	2452+100n 2453+100n	○	[Md.102] Deviation counter value	
854+100n 855+100n	2454+100n 2455+100n	○	[Md.103] Motor rotation speed	
856+100n	2456+100n	○	[Md.104] Motor current value	
858+100n	2458+100n	○	[Md.125] Servo status3	
864+100n 865+100n 866+100n 867+100n 868+100n 869+100n	2464+100n 2465+100n 2466+100n 2467+100n 2468+100n 2469+100n	○	[Md.106] Servo amplifier software No.	
870+100n	2470+100n	○	[Md.107] Parameter error No.	
876+100n 877+100n	2476+100n 2477+100n	○	[Md.108] Servo status	
878+100n	2478+100n	○	[Md.109] Regenerative load ratio/Optional data monitor output 1	
879+100n	2479+100n	○	[Md.110] Effective load torque/Optional data monitor output 2	
880+100n	2480+100n	○	[Md.111] Peak torque ratio/Optional data monitor output 3	
881+100n	2481+100n	○	[Md.112] Optional data monitor output 4	
887+100n	2487+100n	○	[Md.113] Semi/Fully closed loop status	
888+100n	2488+100n	○	[Md.114] Servo alarm	
890+100n	2490+100n	○	[Md.116] Encoder option information	
891+100n	2491+100n	○	[Md.120] Reverse torque limit stored value	
892+100n 893+100n	2492+100n 2493+100n	○	[Md.122] Speed during command	
894+100n	2494+100n	○	[Md.123] Torque during command	
895+100n	2495+100n	○	[Md.124] Control mode switching status	
899+100n	2499+100n	○	[Md.48] Deceleration start flag	
59300+100n		○	[Md.500] Servo status7	
59302+100n		○	[Md.502] Driver operation alarm number	

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
1500+100n	4300+100n	○	[Cd.3] Positioning start No.	Axis control data
1501+100n	4301+100n	○	[Cd.4] Positioning starting point No.	
1502+100n	4302+100n	○	[Cd.5] Axis error reset	
1503+100n	4303+100n	○	[Cd.6] Restart command	
1504+100n	4304+100n	○	[Cd.7] M code OFF request	
1505+100n	4305+100n	○	[Cd.8] External command valid	
1506+100n	4306+100n	○	[Cd.9] New current value	
1507+100n	4307+100n			
1508+100n	4308+100n	○	[Cd.10] New acceleration time value	
1509+100n	4309+100n			
1510+100n	4310+100n	○	[Cd.11] New deceleration time value	
1511+100n	4311+100n			
1512+100n	4312+100n	○	[Cd.12] Acceleration/deceleration time change value during speed change, enable/disable	
1513+100n	4313+100n	○	[Cd.13] Positioning operation speed override	
1514+100n	4314+100n	○	[Cd.14] New speed value	
1515+100n	4315+100n			
1516+100n	4316+100n	○	[Cd.15] Speed change request	
1517+100n	4317+100n	○	[Cd.16] Inching movement amount	
1518+100n	4318+100n	○	[Cd.17] JOG speed	
1519+100n	4319+100n			
1520+100n	4320+100n	○	[Cd.18] Interrupt request during continuous operation	
1521+100n	4321+100n	○	[Cd.19] HPR request flag OFF request	
1522+100n	4322+100n	○	[Cd.20] Manual pulse generator 1 pulse input magnification	
1523+100n	4323+100n			
1524+100n	4324+100n	○	[Cd.21] Manual pulse generator enable flag	
1525+100n	4325+100n	○	[Cd.22] New torque value/forward new torque value	
1526+100n	4326+100n	○	[Cd.23] Speed-position switching control movement amount change register	
1527+100n	4327+100n			
1528+100n	4328+100n	○	[Cd.24] Speed-position switching enable flag	
1530+100n	4330+100n	○	[Cd.25] Position-speed switching control speed change register	
1531+100n	4331+100n			
1532+100n	4332+100n	○	[Cd.26] Position-speed switching enable flag	
1534+100n	4334+100n	○	[Cd.27] Target position change value (New address)	
1535+100n	4335+100n			
1536+100n	4336+100n	○	[Cd.28] Target position change value (New speed)	
1537+100n	4337+100n			
1538+100n	4338+100n	○	[Cd.29] Target position change request flag	
	4339+100n	×	[Cd.43] Simultaneous starting axis	
1540+100n		×	[Cd.30] Simultaneous starting axis start data No. (axis 1 start data No.)	
	4340+100n		[Cd.30] Simultaneous starting own axis start data No.	
1541+100n		×	[Cd.31] Simultaneous starting axis start data No. (axis 2 start data No.)	
	4341+100n		[Cd.31] Simultaneous starting axis start data No.1	
1542+100n		×	[Cd.32] Simultaneous starting axis start data No. (axis 3 start data No.)	
	4342+100n		[Cd.32] Simultaneous starting axis start data No.2	
1543+100n		×	[Cd.33] Simultaneous starting axis start data No. (axis 4 start data No.)	
	4343+100n		[Cd.33] Simultaneous starting axis start data No.3	

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
1544+100n	4344+100n	○	[Cd.34] Step mode	Axis control data Control data
1545+100n	4345+100n	○	[Cd.35] Step valid flag	
1546+100n	4346+100n	○	[Cd.36] Step start information	
1547+100n	4347+100n	○	[Cd.37] Skip command	
1548+100n	4348+100n	○	[Cd.38] Teaching data selection	
1549+100n	4349+100n	○	[Cd.39] Teaching positioning data No.	
1550+100n	4350+100n	○	[Cd.40] ABS direction in degrees	
1551+100n	4351+100n	○	[Cd.100] Servo OFF command	
1552+100n	4352+100n	○	[Cd.101] Torque output setting value	
1554+100n	4354+100n	○	[Cd.130] Servo parameter write request	
1555+100n	4355+100n	○	[Cd.131] Parameter No. (Setting for servo parameters to be changed)	
1556+100n	4356+100n	○	[Cd.132] Change data	
1557+100n	4357+100n			
1558+100n	4358+100n	○	[Cd.133] Semi/Fully closed loop switching request	
1559+100n	4359+100n	○	[Cd.108] Gain switching command flag	
1563+100n	4363+100n	○	[Cd.112] Torque change function switching request	
1564+100n	4364+100n	○	[Cd.113] New reverse torque value	
1565+100n	4365+100n	○	[Cd.136] PI-PID switching request	
1566+100n	4366+100n	○	[Cd.45] Speed-position switching device selection	
1567+100n	4367+100n	○	[Cd.46] Speed-position switching command	
1574+100n	4374+100n	○	[Cd.138] Control mode switching request	
1575+100n	4375+100n	○	[Cd.139] Control mode setting	
1576+100n	4376+100n	○	[Cd.140] Command speed at speed control mode	
1577+100n	4377+100n			
1578+100n	4378+100n	○	[Cd.141] Acceleration time at speed control mode	
1579+100n	4379+100n	○	[Cd.142] Deceleration time at speed control mode	
1580+100n	4380+100n	○	[Cd.143] Command torque at torque control mode	
1581+100n	4381+100n	○	[Cd.144] Torque time constant at torque control mode (Forward direction)	
1582+100n	4382+100n	○	[Cd.145] Torque time constant at torque control mode (Negative direction)	
1584+100n	4384+100n	○	[Cd.146] Speed limit value at torque control mode	
1585+100n	4385+100n			
1586+100n	4386+100n	○	[Cd.147] Speed limit value at continuous operation to torque control mode	
1587+100n	4387+100n			
1588+100n	4388+100n	○	[Cd.148] Acceleration time at continuous operation to torque control mode	
1589+100n	4389+100n	○	[Cd.149] Deceleration time at continuous operation to torque control mode	
1590+100n	4390+100n	○	[Cd.150] Target torque at continuous operation to torque control mode	
1591+100n	4391+100n	○	[Cd.151] Torque time constant at continuous operation to torque control mode (Forward direction)	
1592+100n	4392+100n	○	[Cd.152] Torque time constant at continuous operation to torque control mode (Negative direction)	
1593+100n	4393+100n	○	[Cd.153] Control mode auto-shift selection	
1594+100n	4394+100n	○	[Cd.154] Control mode auto-shift parameter	
1595+100n	4395+100n			

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area	
QD77MS2 QD77MS4	QD77MS16			System control data	Control data
1900	5900	○	[Cd.1] Flash ROM write request		
1901	5901	○	[Cd.2] Parameter initialization request		
1905	5905	○	[Cd.41] Deceleration start flag valid		
1907	5907	○	[Cd.42] Stop command processing for deceleration stop selection		
1909	5909	○	[Cd.47] QD75MH initial value setting request		
1926	5926	○	[Cd.137] Amplifier-less operation mode switching request		
1928	5928 5929 5930 5931	△	[Cd.44] External input signal operation device (Axis 1 to 16)	Axis expansion control data	Control data
1945	5945	○	[Cd.158] Forced stop input		
1932	5932	○	[Cd.102] SSCNET control command		
	30100+10n	×	[Cd.180] Axis stop		
	30101+10n	×	[Cd.181] Forward run JOG start	Axis expansion control data	Control data
	30102+10n	×	[Cd.182] Reverse run JOG start		
	30103+10n	×	[Cd.183] Execution prohibition flag		



# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
2000+6000n	6000+1000n	○	[Da.1] Operation pattern	Positioning identifier
		○	[Da.2] Control method	
		○	[Da.3] Acceleration time No.	
		○	[Da.4] Deceleration time No.	
		×	[Da.5] Axis to be interpolated	
2001+6000n	6001+1000n	○	[Da.10] M code/condition data No. /Number of LOOP to LEND repetitions	No.1  Positioning data Data for positioning
2002+6000n	6002+1000n	○	[Da.9] Dwell time/JUMP destination positioning data No.	
/	6003+1000n	×	[Da.20] Axis to be interpolated No.1	
			[Da.21] Axis to be interpolated No.2	
			[Da.22] Axis to be interpolated No.3	
2004+6000n 2005+6000n	6004+1000n 6005+1000n	○	[Da.8] Command speed	
2006+6000n 2007+6000n	6006+1000n 6007+1000n	○	[Da.6] Positioning address/movement amount	
2008+6000n 2009+6000n	6008+1000n 6009+1000n	○	[Da.7] Arc address	
2010+6000n to 2019+6000n	6010+1000n to 6019+1000n	△	No.2	
2020+6000n to 2029+6000n	6020+1000n to 6029+1000n	△	No.3	
to	to	to	to	
2990+6000n to 2999+6000n	6990+1000n to 6999+1000n	△	No.100	
3000+6000n to 3009+6000n	Set with GX Works2	△	No.101	
to		to	to	
7990+6000n to 7999+6000n		△	No.600	

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address				Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area				
QD77MS2 QD77MS4		QD77MS16								
26000 +1000n	/	22000 +400n	/	○	[Da.11] Shape [Da.12] Start data No.	1st point	Block start data			
/	26050 +1000n	/	22050 +400n	○	[Da.13] Special start instruction [Da.14] Parameter					
26001 +1000n	26051 +1000n	22001 +400n	22051 +400n	○	2nd point	Block start data				
26002 +1000n	26052 +1000n	22002 +400n	22052 +400n	○	3rd point					
to		to		to	to					
26049 +1000n	26099 +1000n	22049 +400n	22099 +400n	○	50th point					
26100+1000n		22100+400n		○	[Da.15] Condition target	Condition data				
				△	[Da.16] Condition operator					
/		22101+400n		×	[Da.23] Number of simultaneous starting axes	Simultaneous starting axis No.1	Starting block 0			
					[Da.24] Simultaneous starting axis No.1					
					[Da.25] Simultaneous starting axis No.2					
					[Da.26] Simultaneous starting axis No.3					
26102+1000n 26103+1000n		22102+400n 22103+400n		○	[Da.17] Address	No.1	Starting block 0			
26104+1000n 26105+1000n		22104+400n 22105+400n		△	[Da.18] Parameter 1					
26106+1000n 26107+1000n		22106+400n 22107+400n		△	[Da.19] Parameter 2					
26110+1000n to 26119+1000n		22110+400n to 22119+400n		△	No.2	Condition data				
26120+1000n to 26129+1000n		22120+400n to 22129+400n		△	No.3					
to		to		to	to					
26190+1000n to 26199+1000n		22190+400n to 22199+400n		△	No.10					
26200+1000n to 26299+1000n		22200+400n to 22299+400n		○	Block start data	Starting block 1				
26300+1000n to 26399+1000n		22300+400n to 22399+400n		△	Condition data	Starting block 2				
26400+1000n to 26499+1000n		Set with GX Works2		○	Block start data	Starting block 3				
26500+1000n to 26599+1000n				△	Condition data	Starting block 4				
26600+1000n to 26699+1000n				○	Block start data					
26700+1000n to 26799+1000n				△	Condition data					
26800+1000n to 26899+1000n				○	Block start data					
26900+1000n to 26999+1000n				△	Condition data					

# APPENDICES

(continued)

Mark detection setting No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area	
QD77MS2 QD77MS4	QD77MS16				
54000+20k		○	[Pr.800] Mark detection signal setting	Mark detection setting parameters	
54001+20k		○	[Pr.801] Mark detection signal compensation time		
54002+20k		○	[Pr.802] Mark detection data type		
54003+20k		○	[Pr.803] Mark detection data axis No.		
54004+20k		○	[Pr.804] Mark detection data buffer memory No.		
54005+20k					
54006+20k		○	[Pr.805] Latch data range upper limit value		
54007+20k					
54008+20k		○	[Pr.806] Latch data range lower limit value		
54009+20k					
54010+20k		○	[Pr.807] Mark detection mode setting		
54640+10k		○	[Cd.800] Number of mark detection clear request	Mark detection control data	
54641+10k		○	[Cd.801] Mark detection invalid flag		
54642+10k		○	[Cd.802] Latch data range change request		
54960+80k		○	[Md.800] Number of mark detection	Mark detection monitor data	
54962+80k		○	[Md.801] Mark detection data storage area (1 to 32)		1
54963+80k		○			2
54964+80k		○			3
54965+80k		○			
54966+80k		○			to
54967+80k		○			
to		○			32
55024+80k		○			
55025+80k		○			

# APPENDICES

The following list shows buffer memory addresses corresponding to servo parameters.

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
30100+200n	28400+100n	○	[Pr.100] Servo series	—
30101+200n	28401+100n	○	—	PA01
30102+200n	28402+100n	○	—	PA02
30103+200n	28403+100n	○	—	PA03
30104+200n	28404+100n	○	—	PA04
30105+200n	28405+100n	○	—	PA05
30106+200n	28406+100n	○	—	PA06
30107+200n	28407+100n	○	—	PA07
30108+200n	28408+100n	○	—	PA08
30109+200n	28409+100n	○	—	PA09
30110+200n	28410+100n	○	—	PA10
30111+200n	28411+100n	○	—	PA11
30112+200n	28412+100n	○	—	PA12
30113+200n	28413+100n	○	—	PA13
30114+200n	28414+100n	○	—	PA14
30115+200n	28415+100n	○	—	PA15
30116+200n	28416+100n	○	—	PA16
30117+200n	28417+100n	○	—	PA17
30118+200n	28418+100n	○	—	PA18
30119+200n	28419+100n	○	—	PB01
30120+200n	28420+100n	○	—	PB02
30121+200n	28421+100n	○	—	PB03
30122+200n	28422+100n	○	—	PB04
30123+200n	28423+100n	○	—	PB05
30124+200n	28424+100n	○	—	PB06
30125+200n	28425+100n	○	—	PB07
30126+200n	28426+100n	○	—	PB08
30127+200n	28427+100n	○	—	PB09
30128+200n	28428+100n	○	—	PB10
30129+200n	28429+100n	○	—	PB11
30130+200n	28430+100n	○	—	PB12
30131+200n	28431+100n	○	—	PB13
30132+200n	28432+100n	○	—	PB14
30133+200n	28433+100n	○	—	PB15
30134+200n	28434+100n	○	—	PB16
30135+200n	28435+100n	○	—	PB17
30136+200n	28436+100n	○	—	PB18
30137+200n	28437+100n	○	—	PB19
30138+200n	28438+100n	○	—	PB20
30139+200n	28439+100n	○	—	PB21
30140+200n	28440+100n	○	—	PB22

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
30141+200n	28441+100n	○	—	Servo parameters
30142+200n	28442+100n	○	—	
30143+200n	28443+100n	○	—	
30144+200n	28444+100n	○	—	
30145+200n	28445+100n	○	—	
30146+200n	28446+100n	○	—	
30147+200n	28447+100n	○	—	
30148+200n	28448+100n	○	—	
30149+200n	28449+100n	○	—	
30150+200n	28450+100n	○	—	
30151+200n	28451+100n	○	—	
30152+200n	28452+100n	○	—	
30153+200n	28453+100n	○	—	
30154+200n	28454+100n	○	—	
30155+200n	28455+100n	○	—	
30156+200n	28456+100n	○	—	
30157+200n	28457+100n	○	—	
30158+200n	28458+100n	○	—	
30159+200n	28459+100n	○	—	
30160+200n	28460+100n	○	—	
30161+200n	28461+100n	○	—	
30162+200n	28462+100n	○	—	
30163+200n	28463+100n	○	—	
30164+200n	28464+100n	○	—	
30165+200n	28465+100n	○	—	
30166+200n	28466+100n	○	—	
30167+200n	28467+100n	○	—	
30168+200n	28468+100n	○	—	
30169+200n	28469+100n	○	—	
30170+200n	28470+100n	○	—	
30171+200n	28471+100n	○	—	
30172+200n	28472+100n	○	—	
30173+200n	28473+100n	○	—	
30174+200n	28474+100n	○	—	
30175+200n	28475+100n	○	—	
30176+200n	28476+100n	○	—	
30177+200n	28477+100n	○	—	
30178+200n	28478+100n	○	—	
30179+200n	28479+100n	○	—	
30180+200n	28480+100n	○	—	
30181+200n	28481+100n	○	—	
30182+200n	28482+100n	○	—	
30183+200n	28483+100n	○	—	

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item		Memory area
QD77MS2 QD77MS4	QD77MS16				
30184+200n	28484+100n	○	—	PC21	Servo parameters
30185+200n	28485+100n	○	—	PC22	
30186+200n	28486+100n	○	—	PC23	
30187+200n	28487+100n	○	—	PC24	
30188+200n	28488+100n	○	—	PC25	
30189+200n	28489+100n	○	—	PC26	
30190+200n	28490+100n	○	—	PC27	
30191+200n	28491+100n	○	—	PC28	
30192+200n	28492+100n	○	—	PC29	
30193+200n	28493+100n	○	—	PC30	
30194+200n	28494+100n	○	—	PC31	
30195+200n	28495+100n	○	—	PC32	
30196+200n	Set with GX Works2	○	—	PD01	
30197+200n		○	—	PD02	
30198+200n		○	—	PD03	
30199+200n		○	—	PD04	
30200+200n		○	—	PD05	
30201+200n		○	—	PD06	
30202+200n		○	—	PD07	
30203+200n		○	—	PD08	
30204+200n		○	—	PD09	
30205+200n		○	—	PD10	
30206+200n		○	—	PD11	
30207+200n		○	—	PD12	
30208+200n		○	—	PD13	
30209+200n		○	—	PD14	
30210+200n		○	—	PD15	
30211+200n		○	—	PD16	
30212+200n		○	—	PD17	
30213+200n		○	—	PD18	
30214+200n		○	—	PD19	
30215+200n		○	—	PD20	
30216+200n		○	—	PD21	
30217+200n		○	—	PD22	
30218+200n		○	—	PD23	
30219+200n		○	—	PD24	
30220+200n		○	—	PD25	
30221+200n		○	—	PD26	
30222+200n	○	—	PD27		
30223+200n	○	—	PD28		
30224+200n	○	—	PD29		
30225+200n	○	—	PD30		
30226+200n	○	—	PD31		

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
30227+200n	Set with GX Works2	○	—	PD32
30228+200n		○	—	PE01
30229+200n		○	—	PE02
30230+200n		○	—	PE03
30231+200n		○	—	PE04
30232+200n		○	—	PE05
30233+200n		○	—	PE06
30234+200n		○	—	PE07
30235+200n		○	—	PE08
30236+200n		○	—	PE09
30237+200n		○	—	PE10
30238+200n		○	—	PE11
30239+200n		○	—	PE12
30240+200n		○	—	PE13
30241+200n		○	—	PE14
30242+200n		○	—	PE15
30243+200n		○	—	PE16
30244+200n		○	—	PE17
30245+200n		○	—	PE18
30246+200n		○	—	PE19
30247+200n		○	—	PE20
30248+200n		○	—	PE21
30249+200n		○	—	PE22
30250+200n		○	—	PE23
30251+200n		○	—	PE24
30252+200n		○	—	PE25
30253+200n		○	—	PE26
30254+200n		○	—	PE27
30255+200n		○	—	PE28
30256+200n		○	—	PE29
30257+200n		○	—	PE30
30258+200n		○	—	PE31
30259+200n		○	—	PE32
30260+200n		○	—	PE33
30261+200n	○	—	PE34	
30262+200n	○	—	PE35	
30263+200n	○	—	PE36	
30264+200n	○	—	PE37	
30265+200n	○	—	PE38	
30266+200n	○	—	PE39	
30267+200n	○	—	PE40	
30268+200n	○	—	PS01	
30269+200n	○	—	PS02	

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
30270+200n	Set with GX Works2	○	—	PS03
30271+200n		○	—	PS04
30272+200n		○	—	PS05
30273+200n		○	—	PS06
30274+200n		○	—	PS07
30275+200n		○	—	PS08
30276+200n		○	—	PS09
30277+200n		○	—	PS10
30278+200n		○	—	PS11
30279+200n		○	—	PS12
30280+200n		○	—	PS13
30281+200n		○	—	PS14
30282+200n		○	—	PS15
30283+200n		○	—	PS16
30284+200n		○	—	PS17
30285+200n		○	—	PS18
30286+200n		○	—	PS19
30287+200n		○	—	PS20
30288+200n		○	—	PS21
30289+200n		○	—	PS22
30290+200n		○	—	PS23
30291+200n		○	—	PS24
30292+200n		○	—	PS25
30293+200n		○	—	PS26
30294+200n		○	—	PS27
30295+200n		○	—	PS28
30296+200n		○	—	PS29
30297+200n		○	—	PS30
30298+200n		○	—	PS31
30299+200n		○	—	PS32
30900+50n		○	—	PF01
30901+50n		○	—	PF02
30902+50n		○	—	PF03
30903+50n		○	—	PF04
30904+50n		○	—	PF05
30905+50n		○	—	PF06
30906+50n		○	—	PF07
30907+50n		○	—	PF08
30908+50n		○	—	PF09
30909+50n		○	—	PF10
30910+50n	○	—	PF11	
30911+50n	○	—	PF12	
30912+50n	○	—	PF13	

Servo parameters



# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item		Memory area
QD77MS2 QD77MS4	QD77MS16				
30913+50n	Set with GX Works2	○	—	PF14	Servo parameters
30914+50n		○	—	PF15	
30915+50n		○	—	PF16	
30916+50n		○	—	Po01	
30917+50n		○	—	Po02	
30918+50n		○	—	Po03	
30919+50n		○	—	Po04	
30920+50n		○	—	Po05	
30921+50n		○	—	Po06	
30922+50n		○	—	Po07	
30923+50n		○	—	Po08	
30924+50n		○	—	Po09	
30925+50n		○	—	Po10	
30926+50n		○	—	Po11	
30927+50n		○	—	Po12	
30928+50n		○	—	Po13	
30929+50n		○	—	Po14	
30930+50n		○	—	Po15	
30931+50n		○	—	Po16	
30932+50n		○	—	PA19	
64400+250n	64400+70n	○	—	PA20	
64401+250n	64401+70n	○	—	PA21	
64402+250n	64402+70n	○	—	PA22	
64403+250n	64403+70n	○	—	PA23	
64404+250n	64404+70n	○	—	PA24	
64405+250n	64405+70n	○	—	PA25	
64406+250n	64406+70n	○	—	PA26	
64407+250n	64407+70n	○	—	PA27	
64408+250n	64408+70n	○	—	PA28	
64409+250n	64409+70n	○	—	PA29	
64410+250n	64410+70n	○	—	PA30	
64411+250n	64411+70n	○	—	PA31	
64412+250n	64412+70n	○	—	PA32	
64413+250n	64413+70n	○	—	PB46	
64414+250n	64414+70n	○	—	PB47	
64415+250n	64415+70n	○	—	PB48	
64416+250n	64416+70n	○	—	PB49	
64417+250n	64417+70n	○	—	PB50	
64418+250n	64418+70n	○	—	PB51	
64419+250n	64419+70n	○	—	PB52	
64420+250n	64420+70n	○	—	PB53	
64421+250n	64421+70n	○	—	PB54	
64422+250n	64422+70n	○	—	PB55	

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
64423+250n	64423+70n	○	—	PB56
64424+250n	64424+70n	○	—	PB57
64425+250n	64425+70n	○	—	PB58
64426+250n	64426+70n	○	—	PB59
64427+250n	64427+70n	○	—	PB60
64428+250n	64428+70n	○	—	PB61
64429+250n	64429+70n	○	—	PB62
64430+250n	64430+70n	○	—	PB63
64431+250n	64431+70n	○	—	PB64
64432+250n	64432+70n	○	—	PC33
64433+250n	64433+70n	○	—	PC34
64434+250n	64434+70n	○	—	PC35
64435+250n	64435+70n	○	—	PC36
64436+250n	64436+70n	○	—	PC37
64437+250n	64437+70n	○	—	PC38
64438+250n	64438+70n	○	—	PC39
64439+250n	64439+70n	○	—	PC40
64440+250n	64440+70n	○	—	PC41
64441+250n	64441+70n	○	—	PC42
64442+250n	64442+70n	○	—	PC43
64443+250n	64443+70n	○	—	PC44
64444+250n	64444+70n	○	—	PC45
64445+250n	64445+70n	○	—	PC46
64446+250n	64446+70n	○	—	PC47
64447+250n	64447+70n	○	—	PC48
64448+250n	64448+70n	○	—	PC49
64449+250n	64449+70n	○	—	PC50
64450+250n	64450+70n	○	—	PC51
64451+250n	64451+70n	○	—	PC52
64452+250n	64452+70n	○	—	PC53
64453+250n	64453+70n	○	—	PC54
64454+250n	64454+70n	○	—	PC55
64455+250n	64455+70n	○	—	PC56
64456+250n	64456+70n	○	—	PC57
64457+250n	64457+70n	○	—	PC58
64458+250n	64458+70n	○	—	PC59
64459+250n	64459+70n	○	—	PC60
64460+250n	64460+70n	○	—	PC61
64461+250n	64461+70n	○	—	PC62
64462+250n	64462+70n	○	—	PC63
64463+250n	64463+70n	○	—	PC64
64464+250n	Set with	○	—	PD33
64465+250n	GX Works2	○	—	PD34

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
64466+250n	Set with GX Works2	○	—	PD35
64467+250n		○	—	PD36
64468+250n		○	—	PD37
64469+250n		○	—	PD38
64470+250n		○	—	PD39
64471+250n		○	—	PD40
64472+250n		○	—	PD41
64473+250n		○	—	PD42
64474+250n		○	—	PD43
64475+250n		○	—	PD44
64476+250n		○	—	PD45
64477+250n		○	—	PD46
64478+250n		○	—	PD47
64479+250n		○	—	PD48
64480+250n		○	—	PE41
64481+250n		○	—	PE42
64482+250n		○	—	PE43
64483+250n		○	—	PE44
64484+250n		○	—	PE45
64485+250n		○	—	PE46
64486+250n		○	—	PE47
64487+250n		○	—	PE48
64488+250n		○	—	PE49
64489+250n		○	—	PE50
64490+250n		○	—	PE51
64491+250n		○	—	PE52
64492+250n		○	—	PE53
64493+250n		○	—	PE54
64494+250n		○	—	PE55
64495+250n		○	—	PE56
64496+250n		○	—	PE57
64497+250n		○	—	PE58
64498+250n		○	—	PE59
64499+250n		○	—	PE60
64500+250n		○	—	PE61
64501+250n		○	—	PE62
64502+250n		○	—	PE63
64503+250n		○	—	PE64
64504+250n		○	—	PF17
64505+250n		○	—	PF18
64506+250n	○	—	PF19	
64507+250n	○	—	PF20	
64508+250n	○	—	PF21	

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
64509+250n	Set with GX Works2	○	—	PF22
64510+250n		○	—	PF23
64511+250n		○	—	PF24
64512+250n		○	—	PF25
64513+250n		○	—	PF26
64514+250n		○	—	PF27
64515+250n		○	—	PF28
64516+250n		○	—	PF29
64517+250n		○	—	PF30
64518+250n		○	—	PF31
64519+250n		○	—	PF32
64520+250n		○	—	PF33
64521+250n		○	—	PF34
64522+250n		○	—	PF35
64523+250n		○	—	PF36
64524+250n		○	—	PF37
64525+250n		○	—	PF38
64526+250n		○	—	PF39
64527+250n		○	—	PF40
64528+250n		○	—	PF41
64529+250n		○	—	PF42
64530+250n		○	—	PF43
64531+250n		○	—	PF44
64532+250n		○	—	PF45
64533+250n		○	—	PF46
64534+250n		○	—	PF47
64535+250n		○	—	PF48
64536+250n		○	—	Po17
64537+250n		○	—	Po18
64538+250n		○	—	Po19
64539+250n		○	—	Po20
64540+250n		○	—	Po21
64541+250n	○	—	Po22	
64542+250n	○	—	Po23	
64543+250n	○	—	Po24	
64544+250n	○	—	Po25	
64545+250n	○	—	Po26	
64546+250n	○	—	Po27	
64547+250n	○	—	Po28	
64548+250n	○	—	Po29	
64549+250n	○	—	Po30	
64550+250n	○	—	Po31	
64551+250n	○	—	Po32	

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
64552+250n	Set with GX Works2	○	—	PL01
64553+250n		○	—	PL02
64554+250n		○	—	PL03
64555+250n		○	—	PL04
64556+250n		○	—	PL05
64557+250n		○	—	PL06
64558+250n		○	—	PL07
64559+250n		○	—	PL08
64560+250n		○	—	PL09
64561+250n		○	—	PL10
64562+250n		○	—	PL11
64563+250n		○	—	PL12
64564+250n		○	—	PL13
64565+250n		○	—	PL14
64566+250n		○	—	PL15
64567+250n		○	—	PL16
64568+250n		○	—	PL17
64569+250n		○	—	PL18
64570+250n		○	—	PL19
64571+250n		○	—	PL20
64572+250n		○	—	PL21
64573+250n		○	—	PL22
64574+250n		○	—	PL23
64575+250n		○	—	PL24
64576+250n		○	—	PL25
64577+250n		○	—	PL26
64578+250n		○	—	PL27
64579+250n		○	—	PL28
64580+250n		○	—	PL29
64581+250n		○	—	PL30
64582+250n		○	—	PL31
64583+250n		○	—	PL32
64584+250n		○	—	PL33
64585+250n		○	—	PL34
64586+250n		○	—	PL35
64587+250n		○	—	PL36
64588+250n		○	—	PL37
64589+250n		○	—	PL38
64590+250n		○	—	PL39
64591+250n		○	—	PL40
64592+250n		○	—	PL41
64593+250n		○	—	PL42
64594+250n		○	—	PL43

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
64595+250n	Set with GX Works2	○	—	PL44
64596+250n		○	—	PL45
64597+250n		○	—	PL46
64598+250n		○	—	PL47
64599+250n		○	—	PL48
64600+250n		○	—	PT01
64601+250n		○	—	PT02
64602+250n		○	—	PT03
64603+250n		○	—	PT04
64604+250n		○	—	PT05
64605+250n		○	—	PT06
64606+250n		○	—	PT07
64607+250n		○	—	PT08
64608+250n		○	—	PT09
64609+250n		○	—	PT10
64610+250n		○	—	PT11
64611+250n		○	—	PT12
64612+250n		○	—	PT13
64613+250n		○	—	PT14
64614+250n		○	—	PT15
64615+250n		○	—	PT16
64616+250n		○	—	PT17
64617+250n		○	—	PT18
64618+250n		○	—	PT19
64619+250n		○	—	PT20
64620+250n		○	—	PT21
64621+250n		○	—	PT22
64622+250n		○	—	PT23
64623+250n		○	—	PT24
64624+250n		○	—	PT25
64625+250n		○	—	PT26
64626+250n		○	—	PT27
64627+250n		○	—	PT28
64628+250n		○	—	PT29
64629+250n		○	—	PT30
64630+250n		○	—	PT31
64631+250n	○	—	PT32	
64632+250n	○	—	PT33	
64633+250n	○	—	PT34	
64634+250n	○	—	PT35	
64635+250n	○	—	PT36	

Servo parameters

# APPENDICES

(continued)

n: Axis No.-1, ○: Compatible, △: Partly compatible, ×: Not compatible

Buffer memory address		Compatibility of QD77MS2/4 and QD77MS16	Item	Memory area
QD77MS2 QD77MS4	QD77MS16			
64636+250n	Set with GX Works2	○	—	Servo parameters
64637+250n		○	—	
64638+250n		○	—	
64639+250n		○	—	
64640+250n		○	—	
64641+250n		○	—	
64642+250n		○	—	
64643+250n		○	—	
64644+250n		○	—	
64645+250n		○	—	
64646+250n		○	—	
64647+250n		○	—	





# **WARRANTY**

Please confirm the following product warranty details before using this product.

## **1. Gratis Warranty Term and Gratis Warranty Range**

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
  1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
  2. Failure caused by unapproved modifications, etc., to the product by the user.
  3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
  4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
  5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
  6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
  7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

## **2. Onerous repair term after discontinuation of production**

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

## **3. Overseas service**

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

## **4. Exclusion of loss in opportunity and secondary loss from warranty liability**

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

## **5. Changes in product specifications**

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

## **6. Precautions for Choosing the Products**

- (1) For the use of our Simple Motion module, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in Simple Motion module, and a backup or fail-safe function should operate on an external system to Simple Motion module when any failure or malfunction occurs.
- (2) Our Simple Motion module is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used. In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used. We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Ethernet is a registered trademark of Fuji Xerox Corporation in Japan.

The company names, system names and product names mentioned in this document are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as '™' or '®' are not specified in this manual.



# Migration Guide from Positioning Module to Simple Motion Module [QD75M(H) ⇒ QD77MS]

Country/Region	Sales office	
USA	Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.	Tel : +1-847-478-2100
Mexico	Mitsubishi Electric Automation, Inc. Mexico Branch Boulevard Miguel de Cervantes Saavedra 301, Torre Norte Piso 5, Ampliacion Granada, Miguel Hidalgo, Ciudad de Mexico, Mexico, C.P.11520	Tel : +52-55-3067-7512
Brazil	Mitsubishi Electric do Brasil Comercio e Servicos Ltda. Avenida Adelino Cardana, 293, 21 andar, Bethaville, Barueri SP, Brazil	Tel : +55-11-4689-3000
Germany	Mitsubishi Electric Europe B.V. German Branch Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany	Tel : +49-2102-486-0
UK	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K.	Tel : +44-1707-28-8780
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Direzionale Colleoni - Palazzo Sirio, Viale Colleoni 7, 20864 Agrate Brianza (MB), Italy	Tel : +39-039-60531
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi, 76-80-Apdo. 420, E-08190 Sant Cugat del Valles (Barcelona), Spain	Tel : +34-935-65-3131
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, 92741 Nanterre Cedex, France	Tel : +33-1-55-68-55-68
Czech Republic	Mitsubishi Electric Europe B.V. Czech Branch, Prague Office Pekarska 621/7, 155 00 Praha 5, Czech Republic	Tel : +420-255-719-200
Poland	Mitsubishi Electric Europe B.V. Polish Branch ul. Krakowska 50, 32-083 Balice, Poland	Tel : +48-12-347-65-00
Russia	Mitsubishi Electric (Russia) LLC St. Petersburg Branch Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; 195027 St. Petersburg, Russia	Tel : +7-812-633-3497
Sweden	Mitsubishi Electric Europe B.V. (Scandinavia) Hedvig Mollersgata 6, 223 55 Lund, Sweden	Tel : +46-8-625-10-00
Turkey	Mitsubishi Electric Turkey A.S. Umraniye Branch Serifali Mahallesi Nutuk Sokak No:5, TR-34775 Umraniye / Istanbul, Turkey	Tel : +90-216-526-3990
UAE	Mitsubishi Electric Europe B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E.	Tel : +971-4-3724716
South Africa	Adroit Technologies 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa	Tel : +27-11-658-8100
China	Mitsubishi Electric Automation (China) Ltd. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China	Tel : +86-21-2322-3030
Taiwan	SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan	Tel : +886-2-2299-2499
Korea	Mitsubishi Electric Automation Korea Co., Ltd. 7F to 9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea	Tel : +82-2-3660-9529
Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943	Tel : +65-6473-2308
Thailand	Mitsubishi Electric Factory Automation (Thailand) Co., Ltd. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpong, Khet Yannawa, Bangkok 10120, Thailand	Tel : +66-2682-6522 to 6531
Indonesia	PT. Mitsubishi Electric Indonesia Gedung Jaya 8th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia	Tel : +62-21-3192-6461
Vietnam	Mitsubishi Electric Vietnam Company Limited Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam	Tel : +84-28-3910-5945
India	Mitsubishi Electric India Pvt. Ltd. Pune Branch Emerald House, EL-3, J Block, M.I.D.C., Bhosari, Pune - 411026, Maharashtra, India	Tel : +91-20-2710-2000
Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia	Tel : +61-2-9684-7777

## MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN  
NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN