



Programmable Controller

CC-Link IE Field Network Remote IO-Link Module
Function Block Reference (For MELSEC iQ-R)

CONTENTS

CHAPTER 1	MODULE FUNCTION BLOCK (FB) LIST	2
CHAPTER 2	CC-Link IE Field Network Remote IO-Link Module FB	4
2.1	M+NZ2GF2S-60IOLD8_RemoteBufMemRd	4
2.2	M+NZ2GF2S-60IOLD8_RemoteBufMemWt	7
2.3	M+NZ2GF2S-60IOLD8_OutputOnCntRd	10
2.4	M+NZ2GF2S-60IOLD8_OutputOnCntClr	13
2.5	M+NZ2GF2S-60IOLD8_UnitParamRd	16
2.6	M+NZ2GF2S-60IOLD8_UnitParamWt	19
2.7	M+NZ2GF2S-60IOLD8_DeviceParamRd	22
2.8	M+NZ2GF2S-60IOLD8_DeviceParamWt	26
2.9	M+NZ2GF2S-60IOLD8_DeviceChg	30
2.10	M+NZ2GF2S-60IOLD8_EventRd	33
2.11	M+NZ2GF2S-60IOLD8_EventClr	36
	INSTRUCTION INDEX	41
	REVISIONS	43
	TRADEMARKS	44

1 MODULE FUNCTION BLOCK (FB) LIST

This chapter lists the module FBs for CC-Link IE Field Network IO-Link module.

Name*1	Description
M+NZ2GF2S-60IOLD8_RemoteBufMemRd	Reads the value from the specified remote buffer memory.
M+NZ2GF2S-60IOLD8_RemoteBufMemWt	Writes the value to the specified remote buffer memory.
M+NZ2GF2S-60IOLD8_OutputOnCntRd	Reads the number of output ON times integration value of the IO-Link module.
M+NZ2GF2S-60IOLD8_OutputOnCntClr	Clears the number of output ON times integration value of the IO-Link module.
M+NZ2GF2S-60IOLD8_UnitParamRd	Reads the IO-Link module parameters.
M+NZ2GF2S-60IOLD8_UnitParamWt	Writes the IO-Link module parameters.
M+NZ2GF2S-60IOLD8_DeviceParamRd	Reads the specified parameter from the IO-Link device.
M+NZ2GF2S-60IOLD8_DeviceParamWt	Writes the specified parameter to the IO-Link device.
M+NZ2GF2S-60IOLD8_DeviceChg	Turns on the device change flag and disables the detection of disconnection error. This module FB disables input/output in IO-Link mode and turns off input/output in SIO mode. This module FB is used when the device is replaced during power-on.
M+NZ2GF2S-60IOLD8_EventRd	Reads the oldest event information from unchecked events.
M+NZ2GF2S-60IOLD8_EventClr	Clears the event history.

*1 Module FB names are suffixed with the version information such as "_00A". In this reference, the suffixes are omitted.

Precautions

- These module FBs are for GX Works3.
- These module FBs do not include the error recovery processing. Program the error recovery processing separately in accordance with the required system operation.
- Do not use these module FBs in an interrupt program.
- An interlock program with the transient transmission is required since this module FB uses the transient transmission. Create the interlock program separately.
- This module FB uses the index register areas (Z7 to Z9). When an interrupt program is used, do not use those areas.
- Configure the ladder setting for all the input labels in these module FBs.

2 CC-Link IE Field Network Remote IO-Link Module FB

2.1 M+NZ2GF2S-60IOLD8_RemoteBufMemRd

Name

M+NZ2GF2S-60IOLD8_RemoteBufMemRd

Overview

Item	Description																														
Functional overview	Reads the value from the specified remote buffer memory.																														
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center; margin: 0;">M+NZ2GF2S-60IOLD8_RemoteBufMemRd</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">(1) —</td> <td style="width: 40%;">B:i_bEN</td> <td style="width: 20%;"></td> <td style="width: 25%;">o_bENO:B</td> <td style="width: 10%;">(7)</td> </tr> <tr> <td>(2) —</td> <td>UW:i_uStart_IO_No</td> <td></td> <td>o_bOK:B</td> <td>(8)</td> </tr> <tr> <td>(3) —</td> <td>UW:i_uStation_No</td> <td></td> <td>o_uReadData:UW</td> <td>(9)</td> </tr> <tr> <td>(4) —</td> <td>UW:i_uCH_No</td> <td></td> <td>o_bErr:B</td> <td>(10)</td> </tr> <tr> <td>(5) —</td> <td>UW:i_uAddress</td> <td></td> <td>o_uErrId:UW</td> <td>(11)</td> </tr> <tr> <td>(6) —</td> <td>UW:i_uReadPoint</td> <td></td> <td></td> <td></td> </tr> </table> </div>	(1) —	B:i_bEN		o_bENO:B	(7)	(2) —	UW:i_uStart_IO_No		o_bOK:B	(8)	(3) —	UW:i_uStation_No		o_uReadData:UW	(9)	(4) —	UW:i_uCH_No		o_bErr:B	(10)	(5) —	UW:i_uAddress		o_uErrId:UW	(11)	(6) —	UW:i_uReadPoint			
(1) —	B:i_bEN		o_bENO:B	(7)																											
(2) —	UW:i_uStart_IO_No		o_bOK:B	(8)																											
(3) —	UW:i_uStation_No		o_uReadData:UW	(9)																											
(4) —	UW:i_uCH_No		o_bErr:B	(10)																											
(5) —	UW:i_uAddress		o_uErrId:UW	(11)																											
(6) —	UW:i_uReadPoint																														

Labels


■ Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uAddress	Remote buffer memory address	Word [unsigned]	0000H to 4DFFH	Specifies the start address of the remote buffer memory to be read.
(6)	i_uReadPoint	Number of read points	Word [unsigned]	1 to 240	Specifies the number of points to be read.

Output arguments

No.	Variable name	Name	Data type	Description	Default value
(7)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(8)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(9)	o_uReadData	Read data	Word [unsigned]	Specifies the start device to which the read value of the remote buffer memory is stored.	0
(10)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(11)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	CPU module	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	221 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	<p>When i_bEN (execution command) is turned on, the remote buffer memory value for the number of points specified by i_uReadPoint (number of read points) is read from the remote buffer memory address specified by i_uAddress (remote buffer memory address). The read remote buffer memory value for the number of points specified by i_uReadPoint (number of read points) is stored in the device starting from the one specified by o_uReadData (read data). (For example, when the remote buffer memory address of the input label is 1000H, the number of read points is 10, and the read data of the output label is D100, the specified remote buffer memory value is stored in D100 to D109.)</p>  <p>(1) Number of read points (10 words) (2) Remote buffer memory (3) Read data (4) Read</p>	
FB compilation method	Macro type	
FB operation	On-demand execution type	
FB_EN input condition	None	

Item	Description
Timing chart of I/O signals	<ul style="list-style-type: none"> When the processing is completed successfully <ul style="list-style-type: none"> When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Not updated (4) Updating (5) Error code (a) Only for one scan is turned on. (b) Read data is updated upon each completion of read processing.</p>
Precautions	<ul style="list-style-type: none"> When i_bEN (execution command) is turned off during the read processing of the remote buffer memory, the value for the previous read processing remains stored. If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMFR instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). For the start device where the read remote buffer memory value is stored, successive areas for the number of read points are required.

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual. MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.2 M+NZ2GF2S-60IOLD8_RemoteBufMemWt

Name

M+NZ2GF2S-60IOLD8_RemoteBufMemWt

Overview

Item	Description																												
Functional overview	Writes the value to the specified remote buffer memory.																												
Symbol	<div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_RemoteBufMemWt</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">(1) —</td> <td style="width: 45%;">B:i_bEN</td> <td style="width: 15%;"></td> <td style="width: 25%;">o_bENO:B — (8)</td> </tr> <tr> <td>(2) —</td> <td>UW:i_uStart_IO_No</td> <td></td> <td>o_bOK:B — (9)</td> </tr> <tr> <td>(3) —</td> <td>UW:i_uStation_No</td> <td></td> <td>o_bErr:B — (10)</td> </tr> <tr> <td>(4) —</td> <td>UW:i_uCH_No</td> <td></td> <td>o_uErrId:UW — (11)</td> </tr> <tr> <td>(5) —</td> <td>UW:i_uAddress</td> <td></td> <td></td> </tr> <tr> <td>(6) —</td> <td>UW:i_uWritePoint</td> <td></td> <td></td> </tr> <tr> <td>(7) —</td> <td>UW:i_uWriteData</td> <td></td> <td></td> </tr> </table> </div>	(1) —	B:i_bEN		o_bENO:B — (8)	(2) —	UW:i_uStart_IO_No		o_bOK:B — (9)	(3) —	UW:i_uStation_No		o_bErr:B — (10)	(4) —	UW:i_uCH_No		o_uErrId:UW — (11)	(5) —	UW:i_uAddress			(6) —	UW:i_uWritePoint			(7) —	UW:i_uWriteData		
(1) —	B:i_bEN		o_bENO:B — (8)																										
(2) —	UW:i_uStart_IO_No		o_bOK:B — (9)																										
(3) —	UW:i_uStation_No		o_bErr:B — (10)																										
(4) —	UW:i_uCH_No		o_uErrId:UW — (11)																										
(5) —	UW:i_uAddress																												
(6) —	UW:i_uWritePoint																												
(7) —	UW:i_uWriteData																												

Labels

Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uAddress	Remote buffer memory address	Word [unsigned]	0000H to 4DFFH	Specifies the start address of the remote buffer memory to be written.
(6)	i_uWritePoint	Number of write points	Word [unsigned]	1 to 240	Specifies the number of points to be written.
(7)	i_uWriteData	Write data	Word [unsigned]	—	Specifies the start device of data to be written.

Output arguments

No.	Variable name	Name	Data type	Description	Default value
(8)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(9)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(10)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(11)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	CPU module	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	320 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	<p>When i_bEN (execution command) is turned on, word data starting from the device specified by i_uWriteData (write data) is written to the remote buffer memory for the number of points specified by i_uWritePoint (number of write points). (For example, when the remote buffer memory address of the input label is 1000H, the number of write points is 10, and the write data is D100, the value in D100 to D109 is written to the specified remote buffer memory.)</p> <p>(1) Number of write points (10 words) (2) Write data (3) Remote buffer memory (4) Write</p>	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	

Item	Description
Timing chart of I/O signals	<ul style="list-style-type: none"> When the processing is completed successfully <ul style="list-style-type: none"> When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Not updated (4) Updating (5) Error code</p>
Precautions	<ul style="list-style-type: none"> If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully).

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual. MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.3 M+NZ2GF2S-60IOLD8_OutputOnCntRd

Name

M+NZ2GF2S-60IOLD8_OutputOnCntRd

Overview

Item	Description																				
Functional overview	Reads the number of output ON times integration value of the IO-Link module.																				
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_OutputOnCntRd</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">(1) — B:i_bEN</td> <td style="width: 40%;"></td> <td style="width: 20%; text-align: right;">o_bENO:B</td> <td style="width: 20%; text-align: right;">(5)</td> </tr> <tr> <td>(2) — UW:i_uStart_IO_No</td> <td></td> <td style="text-align: right;">o_bOK:B</td> <td style="text-align: right;">(6)</td> </tr> <tr> <td>(3) — UW:i_uStation_No</td> <td style="text-align: center;">o_uOutputONTotal:UW</td> <td></td> <td style="text-align: right;">(7)</td> </tr> <tr> <td>(4) — UW:i_uCH_No</td> <td></td> <td style="text-align: right;">o_bErr:B</td> <td style="text-align: right;">(8)</td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uErrId:UW</td> <td style="text-align: right;">(9)</td> </tr> </table> </div>	(1) — B:i_bEN		o_bENO:B	(5)	(2) — UW:i_uStart_IO_No		o_bOK:B	(6)	(3) — UW:i_uStation_No	o_uOutputONTotal:UW		(7)	(4) — UW:i_uCH_No		o_bErr:B	(8)			o_uErrId:UW	(9)
(1) — B:i_bEN		o_bENO:B	(5)																		
(2) — UW:i_uStart_IO_No		o_bOK:B	(6)																		
(3) — UW:i_uStation_No	o_uOutputONTotal:UW		(7)																		
(4) — UW:i_uCH_No		o_bErr:B	(8)																		
		o_uErrId:UW	(9)																		

Labels

Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.

Output arguments


No.	Variable name	Name	Data type	Description	Default value
(5)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(6)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(7)	o_uOutputONTotal	The number of output ON times integration value	Word [unsigned]	Specifies the start device to which the number of output ON times integration value is stored.	0
(8)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(9)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	325 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	When i_bEN (execution command) is turned on, the number of output ON times integration value of the IO-Link module is read. For the read number of output ON times integration value, 16-word data is stored in the device starting from the one specified by o_uOutputONTotal (the number of output ON times integration value).	
FB compilation method	Macro type	
FB operation	On-demand execution type	
FB_EN input condition	None	
Timing chart of I/O signals	<ul style="list-style-type: none"> • When the processing is completed successfully <ul style="list-style-type: none"> • When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Not updated (4) Updating (5) Error code (a) Only for one scan is turned on. (b) Read data is updated upon each completion of read processing.</p>	

Item	Description
Precautions	<ul style="list-style-type: none"> When i_bEN (execution command) is turned off during the read processing of the number of output ON times integration value, the value for the previous read processing remains stored. If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMFR instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully).

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.4 M+NZ2GF2S-60IOLD8_OutputOnCntClr

Name

M+NZ2GF2S-60IOLD8_OutputOnCntClr

Overview

Item	Description
Functional overview	Clears the number of output ON times integration value of the IO-Link module.
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_OutputOnCntClr</p> <p>(1) — B:i_bEN o_bENO:B — (6)</p> <p>(2) — UW:i_uStart_IO_No o_bOK:B — (7)</p> <p>(3) — UW:i_uStation_No o_bErr:B — (8)</p> <p>(4) — UW:i_uCH_No o_uErrId:UW — (9)</p> <p>(5) — UW:i_uOutputClrSlct</p> </div>

Labels



Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uOutputClrSlct	The number of output ON times integration value clear selection	Word [unsigned]	IO-Link module • b00: CH1 • b01: CH2 • b02: CH3 • b03: CH4 • b04: CH5 • b05: CH6 • b06: CH7 • b07: CH8	Sets the range of which the number of output ON times integration value is cleared. (For example, set 0025H to clear CH1, CH3, and CH6.)


Output arguments

No.	Variable name	Name	Data type	Description	Default value
(6)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(7)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(8)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(9)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	569 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	<ul style="list-style-type: none"> • When i_bEN (execution command) is turned on, the total number of output on times selected by i_uOutputClrSlct (total number of output on times clear selection) is cleared. • This module FB operates only for one shot when i_bEN (execution command) is turned on. 	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	
Timing chart of I/O signals	<ul style="list-style-type: none"> • When the processing is completed successfully  <ul style="list-style-type: none"> • When the processing is completed with an error  <p>(1) Not processed (2) Processing (3) Error code</p>	
Precautions	<ul style="list-style-type: none"> • If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). • This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. • This FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). 	

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
0200H	The module FB fails to be executed because the request flag or the command flag has already been turned on.	Turn off the relevant request flag or the command flag. Then, execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.5 M+NZ2GF2S-60IOLD8_UnitParamRd

Name

M+NZ2GF2S-60IOLD8_UnitParamRd

Overview

Item	Description																				
Functional overview	Reads the IO-Link module parameters.																				
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_UnitParamRd</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">(1) — B:i_bEN</td> <td style="width: 40%;"></td> <td style="width: 20%; text-align: right;">o_bENO:B</td> <td style="width: 20%; text-align: right;">(5)</td> </tr> <tr> <td>(2) — UW:i_uStart_IO_No</td> <td></td> <td style="text-align: right;">o_bOK:B</td> <td style="text-align: right;">(6)</td> </tr> <tr> <td>(3) — UW:i_uStation_No</td> <td style="text-align: center;">o_uReadData:UW</td> <td></td> <td style="text-align: right;">(7)</td> </tr> <tr> <td>(4) — UW:i_uCH_No</td> <td></td> <td style="text-align: right;">o_bErr:B</td> <td style="text-align: right;">(8)</td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uErrId:UW</td> <td style="text-align: right;">(9)</td> </tr> </table> </div>	(1) — B:i_bEN		o_bENO:B	(5)	(2) — UW:i_uStart_IO_No		o_bOK:B	(6)	(3) — UW:i_uStation_No	o_uReadData:UW		(7)	(4) — UW:i_uCH_No		o_bErr:B	(8)			o_uErrId:UW	(9)
(1) — B:i_bEN		o_bENO:B	(5)																		
(2) — UW:i_uStart_IO_No		o_bOK:B	(6)																		
(3) — UW:i_uStation_No	o_uReadData:UW		(7)																		
(4) — UW:i_uCH_No		o_bErr:B	(8)																		
		o_uErrId:UW	(9)																		

Labels

Input arguments


No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.

Output arguments


No.	Variable name	Name	Data type	Description	Default value
(5)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(6)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(7)	o_uReadData	Read data	Word [unsigned]	Specifies the start device to which the read parameter value is stored. For parameter data configuration, refer to the following. CC-Link IE Field Network Remote IO-Link Module User's Manual	0
(8)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(9)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	684 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	<ul style="list-style-type: none"> • When i_bEN (execution command) is turned on, parameters of the IO-Link module are read and stored in o_uReadData (read data). • This module FB is completed in several scans after i_bEN (execution command) is turned on. 	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	
Timing chart of I/O signals	<ul style="list-style-type: none"> • When the processing is completed successfully <ul style="list-style-type: none"> • When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Parameter (4) Error code</p>	

Item	Description
Precautions	<ul style="list-style-type: none"> If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMFR instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). For the start device where the read parameter value is stored, successive areas with the parameter size are required. For parameter data configuration, refer to the following.  CC-Link IE Field Network Remote IO-Link Module User's Manual This module FB reads values from the parameter area of the remote buffer memory. Therefore, the read values may differ from actual operation parameters.

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.6 M+NZ2GF2S-60IOLD8_UnitParamWt

Name

M+NZ2GF2S-60IOLD8_UnitParamWt

Overview

Item	Description															
Functional overview	Writes the IO-Link module parameters.															
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_UnitParamWt</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">(1) — B:i_bEN</td> <td style="width: 40%;"></td> <td style="width: 30%;">o_bENO:B — (6)</td> </tr> <tr> <td>(2) — UW:i_uStart_IO_No</td> <td></td> <td>o_bOK:B — (7)</td> </tr> <tr> <td>(3) — UW:i_uStation_No</td> <td></td> <td>o_bErr:B — (8)</td> </tr> <tr> <td>(4) — UW:i_uCH_No</td> <td></td> <td>o_uErrId:UW — (9)</td> </tr> <tr> <td>(5) — UW:i_uWriteData</td> <td></td> <td></td> </tr> </table> </div>	(1) — B:i_bEN		o_bENO:B — (6)	(2) — UW:i_uStart_IO_No		o_bOK:B — (7)	(3) — UW:i_uStation_No		o_bErr:B — (8)	(4) — UW:i_uCH_No		o_uErrId:UW — (9)	(5) — UW:i_uWriteData		
(1) — B:i_bEN		o_bENO:B — (6)														
(2) — UW:i_uStart_IO_No		o_bOK:B — (7)														
(3) — UW:i_uStation_No		o_bErr:B — (8)														
(4) — UW:i_uCH_No		o_uErrId:UW — (9)														
(5) — UW:i_uWriteData																

Labels

Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uWriteData	Write data	Word [unsigned]	—	Specifies the start device of the parameter data to be written. For parameter data configuration, refer to the following. CC-Link IE Field Network Remote IO-Link Module User's Manual

Output arguments


No.	Variable name	Name	Data type	Description	Default value
(6)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(7)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(8)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(9)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	1128 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	<ul style="list-style-type: none"> • Writes the parameters of the IO-Link module when i_bEN (execution command) is turned on. • This module FB is completed in several scans after i_bEN (execution command) is turned on. 	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	
Timing chart of I/O signals	<ul style="list-style-type: none"> • When the processing is completed successfully <ul style="list-style-type: none"> • When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Not updated (4) Updating (5) Error code</p>	

Item	Description
Precautions	<ul style="list-style-type: none"> • If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). • This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. • This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). • Do not power off the module or perform remote reset during execution of this module FB.

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
0200H	The module FB fails to be executed because the request flag or the command flag has already been turned on.	Turn off the relevant request flag or the command flag. Then, execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.7 M+NZ2GF2S-60IOLD8_DeviceParamRd

Name

M+NZ2GF2S-60IOLD8_DeviceParamRd

Overview

Item	Description																																																												
Functional overview	Reads the specified parameter from the IO-Link device.																																																												
Symbol	<div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_DeviceParamRd</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">(1)</td> <td style="width: 40%;">B:i_bEN</td> <td style="width: 40%;"></td> <td style="width: 10%;"></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_bENO:B</td> <td style="text-align: right;">(9)</td> </tr> <tr> <td>(2)</td> <td>UW:i_uStart_IO_No</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_bOK:B</td> <td style="text-align: right;">(10)</td> </tr> <tr> <td>(3)</td> <td>UW:i_uStation_No</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uReadSize:UW</td> <td style="text-align: right;">(11)</td> </tr> <tr> <td>(4)</td> <td>UW:i_uCH_No</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uReadData:UW</td> <td style="text-align: right;">(12)</td> </tr> <tr> <td>(5)</td> <td>UW:i_uTarget_CH</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_bErr:B</td> <td style="text-align: right;">(13)</td> </tr> <tr> <td>(6)</td> <td>UW:i_uIndex</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uErrId:UW</td> <td style="text-align: right;">(14)</td> </tr> <tr> <td>(7)</td> <td>UW:i_uSubIndex</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uResult:UW</td> <td style="text-align: right;">(15)</td> </tr> <tr> <td>(8)</td> <td>UW:i_uReadSize</td> <td></td> <td></td> </tr> </table> </div>	(1)	B:i_bEN					o_bENO:B	(9)	(2)	UW:i_uStart_IO_No					o_bOK:B	(10)	(3)	UW:i_uStation_No					o_uReadSize:UW	(11)	(4)	UW:i_uCH_No					o_uReadData:UW	(12)	(5)	UW:i_uTarget_CH					o_bErr:B	(13)	(6)	UW:i_uIndex					o_uErrId:UW	(14)	(7)	UW:i_uSubIndex					o_uResult:UW	(15)	(8)	UW:i_uReadSize		
(1)	B:i_bEN																																																												
		o_bENO:B	(9)																																																										
(2)	UW:i_uStart_IO_No																																																												
		o_bOK:B	(10)																																																										
(3)	UW:i_uStation_No																																																												
		o_uReadSize:UW	(11)																																																										
(4)	UW:i_uCH_No																																																												
		o_uReadData:UW	(12)																																																										
(5)	UW:i_uTarget_CH																																																												
		o_bErr:B	(13)																																																										
(6)	UW:i_uIndex																																																												
		o_uErrId:UW	(14)																																																										
(7)	UW:i_uSubIndex																																																												
		o_uResult:UW	(15)																																																										
(8)	UW:i_uReadSize																																																												

Labels

Input arguments



No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uTarget_CH	Channel of the IO-Link module	Word [unsigned]	1 to 8	Specifies the channel of the IO-Link module to which the target IO-Link device is connected.
(6)	i_uIndex	Index	Word [unsigned]	0 to 2, 4 to 65535	Specifies the index of the parameter to be read.
(7)	i_uSubIndex	Sub index	Word [unsigned]	0 to 255	Specifies the sub index of the parameter to be read.
(8)	i_uReadSize	Read data size	Word [unsigned]	0 to 256	Specifies data size of the parameter to be read.

Output arguments


No.	Variable name	Name	Data type	Description	Default value
(9)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(10)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(11)	o_uReadSize	Read data size	Word [unsigned]	Size of the read parameter data is stored in units of byte.	0
(12)	o_uReadData	Read data	Word [unsigned]	Specifies the start device to which the read parameter value is stored.	0
(13)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(14)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0
(15)	o_uResult	Execution result	Word [unsigned]	The execution result of communications with IO-Link device is stored.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	849 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	When i_bEN (execution command) is turned on, the parameter specified by i_uIndex (index) or i_uSubIndex (sub index) is read from the IO-Link device connected to the channel of the IO-Link module specified by i_uTarget_CH (channel of the IO-Link module), and data of the size specified by i_uReadSize (read data size) is stored in o_uReadData (read data). When i_uSubIndex (sub index) is set to 0, all the parameters of i_uIndex (index) is read. When i_uSubIndex (sub index) is set to other than 0, parameter is read according to the sub index. In addition, the actual size of the read data is stored in o_uReadSize (read data size). The execution result is stored in o_uResult (execution result). (Page 25 Execution result)	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	

Item	Description
Timing chart of I/O signals	<ul style="list-style-type: none"> When the processing is completed successfully  <ul style="list-style-type: none"> When the processing is completed with an error  <p>(1) Not processed (2) Processing (3) Data (4) Updating (5) Error code</p>
Precautions	<ul style="list-style-type: none"> If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). For the start device where the read parameter value is stored, successive areas with the parameter size are required. (Up to 232 bytes) When the read data size is set to odd number of bytes, 0 is stored for the upper one byte of the read data. Do not execute this module FB until the module FB for reading/writing IO-Link device parameters is completed successfully or completed with an error.

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
0102H	The channel of the IO-Link module is out of the setting range. The channel of the IO-Link module is out of the range between 1 and 8.	Check the setting, and execute the module FB again.
0201H	The module FB is being executed for the target IO-Link module.	Execute the module FB again after the completion of the module FB for reading/writing IO-Link device parameters that is being executed.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

Execution result

Execution result	Description	Action
0000H	The module FB has been completed successfully.	No actions are required.
0001H	No data is available for reading.	Check the following settings, and execute the module FB again. <ul style="list-style-type: none"> • Index • Sub index
1000H, 1100H, 5600H	Communications have failed.	Check the connection with the IO-Link device.
5700H, 8023H, 8035H	IO-Link device does not support the function.	Refer to the manual of the IO-Link device used.
8011H	Index is out of the setting range.	Check the setting, and execute the module FB again.
8012H	Sub index is out of the setting range.	Check the setting, and execute the module FB again.
8020H to 8022H, 8036H, 8082H	Service becomes temporarily unavailable.	Execute the module FB again after a while.
8040H to 8041H	Parameter setting is invalid.	Refer to the manual of the IO-Link device used.
8100H to 81FFH	Error unique to the IO-Link device used has occurred.	Refer to the manual of the IO-Link device used.

2.8 M+NZ2GF2S-60IOLD8_DeviceParamWt

Name

M+NZ2GF2S-60IOLD8_DeviceParamWt

Overview

Item	Description																																				
Functional overview	Writes the specified parameter to the IO-Link device.																																				
Symbol	<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_DeviceParamWt</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%;">(1)</td> <td style="width: 40%;">B:i_bEN</td> <td style="width: 40%; text-align: right;">o_bENO:B</td> <td style="width: 10%; text-align: right;">(10)</td> </tr> <tr> <td>(2)</td> <td>UW:i_uStart_IO_No</td> <td style="text-align: right;">o_bOK:B</td> <td style="text-align: right;">(11)</td> </tr> <tr> <td>(3)</td> <td>UW:i_uStation_No</td> <td style="text-align: right;">o_bErr:B</td> <td style="text-align: right;">(12)</td> </tr> <tr> <td>(4)</td> <td>UW:i_uCH_No</td> <td style="text-align: right;">o_uErrId:UW</td> <td style="text-align: right;">(13)</td> </tr> <tr> <td>(5)</td> <td>UW:i_uTarget_CH</td> <td style="text-align: right;">o_uResult:UW</td> <td style="text-align: right;">(14)</td> </tr> <tr> <td>(6)</td> <td>UW:i_uIndex</td> <td></td> <td></td> </tr> <tr> <td>(7)</td> <td>UW:i_uSubIndex</td> <td></td> <td></td> </tr> <tr> <td>(8)</td> <td>UW:i_uWriteSize</td> <td></td> <td></td> </tr> <tr> <td>(9)</td> <td>UW:i_uWriteData</td> <td></td> <td></td> </tr> </table> </div>	(1)	B:i_bEN	o_bENO:B	(10)	(2)	UW:i_uStart_IO_No	o_bOK:B	(11)	(3)	UW:i_uStation_No	o_bErr:B	(12)	(4)	UW:i_uCH_No	o_uErrId:UW	(13)	(5)	UW:i_uTarget_CH	o_uResult:UW	(14)	(6)	UW:i_uIndex			(7)	UW:i_uSubIndex			(8)	UW:i_uWriteSize			(9)	UW:i_uWriteData		
(1)	B:i_bEN	o_bENO:B	(10)																																		
(2)	UW:i_uStart_IO_No	o_bOK:B	(11)																																		
(3)	UW:i_uStation_No	o_bErr:B	(12)																																		
(4)	UW:i_uCH_No	o_uErrId:UW	(13)																																		
(5)	UW:i_uTarget_CH	o_uResult:UW	(14)																																		
(6)	UW:i_uIndex																																				
(7)	UW:i_uSubIndex																																				
(8)	UW:i_uWriteSize																																				
(9)	UW:i_uWriteData																																				

Labels

Input arguments



No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uTarget_CH	Channel of the IO-Link module	Word [unsigned]	1 to 8	Specifies the channel of the IO-Link module to which the target IO-Link device is connected.
(6)	i_uIndex	Index	Word [unsigned]	2, 4 to 65535	Specifies the index of the parameter to be written.
(7)	i_uSubIndex	Sub index	Word [unsigned]	0 to 255	Specifies the sub index of the parameter to be written.
(8)	i_uWriteSize	Write data size	Word [unsigned]	1 to 232	Specifies the size of data to be written in units of byte.
(9)	i_uWriteData	Write data	Word [unsigned]	—	Specifies the start device of data to be written.

Output arguments


No.	Variable name	Name	Data type	Description	Default value
(10)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(11)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(12)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(13)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0
(14)	o_uResult	Execution result	Word [unsigned]	The execution result of communications with IO-Link device is stored.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	808 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	When i_bEN (execution command) is turned on, data specified by i_uWriteSize (write data size) and i_uWriteData (write data) is written to the parameter specified by i_uIndex (index) and i_uSubIndex (sub index) of the IO-Link device connected to the channel of the IO-Link module specified by i_uTarget_CH (channel of the IO-Link module). When i_uSubIndex (sub index) is set to 0, data is written to all the parameters of i_uIndex (index). When i_uSubIndex (sub index) is set to other than 0, data is written only to the parameter set by the sub index. The execution result is stored in o_uResult (execution result). (Page 29 Execution result)	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	

Item	Description
Timing chart of I/O signals	<ul style="list-style-type: none"> When the processing is completed successfully  <ul style="list-style-type: none"> When the processing is completed with an error  <p>(1) Not processed (2) Processing (3) Not updated (4) Updating (5) Error code</p>
Precautions	<ul style="list-style-type: none"> If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). Do not power off the module or perform remote reset during execution of this module FB. Do not execute this module FB until the module FB for reading/writing IO-Link device parameters is completed successfully or completed with an error.

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
0102H	The channel of the IO-Link module is out of the setting range. The channel of the IO-Link module is out of the range between 1 and 8.	Check the setting, and execute the module FB again.
0201H	The module FB is being executed for the target IO-Link module.	Execute the module FB again after the completion of the module FB for reading/writing IO-Link device parameters that is being executed.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

Execution result

Execution result	Description	Action
0000H	The module FB has been completed successfully.	No actions are required.
1000H, 1100H, 5600H	Communications have failed.	Check the connection with the IO-Link device.
5700H, 8023H, 8035H	IO-Link device does not support the function.	Refer to the manual of the IO-Link device used.
8011H	Index is out of the setting range.	Check the setting, and execute the module FB again.
8012H	Sub index is out of the setting range.	Check the setting, and execute the module FB again.
8020H to 8022H, 8036H, 8082H	Service becomes temporarily unavailable.	Execute the module FB again after a while.
8030H	Write data is out of the setting range.	Refer to the manual of the IO-Link device used.
8031H	Write data exceeds the upper limit value.	Refer to the manual of the IO-Link device used.
8032H	Write data falls below the lower limit value.	Refer to the manual of the IO-Link device used.
8033H to 8034H	Write data size is out of the setting range.	Refer to the manual of the IO-Link device used.
8040H to 8041H	Parameter setting is invalid.	Refer to the manual of the IO-Link device used.
8100H to 81FFH	Error unique to the IO-Link device used has occurred.	Refer to the manual of the IO-Link device used.

2.9 M+NZ2GF2S-60IOLD8_DeviceChg

Name

M+NZ2GF2S-60IOLD8_DeviceChg

Overview

Item	Description															
Functional overview	Turns on the device change flag and disables the detection of disconnection error. This module FB disables input/output in IO-Link mode and turns off input/output in SIO mode. This module FB is used when the device is replaced during power-on.															
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_DeviceChg</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">(1) — B:i_bEN</td> <td style="width: 60%;"></td> <td style="width: 20%;">o_bENO:B — (6)</td> </tr> <tr> <td>(2) — UW:i_uStart_IO_No</td> <td></td> <td>o_bOK:B — (7)</td> </tr> <tr> <td>(3) — UW:i_uStation_No</td> <td></td> <td>o_bErr:B — (8)</td> </tr> <tr> <td>(4) — UW:i_uCH_No</td> <td></td> <td>o_uErrId:UW — (9)</td> </tr> <tr> <td>(5) — UW:i_uChangeSlct</td> <td></td> <td></td> </tr> </table> </div>	(1) — B:i_bEN		o_bENO:B — (6)	(2) — UW:i_uStart_IO_No		o_bOK:B — (7)	(3) — UW:i_uStation_No		o_bErr:B — (8)	(4) — UW:i_uCH_No		o_uErrId:UW — (9)	(5) — UW:i_uChangeSlct		
(1) — B:i_bEN		o_bENO:B — (6)														
(2) — UW:i_uStart_IO_No		o_bOK:B — (7)														
(3) — UW:i_uStation_No		o_bErr:B — (8)														
(4) — UW:i_uCH_No		o_uErrId:UW — (9)														
(5) — UW:i_uChangeSlct																

Labels

Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.
(5)	i_uChangeSlct	Device change selection	Word [unsigned]	IO-Link module • b00: CH1 • b01: CH2 • b02: CH3 • b03: CH4 • b04: CH5 • b05: CH6 • b06: CH7 • b07: CH8	Specifies the channel of the IO-Link module to which the target device is connected. (For example, set 0025H to set CH1, CH3 and CH6 as the target of the device replacement.)


Output arguments

No.	Variable name	Name	Data type	Description	Default value
(6)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(7)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(8)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(9)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description
Available device	Target module NZ2GF2S-60IOLD8
	Network module • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU RCPU
	Engineering tool GX Works3
Language	Ladder diagram
Number of basic steps	281 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.
Functional description	When i_bEN (execution command) is turned on, the device change flags for all the channels of the IO-Link module are collectively set according to the settings specified by i_uChangeSlct (device change selection). For device change flag, refer to CC-Link IE Field Network Remote IO-Link Module User's Manual. Before replacing the device, when o_bOK (completed successfully) is turned on and IO-Link mode is used, check that the CHLED of the channel of the IO-Link module selected by the device change selection is flashing.
FB compilation method	Macro type
FB operation	Pulse execution type (multiple scan execution type)
FB_EN input condition	None
Timing chart of I/O signals	<ul style="list-style-type: none"> When the processing is completed successfully <ul style="list-style-type: none"> When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Error code</p>
Precautions	<ul style="list-style-type: none"> After replacing the device, set the target bit of i_uChangeSlct (device change selection) to off, and execute this module FB again. If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully).

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.10 M+NZ2GF2S-60IOLD8_EventRd

Name

M+NZ2GF2S-60IOLD8_EventRd

Overview

Item	Description																				
Functional overview	Reads the oldest event information from unchecked events.																				
Symbol	<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 10px auto;"> <p style="text-align: center;">M+NZ2GF2S-60IOLD8_EventRd</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">(1) — B:i_bEN</td> <td style="width: 40%;"></td> <td style="width: 20%; text-align: right;">o_bENO:B</td> <td style="width: 20%; text-align: right;">(5)</td> </tr> <tr> <td>(2) — UW:i_uStart_IO_No</td> <td></td> <td style="text-align: right;">o_bOK:B</td> <td style="text-align: right;">(6)</td> </tr> <tr> <td>(3) — UW:i_uStation_No</td> <td style="text-align: center;">o_uEventData:UW</td> <td></td> <td style="text-align: right;">(7)</td> </tr> <tr> <td>(4) — UW:i_uCH_No</td> <td></td> <td style="text-align: right;">o_bErr:B</td> <td style="text-align: right;">(8)</td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;">o_uErrId:UW</td> <td style="text-align: right;">(9)</td> </tr> </table> </div>	(1) — B:i_bEN		o_bENO:B	(5)	(2) — UW:i_uStart_IO_No		o_bOK:B	(6)	(3) — UW:i_uStation_No	o_uEventData:UW		(7)	(4) — UW:i_uCH_No		o_bErr:B	(8)			o_uErrId:UW	(9)
(1) — B:i_bEN		o_bENO:B	(5)																		
(2) — UW:i_uStart_IO_No		o_bOK:B	(6)																		
(3) — UW:i_uStation_No	o_uEventData:UW		(7)																		
(4) — UW:i_uCH_No		o_bErr:B	(8)																		
		o_uErrId:UW	(9)																		

Labels



Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.


Output arguments

No.	Variable name	Name	Data type	Description	Default value
(5)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(6)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(7)	o_uEventData	Event information	Word [unsigned]	Specifies the start device to which the read event information is stored.	0
(8)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(9)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	603 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	When i_bEN (execution command) is turned on, the information of the oldest unchecked event is read from the target module and written to o_uEventData (event information).	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	
Timing chart of I/O signals	<ul style="list-style-type: none"> • When the processing is completed successfully  <ul style="list-style-type: none"> • When the processing is completed with an error  <p>(1) Event information (2) Error code</p>	
Precautions	<ul style="list-style-type: none"> • If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). • This module FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). • For the start device where the read event information value is stored, successive areas having the size of the event data for each station (5 words) are required. For details on the event data for each station, refer to the following. <ul style="list-style-type: none"> ☞ CC-Link IE Field Network Remote IO-Link Module User's Manual • This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. 	

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
0200H	The module FB fails to be executed because the request flag or the command flag has already been turned on.	Turn off the relevant request flag or the command flag. Then, execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

2.11 M+NZ2GF2S-60IOLD8_EventClr

Name

M+NZ2GF2S-60IOLD8_EventClr

Overview

Item	Description																				
Functional overview	Clears the event history.																				
Symbol	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p style="text-align: center; margin: 0;">M+NZ2GF2S-60IOLD8_EventClr</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">(1) —</td> <td style="width: 40%;">B:i_bEN</td> <td style="width: 20%;"></td> <td style="width: 20%;">o_bENO:B —</td> <td style="width: 10%;">(5)</td> </tr> <tr> <td>(2) —</td> <td>UW:i_uStart_IO_No</td> <td></td> <td>o_bOK:B —</td> <td>(6)</td> </tr> <tr> <td>(3) —</td> <td>UW:i_uStation_No</td> <td></td> <td>o_bErr:B —</td> <td>(7)</td> </tr> <tr> <td>(4) —</td> <td>UW:i_uCH_No</td> <td></td> <td>o_uErrId:UW —</td> <td>(8)</td> </tr> </table> </div>	(1) —	B:i_bEN		o_bENO:B —	(5)	(2) —	UW:i_uStart_IO_No		o_bOK:B —	(6)	(3) —	UW:i_uStation_No		o_bErr:B —	(7)	(4) —	UW:i_uCH_No		o_uErrId:UW —	(8)
(1) —	B:i_bEN		o_bENO:B —	(5)																	
(2) —	UW:i_uStart_IO_No		o_bOK:B —	(6)																	
(3) —	UW:i_uStation_No		o_bErr:B —	(7)																	
(4) —	UW:i_uCH_No		o_uErrId:UW —	(8)																	

Labels

Input arguments

No.	Variable name	Name	Data type	Scope	Description
(1)	i_bEN	Execution command	Bit	On or off	On: The module FB is activated. Off: The module FB is not activated.
(2)	i_uStart_IO_No	XY address of module mounted	Word [unsigned]	Depends on the number of I/O points of the CPU module.	Specifies the start I/O number to which the CC-Link IE Field Network master/local module is mounted.
(3)	i_uStation_No	Station number	Word [unsigned]	1 to 120	Specifies the target station number of the IO-Link module.
(4)	i_uCH_No	Channel used by own station	Word [unsigned]	1 to 32	Specifies the channel for accessing other stations from the own station.


Output arguments

No.	Variable name	Name	Data type	Description	Default value
(5)	o_bENO	Execution status	Bit	The execution status of the module FB is output. On: In execution Off: Not in execution	Off
(6)	o_bOK	Normal completion	Bit	The on state indicates that the module FB processing has been completed successfully.	Off
(7)	o_bErr	Error completion	Bit	The on state indicates that the module FB processing has been completed with an error.	Off
(8)	o_uErrId	Error code	Word [unsigned]	Error code is stored when the processing has been completed with an error.	0

FB details

Item	Description	
Available device	Target module	NZ2GF2S-60IOLD8
	Network module	<ul style="list-style-type: none"> • RJ71EN71 • RJ71GF11-T2 • RnENCPU (network part)
	Target CPU	RCPU
	Engineering tool	GX Works3
Language	Ladder diagram	
Number of basic steps	487 steps The number of steps of the FB embedded in a program depends on the CPU module used, the input/output definitions, and the options setting of GX Works3. For the options setting of GX Works3, refer to the GX Works3 Operating Manual.	
Functional description	<ul style="list-style-type: none"> • When i_bEN (execution command) is turned on, the event history is cleared. • This module FB operates only for one shot when i_bEN (execution command) is turned on. 	
FB compilation method	Macro type	
FB operation	Pulse execution type (multiple scan execution type)	
FB_EN input condition	None	
Timing chart of I/O signals	<ul style="list-style-type: none"> • When the processing is completed successfully <ul style="list-style-type: none"> • When the processing is completed with an error <p>(1) Not processed (2) Processing (3) Error code</p>	
Precautions	<ul style="list-style-type: none"> • If an error occurs, o_bErr (completed with an error) is turned on, and the module FB processing is suspended. In addition, error code is stored in o_uErrId (error code). • This module FB uses the REMFR/REMTO instruction. When this module FB is operated simultaneously with other module FBs including this module FB or when the REMFR/REMTO instruction is used in a program, ensure that the channels used by own stations are not overlapped. • Do not power off the module or perform remote reset during execution of this module FB. • This FB requires several scans for the processing from turning on i_bEN (execution command) to turning on o_bOK (completed successfully). 	

Error code

Error code	Description	Action
0100H	The station number is out of the range between 1 and 120.	Check the setting, and execute the module FB again.
0101H	The channel used by own station is out of the setting range. The channel used by own station is out of the range between 1 and 32.	Check the setting, and execute the module FB again.
0200H	The module FB fails to be executed because the request flag or the command flag has already been turned on.	Turn off the relevant request flag or the command flag. Then, execute the module FB again.
D000H to DAF9H	A failure has occurred in CC-Link IE Field Network.	For error codes, refer to the following manual.  MELSEC iQ-R CC-Link IE Field Network User's Manual (Application)

INSTRUCTION INDEX

M

M+NZ2GF2S-60IOLD8_DeviceParamRd.	22
M+NZ2GF2S-60IOLD8_DeviceParamWt.	26
M+NZ2GF2S-60IOLD8_EventClr	36
M+NZ2GF2S-60IOLD8_EventRd	33
M+NZ2GF2S-60IOLD8_IOLDeviceChg	30
M+NZ2GF2S-60IOLD8_OutputOnCntClr	13
M+NZ2GF2S-60IOLD8_OutputOnCntRd	10
M+NZ2GF2S-60IOLD8_RemoteBufMemRd.	4
M+NZ2GF2S-60IOLD8_RemoteBufMemWt.	7
M+NZ2GF2S-60IOLD8_UnitParamRd.	16
M+NZ2GF2S-60IOLD8_UnitParamWt.	19



MEMO

REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Description
October, 2018	BCN-P5999-1048-A	First edition

Japanese manual number: BCN-P5999-1047-A

This manual confers no industrial property rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2018 MITSUBISHI ELECTRIC CORPORATION

TRADEMARKS

IO-Link is either a registered trademark or a trademark of PROFIBUS Nutzerorganisation e.V.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.

BCN-P5999-1048-A(1810)

mitsubishi electric corporation

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.