




# FR-A802 (SEPARATED CONVERTER TYPE) INSTRUCTION MANUAL (HARDWARE)

High functionality and high performance

FR-A842-07700(315K) to 12120(500K)



Safet	y instructions	. 4
Cha	pter 1 INTRODUCTION1	2
1.1	Product checking and accessories	13
1.2	Inverter component names	
1.3	About the related manuals	16
Cha	pter 2 INSTALLATION AND WIRING1	8
2.1	Peripheral devices	
2.1.1 2.1.2	Inverter and peripheral devices	18
2.2	Removal and reinstallation of the operation panel or the front covers	21
2.3	Installation of the inverter and enclosure design	
2.3.1 2.3.2 2.3.3 2.3.4 2.3.5 2.4	Inverter installation environment Amount of heat generated by the inverter Cooling system types for inverter enclosure Inverter installation Protruding the heat sink through a panel  Terminal connection diagrams.	26 27 29 30
2.5	Main circuit terminals	38
2.5.1 2.5.2 2.5.3 2.5.4 2.5.5	Details on the main circuit terminals of the inverter  Details on the main circuit terminals of the converter unit (FR-CC2)  Main circuit terminal layout and wiring to power supply and motor.  Applicable cables and wiring length  Earthing (grounding) precautions  Control circuit.	38 39 40 43
2.6.1 2.6.2 2.6.3 2.6.4 2.6.5 2.6.6 2.6.7 2.6.8	Details on the control circuit terminals of the inverter  Details on the control circuit terminals of the converter unit (FR-CC2).  Control logic (sink/source) change  Wiring of inverter control circuit.  Wiring precautions  When using separate power supplies for the control circuit and the main circuit  When supplying 24 V external power to the control circuit.  Safety stop function.	44 48 49 52 54 55 57
2.7	Communication connectors and terminals	61
2.7.1 2.7.2 2.7.3	PU connector USB connector RS-485 terminal block	62 63
2.8	Connection to a motor with encoder (Vector control)	о4

2.9	Parameter settings for a motor with encoder
2.10	Connection of stand-alone option units
2.10.1 2.10.2 2.10.3	Connection of the brake unit (FR-BU2).71Connection of the high power factor converter (FR-HC2).72Connection of the power regeneration converter (MT-RC).74
Cha	pter 3 PRECAUTIONS FOR USE OF THE INVERTER 76
3.1	Electro-magnetic interference (EMI) and leakage currents
3.1.1 3.1.2 3.1.3	Leakage currents and countermeasures.76Techniques and measures for electromagnetic compatibility (EMC)78Converter unit (FR-CC2) built-in EMC filter.81
3.2	Power supply harmonics
3.2.1 3.2.2	Power supply harmonics
3.3	Installation of a reactor
3.4	Power shutdown and magnetic contactor (MC)
3.5	Countermeasures against deterioration of the 400 V class motor insulation
3.6	Checklist before starting operation89
3.7	Failsafe system which uses the inverter92
Cha	pter 4 PROTECTIVE FUNCTIONS
4.1	Inverter fault and alarm indications
4.2	Reset method for the protective functions
4.3	Check and clear of the fault history
4.4	List of fault displays
Cha	pter 5 PRECAUTIONS FOR MAINTENANCE AND INSPECTION
5.1	Inspection item
5.1.1 5.1.2 5.1.3 5.1.4 5.1.5	Daily inspection104Periodic inspection104Daily and periodic inspection105Checking the inverter and converter semiconductor devices106Cleaning107

5.1.6 5.1.7	Replacement of parts
5.2	Measurement of main circuit voltages, currents, and powers
5.2.1 5.2.2 5.2.3 5.2.4 5.2.5 5.2.6 5.2.7 5.2.8	Measurement of powers113Measurement of voltages113Measurement of currents114Example of measuring converter unit (FR-CC2) input power factor114Measurement of converter output voltage (between terminals P and N)114Measurement of inverter output frequency114Insulation resistance test using megger114Pressure test115
Cha	apter 6 SPECIFICATIONS118
6.1	Inverter rating
6.2	Common specifications
6.3	Outline dimension drawings
Cha	apter 7 APPENDIX124
7.1	For customers replacing the conventional model with this inverter
7.1.1 7.1.2	Replacement of the FR-A740 series
7.2	Comparison with FR-A840
7.3	Instructions for compliance with the EU Directives
7.4	Instructions for UL and cUL
7.5	Instructions for EAC
7.6	Restricted Use of Hazardous Substances in Electronic and Electrical Products
7.7	Referenced Standard (Requirement of Chinese standardized law)

# Safety instructions

Thank you for choosing Mitsubishi Electric inverter.

This Instruction Manual describes handling and cautions about the hardware, such as installation and wiring, for the FR-A802 (separated converter type) inverter that are different from the FR-A800.

Information about the software, such as basic operations and parameters, is described in the FR-A800 Instruction Manual (Detailed) in the CD-ROM enclosed with the product. In addition to this manual, read all the relevant instruction manuals on the enclosed CD-ROM carefully to ensure proper use. Do not use this product until you have a full knowledge of this product's workings, safety information and instructions.

Please forward this Instruction Manual to the end user.

Do not attempt to install, operate, maintain or inspect this product until you have read the Instruction Manuals and appended documents carefully. Do not use this product until you have a full knowledge of this product mechanism, safety information and instructions.

Installation, operation, maintenance and inspection must be performed by qualified personnel. Here, qualified personnel means a person who meets all the following conditions:

- A person who possesses a certification in regard with electric appliance handling, or person took a proper engineering training. Such training may be available at your local Mitsubishi Electric office. Contact your local sales office for schedules and locations.
- A person who can access operating manuals for the protective devices (for example, light curtain) connected to the safety
  control system, or a person who has read these manuals thoroughly and familiarized themselves with the protective
  devices.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

**∴WARNING** In

Incorrect handling may cause hazardous conditions, resulting in death or severe injury.

**∴** CAUTION

Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

Note that even the **ACAUTION** level may lead to a serious consequence depending on conditions. Be sure to follow the instructions of both levels as they are critical to personnel safety.

#### **♦**Electric shock prevention

### **WARNING**

- Do not remove the front cover or the wiring cover while the power of this product is ON, and do not run this product with the front cover or the wiring cover removed as the exposed high voltage terminals or the charging part of the circuitry can be touched. Otherwise you may get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. as the inside of this product is charged. Otherwise you may get an electric shock.
- Before wiring or inspection, check that the LED display of the operation panel is OFF. Any person who is involved in
  wiring or inspection shall wait for 10 minutes or longer after the power supply has been cut off, and check that there are
  no residual voltage using a digital multimeter or the like. The capacitor is charged with high voltage for some time after
  power OFF, and it is dangerous.
- This product must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, IEC 61140 class 1 and other applicable standards). A neutral-point earthed (grounded) power supply must be used to be compliant with EN standard.
- Any person who is involved in wiring or inspection of this product shall be fully competent to do the work.
- This product body must be installed before wiring. Otherwise you may get an electric shock or be injured.
- Do not touch the setting dial or keys with wed hands. Doing so may cause an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Doing so may cause an electric shock.
- Do not change the cooling fan while power is ON as it is dangerous.
- Do not touch the printed circuit board or handle the cables with wet hands. Doing so may cause an electric shock.
- Before wiring or inspection for a PM motor, confirm that the PM motor is stopped as a PM motor is a synchronous motor with high-performance magnets embedded inside and high-voltage is generated at the motor terminals while the motor is running even after the power of this product is turned OFF. In an application, such as fan and blower, that the motor may be driven by the load, connect a low-voltage manual contactor at the output side of this product and keep it open during wiring and inspection of this product. Otherwise you may get an electric shock.

#### ◆Fire prevention

### **⚠CAUTION**

- This product must be installed on a nonflammable wall without holes in it so that its components cannot be touched from behind. Installing it on or near flammable material may cause a fire.
- If this product becomes faulty, the product power must be switched OFF. A continuous flow of large current may cause a fire.
- Be sure to perform daily and periodic inspections as specified in the Instruction Manual. There is a possibility of explosion, damage, or fire if this product is used without inspection.

#### ♦Injury prevention

### **CAUTION**

- The voltage applied to each terminal must be as specified in the Instruction Manual. Otherwise burst, damage, etc. may occur.
- The cables must be connected to the correct terminals. Otherwise burst, damage, etc. may occur.
- The polarity (+ and -) must be correct. Otherwise burst, damage, etc. may occur.
- While power is ON or for some time after power-OFF, do not touch this product as it will be extremely hot. Doing so may
  cause a burn.

#### Additional instructions

The following instructions must be also followed. If this product is handled incorrectly, it may cause unexpected fault, an injury, or an electric shock.

#### **↑** CAUTION

#### Transportation and installation

- To prevent injury, wear cut-resistant gloves when opening packaging with sharp tools.
- Use proper lifting techniques or a trolley when carrying products. Failure to do so may lead to injuries.
- Do not stand or place any heavy object on this product.
- Do not stack the boxes containing this product higher than the number recommended.
- When carrying this product, do not hold it by the front cover. It may fall or break.
- During installation, caution must be taken not to drop this product as doing so may cause injuries.
- The product must be installed on a surface that withstands the weight of the product.
- Do not install this product on a hot surface.
- Ensure the mounting orientation of this product is correct.
- Ensure this product is mounted securely in its enclosure.
- Do not install or operate this product if it is damaged or has parts missing.
- Foreign conductive objects must be prevented from entering this product. That includes screws and metal fragments or other flammable substance such as oil.
- As this product is a precision instrument, do not drop or subject it to impact.
- The surrounding air temperature must be between -10°C and +50°C (non-freezing) for this product at HD (heavy duty), ND (normal duty) (initial setting), or LD (light duty) rating, and between -10°C and +40°C (non-freezing) for this product at SLD (super light duty) rating. Otherwise this product may be damaged.
- The ambient humidity must be 95% RH or less (non-condensing) for this product. Otherwise the product may be damaged. (Refer to page 24for details.)
- The temporary storage temperature (applicable to a short limited time such as a transportation time) must be between 20°C and +65°C. Otherwise this product may be damaged.
- This product must be used indoors (without corrosive gas, flammable gas, oil mist, dust and dirt). Otherwise the product may be damaged.
- Do not use this product at an altitude above 2500 m. Vibration should not exceed 2.9 m/s<sup>2</sup> at 10 to 55 Hz in X, Y, and Z directions. Otherwise this product may be damaged. (Refer to page 24for details.)
- If halogens (including fluorine, chlorine, bromine, and iodine) contained in fumigants for wood packages enter this
  product, the product may be damaged. Prevent the entry of fumigant residuals or use an alternative method such as heat
  disinfection. Note that sterilization or disinfection of wood packages should be performed before packing the product.

#### Wiring

- Do not install a power factor correction capacitor, surge absorber, or radio noise filter on the output side of this product. These devices may overheat or burn out.
- The output of this product (output terminals U, V, W) must be correctly connected to a motor. Otherwise the motor will rotate inversely.
- Even with the power OFF, high voltage is still applied to the terminals U, V and W while the PM motor is running. Ensure the PM motor has stopped before carrying out any wiring. Otherwise you may get an electric shock.
- Never connect a PM motor to a commercial power supply. Connecting a commercial power supply to the input terminals
   (U, V, W) of a PM motor will burn it out. The PM motor must be applied a power from this product with the output terminals
   (U, V, W).

#### Test operation

Before starting the test operation, confirm or adjust the parameter settings. Failure to do so may cause some machines
to make unexpected motions.

# / WARNING

#### Usage

- Stay away from the equipment after using the retry function in this product as the equipment will restart suddenly after the output shutoff of this product.
- Depending on the function settings of this product, the product does not stop its output even when the STOP/RESET key on the operation panel is pressed. To prepare for it, provide a separate circuit and switch (to turn OFF the power of this product, or apply a mechanical brake, etc.) for an emergency stop.
- Be sure to turn OFF the start (STF/STR) signal before clearing the fault as this product will restart the motor suddenly after a fault is cleared.
- Do not use a PM motor for an application that the motor may be driven by the load and run at a speed higher than the maximum motor speed.
- Use only a three-phase induction motor or PM motor as a load on this product. Connection of any other electrical equipment to the output of this product may damage the equipment.
- Performing pre-excitation (by using the LX or X13 signal) during torque control (under Real sensorless vector control)
  may rotate a motor at a low speed even though a start command (STF or STR) is not given. This product with the start
  command ON may also rotate the motor at a low speed when the speed limit value is set to zero. Confirm that the motor
  running does not cause any safety problems before performing pre-excitation.
- Do not modify this product.
- Do not remove any part which is not instructed to be removed in the Instruction Manuals. Doing so may lead to a failure or damage of this product.

#### **⚠** CAUTION

#### Usage

- The electronic thermal O/L relay function may not be enough for protection of a motor from overheating. It is recommended to install an external thermal relay or a PTC thermistor for overheat protection.
- Do not repeatedly start or stop this product with a magnetic contactor on its input side. Doing so may shorten the life of this product.
- Use a noise filter or other means to minimize electromagnetic interference with other electronic equipment used nearby this product.
- Appropriate precautions must be taken to suppress harmonics. Otherwise harmonics in power systems generated from this product may heat/damage a power factor correction capacitor or a generator.
- To drive a 400V class motor with this product, use an insulation-enhanced motor, or take measures to suppress surge voltage. Otherwise surge voltage, which is attributed to the length and thickness of wire, may occur at the motor terminals, causing the motor insulation to deteriorate.
- As all parameters return to their initial values after the Parameter clear or All parameter clear is performed, the needed parameters for this product operation must be set again before the operation is started.
- This product can be easily set for high-speed operation. Therefore, consider all things related to the operation such as the performance of a motor and equipment in a system before the setting change.
- This product's brake function cannot be used as a mechanical brake. Use a separate device instead.
- Perform an inspection and test operation of this product if it has been stored for a long period of time.
- To avoid damage to this product due to static electricity, static electricity in your body must be discharged before you touch this product.
- Only one PM motor can be connected to a single unit of this product.
- A PM motor must be used under PM sensorless vector control. Do not use a synchronous motor, induction motor, or synchronous induction motor.
- Do not connect a PM motor to this product with it set to the induction motor control setting (initial setting). Do not connect an induction motor to this product with it set to the PM sensorless vector control setting. Doing so will cause failure.
- As a process of starting a PM motor, turn ON the power of this product first, and then close the contactor on the output side of this product.

#### Emergency stop

- A safety backup such as an emergency brake must be provided for devices or equipment in a system to prevent hazardous conditions in case of failure of this product or an external device controlling this product.
- If the breaker installed on the input side of this product trips, check for wiring faults (such as short circuits) and damage to internal parts of this product, etc. Identify and remove the cause of the trip before resetting the tripped breaker (or before applying the power to this product again).
- When any protective function is activated, take an appropriate corrective action before resetting this product to resume the operation.

#### Maintenance, inspection and parts replacement

• Do not carry out a megger (insulation resistance) test on the control circuit of this product. Doing so will cause failure.

#### Disposal

• This product must be treated as industrial waste.

Application of caution labels


Caution labels are used to ensure safety during use of Mitsubishi Electric inverters.

Apply the following labels to the inverter if the "retry function" and/or "automatic restart after instantaneous power failure" have been enabled.

• For the retry function





• For automatic restart after instantaneous power failure



Application of motor control labels

Apply the following labels to the inverter to avoid connecting a motor different from those intended for the motor control setting.





#### General instruction

• For clarity, illustrations in this Instruction Manual may be drawn with covers or safety guards removed. Ensure all covers and safety guards are properly installed prior to starting operation. For details on the PM motor, refer to the Instruction Manual of the PM motor.

# MEMO

# **CHAPTER 1 INTRODUCTION**

1.1	Product checking and accessories	.13
1.2	Inverter component names	.15
1.3	About the related manuals	.16

# INTRODUCTION

The contents described in this chapter must be read before using this product. Always read the instructions before use.

#### Abbreviations

Item	Description
DU	Operation panel (FR-DU08)
Operation panel	Operation panel (FR-DU08) and LCD operation panel (FR-LU08)
Parameter unit	Parameter unit (FR-PU07)
PU	Operation panel and parameter unit
Inverter	Mitsubishi Electric FR-A800 series inverter (separated converter type)
Vector control compatible option	FR-A8AP/FR-A8AL/FR-A8APA/FR-A8APR/FR-A8APS (plug-in option), FR-A8TP (control terminal option)
Pr.	Parameter number (Number assigned to function)
PU operation	Operation using the PU (operation panel/parameter unit)
External operation	Operation using the control circuit signals
Combined operation	Combined operation using the PU (operation panel/parameter unit) and External operation

#### **◆** Trademarks

- MODBUS is a registered trademark of SCHNEIDER ELECTRIC USA, INC.
- · Other company and product names herein are the trademarks and registered trademarks of their respective owners.

#### Notes on descriptions in this Instruction Manual

· Connection diagrams in this Instruction Manual appear with the control logic of the input terminals as sink logic, unless otherwise specified. (For the control logic, refer to page 49.)


# **♦** Harmonic suppression guidelines

All the models of the inverters used by specific consumers are covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage". (For details, refer to page 82.)

# 1.1 Product checking and accessories

Unpack the product and check the rating plate and the capacity plate of the inverter to ensure that the model agrees with the order and the product is intact.

#### ◆ Inverter model



<sup>\*1</sup> Specification differs by the type as follows.

		Initial setting					
Туре	Monitor output	Control logic	Rated frequency	Pr.19 Base frequency voltage			
FM (terminal FM equipped model)	Terminal FM (pulse train output) Terminal AM (analog voltage output (0 to ±10 VDC))	Sink logic	60 Hz	9999 (same as the power supply voltage)			
CA (terminal CA equipped model)	Terminal CA (analog current output (0 to 20 mADC)) Terminal AM (analog voltage output (0 to ±10 VDC))	Source logic	50 Hz	8888 (95% of the power supply voltage)			

<sup>\*2</sup> Conforming to IEC 60721-3-3 3C2/3S2




- In this Instruction Manual, the inverter model name consists of the applicable motor capacity and the rated current. (Example) FR-A842-07700(315K)
- By installing the FR-A8AVP, the inverter can be used as the high power factor converter. For details, refer to the FR-A8AVP Instruction Manual (For Inverter/Converter Switching).

# **♦ SERIAL** number

Rating plate example	The SERIAL consists of one symbol, two characters indicating the production year					
	and month, and six characters indicating the control number.					
Symbol Year Month Control number	The last digit of the production year is indicated as the Year, and the Month is					
SERIAL	indicated by 1 to 9, X (October), Y (November), or Z (December).					

# 1.2 Inverter component names

Component names are as follows.



Symbol	Name	Description	Refer to page
(a)	RS-485 terminals	Enables RS-485 communication.	63
(b)	Plug-in option connector 1		Instruction
(c)	Plug-in option connector 2	Connects a plug-in option or a communication option.	Manual of the
(d)	Plug-in option connector 3		option
(e)	Voltage/current input switch	Selects between voltage and current for the input via terminals 2 and 4.	*1
(f)	Control circuit terminal block	Connects cables for the control circuit.	44
(g)	PU connector	Connects the operation panel (FR-DU08) or the parameter unit (FR-PU07). This connector also enables the RS-485 communication.	61
(h)	USB A connector	Connects a USB memory device.	62
(i)	USB mini B connector	Connects a personal computer and enables communication with FR Configurator2.	62
(j)	Front cover (upper side)	Remove this cover for the installation of the product, installation of a plug-in (communication) option, RS-485 terminal wiring, switching of the voltage/current input switches, etc.	21
(k)	Power lamp	Stays ON while the power is supplied to the control circuit (R1/L11, S1/L21).	39
(I)	Alarm lamp	Turns ON when the protective function of the inverter is activated.	96
(m)	Charge lamp	Stays ON while the power is supplied to the main circuit.	39
(n)	Operation panel (FR-DU08)	Operates and monitors the inverter.	*1
(o)	Front cover (lower side)	Remove this cover for wiring.	21
(p)	Main circuit terminal block	Connects cables for the main circuit.	38
(q)	Cooling fan	Cools the inverter.	107
(r)	Switches (SW3 and SW4) for manufacturer setting	Do not change the initial setting (OFF Topics).	_

# About the related manuals

The manuals related to FR-A800 are as follows.

Manual name	Manual number
FR-A800 Instruction Manual (Detailed)	IB-0600503ENG
FR-CC2 Instruction Manual	IB-0600543ENG
FR Configurator 2 Instruction Manual	IB-0600516ENG
FR-A800/F800 PLC Function Programming Manual	IB-0600492ENG
FR-A800 Safety Stop Function Instruction Manual	BCN-A23228-001

# **CHAPTER 2** INSTALLATION AND WIRING


2.1	Peripheral devices	18
2.2	Removal and reinstallation of the operation panel or the front covers	21
2.3	Installation of the inverter and enclosure design	24
2.4	Terminal connection diagrams	33
2.5	Main circuit terminals	38
2.6	Control circuit	44
2.7	Communication connectors and terminals	61
2.8	Connection to a motor with encoder (Vector control)	64
2.9	Parameter settings for a motor with encoder	70
2 10	Connection of stand-alone ontion units	71

# 2 INSTALLATION AND WIRING

This chapter explains the installation and the wiring of this product. Always read the instructions before use.

# 2.1 Peripheral devices

# 2.1.1 Inverter and peripheral devices





- · To prevent an electric shock, always earth (ground) the motor, the inverter, and the converter unit.
- Do not install a power factor correction capacitor, surge suppressor, or capacitor type filter on the inverter's output side. Doing so will cause the inverter shut off or damage the capacitor or surge suppressor. If any of the above devices is connected, immediately remove it. When installing a molded case circuit breaker on the output side of the inverter, contact the manufacturer of the molded case circuit breaker.
- Electromagnetic wave interference:
  - The input/output (main circuit) of the inverter or the converter unit includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter or the converter unit. In this case, activating the EMC filter of the converter unit may minimize interference. (Refer to page 81.)
- For details of options and peripheral devices, refer to the respective Instruction Manual.
- A PM motor cannot be driven by the commercial power supply.
- A PM motor is a motor with permanent magnets embedded inside. High voltage is generated at the motor terminals while the
  motor is running. Before closing the contactor at the output side, make sure that the inverter power is ON and the motor is
  stopped.

Symbol	Name	Overview	Refer to page			
(a)	Inverter (FR-A802)	The life of the inverter and the converter unit is influenced by the				
(b)	Converter unit (FR-CC2)	surrounding air temperature.  The surrounding air temperature should be as low as possible within the permissible range. This must be noted especially when the inverter is installed in an enclosure.  Incorrect wiring may lead to damage of the inverter and the converter unit. The control signal lines must be kept fully away from the main circuit lines to protect them from noise.  The built-in EMC filter of the converter unit can reduce the noise.	24, 33, 81			
(c)	Three-phase AC power supply  Must be within the permissible power supply specifications of the converter unit.					
(d)	Molded case circuit breaker (MCCB), earth leakage circuit breaker (ELB), or fuse	Must be selected carefully since an inrush current flows in the converter unit at power ON.	20			
(e)	Install this to ensure safety.  Magnetic contactor (MC)  Magnetic contactor (MC)  Install this to ensure safety.  Do not use this to start and stop the inverter. Doing so will shorten the life of the inverter and the converter unit.					
(f)	AC reactor (FR-HAL)	Install this to suppress harmonics and to improve the power factor. An AC reactor (FR-HAL) (option) is required when installing the inverter near a large power supply system (1000 kVA or more). Under such condition, the inverter and the converter unit may be damaged if you do not use a reactor.  Select a reactor according to the applied motor capacity.	85			
(g)	Noise filter	Suppresses the noise radiated from the power supply side of the converter unit.	78			
(h)	High power factor converter (FR-HC2)	Suppresses the power supply harmonics significantly. Install this as required.  When FR-HC2 is used, FR-CC2 is not required.	72			
(i)	Brake unit (FR-BU2)	Allows the inverter to provide the optimal regenerative braking capability.	71			
(j)	Resistor unit (MT-BR5)	Install this as required.	/1			
(k)	USB connection	Connect between the inverter and a personal computer with a USB (ver. 1.1) cable.  Use a USB memory device to copy parameter settings or use the trace function.	62			
(I)	Noise filter	Install this to reduce the electromagnetic noise generated from the inverter and the converter unit. The noise filter is effective in the range from about 0.5 to 5 MHz.	78			
(m)	Induction motor	Connect a squirrel-cage induction motor.	_			
(n)	Contactor Example) No-fuse switch (DSN type)	Connect this for an application where a PM motor is driven by the load even while the inverter power is OFF. Do not open or close the contactor while the inverter is running (outputting).	_			
(o)	PM motor	A PM motor can be used. A PM motor cannot be driven by the commercial power supply.	_			

# 2.1.2 Peripheral devices

### **♦** Selecting the converter unit (FR-CC2)

Select the capacity of the FR-CC2 converter unit according to the connected motor capacity.

							Inve	erter						
Motor	Converter unit	SLD (	superlig	ht duty)	LC	) (light d	uty)	ND (no	rmal du value)	ty, initial	HD	(heavy	duty)	
capacity (kW) *1	30 A	FR-CC2-[]		el FR- 12-[]	Rated current (A)		el FR- 12-[]	Rated current (A)	Mode A84	el FR-  2-[]	Rated current (A)		el FR- 12-[]	Rated current (A)
280	H315K	_	_	_	_	_	_	_	_	_	315K	07700	547	
315	H315K	_	_	_	_	_	_	315K	07700	610	355K	08660	610	
355	H355K	_	_	_	315K	07700	683	355K	08660	683	400K	09620	683	
400	H400K	315K	07700	770	355K	08660	770	400K	09620	770	450K	10940	770	
450	H450K	355K	08660	866	400K	09620	866	450K	10940	866	500K	12120	866	
500	H500K	400K	09620	962	450K	10940	962	500K	12120	962	_	_	_	
560	H560K	450K	10940	1094	500K	12120	1094	_	_	_	_	_	_	
630	H630K	500K	12120	1212	_	_	_	_	_	_	_	_	-	

<sup>\*1</sup> The motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi Electric 4-pole standard motor.

#### ◆ Selecting the breaker / magnetic contactor

Check the model name of the inverter and the converter unit you purchased. Appropriate peripheral devices must be selected according to the capacity.


Refer to the following table to prepare appropriate peripheral devices.

400 V class

Motor output (kW)	Applicable converter model <sup>*1</sup>	Molded case circuit breaker (MCCB)*1*2or earth leakage circuit breaker (ELB) (NF or NV type)	Magnetic contactor (MC)*1*3on converter unit's input side
315	FR-CC2-H315K	700 A	S-N600
355	FR-CC2-H355K	800 A	S-N600
400	FR-CC2-H400K	900 A	S-N800
450	FR-CC2-H450K	1000 A	1000 A rated product
500	FR-CC2-H500K	1200 A	1000 A rated product
560	FR-CC2-H560K	1500 A	1200 A rated product
630	FR-CC2-H630K	2000 A	1400 A rated product

- \*1 Assumes the use of a Mitsubishi Electric 4-pole standard motor with the power supply voltage of 400 VAC 50 Hz.
- \*2 Select an MCCB according to the power supply capacity.

  Install one MCCB per converter unit. For the use in the United States or Canada, refer to page 130, and select the appropriate fuse.



\*3 The matrix shows the magnetic contactor selected according to the standards of Japan Electrical Manufacturers' Association (JEM standards) for AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the MC is used for emergency stops during motor driving, the electrical durability is 25 times.

When using an MC for emergency stop during driving the motor, select the MC with JEM 1038-AC-3 class rated current for the converter unit input current. When installing an MC on the inverter output side to switch to the commercial-power supply operation while running a general-purpose motor, select the MC for the rated motor current according to the rated current against JEM 1038 standards for AC-3 class.




- When the converter unit capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the converter unit model, and select cables and reactors according to the motor output.
- When the breaker on the converter unit's input side trips, check for the wiring fault (short circuit), damage to internal parts of
  the inverter or the converter unit, etc. The cause of the output shutoff must be identified and removed before turning ON the
  power of the breaker.


# 2.2 Removal and reinstallation of the operation panel or the front covers

# ◆ Removal and reinstallation of the operation panel

 Loosen the two screws on the operation panel. (These screws cannot be removed.)




 Press the upper edge of the operation panel while pulling out the operation panel.




To reinstall the operation panel, align its connector on the back with the PU connector of the inverter, and insert the operation panel. After confirming that the operation panel is fit securely, tighten the screws. (Tightening torque: 0.40 to 0.45 N·m)

# ◆ Removal of the front cover (lower side)




- (a) When the mounting screws are removed, the front cover (lower side) can be removed. (The number of the mounting screws differs by the capacity.)
- (b) With the front cover (lower side) removed, wiring of the main circuit terminals can be performed.

### ◆ Removal of the front cover (upper side)



- (a) With the front cover (lower side) removed, loosen the mounting screws on the front cover (upper side). (These screws cannot be removed.)
- (b) While holding the areas around the installation hooks on the sides of the front cover (upper side), pull out the cover using its upper side as a support.
- (c) With the front cover (upper side) removed, wiring of the control circuit and the RS-485 terminals and installation of the plugin option can be performed.

#### ◆ Reinstallation of the front cover



- (a) Insert the upper hooks of the front cover (upper side) into the sockets of the inverter.

  Securely install the front cover (upper side) to the inverter by fixing the hooks on the sides of the cover into place.
- (b) Tighten the mounting screw(s) at the lower part of the front cover (upper side).
- (c) Fasten the front cover (lower side) with the mounting screws. (The number of the mounting screws differs by the capacity.)



- When installing the front cover (upper side), fit the connector of the operation panel securely along the guides of the PU connector.
- Fully make sure that the front cover has been reinstalled securely. Always tighten the installation screws of the front cover.

# 2.3 Installation of the inverter and enclosure design

When designing or manufacturing an inverter enclosure, determine the structure, size, and device layout of the enclosure by fully considering the conditions such as heat generation of the contained devices and the operating environment. An inverter uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

### 2.3.1 Inverter installation environment

The following table lists the standard specifications of the inverter installation environment. Using the inverter in an environment that does not satisfy the conditions deteriorates the performance, shortens the life, and causes a failure. Refer to the following points, and take adequate measures.

#### ◆ Standard environmental specifications of the inverter

Item		Description			
Surrounding air	LD, ND (initial setting), HD	-10°C to +50°C (non-freezing)	Measurement position  Scm   Inverter   Scm   5cm		
temperature	SLD	-10°C to +40°C(non-freezing)	Measurement 5cm position		
Ambient humidity		With circuit board coating (conforming to class 3C2/3S2 in IEC 60721-3-3): 95% RH or less (non-condensing) Without circuit board coating: 90% RH or less (non-condensing)			
Storage temperature		-20°C to +65°C*1			
Atmosphere		Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)			
Altitude		Maximum 2500 m <sup>*2</sup>			
Vibration		2.9 m/s <sup>2</sup> or less at 10 to 55 Hz (directions of X, Y, Z axes)			

- \*1 Temperature applicable for a short time, for example, in transit.
- 2 For installation at an altitude above 1000 m, consider a 3% reduction in the rated current per 500 m increase in altitude.

# ◆ Temperature

The permissible surrounding air temperature of the inverter is between -10°C and +50°C (-10°C and +40°C at the SLD rating). Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures to keep the surrounding air temperature of the inverter within the specified range.

#### ■ Measures against high temperature

- Use a forced ventilation system or similar cooling system. (Refer to page 27.)
- · Install the enclosure in an air-conditioned electric chamber.
- · Block direct sunlight.
- · Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
- · Ventilate the area around the enclosure well.

#### ■ Measures against low temperature

- Provide a space heater in the enclosure.
- Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)

#### ■ Sudden temperature changes

- · Select an installation place where temperature does not change suddenly.
- Avoid installing the inverter near the air outlet of an air conditioner.
- · If temperature changes are caused by opening/closing of a door, install the inverter away from the door.



• For the amount of heat generated by the inverter unit, refer to page 26.

### Humidity

Operate the inverter within the ambient air humidity of usually 45 to 90% (up to 95% with circuit board coating). Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may cause a spatial electrical breakdown. The humidity conditions for the insulation distance defined in JEM 1103 standard "Insulation Distance from Control Equipment" is 45 to 85%.

#### ■ Measures against high humidity

- · Make the enclosure enclosed, and provide it with a hygroscopic agent.
- · Provide dry air into the enclosure from outside.
- · Provide a space heater in the enclosure.

#### ■ Measures against low humidity

Air with proper humidity can be blown into the enclosure from outside. Also, when installing or inspecting the unit, discharge your body (static electricity) beforehand, and keep your body away from the parts and patterns.

#### ■ Measures against condensation

Condensation may occur if frequent operation stops change the in-enclosure temperature suddenly or if the outside air temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- · Take the measures against high humidity.
- · Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)

#### **◆** Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contacts, reduced insulation and cooling effect due to the moisture-absorbed accumulated dust and dirt, and in-enclosure temperature rise due to a clogged filter. In an atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time. Since oil mist will cause similar conditions, it is necessary to take adequate measures.

#### **■** Countermeasure

- Place the inverter in a totally enclosed enclosure.
   Take measures if the in-enclosure temperature rises. (Refer to page 27.)
- Purge air.
   Pump clean air from outside to make the in-enclosure air pressure higher than the outside air pressure.

# ◆ Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the measures given in the previous paragraph.

# **♦** Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion-proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

# ♦ High altitude

Use the inverter at an altitude of within 2500 m. For use at an altitude above 1000 m, consider a 3% reduction in the rated current per 500 m increase in altitude.

If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

## ◆ Vibration, impact

The vibration resistance of the inverter is up to  $2.9 \text{ m/s}^2$  at 10 to 55 Hz frequency and 1 mm amplitude for the directions of X, Y, Z axes. Applying vibration and impacts for a long time may loosen the structures and cause poor contacts of connectors, even if those vibration and impacts are within the specified values.

Especially when impacts are applied repeatedly, caution must be taken because such impacts may break the installation feet.

#### Countermeasure

- Provide the enclosure with rubber vibration isolators.
- Strengthen the structure to prevent the enclosure from resonance.
- Install the enclosure away from the sources of the vibration.

# 2.3.2 Amount of heat generated by the inverter

### ♦ Installing the heat sink inside the enclosure

When the heat sink is installed inside the enclosure, the amount of heat generated by the inverter unit and converter unit is shown in the following tables.

Converter FR-CC2- H[]	Amount of heat generated (W)
315K	2350
355K	2600
400K	3050
450K	3400
500K	3800
560K	4400
630K	4920

Inverter FR-A842-[]	Amount of heat generated (W)				
inverter FK-A042-[]	SLD	LD	ND	HD	
315K	5800	5050	4450	3900	
355K	6690	5800	5100	4410	
400K	7370	6480	5650	4930	
450K	8600	7340	6500	5650	
500K	9810	8630	7400	6490	



• \* The amount of heat generated shown assumes that the output current is the inverter rated current, and the carrier frequency is 2 kHz.

## Installing the heat sink outside the enclosure

When the heat sink is installed outside the enclosure, the amount of heat generated by the inverter unit and the converter unit is shown in the following tables. (For the details on protruding the heat sink outside the enclosure, refer to page 30.)

Converter FR-CC2-	Amount of heat generated (W)					
H[]	Heat sink section (outside of enclosure)	Control section (inside of enclosure)				
315K	1640	710				
355K	1820	780				
400K	2130	920				
450K	2380	1020				
500K	2660	1140				
560K	3080	1320				
630K	3440	1480				

	Amount of heat generated (W)							
Inverter FR-A842-[]	Heat sink section (outside of enclosure)			Control section (inside of enclosure)				
	SLD	LD	ND	HD	SLD	LD	ND	HD
315K	4060	3530	3110	2730	1740	1520	1340	1170
355K	4680	4060	3570	3080	2010	1740	1530	1330
400K	5160	4530	3950	3450	2210	1950	1700	1480
450K	6020	5140	4550	3950	2580	2200	1950	1700
500K	6860	6040	5180	4540	2950	2590	2220	1950



<sup>• \*</sup> The amount of heat generated shown assumes that the output current is the inverter rated current, and the carrier frequency is 2 kHz.

# 2.3.3 Cooling system types for inverter enclosure

From the enclosure that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-enclosure temperature lower than the permissible temperatures of the in-enclosure equipment including the inverter.


The cooling systems are classified as follows in terms of the cooling calculation method.

- · Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- Cooling by heat sink (aluminum fin, etc.)
- Cooling by ventilation (forced ventilation type, pipe ventilation type)
- Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)

Cooling system		Enclosure structure	Comment		
	Natural ventilation (enclosed type / open type)	INV	This system is low in cost and generally used, but the enclosure size increases as the inverter capacity increases. This system is for relatively small capacities.		
Natural	Natural ventilation (totally enclosed type)		Being a totally enclosed type, this system is the most appropriate for hostile environment having dust, dirt, oil mist, etc. The enclosure size increases depending on the inverter capacity.		
Forced air	Heat sink cooling	Heat sink [INV	This system has restrictions on the heat sink mounting position and area. This system is for relatively small capacities.		
	Forced ventilation		This system is for general indoor installation. This is appropriate for enclosure downsizing and cost reduction, and often used.		
	Heat pipe	Heat pipe	This system is a totally enclosed type, and is appropriate for enclosure downsizing.		


### 2.3.4 Inverter installation

### ◆ Inverter placement



- · Install the inverter on a strong surface securely with screws.
- · Leave enough clearances and take cooling measures.
- · Avoid places where the inverter is subjected to direct sunlight, high temperature and high humidity.
- · Install the inverter on a nonflammable wall surface.
- · When encasing multiple inverters in an enclosure, install them in parallel as a cooling measure.
- For heat dissipation and maintenance, keep clearance between the inverter and the other devices or enclosure surface.

  The clearance below the inverter is required as a wiring space, and the clearance above the inverter is required as a heat dissipation space.
- When designing or building an enclosure for the inverter, carefully consider influencing factors such as heat generation of the contained devices and the operating environment.



\*1 For replacing the cooling fan, 30 cm or more of space is necessary in front of the inverter. Refer to page 107for fan replacement.

#### ◆ Installation orientation of the inverter

Install the inverter on a wall as specified. Do not mount it horizontally or in any other way.


#### **◆** Above the inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.

### ◆ Encasing multiple inverters and converter units

When multiple inverters and converter units are placed in the same enclosure, generally arrange them horizontally as shown in the figure below. Do not place multiple products vertically. The exhaust air temperature of the inverter and the converter unit may be increased.


When mounting multiple inverters and converter units, fully take caution not to make the surrounding air temperature of the inverter and the converter unit higher than the permissible value by providing ventilation and increasing the enclosure size.



Arrangement of multiple inverters and converter units

### ◆ Arrangement of the ventilation fan and inverter

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



Arrangement of the ventilation fan and inverter


# 2.3.5 Protruding the heat sink through a panel

When encasing the inverter to an enclosure, the heat generated in the enclosure can be greatly reduced by protruding the heat sink of the inverter.

When installing the inverter in a compact enclosure, etc., this installation method is recommended.


#### ■ Panel cutting

Cut the panel of the enclosure according to the inverter capacity.




#### ■ Removal of the rear installation frame

The upper and lower installation frames are attached on the inverter (two for each position). Remove the rear installation frames on the top and bottom of the inverter as follows.



#### ■ Installation of the inverter on the enclosure

Push the inverter heat sink part outside the enclosure, and fix the inverter to the panel with upper and lower installation frames.






- As the heat sink part protruded through the panel includes a cooling fan, this type of installation is not suitable for the environment of water drops, oil, mist, dust, etc.
- Be careful not to drop screws, dust etc. into the inverter and cooling fan section.

# 2.4 Terminal connection diagrams

#### ◆ FM type




- \*1 Terminals R1/L11 and S1/L21 are connected to terminals P/+ and N/- with a jumper respectively. When using separate power supply for the control circuit, remove the jumpers connected to terminals R1/L11 and S1/L21.
- \*2 The function of these terminals can be changed using the Input terminal function selection (Pr.178 to Pr.189).
- \*3 Terminal JOG is also used as a pulse train input terminal. Use Pr.291 to choose JOG or pulse.
- \*4 The X10 signal (NC contact input specification) is assigned to the terminal MRS in the initial setting. Set **Pr.599** = "0" to change the input specification of the X10 signal to NO contact.
- \*5 Terminal input specifications can be changed by analog input specification switchover (**Pr.73**, **Pr.267**). To input voltage (0 to 5 V/0 to 10 V), set the voltage/current input switch OFF. To input current (4 to 20 mA), set the voltage/current input switch ON. Terminals 10 and 2 are also used as a PTC input terminal. (**Pr.561**)
- \*6 It is recommended to use 2 W 1 kΩ when the frequency setting signal is changed frequently.
- \*7 The function of these terminals can be changed using the Output terminal function selection (Pr.195 or Pr.196).
- \*8 The function of these terminals can be changed using the Output terminal function selection (Pr.190 to Pr.194).
- \*9 No function is assigned in the initial setting. Use **Pr.192** for function assignment.
- \*10 Terminal FM can be used to output pulse trains as open collector output by setting Pr.291.
- \*11 Not required when calibrating the scale with the operation panel.



- To prevent a malfunction due to noise, keep the signal cables 10 cm or more away from the power cables. Also, keep the cables of the main circuit for input and output separated.
- After wiring, wire offcuts must not be left in the inverter.
  - Wire offcuts can cause a fault, failure or malfunction. Always keep the inverter clean.
  - When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter.
- Set the switches of the voltage/current input selection switch assembly correctly. Incorrect setting may cause a fault, failure or malfunction.

### ◆ CA type



<sup>\*1</sup> Terminals R1/L11 and S1/L21 are connected to terminals P/+ and N/- with a jumper respectively. When using separate power supply for the control circuit, remove the jumpers connected to terminals R1/L11 and S1/L21.

<sup>\*2</sup> The function of these terminals can be changed using the Input terminal function selection (Pr.178 to Pr.189).

<sup>\*3</sup> Terminal JOG is also used as a pulse train input terminal. Use **Pr.291** to choose JOG or pulse.

- \*4 The X10 signal (NC contact input specification) is assigned to the terminal MRS in the initial setting. Set **Pr.599** = "0" to change the input specification of the X10 signal to NO contact.
- \*5 Terminal input specifications can be changed by analog input specification switchover (**Pr.73**, **Pr.267**). To input voltage (0 to 5 V/0 to 10 V), set the voltage/current input switch OFF. To input current (4 to 20 mA), set the voltage/current input switch ON. Terminals 10 and 2 are also used as a PTC input terminal. (**Pr.561**)
- $^{*}6$  It is recommended to use 2 W 1 k $\Omega$  when the frequency setting signal is changed frequently.
- \*7 The function of these terminals can be changed using the Output terminal function selection (Pr.195 or Pr.196).
- 78 The function of these terminals can be changed using the Output terminal function selection (Pr.190 to Pr.194).
- \*9 No function is assigned in the initial setting. Use **Pr.192** to assign a function to the terminal.



- To prevent a malfunction due to noise, keep the signal cables 10 cm or more away from the power cables. Also, keep the cables of the main circuit for input and output separated.
- After wiring, wire offcuts must not be left in the inverter.
  - Wire offcuts can cause a fault, failure or malfunction. Always keep the inverter clean.
- When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter.
- Set the switches of the voltage/current input selection switch assembly correctly. Incorrect setting may cause a fault, failure or malfunction.


#### ◆ Connection between the converter unit and the inverter

Wire correctly to ensure the command transmission from the converter unit to the inverter. Otherwise, the converter unit and the inverter may be damaged.

For the wiring length, refer to the following tables.

Location in the connection diagram	Total wiring length
Between the terminals P and P and the terminals N and N	50m or shorter
Other control signal cables	30m or shorter

For the cable gauge of the cable across the main circuit terminals P/+ and N/- (P and P, N and N), refer to page 40.



- \*1 Do not install an MCCB across terminals P/+ and N/- (between terminals P and P/+ or between terminals N and N/-). Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.
- \*2 For the X10 signal input, set "10" in any parameter from **Pr.178 to Pr.189 (Input terminal function selection)** to assign the function. (The X10 signal is assigned to terminal MRS in the initial setting.)
  - The state of contact at terminal MRS is initially set to be normally closed (NC). To change the contact state to normally open (NO), set **Pr.599** = "0".
- \*3 For the X11 signal input, set "11" in any parameter from **Pr.178 to Pr.189 (Input terminal function selection)** to assign the function. For RS-485 or any other communication where the start command is only transmitted once, use the X11 signal to save the operation mode at the time of an instantaneous power failure.
- \*4 Always connect terminal RDA of the converter unit and terminal MRS (X10) of the inverter, and terminal SE of the converter unit and terminal SD (sink logic) of the inverter. Otherwise, the converter unit may be damaged.

#### 2.5 Main circuit terminals


#### Details on the main circuit terminals of the inverter 2.5.1

Terminal symbol	Terminal name	Terminal function description	Refer to page
U, V, W	Inverter output	Connect these terminals to a three-phase squirrel cage motor or a PM motor.	_
R1/L11, S1/L21	Power supply for the control circuit	Connected to terminals P/+ and N/ To retain the fault display and fault output, or to use the converter unit (FR-CC2), remove the jumpers installed in terminals R1/L11 and S1/L21, and apply external power supply to these terminals.  When using a separate power supply connected to terminals R1/L11 and S1/L21, the necessary power capacity is 80 VA.	55
P/+, N/- Converter unit connection		Connect the converter unit (FR-CC2), brake unit (FR-BU2), or high power factor converter (FR-HC2).	33, 71
	Earth (ground)	For earthing (grounding) the inverter chassis. Be sure to earth (ground) the inverter.	43

### Details on the main circuit terminals of the 2.5.2 converter unit (FR-CC2)

Terminal symbol	Terminal name	Terminal function description	Refer to page
R/L1, S/L2, T/L3	AC power input	Connect these terminals to the commercial power supply. (When the converter unit is connected to the 12-phase rectifier power transformer, refer to the Instruction Manual of the FR-CC2.)	_
R1/L11, S1/L21	Power supply for the control circuit	Connected to the AC power supply terminals R/L1 and S/L2. To retain the fault display and fault output, remove the jumpers across terminals R/L1 and R1/L11 and across S/L2 and S1/L21, and apply external power to these terminals.  When using a separate power supply connected to terminals R1/L11 and S1/L21, the necessary power capacity is 80 VA.	55
P/+, N/-	Inverter connection	Connected to the inverter terminals P/+ and N/	33
	Earth (ground)	For earthing (grounding) the converter unit chassis. This product must be earthed (grounded).	43


# 2.5.3 Main circuit terminal layout and wiring to power supply and motor






- Make sure the power cables are connected to the R/L1, S/L2, and T/L3 of the converter unit. (Phase need not be matched.)
   Never connect the power cable to the U, V, and W of the inverter. Doing so will damage the inverter.
- Connect the motor to the U, V, and W of the inverter. (The phases must be matched.)
- When wiring cables to the main circuit conductor, tighten each nut from the right of the conductor as seen from the front of the
  unit.

When wiring two cables, place cables on both sides of the conductor. (Refer to the diagram below.) For wiring, use bolts (nuts) provided with the inverter.



• When wiring the main circuit conductor (R/L1, S/L2, T/L3) of the converter unit (FR-CC2), use bolts (nuts) for wiring the main circuit before the conductor.



#### 2.5.4 Applicable cables and wiring length

Select a recommended size cable to ensure that the voltage drop ratio is within 2%.

If the wiring distance is long between the inverter and motor, the voltage drop in the main circuit will cause the motor torque to decrease especially at a low speed.

The following tables show a selection example for the wiring length of 20 m (at 440 V input power supply).

• Converter unit (FR-CC2)

		ew torque	Crimp	Cable gauge						
Converter model FR-	Terminal screw		terminal	HIV cables, etc. (mm²) <sup>*1</sup>			AWG/ MCM <sup>*2</sup>	PVC cables,	, etc. (mm²) <sup>*3</sup>	
CC2-H-[]	size*4		R/L1, S/L2, T/L3	R/L1, S/L2, T/L3	P/+, N/-	Earthing (grounding) cable	R/L1, S/L2, T/L3	R/L1, S/L2, T/L3	Earthing (grounding) cable	
315K	M12 (M10)	46	150-12	2×150	2×150	100	2×300	2×150	150	
355K	M12 (M10)	46	C2-200	2×200	2×200	100	2×350	2×185	2×95	
400K	M12 (M10)	46	C2-200	2×200	2×200	100	2×400	2×185	2×95	
450K	M12 (M10)	46	C2-250	2×250	2×250	100	2×500	2×240	2×120	
500K	M12 (M10)	46	C2-200	3×200	3×200	2×100	2×500	2×240	2×120	
560K	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×350	3×185	2×150	
630K	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×400	3×185	2×150	

· Inverter (ND rating)

		Terminal Tightening screw torque size*4 (N·m)	Crimp			Cable	gauge		
Inverter model FR-	screw		terminal	HIV cables, etc. (mm <sup>2</sup> )*1			AWG/ MCM <sup>*2</sup>	PVC cables	, etc. (mm²) <sup>*3</sup>
A842-[]			U, V, W	U, V, W	P/+, N/-	Earthing (grounding) cable	U, V, W	U, V, W	Earthing (grounding) cable
07700(315K)	M12 (M10)	46	150-12	2×150	2×150	100	2×300	2×150	150
08660(355K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×350	2×185	2×95
09620(400K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×400	2×185	2×95
10940(450K)	M12 (M10)	46	C2-250	2×250	2×250	100	2×500	2×240	2×120
12120(500K)	M12 (M10)	46	C2-250	2×250	3×200	2×100	2×500	2×240	2×120

• Inverter (SLD rating)

		Ferminal Tightening screw torque size*4 (N·m)	Crimp	Cable gauge					
Inverter model FR- A842-[]			terminal	HIV cables, etc. (mm <sup>2</sup> ) <sup>*1</sup>			AWG/ MCM <sup>*2</sup>	PVC cables	, etc. (mm <sup>2</sup> ) <sup>*3</sup>
			U, V, W	U, V, W	P/+, N/-	Earthing (grounding) cable	U, V, W	U, V, W	Earthing (grounding) cable
07700(315K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×400	2×185	2×95
08660(355K)	M12 (M10)	46	C2-250	2×250	2×250	100	2×500	2×240	2×120
09620(400K)	M12 (M10)	46	C2-250	2×250	3×200	2×100	2×500	2×240	2×120
10940(450K)	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×350	3×185	2×150
12120(500K)	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×400	3×185	2×150

· Inverter (LD rating)

		Terminal Screw torque size*4 (N·m)	Crimp	Cable gauge						
Inverter model FR- A842-[]	screw		terminal	HIV cables, etc. (mm <sup>2</sup> )*1			AWG/ MCM <sup>*2</sup>	PVC cables	, etc. (mm <sup>2</sup> ) <sup>*3</sup>	
			U, V, W	U, V, W	P/+, N/-	Earthing (grounding) cable	U, V, W	U, V, W	Earthing (grounding) cable	
07700(315K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×350	2×185	2×95	
08660(355K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×400	2×185	2×95	
09620(400K)	M12 (M10)	46	C2-250	2×250	2×250	100	2×500	2×240	2×120	
10940(450K)	M12 (M10)	46	C2-250	2×250	3×200	2×100	2×500	2×240	2×120	
12120(500K)	M12 (M10)	46	C2-200	3×200	3×200	2×100	3×350	3×185	2×150	

#### · Inverter (HD rating)

	Terminal screw size <sup>*4</sup>	screw torque	Crimp	Cable gauge						
Inverter model FR- A842-[]			terminal	HIV cables, etc. (mm <sup>2</sup> )*1			AWG/ MCM <sup>*2</sup>	PVC cables	, etc. (mm²) <sup>*3</sup>	
			U, V, W	U, V, W	P/+, N/-	Earthing (grounding) cable	U, V, W	U, V, W	Earthing (grounding) cable	
07700(315K)	M12 (M10)	46	150-12	2×125	2×150	100	2×250	2×120	150	
08660(355K)	M12 (M10)	46	150-12	2×150	2×150	100	2×300	2×150	150	
09620(400K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×350	2×185	2×95	
10940(450K)	M12 (M10)	46	C2-200	2×200	2×200	100	2×400	2×185	2×95	
12120(500K)	M12 (M10)	46	C2-250	2×250	2×250	100	2×500	2×240	2×120	

- \*1 The recommended cable size is that of the cable (LMFC (heat resistant flexible cross-linked polyethylene insulated cable), etc.) with continuous maximum permissible temperature of 90°C or higher. It assumes a surrounding air temperature of 50°C or lower and in-enclosure wiring.
- \*2 It is the gauge of the cable with continuous maximum permissible temperature of 90°C (THHN cable). It assumes a surrounding air temperature of 40°C or lower and in-enclosure wiring.
  - (For the use in the United States or Canada, refer to page 130.)
- \*3 The recommended cable size is that of the cable (XLPE cable) with continuous maximum permissible temperature of 90°C. It assumes a surrounding air temperature of 40°C or lower and in-enclosure wiring.

  (Selection example mainly for use in Europe.)
- \*4 The screw size for terminals R/L1, S/L2, T/L3, U, V, W, P/+, N/-, and the earthing (grounding) terminal are shown. Screw size for earthing (grounding) is indicated in parentheses.

The line voltage drop can be calculated by the following formula:

Line voltage drop [V] = 
$$\frac{\sqrt{3} \times \text{wire resistance } [\text{m}\Omega/\text{m}] \times \text{wiring distance } [\text{m}] \times \text{current } [\text{A}]}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.




- Tighten the terminal screw to the specified torque.
  - A screw that has been tightened too loosely can cause a short circuit or malfunction.
  - A screw that has been tightened too tightly can cause a short circuit or malfunction due to the unit breakage.
- Use crimp terminals with insulation sleeves to wire the power supply and motor.

#### ◆ Total wiring length

#### **■** With induction motor

Connect one or more general-purpose motors within the total wiring length 500 m. (The wiring length should be 100 m or shorter under Vector control.)



When driving a 400 V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor. In this case, take one of the following measure.

• Use a "400 V class inverter-driven insulation-enhanced motor" and set **Pr.72 PWM frequency selection** according to the wiring length.

Wiring length 100 m or shorter	Wiring length longer than 100 m
6 (6 kHz) or lower	4 (4 kHz) or lower

• If the motor capacity is 280 kW or lower, connect the sine wave filter (MT-BSL/BSC) to the output side.

#### ■ With PM motor

Use the wiring length of 100 m or shorter when connecting a PM motor.

Use one PM motor for one inverter. Multiple PM motors cannot be connected to an inverter.

When the wiring length exceeds 50 m for a 400 V class motor driven by an inverter under PM sensorless vector control, set "9" (6 kHz) or less in **Pr.72 PWM frequency selection**.



- Especially for long-distance wiring, the inverter may be affected by a charging current caused by stray capacitances of the
  wiring, leading to an activation of the overcurrent protection, malfunction of the fast-response current limit operation, or even
  to an inverter failure. It may also cause a malfunction or fault of the equipment connected ON the inverter output side. If the
  fast-response current limit function malfunctions, disable the function. (For the details of Pr.156 Stall prevention operation
  selection, refer to the FR-A800 Instruction Manual (Detailed).)
- · A sine wave filter (MT-BSL/BSC) can be used under V/F control. Do not use the filters under different control methods.
- For the details of Pr.72 PWM frequency selection, refer to the Instruction Manual (Detailed).
- Refer to page 88 to drive a 400 V class motor by an inverter.
- The carrier frequency is limited during PM sensorless vector control. (Refer to the Instruction Manual (Detailed).)

## 2.5.5 Earthing (grounding) precautions

· Always earth (ground) the motor, the inverter, and the converter unit.

## **♦** Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use.


An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flows into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operators from getting an electric shock from this leakage current when touching it.


To avoid the influence of external noises, the earthing (grounding) is important to EMI-sensitive equipment that handle low-level signals or operate very fast such as audio equipment, sensors, computers.


## Earthing (grounding) system to be established

As described previously, the purpose of earthing (grounding) is roughly classified into the electrical shock prevention and the prevention of malfunction due to the influence of electromagnetic noise. These two purposes should be clearly distinguished, and the appropriate earth (ground) system must be established to prevent the leakage current having the inverter's high frequency components from reversing through another earth (ground) point for malfunction prevention by following these instructions:

- Make the separate earth (ground) connection (I) for high frequency products such as the inverter from any other devices (EMI-sensitive devices described above) wherever possible.
  - Establishing adequate common (single-point) earth (ground) system (II) shown in the following figure is allowed only in cases where the separate earth (ground) system (I) is not feasible. Do not make inadequate common (single-point) earth (ground) connection (III).
  - As leakage currents containing many high frequency components flows into the earthing (grounding) cables of the inverter and peripheral devices (including a motor), the inverter must also be earthed (grounded) separately from EMI-sensitive devices described above.
  - In a high building, it may be effective to use its iron structure frames as earthing (grounding) electrode for EMI prevention in order to separate from the earth (ground) system for electric shock prevention.
- Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical codes (NEC section 250, IEC 61140 class 1 and other applicable standards).
  - A neutral-point earthed (grounded) power supply must be used to be compliant with EN standard.
- Use the thickest possible earthing (grounding) cable. The earthing (grounding) cable should be the size indicated in the table on page 40.
- The earthing (grounding) point should be as close as possible to the inverter, and the earth (ground) wire length should be as short as possible.
- Run the earthing (grounding) cable as far away as possible from the I/O wiring of the EMI-sensitive devices and run them in parallel in the minimum distance.









• To be compliant with the EU Directive (Low Voltage Directive), refer to page 127.

#### 2.6 **Control circuit**

#### Details on the control circuit terminals of the 2.6.1 inverter

For the parameter details, refer to the FR-A800 Instruction Manual (Detailed).

## ◆ Input signal

Туре	Terminal symbol	Terminal name	Terminal function descrip	tion	Rated specification			
	STF*1	Forward rotation start	Turn ON the STF signal to start forward rotation and turn it OFF to stop.	When the STF and STR signals are turned ON				
	STR*1	Reverse rotation start	Turn ON the STR signal to start reverse rotation and turn it OFF to stop.	simultaneously, the stop command is given.	Input resistance: 4.7 kΩ,			
	STOP*1	Start self-holding selection	Turn ON the STOP signal to self-hold the start s	ignal.	voltage when contacts are open: 21 to 27 VDC,			
	RH RM RL*1	Multi-speed selection	Multi-speed can be selected according to the corRL signals.	nbination of RH, RM and	current when contacts are short-circuited: 4 to 6 mADC			
		Jog mode selection	Turn ON the JOG signal to enable JOG operatio ON the start (STF or STR) signal to start JOG o					
	JOG*1	Pulse train input	Terminal JOG is also used as a pulse train input pulse train input terminal, change the <b>Pr.291</b> set (maximum input pulse: 100k pulses/s)	Input resistance: 2 kΩ, current when contacts are short-circuited: 8 to 13 mADC				
	RT*1	Second function selection	Turn ON the RT signal to enable the second fun When the second function such as "second torque F (base frequency)" is set, turning ON the RT sign function.	ue boost" and "second V/				
t	MRS (X10)*1	Output stop (Inverter operation enable)	Connect to the terminal RDA of the converter un RDA signal is turned OFF, the inverter output is The X10 signal (NC contact) is assigned to the testing. Use <b>Pr.599</b> to change the specification to	Input resistance: 4.7 $k\Omega$ , voltage when contacts				
Contact input	RES <sup>*1</sup>	Reset	is activated. Turn ON the RES signal for 0.1 seconoff.  In the initial setting, reset is always enabled. By	Use this signal to reset a fault output provided when a protective function is activated. Turn ON the RES signal for 0.1 second or longer, then turn it DFF.  In the initial setting, reset is always enabled. By setting <b>Pr.75</b> , reset can be enabled only at an inverter fault occurrence. The inverter recovers				
	AU <sup>*1</sup>	Terminal 4 input selection	The terminal 4 function is available only when th Turning the AU signal ON makes terminal 2 inva					
	CS*1	Selection of automatic restart after instantaneous power failure	When the CS signal is left ON, the inverter restar restoration. Note that restart setting is necessary the converter unit for this operation. In the initial disabled.	on both the inverter and				
		Contact input common (sink)*3	Common terminal for the contact input terminal FM.	(sink logic) and terminal				
	SD	External transistor common (source)*4	Connect this terminal to the power supply commo output (open collector output) device, such as a pin the source logic to avoid malfunction by under	orogrammable controller,	_			
		24 VDC power supply common	Common terminal for the 24 VDC power supply +24). Isolated from terminals 5 and SE.	,				
	PC	External transistor common (sink)*3	Connect this terminal to the power supply commo output (open collector output) device, such as a in the sink logic to avoid malfunction by undesira	orogrammable controller,	Power supply voltage range: 19.2 to 28.8			
	70	Contact input common (source)*4	Common terminal for contact input terminal (sou	rce logic).	VDC, permissible load current: 100 mA			
		24 VDC power supply	Can be used as a 24 VDC 0.1 A power supply.					

Туре	Terminal symbol	Terminal name	Terminal function description	Rated specification
	10E	Frequency setting	When connecting the frequency setting potentiometer at an initial status, connect it to terminal 10.	10 ±0.4 VDC, permissible load current: 10 mA
	10	power supply	Change the input specifications of terminal 2 using <b>Pr.73</b> when connecting it to terminal 10E.	5 ±0.5 VDC, permissible load current: 10 mA
Đ.	2	Frequency setting (voltage)	Inputting 0 to 5 VDC (or 0 to 10 V, 0 to 20 mA) provides the maximum output frequency at 5 V (10 V, 20 mA) and makes input and output proportional. Use <b>Pr.73</b> to switch among input 0 to 5 VDC (initial setting), 0 to 10 VDC, and 0 to 20 mA. Set the voltage/current input switch in the ON position to select current input (0 to 20 mA).*2	For voltage input, Input resistance: 10 ±1 kΩ, maximum permissible voltage: 20 VDC.
Frequency setting	4	Frequency setting (current)	Inputting 4 to 20 mADC (or 0 to 5 V, 0 to 10 V) provides the maximum output frequency at 20 mA and makes input and output proportional. This input signal is valid only when the AU signal is ON (terminal 2 input is invalid). Use <b>Pr.267</b> to switch among input 4 to 20 mA (initial setting), 0 to 5 VDC, and 0 to 10 VDC. Set the voltage/current input switch in the OFF position to select voltage input (0 to 5 V/0 to 10 V).*2Use <b>Pr.858</b> to switch terminal functions.	For current input, Input resistance: 245 ±5 Ω, maximum permissible current: 30 mA.  Voltage/current input switch switch switch 2 switch 1 4
	1	Frequency setting auxiliary	Input 0 to ±5 VDC or 0 to ±10 VDC to add this signal to the frequency setting signal input via terminal 2 or 4. Use <b>Pr.73</b> to switch between input 0 to ±5 VDC and 0 to ±10 VDC (initial setting). Use <b>Pr.868</b> to switch terminal functions.	Input resistance: 10 ±1 kΩ, maximum permissible voltage: ±20 VDC.
	5	Frequency setting common	Common terminal for the frequency setting signal (via terminal 2, 1, or 4) and for the analog output terminals AM and CA. Do not earth (ground).	_
Thermistor	10 2	PTC thermistor input	For receiving PTC thermistor outputs. When PTC thermistor is valid ( <b>Pr.561</b> ≠ "9999"), terminal 2 is not available for frequency setting.	Applicable PTC thermistor specification, overheat detection resistance: 0.5 to 30 kΩ (Set by <b>Pr.561</b> )
Power supply input	+24 24 V external power supply input		For connecting a 24 V external power supply.  If a 24 V external power supply is connected, power is supplied to the control circuit while the main power circuit is OFF.	Input voltage: 23 to 25.5 VDC, input current: 1.4 A or less

- \*1 Terminal functions can be selected using Pr.178 to Pr.189 (Input terminal function selection).
- \*2 Set **Pr.73**, **Pr.267**, and the voltage/current input switch correctly, then input an analog signal in accordance with the setting.

  Applying a voltage with the switch ON (current input is selected) or applying a current with the switch OFF (voltage input is selected) could cause component damage of the inverter or analog circuits of output devices. (Refer to the Instruction Manual (Detailed).)
- $^{\star}3$  Sink logic is initially set for the FM-type inverter.
- \*4 Source logic is initially set for the CA-type inverter.

# ◆ Output signal

Туре	Terminal symbol	Terminal name	Terminal function descripti	on	Rated specification			
Relay	A1, B1, C1 <sup>*1</sup>	Relay output 1 (fault output)	1 changeover contact output that indicates that ar function has been activated and the outputs are s Fault: discontinuity across B and C (continuity acr continuity across B and C (discontinuity across A	topped. oss A and C), Normal:	Contact capacity: 230 VAC 0.3 A (power factor = 0.4), 30			
, ŭ	A2, B2, C2 <sup>*1</sup>	Relay output 2	1 changeover contact output	·				
	RUN*1	Inverter running	The output is in LOW state when the inverter output or higher than the starting frequency (initial value: in HIGH state during stop or DC injection brake op	0.5 Hz). The output is				
	SU*1	Up to frequency	The output is in LOW state when the output frequency is within the set frequency range ±10% (initial value). The output is in HIGH state during acceleration/deceleration and at a stop.		Permissible load: 24 VDC (27 VDC at maximum) 0.1 A (The voltage drop is			
Open collector	OL*1	Overload alarm	The output is in LOW state when stall prevention is activated by the stall prevention function. The output is in HIGH state when stall prevention is canceled.	Fault code (4 bits)	2.8 V at maximum while the signal is ON.) The open collector transistor is ON (conductive) in LOW state. The transistor is OFF			
Ope	IPF*1	Open collector output	No function is assigned in the initial setting. Use <b>Pr.192</b> to assign a function to the terminal.	output.				
	FU <sup>*1</sup>	Frequency detection	The output is in LOW state when the inverter output frequency is equal to or higher than the preset detection frequency, and is in HIGH state when it is less than the preset detection frequency.	(not conductive) in HIGH state.				
	SE	Open collector output common	Common terminal for terminals RUN, SU, OL, IPF	, FU	_			
Pulse	FM*2	For meter		Output item: output frequency (initial setting)	Permissible load current: 2 mA, pulse for full scale: 1440 pulses/s			
Pul	FM <sup>2</sup>	NPN open collector output	Among several monitor items such as output frequency, select one to output it via these terminals. The signal is not output during an	This terminal can be used for open collector outputs by setting <b>Pr.291</b> .	Maximum output pulse: 50k pulses/s, permissible load current: 80 mA			
Analog	АМ	Analog voltage output	inverter reset.  The size of output signal is proportional to the magnitude of the corresponding monitor item.  Use Pr.55, Pr.56, and Pr.866 to set full scales for the monitored output frequency, output current, and torque.	Output item: output frequency (initial setting)	Output signal: 0 ±10 VDC, permissible load current: 1 mA (load impedance 10 kΩ or more), resolution: 8 bits			
	CA <sup>*3</sup>	Analog current output			Load impedance: 200 to 450 $\Omega$ , output signal: 0 to 20 mADC			

<sup>\*1</sup> Terminal functions can be selected using Pr.190 to Pr.196 (Output terminal function selection).

### Communication

<sup>\*2</sup> Terminal FM is provided in the FM-type inverter.
\*3 Terminal CA is provided in the CA-type inverter.

Туре		erminal symbol	Terminal name	Terminal function description				
85	_		— PU connector		PU connector	RS-485 communication can be made through the PU connector (For connection on a 1:1 basis only)  Conforming standard: EIA-485 (RS-485)  Transmission format: Multidrop link  Communication speed: 4800 to 115200 bps  Wiring length: 500 m		
RS-485	als	TXD+	Inverter transmission	RS-485 communication can be made through the RS-485 terminals.				
	termina	TXD-	terminal	Conforming standard: EIA-485 (RS-485) Transmission format: Multidrop link Communication speed: 300 to 115200 bps				
	RS-485 ter	RXD+	Inverter reception					
		RXD-	terminal					
		SG	Earthing (grounding)	Overall length: 500 m				
8	_		USB A connector	A connector (receptacle). Plug a USB memory device into this connector to copy parameter settings or use the trace function.	Interface: conforms to USB 1.1 (USB 2.0 full-			
USB			USB B connector	Mini B connector (receptacle). By connecting the inverter to a personal computer via this connector, FR Configurator2 installed on the computer can be used for setting the inverter, or monitoring or testing the inverter operation.	speed compatible) Transmission speed: 12 Mbps			

# ♦ Safety stop signal

Terminal symbol	Terminal name	Terminal function description	Rated specification	Refer to page
S1	Safety stop input (Channel 1)	Use terminals S1 and S2 to receive the safety stop signal input from the safety relay module. Terminals S1 and S2 can be used at a time (dual channel).  The Inverter judges the condition of the internal safety circuit from the status (shorted/opened) between terminals S1 and SIC, or	Input resistance: $4.7 \text{ k}\Omega$ ,	
S2	Safety stop input (Channel 2)	between S2 and SIC. When the status is opened, the inverter output is shut off.  In the initial status, terminal S1 and S2 are shorted with terminal PC by shorting wires. Terminal SIC is shorted with terminal SD. Remove the shorting wires and connect the safety relay module when using the safety stop function.	input current: 4 to 6 mADC (with 24 VDC input)	
SIC	Safety stop input terminal common	Common terminal for terminals S1 and S2.	_	59
So (SO)	Safety monitor output (open collector output)	The output status varies depending on the input status of the safety stop signals.  The output is in HIGH state during occurrence of the internal safety circuit failure. The output is in LOW state otherwise.  (The open collector transistor is ON (conductive) in LOW state. The transistor is OFF (not conductive) in HIGH state.)  Refer to the Safety Stop Function Instruction Manual if the output becomes in HIGH state even though both terminals S1 and S2 are open. (Contact your sales representative for this manual.)	Permissible load: 24 VDC (27 VDC at maximum), 0.1 A (The voltage drop is 3.4 V at maximum while the signal is ON.)	
soc	Safety monitor output terminal common	Common terminal for terminal So (SO).	_	

## 2.6.2 Details on the control circuit terminals of the converter unit (FR-CC2).

For the parameter details, refer to the FR-CC2 Instruction Manual.

## ♦ Input signal

Туре	Terminal symbol	Terminal name	Terminal function description	Rated specification	
	RES <sup>*1</sup>	Reset	Use this signal to reset a fault output provided when a protective function is activated. Turn ON the RES signal for 0.1 second or longer, then turn it OFF.  In the initial setting, reset is always enabled. By setting <b>Pr.75</b> , reset can be enabled only at fault occurrence of the converter unit. The inverter recovers about 1s after the reset is released.	Input resistance: 4.7 kΩ, voltage when contacts are open: 21 to 27	
	OH*1	External thermal relay input	The External thermal relay input (OH) signal is used when using the external thermal relay or the thermal protector built into the motor to protect the motor from overheating.  When the thermal relay is activated, the inverter output is shut off by the external thermal relay operation (E.OHT).	VDC, current when contacts are short-circuited: 4 to 6 mADC	
put	RDI*1	Contact input	Use <b>Pr.178</b> to assign a function to the terminal.		
Contact input	SD	Contact input common (sink)	Common terminal for the contact input terminal (sink logic) and terminal FM.		
Con		SD	External transistor common (source)	Connect this terminal to the power supply common terminal of a transistor output (open collector output) device, such as a programmable controller, in the source logic to avoid malfunction by undesirable current.	_
			24 VDC power supply common	Common terminal for the 24 VDC power supply (terminal PC, terminal +24). Isolated from terminals 5 and SE.	
	DC.	External transistor common (sink)	Connect this terminal to the power supply common terminal of a transistor output (open collector output) device, such as a programmable controller, in the sink logic to avoid malfunction by undesirable current.	Power supply voltage range: 19.2 to 28.8	
	PC	Contact input common (source)	Common terminal for contact input terminal (source logic).	VDC, permissible load current: 100 mA	
		24 VDC power supply	Can be used as a 24 VDC 0.1 A power supply.		

Туре	Terminal symbol	Terminal name	Terminal function description	Rated specification
Power supply input	+24	24 V external power supply input	For connecting a 24 V external power supply.  If a 24 V external power supply is connected, power is supplied to the control circuit while the main power circuit is OFF.	Input voltage: 23 to 25.5 VDC, input current: 1.4 A or less

<sup>\*1</sup> Terminal functions can be selected using Pr.178, Pr.187, or Pr.189 (Output terminal function selection).

## **♦** Output signal

Туре	Terminal symbol	Terminal name	Terminal function description	Rated specification		
Relay	A1, B1, C1 <sup>*1</sup>	Relay output 1 (fault output)	changeover contact output that indicates that the protective function of ne converter unit has been activated and the outputs are stopped. (ault: discontinuity across B and C (continuity across A and C), Normal: 30 VDC 0.3 A			
	88R, 88S	For manufacturer settin	g. Do not use.			
Open collector	RDA*1	Inverter operation enable (NO contact)	Switched to LOW when the converter unit operation is ready. Assign the signal to the terminal MRS (X10) of the inverter. The inverter can be started when the RDA status is LOW.	Permissible load: 24 VDC (27 VDC at maximum) 0.1 A		
	RDB*1	Inverter operation enable (NC contact)	Switched to LOW when a converter unit fault occurs or the converter is reset.  The inverter can be started when the RDB status is HIGH.	(The voltage drop is 2.8 V at maximum while the signal is ON.)		
	RSO*1	Inverter reset	Switched to LOW when the converter is reset (RES-ON). Assign the signal to the terminal RES of the inverter. The inverter is reset when it is connected with the RSO status LOW.	The open collector transistor is ON (conductive) in LOW		
	IPF*1	Instantaneous power failure	Switched to LOW when an instantaneous power failure is detected.	state. The transistor is OFF (not conductive) in		
	FAN*1	Cooling fan fault	Switched to LOW when a cooling fan fault occurs.	HIGH state.		
	SE	Open collector output common	Common terminal for terminals RDA, RDB, RSO, IPF, FAN Connect this terminal to the terminal SD (sink logic) or PC (source logic) of the inverter.	_		

<sup>\*1</sup> Terminal functions can be selected using Pr.190 to Pr.195 (Output terminal function selection).

#### ♠ CAUTION

- Do not use the empty terminals (NC) of the control circuit. Doing so may lead to damage of the converter unit and the inverter.
- Always connect the terminal RDA of the converter unit and the terminal MRS (X10) of the inverter, and the terminal SE
  of the converter unit and the terminal SD (terminal PC in the source logic) of the inverter. Not doing so may lead to
  damage of the converter unit.

# 2.6.3 Control logic (sink/source) change

Switch the control logic of input signals as necessary.


To change the control logic, change the jumper connector position on the control circuit board.

Connect the jumper connector to the connector pin of the desired control logic.

The control logic of input signals is initially set to the sink logic (SINK) for the type FM inverter.

The control logic of input signals is initially set to the source logic (SOURCE) for the type CA inverter.

(The output signals may be used in either the sink or source logic independently of the jumper connector position.)






- · Make sure that the jumper connector is installed correctly.
- · Never change the control logic while power is ON.

#### ◆ Sink logic and source logic

- In the sink logic, a signal turns ON when a current exits from the corresponding signal input terminal.

  Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
- In the source logic, a signal turns ON when a current enters into the corresponding signal input terminal.


  Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.



· When using an external power supply for transistor output


#### Sink logic

Use terminal PC as a common terminal, and perform wiring as shown below. (Do not connect terminal SD on the inverter with the terminal of 0 V for the external power supply. When using terminals PC-SD as a 24 VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)




#### Source logic

Use terminal SD as a common terminal, and perform wiring as shown below. (Do not connect terminal PC on the inverter with the terminal of +24 V for the external power supply. When using terminals PC-SD as a 24 VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



## 2.6.4 Wiring of inverter control circuit

## **♦** Control circuit terminal layout



- 11 This terminal operates as terminal FM for the type FM inverter. For the type CA inverter, the terminal operates as terminal CA.
- \*2 The X10 signal is assigned to terminal MRS in the initial setting
- \*3 No function is assigned in the initial setting.

#### **♦** Wiring method


#### **■** Power supply connection

For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply directly.

Insert the blade terminal or the single wire into a socket of the terminal.

1. Strip off the sheath for the below length. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.

Wire the stripped cable after twisting it to prevent it from becoming loose. Do not solder it.








**2.** Crimp the blade terminal.

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.

Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.









Blade terminals commercially available (as of January 2017)

· Phoenix Contact Co., Ltd.

Cable gauge (mm²)		Crimping tool		
Cable gauge (IIIII )	With insulation sleeve	Without insulation sleeve	For UL wire*1	name
0.3	AI 0,34-10TQ	_	_	
0.5	AI 0,5-10WH	_	AI 0,5-10WH-GB	
0.75	AI 0,75-10GY	A 0,75-10	AI 0,75-10GY-GB	ODIMADEOV C
1	AI 1-10RD	A 1-10	AI 1-10RD/1000GB	CRIMPFOX 6
1.25, 1.5	AI 1, 5-10BK	A 1, 5-10	AI 1,5-10BK/1000GB*2	
0.75 (two-wire product)	AI-TWIN 2×0,75-10GY	_	_	


<sup>\*1</sup> A ferrule terminal with an insulation sleeve compatible with the MTW wire which has a thick wire insulation.

<sup>\*2</sup> Applicable for terminals A1, B1, C1, A2, B2, C2.


#### · NICHIFU Co., Ltd.

Cable gauge (mm²)	Blade terminal product number	Insulation cap product number	Crimping tool product number	
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 69	

**3.** Insert the wires into a socket.



When using single wire or stranded wire without crimp terminal, push an open/close button all the way down with a flathead screwdriver, and insert the wire.






- · When using stranded wires without a blade terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.

#### **■** Wire removal

Pull the wire while pushing the open/close button all the way down firmly with a flathead screwdriver.



## NOTE

- · Pulling out the wire forcefully without pushing the open/close button all the way down may damage the terminal block.
- Use a small flathead screwdriver (tip thickness: 0.4 mm, tip width: 2.5 mm).
   If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.
   Commercially available products (as of February 2016)

Product name	Model	Manufacturer
Screwdriver	SZF 0- 0,4 × 2,5	Phoenix Contact Co., Ltd.

• Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.


## ◆ Common terminals of the control circuit (SD, PC, 5, SE)

- Terminals SD (sink logic), PC (source logic), 5, and SE are common terminals (0 V) for I/O signals. (All common terminals are isolated from each other.) Do not earth (ground) these terminals. Avoid connecting terminal SD (sink logic) with terminal 5, terminal PC (source logic) with terminal 5, and terminal SE with terminal 5.
- In the sink logic, terminal SD is a common terminal for the contact input terminals (STF, STR, STP (STOP), RH, RM, RL, JOG, RT, MRS, RES, AU, and CS) and the pulse train output terminal (FM\*1). The open collector circuit is isolated from the internal control circuit by photocoupler.


- In the source logic, terminal PC is a common terminal for the contact input terminals (STF, STR, STP (STOP), RH, RM, RL, JOG, RT, MRS, RES, AU, CS). The open collector circuit is isolated from the internal control circuit by photocoupler.
- · Terminal 5 is a common terminal for the frequency setting terminals (1, 2, and 4) and the analog output terminals (AM and CA<sup>\*2</sup>). It should be protected from external noise using a shielded or twisted cable.
- Terminal SE is a common terminal for the open collector output terminals (RUN, SU, OL, IPF, and FU). The contact input circuit is isolated from the internal control circuit by photocoupler.
  - \*1 Terminal FM is provided in the FM-type inverter.
  - \*2 Terminal CA is provided in the CA-type inverter.

#### Signal inputs by contactless switches

The contact input terminals of the inverter (STF, STR, STP (STOP), RH, RM, RL, JOG, RT, MRS, RES, AU, and CS) can be controlled using a transistor instead of a contact switch as follows.



External signal input using transistor (sink logic)



External signal input using transistor (source logic)

#### 2.6.5 Wiring precautions

- It is recommended to use a cable of 0.3 to 0.75 mm<sup>2</sup> for the connection to the control circuit terminals.
- The wiring length should be 30 m (200 m for terminal FM) at the maximum.
- · Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.






Micro signal contacts

Twin contacts

- · To suppress EMI, use shielded or twisted cables for the control circuit terminals and run them away from the main and power circuits (including the 200 V relay sequence circuit). For the cables connected to the control circuit terminals, connect their shields to the common terminal of the connected control circuit terminal. When connecting an external power supply to terminal PC, however, connect the shield of the power supply cable to the negative side of the external power supply. Do not directly earth (ground) the shield to the enclosure, etc.
- Always apply a voltage to the fault output terminals (A1, B1, C1, A2, B2, C2) via a relay coil, lamp, etc.

Separate the wiring of the control circuit away from the wiring of the main circuit.
 Make cuts in rubber bush of the inverter side and lead the wires through.



# 2.6.6 When using separate power supplies for the control circuit and the main circuit

# ◆ Cable size for the control circuit power supply (terminals R1/L11 and S1/L21)

Terminal screw size: M4
 Cable gauge: 0.75 to 2 mm<sup>2</sup>
 Tightening torque: 1.5 N·m

#### Connection method

If a fault occurs and the electromagnetic contactor (MC) installed at the inverter's input line is opened, power supply to the control circuit is also stopped and the fault signals cannot be output anymore. Terminals R1/L11 and S1/L21 of the control circuit are provided to keep outputting the fault signals in such a case. Follow the following steps to wire terminals R1/L11 and S1/L21 on the inverter to the power input lines of the MC.

Terminals R1/L11 and S1/L21 are connected to terminals P/+ and N/- with a jumper respectively. Do not connect the power cable to incorrect terminals. Doing so may damage the inverter.

Connection diagram


MC Converter unit Inverter

R/L1 P/+ P/+

S/L2 N/- N/
T/L3

R1/L11

Remove the jumper



- (a) Remove the upper screws.
- (b) Remove the lower screws.
- (c) Pull the jumper toward you to remove.
- (d) Connect the separate power supply cable for the control circuit to the upper terminals (R1/L11, S1/L21).



- When using separate power supplies, always remove the jumpers connected to terminals R1/L11 and S1/L21. The inverter may be damaged if the jumpers are not removed.
- When the control circuit power is supplied from other than the input line of the MC, the voltage of the separate power supply must be the same as that of the main control circuit .
- When using a separate power supply connected to terminals R1/L11 and S1/L21, the necessary power capacity is 80 VA.
- If the main circuit power is switched OFF (for 0.1 second or more) then ON again, the inverter is reset and a fault output will not be held.

# 2.6.7 When supplying 24 V external power to the control circuit

Connect the 24 V external power supply across terminals +24 and SD to turn the I/O terminal ON/OFF operation, keep the operation panel ON, and carry out communication during communication operation even at power-OFF state of inverter's main circuit power supply. When the main circuit power supply is turned ON, the power supply is switched from the 24 V external power supply to the main circuit power supply.

#### ◆ Specification of the applied 24 V external power supply

Item	Rated specification
Input voltage	23 to 25.5 VDC
Input current	1.4 A or less

Commercially available products (as of February 15)

Model	Manufacturer
S8JX-N05024C <sup>*1</sup> Specifications: Capacity 50 W, output voltage 24 VDC, output current 2.1 A Installation method: Front installation with cover	OMRON Corporation
S8VS-06024*1 Specifications: Capacity 60 W, output voltage 24 VDC, output current 2.5 A Installation method: DIN rail installation	Civil Conporation

<sup>\*1</sup> For the latest information about OMRON power supply, contact OMRON corporation.

### ◆ Starting and stopping the 24 V external power supply operation

- Supplying 24 V external power while the main circuit power is OFF starts the 24 V external power supply operation. Likewise, turning OFF the main circuit power while supplying 24 V external power starts the 24 V external power supply operation.
- Turning ON the main circuit power stops the 24 V external power supply operation and enables the normal operation.




- When the 24 V external power is supplied while the main circuit power supply is OFF, the inverter operation is disabled.
- In the initial setting, when the main power supply is turned ON during the 24 V external power supply operation, a reset is performed in the inverter, then the power supply changes to the main circuit power supply. (The reset can be disabled using **Pr.30**.)

## ◆ Confirming the 24 V external power supply input

• During the 24 V external power supply operation, "EV" blinks on the operation panel. The alarm lamp also blinks. Thus, the 24 V external power supply operation can be confirmed even when the operation panel is removed.





During the 24 V external power supply operation, the 24 V external power supply operation (EV) signal is output. To use
the EV signal, set "68 (positive logic) or 168 (negative logic)" in one of Pr.190 to Pr.196 (Output terminal function
selection) to assign function to an output terminal.

## ♦ Operation while the 24 V external power is supplied

- Fault records and parameters can be read and parameters can be written (when the parameter write from the operation panel is enabled) using the operation panel keys.
- The safety stop function is invalid during the 24 V external power supply operation.
- During the 24 V external power supply operation, the monitor items related to inputs to main circuit power supply, such as the output current and converter output voltage, are invalid.

- The alarms, which have occurred when the main circuit power supply is ON, continue to be output after the power supply is changed to the 24 V external power supply. Perform the inverter reset or turn OFF then ON the power to reset the faults.
- The output data is retained when "1 or 11" is set in Pr.495 Remote output selection.

#### • NOTE

- Inrush current equal to or higher than the 24 V external power supply specification may flow at power-ON. Confirm that the power supply and other devices are not affected by the inrush current and the voltage drop caused by it. Depending on the power supply, the inrush current protection may be activated to disable the power supply. Select the power supply and capacity carefully.
- When the wiring length between the external power supply and the inverter is long, the voltage often drops. Select the appropriate wiring size and length to keep the voltage in the rated input voltage range.
- In a serial connection of several inverters, the current increases when it flows through the inverter wiring near the power supply. The increase of the current causes voltage to drop further. When connecting different inverters to different power supplies, use the inverters after confirming that the input voltage of each inverter is within the rated input voltage range. Depending on the power supply, the inrush current protection may be activated to disable the power supply. Select the power supply and capacity carefully.
- "E.SAF" or "E.P24" may appear when the start-up time of the 24 V power supply is too long (less than 1.5 V/s) in the 24 V external power supply operation.
- "E.P24" may appear when the 24 V external power supply input voltage is low. Check the external power supply input.
- Do not touch the control circuit terminal block (circuit board) during the 24 V power supply operation (when conducted). Otherwise you may get an electric shock or burn.

# 2.6.8 Safety stop function

### **◆** Function description

The terminals related to the safety stop function are as follows.

Terminal symbol	Terminal function description				
S1*1	Input terminal as the safety stop channel 1.	Status of both the circuit between terminals S1 and SIC and the circuit between terminals S2 and SIC			
S2*1	Input terminal as the safety stop channel 2.	Open: Safety stop is activated. Shorted: Safety stop is not activated			
SIC*1	Common terminal for S1 and S2.				
So (SO)	Output terminal used for fault detection and fault indication display.  The terminal is ON (conducted) while no internal safety circuit failure*2 exists.	OFF: Internal safety circuit failure <sup>*2</sup> ON: No internal safety circuit failure <sup>*2</sup>			
SOC	Open collector output (terminal So (SO)) common				

<sup>\*1</sup> In the initial status, terminals S1 and PC, S2 and PC, and SIC and SD are respectively shorted with shorting wires. To enable the safety stop function, remove all the shorting wires, and then connect a safety relay module as shown in the connection diagram.


<sup>\*2</sup> When any fault listed on the next page occurs in the internal safety circuit, the corresponding indication is shown on the operation panel.



• Terminal So (SO) can be used to display a fault indication and to prevent restarting of the inverter. The signal output from terminal So (SO) cannot be used to input a safety stop signal to other devices.

## **◆** Connection diagram

To prevent restart at failure occurrence, connect terminals So (SO) and SOC to the reset button, which are the feedback input terminals of the safety relay module.



#### **♦** Safety stop function operation

Input power	Internal safety circuit	Input terminal*1*2		Output terminal	Output signal <sup>*8*9*10</sup>	Inverter operating status	Operation panel indication	
	status	S1	S2	So (SO)	SAFE		E.SAF*6	SA <sup>*7</sup>
OFF	_	_	_	OFF	OFF	Output shutoff (Safe state)	Not displayed	Not displayed
	Normal	ON	ON	ON <sup>*3</sup>	OFF	Operation enabled	Not displayed	Not displayed
	Normal	ON	OFF	OFF*4	OFF*4	Output shutoff (Safe state)	Displayed	Displayed
	Normal	OFF	ON	OFF*4	OFF*4	Output shutoff (Safe state)	Displayed	Displayed
ON	Normal	OFF	OFF	ON*3	ON*3	Output shutoff (Safe state)	Not displayed	Displayed
	Fault	ON	ON	OFF	OFF	Output shutoff (Safe state)	Displayed	Not displayed*5
	Fault	ON	OFF	OFF	OFF	Output shutoff (Safe state)	Displayed	Displayed
	Fault	OFF	ON	OFF	OFF	Output shutoff (Safe state)	Displayed	Displayed
	Fault	OFF	OFF	OFF	OFF	Output shutoff (Safe state)	Displayed	Displayed

<sup>\*1</sup> The terminal ON state shows that the terminal is conducted (the line is closed), and the OFF state shows that the terminal is not conducted (the line is open).

<sup>\*3</sup> If any of the faults shown in the following table occurs, terminal So (SO) and the SAFE signal turns OFF.

Fault type	Operation panel indication
Option fault	E.OPT
Communication option fault	E.OP1 to E.OP3
Parameter storage device fault (control circuit board)	E.PE
Retry count excess	E.RET
Parameter storage device fault (main circuit board)	E.PE2
Operation panel power supply short circuit/RS-485 terminals power supply short circuit	E.CTE
24 VDC power fault	E.P24
Safety circuit fault	E.SAF
Overspeed occurrence	E.OS

Fault type	Operation panel indication
Speed deviation excess detection	E.OSD
Signal loss detection	E.ECT
Excessive position fault	E.OD
Brake sequence fault	E.MB1 to E.MB7
CPU fault	E.CPU
	E.5 to E.7
Encoder phase fault	E.EP
Magnetic pole position unknown	E.MP
Internal circuit fault	E.13

<sup>\*4</sup> When the internal safety circuit is operated normally (no faults occurs), terminal So (SO) and the SAFE signal remain ON until "E.SAF" is displayed. Terminal So (SO) and the SAFE signal turn OFF when "E.SAF" is displayed.

<sup>\*9</sup> To assign the function of the SAFE signal to an output terminal, set either value shown in the following table in any parameter from **Pr.190 to Pr.196 (Output terminal function selection)**.

Output signal	Pr.190 to Pr.196 settings Positive logic Negative logic	
Output signal		
SAFE	80	180

<sup>\*10</sup> The use of SAFE signal has not been certified for compliance with safety standards.

For more details, refer to the Safety Stop Function Instruction Manual.

Find a PDF file of the manual in the CD-ROM enclosed with the product.

<sup>\*2</sup> When not using the safety stop function, short across terminals S1 and PC, S2 and PC, and SIC and SD to use the inverter. (In the initial status, terminals S1 and PC, S2 and PC, and SIC and SD are respectively shorted with shorting wires.)

<sup>\*5 &</sup>quot;SA" is displayed when terminals S1 and S2 are identified as OFF due to a fault occurred in the internal safety circuit.

<sup>\*6</sup> If another fault occurs when the fault E.SAF occurs, the other fault indication may be displayed.

<sup>\*7</sup> If another warning occurs when the warning SA occurs, the other warning indication may be displayed.

<sup>\*8</sup> The ON/OFF state of the output signal is the one for the positive logic. The ON and OFF are reversed for the negative logic.

## 2.7 Communication connectors and terminals

## 2.7.1 PU connector


## Mounting the operation panel or the parameter unit on the enclosure surface

• Having an operation panel or a parameter unit on the enclosure surface is convenient. With a connection cable, the operation panel or the parameter unit can be mounted to the enclosure surface and connected to the inverter.

Use the option FR-CB2[], or connectors and cables available on the market.

(To mount the operation panel, the optional connector (FR-ADP) is required.)

Securely insert one end of the cable into the PU connector and the other end into the connection connector on the parameter unit or the FR-ADP attached on the operation panel until the stoppers are fixed.



#### NOTE

- Refer to the following table when fabricating the cable on the user side. Keep the total cable length within 20 m.
- Commercially available products (as of February 2015)

Name	Model	Manufacturer
Communication cable	SGLPEV-T (Cat5e/300 m) 24AWG × 4P	Mitsubishi Cable Industries, Ltd.
RJ-45 connector	5-554720-3	Tyco Electronics


## **◆** Communication operation

• Using the PU connector as a computer network port enables communication operation from a personal computer, etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the inverter or read and write parameters.

Communication can be performed with the Mitsubishi inverter protocol (computer link operation).

For the detail, refer to the Instruction Manual (Detailed).

## 2.7.2 USB connector



#### **◆ USB** host communication

Interface Conforms to USB 1.1		Conforms to USB 1.1
Transmission speed 12 Mbps		12 Mbps
Wi	iring length	Maximum 5 m
Connector		USB A connector (receptacle)
Commetible	Format	FAT32
Compatible USB memory	Capacity	1 GB or more (used in the recorder mode of the trace function)
Encryption function		Not available

Different inverter data can be saved in a USB memory device.
 The USB host communication enables the following functions.

Function	Description	
Parameter copy	<ul> <li>Copies the parameter settings from the inverter to the USB memory device. A maximum of 99 parameter setting files can be saved in a USB memory device.</li> <li>The parameter setting data copied in the USB memory device can be copied to other inverters. This function is useful in backing up the parameter setting or for sharing the parameter setting among multiple inverters.</li> <li>The parameter setting file can be copied onto a personal computer from the USB memory device and edited using FR Configurator2.</li> </ul>	
Trace	<ul> <li>The monitoring data and output status of the signals can be saved in a USB memory device.</li> <li>The saved data can be imported to FR Configurator2 to diagnose the operating status of the inverter.</li> </ul>	
PLC function data copy	<ul> <li>This function copies the PLC function project data to a USB memory device when the PLC function is used.</li> <li>The PLC function project data copied in the USB memory device can be copied to other inverters.</li> <li>This function is useful in backing up the parameter setting and for allowing multiple inverters to operate by the same sequence programs.</li> </ul>	

- When the inverter recognizes the USB memory device without any problem, \_\_\_\_\_ is briefly displayed on the operation panel.
- When the USB memory device is removed, LI is briefly displayed on the operation panel.
- · The operating status of the USB host can be checked on the LED display of the inverter.

LED display status	Operating status	
OFF	No USB connection.	
ON	The communication is established between the inverter and the USB device.	
Fast blinking	The USB memory device is being accessed. (Do not remove the USB memory device.)	
Slow blinking	Error in the USB connection.	

- When a device such as a USB charger is connected to the USB connector and an excessive current (500 mA or higher) flows, USB host error " (UF warning) is displayed on the operation panel.
- When the UF warning appears, the USB error can be canceled by removing the USB device and setting **Pr.1049** = "1". (The UF warning can also be canceled by resetting the inverter power or resetting with the RES signal.)



- Do not connect devices other than a USB memory device to the inverter.
- · If a USB device is connected to the inverter via a USB hub, the inverter cannot recognize the USB memory device properly.
- For the detail of usage, refer to the Instruction Manual (Detailed).

#### **◆ USB** device communication

The inverter can be connected to a personal computer with a USB (ver. 1.1) cable. Parameter setting and monitoring can be performed by using FR Configurator2.

Interface	Conforms to USB 1.1	
Transmission speed	12 Mbps	
Wiring length	Maximum 5 m	
Connector	USB mini B connector (receptacle)	
Power supply	Self-powered	



• For the details of FR Configurator2, refer to the FR Configurator2 Instruction Manual.


## 2.7.3 RS-485 terminal block

#### **◆** Communication operation

Conforming standard	EIA-485 (RS-485)
Transmission format	Multidrop link
Communication speed	maximum 115200 bps
Overall length	500 m
Connection cable	Twisted pair cable (4 pairs)

The RS-485 terminals enable communication operation from a personal computer, etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run to monitor the inverter or read and write parameters.

Communication can be performed with the Mitsubishi inverter protocol (computer link operation) and MODBUS RTU protocol. For the detail, refer to the Instruction Manual (Detailed).






- To avoid malfunction, keep the RS-485 terminal wires away from the control circuit board.
- For wiring of the RS-485 terminals used with a plug-in option, lead the wires on the left side of the plug-in option.

# 2.8 Connection to a motor with encoder (Vector control)

Using encoder-equipped motors together with a Vector control compatible option enables speed, torque, and positioning control operations under orientation control, encoder feedback control, and full-scale Vector control. This section explains wiring for use of the FR-A8AP.

#### **♦** Appearance and parts name of the FR-A8AP



Symbol	Name	Description	Refer to page
(a)	Mounting hole	Used for installation to the inverter.	_
(b)	Terminal block	Connected with the encoder.	67
(c)	Encoder type selection switch (SW3)	Switches the encoder type (differential line driver/complementary).	65
(d)	CON2 connector	Used for extension.	_
(e)	Terminating resistor selection switches (SW1)	Switch ON or OFF the internal terminating resistor.	65
(f)	Switches (SW2) for manufacturer setting	Do not change the initial setting (both SW2-1 and SW2-2 switches: OFF	_
(g)	Board mounted option connector	Used to connect this product to the option connector on the inverter.	15
(h)	LED for manufacturer check	Not used.	_

#### **◆** Terminals of the FR-A8AP

Terminal symbol	Terminal name	Description	
PA1	Encoder A-phase signal input terminal		
PA2	Encoder A-phase inverse signal input terminal		
PB1	Encoder B-phase signal input terminal	A. D. and 7 whose signals are input from the anceder	
PB2	Encoder B-phase inverse signal input terminal	A-, B- and Z-phase signals are input from the encoder.	
PZ1	Encoder Z-phase signal input terminal		
PZ2	Encoder Z-phase inverse signal input terminal		
PG	Encoder power supply (positive) input terminal Input terminal for the encoder power supply.		
SD	Encoder power supply ground terminal	Connect the external power supply (5 V, 12 V, 15 V, 24 V) and the encode power cable. When the encoder output is the differential line driver type, only 5 V can be input. Make the voltage of the external power supply same as the encoder output voltage. (Check the encoder specification.)	
PIN	Netwood		
PO	Not used.		

## • NOTE


- · When the encoder's output voltage differs from its input power supply voltage, the signal loss detection (E.ECT) may occur.
- Incorrect wiring or faulty setting to the encoder will cause a fault such as an overcurrent (E.OC[]) and an inverter overload (E.THT). Correctly perform the encoder wiring and setting.

#### ◆ Switches on the FR-A8AP

• Encoder type selection switch (SW3)

Selects either the differential line driver or complementary setting.


It is initially set to the differential line driver. Switch its position according to the output circuit.



Use the terminating resistor selection switches (SW1) to select ON/OFF of the internal terminating resistor.
 Set the switches ON (initial status) when an encoder output type is differential line driver, and set OFF when complementary.

ON: With internal terminating resistor (initial status)

OFF: Without internal terminating resistor







- · Set all switches to the same setting (ON/OFF).
- Set the switches OFF when sharing an encoder with another unit (NC (computerized numerical controller), etc.) having a terminating resistor under the differential line driver setting.
- Prepare the power supply (5 V/12 V/15 V/24 V) for the encoder according to the encoder's output voltage. When the control terminal option FR-A8TP is installed, 24 V power supply can be provided from the FR-A8TP. When the encoder output is the differential line driver type, only 5 V can be input.
- The SW2 switches are for manufacturer setting. Do not change the setting.
- When the power supply of the inverter is turned OFF, also turn off the power supply of the encoder. Otherwise, the plug-in option may be damaged.
- · Encoder specification

Item	Specification
Resolution	0 to 4096 Pulse/Rev (setting by Pr.369)
Power supply voltage	5 V, 12 V, 15 V, or 24 V
Output signal form	A, B phases (90° phase shift), Z phase: 1 pulse/rev
Output circuit	Differential line driver or complementary

#### **◆** Encoder cable


#### **■ FR-JCBL**






Model	Length L (m)
FR-JCBL5	5
FR-JCBL15	15
FR-JCBL30	30

#### ■ FR-V7CBL




A P clip for earthing (grounding) a shielded cable is provided.



Model	Length L (m)
FR-V7CBL5	5
FR-V7CBL15	15
FR-V7CBL30	30

As the terminal block of the FR-A8AP is an insertion type, cables need to be treated when the encoder cables of the inverter
are crimping terminals. Cut the crimp terminal of the encoder cable and strip its sheath to make its cable wires loose.
 Also, treat the shielding wires of the shielded twisted pair cable to ensure that they do not contact conductive areas.
 Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.









Information on blade terminals
 Commercially available products (as of January 2017)
 Phoenix Contact Co., Ltd.

Terminal screw	Cable gauge	Ferrule	part No.	- Crimping tool	
size	Cable gauge (mm <sup>2</sup> )	With insulation sleeve	Without insulation sleeve	name	
M2	0.3	AI 0,34-6TQ	A 0,34-7	CRIMPFOX 6	
IVIZ	0.5	AI 0,5-6WH	A 0,5-6	CRIMPFOX 0	

NICHIFU Co., Ltd.

Terminal screw size	Cable gauge (mm²)	Blade terminal part No.	Insulation cap part No.	Crimping tool model No.
M2	0.3 to 0.75	BT 0.75-7	VC 0.75	NH 69

· When using a blade terminal (without insulation sleeve), take caution that the twisted wires do not come out.




· Connection terminal compatibility table


Encoder cable		FR-V7CBL	FR-JCBL
	PA1	PA	PA
	PA2	Do not connect anything to this.	PAR
	PB1	PB	РВ
FR-A8AP terminal	PB2	Do not connect anything to this.	PBR
FR-AOAF terminal	PZ1	PZ	PZ
	PZ2	Do not connect anything to this.	PZR
	PG	PG	5E
	SD	SD	AG2

## **♦** Wiring example


· Speed control



#### · Torque control



· Position control




- \*1 The pin number differs according to the encoder used.
  - Speed, control, torque control, and position control by pulse train input are available with or without the Z-phase being connected.
- \*2 Connect the encoder so that there is no looseness between the motor and motor shaft. Speed ratio must be 1:1.
- \*3 Earth (ground) the shield of the encoder cable to the enclosure using a tool such as a P-clip. (Refer to page 69.)
- \*4 For the complementary, set the terminating resistor selection switches in the OFF position. (Refer to page 65.)
- \*5 A separate power supply of 5 V/12 V/15 V/24 V is necessary according to the encoder power specification. When the encoder output is the differential line driver type, only 5 V can be input.
  - Make the voltage of the external power supply same as the encoder output voltage, and connect the external power supply between PG and SD.
- \*6 For terminal compatibility of the FR-JCBL, FR-V7CBL, and FR-A8AP, refer to page 67.
- \*7 Assign the function using Pr.178 to Pr.184, Pr.187 to Pr.189 (Input terminal function selection).
- \*8 When position control is selected, terminal JOG function is invalid and simple position pulse train input terminal becomes valid.
- \*9 Assign the function using Pr.190 to Pr.194 (Output terminal function selection).

#### **♦** Instructions for encoder cable wiring

• Use shielded twisted pair cables (0.2 mm<sup>2</sup> or larger) to connect the FR-A8AP. For the wiring to terminals PG and SD, use several cables in parallel or use a thick cable, according to the wiring length.

To protect the cables from noise, run them away from any source of noise (such as the main circuit and power supply voltage).




Wiring length	Parallel connec	Larger-size cable	
Within 10 m	At least two cables in parallel	Cabla manna	0.4 mm <sup>2</sup> or larger
Within 20 m	At least four cables in parallel	Cable gauge 0.2mm <sup>2</sup>	0.75 mm <sup>2</sup> or larger
Within 100 m*1	At least six cables in parallel		1.25 mm <sup>2</sup> or larger


\*1 When differential line driver is set and a wiring length is 30 m or more.

The wiring length can be extended to 100 m by increasing the 5 V power supply (approximately to 5.5 V) while using six or more 0.2 mm<sup>2</sup> gauge cables in parallel or a 1.25 mm<sup>2</sup> or larger gauge cable. The voltage applied must be within power supply specifications of encoder.

• To reduce noise of the encoder cable, earth (ground) the encoder's shielded cable to the enclosure (as close as possible to the inverter) with a P-clip or U-clip made of metal.



• When one encoder is shared between the FR-A8AP and CNC (computerized numerical controller), its output signal should be connected as follows. In this case, the wiring length between the FR-A8AP and CNC should be as short as possible, within 5 m.





- For the details of the optional encoder dedicated cable (FR-JCBL/FR-V7CBL), refer to page 66.
- The FR-V7CBL is provided with a P-clip for earthing (grounding) shielded cables.

# 2.9 Parameter settings for a motor with encoder

## ◆ Parameter for the encoder (Pr.359, Pr.369, Pr.851, Pr.852)

· Set the encoder specifications.

P	r.	Name	Initial value	Setting range	Description	
				0	Set when using a motor for which forward rotation (encoder) is clockwise	Set for the operation at 120 Hz or less.
350	250 250			100	CW	Set for the operation at a frequency higher than 120 Hz.
	852 C241	Encoder rotation direction   1	1	1	Set when using a motor for which forward rotation (encoder) is	Set for the operation at 120 Hz or less.
				101	counterclockwise (CCW) viewed from the shaft.	Set for the operation at a frequency higher than 120 Hz.
369 C140	851 C240	Number of encoder pulses	1024	0 to 4096	Set the number of encoder pulses. Set the number of pulses before it is multiplied by 4.	

The parameters above can be set when a Vector control compatible option is installed.

• The following table shows parameters to be set according to the Vector control compatible option to be used.

Item	FR-A8AP/FR-A8AL/FR- A8APA parameter FR-A8APR parameter FR-A8APS parameter			FR-A8TP parameter
Encoder/Resolver rotation direction	Pr.359	Pr.852		
Number of detector pulses	Pr.369	— (fixed pulses of 1024)	(obtained via communication from the encoder)	Pr.851

## ◆ Parameter settings for the motor under Vector control

Motor model	Pr.9 Electronic thermal O/L relay	Pr.71 Applied motor	Pr.80 Motor capacity	Pr.81 Number of motor poles	Pr.359/Pr.852 Encoder rotation direction	Pr.369/Pr.851 Number of encoder pulses
Standard motor	Rated motor current	0 (3)*1	Motor capacity	Number of motor poles	*2	*2
Constant-torque motor	Rated motor current	1 (13) <sup>*1</sup>	Motor capacity	Number of motor poles	*2	*2

<sup>\*1</sup> Offline auto tuning is required. (Refer to the Instruction Manual (Detailed).)

<sup>\*2</sup> Set this parameter according to the motor.

# 2.10 Connection of stand-alone option units


The inverter accepts a variety of stand-alone option units as required.

Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the Instruction Manual of the corresponding option unit.

# 2.10.1 Connection of the brake unit (FR-BU2)

Connect the brake unit (FR-BU2) as follows to improve the braking capability during deceleration.

After making sure that the wiring is correct and secure, set "11 or 111" in **Pr.30 Regenerative function selection**. Set **Pr.0 Brake mode selection** = "2" in the brake unit FR-BU2.



<sup>\*1</sup> When wiring, make sure to match the terminal symbols (P/+, N/-) on the inverter and on the brake unit (FR-BU2). (Incorrect connection will damage the inverter and brake unit.)

<sup>\*2</sup> For the FR-A842-08660(355K) or lower, up to two cables can be connected to terminals P/+ and N/-. For the FR-A842-09620(400K) or higher, up to four cables can be connected. To use more cables, use a bus bar.

<sup>\*3</sup> When the power supply is 400 V class, install a stepdown transformer.

<sup>\*4</sup> The wiring distance between the inverter, brake unit (FR-BU2) and resistor unit (FR-BR) must be within 5 m. When using twisted pair cable, use the cable within 10 m.

<sup>\*5</sup> The contact between TH1 and TH2 is open in the normal status and is closed at a fault.

<sup>\*6</sup> The CN8 connector used with the MT-BU5 type brake unit is not used.




- The warning "oL" of the stall prevention (overvoltage) is disabled while Pr.30 Regenerative function selection = "11 or 111".
- For the parameter details, refer to the FR-A800 Instruction Manual (Detailed).

# 2.10.2 Connection of the high power factor converter (FR-HC2)

When connecting the high power factor converter (FR-HC2) to suppress power harmonics, perform wiring securely as follows. Incorrect connection will damage the high power factor converter and the inverter.

After making sure that the wiring is correct and secure, set the rated motor voltage in **Pr.19 Base frequency voltage** (under V/F control) or **Pr.83 Rated motor voltage** (under other than V/F control) and "2 or 102" in **Pr.30 Regenerative function selection**.




- \*1 Remove jumpers installed between terminals R1/L11 and S1/L21 of the inverter, and connect the power supply for the control circuit to terminals R1/L11 and S1/L21.
- \*2 For wiring, the power phase must be consistent between terminals R4/L14, S4/L24, and T4/L34 and terminals R/L1, S/L2, and T/L3.
- \*3 Do not install an MCCB across terminals P/+ and N/- (between terminals P and P/+ or between terminals N and N/-). Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.
  - When using the FR-HC2 with the FR-A802 series, installation of a fuse is not required.
- \*4 Change the FR-HC2 parameter setting to Pr.10 RDY signal logic selection = "0" (positive logic).
   \*5 Use Pr.178 to Pr.189 (Input terminal function selection) to assign the terminals used for the X11 signal.
   For RS-485 or any other communication where the start command is only transmitted once, use the X11 signal to save the operation mode at the time of an instantaneous power failure.
- \*6 Assign the IPF signal to a terminal on the FR-HC2. (Refer to the Instruction Manual of the FR-HC2.)
- \*7 Always connect between the FR-HC2 terminal RDY and the inverter terminal MRS (X10), and between the FR-HC2 terminal SE and the inverter terminal SD. Not connecting these terminals may damage the FR-HC2.
- \*8 Always connect terminals R/L1, S/L2, and T/L3 on the FR-HC2 to the power supply. Operating the inverter without connecting them will damage the FR-HC2.
- \*9 Do not install an MCCB or MC across terminals (R/L1, S/L2, T/L3) on the reactor 1 and terminals (R4/L14, S4/L24, T4/L34) on the FR-HC2. Doing so disrupts proper operation.
- \*10 Securely perform grounding (earthing) by using the grounding (earthing) terminal.
- \*11 The number of connected peripheral devices differs according to the capacity. For the details, refer to the Instruction Manual of the FR-HC2.



- The voltage phases of terminals R/L1, S/L2, and T/L3 and the voltage phases of terminals R4/L14, S4/L24, and T4/L34 must be matched
- The control logic (sink logic/source logic) of the high power factor converter and the inverter must be matched. (Refer to page 49.)
- When using a sine wave filter and FR-HC2 together, use MT-BSL-HC for the sine wave filter.
- For the parameter details, refer to the Fr-A800 Instruction Manual (Detailed).

# 2.10.3 Connection of the power regeneration converter (MT-RC)


When connecting the power regeneration converter (MT-RC), perform wiring securely as follows. Incorrect connection will damage the power regeneration converter and the inverter. After making sure that the wiring is correct and secure, set "1" in **Pr.30 Regenerative function selection**.



\*1 For the FR-A842-08660(355K) or lower, up to two cables can be connected to terminals P/+ and N/-. For the FR-A842-09620(400K) or higher, up to four cables can be connected. To use more cables, use a bus bar.



• When using the inverter with the MT-RC, install a magnetic contactor (MC) at the input side of the inverter so that power is supplied to the inverter after one second or more has elapsed after powering ON the MT-RC. When power is supplied to the inverter prior to the MT-RC, the inverter and the MT-RC may be damaged or the MCCB may be shut off or damaged.



• When connecting the power coordination reactor and others, refer to Instruction Manual of the MT-RC for precautions.

### **CHAPTER 3** PRECAUTIONS FOR USE OF THE INVERTER

3.1	Electro-magnetic interference (EMI) and leakage currents	76
3.2	Power supply harmonics	
3.3	Installation of a reactor	
3.4	Power shutdown and magnetic contactor (MC)	86
3.5	Countermeasures against deterioration of the 400 V class motor insulation	88
3.6	Checklist before starting operation	89
3.7	Failsafe system which uses the inverter	92

### 3 PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the precautions for use of this product.

Always read the instructions before use.

# 3.1 Electro-magnetic interference (EMI) and leakage currents

### 3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following countermeasures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

### ◆ To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earthing (grounding) cable, etc. These leakage currents may operate earth leakage circuit breakers and earth leakage relays unnecessarily.

#### **■** Countermeasures


- If the carrier frequency setting is high, decrease the Pr.72 PWM frequency selection setting.
   Note that motor noise increases. Selecting Pr.240 Soft-PWM operation selection makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).

#### ■ To-earth (ground) leakage currents

- Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
- · High motor capacity will increase the leakage current.

### ◆ Line-to-line leakage currents

Harmonics of leakage currents flowing in static capacitances between the inverter output cables may operate the external thermal relay unnecessarily.



#### **■** Countermeasures

- Use Pr.9 Electronic thermal O/L relay.
- If the carrier frequency setting is high, decrease the Pr.72 PWM frequency selection setting.
   Note that motor noise increases. Selecting Pr.240 Soft-PWM operation selection makes the sound inoffensive.
   To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.

#### ■ Installation and selection of the molded case circuit breaker

Install a molded case circuit breaker (MCCB) on the power receiving side to protect the wiring at the inverter input side. Select an MCCB according to the inverter input side power factor, which depends on the power supply voltage, output frequency and load. Especially for a completely electromagnetic MCCB, a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.

### ◆ Selecting the rated sensitivity current for the earth leakage circuit breaker

To install the earth leakage circuit breaker on the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

• Breaker designed for harmonic and surge suppression Rated sensitivity current

 $|\Delta n| \ge 10 \times (|g1 + |gn + |gi + |g2 + |gm|)$ 

Standard breaker
 Rated sensitivity current
 IΔn ≥ 10 × {Ig1 + Ign + Igi + 3 × (Ig2 + Igm)}


Ig1, Ig2: Leakage currents in wire path during commercial power supply operation

Ign: Leakage current from noise filters on the input side of the inverter


Igm: Leakage current from the motor during commercial power supply operation

Igi: Leakage current of inverter unit

Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit




Leakage current example of threephase induction motor during the commercial power supply operation



For "\\_" connection, the amount of leakage current is appox. 1/3 of the above value

• Selection example for the 人 connection of the 400 V class

#### Example



Item	Breaker designed for harmonic and surge suppression	Standard breaker		
Leakage current lg1 (mA)	$\frac{1}{3}$ × 66 × $\frac{5\text{m}}{1000\text{m}}$ = 0.1	1		
Leakage current Ign (mA)	0 (without noise filter)			
Leakage current lgi (mA)	1 (without EMC filter). For the leakage current of the inverter, refer to the following table.			
Leakage current lg2 (mA)	$\frac{1}{3} \times 66 \times \frac{60\text{m}}{1000\text{m}} = 1.32$			
Motor leakage current Igm (mA)	0.36			
Total leakage current (mA)	2.79	6.15		
Rated sensitivity current (mA) (≥ Ig × 10)	30	100		

· Inverter/converter unit leakage current (mA)

Inverter/converter unit	FR-A800 (Standard model)		FR-A802 (Separated converter type)	Converter u	nit (FR-CC2)	Remarks	
EMC filter	ON	OFF	_	ON	OFF		
Phase earthing (grounding)	35	2	2	70	2	Input power conditions	
Earthed-neutral system	2	1	1	2	1	(440 V/60 Hz, power supply imbalance within 3%)	



- · Install the earth leakage circuit breaker (ELB) on the input side of the converter.
- In the A connection earthed-neutral system, the sensitivity current is blunt against a ground fault in the inverter output side.
   Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 61140 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is within the rating.
  - In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- The following models and products are standard breakers: BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F,
  earth leakage relay (except NV-ZHA), NV with AA neutral wire open-phase protection
   The other models are designed for harmonic and surge suppression: NV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2,
  earth leakage alarm breaker (NF-Z), NV-ZHA, and NV-H.
- · For the leakage current of a 75 kW or higher motor, contact the motor manufacturer.

# 3.1.2 Techniques and measures for electromagnetic compatibility (EMC)

Some electromagnetic noises enter the inverter or the converter unit to cause its malfunction, and others are radiated by the inverter or the converter unit to cause the peripheral devices to malfunction. Though the inverter or the converter unit is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Pay attention to the electromagnetic noises that could be generated by the inverter since the inverter chops outputs at high carrier frequency. If these electromagnetic noises cause peripheral devices to malfunction, EMI countermeasures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

#### ◆ Basic measures

- Do not run the power cables (I/O cables) and signal cables of the inverter or the converter unit in parallel with each other and do not bundle them.
- Use shielded twisted pair cables for the detector connecting and control signal cables and connect the sheathes of the shielded cables to terminal SD.
- Ground (Earth) the inverter or the converter unit, motor, etc. at one point.


### ◆ Techniques to reduce electromagnetic noises that enter and cause a malfunction of the inverter or the converter unit (EMI countermeasures)

When devices that generate many electromagnetic noises (which use magnetic contactors, electromagnetic brakes, many relays, for example) are installed near the inverter or the converter unit and it may malfunction due to electromagnetic noises, the following countermeasures must be taken:

- · Provide surge suppressors for devices that generate many electromagnetic noises to suppress electromagnetic noises.
- Install data line filters (page 79) to signal cables.
- · Ground (Earth) the shields of the detector connection and control signal cables with cable clamp metal.

# ◆ Techniques to reduce electromagnetic noises that are radiated by the inverter or the converter unit to cause the peripheral devices to malfunction (EMI countermeasures)

Noises generated from the inverter or the converter unit are largely classified into those radiated by the cables connected to the inverter or the converter unit and its main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.




Noise propagation path	Countermeasure
(a), (b), (c)	When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g. instruments, receivers and sensors, are contained in the enclosure that contains the inverter or the converter unit, or when their signal cables are run near the inverter, the devices may malfunction due to by air-propagated electromagnetic noises. The following countermeasures must be taken:  Install easily affected devices as far away as possible from the inverter or the converter unit.  Run easily affected signal cables as far away as possible from the inverter or the converter unit, and its I/O cables.  Do not run the signal cables and power cables (inverter or converter unit I/O cables) in parallel with each other, and do not bundle them.  Set the EMC filter ON/OFF connector of the converter unit to the ON position. (Refer to page 81.)  Inserting a line noise filter into the output suppresses the radiated noise from the cables.  Use shielded cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
(d), (e), (f)	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises may be propagated to the signal cables to cause malfunction of the devices and the following countermeasures must be taken:  Install easily affected devices as far away as possible from the inverter or the converter unit.  Run easily affected signal cables as far away as possible from the inverter or the converter unit, and its I/O cables.  Do not run the signal cables and power cables (inverter or converter unit I/O cables) in parallel with each other, and do not bundle them.  Use shielded cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
(g)	When the power supplies of the peripheral devices are connected to the power supply of the inverter or the converter unit in the same line, its generated noises may flow back through the power supply cables to cause malfunction of the devices and the following countermeasures must be taken:  • Set the EMC filter ON/OFF connector of the converter unit to the ON position. (Refer to page 81.)  • Install the line noise filter to the power cables (output cables) of the inverter.
(h)	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter or the converter unit, leakage currents may flow through the earthing (grounding) cable of the inverter or the converter unit to cause the device to malfunction. In that case, disconnecting the earthing (grounding) cable from the device may stop the malfunction of the device.

#### ■ Data line filter

Data line filter is effective as an EMI countermeasure. Provide a data line filter for the detector cable, etc.


Commercially available data line filter: ZCAT3035-1330 (by TDK), ESD-SR-250 (by NEC TOKIN)

• Specification example (ZCAT3035-1330 by TDK)



The impedance values above are reference values, and not guaranteed values.

### **■** EMI measure example





• For compliance with the EU EMC Directive, refer to page 127.

### 3.1.3 Converter unit (FR-CC2) built-in EMC filter


The converter unit (FR-CC2) is equipped with a built-in EMC filter (capacitive filter).

These filters are effective in reducing air-propagated noise on the input side of the converter unit.

To enable the EMC filter, set the EMC filter ON/OFF connector to the ON position.

Two female connectors are initially connected to the OFF (disabled) male connectors.


To enable the EMC filter, fit both of the EMC filter ON/OFF connectors to the "enabled" (ON) position.



#### **♦** How to enable or disable the filter

- Before removing a front cover, check to make sure that the indication of the inverter operation panel is OFF, wait for at least 10 minutes after the power supply has been switched OFF, and check that there is no residual voltage using a digital multimeter or the like.
- When disconnecting the connector, push the fixing tab and pull the connector straight without pulling the cable or forcibly pulling the connector with the tab fixed.
  - When installing the connector, also engage the fixing tab securely.

(If it is difficult to disconnect the connector, use a pair of needle-nose pliers, etc.)





- Fit the connector to either ON or OFF position.
- Enabling (turning ON) the EMC filter increases leakage current. (Refer to page 77.)

### ♠ WARNING

• While power is ON, do not open the front cover. Otherwise you may get an electric shock.

### 3.2 Power supply harmonics

### 3.2.1 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power factor correction capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


· Differences between harmonics and noises

Item	Harmonics	Noise
frequency	Normally 40th to 50th degrees or less (3 kHz or less).	High frequency (several 10 kHz to 1 GHz order).
Location	To-electric channel, power impedance.	To-space, distance, wiring path.
Quantitative understanding	Theoretical calculation possible.	Random occurrence, quantitative grasping difficult.
Generated amount	Nearly proportional to the load capacity.	Changes with the current variation ratio. (Gets larger as switching speed increases.)
Affected equipment immunity	Specified by standards per equipment.	Different depending on maker's equipment specifications.
Countermeasure	Provide a reactor.	Increase distance.

#### · Countermeasures

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that this should be calculated in the conditions under the rated load at the maximum operating frequency.



\*1 The converter unit (FR-CC2) has a built-in DC reactor.



The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the
harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent
protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter.
 For power factor improvement, install a reactor on the inverter input side or in the DC circuit.

### 3.2.2 Harmonic suppression guidelines in Japan

Inverters have a converter section (rectifier circuit) and generate a harmonic current.

Harmonic currents flow from the inverter to a power receiving point via a power transformer. The Harmonic Suppression Guidelines was established to protect other consumers from these outgoing harmonic currents.

The three-phase 200 V input specifications 3.7 kW or lower were previously covered by "the Harmonic Suppression Guidelines for Household Appliances and General-purpose Products" and other models were covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage". However, the transistorized inverter has been excluded from the target products covered by "the Harmonic Suppression Guidelines for Household Appliances and General-purpose Products" in January 2004 and "the Harmonic Suppression Guideline for Household Appliances and General-purpose Products" was repealed on September 6, 2004.

All capacity and all models of general-purpose inverter used by specific consumers are now covered by "the Harmonic Suppression Guidelines for Consumers Who Receive High Voltage or Special High Voltage" (hereinafter referred to as "the Specific Consumer Guidelines").


• "Specific Consumer Guidelines"

This guideline sets forth the maximum harmonic currents outgoing from a high-voltage or especially high-voltage receiving consumer who will install, add or renew harmonic generating equipment. If any of the maximum values is exceeded, this guideline requires that consumer to take certain suppression measures.

· Maximum values of outgoing harmonic currents per 1 kW contract power

Received power voltage	5th	7th	11th	13th	17th	19th	23rd	Over 23rd
6.6 kV	3.5	2.5	1.6	1.3	1.0	0.9	0.76	0.70
22 kV	1.8	1.3	0.82	0.69	0.53	0.47	0.39	0.36
33 kV	1.2	0.86	0.55	0.46	0.35	0.32	0.26	0.24

### **♦** Application of the specific consumer guidelines



#### **■** Conversion factor

Classification	Circui	Conversion factor Ki	
2	Three-phase bridge (capacitor	With reactor (DC side)	K33 = 1.8
J	smoothing)	With reactors (AC, DC sides)	K34 = 1.4
5	Self-excitation three-phase bridge	When a high power factor converter is used	K5 = 0

### ■ Equivalent capacity limit

Received power voltage	Reference capacity
6.6 kV	50 kVA
22/33 kV	300 kVA
66 kV or more	2000 kVA

### ■ Harmonic content (when the fundamental current is considered as 100%)

Reactor	5th	7th	11th	13th	17th	19th	23rd	25th
Used (DC side)	30	13	8.4	5.0	4.7	3.2	3.0	2.2
Used (AC, DC sides)	28	9.1	7.2	4.1	3.2	2.4	1.6	1.4

#### ■ Calculation of equivalent capacity P0 of harmonic generating equipment

"Equivalent capacity" is the capacity of a 6-pulse converter converted from the capacity of consumer's harmonic generating equipment and is calculated by the following equation. If the sum of equivalent capacities is higher than the limit (refer to page 83), harmonics must be calculated by the equation in next subheading.

 $P0 = \Sigma (Ki \times Pi) [kVA]$ 

Ki: Conversion factor (Refer to page 83.)

Pi: Rated capacity of harmonic generating equipment [kVA]

i: Number indicating the conversion circuit type

\*1 Rated capacity: Determined by the capacity of the applied motor and found in the following table. The rated capacity used here is used to calculate the generated harmonic amount and is different from the power supply capacity required for actual inverter drive.

#### ■ Calculation of outgoing harmonic current

<u>Outgoing harmonic current = fundamental wave current (value converted from received power voltage) × operation ratio × harmonic content</u>

- Operation ratio: actual load factor × operation time ratio during 30 minutes
- Harmonic content: Refer to page 83.

#### ■ Rated capacities and outgoing harmonic currents of inverter-driven motors

Applicable	Rated current (A)	Fundamental wave current	Rated	Outg	oing harr	nonic cur react	rent conv or, 100%			(mA) (with	n a DC
motor (kW)	400 V	converted from 6.6 kV (mA)	capacity (kVA)	5th	7th	11th	13th	17th	19th	23rd	25th
75	123	7455	87.2	2237	969	626	373	350	239	224	164
90	147	8909	104	2673	1158	748	445	419	285	267	196
110	179	10848	127	3254	1410	911	542	510	347	325	239
132	216	13091	153	3927	1702	1100	655	615	419	393	288
160	258	15636	183	4691	2033	1313	782	735	500	469	344
220	355	21515	252	6455	2797	1807	1076	1011	688	645	473
250	403	24424	286	7327	3175	2052	1221	1148	782	733	537
280	450	27273	319	8182	3545	2291	1364	1282	873	818	600
315	506	30667	359	9200	3987	2576	1533	1441	981	920	675
355	571	34606	405	10382	4499	2907	1730	1627	1107	1038	761
400	643	38970	456	11691	5066	3274	1949	1832	1247	1169	857
450	723	43818	512	13146	5696	3681	2191	2060	1402	1315	964
500	804	48727	570	14618	6335	4093	2436	2290	1559	1462	1072
560	900	54545	638	16364	7091	4582	2727	2564	1746	1636	1200
630	1013	61394	718	18418	7981	5157	3070	2886	1965	1842	1351

#### ■ Determining if a countermeasure is required


A countermeasure for harmonics is required if the following condition is satisfied: outgoing harmonic current > maximum value per 1 kW contract power × contract power.


#### ■ Harmonic suppression techniques

No.	Item	Description
1	Reactor installation (FR-HAL)	With the DC reactor equipped on its DC side, the converter unit (FR-CC2) can suppress the outgoing harmonic current. Install an AC reactor (FR-HAL) on the AC side of the inverter to further suppress outgoing harmonic currents.
2	High power factor converter (FR-HC2)	This converter trims the current waveform to be a sine waveform by switching the rectifier circuit (converter module) with transistors. Doing so suppresses the generated harmonic amount significantly. Connect it to the DC area of an inverter. Use the high power factor converter (FR-HC2) with the accessories that come as standard.
3	Installation of power factor improving capacitor	When used with a reactor connected in series, the power factor improving correction capacitor can absorb harmonic currents.
4	Transformer multi-phase operation	Use two transformers with a phase angle difference of 30° in combinations of $\bot$ to $\Delta$ and $\Delta$ to $\Delta$ , to provide an effect corresponding to 12 pulses, reducing low-degree harmonic currents.
5	Passive filter (AC filter)	A capacitor and a reactor are used together to reduce impedances at specific frequencies. Harmonic currents are expected to be absorbed greatly by using this technique.
6	Active filter	This filter detects the current in a circuit generating a harmonic current and generates a harmonic current equivalent to a difference between that current and a fundamental wave current to suppress the harmonic current at the detection point. Harmonic currents are expected to be absorbed greatly by using this technique.

### 3.3 Installation of a reactor

When the inverter is connected near a large-capacity power transformer (1000 kVA or more) or when a power factor correction capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an AC reactor (FR-HAL), which is available as an option.





### 3.4 Power shutdown and magnetic contactor (MC)

### ◆ Converter unit input side magnetic contactor (MC)


On the converter unit input side, it is recommended to provide an MC for the following purposes. (Refer to page 20 for selection.)

- To disconnect the inverter from the power supply at activation of a protective function or at malfunctioning of the driving system (emergency stop, etc.).
- To prevent any accident due to an automatic restart at power restoration after an inverter stop made by a power failure.
- · To separate the inverter from the power supply to ensure safe maintenance and inspection work.

To use an MC to perform an emergency stop during operation, select the MC conforming to JEM 1038-AC-3 rated current for the converter unit rated input current.



- Since repeated inrush currents at power ON will shorten the life of the converter circuit (switching life is about 1,000,000 times), frequent starts and stops of the magnetic contactor must be avoided. Turn ON or OFF the start (STF/STR) signal for the inverter start control to run or stop the inverter.
- Inverter start/stop circuit example
   As shown in the following figure, always use the start signal (turn ON or OFF the STF/STR signal) to make a start or stop.



- \*1 When the power supply is 400 V class, install a stepdown transformer.
- \*2 To hold the Fault signal when the inverter's protective circuit is activated, connect the control circuit power supply terminals R1/L11 and S1/L21 to the input side of the MC. At this time, remove the jumpers connected to terminals R1/L11 and S1/L21. (Refer to page 55for removal of the jumper.)

### ◆ Handling of the magnetic contactor on the inverter's output side

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned ON while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided to switch to a commercial power supply, for example, it is recommended to use the electronic bypass function **Pr.135 to Pr.139**. (The commercial power supply operation is not available with Vector control dedicated motors nor with PM motors.)

### ♦ Handling of the manual contactor on the inverter's output side

A PM motor is a synchronous motor with high-performance magnets embedded inside. High-voltage is generated at the motor terminals while the motor is running even after the inverter power is turned OFF. In an application where the PM motor is driven by the load even after the inverter is powered OFF, a low-voltage manual contactor must be connected at the inverter's output side.



- · Before wiring or inspection for a PM motor, confirm that the PM motor is stopped. In an application, such as fan and blower, where the motor is driven by the load, a low-voltage manual contactor must be connected at the inverter's output side, and wiring and inspection must be performed while the contactor is open. Otherwise you may get an electric shock.
- Do not open or close the contactor while the inverter is running (outputting).

# 3.5 Countermeasures against deterioration of the 400 V class motor insulation

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially in a 400 V class motor, the surge voltage may deteriorate the insulation. When the 400 V class motor is driven by the inverter, consider the following countermeasures:

### **♦** Countermeasures (with induction motor)

It is recommended to take one of the following countermeasures:

### ■ Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length

For the 400 V class motor, use an <u>insulation-enhanced motor</u>.

Specifically,

- Order a "400 V class inverter-driven insulation-enhanced motor".
- For the dedicated motor such as the constant-torque motor and low-vibration motor, use an "inverter-driven dedicated motor".
- Set Pr.72 PWM frequency selection as indicated below according to the wiring length.

	Wiring length			
	100 m or shorter	Longer than 100 m		
Pr.72 PWM frequency selection	6 (6 kHz) or lower	4 (4 kHz) or lower		

#### ■ Suppressing the surge voltage on the inverter side

· If the motor capacity is 280 kW or lower, connect the sine wave filter (MT-BSL/BSC) to the output side.

### ◆ Countermeasures (with PM motor)

When the wiring length exceeds 50 m, set "9" (6 kHz) or less in Pr.72 PWM frequency selection.



- When using an optional sine wave filter (MT-BSL/BSC), set "25" (2.5 kHz) in Pr.72.
- For the details of the sine wave filter (MT-BSL/BSC), refer to the Instruction Manual of each option.
- · A sine wave filter (MT-BSL/BSC) can be used under V/F control. Do not use the filters under different control methods.
- The carrier frequency is limited during PM sensorless vector control. (Refer to the FR-A800 Instruction Manual (Detailed).)

### 3.6 Checklist before starting operation

The FR-A800 series inverter and FR-CC2 converter unit are highly reliable products, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the products.

Before starting operation, always recheck the following points.

Checkpoint	Countermeasure	Refer to page	Check by user
Crimp terminals are insulated.	Use crimp terminals with insulation sleeves to wire the power supply and the motor.		
The wiring between the power supply (terminals R/L1, S/L2, T/L3) and the motor (terminals U, V, W) is correct.	Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.		
No wire offcuts are left from the time of wiring.	Wire offcuts can cause a fault, failure, or malfunction. Always keep the inverter and the converter unit clean.  When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the inverter or the converter unit.		
The main circuit cable gauge is correctly selected.	Use an appropriate cable gauge to suppress the voltage drop to 2% or less. If the wiring distance is long between the inverter and motor, a voltage drop in the main circuit will cause the motor torque to decrease especially during the output of a low frequency.	40	
The total wiring length is within the specified length.	Keep the total wiring length within the specified length. In long distance wiring, charging currents due to stray capacitance in the wiring may degrade the fast-response current limit operation or cause the equipment on the inverter's output side to malfunction. Pay attention to the total wiring length.	40	
Countermeasures are taken against EMI.	The input/output (main circuit) of the inverter or the converter unit includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter or the converter unit. In such case, enable the EMC filter (turn ON the EMC filter ON/OFF connector) to minimize interference.	81	
On the inverter's output side, there is no power factor correction capacitor, surge suppressor, or radio noise filter installed.	Doing so will shut off the inverter output or damage the capacitor or surge suppressor. If any of the above devices is connected, immediately remove it.	_	
When performing an inspection or rewiring on the product that has been energized, the operator has waited long enough after shutting off the power supply.	For a short time after the power-OFF, a high voltage remains in the smoothing capacitor, and it is dangerous.  Before performing an inspection or rewiring, wait 10 minutes or longer after the power supply turns OFF, then confirm that the voltage across the main circuit terminals P/+ and N/- of the inverter is low enough using a digital multimeter, etc.	_	
The inverter's output side has no short circuit or ground fault occurring.	<ul> <li>A short circuit or ground fault on the inverter's output side may damage the inverter module.</li> <li>Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation resistance may damage the inverter module.</li> <li>Fully check the to-earth (ground) insulation and phase-to-phase insulation of the inverter's output side before power-ON. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance, etc.</li> </ul>	_	
The circuit is not configured to use the converter unit's input-side magnetic contactor to start/stop the inverter frequently.	Since repeated inrush currents at power ON will shorten the life of the inverter and the converter unit, frequent starts and stops of the magnetic contactor must be avoided. Turn ON or OFF the inverter's start (STF/STR) signal to run or stop the inverter.	86	
The voltage applied to the I/O signal circuits of the inverter and the converter unit are within the specifications.	Application of a voltage higher than the permissible voltage to the I/O signal circuits of the inverter or the converter unit or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short circuit terminals 10E and 5.	44	

Checkpoint	Countermeasure	Refer to page	Checkby user
The converter unit and the inverter are correctly connected.	<ul> <li>Make sure that the terminal P/+ of the converter unit and the terminal P/+ of the inverter, and the terminal N/- of the converter unit and the terminal N- of the inverter are correctly connected. Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.     Also, do not install an MCCB across the terminals P/+ and N/- (across terminals P and P/+ or across N and N/-).</li> <li>Always connect the terminal RDA of the converter unit and the terminal MRS (X10) of the inverter, and the terminal SE of the converter unit and the terminal SD (terminal PC in the source logic) of the inverter. Not doing so may lead to damage of the converter unit.</li> </ul>	37	
When using the electronic bypass operation, electrical and mechanical interlocks are provided between the electronic bypass contactors MC1 and MC2.	When using a switching circuit as shown below, chattering due to misconfigured sequence or arc generated at switching may allow undesirable current to flow in and damage the inverter. Miswiring may also damage the inverter. (The commercial power supply operation is not available with Vector control dedicated motors nor with PM motors.)  **MC1**   Interlock   Power   R/L1   U   MC2   Undesirable current   Undesirabl	_	
	If switching to the commercial power supply operation while a failure such as an output short circuit has occurred between the magnetic contactor MC2 and the motor, the damage may further spread.  Therefore, make sure to take precautions against such a failure, for example, providing a protection circuit using the OH input signal.		
A countermeasure is provided for power restoration after a power failure.	If the machine must not be restarted when power is restored after a power failure, provide an MC in the converter unit's input side and also make up a sequence which will not switch ON the start signal. If the start signal (start switch) remains ON after a power failure, the inverter will automatically restart as soon as the power is restored.	_	
For Vector control, the encoder is properly installed.	The encoder must be directly connected to a motor shaft without any backlash. (Real sensorless vector control or PM sensorless vector control do not require an encoder.)	64	
A magnetic contactor (MC) is installed on the converter unit's input side.	<ul> <li>On the converter unit's input side, connect an MC for the following purposes:</li> <li>To disconnect the inverter and the converter unit from the power supply at activation of a protective function or at malfunctioning of the driving system (emergency stop, etc.).</li> <li>To prevent any accident due to an automatic restart at power restoration after an inverter stop made by a power failure.</li> <li>To separate the inverter and the converter unit from the power supply to ensure safe maintenance and inspection work.</li> <li>Use the converter unit input current as a reference for selection of an MC to perform an emergency stop during operation, and select the MC conforming to JEM 1038-AC-3 class rated operational current.</li> </ul>	86	
The magnetic contactor on the inverter's output side is properly handled.	Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop.	86	
When using a PM motor, a low- voltage manual contactor is installed on the inverter's output side.	A PM motor is a synchronous motor with high-performance magnets embedded inside. High-voltage is generated at the motor terminals while the motor is running even after the inverter power is turned OFF. In an application, such as fan and blower, where the motor is driven by the load, a low-voltage manual contactor must be connected on the inverter's output side, and wiring and inspection must be performed while the contactor is open. Otherwise you may get an electric shock.	86	
An EMI countermeasure is provided for the frequency setting signals.	If electromagnetic noise generated from the inverter and the converter unit causes the frequency setting signal to fluctuate and motor rotation speed to become unstable when changing the motor speed with an analog signals, the following measures are effective.  • Do not run the signal cables and power cables (inverter and converter unit I/O cables) in parallel with each other, and do not bundle them.  • Run the signal cables as far away as possible from the power cables (inverter and converter unit I/O cables).  • Use shielded cables.  • Install a ferrite core on the signal cable (Example: ZCAT3035-1330 TDK).	_	

Checkpoint	Countermeasure		Check by user
A countermeasure is provided for an overload operation.	When performing frequent starts/stops by the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Reducing current may extend the service life but may also cause torque shortage, which leads to a start failure. Adding a margin to the current can eliminate such a condition. For an induction motor, use an inverter and a converter unit of higher capacities (up to two ranks). For a PM motor, use an inverter and a converter unit, and PM motor of higher capacities.		
The specifications and rating match the system requirements.	Make sure that the specifications and rating match the system requirements.	_	
Countermeasures are taken against electrical corrosion on the motor bearing.	When a motor is driven by the inverter, axial voltage is generated on the motor shaft, which may cause electrical corrosion of the bearing in rare cases depending on the wiring, load, operating conditions of the motor or specific inverter settings (high carrier frequency and EMC filter ON). Contact your sales representative to take appropriate countermeasures for the motor. The following shows examples of countermeasures for the inverter.  • Decrease the carrier frequency.  • Turn OFF the EMC filter.  • Provide a common mode choke*1 on the output side of the inverter. (This is effective regardless of the EMC filter ON/OFF connector setting.)	_	

<sup>\*1</sup> Recommended common mode choke: FT-3KM F series FINEMET® common mode choke cores manufactured by Hitachi Metals, Ltd. FINEMET is a registered trademark of Hitachi Metals, Ltd.

### 3.7 Failsafe system which uses the inverter

When a fault is detected by the protective function, the protective function activates and outputs the Fault signal. However, the Fault signal may not be output at an inverter's fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi assures the best quality products, provide an interlock which uses inverter status output signals to prevent accidents such as damage to the machine when the inverter fails for some reason. Also at the same time consider the system configuration where a failsafe from outside the inverter, without using the inverter, is enabled even if the inverter fails.

### ◆ Interlock method which uses the inverter status output signals

By combining the inverter output signals to provide an interlock as shown below, an inverter failure can be detected.

No.	Interlock method	Check method	Used signals
а	Inverter protective function operation	Operation check of an alarm contact. Circuit error detection by negative logic.	Fault (ALM) signal
b	Inverter operating status	Operation ready signal check.	Inverter operation ready (RY) signal
С	Inverter running status	Logic check of the start signal and running signal.	Start (STF or STR) signal Inverter running (RUN) signal
d	Inverter running status	Logic check of the start signal and output current.	Start (STF or STR) signal Output current detection (Y12) signal

 When using various signals, assign the functions to Pr.190 to Pr.196 (Output terminal function selection) referring to the table on the left.


Output	Pr.190 to Pr.196 setting		
signal	Positive logic	Negative logic	
ALM	99	199	
RY	11	111	
RUN	0	100	
Y12	12	112	



• Changing the terminal assignment using **Pr.190 to Pr.196 (Output terminal function selection)** may affect the other functions. Set parameters after confirming the function of each terminal.

#### ■ Checking by using the Fault signal output from the inverter... (a)

When the inverter's protective function activates and the inverter output is stopped, the Fault (ALM) signal is output. (The ALM signal is assigned to terminal A1B1C1 in the initial setting). With this signal, check that the inverter operates properly. In addition, negative logic can be set. (ON when the inverter is normal, OFF when the fault occurs.)




### ■ Checking the inverter operating status by using the Inverter operation ready signal output from the inverter ... (b)

The Inverter operation ready (RY) signal is output when the inverter power is ON and the inverter becomes operative. Check if the RY signal is output after powering ON the inverter.

### ■ Checking the inverter operating status by using the start signal input to the inverter and the Inverter running signal output from the inverter ... (c)

The Inverter running (RUN) signal is output when the inverter is running. (The RUN signal is assigned to terminal RUN in the initial setting.) Check if the RUN signal is output while a start signal (the STF/STR signal for forward/reverse rotation command) is input to the inverter. Even after the start signal is turned OFF, the RUN signal is kept output until the inverter makes the motor to decelerate and to stop. For the logic check, configure a sequence considering the inverter's deceleration time.



### ■ Checking the motor operating status by using the start signal input to the inverter and the Output current detection signal output from the inverter ... (d)

The Output current detection (Y12) signal is output when the inverter operates and currents flows into the motor.

Check if the Y12 signal is output while a start signal (the STF/STR signal for forward/reverse rotation command) is input to the inverter. The Y12 signal is initially set to be output at 150% inverter rated current. Adjust the level to around 20% using no load current of the motor as reference with **Pr.150 Output current detection level**.

Like the Inverter running (RUN) signal, even after the start signal is turned OFF, the Y12 signal is kept output until the inverter stops the output to a decelerating motor. For the logic check, configure a sequence considering the inverter's deceleration time.

### ♦ Backup method which does not use the inverter

Even if the interlock is provided by the inverter status signal, enough failsafe is not ensured depending on the failure status of the inverter itself. For example, if an inverter CPU fails in a system interlocked with the inverter's Fault, start, and RUN signals, no Fault signals will be output and the RUN signal will be kept ON because the inverter CPU is down.


Provide a speed detector to detect the motor speed and current detector to detect the motor current, and consider the backup system such as performing a check as follows according to the level of importance of the system.

#### ■ Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the inverter by comparing the start signal to the inverter and detected speed of the speed detector or detected current of the current detector. Note that the current is flowing through the motor while the motor coasts to stop, even after the inverter's start signal is turned OFF. For the logic check, configure a sequence considering the inverter's deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

### ■ Command speed and actual operation check

Check for a gap between the actual speed and commanded speed by comparing the inverter's speed command and the speed detected by the speed detector.



### **CHAPTER 4** PROTECTIVE FUNCTIONS

4.1	Inverter fault and alarm indications	96
4.2	Reset method for the protective functions	97
4.3	Check and clear of the fault history	98
4.4	List of fault displays	100

### 4 PROTECTIVE FUNCTIONS

This chapter explains the "PROTECTIVE FUNCTIONS" that operate in this product. Always read the instructions before use.

### 4.1 Inverter fault and alarm indications

- When the inverter detects a fault, depending on the nature of the fault, the operation panel displays an error message or warning, or a protective function is activated to shut off the inverter output.
- When any fault occurs, take an appropriate corrective action, then reset the inverter, and resume the operation. Restarting the operation without a reset may break or damage the inverter.
- When a protective function is activated, note the following points.

Item	Description	
Fault output signal	Opening the magnetic contactor (MC) provided on the input side of the inverter at a fault occurrence shuts off the control power to the inverter, therefore, the fault output will not be retained.	
Fault or alarm indication	When a protective function is activated, the operation panel displays a fault indication.	
Operation restart method While a protective function is activated, the inverter output is kept shutoff. Reset the inverted operation.		

· Inverter fault or alarm indications are categorized as follows.

Displayed item	Description
Error message	A message regarding operational fault and setting fault by the operation panel and the parameter unit. The inverter output is not shut off.
Warning	The inverter output is not shut off even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
Alarm	The inverter output is not shut off. An Alarm (LF) signal can also be output with a parameter setting.
Fault	When a protective function is activated, the inverter output is shut off and a Fault (ALM) signal is output.



- · For the details of fault indications and other malfunctions, refer to the FR-A800 Instruction Manual (Detailed).
- The last eight faults can be displayed on the operation panel. (Fault history) (For the operation, refer to page 98.)

### 4.2 Reset method for the protective functions

Reset the inverter by performing any of the following operations. Note that the accumulated heat value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter.

The inverter recovers about 1 second after the reset is released.

• On the operation panel, press STOP to reset the inverter.


(This may only be performed when a fault occurs.)



· Switch the power OFF once, then switch it ON again.



• Turn ON the Reset (RES) signal for 0.1 second or more. (If the RES signal is kept ON, "Err" appears (blinks) to indicate that the inverter is in a reset status.)




NOTE

• OFF status of the start signal must be confirmed before resetting the inverter fault. Resetting an inverter fault with the start signal ON restarts the motor suddenly.

### 4.3 Check and clear of the fault history

The operation panel stores the past eight fault records which appears when a protective function is activated. (Fault history)

### **♦** Check for the fault history



<sup>\*1</sup> When an overcurrent trip occurs by an instantaneous overcurrent, the monitored current value saved in the fault history may be lower than the actual current that has flowed.

<sup>\*2</sup> The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0.

### ◆ Fault history clearing procedure



Set Err.CL Fault history clear = "1" to clear the fault history.

### Operating procedure

- **1.** Turning ON the power of the inverter The operation panel is in the monitor mode.
- **2.** Selecting the parameter setting mode

Press Mode to choose the parameter setting mode. (The parameter number read previously appears.)

**3.** Selecting the parameter number

Turn until "L - - [ [ " (Fault history clear) appears. Press set value." [ " (initial value) appears.

**4.** Fault history clear

Turn to change the set value to " \". Press SET to start clearing.

- " | and | are displayed alternately after parameters are cleared.
  - Turn to read another parameter.
  - Press SET to show the setting again.
  - Press | SET | twice to show the next parameter.

#### 4.4 List of fault displays

For details, refer to the FR-A800 Instruction Manual (Detailed).

### Error message

· A message regarding operational fault and setting fault by the operation panel and the parameter unit is displayed. The inverter output is not shut off.

Operation panel indication		Name
HOLE	HOLD	Operation panel lock
LOEd	LOCD	Password locked
E- 10 E-4 E-8	Er1 to Er4, Er8	Parameter write error
E   to	rE1 to rE8	Copy operation error
Err.	Err.	Error

### Warning

· The inverter output is not shut off even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.

Operation panel i	ndication	Name
	OL	Stall prevention (overcurrent)
۵L	oL	Stall prevention (overvoltage)
[ <del>     </del>	TH	Electronic thermal relay function pre-alarm
P5	PS	PU stop
5L	SL	Speed limit indication
<u>[</u> F	CF	Continuous operation during communication fault
EP	СР	Parameter copy
58	SA	Safety stop
MF 1 to	MT1 to MT3	Maintenance timer 1 to 3
	UF	USB host error
HP 1	HP1	Home position return setting error
HPZ	HP2	Home position return uncompleted
HP3	HP3	Home position return parameter setting error

### Alarm

• The inverter output is not shut off. An Alarm (LF) signal can also be output with a parameter setting.

Operation panel indication		Name	
FN	FN	Fan alarm	

### Fault

- · When a protective function is activated, the inverter output is shut off and a Fault (ALM) signal is output.
- · The data code is used for checking the fault detail via communication or with Pr.997 Fault initiation.

Operation panel indication		ndication	Name
E.		E.OC1	Overcurrent trip during acceleration
E.		E.OC2	Overcurrent trip during constant speed
上.		E.OC3	Overcurrent trip during deceleration or stop
E.		E.OV1	Regenerative overvoltage trip during acceleration
E.		E.OV2	Regenerative overvoltage trip during constant speed
E.		E.OV3	Regenerative overvoltage trip during deceleration or stop
E.	[  -   T	E.THT	Inverter overload trip (electronic thermal relay function)
E. E.	1-114	E.THM	Motor overload trip (electronic thermal relay function)
E.	FIN	E.FIN	Heat sink overheat
E.		E.OLT	Stall prevention stop
E.	501	E.SOT	Loss of synchronism detection
E.	GF	E.GF	Output side earth (ground) fault overcurrent
E.	LF	E.LF	Output phase loss
E.		E.OHT	External thermal relay operation
E.	FIL	E.PTC	PTC thermistor operation
E.		E.OPT	Option fault
E.		E.OP1 to	Communication option fault
to E.	OP3	E.OP3	Communication option laut
E. to E.	16 20	E.16 to E.20	User definition error by the PLC function
E.	PE	E.PE	Parameter storage device fault (control circuit board)
E.	PLIE	E.PUE	PU disconnection

Operation panel indication			Name		
F	REF	E.RET	Retry count excess		
E.	PEZ	E.PE2	Parameter storage device fault (main circuit board)		
E. E. E.	EPU 5	E.CPU, E. 5 to E. 7	CPU fault		
E.	EFE	E.CTE	Operation panel power supply short circuit/RS-485 terminals power supply short circuit		
E.	PEH	E.P24	24 VDC power fault		
E.		E.CDO	Abnormal output current detection		
E.	SER	E.SER	Communication fault (inverter)		
E.	Al E	E.AIE	Analog input fault		
E.	U56	E.USB	USB communication fault		
E.	SAF	E.SAF	Safety circuit fault		
E.	749 13	E.PBT, E. 13	Internal circuit fault		
E.	05	E.OS	Overspeed occurrence		
E.	058	E.OSD	Speed deviation excess detection		
E.	ELL	E.ECT	Signal loss detection		
E.		E.OD	Excessive position fault		
	M6 1 M6 7	E.MB1 to E.MB7	Brake sequence fault		
E.	EP	E.EP	Encoder phase fault		
E.	MF	E.MP	Magnetic pole position unknown		
E.	EF	E.EF	External fault during output operation		
E.		E.LCI	4 mA input fault		
E.	FIH	E.PCH	Pre-charge fault		
E.	PI d	E.PID	PID signal fault		
E. to	; 3	E. 1 to E. 3	Option fault		
E.	11	E.11	Opposite rotation deceleration fault		

E.	1	1	E.1			
<b>♦</b> Others						

• The fault history and the operation status of the inverter are displayed. It is not a fault indication.

Operation panel indication			Name	
<b>E</b> E		E	Fault history	
E.		E.0	No fault records	

Operation panel i	ndication	Name		
! ! *     EV		24 V external power supply operation		
RD RD		Backup in progress		
MR	WR	Restoration in progress		

If faults other than the above appear, contact your sales representative.

### **MEMO**

### **CHAPTER 5** PRECAUTIONS FOR **MAINTENANCE AND INSPECTION**

5.1	Inspection item	104
5.2	Measurement of main circuit voltages, currents, and powers	111

# 5 PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter explains the precautions for maintenance and inspection of this product. Always read the instructions before use.

### 5.1 Inspection item

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

### **♦** Precautions for maintenance and inspection

When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched OFF. Then, make sure that the voltage across the main circuit terminals P/+ and N/- on the inverter is not more than 30 VDC using a tester, etc.

### 5.1.1 Daily inspection

Basically, check for the following faults during operation.

- · Motor operation fault
- · Improper installation environment
- · Cooling system fault
- · Abnormal vibration, abnormal noise
- · Abnormal overheat, discoloration

### 5.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection. Consult us for periodic inspection.

Check and clean the cooling system: Clean the air filter, etc.

Check the tightening and retighten:

The screws and bolts may become loose due to vibration, temperature

changes, etc. Check and tighten them. Tighten them according to the specified

tightening torque. (Refer to page 40.)

Check the conductors and insulating materials for corrosion and damage.

Measure the insulation resistance.

Check and change the cooling fan and relay.



When using the safety stop function, periodic inspection is required to confirm that safety function of the safety system
operates correctly. For more information on the safety stop function, refer to the FR-A800/F800 Safety Stop Function
Instruction Manual.

### 5.1.3 Daily and periodic inspection

Area of	Inspection item		Description		pection nterval	Corrective action at fault	Check	
inspection			Description		Periodic*3	occurrence	by user	
		rounding vironment				Improve the environment.		
General	Overall unit		Check for unusual vibration and noise.	0		Check fault location and retighten.		
Conorai			Check for dirt, oil, and other foreign material.*1	0		Clean.		
	l	wer supply age	Check that the main circuit voltage and control circuit voltage are normal.*2	0		Inspect the power supply.		
	70		Check with megger (between main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer.		
	Ge	neral	<ul><li>Check for loose screws and bolts.</li><li>Check for overheat traces on the parts.</li></ul>		0	Retighten. Contact the manufacturer.		
			Check for stains.		0	Clean.		
			Check conductors for distortion.		0	Contact the manufacturer.		
	Coi cab	nductors and bles	Check cable sheaths for breakage and deterioration (crack, discoloration, etc.).		0	Contact the manufacturer.		
Main circuit		nsformer/ ctor	Check for unusual odor and abnormal increase of whining sound.	0		Stop the equipment and contact the manufacturer.		
		minal block	Check for a damage.		0	Stop the equipment and contact the manufacturer.		
	Sm	oothing	Check for liquid leakage.		0	Contact the manufacturer.		
	aluminum electrolytic capacitor Relay/contactor		Check for safety valve projection and bulge.		0	Contact the manufacturer.		
			Visual check		0			
			Check that the operation is normal and no chattering sound is heard.		0	Contact the manufacturer.		
	Operation check		Check for an output voltage imbalance between phases while operating the inverter alone.		0	Contact the manufacturer.		
			<ul> <li>Check that no fault is found in protective and display circuits in a sequence protective operation test.</li> </ul>		0	Contact the manufacturer.		
Control circuit, protective	eck	Overall	Check for unusual odor and discoloration.		0	Stop the equipment and contact the manufacturer.		
circuit	ç		Check for serious rust development.		0	Contact the manufacturer.		
	omponents check	onents	Aluminum	<ul> <li>Check for liquid leakage in a capacitor and deformation trace.</li> </ul>		0	Contact the manufacturer.	
	Compo	electrolytic capacitor	<ul> <li>Visual check and judge by the life check of the control circuit capacitor. (Refer to the FR-A800 Instruction Manual (Detailed)).</li> </ul>		0			
			Check for unusual vibration and noise.	0		Replace the fan.		
Cooling system	Cooling fan		Check for loose screws and bolts.		0	Fix with the fan cover fixing screws.		
			Check for stains.		0	Clean.		
	Lام	at ciple	Check for clogging.		0	Clean.		
	Heat sink		Check for stains.		0	Clean.		
Diami	Indication		Check that indications are correct.     Check for stains.	0	0	Contact the manufacturer. Clean.		
Display	Meter/counter		Check that readouts are correct.	0		Stop the equipment and contact the manufacturer.		
Load motor	Ор	eration check	Check for vibration and abnormal increase in operation noise.	0		Stop the equipment and contact the manufacturer.		

<sup>\*1</sup> Oil component of the heat dissipation grease used inside the inverter may leak out. The oil component, however, is not flammable, corrosive, nor conductive and is not harmful to humans. Wipe off such oil component.

<sup>\*2</sup> It is recommended to install a voltage monitoring device for checking the voltage of the power supplied to the inverter.

<sup>\*3</sup> One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.



• Continuous use of a leaked, deformed, or degraded smoothing aluminum electrolytic capacitor (as shown in the table above) may lead to a burst, breakage, or fire. Replace such capacitor without delay.

## 5.1.4 Checking the inverter and converter semiconductor devices

### Preparation

- Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W). (Measurement can be made without disconnecting the cables connecting the inverter and the converter unit (FR-CC2).)
- Prepare a continuity tester. (For the resistance measurement, use the 100  $\Omega$  range.)

### Checking method

Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, P/+, and N/- and check the electric continuity.




- · Before measurement, check that the smoothing capacitor is discharged.
- At the time of electric discontinuity, the measured value is almost ∞. When there is an instantaneous electric continuity, due
  to the smoothing capacitor, the tester may not indicate ∞. At the time of electric continuity, the measured value is several Ω to
  several tens of Ω. When all measured values are almost the same (although values may not be constant depending on the
  tester type), it shows that there are no electrical paths with problems.

### Semiconductor device numbers and terminals to be checked

		Tester polarity		Continuity		Tester polarity		Continuity
		$\oplus$	θ			Ф	$\Theta$	
	D1	R/L1	P/+	No	D4	R/L1	N/-	Yes
		P/+	R/L1	Yes	D4	N/-	R/L1	No
Converter unit	D2	S/L2	P/+	No	D5	S/L2	N/-	Yes
Converter unit		P/+	S/L2	Yes		N/-	S/L2	No
	D3	T/L3	P/+	No	D6	T/L3	N/-	Yes
		P/+	T/L3	Yes		N/-	T/L3	No
	TR1	U	P/+	No	TR4	U	N/-	Yes
		P/+	U	Yes		N/-	U	No
Inverter		V	P/+	No	TR6	V	N/-	Yes
ilivertel		P/+	V	Yes		N/-	V	No
	TR5	W	P/+	No	TR2	W	N/-	Yes
	IKO	P/+	W	Yes		N/-	W	No

(Assuming that an analog meter is used.)



#### Cleaning 5.1.5

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.



- · Do not use solvent, such as acetone, benzene, toluene and alcohol, as these will cause the inverter surface paint to peel off.
- The display, etc. of the operation panel (FR-DU08) and parameter unit (FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

#### Replacement of parts 5.1.6

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part name	Estimated lifespan*1	Description	
Cooling fan	10 years	Replace (as required)	
Main circuit smoothing capacitor	10 years <sup>*2</sup>	Replace (as required)	
On-board smoothing capacitor	10 years <sup>*2</sup>	Replace the board (as required).	
Relays	_	As required	
Main circuit fuse	10 years	Replace (as required)	

- \*1 Estimated lifespan for when the yearly average surrounding air temperature is 40°C. (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)
- \*2 Output current: 80% of the inverter rating



• For parts replacement, contact the nearest Mitsubishi Electric FA center.

### ◆ Inverter parts life display

The inverter diagnoses the control circuit capacitor and the cooling fan by itself, and estimates their lives.

The self-diagnostic warning is output when the life span of each part is near its end. It gives an indication of replacement time.

Guideline for life judgment using the life warning output

Part	Judgment level		
Control circuit capacitor	Estimated remaining life 10%		
Cooling fan	Not more than the specified speed		




· Refer to the Instruction Manual (Detailed) to perform the life check of the inverter parts.

### ◆ Replacement procedure of the cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the surrounding air temperature. When unusual noise and/or vibration are noticed during inspection, the cooling fan must be replaced immediately.

#### ■ Removal


- **1.** Remove the fan cover fixing screws, and remove the fan cover.
- **2.** Disconnect the fan connector and remove the fan block.
- **3.** Remove the fan fixing screws, and remove the fan.



\*1 The number of cooling fans differs according to the inverter capacity.

#### ■ Reinstallation

**1.** After confirming the orientation of the fan, reinstall the fan so that the "AIR FLOW" faces up.



<Fan side face>

**2.** Install fans referring to the above figure. Tightening torque of the fan fixing screws is 0.73 N·m.



- $\bullet\,$  Installing the fan in the opposite direction of air flow may shorten the inverter life.
- · Ensure that the cables are not caught when the fan is installed.
- Switch OFF the power before starting the fan replacement work. To prevent an electric shock accident, keep the inverter with its covers on during fans replacement since the inverter circuits are charged with voltage even after power OFF.

## **♦** Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the DC section of the main circuit, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Adverse effects from ripple currents deteriorate capacitors. Replacement intervals of capacitors vary greatly with surrounding temperatures and operating conditions. Replace them roughly every 10 years when used in normal air-conditioned environments.

Inspecting the product visually:

- · Case: Check that the sides and bottom of the capacitor have not ruptured.
- · Rubber seal: Check for any noticeable bulging or severe cracks.
- Check for external cracks, discoloration, leakage, etc. It is assumed that the capacitor has reached the end of its life when its capacity has dropped below 80% of its rated capacity.



• The inverter diagnoses the control circuit capacitor by itself, and estimates its life. (Refer to the Instruction Manual (Detailed).)

### ◆ Relay output terminals

- The contacts of relays deteriorate over time. To prevent faults from occurring, relays must be replaced when they have reached the maximum of switching operations (switching life).
- The control terminal block must be replaced in case of failure of either relay connected to the relay output terminals A1, B1, and C1, or A2, B2, and C2.

#### ◆ Main circuit fuse

Fuses are used in some inverters. Replacement intervals of capacitors vary greatly with surrounding temperatures and operating conditions. Replace them roughly every 10 years when used in normal air-conditioned environments.


# 5.1.7 Removal and reinstallation of the control circuit terminal block

This product has a removable control circuit terminal block, which can be replaced with a new one or a control terminal option.

#### Removal and reinstallation

1. Loosen the two installation screws at the both side of the control circuit terminal block. (These screws cannot be removed.)

Slide down the control circuit terminal block to remove it.



**2.** Be careful not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the mounting screws.




• Before starting inverter replacement, switch OFF the power, wait for at least 10 minutes, and then check the voltage with a tester and such to ensure safety.

#### ◆ Removal and reinstallation precautions

Precautions to be taken when removing or reinstalling the control circuit terminal block are shown below. Observe the following precautions and handle the inverter properly to avoid malfunctions or failures.

- · To remove or reinstall the control circuit terminal block, keep it upright so that it is parallel with the inverter.
- To install the control circuit terminal block, slide it upward so that the tongues on the inverter slot into the grooves on the terminal block.
- Check that the terminal block is parallel to the inverter and the pins on the inverter control circuit connector are not bent.

  After checking proper connection, fix the terminal block in place with two screws.





- Do not tilt the terminal block while tightening the screws or removing it from the inverter. (Otherwise, a stress applied to the control circuit terminal block or the control circuit connector may cause damage to them.)
- After replacing the control terminal block, connect the jumper connector to the correct position in accordance with the control logic of input signals. (Refer to page 49.)


# 5.2 Measurement of main circuit voltages, currents, and powers

Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured. When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.



When installing meters etc. on the inverter output side
 When the inverter-to-motor wiring length is long, the meters and CTs may generate heat due to line-to-line leakage current.
 Therefore, choose the equipment which has enough allowance for the current rating.

To measure and display the output voltage and output current of the inverter, it is recommended to use the terminal AM and FM/CA output functions of the inverter.



# **♦** Measuring points and instruments

	Item	Measuring point	Measuring instrument	Remarks (reference measure	ed value)	
	Power supply voltage V1	Between R/L1 and S/L2, S/L2 and T/L3, and T/L3 and R/L1		Commercial power Within permissible AC voltage fluctor to page 118.)	uation. (Refer	
	Input current	Line current at R/L1, S/L2, and T/L3	Digital power meter (designed for inverter)			
	Input power P1	At R/L1, S/L2, and T/L3, and between R/L1 and S/ L2, S/L2 and T/L3, and T/ L3 and R/L1	(designed for inventor)	P1 = W11 + W12 + W13 (3-wattmeter method)		
Converter unit (FR-CC2)	Input power factor Pf1	Calculate after measuring input voltage, input current and input power. $Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1} \times 100\%$				
rter ur	Converter output	Between P/+ and N/-	Digital multimeter or other tester	Inverter LED indication 1.35 × V1		
Conve	Operation enable signal External thermal relay signal Reset signal	Across terminals RDI, OH, RES(+) and SD (for sink logic)	Digital multimeter or other tester, or moving-coil type instrument (internal resistance 50 k $\Omega$ or more)	to 30 VDC. Voltage when signal is ON: 1 V or terminal		
	Alarm signal	Between A1 and C1 Between B1 and C1	Digital multimeter or other tester	Continuity check*3 [Normal] Across A1 and C1: Discontinuity Across B1 and C1: Continuity [Fault] Across A1 and C1: Continuity Across B1 and C1: Discontinuity		

	Item	Measuring point	Measuring instrument	Remarks (reference measur	ed value)	
	Output voltage V2	Between U and V, V and W, and W and U	Digital power meter	Difference between the phases must be within 1% of the maximum output voltage.		
	Output current I2	Line current at U, V, and W	(designed for inverter)*1	Difference between the phases must be within 10%.		
	Output power P2	At U, V, and W, and between U and V, and V and W	Digital power meter (designed for inverter) P2 = W21 + W22 2-wattmeter method (or 3-wattmeter)		er method)	
	Output power factor Pf2	Calculate in similar manner $Pf_2 = \frac{P_2}{\sqrt{3}V_2 \times I_2} \times \frac{V_2}{V_2}$				
	Frequency setting signal	2, and between 4(+) and 5		0 to 10 VDC, 4 to 20 mA		
	r requericy setting signal	Between 1(+) and 5		0 to ±5 VDC and 0 to ±10 VDC		
	Power supply for a	Between 10(+) and 5		5.2 VDC		
	frequency setting potentiometer	Between 10E(+) and 5		10 VDC	Terminal 5 is	
Inverter	Frequency meter signal	Between AM(+) and 5		Approximately 10 VDC at maximum frequency (without frequency meter)	terminal.	
		Between CA(+) and 5		Approximately 20 mADC at maximum frequency		
		Between FM(+) and SD	Digital multimeter or other tester, or moving-coil type instrument (internal resistance 50 k $\Omega$ or more)	Approximately 5 VDC at maximum frequency (without frequency meter)  T1  8VDC  Pulse width T1: Adjust with C0 (Pr.900).  Pulse cycle T2: Set with Pr.55 (for frequency monitor only).	Terminal SD is a common terminal.	
	Start signal, Select signal, Reset signal, Output stop signal	Across STF, STR, RH, RM, RL, JOG, RT, AU, STOP, CS, RES, MRS(+) and SD (for sink logic)		Voltage when terminal is open: 20 to 30 VDC. Voltage when signal is ON: 1 V or less.		
	Fault signal	Between A1 and C1 Between B1 and C1	Digital multimeter or other tester	Continuity check*3 [Normal] Across A1 and C1: Discontinuity Across B1 and C1: Continuity [Fault] Across A1 and C1: Continuity Across B1 and C1: Discontinuity		

<sup>\*1</sup> Use an FFT to measure the output voltage accurately. A digital multimeter or general measuring instrument cannot measure accurately.

# 5.2.1 Measurement of powers

Use a digital power meter (for inverter) for the input side of the converter unit (FR-CC2) and the output side of the inverter.

# 5.2.2 Measurement of voltages

# ◆ Converter unit (FR-CC2) input side

Use digital power meters (for inverters) for the input side voltage.

# ♦ Inverter output side

When using a measuring instrument, use a digital power meter for inverters as the inverter outputs PWM-controlled square wave voltage.

<sup>\*2</sup> When the carrier frequency exceeds 5 kHz, do not use this instrument since using it may increase eddy current losses produced in metal parts inside the instrument, leading to burnout. In this case, use an approximate-effective value type.

<sup>\*3</sup> When the setting of Pr.195 ABC1 terminal function selection is the positive logic.

The value displayed on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values using the operation panel.

#### Measurement of currents 5.2.3

Use a digital power meter (for inverter) for the input side of the converter unit (FR-CC2) and the output side of the inverter. Since the converter unit input current tends to be unbalanced, measurement of three phases is recommended. The correct value cannot be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output current should be within 10%.

The inverter output current can be monitored on the operation panel. The value displayed on the operation panel is accurate even if the output frequency varies. Hence, it is recommended to monitor values on the operation panel.

### **Example of measuring converter unit (FR-CC2)** 5.2.4 input power factor

Calculate the factor from the effective power and the apparent power. A power-factor meter cannot indicate an exact value.

Total power factor of the converter unit =

Effective power

=  $\frac{\text{Three-phase input power found by the 3-wattmeter method}}{\sqrt{3} \times \text{V (power supply voltage)} \times \text{I (input current effective value)}}$ 

#### Measurement of converter output voltage (between 5.2.5 terminals P and N)

The output voltage of the converter is output across terminals P and N, and can be measured with a voltmeter such as a digital multimeter. The voltage varies according to the power supply voltage. Approximately 540 to 600 VDC is output when no load is connected. The voltage decreases when a load is applied.

When energy is regenerated from the motor during deceleration, for example, the converter output voltage rises to nearly 800 to 900 VDC maximum.

#### 5.2.6 Measurement of inverter output frequency

In the initial setting of the FM type inverter, a pulse train proportional to the output frequency is output across the pulse train output terminals FM and SD on the inverter. This pulse train output can be counted by a frequency counter, or a digital multimeter can be used to read the mean value of the pulse train output voltage. When a digital multimeter is used to measure the output frequency, approximately 5 VDC is indicated at the maximum frequency.

For detailed specifications of the pulse train output terminal FM, refer to the FR-A800 Instruction Manual (Detailed).

In the initial setting of the CA type inverter, a pulse train proportional to the output frequency is output across the analog current output terminals CA and 5 on the inverter. Measure the current using a digital multimeter.


For detailed specifications of the analog current output terminal CA, refer to the FR-A800 Instruction Manual (Detailed).

#### 5.2.7 Insulation resistance test using megger

· For the inverter and the converter unit (FR-CC2), conduct the insulation resistance test on the main circuit only as follows and do not perform the test on the control circuit. (Use a 500 VDC megger.)



- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter and the converter unit so that the test voltage is not applied to the inverter and the converter unit.
- For the continuity test of the control circuit, use a tester for high resistance range and do not use the megger or buzzer.



## 5.2.8 Pressure test

Do not conduct a pressure test. Deterioration may occur.

# **MEMO**

# **CHAPTER 6 SPECIFICATIONS**

6.1	Inverter rating	118
6.2	Common specifications	119
6.3	Outline dimension drawings	121

# 6 SPECIFICATIONS

This chapter explains the specifications of this product.

Always read the instructions before use.

# 6.1 Inverter rating

#### ♦ 400 V class

· Inverter

	Model FR-A842-[]		07700	08660	09620	10940	12120	
			315K	355K	400K	450K	500K	
	Applicable motor capacity (kW)*1 LD S ND (initial setting) 3		400	450	500	560	630	
Ар			355	400	450	500	560	
cap			315	355	400	450	500	
		HD	280	315	355	400	450	
		SLD	587	660	733	834	924	
	Rated capacity	LD	521	587	660	733	834	
	(kVA) <sup>*2</sup>	ND (initial setting)	465	521	587	660	733	
		HD	417	465	521	587	660	
		SLD	770	866	962	1094	1212	
	Rated current (A)	LD	683	770	866	962	1094	
	rtated current (A)	ND (initial setting)	610	683	770	866	962	
		HD	547	610	683	770	866	
Output		SLD	110% 60 s, 120% 3 s (inverse-time characteristics) at surrounding air temperature of 40°C					
S	Overload current rating*3	LD	120% 60 s, 150% 3 s (inverse-time characteristics) at surrounding air temperature of 50°C					
		ND (initial setting)	150% 60 s, 200% 3 s (inverse-time characteristics) at surrounding air temperature of 50°C					
		HD	200% 60 s, 250% 3 s (inverse-time characteristics) at surrounding air temperature of 50°C					
	Rated voltage*4		Three-phase 38	0 to 500 V				
	Regenerative braking torque*5(when used with the converter unit (FR-CC2))	egenerative raking orque <sup>*5</sup> (when used ith the converter		ntinuous				
Je.	Power supply voltage		430 to 780 VDC					
power	Control power supply	auxiliary input	Single-phase 380 to 500 V, 50/60 Hz*7					
Input	Permissible control power supply auxiliary input fluctuation Frequency ±5%, voltage ±10%							
Pro	tection rating of structu	ure (IEC 60529)*6	Open type (IP00)					
Со	oling system		Forced air					
Ар	prox. mass (kg)		163	163	243	243	243	

- \*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi Electric 4-pole standard motor.
- \*2 The rated output capacity is the value with respect to 440 V output voltage.
- \*3 The percentage of the overload current rating is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- \*4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the maximum point of the voltage waveform at the inverter output side is the power supply voltage multiplied by about  $\sqrt{2}$ .
- \*5 Value for the ND rating
- \*6 FR-DU08: IP40 (except for the PU connector)
- \*7 For the power voltage exceeding 480 V, set **Pr.977 Input voltage mode selection**. (For details, refer to the FR-A800 Instruction Manual (Detailed).)

## 6.2 **Common specifications**


	Control metho	d	Soft-PWM control, high carrier frequency PWM control (selectable among V/F control, Advanced magnetic flux vector control, Real sensorless vector control), Optimum excitation control, Vector				
			control <sup>*1</sup> , and PM sensorless vector control				
			0.2 to 590 Hz (The upper-limit frequency is 400 Hz under Advanced magnetic flux vector control, Real				
	Output freque	ncy range	sensorless vector control, Vector control <sup>*1</sup> , and PM sensorless vector control.)				
	Frequency setting Analog input		0.015 Hz/60 Hz at 0 to 10 V/12 bits (terminals 2 and 4). 0.03 Hz/60 Hz at 0 to 5 V/11 bits or 0 to 20 mA/approx. 11 bits (terminals 2 and 4), at 0 to $\pm$ 10 V/12 bits (terminal 1).				
	resolution	5	0.06 Hz/60 Hz at 0 to ±5 V/11 bits (terminal 1).				
		Digital input	0.01 Hz				
	Frequency	Analog input	Within ±0.2% of the maximum output frequency (25°C ±10°C)				
_	accuracy	Digital input	0.01% or less of the set output frequency				
Control	Voltage/freque characteristics		Base frequency can be set from 0 to 590Hz. Constant-torque/variable-torque pattern or adjustable 5 points V/F can be selected.				
	Starting torque	e	SLD rating: 120% 0.3 Hz, LD rating: 150% 0.3 Hz, ND rating: 200%*20.3 Hz, HD rating: 250%*20.3 Hz (under Real sensorless vector control or Vector control*1)				
	Targue baset						
	Torque boost	apploration time	Manual torque boost  O to 3600 s (coccleration and deceleration can be set individually) linear or S nattern acceleration/				
	setting	eceleration time	0 to 3600 s (acceleration and deceleration can be set individually), linear or S-pattern acceleration/deceleration mode, backlash countermeasures acceleration/deceleration can be selected.				
	DC injection b motor)	rake (induction	Operation frequency (0 to 120 Hz), operation time (0 to 10 s), operation voltage (0 to 30%) variable				
	Stall prevention operation level		Activation range of stall prevention operation (SLD rating: 0 to 120%, LD rating: 0 to 150%, ND rating: 0 to 220%, HD rating: 0 to 280%). Whether to use the stall prevention or not can be selected (V/F control, Advanced magnetic flux vector control)				
	Torque limit level		Torque limit value can be set (0 to 400% variable). (Real sensorless vector control, Vector control*1, PM sensorless vector control)				
	Frequency setting signal	Analog input	Terminals 2 and 4: 0 to 10 V / 0 to 5 V / 4 to 20 mA (0 to 20 mA).  Terminal 1: -10 to +10 V / -5 to +5 V.				
		Digital input	Input using the setting dial of the operation panel or parameter unit. Input of four-digit BCD (Binary-coded decimal) or 16-bit binary (when the option FR-A8AX is installed).				
	Start signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.				
	Input signal (1	2)	Low-speed operation command, Middle-speed operation command, High-speed operation command, Second function selection, Terminal 4 input selection, Jog operation selection, Selection of automatic restart after instantaneous power failure / flying start, Output stop, Start self-holding selection, Forward rotation command, Reverse rotation command, Inverter reset				
			The signal to be input can be changed using Pr.178 to Pr.189 (Input terminal function selection).				
	Pulse trair	n input	100k pulses/s				
Operation	Operational function		Maximum and minimum frequency settings, multi-speed operation, acceleration/deceleration pattern, thermal protection, DC injection brake, starting frequency, JOG operation, output stop (MRS), stall prevention, regeneration avoidance, increased magnetic excitation deceleration, frequency jump, rotation display, automatic restart after instantaneous power failure, electronic bypass sequence, remote setting, automatic acceleration/deceleration, retry function, carrier frequency selection, fast-response current limit, forward/reverse rotation prevention, operation mode selection, slip compensation, droop control, load torque high-speed frequency control, speed smoothing control, traverse, auto tuning, applied motor selection, gain tuning, RS-485 communication, PID control, PID pre-charge function, easy dancer control, cooling fan operation selection, stop selection (deceleration stop/coasting), power failure time deceleration-to-stop function, stop-on-contact control, PLC				
			function, life diagnosis, maintenance timer, current average monitor, multiple rating, orientation control 1, speed control, torque control, position control, pre-excitation, torque limit, test run, 24 V power supply input for control circuit, safety stop function, vibration control				
	Output signal		Inverter running, Up to frequency, Overload warning, Output frequency detection, Fault				
	Open collector terminals)	• `	The signal to be output can be changed using <b>Pr.190 to Pr.196 (Output terminal function selection)</b> .				
	Relay output (	two terminals)	Fault codes (4 bits) of the inverter can be output from the open collector.				
	Pulse trair	output	50k pulses/s				

		Pulse train	Max. 2.4 kHz via one terminal (for the indication of inverter output frequency).		
	For indication	output (FM type inverter)	The item for monitoring can be changed using Pr.54 FM/CA terminal function selection.		
	on external	Current output	Max. 20 mADC via one terminal (for the indication of inverter output frequency).		
E	meters	(CA type inverter)	The item for monitoring can be changed using Pr.54 FM/CA terminal function selection.		
Indication		Voltage output	Max. 10 VDC via one terminal (for the indication of inverter output frequency).		
<u>lu</u>		voltago output	The item for monitoring can be changed using Pr.158 AM terminal function selection.		
		Status	Output frequency, output current, output voltage, and frequency setting value are monitored.		
	Operation	monitoring	The item for monitoring can be changed using Pr.52 Operation panel main monitor selection.		
	panel (FR- DU08)	Fault record	When a protective function is activated, a fault indication is displayed and the output voltage, output current, output frequency, cumulative energization time, date (year, month, day) and time at the occurrence of the fault are stored. Each fault is recorded and the last 8 records can be displayed.		
Prot	Overcurrent trip during acceleration, Overcurrent trip during constant speed, Overcurrent deceleration or stop, Regenerative overvoltage trip during acceleration, Regenerative overvoltage trip during deceleration or stop, Inverter trip (electronic thermal relay function), Motor overload trip (electronic thermal relay function) sink overheat, Stall prevention stop, Loss of synchronism detection*5, Upper limit fault det Lower limit fault detection, Output side earth (ground) fault overcurrent, Output phase loss thermal relay operation*5, PTC thermistor operation*5, Option fault, Communication option Parameter storage device fault (control circuit board), Parameter storage device fault (match board), PU disconnection, Retry count excess*5, CPU fault, Operation panel power supply circuit/RS-485 terminals power supply short circuit, 24 VDC power fault, Abnormal output detection, Communication fault (inverter), Analog input fault, USB communication fault, Sa		Overcurrent trip during acceleration, Overcurrent trip during constant speed, Overcurrent trip during deceleration or stop, Regenerative overvoltage trip during acceleration, Regenerative overvoltage trip during constant speed, Regenerative overvoltage trip during deceleration or stop, Inverter overload trip (electronic thermal relay function), Motor overload trip (electronic thermal relay function), Heat sink overheat, Stall prevention stop, Loss of synchronism detection*5, Upper limit fault detection, Lower limit fault detection, Output side earth (ground) fault overcurrent, Output phase loss, External thermal relay operation*5, PTC thermistor operation*5, Option fault, Communication option fault, Parameter storage device fault (control circuit board), Parameter storage device fault (main circuit board), PU disconnection, Retry count excess*5, CPU fault, Operation panel power supply short circuit/RS-485 terminals power supply short circuit, 24 VDC power fault, Abnormal output current detection, Communication fault (inverter), Analog input fault, USB communication fault, Safety circuit fault, Overspeed occurrence*5, Speed deviation excess detection*1*5, Signal loss detection*1*5, Excessive position fault*1*5, Brake sequence fault*5, Encoder phase fault*1*5, 4 mA input fault*5, Pre-		
			charge fault* <sup>5</sup> , PID signal fault* <sup>5</sup> , Opposite rotation deceleration fault* <sup>5</sup> , Internal circuit fault, Magnetic pole position unknown* <sup>1</sup> , External fault during output operation* <sup>5</sup>		
			Fan alarm, Stall prevention (overcurrent), Stall prevention (overvoltage), Electronic thermal relay		
		Alarm,	function pre-alarm, PU stop, Speed limit indication <sup>*5</sup> , Parameter copy, Safety stop, Maintenance		
		Warning, Error	signal output <sup>*5</sup> , USB host error, Home position return setting error <sup>*5</sup> , Home position return		
		message	uncompleted <sup>*5</sup> , Home position return parameter setting error <sup>*5</sup> , Operation panel lock <sup>*5</sup> , Password		
			locked <sup>*5</sup> , Parameter write error, Copy operation error, 24 V external power supply operation, Continuous operation during communication fault		
	Surrounding a	ir temperature	-10°C to +50°C (non-freezing) (LD, ND, HD ratings) -10°C to +40°C (non-freezing) (SLD rating)		
Environment	Surrounding a	ir humidity	95% RH or less (non-condensing) (With circuit board coating (conforming to IEC 60721-3-3 3C2/3S2)) 90% RH or less (non-condensing) (Without circuit board coating)		
in	Storage tempe	erature <sup>*3</sup>	-20°C to +65°C		
	Ambience		Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)		
	Altitude/vibration	on	Maximum 2500 m <sup>*4</sup> , 2.9 m/s <sup>2</sup> or less at 10 to 55 Hz (in either X, Y, or Z direction)		

- \*1 Available when a Vector control compatible option is installed.
- \*2 In the initial setting, the starting torque is limited to 150% by the torque limit level.
- \*3 Applicable to conditions for a short time, for example, in transit.
- \*4 For installation at an altitude above 1000 m, consider a 3% reduction in the rated current per 500 m increase in altitude.
- \*5 Not activated in the inverter in the initial state.


# 6.3 Outline dimension drawings

#### FR-A842-07700(315K), FR-A842-08660(355K)



(Unit: mm)

#### FR-A842-09620(400K), FR-A842-10940(450K), FR-A842-12120(500K)



(Unit: mm)

#### Operation panel (FR-DU08, FR-LU08)

3

#### **Outline drawing**

72

# Panel 3.2max Operation panel 78.5 3 2-M3 screw

\* Denotes the space required to connect an optional parameter unit connection cable (FR-CB2[]). When using another cable, leave the space required for the cable specification.

120 or more\*

Parameter unit connection cable (FR-CB2[])

(option)

Operation panel connection connector (FR-ADP option)

27.8

Panel cutting dimension drawing

(Unit: mm)

# **CHAPTER 7** APPENDIX

7.1	For customers replacing the conventional model with this inverter	124
7.2	Comparison with FR-A840	126
7.3	Instructions for compliance with the EU Directives	127
7.4	Instructions for UL and cUL	130
7.5	Instructions for EAC	131
7.6	Restricted Use of Hazardous Substances in Electronic and Electrical Products	133
7.7	Referenced Standard (Requirement of Chinese standardized law)	133

# **7** APPENDIX

APPENDIX provides the reference information for use of this product. Refer to APPENDIX as required.

# 7.1 For customers replacing the conventional model with this inverter

# 7.1.1 Replacement of the FR-A740 series

# ♦ Differences and compatibility with the FR-A740 series

	Item	FR-A740	FR-A842	
	Control method	V/F control Advanced magnetic flux vector control Real sensorless vector control Vector control (with plug-in option) PM sensorless vector control (IPM motor)	V/F control Advanced magnetic flux vector control Real sensorless vector control Vector control (with plug-in option) PM sensorless vector control (IPM/SPM motor)	
Added functions		_	USB host function Safety stop function etc.	
~ ~	V/F control	400 Hz	590 Hz	
Maximum output frequency	Advanced magnetic flux vector control	120 Hz	400 Hz	
outpr	Real sensorless vector control	120 Hz	400 Hz	
Ē	Vector control	120 Hz	400 Hz	
Maxim	PM sensorless vector control  300 Hz  4		400 Hz	
	PID control	Turn the X14 signal ON to enable PID control.	When the X14 signal is not assigned, just set a value in Pr.128 to enable PID control.  When the X14 signal is assigned, turn the X14 signal ON while Pr.128 ≠ "0" to enable PID control.  The PID pre-charge function and dancer control are added.	
	omatic restart after stantaneous power failure	Turn the CS signal ON to enable restart.	The CS signal does not need to be assigned. (Restart is enabled with the <b>Pr.57</b> setting only.)	
Number of motor poles V/F control switching		The V/F switchover (X18) signal is valid when <b>Pr.81</b> = "12 to 20" (2 to 10 poles).	Pr.81 = "12" (12 poles) The X18 signal is valid regardless of the Pr.81 setting. (The Pr.81 settings "14 to 20" are not available.)	
PT	C thermistor input	Input through terminal AU (The function of terminal AU is switched by a switch.)	Input through terminal 2 (The function of terminal 2 is switched by the <b>Pr.561</b> setting.)	
	USB connector	B connector	Mini B connector	
Cor	ntrol circuit terminal block	Removable terminal block (screw type)	Removable terminal block (spring clamp type)	
Terr	ninal response level		than the FR-A700's terminals. By setting <b>Pr.289 Inverter</b> the terminal response level can be compatible with that of setting according to the system.	
	PU	FR-DU07 (4-digit LED) FR-PU07	FR-DU08 (5-digit LED) FR-PU07 (Some functions are unavailable.) The FR-DU07 is not supported.	
	Plug-in option	Dedicated plug-in options (not interchangeable)		
	mmunication option	Connected to the connector 3	Connected to the connector 1	
	Installation size	Installation size is not compatible. (New mounting holes		
	Converter	Built-in for all capacities	The converter unit (FR-CC2) is required.	
	DC reactor	DC reactor (FR-HEL) is provided.	Built in the converter unit (FR-CC2)	
	Brake unit	FR-BU2, MT-BU5	FR-BU2	

### Installation precautions

- · Removal procedure of the front cover is different. (Refer to page 21.)
- Plug-in options of the FR-A700 series are not compatible.
- · Operation panel (FR-DU07) cannot be used.

### **♦** Wiring instructions

· The spring clamp type terminal block has changed to the screw type. Use of blade terminals is recommended.

# ♦ Instructions for continuous use of the PU07 (parameter unit) manufactured in September 2015 or earlier

- For the FR-A800 series, many functions (parameters) have been added. When setting these parameters, the parameter names and setting ranges are not displayed.
- Only the parameter with the numbers up to "999" can be read and set. The parameters with the numbers after "999" cannot be read or set.
- Many protective functions have been added for the FR-A800 series. These functions are available, but all faults are displayed as "Fault". When the fault history is checked, "ERR" appears. Added faults will not appear on the parameter unit. (However, MT1 to MT3 are displayed as MT.)
- · Parameter copy/verification function are not available.

## **♦** Copying parameter settings

• The FR-A700 series' parameter settings can be easily copied to the FR-A800 series by using the setup software (FR Configurator2). (Not supported by the setup software FR-SW3-SETUP or older.)

# 7.1.2 Replacement of the FR-A500(L) series

### **♦** Installation precautions

- Installation size is not compatible. (New mounting holes are required.)
- The optional converter unit (FR-CC2) is required.

### 7.2 **Comparison with FR-A840**

Item	FR-A840	FR-A842
Pr.30 Regenerative function selection	Setting ranges: "0 to 2, 10, 11, 20, 21, 100 to 102, 110, 111, 120, 121" Initial value: "0"	Setting ranges: "2, 10, 11, 102, 110, 111" Initial value: "10"
Pr.70 Special regenerative brake duty	With the parameter	Without the parameter
Monitor function (Pr.52, Pr.54, Pr.158, Pr.774 to Pr.776, Pr.992, Pr.1027 to Pr.1034)	Regenerative brake duty: Available	Regenerative brake duty: Unavailable
Input terminal function selection (Pr.178 to Pr.189)	DC feeding operation permission (X70), DC feeding cancel (X71): Available	DC feeding operation permission (X70), DC feeding cancel (X71): Unavailable
Pr.187 MRS terminal function selection	Initial value "24" (MRS)	Initial value "10" (X10)
Output terminal function assignment selection (Pr.190 to Pr.196, Pr.313 to Pr.322)	Instantaneous power failure/undervoltage (IPF), Regenerative brake prealarm (RBP), DC current feeding (Y85), Main circuit capacitor life (Y87), Inrush current limit circuit life (Y89) Available	Instantaneous power failure/undervoltage (IPF), Regenerative brake prealarm (RBP), DC current feeding (Y85), Main circuit capacitor life (Y87), Inrush current limit circuit life (Y89) Unavailable
Pr.192 IPF terminal function selection	Initial value "2" (IPF)	Initial value "9999" (No function)
Inrush current limit circuit life display, Main circuit capacitor life display (Pr.256, Pr.258, Pr.259)	With the parameter	Without the parameter
Pr.599 X10 terminal input selection	Initial value "0" (NO contact specification)	Initial value "1" (NC contact specification)
Pr.872 Input phase loss protection selection	With the parameter	Without the parameter
Warning, protective functions	Regenerative brake prealarm (RB), Instantaneous power failure (E.IPF), Undervoltage (E.UVT), Input phase loss (E.ILF), Brake transistor alarm detection (E.BE), Inrush current limit circuit fault Available	Regenerative brake prealarm (RB), Instantaneous power failure (E.IPF), Undervoltage (E.UVT), Input phase loss (E.ILF), Brake transistor alarm detection (E.BE), Inrush current limit circuit fault Unavailable

# 7.3 Instructions for compliance with the EU Directives

The EU Directives are issued to standardize different national regulations of the EU Member States and to facilitate free movement of the equipment, whose safety is ensured, in the EU territory.

Since 1996, compliance with the EMC Directive that is one of the EU Directives has been legally required. Since 1997, compliance with the Low Voltage Directive, another EU Directive, has been also legally required. When a manufacturer confirms its equipment to be compliant with the EMC Directive and the Low Voltage Directive, the manufacturer must declare the conformity and affix the CE marking.

· The authorized representative in the EU

The authorized representative in the EU is shown below.

Name: Mitsubishi Electric Europe B.V.

Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany

#### **◆ EMC Directive**

We declare that this inverter conforms with the EMC Directive and affix the CE marking on the inverter.

- EMC Directive: 2014/30/EU
- Standard(s): EN 61800-3:2004+A1:2012 (Second environment / PDS Category "C3")
- This inverter is not intended to be used on a low-voltage public network which supplies domestic premises. When using
  the inverter in a residential area, take appropriate measures and ensure the conformity of the inverter used in the
  residential area.
- · Radio frequency interference is expected if used on such a network.
- The installer shall provide a guide for installation and use, including recommended mitigation devices.

#### Note:

First environment

Environment including buildings/facilities which are directly connected to a low voltage main supply which also supplies residential buildings. Directly connected means that there is no intermediate transformer between these buildings.

Second environment

Environment including all buildings/facilities which are not directly connected to a low voltage main supply which also supplies residential buildings.

#### ■ Note

Ensure the EMC filter is enabled, install the product as stated below, and, then carry out any wiring.

- The converter unit has a built-in EMC filter (Class C3). Enable the EMC filter. (For the details, refer to page 81.)
- · Connect the inverter and the converter unit to an earthed (grounded) power supply.
- Install the motor and controller cable found in the EMC Installation Manual (BCN-A21041-204) and Technical News (MF-S-113) according to the instructions.
- To make full use of the built-in EMC filter, motor cable lengths should not exceed 20 m.
- · Ensure that the finalized system which includes an inverter and converter unit complies with the EMC Directive.

## **♦** Low Voltage Directive

We have self-confirmed our inverters as products compliant to the Low Voltage Directive and affix the CE marking on the inverters.

• Low Voltage Directive: 2014/35/EU

· Conforming standard: EN 61800-5-1:2007

#### ■ Outline of instructions

- Do not use an earth leakage circuit breaker as an electric shock protector without connecting the equipment to the earth. Connect the equipment to the earth (ground) securely.
- Wire the earth terminal independently. (Do not connect two or more cables to one terminal.)

- Use the cable sizes on page 40under the following conditions.
  - Surrounding air temperature: 40°C maximum
  - If conditions are different from above, select appropriate wire according to EN 60204 or IEC 60364-5-52.
- Use a tinned (plating should not include zinc) crimping terminal to connect the earth (ground) cable. When tightening the screw, be careful not to damage the threads.
- For use as a product compliant with the Low Voltage Directive, use PVC cable whose size is indicated on page 40.
- · Use the molded case circuit breaker and magnetic contactor which conform to the EN or IEC Standard.
- DC current may flow from the converter to a protective earth (ground) conductor. When using a residual current device (RCD) or residual current monitor (RCM), connect a type B RCD or RCM to the power supply side.
- Use the inverter under the conditions of overvoltage category II (regardless of the earth (ground) condition of the power supply), overvoltage category III (400 V class converters must be used with the earth-neutral system power supply) and pollution degree 2 or lower specified in IEC 60664.
  - To use the inverter under the conditions of pollution degree 2, install it in the enclosure of IP2X or higher.
  - To use the inverter under the conditions of pollution degree 3, install it in the enclosure of IP54 or higher.
- On the input and output of the inverter and the converter unit, use cables of the type and size set forth in EN 60204 or IEC 60364-5-52.
- The operating capacity of the relay outputs (terminal symbols A1, B1, C1, A2, B2, C2) should be 30 VDC, 0.3 A. (Relay output has basic isolation from the internal circuit of the inverter and the converter unit.)
- Control circuit terminals on page 33are safely isolated from the main circuit.
- Environment (For the details, refer to page 24.)

	During operation	In storage	During transportation
Surrounding air temperature	LD, ND (initial setting), HD: -10°C to +50°C SLD: -10°C to +40°C	-20°C to +65°C	-20°C to +65°C
Humidity	95% RH or less	95% RH or less	95% RH or less
Maximum altitude	2500 m <sup>*1</sup>	2500 m	10000 m

<sup>\*1</sup> For installation at an altitude above 1000 m, consider a 3% reduction in the rated current per 500 m increase in altitude.

#### ■ Branch circuit protection

Class T, Class J, Class CC, or Class L fuse must be provided. (Use a product which conforms to the EN or IEC Standard.)

FR-CC2-[]	H315K	H355K	H400K	H450K	H500K	H560K	H630K
Rated fuse voltage (V)	500 V or mor	500 V or more					
Permissible fuse rating (A)	1100	1200	1350	1500	1800	1800	1800

#### ■ Short circuit ratings

Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 500 V maximum.


### **◆** Motor overload protection

When using the electronic thermal relay function as motor overload protection, set the rated motor current in **Pr.9 Electronic thermal O/L relay**.

This function detects the overload of the motor and shut off the inverter output by stopping the operation of the transistor at the inverter output side. (The operation characteristic is shown below.)

- · When using the Mitsubishi Electric constant-torque motor
  - 1. Set "1, 13 to 16" in Pr.71. (This setting enables the 100% constant-torque characteristic in the low-speed range.)
  - 2. Set the rated motor current in Pr.9.

Operational characteristic of the electronic thermal relay function



- \*1 When setting Pr.9 to a value (current value) of 50% of the inverter rated output current.
- \*2 The % value denotes the percentage to the inverter rated current. It is not the percentage to the rated motor current.
- \*3 When you set the electronic thermal relay function dedicated to the Mitsubishi Electric constant-torque motor, this characteristic curve applies to operation at 6 Hz or higher.
- \*4 Transistor protection is activated depending on the temperature of the heat sink. The protection may be activated even with less than 150% depending on the operating conditions.

### • NOTE

- The internal accumulated heat value of the electronic thermal O/L relay is reset to the initial value by the inverter's power reset or reset signal input. Avoid unnecessary reset and power-OFF.
- Install an external thermal relay (OCR) between the inverter and motors to operate several motors, a multi-pole motor or a dedicated motor with one inverter. When setting an external thermal relay, note that the current indicated on the motor rating plate is affected by the line-to-line leakage current. (Refer to the Instruction Manual (Detailed).)
- The cooling effect of the motor drops during low-speed operation. Use a thermal protector or a motor with built-in thermistor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In such case, use an external thermal relay.
- · A dedicated motor cannot be protected by the electronic thermal relay. Use an external thermal relay.
- · Motor over temperature sensing is not provided by the drive.
- The electronic thermal memory retention function is not provided by the drive.

# 7.4 Instructions for UL and cUL

(Standard to comply with: UL 508C, CSA C22.2 No.274-13)

#### **♦** Installation

The below types of inverter have been approved as products for use in enclosure.

Design the enclosure so that the surrounding air temperature, humidity and ambience of the inverter will satisfy the specifications. (Refer to page 24.)

#### ■ Branch circuit protection

For installation in the United States, Class T, Class J, Class CC, or Class L fuse must be provided, in accordance with the National Electrical Code and any applicable local codes.

For installation in Canada, Class T, Class J, Class CC, or Class L fuse must be provided, in accordance with the Canadian Electrical Code and any applicable local codes.

FR-CC2-[]	H315K	H355K	H400K	H450K	H500K	H560K	H630K
Rated fuse voltage (V)	500 V or more						
Permissible fuse rating (A)	1100	1200	1350	1500	1800	1800	1800

## Wiring to the power supply and the motor

Refer to the National Electrical Code (Article 310) regarding the allowable current of the cable. Select the cable size for 125% of the rated current according to the National Electrical Code (Article 430).

For wiring the input (R/L1, S/L2, T/L3) terminals of the converter unit and output (U, V, W) terminals of the inverter, use the UL listed copper, stranded wires (rated at 75°C) and round crimp terminals. Crimp the terminals with the crimping tool recommended by the terminal manufacturer.

## **♦** Short circuit ratings

Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 500 V maximum.

## **♦** Motor overload protection


When using the electronic thermal relay function as motor overload protection, set the rated motor current in **Pr.9 Electronic** thermal O/L relay.

This function detects the overload (overheat) of the motor and shut off the inverter output by stopping the operation of the transistor at the inverter output side. (The operation characteristic is shown below.)

- · When using the Mitsubishi Electric constant-torque motor
  - **1.** Set "1, 13 to 16" in **Pr.71**. (This setting enables the 100% constant-torque characteristic in the low-speed range.)

#### 2. Set the rated motor current in Pr.9.

Operation Characteristics of electronic thermal O/L relay function



- When setting **Pr.9** to a value (current value) of 50% of the inverter rated output current.
- \*2 The % value denotes the percentage to the inverter rated current. It is not the percentage to the rated motor current.
- \*3 When you set the electronic thermal relay function dedicated to the Mitsubishi Electric constant-torque motor, this characteristic curve applies to operation at 6 Hz or higher.
- \*4 Transistor protection is activated depending on the temperature of the heat sink. The protection may be activated even with less than 150% depending on the operating conditions.

#### NOTE

- The internal accumulated heat value of the electronic thermal O/L relay is reset to the initial value by the inverter's power reset or reset signal input. Avoid unnecessary reset and power-OFF.
- Install an external thermal relay (OCR) between the inverter and motors to operate several motors, a multi-pole motor or a dedicated motor with one inverter. When setting an external thermal relay, note that the current indicated on the motor rating plate is affected by the line-to-line leakage current. (Refer to the Instruction Manual (Detailed).)
- The cooling effect of the motor drops during low-speed operation. Use a thermal protector or a motor with built-in thermistor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In such case, use an external thermal relay.
- · A dedicated motor cannot be protected by the electronic thermal relay. Use an external thermal relay.
- · Motor over temperature sensing is not provided by the drive.

# 7.5 Instructions for EAC

EHC

The product certified in compliance with the Eurasian Conformity has the EAC marking.

Note: EAC marking

In 2010, three countries (Russia, Belarus, and Kazakhstan) established a Customs Union for the purposes of revitalizing the economy by forming a large economic bloc by abolishing or reducing tariffs and unifying regulatory procedures for the handling of articles.

Products to be distributed over these three countries of the Customs Union must comply with the Customs Union Technical Regulations (CU-TR), and the EAC marking must be affixed to the products.

For information on the country of origin, manufacture year and month, and authorized sales representative (importer) in the CU area of this product, refer to the following:

· Country of origin indication

Check the rating plate of the product. (Refer to page 13.)

Example: MADE IN JAPAN · Manufactured year and month

Check the SERIAL number indicated on the rating plate of the product. (Refer to page 13.)

• Authorized sales representative (importer) in the CU area

The authorized sales representative (importer) in the CU area is shown below.

Name: Mitsubishi Electric (Russia) LLC

Address: 52, bld 1 Kosmodamianskaya Nab 115054, Moscow, Russia

Phone: +7 (495) 721-2070 Fax: +7 (495) 721-2071

# 7.6 Restricted Use of Hazardous Substances in Electronic and Electrical Products

The mark of restricted use of hazardous substances in electronic and electrical products is applied to the product as follows based on the "Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products" of the People's Republic of China.

电器电子产品有害物质限制使用标识要求



本产品中所含有的有害物质的名称、含量、含有部件如下表所示。

• 产品中所含有害物质的名称及含量

	有害物质 *1							
部件名称 * <sup>2</sup>	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)		
电路板组件(包括印刷电路板及其构成的零部件, 如电阻、电容、集成电路、连接器等)、电子部件	×	0	×	0	0	0		
金属壳体、金属部件	×	0	0	0	0	0		
树脂壳体、树脂部件	0	0	0	0	0	0		
螺丝、电线	0	0	0	0	0	0		

- 上表依据 SJ/T11364 的规定编制。
- 〇:表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572 规定的限量要求以下。
- ×:表示该有害物质在该部件的至少一种均质材料中的含量超出 GB/T26572 规定的限量要求。
  - \*1 即使表中记载为 × ,根据产品型号,也可能会有有害物质的含量为限制值以下的情况。
  - \*2 根据产品型号,一部分部件可能不包含在产品中。

# 7.7 Referenced Standard (Requirement of Chinese standardized law)

This Product is designed and manufactured accordance with the following Chinese standards.

Machinery safety:	GB/T 16855.1 GB/T 12668.502 GB 28526 GB/T 12668.3
Electrical safety:	GB/T 12668.501
EMC	GB/T 12668.3

## WARRANTY

When using this product, make sure to understand the warranty described below.

#### 1. Warranty period and coverage

We will repair any failure or defect (hereinafter referred to as "failure") in our FA equipment (hereinafter referred to as the "Product") arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit are repaired or replaced.

#### [Term]

The term of warranty for Product is twelve months after your purchase or delivery of the Product to a place designated by you or eighteen months from the date of manufacture whichever comes first ("Warranty Period"). Warranty period for repaired Product cannot exceed beyond the original warranty period before any repair work.

#### [Limitations]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule. It can also be carried out by us or our service company upon your request and the actual cost will be charged.
  However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
  - a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
  - · a failure caused by any alteration, etc. to the Product made on your side without our approval
  - a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety
    device required by applicable laws and has any function or structure considered to be indispensable according to a common
    sense in the industry
  - a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
  - any replacement of consumable parts (condenser, cooling fan, etc.)
  - a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
  - a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
  - any other failures which we are not responsible for or which you acknowledge we are not responsible for

#### 2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

#### 3 Service in overseas

Our regional FA Center in overseas countries will accept the repair work of the Product; however, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA center for details.

#### 4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi Electric shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi Electric.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi Electric products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi Electric products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

#### 5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

#### 6. Application and use of the Product

- (1) For the use of our product, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in product, and a backup or fail-safe function should operate on an external system to product when any failure or malfunction occurs
- (2) Our product is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.

In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used. We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

# About the enclosed CD-ROM

The enclosed CD-ROM contains PDF files of manuals related to this product.

#### **♦**Before using the enclosed CD-ROM

- The copyright and other rights of the enclosed CD-ROM all belong to Mitsubishi Electric Corporation.
- · No part of the enclosed CD-ROM may be copied or reproduced without the permission of Mitsubishi Electric Corporation.
- · Specifications of the enclosed CD-ROM are subject to change for modification without notice.
- · We are not responsible for any damages and lost earnings, etc. from use of the enclosed CD-ROM.
- Microsoft, Windows, Windows Vista, and Internet Explorer are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe and Adobe Reader are registered trademarks of Adobe Systems Incorporated in the United States and/or other countries

Intel and Pentium are registered trademarks of Intel Corporation in the United States and/or other countries.

Other company and product names herein are the trademarks and registered trademarks of their respective owners.

Warranty

We do not provide a warranty against defects in the enclosed CD-ROM and related documents.



• This is a personal computer dedicated CD-ROM. Do not attempt to play it on ordinary audio devices. The loud volume may damage hearing and speakers.

#### ◆System requirements for the enclosed CD-ROM

· The following system is required to read instruction manuals contained in the enclosed CD-ROM.

Item	Specification
os	Microsoft® Windows® 10, Windows® 8.1, Windows® 8, Windows® 7, Windows Vista®
CPU	Intel® Pentium® or better processor
Memory	128MB of RAM
Hard disk	90MB of available hard-disk space
CD-ROM drive	Double speed or more (more than quadruple speed is recommended)
Monitor	800x600 dot or more
Application	Adobe® Reader® 7.0 or higher Internet Explorer® 6.0 or higher

#### **◆**Operating method of the enclosed CD-ROM

- · How to read instruction manuals
  - Step 1. Start a computer and place the enclosed CD-ROM in the CD-ROM drive.
  - Step 2. The main window automatically opens by the web browser.
  - Step 3. Choose your language from the language choice menu.
  - Step 4. Click a manual you want to read in the "INSTRUCTION MANUAL" list.
  - Step 5. PDF manual you clicked opens.
- · Manual opening of the enclosed CD-ROM
  - Step 1. Start a computer and place the enclosed CD-ROM in the CD-ROM drive.
  - Step 2. Open "index.html" file in the enclosed CD-ROM.
  - Step 3. The main window opens by the web browser. Operate according to the steps from "Step 3" of "How to read instruction manuals".
- PDF data of the instruction manual are stored in "MANUAL" folder on this CD-ROM.

# **REVISIONS**

\*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Revision
Feb. 2014	IB(NA)-0600534ENG-A	First edition
Jul. 2016	IB(NA)-0600534ENG-B	Modification
		Safety stop function
		Addition
		Instructions for EAC
	ID (114) 000050 (ENIO O	Restricted Use of Hazardous Substances in Electronic and Electrical Products
Mar. 2019	IB(NA)-0600534ENG-C	Addition • Referenced Standard
		(Requirement of Chinese standardized law)
		Removal and reinstallation precautions of the control circuit terminal block
		Rating plate (High power factor converter)
		rading plate (riigh perior label)

# FR-A800/A800 Plus Series Instruction Manual Supplement

# 1 Internal storage device fault (E.PE6)

The operation of the storage device in the inverter can be checked.

If a data fault occurs in the storage device in the inverter, the protective function (E.PE6) is activated.

When the read value of **Pr.890** is "7" or smaller, an inverter reset after All parameter clear can return the operation to normal. (The parameters that had been changed before All parameter clear must be set again.)

Operation panel indication	E.PE6	E.	PE6	FR-LU08 indication	Fault			
Name	Internal storage device fault							
Description		This protective function is activated by an inverter reset if writing data fails due to power-OFF or a data fault occurs in the storage device during parameter operations*1.						
Check point	Check if the power v	Check if the power was turned OFF during parameter operations.						
Corrective action	When E.PE6 occ Check the read v then an inverter r set again. When E.PE6 occ	Check the power supply or the devices on the power system to check that the devices have no fault.  • When E.PE6 occurs due to power-OFF during parameter operations:  Check the read value of <b>Pr.890</b> . When the value is "7" or smaller, perform All parameter clear and then an inverter reset. The parameters that had been changed before All parameter clear must be						

<sup>\*1</sup> For example, when parameter clear, All parameter clear, Parameter copy, or offline auto tuning is performed in the inverter, or when parameter batch write is performed in FR Configurator2.



- "E.PE6" does not activate the retry function.
- "E.PE6" outputs the Fault output 3 (Y91) signal.
- · "E.PE6" turns OFF the Safety monitor output (SAFE) signal.
- "E.PE6" is not cleared by turning ON the Fault clear (X51) signal.
- "E.PE6" is not activated during emergency drive operation.
- The communication data code for "E.PE6" is 172 (HAC).

## ◆ Checking faulty area in the internal storage device

When E.PE6 occurs, faulty area in the internal storage device can be checked by reading Pr.890.

Pr.	Name	Initial value	Setting range	Description
890 H325	Internal storage device status indication	0	(0 to 9999)	A faulty area detected by self-check function can be indicated in the internal storage device.



- Use the read value of Pr.890 to check the faulty area.
- The following table shows faulty areas indicated by the read value of Pr.890. Some read values indicate that there are multiple
  faulty areas. (For example, the read value "7" indicates that all the areas described in No. 1 to No. 3 are faulty.)

No.	Read value	Description
1	1, 3, 5, 7	Storage area other than the area for parameter settings is faulty (such as area for the set frequency). (When All parameter clear is performed, the set frequency, remotely-set frequency, host name for Ethernet communication, position pulse, multi-revolution counter, and offline auto tuning data are cleared.)
2	2, 3, 6, 7	Storage area for standard parameter settings is faulty.
3	4, 5, 6, 7	Storage area for communication parameter settings is faulty.
4	8 to 9999	Area for manufacturer setting

# FR-A800/A800 Plus Series Instruction Manual Supplement

# 1 Earth (ground) fault detection at start / restricting reset method for an earth (ground) fault

The reset method for the output side earth (ground) fault overcurrent (E.GF) can be restricted.

- Select whether to enable or disable the earth (ground) fault detection at start. When enabled, the earth (ground) fault detection is performed immediately after a start signal input to the inverter.
- Select whether to restrict the reset method for an earth (ground) fault.

D.	Pr. Name	Initial value	Setting range	Description		
FI.		Illitiai value	Setting range	Earth (ground) fault	Reset method	
249 Earth (ground) fault det H101 at start	Fadi (a. a. al) fadi data di a	0	0	Not detected at start	Not restricted	
			1	Detected at start		
	at start		2	Detected at Start	Restricted	

# ◆ Selecting whether to perform the earth (ground) fault detection at start ✓// Magneticifix

- If an earth (ground) fault is detected at start while **Pr.249** = "1 or 2", the output side earth (ground) fault overcurrent (E.GF) is detected and output is shut off.
- · Earth (ground) fault detection at start is enabled under V/F control and Advanced magnetic flux vector control.
- · When the Pr.72 PWM frequency selection setting is high, enable the earth (ground) fault detection at start.

## • NOTE

- Because the detection is performed at start, output is delayed for approx. 20 ms every start.
- Use Pr.249 to enable/disable the earth (ground) fault detection at start. During operation, earth (ground) faults are
  detected regardless of the Pr.249 setting.

### Restricting reset method for an earth (ground) fault

- The reset method when the output is shut off due to the output side earth (ground) fault overcurrent (E.GF) can be restricted. When E.GF occurs while **Pr.249** = "2", E.GF can be reset only by turning OFF the control circuit power.
- This restriction prevents the inverter from being damaged due to repeated reset operations by the other methods such as entering the RES signal.
- When E.GF occurs while Pr.249 = "2", the output short-circuit detection (ALM4) signal can be output.
- For the terminal used to output the ALM4 signal, set "23" (positive logic) or "123" (negative logic) in any of **Pr.190** to **Pr.196 (Output terminal function selection)**.
- If Pr.249 is set to "2" while the retry function is enabled (Pr.67 is not set to "0"), no retry is performed even when E.GF occurs.
- If **Pr.249** is set to "2" while the automatic bypass switching after inverter fault is enabled (**Pr.138** is not set to "1"), the operation is not switched to the commercial power supply operation even when E.GF occurs.

#### NOTE

- Changing the terminal assignment using Pr.190 to Pr.196 (Output terminal function selection) may affect the
  other functions. Set parameters after confirming the function of each terminal.
- E.GF is not cleared by turning ON the Fault clear (X51) signal when Pr.249 = "2".
- If E.GF occurs during emergency drive operation when Pr.249 = "2", the output is shut off.

# 2 Output short-circuit fault (E.SCF)

Select the reset operation and fault indication for an output short-circuit.

Pr.	Name	Initial	Setting range	Description		
F1.	Name	value	Setting range	Operation after detection	Reset method	
521		0	0	E.OC1 to E.OC3	Not restricted	
H194			1	E.SCF	Restricted	

- The fault indication for an output short-circuit (E.OC1 to E.OC3, and E.SCF) can be changed by the Pr.521 setting.
- When an output short-circuit is detected while Pr.521 = "1", E.SCF is displayed and the inverter output is shut off.
- When E.SCF occurs while **Pr.521** = "1", E.SCF can be reset only by turning OFF the control circuit power. (E.OC1 to E.OC3 can be reset by any reset method.)
- This restriction prevents the inverter from being damaged due to repeated reset operations by the other methods such as entering the RES signal.
- When E.SCF occurs, the output short-circuit detection (ALM4) signal can be output.
- For the terminal used to output the ALM4 signal, set "23" (positive logic) or "123" (negative logic) in any of **Pr.190** to **Pr.196 (Output terminal function selection)**.
- If the automatic bypass switching after inverter fault is enabled (**Pr.138** is not set to "1"), the operation is not switched to the commercial power supply operation even when E.SCF occurs.

Operation panel indication	E.SCF	E.	SEF	FR-LU08 indication	Fault			
Name	Output short-circuit	ault						
Description		The inverter output is shut off when an output short-circuit is detected while <b>Pr.521</b> = "1". When <b>Pr.521</b> = "0" (initial value), E.OC1, E.OC2, or E.OC3 appears when an output short-circuit is detected.						
Check point	Check for output she	Check for output short-circuit.						
Corrective action	Check the wiring to circuit power to rese			ut short circuit does n	ot occur, then turn OFF the control			

#### NOTE

- When short-circuit resistance is large, the current does not reach the short-circuit detection level. In such a case, an output short-circuit cannot be detected.
- Changing the terminal assignment using **Pr.190** to **Pr.196** (**Output terminal function selection**) may affect the other functions. Set parameters after confirming the function of each terminal.
- · E.SCF does not activate the retry function.
- E.SCF is not cleared by turning ON the Fault clear (X51) signal.
- · If E.SCF occurs during emergency drive operation, the output is shut off.
- The communication data code for E.SCF is 20 (H14).

# 3 Extended detection time of the output current and zero current

The setting range of the **Pr.151 Output current detection signal delay time** and **Pr.153 Zero current detection time** is extended.

Pr.	Name	Initial value	Setting range	Description
151 M461	Output current detection signal delay time	0 s	0 to 300 s	Set the output current detection time. Enter the time from when the output current reaches the set current or higher to when the Output current detection (Y12) signal is output.
153 M463	Zero current detection time	0.5 s	0 to 300 s	Set the time from when the output current drops to the <b>Pr.152</b> setting or lower to when the Zero current detection (Y13) signal is output.

# 4 Selecting the command interface in the Network operation mode (Pr.338, Pr.339)

- The proximity dog (X76) signal can be input via communication.
- The following table shows the command interface for the function in the Network operation mode, determined by the parameter settings: an external terminal or a communication interface (RS-485 terminals or communication option).

Pr.338	Pr.338 Communication operation command source			0: NET			1: EXT		
Pr.33	9 Communication speed command source	0: NET   1: EXT   2: EXT			0: NET   1: EXT   2: EXT				
X76	X76 Proximity dog		Combined		EXT				

[Explanation of Terms in Table]

EXT: External terminal only

Combined: Either external terminal or communication interface

# FR-A800/A800 Plus Series Instruction Manual Supplement

# 1 Instructions for UL and cUL

(Standard to comply with: UL 61800-5-1, CSA C22.2 No. 274)

#### **◆** Applicable models

MANUAL (HARDWARE)

FR-A842-07700(315K) to 12120(500K)
 The above models are compliant with both UL 508C and UL 61800-5-1, CSA C22.2 No. 274.
 For the instructions for UL 61800-5-1, CSA C22.2 No. 274, refer to this Instruction Manual Supplement.
 For the instructions for UL 508C, refer to the FR-A802 (SEPARATED CONVERTER TYPE) INSTRUCTION

## Product handling information / Informations sur la manipulation du produit

-WARNING- Operation of this product requires detailed installation and operation instructions provided in the Instruction Manual (HARDWARE) and the Instruction Manual (Detailed) intended for use with this product. Please forward relevant manuals to the end user. The manuals can also be downloaded in PDF form from the Mitsubishi Electric FA Global Website. To order manuals, please contact your sales representative.

#### -AVERTISSEMENT-

L'utilisation de ce produit nécessite des instructions détaillées d'installation et d'utilisation fournies dans les manuels d'instructions en anglais (Instruction Manual (HARDWARE) et Instruction Manual (Detailed)) destinés à être utilisés avec ce produit. Veuillez transmettre les manuels correspondants à l'utilisateur final. Les manuels peuvent également être téléchargés au format PDF sur Mitsubishi Electric FA Global Website. Pour commander des manuels, veuillez contacter votre représentant commercial.

#### ◆ Precautions for compliance with CSA C22.2 No.274

Use the inverter under the conditions of overvoltage category III and pollution degree 2 or lower specified in IEC 60664.

#### Branch circuit protection

For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code and any applicable provincial codes.

For installation in Canada, branch circuit protection must be provided in accordance with the Canadian Electrical Code and any applicable provincial codes. Short circuit protection of the inverter cannot be used as branch circuit protection. Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local code.

# ■ Precautions for opening the branch-circuit protective device / Précautions pour ouvrir le dispositif de protection du circuit de dérivation

-WARNING- If the fuse melts down or the breaker trips on the input side of this product, check for wiring faults (such as short circuits). Identify and remove the cause of melting down or the trip before replacing the fuse or resetting the tripped breaker (or before applying the power to the inverter again).

#### -AVERTISSEMENT-

Si le fusible fond ou si le disjoncteur se déclenche du côté entrée de ce produit, vérifier les défauts de câblage (tels que les courts-circuits). Identifier et éliminer la cause de la fonte ou du déclenchement avant de remplacer le fusible ou de réinitialiser le disjoncteur déclenché (ou avant de remettre sous tension l'onduleur).

#### **■** Fuse selection

Fuses are selected based on IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274.

For installation in the United States, the following semi-conductor fuses must be provided, in accordance with the National Electrical Code and any applicable local codes. For installation in Canada, the following semi-conductor fuses must be provided, in accordance with the Canada Electrical Code and any applicable provincial codes. Always install the following semi-conductor fuses for branch circuit protection.

#### · 6-phase rectification

Converter model	Cat. No.	Manufacturer	Rating (A)
FR-CC2-H315K	PC33UD69V1250TF	Mersen	1250
FR-CC2-H355K	PC33UD69V1250TF	Mersen	1250
FR-CC2-H400K	PC33UD69V1400TF	Mersen	1400
FR-CC2-H450K	PC33UD69V1400TF	Mersen	1400
FR-CC2-H500K	PC33UD69V1400TF	Mersen	1400
FR-CC2-H560K	PC33UD69V1400TF	Mersen	1400
FR-CC2-H630K	PC33UD69V1400TF	Mersen	1400

#### · 12-phase rectification

Converter model	Cat. No.	Manufacturer	Rating (A)
FR-CC2-H315K	PC33UD69V900TF	Mersen	900
FR-CC2-H355K	PC33UD69V900TF	Mersen	900
FR-CC2-H400K	PC33UD69V1100TF	Mersen	1100
FR-CC2-H450K	PC33UD69V1100TF	Mersen	1100
FR-CC2-H500K	PC33UD69V1100TF	Mersen	1100
FR-CC2-H560K	PC33UD69V1100TF	Mersen	1100
FR-CC2-H630K	PC33UD69V1100TF	Mersen	1100

### ◆ Capacitor discharge time / Temps de décharge du condensateur

CAUTION -Risk of Electric Shock-

Before wiring or inspection, check that the LED indicator turns OFF. Any person who is involved in wiring or inspection shall wait for 10 minutes or longer after power OFF and check that there are no residual voltage using a digital multimeter or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.

#### ATTENTION -Risque de choc électrique-

Avant le câblage ou l'inspection, vérifier que le témoin LED s'éteint. Toute personne impliquée dans le câblage ou l'inspection doit attendre 10 minutes ou plus après la mise hors tension et vérifier l'absence de tension résiduelle à l'aide d'un multimètre numérique ou similaire. Le condensateur est chargé avec une haute tension pendant un certain temps après la mise hors tension, ce qui est dangereux. Précautions pour ouvrir le dispositif de protection du circuit de dérivation.

#### Wiring to the power supply and the motor

Refer to the National Electrical Code (Article 310) regarding the allowable current of the cable. Select the cable size for 125% of the rated current according to the National Electrical Code (Article 430). For wiring the input (R/L1, S/L2, T/L3) and output (U, V, W) terminals of the inverter, use the UL listed copper, stranded wires (rated at 75°C) and round crimp terminals. Crimp the terminals with the crimping tool recommended by the terminal manufacturer.


#### Short circuit ratings

 Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 500 V Maximum.

### **♦** Motor overload protection

When using the electronic thermal relay function as motor overload protection, set the rated motor current in **Pr.9 Electronic thermal O/L relay**.

Operation characteristics of electronic thermal relay function



This function detects the overload (overheat) of the motor, stops the operation of the inverter's output transistor, and stops the output. (The operation characteristic is shown on the left.)

- · When using the Mitsubishi Electric constant-torque motor
- (1) Set one of "1, 13 to 16" in **Pr.71**. (This provides a 100% continuous torque characteristic in the low-speed range.)
- (2) Set the rated current of the motor in Pr.9.
  - \*1 When a value 50% of the inverter rated output current (current value) is set in Pr.9
  - \*2 The % value denotes the percentage to the inverter rated current. It is not the percentage to the rated motor current.
  - \*3 When you set the electronic thermal relay function dedicated to the Mitsubishi Electric constant-torque motor, this characteristic curve applies to operation at 6 Hz or higher.
  - \*4 Transistor protection is activated depending on the temperature of the heat sink. The protection may be activated even with less than 150% depending on the operating conditions.



- The internal accumulated heat value of the electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-OFF.
- When multiple motors are driven with a single inverter or when a multi-pole motor or a special motor is driven, install
  an external thermal relay (OCR) between the inverter and motors. Note that the current indicated on the motor rating
  plate is affected by the line-to-line leakage current (details in the Instruction Manual (HARDWARE)) when selecting
  the setting for an external thermal relay.
- The cooling effect of the motor drops during low-speed operation. Use a thermal protector or a motor with built-in thermistor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- A special motor cannot be protected by the electronic thermal relay function. Use an external thermal relay.
- Motor over temperature sensing is not provided by the drive.

### Applicable power supply

For use at an altitude above 2000 m (maximum 2500 m), only a neutral-point earthed (grounded) power supply can be used.

# **MEMO**

# FR-A800/A800 Plus Series FR-A842 Instruction Manual Supplement

# 1 Emergency drive (Fire mode)



The emergency drive function is available for the separated converter type.


The inverter can continue driving the motor in case of emergency such as a fire, since protective functions are not activated even if the inverter detects a fault. Using this function may damage the motor or inverter because driving the motor is given the highest priority. Use this function for emergency operation only. The operation can be switched to the commercial power supply operation at the occurrence of a fault which may cause damage of the inverter. To set the emergency drive function, enable the function also in the converter unit.

<b>.</b>	Dr. Name		value	0.40	Description	
Pr.	Name	FM	CA	Setting range	Description	
523 H320	Emergency drive mode selection	9999		100, 111, 112, 121, 122, 123, 124, 200, 211, 212, 221, 222, 223, 224, 300, 311, 312, 321, 322, 323, 324, 400, 411, 412, 421, 422, 423, 424	Select the operation mode of the emergency drive.	
				9999	Emergency drive disabled.	
524	F			0 to 590 Hz*2	Set the running frequency in the fixed frequency mode of the emergency drive (when the fixed frequency mode is selected in <b>Pr.523</b> ).	
H321 <sup>*1</sup>	Emergency drive running speed	9999		0 to 100%*2	Set the PID set point in the PID control mode of the emergency drive (when the PID control mode is selected in <b>Pr.523</b> ).	
				9999 <sup>*2</sup>	Emergency drive disabled.	
515	Emergency drive			1 to 200	Set the retry count during emergency drive operation.	
H322	3. 3			9999*2	Without retry count excess (no restriction on the number of retries)	
1013 H323	Running speed after emergency drive retry reset	60 Hz	50 Hz	0 to 590 Hz	Set the frequency for operation after a retry when any of E.CPU, E.1 to E.3, and E.5 to E.7 occurs during emergency drive operation.	
514	Emergency drive	9999		0.1 to 600 s	Set the retry waiting time during emergency drive operation.	
H324	dedicated retry waiting time			9999	The <b>Pr.68</b> setting is applied to the operation.	
136 A001	MC switchover interlock time	1 s		0 to 100 s	Set the operation interlock time for MC2 and MC3.	
139 A004	traduancy from invartar			0 to 60 Hz	Set the frequency at which the inverter-driven operation is switched over to the commercial power supply operation when the condition for the electronic bypass is established during emergency drive operation.	
				8888, 9999	Electronic bypass during emergency drive is disabled.	
57	Restart coasting time	9999		0	Coasting time differs depending on the inverter capacity. (For details on the coasting time, refer to the Instruction Manual (Detailed).)	
A702				0.1 to 30 s	Set the delay time for the inverter to perform a restart after restoring power due to an instantaneous power failure.	
				9999	No restart	

- \*1 Set Pr.523 before setting Pr.524.
- \*2 When Pr.523 = "100, 200, 300, or 400", the emergency drive is activated regardless of the Pr.524 setting.

#### **◆** Connection example

• The following diagram shows a connection example for emergency drive operation (in the commercial mode).



\*1 Be careful of the capacity of the sequence output terminals.
The applied terminals differ by the settings of Pr.190 to Pr.196 (Output terminal function selection).

Output terminal capacity	Output terminal permissible load
Open collector output of inverter (RUN, SU, IPF, OL, FU)	24 VDC 0.1 A
Inverter relay output (A1-C1, B1-C1, A2-B2, B2-C2) Relay output option (FR-A8AR)	230 VAC 0.3 A 30 VDC 0.3 A

- \*2 When connecting a DC power supply, insert a protective diode.

  When connecting an AC power supply, use relay output terminals of the inverter or contact output terminals of the relay output option (FR-A8AR).
- \*3 The applied terminals differ by the settings of Pr.180 to Pr.189 (Input terminal function selection)
- \*4 The applied terminals differ by the settings of Pr.190 to Pr.196 (Output terminal function selection).
- \*5 The applied terminals differ by the settings of **Pr.178**, **Pr.187**, **and Pr.189** (**Input terminal function selection**). For setting the converter unit, refer to the Instruction Manual of the converter unit.
- \*6 The applied terminals differ by the settings of **Pr.190 to Pr.195 (Output terminal function selection)**. For setting the converter unit, refer to the Instruction Manual of the converter unit.



• Be sure to provide a mechanical interlock for MC2 and MC3.

#### **♦** Emergency drive execution sequence




- When the X84 signal is ON for three seconds, the emergency drive is activated.
- · The Y65 signal is ON during emergency drive operation.
- "ED" is displayed on the operation panel during emergency drive operation.
- The ALM3 signal is ON when a fault occurs during emergency drive operation.
- For protective functions (faults) valid during emergency drive operation, refer to page 8.
- To activate the emergency drive, the X84 signal needs to be ON for three seconds while all the following conditions are satisfied.


Item	Condition
Emergency drive parameter	Pr.523 ≠ "9999"
settings	<b>Pr.524</b> ≠ "9999" (Setting is not required when <b>Pr.523</b> = "100, 200, 300, or 400".)
	Either of the following control methods is selected (when <b>Pr.800</b> = "9, 10, 20, 109, or 110" or <b>Pr.451</b>
	= "10, 20, 110, or 9999")
	V/F control
Control method	Advanced magnetic flux vector control
	Real sensorless vector control (speed control)
	PM sensorless vector control (speed control)
	PM sensorless vector control test operation
	None of the following conditions are satisfied.
	Enabling the electronic bypass sequence function
	Enabling the brake sequence function
Contradictory condition	Using the FR-A8NS (option)
	During offline auto tuning
	Supplying power through terminals R1 and S1
	• Pr.30 = "2 or 102"

- When the "retry" (**Pr.523** = "2[[[], 3[[[]]") is selected, it is recommended to use the automatic restart after instantaneous power failure function at the same time.
- · Parameter setting is not available during emergency drive operation.
- To return to the normal operation during emergency drive operation, do the following. (The operation will not be returned to normal only by turning OFF the X84 signal.)
  - Reset the inverter, or turn OFF the power supply.
  - Clear a fault by turning ON the X51 signal while the sequence function is enabled (when the protective function is activated).
- The operation is switched over to the commercial power supply operation in case of the following during emergency drive operation while the commercial mode or the retry / commercial mode is selected.
  - 24 V external power supply operation, power failure status or operation with the power supplied through R1/S1, undervoltage
- To input the X84 signal, set "84" in any of Pr.178 to Pr.189 (Input terminal function selection) to assign the function.
- To output the Y65 signal, set "65" (positive logic) or "165" (negative logic) in any of Pr.190 to Pr.196 (Output terminal function selection) to assign the function. To output the ALM3 signal, set "66" (positive logic) or "166" (negative logic) in any of Pr.190 to Pr.196 (Output terminal function selection) to assign the function.
- The X84 signal input is valid either through the external terminal or via network regardless of the **Pr.338** and **Pr.339** settings (Selection of control source in Network operation mode).
- During emergency drive operation, the operation is performed as Pr.502 Stop mode selection at
  communication error = "0 (initial value)" and communication errors (such as E.SER) do not occur. (A protective
  function is performed according to its operation during emergency drive operation.)

• The following diagram shows the operation of the emergency drive function (in the retry / output shutoff mode or in the fixed frequency mode (**Pr.523** = "211")).



 The following diagram shows the operation of switching over to the commercial power supply operation during emergency drive operation by using the CS signal (in the commercial mode or in the fixed frequency mode (Pr.523 = "411")).



<sup>\*1</sup> Input the CS signal via an external terminal.



• The emergency drive function is not available for the FR-A800-CRN series inverters.

#### ◆ Emergency drive operation selection (Pr.523, Pr.524)

- Use **Pr.523 Emergency drive mode selection** to select the emergency drive operation. Set a value in the hundreds place to select the operation when a valid protective function is activated (fault) during emergency drive operation. Set values in the ones and tens places to select the operation method.
- For protective functions (faults) valid during emergency drive operation, refer to page 8.

Pr.523 setting	Emergency drive operation mode			Description	
1[][]	Output shutoff m	ode		Output shutoff when a fault occurs.	
2[][]	Retry / output shutoff mode		Selecting operation when a fault occurs during emergency drive operation	Retry operation when a fault occurs.  Output shutoff when a fault for which retry is not permitted occurs or when the retry count is exceeded.	
300*1	Retry / commercial mode			Retry operation when a fault occurs.  The operation is switched over to the commercial power supply operation when a fault for which retry is not permitted occurs or when the retry count is exceeded.  While <b>Pr.515</b> = "9999", the operation is switched over to the commercial power supply operation when the retry count reaches 200.	
4[][]*1	Commercial mode			The operation is switched over to the commercial power supply operation when a fault occurs.	
[]00	Normal operation			The operation is performed with the same set frequency and by the same starting command as those in the normal operation.  Use this mode to avoid output shutoff due to a fault.	
[]11		Forward rotation		The operation is forcibly performed with the frequency set	
[]12	Fixed frequency mode	Reverse rotation		in <b>Pr.524</b> . Even when the motor is stopped, the operation is started by the emergency drive operation.	
[]21		Forward rotation	Selecting the operation method	The operation is performed under PID control using the	
[]22		Reverse rotation	during emergency drive operation	<b>Pr.524</b> setting as a set point. The measured values are input in the method set in <b>Pr.128</b> .	
[]23	PID control mode	Forward rotation (Second PID measured value input)		The operation is performed under PID control using the	
[]24		Reverse rotation (Second PID measured value input)		<b>Pr.524</b> setting as a set point. The measured values are input in the method set in <b>Pr.753</b> .	
9999	Emergency drive disabled.				

<sup>\*1</sup> Under PM sensorless vector control, the operation is not switched over to the commercial power supply operation and the output is shut off.



 The operation is automatically switched from the PU operation mode or External/PU combined operation mode to the External operation mode when the emergency drive is activated in the fixed frequency mode or in the PID control mode.

#### ◆ Retry operation during emergency drive operation (Pr.515, Pr.514)

Set the retry operation during emergency drive operation. Use Pr.515 Emergency drive dedicated retry count
to set the retry count, and use Pr.514 Emergency drive dedicated retry waiting time to set the retry waiting
time.

- The ALM signal output conditions depend on the **Pr.67 Number of retries at fault occurrence** setting. (For details on the retry function, refer to the Instruction Manual (Detailed).)
- For the protective functions (faults) for which retry is permitted during emergency drive operation, refer to page 8.



• The Pr.65 Retry selection is disabled during emergency drive operation.

#### ◆ Electronic bypass during emergency drive (Pr.136, Pr.139, Pr.57)

• For selecting the commercial mode (**Pr.523** = "3[|], 4[|]|"), setting is required as follows.

Set Pr.136 MC switchover interlock time and Pr.139 Automatic switchover frequency from inverter to bypass operation and assign the MC2 and MC3 signals to output terminals.

When the CS signal is assigned to an input terminal, set **Pr.57 Restart coasting time** ≠ "9999" and input the CS signal through the terminal. (In the initial setting, the CS signal is assigned to the terminal CS.)

Select V/F control, Advanced magnetic flux vector control, or Real sensorless vector control. (Under PM sensorless vector control, the operation is not switched over to the commercial power supply operation and the output is shut off.)

• During emergency drive operation, the operation is switched over to the commercial power supply operation when any of the following conditions is satisfied.

The CS signal turns OFF.

A fault for which retry is not permitted occurs while Pr.523 = "3[[[]".

A fault occurs while Pr.523 = "4[][]".

- While the motor is driven by the inverter during emergency drive operation, if a condition for electronic bypass is satisfied, the output frequency is accelerated/decelerated to the Pr.139 setting. When the frequency reaches the set frequency, the operation is switched over to the commercial power supply operation. (The operation is immediately switched over to the commercial power supply operation during output shutoff due to a fault occurrence.)
- If the parameter for electronic bypass is not set while the commercial mode is set (**Pr.523** = "3[[[], 4[[[]]"), the operation is not switched over to the commercial power supply operation even when a condition for switchover is satisfied, and the output is shut off.
- To assign the MC2 and MC3 signals to output terminals, use any two of Pr.190 to Pr.196 (Output terminal
  function selection) and set "18" (positive logic) for the MC2 signal and set "19" (positive logic) for the MC3
  signal.
- Operation of magnetic contactor (MC2, MC3)

Magnetic		Operation		
Magnetic contactor	Installation location	During commercial power supply operation	During inverter operation	
MC2	Between power supply and motor	Shorted	Open	
MC3	Between inverter output side and motor	Open	Shorted	

· The input signals are as follows.

Signal	Function	Operation	MC operation <sup>*4</sup>	
Signal		Operation	MC2	MC3
	Inverter/bypass	ON: Inverter operation	×	0
CS*1		OFF: Emergency drive commercial	_	×
		power supply operation*2	0	
X84	Emergency drive operation	ON: Emergency drive operation	_	_
		OFF: Normal operation*3	×	0
RES	Operation status reset	ON: Reset	×	Unchanged
	Operation status reset	OFF: Normal operation	_	_

<sup>\*1</sup> Input the CS signal via an external terminal. (Set Pr.162 = "0 to 3, 10 to 13" or Pr.338 = "1".)

- \*2 If the signal is turned ON after switchover to the emergency drive commercial power supply operation, the operation will not be returned to the inverter-driven operation.
- \*3 The operation is not switched over to the normal operation even when the signal is turned OFF during emergency drive operation.
- \*4 MC operation is as follows.

Notation	MC operation		
0	ON		
×	OFF		
_	During inverter operation: MC2-OFF, MC3-ON During commercial power supply operation: MC2-ON, MC3-OFF		
Unchanged	Unchanged The status of the MC remains the same after turning ON or OFF the signal.		



During electronic bypass operation while the electronic bypass sequence is enabled (Pr.135 = "1"), the emergency
drive function is not available.

#### PID control during emergency drive operation

- The **Pr.524** setting is used as a set point for operation during emergency drive operation in the PID control mode. Input the measured values in the method set in **Pr.128** or **Pr.753**.
- When the PID control mode is selected for emergency drive, the PID action during emergency drive operation is as follows depending on the PID control setting.

	PID control action				
Item	Set point / measured value input setting	Deviation input setting	Without PID control setting		
Measured value input selection (Pr.128 and Pr.753)	Held	Terminal 4 input	Terminal 4 input		
Forward action / reverse action selection (Pr.128 and Pr.753)	Held	Held	Reverse action		
Proportional band (Pr.129 and Pr.756)	Held	Held	100% (initial setting)		
Integral time (Pr.130 and Pr.757)	Held	Held	1 s (initial setting)		
Differential time (Pr.134 and Pr.758)	Held	Held	Not used (initial setting)		
Applied to the frequency / calculation only (Pr.128 and Pr.753)	Applied to the frequency	Applied to the frequency	Applied to the frequency		
Dancer control	Invalid	Invalid	Invalid		
Other PID-related settings	Held	Held	Held		

• While the "retry" (**Pr.523** = "22[], 32[]") is selected in the PID control mode, if a retry occurs at an occurrence of E.CPU, E.1 to E.3, or E.5 to E.7 during emergency drive operation, the operation is performed not under PID control but with the fixed frequency.

Use Pr.1013 Running speed after emergency drive retry reset to set the fixed frequency.



• For details on the PID control, refer to the Instruction Manual (Detailed).

#### Protective functions during emergency drive operation

· Protective functions during emergency drive operation are as follows.

Protective	Operation during
function	emergency drive
E.OC1	Retry
E.OC2	Retry
E.OC3	Retry
E.SCF	Output shutoff
E.OV1	Retry
E.OV2	Retry
E.OV3	Retry
E.THT	Retry
E.THM	Retry
E.FIN	Retry
E.OLT	Retry
E.SOT	Retry
E.LUP	The function is disabled.
E.LDN	The function is disabled.
E.BE	Retry <sup>*1</sup>
E.GF*2	Retry
E.LF	The function is disabled.
E.OHT	Retry
E.PTC	Retry
E.OPT	The function is disabled.
E.OP1	The function is disabled.
E.OP2	The function is disabled.
E.OP3	The function is disabled.

Protective	Operation during
function	emergency drive
E.16	The function is disabled.
E.17	The function is disabled.
E.18	The function is disabled.
E.19	The function is disabled.
E.20	The function is disabled.
E.PE6	The function is disabled.
E.PE	Output shutoff
E.PUE	The function is disabled.
E.RET	Output shutoff
E.PE2	Output shutoff
E.CPU	Retry
E.CTE	The function is disabled.
E.P24	The function is disabled.
E.CDO	Retry
E.SER	The function is disabled.
E.AIE	The function is disabled.
E.USB	The function is disabled.
E.SAF	Retry <sup>*1</sup>
E.PBT	Retry <sup>*1</sup>
E.OS	The function is disabled.
E.OSD	The function is disabled.
E.ECT	The function is disabled.
E.OD	The function is disabled.

Protective	Operation during
function	emergency drive
E.ECA	The function is disabled.
E.MB1	The function is disabled.
E.MB2	The function is disabled.
E.MB3	The function is disabled.
E.MB4	The function is disabled.
E.MB5	The function is disabled.
E.MB6	The function is disabled.
E.MB7	The function is disabled.
E.EP	The function is disabled.
E.MP	The function is disabled.
E.EF	The function is disabled.
E.LCI	The function is disabled.
E.PCH	The function is disabled.
E.PID	The function is disabled.
E.1	Retry <sup>*3</sup>
E.2	Retry <sup>*3</sup>
E.3	Retry <sup>*3</sup>
E.5	Retry <sup>*3</sup>
E.6	Retry*1*3
E.7	Retry*1*3
E.11	The function is disabled.
E.13	Output shutoff

<sup>\*1</sup> If the same protective function is activated continuously while the electronic bypass during emergency drive operation is enabled, retry is performed up to twice and then operation is switched over to the commercial power supply operation.

· Fault output during emergency drive operation are as follows.

	Pr.190 to Pr.196 setting			
Signal	Positive logic	Negative logic	Description	
ALM	99	199	The signal is ON at the occurrence of a fault that causes the above-mentioned "retry" or "output shutoff" during emergency drive operation.	
ALM3	66	166	The signal is output when a fault occurs during emergency drive operation.  When a fault which does not activate protective functions occurs during emergency drive operation, the signal is ON for three seconds and then turned OFF.	

#### ◆ Input signal operation

- During emergency drive operation in the fixed frequency mode or in the PID control mode, input signals unrelated to the emergency drive become invalid with some exceptions.
- The following table shows functions of the signals that do not become invalid during emergency drive operation in the fixed frequency mode or in the PID control mode.

Input signal status	Fixed frequency mode	PID control mode
Valid	OH, X10, MRS <sup>*1</sup> , X32, TRG, TRC, X51, RES, X70, X71	OH, X10, MRS <sup>*1</sup> , X32, TRG, TRC, X51, RES, X70, X71
Held	RT, X9, X17, X18, MC, SQ, X84	RT, X9, X17, X18, MC, SQ, X64, X65, X66, X67, X79, X84
Always-ON	_	X14, X77, X78, X80

<sup>\*1</sup> When the X10 signal is not assigned to any input terminal, the MRS signal is used as the X10 signal. Therefore, the MRS signal becomes valid when the X10 signal is not assigned to any input terminal.

<sup>\*2</sup> If E.GF occurs when **Pr.249** = "2", the output is shut off.

<sup>\*3</sup> In normal operation (**Pr.523** = "200 or 300"), the start signal is turned OFF at the same time the retry function resets the protective function. Input the start signal again to resume the operation.

### ◆ Emergency drive status monitor

- Set "68" in Pr.52, Pr.774 to Pr.776, Pr.992 to monitor the status of the emergency drive on the operation panel.
- · Description of the status monitor

Operation		Description			
panel indication	Emergency drive setting	En	nergency drive operating status		
0	Emergency drive function setting is not available.	_			
1		During normal operation			
2			Operating properly		
3	Electronic bypass during		A certain alarm is occurring.*2		
4	emergency drive operation is disabled.	Emergency drive in operation	A fault is occurring. The operation is being continued by the retry.		
5			A fault is occurring. The continuous operation is not allowed due to output shutoff.		
10	Parameter settings for electronic bypass during emergency drive operation are enabled.	During normal operation			
11					
12			Operating properly		
13			A certain alarm is occurring.*2		
14	Electronic bypass during	Emergency drive in operation	A fault is occurring. The operation is being continued by the retry.		
15	emergency drive operation is enabled.		A fault is occurring. The continuous operation is not allowed due to output shutoff.		
2[]*1		Electronic bypass is started during emergency drive (during acceleration/ deceleration to the switchover frequency).			
3[]*1		During electronic bypass during emergency drive (waiting during the interlock time).			
4[]*1		During commercial power	er supply operation during emergency drive		

<sup>\*1</sup> The value in the ones place indicates the previous displayed value (the setting at a fault occurrence).

#### **^**CAUTION

When the emergency drive function is enabled, the operation is continued or the retry operation (automatic reset
and restart) is repeated even if a fault occurs, which may damage or burn this product and the motor. Before
restarting the normal operation after using this function, make sure that the inverter and motor have no fault.
Any damage of the inverter or the motor caused by using the emergency drive function is not covered by the
warranty even within the guarantee period.

<sup>\*2 &</sup>quot;A certain alarm" means a protective function disabled during emergency drive shown in the tables on page 8.

# 2 Online L compensation

#### Sensorless


Under Real sensorless vector control, inductance compensation can be used to prevent degradation in control performance when magnetic saturation occurs in the motor.

Pr.	Name	Initial value	Setting range	Description	
221 C161	Excitation current compensation point 1	25%	25 to 200%	Set the excitation current command value for inductance compensation.	
222	Inductance		0 to 200%	Set the inductance compensation rate.	
C162	compensation rate 1	9999	9999	Inductance compensation rate 1 disabled.	
223 C163	Excitation current compensation point 2	50%	25 to 200%	Set the excitation current command value for inductance compensation.	
224	Inductance		0 to 200%	Set the inductance compensation rate.	
C164	compensation rate 2	9999	9999	Inductance compensation rate 2 disabled.	
225 C165	Excitation current compensation point 3	75%	25 to 200%	Set the excitation current command value for inductance compensation.	
226	Inductance		0 to 200%	Set the inductance compensation rate.	
C166	compensation rate 3	9999	9999	Inductance compensation rate 3 disabled.	
227 C167	Excitation current compensation point 4	125%	25 to 200%	Set the excitation current command value for inductance compensation.	
228	Inductance		0 to 200%	Set the inductance compensation rate.	
C168	compensation rate 4	9999	9999	Inductance compensation rate 4 disabled.	
71 C100	Applied motor	NIEG MOTOR (I)		By selecting a motor, the thermal characteristic and motor constant of each motor are set.	
80	Motor capacity	9999	0 to 3600 kW	Set the applied motor capacity.	
C101	motor capacity	3333	9999	V/F control	
81	Number of motor	9999	2, 4, 6, 8, 10, 12	Set the number of motor poles.	
C102	poles	1	9999	V/F control	
9 C103	Electronic thermal O/L relay	Inverter rated current	0 to 3600 A	Set the rated motor current.	
83 C104	Rated motor voltage	400 V	0 to 1000 V	Set the rated motor voltage (V).	
84	Rated motor	9999	10 to 400 Hz	Set the rated motor frequency (Hz).	
C105	frequency	5555	9999	The setting value of <b>Pr.3 Base frequency</b> is used.	
	nequency		0	No offline auto tuning	
		0	1	Offline auto tuning is performed without the motor rotating.	
96 C110	Auto tuning setting/status		11	Offline auto tuning is performed without the motor rotating (under V/F control or for EM-A/MM-CF).	
	- coming otalao		101	Offline auto tuning is performed with the motor rotating.	
			131	Offline auto tuning is performed with the motor rotating (including magnetic saturation L tuning).	


<sup>\*1</sup> For the setting range, refer to the Instruction Manual (Detailed).

## Excitation current compensation point settings (Pr.221, Pr.223, Pr.225, Pr.227)

- The excitation current compensation points 1 to 4 can be set regardless of the order of the parameters Pr.221, Pr.223, Pr.225, and Pr.227. (The Pr.221 setting needs not be smaller than the Pr.225 setting.) The setting values of the excitation current compensation points 1 to 4 are automatically arranged by the inverter in ascending order.
- 100% cannot be set in Pr.221, Pr.223, Pr.225, and Pr.227.
- Set different values in Pr.221, Pr.223, Pr.225, and Pr.227.
- Setting example when Pr.221 setting < Pr.223 setting < Pr.225 setting < Pr.227 setting</li>




Setting example when Pr.225 setting < Pr.223 setting < Pr.221 setting < Pr.227 setting</li>



## Inductance compensation rate settings (Pr.222, Pr.224, Pr.226, Pr.228)

- The inductance compensation rates 1 to 4 can be automatically set by offline auto tuning.
- · When "9999" is set in Pr.222, Pr.224, Pr.226, or Pr.228, the corresponding point is invalid.
- Setting example when "9999" is set in Pr.224 and Pr.228



## ◆ Offline auto tuning (including magnetic saturation L tuning)



- The following describes how to perform magnetic saturation L tuning. For other offline auto tuning, refer to the
  description of offline auto tuning for an induction motor in the Instruction Manual (Detailed).
- When offline auto tuning (including magnetic saturation L tuning) is performed, the tuning result is set in the motor
  constant related parameters (Pr.82, Pr.90 to Pr.94, Pr.859, and Pr.298). For details, refer to the description of
  offline auto tuning for an induction motor in the Instruction Manual (Detailed).

#### ■ Before performing offline auto tuning

Check the following points before performing offline auto tuning:

- Check that a value other than "9999" is set in **Pr.80 and Pr.81**, and Real sensorless vector control is selected (with **Pr.800**).
- · Check that a motor is connected. (Check that the motor is not rotated by an external force during tuning.)
- To perform magnetic saturation L tuning, remove the load and apply only the inertia load.
- Select a motor with the rated current equal to or less than the inverter rated current. (The motor capacity must be
  0.4 kW or higher.) If a motor with substantially low rated current compared with the inverter rated current,
  however, is used, speed and torque accuracies may deteriorate due to torque ripples, etc. Set the rated motor
  current to about 40% or higher of the inverter rated current.
- Tuning is not available for a high-slip motor, high-speed motor, or special motor.
- The maximum frequency is 400 Hz.
- Check the following points for the offline auto tuning with motor rotation (Pr.96 Auto tuning setting/status = "131").

The torque is not sufficient during tuning.

Check that the motor can be rotated up to the speed close to the rated speed.

Check that the mechanical brake is released.

#### **■** Settings

• To perform tuning, set the following parameters about the motor.

First motor Pr.	Name	Initial value	Description
80	Motor capacity	9999 (V/F control)	Set the motor capacity (kW).
81	Number of motor poles	9999 (V/F control)	Set the number of motor poles (2 to 12).
800	Control method selection	20	Set this parameter under Real sensorless vector control.
9	Electronic thermal O/L relay	Inverter rated current	Set the rated motor current (A).
83	Rated motor voltage	400 V	Set the rated motor voltage (V) printed on the motor's rating plate.
84	Rated motor 9999		Set the rated motor frequency (Hz). When the setting is "9999", the <b>Pr.3 Base frequency</b> setting is used.
71	Applied motor	0 (standard motor)	Set this parameter according to the motor.*1 Three types of motor constant setting ranges, units and tuning data can be stored according to settings.
96	Auto tuning setting/ status	0	Set "131".  131: Tuning is performed with the motor rotating. The motor can rotate up to the speed near the rated motor frequency. The magnetic saturation characteristic is also tuned.

\*1 Set Pr.71 Applied motor according to the motor to be used. (For the Pr.71 setting values, refer to the Instruction Manual (Detailed).)



- "131" cannot be set in Pr.463 Second motor auto tuning setting/status.
- When Pr.11 DC injection brake operation time = "0" or Pr.12 DC injection brake operation voltage = "0", offline auto tuning is performed at the initial setting of Pr.11 or Pr.12.
- · For tuning accuracy improvement, set the following parameters when the motor constants are known in advance.

First motor Pr.	Name	Motor (SF-TH)	Other motors
707	Motor inertia (integer)	0000 (initial value)	Motor inertia <sup>*2</sup>
724	Motor inertia (exponent)	9999 (initial value)	Jm = <b>Pr.707</b> × 10 <b>^(-Pr.724</b> ) (kg·m <sup>2</sup> )

\*2 The setting is valid only when a value other than "9999" is set in both Pr.707 and Pr.724.

#### ■ Performing tuning



- Before performing tuning, check the monitor display of the operation panel or parameter unit if the inverter is in the state ready for tuning. The motor starts by turning ON the start command while tuning is unavailable.
- In the PU operation mode, press [FWD] / REV on the operation panel.

  For External operation, turn ON the start command (STF signal or STR signal). Tuning starts.



- Satisfy the required inverter start conditions to start offline auto tuning. For example, stop the input of the MRS signal.
- To force tuning to end, use the MRS or RES signal or RESET on the operation panel.

(Turning OFF the start signal (STF signal or STR signal) also ends tuning.)

- During offline auto tuning, only the following I/O signals are valid (initial value).
   Input terminals <valid signals>: STP (STOP), OH, MRS, RT, RES, STF, STR, S1, and S2
   Output terminals: RUN, OL, IPF, FM/CA, AM, A1B1C1, and So (SO)
- When the rotation speed and the output frequency are selected for terminals FM/CA and AM, the progress status
  of offline auto tuning is output in 15 steps from FM/CA and AM.
- Do not perform ON/OFF switching of the Second function selection (RT) signal during offline auto tuning. Auto tuning will not be performed properly.
- Setting offline auto tuning (Pr.96 Auto tuning setting/status = "131") will make pre-excitation invalid.
- When the offline auto tuning with motor rotation is selected (Pr.96 Auto tuning setting/status = "131"), take caution
  and ensure safety against the rotation of the motor.
- When executing offline auto tuning, input the operation command after switching ON the main circuit power (R/L1, S/L2, T/L3) of the inverter.
- While Pr.79 Operation mode selection = "7", turn ON the PU operation external interlock (X12) signal for tuning
  in the PU operation mode.
- · During tuning, the monitor is displayed on the operation panel as follows.

Tuning status	Operation panel (FR-DU08) display	LCD operation panel (FR-LU08) display
(1) Setting	- PU - MON - M - EXT - MON - M - NET - SEUN - PM	AutoTune 12:34 TUNE 131 STOP PU PREV NEXT
(2) During tuning	PU - HON - MA - NET - HEAL - PM	AutoTune 12:34 TUNE 132 STF FWD PU PREV NEXT
(3) Normal completion	TO THE SELL PORCE  MODE SET ESC PORCE  MODE SE	AutoTune 12:34 TUNE Completed 133 STF STOP PU PREV NEXT

· Note: Offline auto tuning time (with the initial setting)

Offline auto tuning setting	Time
With the motor rotating (including magnetic saturation L tuning) ( <b>Pr.96</b> = "131")	Approximately 140 s maximum

• When offline auto tuning ends, press on the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal).

This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)



- The motor constants measured once during offline auto tuning are stored as parameters and their data are held until offline auto tuning is performed again. However, the tuning data is cleared when performing All parameter clear.
- Changing **Pr.71** after tuning completion will change the motor constant. For example, if "3" is set in **Pr.71** after tuning is performed with **Pr.71** = "0", the tuning data becomes invalid. To use the tuned data, set "0" again in **Pr.71**.

• If offline auto tuning has ended in error (refer to the following table), motor constants are not set. Perform an inverter reset and perform tuning again.

Error display	Error cause	Countermeasures
8	Forced end	Set <b>Pr.96</b> = "131" and retry.
9	Inverter protective function operation	Make the setting again.
91	The current limit (stall prevention) function is activated.	Set the acceleration/deceleration time longer. Set Pr.156 Stall prevention operation selection = "1". Remove the load and apply only the inertia load, then retry.
92	The converter output voltage fell to 75% of the rated voltage.	Check for the power supply voltage fluctuation. Check the <b>Pr.83 Rated motor voltage</b> setting.
93	Calculation error. The motor is not connected.	Check the <b>Pr.83</b> and <b>Pr.84</b> settings. Check the motor wiring and make the setting again.
94	Rotation tuning frequency setting error. (The frequency command for the tuning was given to exceed the maximum frequency setting, or to be in the frequency jump range.)	Check the Pr.1 Maximum frequency and Pr.31 to Pr.36 Frequency jump settings.
95	Magnetic saturation L tuning error (The excitation current did not reach the set point within 20 s.)	Remove the load and apply only the inertia load, then retry. Reduce the range of the excitation current compensation points, and adjust the setting so that the excitation current compensation points 1 to 4 are evenly distributed, then retry.

- When tuning is ended forcibly by pressing or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The motor constants have not been set.)

  Perform an inverter reset and perform tuning again.
- When the rated power supply of the motor is 400/440 V 60 Hz, set the rated motor current multiplied by 1.1 in **Pr.9 Electronic thermal O/L relay** after tuning is complete.
- For a motor with a PTC thermistor, thermal protector, or some other thermal detector, set "0" (motor overheat protection by inverter invalid) in **Pr.9** to protect the motor from overheating.



- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the
  inverter starts normal operation. Therefore, when the STF (STR) signal is ON, the motor starts forward (reverse)
  rotation.
- Any fault occurring during tuning is handled as in the normal operation. However, if the retry function is set, no retry is performed.
- The set frequency monitor displayed during the offline auto tuning is 0 Hz.

#### **↑**CAUTION

· Note that the motor may start running suddenly.

#### ■ Parameters updated by tuning results after tuning

The following table shows the parameters to which the offline auto tuning result is applied according to the **Pr.96** setting.

o: Applied, —: Not applied

First motor Pr.	Name	Pr.96 = 1	Pr.96 = 11	Pr.96 = 101	Pr.96 = 131
82	Motor excitation current	0	_	0	0
90	Motor constant (R1)	0	0	0	0
91	Motor constant (R2)	0	_	0	0
92	Motor constant (L1)/d-axis inductance (Ld)	0	_	0	0
93	Motor constant (L2)/q-axis inductance (Lq)	0	_	0	0

First motor Pr.	Name	Pr.96 = 1	Pr.96 = 11	Pr.96 = 101	Pr.96 = 131
94	Motor constant (X)	0	_	0	0
859	Torque current/Rated PM motor current	0	_	0	0
298	Frequency search gain	0	0	0	0
96	Auto tuning setting/status	0	0	0	0
222	Inductance compensation rate 1	*1	_	*1	0
224	Inductance compensation rate 2	*1	_	*1	0
226	Inductance compensation rate 3	*1	_	*1	0
228	Inductance compensation rate 4	*1	_	*1	0

<sup>\*1</sup> When offline auto tuning is performed with **Pr.96** = "1 or 101", "9999" is set.

# Starting magnetic pole position detection pulse width

#### Vector

When the FR-A8AL or FR-A8TP is used to drive a PM motor under Vector control, the tuning result is applied to the starting magnetic pole position detection pulse width at offline auto tuning with the Vector control setting.

For how to perform offline auto tuning, refer to "Offline auto tuning for a PM motor (under Vector control)" in the Instruction Manual (Detailed).

## **♦** Parameters updated by tuning results after tuning

Pr. Name		Name	Tuning according to Pr.96 (Pr.463) setting			Description	
			101	1	11		
90 (458)	)	Motor constant (R1)	0	0	0	Resistance per phase	
92 (460)	)	Motor constant (L1)/d-axis inductance (Ld)	0	0	_	d-axis inductance	
93 (461)	)	Motor constant (L2)/q-axis inductance (Lq)	0	0	_	q-axis inductance	
711 (739	9)	Motor Ld decay ratio	0	0	_	d-axis inductance decay ratio	
712 (740	0)	Motor Lq decay ratio	0	0	_	q-axis inductance decay ratio	
721 (742	2)	Starting magnetic pole position detection pulse width	o*3	o*3	_	When the setting value is 10000 or more: With polarity inversion for compensation, voltage pulse (Pr. setting minus 10000) µs	
859 (860	0)	Torque current/Rated PM motor current	0	0	_		
96 (463)		Auto tuning setting/status	0 0				
373 <sup>*1</sup>	871 <sup>*2</sup>	Encoder position tuning setting/ status	0	_	_	Encoder position tuning status	
1105 <sup>*1</sup>	887 <sup>*2</sup>	Encoder magnetic pole position offset	0	_	_	Turning data of encoder position tuning	

o: Tuned, —: Not tuned

- \*1 The setting is available when the FR-A8AL/FR-A8APR/FR-A8APS/FR-A8APA is installed.
- \*2 The setting is available when the FR-A8TP is installed.
- \*3 The tuning result is set only when the FR-A8AL or FR-A8TP is used.

#### NOTE

• If the offline auto tuning is started before the encoder position tuning is finished (**Pr.1105** (**Pr.887**) = "65535") for a PM motor, the protective function (E.MP) is activated.

## MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

Model	FR-A802 TORISETSU HARDWARE EIBUN	
Model code	1AJ009	$\int$