



Programmable Controller
MELSEC iQ-F
 MELSEC iQ-F FX5UJ CPU Module

Hardware Manual



Manual Number	IB(NA)-0800636
Revision	B
Date	April 2022

This manual describes the part names, dimensions, installation, cabling and specifications for the product. This manual is extracted from MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware). Refer to MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware) for more details. Before use, read this manual and manuals of relevant products fully to acquire proficiency in the handling and operating the product. Make sure to learn all the product information, safety information, and precautions. And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user. Registration: The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies. In some cases, trademark symbols such as "™" or "®" are not specified in this manual.

Effective April 2022
 Specifications are subject to change without notice.
 © 2019 MITSUBISHI ELECTRIC CORPORATION

Safety Precaution (Read these precautions before use.)
 If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. This manual classifies the safety precautions into two categories:

	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Depending on the circumstances, procedures indicated by may also cause severe injury. It is important to follow all precautions for personal safety.

STARTUP AND MAINTENANCE PRECAUTIONS	
<ul style="list-style-type: none"> Do not touch any terminal while the PLC's power is on. Doing so may cause electric shock or malfunctions. Before cleaning or retightening terminals, cut off all phases of the power supply externally. Failure to do so in the power ON status may cause electric shock. Before modifying the program in operation, forcing output, running or stopping the PLC, read through this manual carefully, and ensure complete safety. An operation error may damage the machinery or cause accidents. Do not change the program in the PLC from two or more peripheral equipment devices at the same time. (i.e. from an engineering tool and a GOT) Doing so may cause destruction or malfunction of the PLC program. 	

STARTUP AND MAINTENANCE PRECAUTIONS	
<ul style="list-style-type: none"> Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric representative. Turn off the power to the PLC before connecting or disconnecting any extension cable. Failure to do so may cause equipment failures or malfunctions. Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause equipment failures or malfunctions. <ul style="list-style-type: none"> Peripheral devices, expansion board, expansion adapter, and connector conversion adapter Extension modules Do not use the chemicals for cleaning. If there is the possibility of touching the PLC inside a control panel in maintenance, make sure to discharge to avoid the influence of static electricity. Since there are risks such as burn injuries, please do not touch the surface of the equipment with bare hands when it is operating in an environment which exceeds ambient temperature of 50°C. 	

DISPOSAL PRECAUTIONS	
<ul style="list-style-type: none"> Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device. 	

TRANSPORTATION PRECAUTIONS	
<ul style="list-style-type: none"> The PLC is a precision instrument. During transportation, avoid impacts larger than those specified in the general specifications (Section 2.1) by using dedicated packaging boxes and shock-absorbing pallets. Failure to do so may cause failures in the PLC. After transportation, verify operation of the PLC and check for damage of the mounting part, etc. 	

Associated manuals
<p>How to obtain manuals</p> <p>For the necessary product manuals or documents, consult with your local Mitsubishi Electric representative.</p>

Associated manuals
 FX5UJ CPU module comes with this document (hardware manual). For a detailed explanation of the FX5UJ CPU module hardware and information on instructions for PLC programming and intelligent function module, refer to the relevant documents.

Manual name	Manual No.	Description
MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)	SH-082452ENG	Describes the details of hardware of the CPU module, including performance specifications, wiring, installation, and maintenance.
MELSEC iQ-F FX5 User's Manual (Ethernet Communication)	JY997D56201	Functions for communication via Ethernet

Certification of UL, cUL standards

Please consult with Mitsubishi Electric for information on UL, cUL standard practices and the corresponding types of equipment.

Compliance with EC directive (CE Marking)

This product complies with EC directive, however, this document does not guarantee that a mechanical system including this product will comply with EC directive. Compliance to EMC directive and LVD directive of the entire mechanical system should be checked by the user/manufacturer. For more details please contact the local Mitsubishi Electric sales site.

For the caution for compliance with the EC directive, refer to MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

Compliance with UKCA marking

The requirements for compliance with UKCA marking are the same as that with EC directive (CE marking).


Incorporated Items

Check if the following product and items are included in the package:

	Included Items	
■ CPU module		
FX5UJ-DMR/ES, FX5UJ-DMT/ES, FX5UJ-DMT/ESS (□: 24, 40, 60)	Product	1 module
	Dust proof protection sheet	1 sheet
	Manuals [Japanese /English]	1 manual
	Manuals [Chinese]	1 manual
■ I/O module		
FX5-0EX/ES, FX5-0EYR/ES, FX5-0EYT/ES, FX5-0EYT/ESS (□: 8, 16)	Product	1 module
	Dust proof protection sheet	1 sheet
FX5-32ER/ES, FX5-32ET/ES, FX5-32ET/ESS	Product	1 module
	Dust proof protection sheet	1 sheet
	Extension cable	1 cable

1. Outline

1.1 Part names




No.	Name
[1]	DIN rail mounting hooks
[2]	Expansion adapter connecting hooks
[3]	Terminal block covers
[4]	Peripheral device connecting connector cover
[5]	Expansion board connector cover
[6]	Input display LEDs (Green)

No.	Name	
	Operation status display LEDs	
	PWR	Green On while the PLC is powered.
[7]	ERR ^{*1}	Red Lit/flashing when an error occurs.
	P.RUN	Green On while the PLC is running.
	CARD	Green Lit when the SD memory card is inserted.
	SD/RD	Green Lit when data is sent or received through communication via built-in Ethernet.
[8]	Extension connector cover	
[9]	Output display LEDs (Green)	


*1 When powered on in the factory default state, ERR LED starts flashing because there is no program. For details, refer to the following manual.
 → Refer to MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

With cover open




No.	Name
[1]	Built-in Ethernet communication connector
[2]	RUN/STOP/RESET switch
[3]	SD memory card disable switch
[4]	Built-in USB communication connector
[5]	SD memory card slot
[6]	Terminal names shows a function grounding terminal.
[7]	Terminal block mounting screws
[8]	Expansion board connector
[9]	Extension connector

Left side




Right side



No.	Name
[1]	Expansion adapter connector cover
[2]	Genuine product certification label ^{*1}
[3]	Nameplate printing ^{*1} is a mark that instructs to use the cable with an appropriate temperature rating (80°C or more) for wiring.
[4]	DIN rail mounting groove

*1 Products that do not have the genuine product certification label or nameplate are not covered by the warranty.

1.2 External dimensions and weight



Model name	W: mm	W1: mm Mounting hole pitches	MASS (Weight): kg
FX5UJ-24M□	95	76	Approx. 0.55
FX5UJ-40M□	130	111	Approx. 0.65
FX5UJ-60M□	175	156	Approx. 0.80

Outer paint color Body: Munsell 0.6B7.6/0.2

2. Installation (general specifications)

As for installation of the I/O modules, expansion adapters and expansion boards, refer to MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

INSTALLATION PRECAUTIONS



- Use the product within the generic environment specifications described in section 2.1 of this manual. Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂ or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind.
- If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.

INSTALLATION PRECAUTIONS



- Do not touch the conductive parts of the product directly. Doing so may cause device failures or malfunctions.
- When drilling screw holes or wiring, make sure that cutting and wiring debris do not enter the ventilation slits of the PLC.
- Failure to do so may cause fire, equipment failures or malfunctions.
- For the product supplied together with a dust proof sheet, the sheet should be affixed to the ventilation slits before installation and wiring work to prevent foreign objects such as cutting and wiring debris. However, when the installation work is completed, make sure to remove the sheet to provide adequate ventilation.
- Failure to do so may cause fire, equipment failures or malfunctions.
- Install the product on a flat surface. If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformities.
- Install the product securely using a DIN rail or mounting screws.
- Connect the extension cables, peripheral device cables and input/output cables connecting cable securely to their designated connectors. Loose connections may cause malfunctions.
- Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause equipment failures or malfunctions.
 - Peripheral devices, expansion board, expansion adapter, and connector conversion adapter
 - Extension modules

2.1 Generic specifications

Item	Specification				
Operating ambient temperature *1	0 to 55 °C (32 to 131 °F), non-freezing				
Storage ambient temperature	-25 to 75 °C (-13 to 167 °F), non-freezing				
Operating ambient humidity	5 to 95%RH, non-condensing*2				
Storage ambient humidity	5 to 95%RH, non-condensing				
Vibration resistance *3*4	Installed on DIN rail	Frequency (Hz)	Acceleration (m/s ²)	Half amplitude (mm)	Sweep count
		5 to 8.4	—	1.75	
	Installed directly	5 to 8.4	—	3.5	10 times each in X, Y, Z directions (80 min in each direction)
		8.4 to 150	4.9	—	
Shock resistance *3	147 m/s ² Acceleration, Action time: 11 ms, 3 times by half-sine pulse in each direction X, Y, and Z				
Noise durability	By noise simulator of 1000 Vp-p noise voltage, 1 μs noise width and 30 to 100 Hz noise frequency				
Dielectric withstand voltage *5	1.5 kV AC for 1 minute or 500 V AC for 1 minute		Between each terminal and ground terminal		
Insulation resistance *5	10 MΩ or higher by 500 V DC insulation resistance tester				
Grounding	Class D grounding (Grounding resistance: 100 Ω or less) <Common grounding with a heavy electrical system is not allowed.>*6				
Working atmosphere	Free from corrosive or flammable gas and excessive conductive dusts				
Operating altitude *7	0 to 2000 m				
Installation location	Inside a control panel*8				
Overvoltage category *9	II or less				
Pollution degree *10	2 or less				

*1 The simultaneous ON ratio of available PLC inputs or outputs changes with respect to the ambient temperature. Refer to MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

*2 When used in a low-temperature environment, use in an environment with no sudden temperature changes. If there are sudden temperature changes because of opening/closing of the control panel or other reasons, condensation may occur, which may cause a fire, fault, or malfunction. Furthermore, use an air conditioner in dehumidifier mode to prevent condensation.

*3 The criterion is shown in IEC61131-2.

*4 When the system has equipment which specification values are lower than above mentioned vibration resistance specification values, the vibration resistance specification of the whole system is corresponding to the lower specification.

*5 Dielectric withstand voltage and insulation resistance are shown in the following table.

Terminal	Dielectric strength	Insulation resistance
■ CPU modules, I/O modules		
Between power supply terminal (AC power) and ground terminal	1.5 kV AC for 1 minute	10 MΩ or higher by 500 V DC insulation resistance tester
Between 24 V DC service power supply connected to input terminal (24 V DC) and ground terminal	500 V AC for 1 minute	
Between output terminal (relay) and ground terminal	1.5 kV AC for 1 minute	
Between output terminal (transistor) and ground terminal	500 V AC for 1 minute	
■ Expansion boards, expansion adapters, intelligent function module		
Between terminal of expansion board and ground terminal	Not allowed	Not allowed
Between terminal of expansion adapter and ground terminal	500 V AC for 1 minute	10 MΩ or higher by 500 V DC insulation resistance tester
Intelligent function module	Each manual	

For dielectric withstand voltage test and insulation resistance test of each product, refer to the following manual.

→ MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

*6 For grounding, refer to Section 3.3.

*7 The PLC cannot be used at a pressure higher than the atmospheric pressure to avoid damage.

*8 The programmable controller is assumed to be installed in an environment equivalent to indoor.


*9 This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within premises. Category II applies to equipment for which electrical power is supplied from fixed facilities. The surge voltage withstand level for up to the rated voltage of 300 V is 2500 V.

*10 This index indicates the degree to which conductive material is generated in the environment in which the equipment is used. Pollution level 2 is when only non-conductive pollution occurs. Temporary conductivity caused by condensation must be expected occasionally.

2.2 Installation location


Install the PLC in an environment conforming to the generic specifications (Section 2.1), installation precautions.

Installation location in enclosure



Space in enclosure

Extension devices can be connected on the left and right sides of the CPU module. If you intend to add extension devices in the future, keep necessary spaces on the left and right sides.



2.2.1 Affixing the dust proof sheet

The dust proof sheet should be affixed to the ventilation port before beginning the installation and wiring work.

→ For the affixing procedure, refer to the instructions on the dust proof sheet.


Be sure to remove the dust proof sheet when the installation and wiring work is completed.

2.3 Procedures for installing to and detaching from DIN rail


The products can be installed on a DIN46277 rail [35 mm wide]. This section explains the installations of the CPU modules.

2.3.1 Installation


- 1) Connect the expansion boards and expansion adapters to the CPU module.
- 2) Push out all DIN rail mounting hooks (below fig. A)



- 3) Fit the upper edge of the DIN rail mounting groove (right fig. B) onto the DIN rail.



- 4) Lock the DIN rail mounting hooks (below fig. C) while pressing the PLC against the DIN rail.



2.4 Procedures for installing directly (with M4 screws)

The product can be installed directly on the panel (with screws). This section explains the installation of the CPU modules.


2.4.1 Mounting hole pitches

Refer to the External Dimensions (Section 1.2) for the product's mounting hole pitch information.

2.4.2 Installation

The FX5UJ-40M□ is used as the CPU module in this example.

- 1) Make mounting holes in the mounting surface referring to the external dimensions diagram.
- 2) Fit the CPU module (below fig. A) based on the holes, and secure it with M4 screws (below fig. B).



3. Specifications and examples of external wiring

As for the details of the power supply wiring and input/output wiring, refer to MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

DESIGN PRECAUTIONS **WARNING**

- Make sure to set up the following safety circuits outside the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents.
 - Most importantly, set up the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit (to prevent damage to the equipment at the upper and lower positioning limits).
 - Note that when the CPU module detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off. Also, when an error that cannot be detected by the CPU module occurs in an input/output control block, output control may be disabled. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
 - Note that the output current of the 24 V DC service power supply varies depending on the model and the absence/presence of extension modules. If an overload occurs, the voltage automatically drops, inputs in the PLC are disabled, and all outputs are turned off. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
 - Note that when an error occurs in a relay or transistor of an output circuit, the output might stay on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
- Construct an interlock circuit in the program so that the whole system always operates on the safe side before executing the control (for data change) of the PLC in operation. Read the manual thoroughly and ensure complete safety before executing other controls (for program change, parameter change, forcible output and operation status change) of the PLC in operation. Otherwise, the machine may be damaged and accidents may occur due to erroneous operations.

DESIGN PRECAUTIONS **CAUTION**

- Simultaneously turn on and off the power supplies of the CPU module and extension modules.

WIRING PRECAUTIONS **WARNING**

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.
- Make sure to attach the terminal cover, provided as an accessory, before turning on the power or initiating operation after installation or wiring work. Failure to do so may cause electric shock.
- The temperature rating of the cable should be 80°C or more.
- Make sure to wire the screw terminal block in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
 - The disposal size of the cable end should follow the dimensions described in the manual.
 - Tightening torque should follow the specifications in the manual.
 - Tighten the screws using a Phillips-head screwdriver No.2 (shaft diameter 6 mm or less). Make sure that the screwdriver does not touch the partition part of the terminal block.


WIRING PRECAUTIONS **CAUTION**

- Perform class D grounding (grounding resistance: 100 Ω or less) of the grounding terminal on the CPU module and extension modules with a wire 2 mm² or thicker. Do not use common grounding with heavy electrical systems (refer to section 3.3).
- Connect the power supply wiring to the dedicated terminals described in this manual. If an AC power supply is connected to a DC input/output terminal or DC power supply terminal, the PLC will burn out.
- Do not wire vacant terminals externally. Doing so may damage the product.
- Make sure to observe the following precautions in order to prevent any damage to the machinery or accidents due to malfunction of the PLC caused by abnormal data written to the PLC due to the effects of noise.
 - Do not bundle the power line, control line and communication cables together with or lay them close to the main circuit, high-voltage line, load line or power line. As a guideline, lay the power line, control line and communication cables at least 100 mm away from the main circuit, high-voltage line, load line or power line.
 - Ground the shield of the shielded wire or shielded cable at one point on the PLC. However, do not use common grounding with heavy electrical systems.

3.1 Cable end treatment and tightening torque

For the terminals of FX5UJ CPU module and I/O module, M3 screws are used. The electric wire ends should be treated as shown below. Tighten the screws to a torque of 0.5 to 0.8 N·m. Do not tighten terminal screws with a torque outside the above-mentioned range. Failure to do so may cause equipment failures or malfunctions.


- When one wire is connected to one terminal



<Reference>

Terminal manufacturer	Type No.	Applicable cable	Certification	Pressure bonding tool
J.S.T. Mfg. Co., Ltd.	FV1.25-B3A	AWG22 to 16	UL Listed	YA-1 (J.S.T. Mfg. Co., Ltd.)
	FV2-MS3	AWG16 to 14		

- When two wires are connected to one terminal¹



<Reference>

Terminal manufacturer	Type No.	Applicable cable	Certification	Pressure bonding tool
J.S.T. Mfg. Co., Ltd.	FV1.25-B3A	AWG22 to 16	UL Listed	YA-1 (J.S.T. Mfg. Co., Ltd.)

¹ To adapt the LVD directive (EN61010-2-201:2013) of the EC directive, avoid the wiring with two wires to the built-in terminal, and take an appropriate action such as adding an external terminal. For the time of compliance with the LVD directive (EN61010-2-201:2013), refer to MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

3.2 Power supply specifications and external wiring

3.2.1 Power supply specifications [CPU module, FX5-32E□]

Item	Specification
Rated voltage	100 to 240 V AC
Voltage fluctuation range	-15%, +10%
Frequency rating	50/60 Hz
Allowable instantaneous power failure time	Operation can be continued upon occurrence of instantaneous power failure for 10 ms or less. ¹
Power fuse	250 V 3.15 A Time-lag Fuse
Rush current	FX5UJ-24M□ 25 A max. 5 ms or less/100 V AC 50 A max. 5 ms or less/200 V AC
	FX5UJ-40M□, FX5UJ-60M□ 30 A max. 5 ms or less/100 V AC 50 A max. 5 ms or less/200 V AC
	FX5-32E□ 30 A max. 5 ms or less/100 V AC 65 A max. 5 ms or less/200 V AC
Power consumption ²	FX5UJ-24M□ 30 W
	FX5UJ-40M□ 32 W
	FX5UJ-60M□ 35 W
	FX5-32E□ 25 W
24 V DC power supply capacity ³	FX5UJ-24M□ 400 mA (460 mA) ⁴
	FX5UJ-40M□ 400 mA (500 mA) ⁴
	FX5UJ-60M□ 400 mA (550 mA) ⁴
	FX5-32E□ 250 mA (310 mA) ⁴
5 V DC built-in power supply capacity ⁵	FX5-32E□ 965 mA

¹ When the supply voltage is 200 V AC, the time can be changed to 10 to 100 ms by editing the user program.

² This item shows value when all 24 V DC power supplies are used in the maximum configuration connectable to the CPU module. (The current of the input circuit is included.)


³ The AC power type has 24 V DC service power supply. When I/O modules are connected, they consume current from the power supply.

⁴ Capacity of 24 V DC service power supply when service power supply is used for the input circuit. The value in () is capacity of 24 V DC service power supply when external power supply is used for the input circuit.

⁵ Power is supplied to I/O modules and intelligent function modules. The following manual shows further information. For details, refer to MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

3.2.2 Example of external wiring

100 to 240 V AC power is supplied to the CPU module and FX5-32E□. For the details of wiring work, refer to Section 3.1.




[1]: CPU module, FX5-32E□

3.3 Grounding

Ground the PLC as stated below.

- Perform class D grounding. (Grounding resistance: 100 Ω or less)
- Ground the PLC independently if possible. If it cannot be grounded independently, ground it jointly as shown below.




- Use ground wires thicker than AWG14 (2 mm²).
- Bring the grounding point close to the PLC as much as possible so that the ground cable can be shortened.

3.4 Input specifications and external wiring

3.4.1 Input specifications (24 V DC input type)

Item		Specification
Input signal voltage		24 V DC +20%, -15%
Input impedance	CPU module X0 to X7	4.3 kΩ
	X10 and subsequent	5.6 kΩ
	FX5 I/O module	5.6 kΩ
Input signal current	CPU module X0 to X7	5.3 mA/24 V DC
	X10 and subsequent	4.0 mA/24 V DC
	FX5 I/O module	4.0 mA/24 V DC
ON input sensitivity current	CPU module X0 to X7	3.5 mA or more
	X10 and subsequent	3.0 mA or more
	FX5 I/O module	3.0 mA or more
OFF input sensitivity current		1.5 mA or less
Input response time		Refer to MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)
Input signal form (Input sensor form)	Sink input	No-voltage contact input NPN open collector transistor
	Source input	No-voltage contact input PNP open collector transistor
Input operation display		LED on panel turns on when input.

3.4.2 Examples of input wiring (when 24 V DC service power supply is used)



* Class D grounding. See section 3.3 for details.
[1]: CPU module, FX5-32E□ [2]: Input module

3.5 Relay output specifications and external wiring


3.5.1 Relay output specifications

Item	Specification
External power supply	30 V DC or less 240 V AC or less ("250 V AC or less" if not a CE, UL, cUL compliant item)
Max. load	2 A/point*1
Min. load	5 V DC, 2 mA (reference value)
Open circuit leakage current	—

Item	Specification
Response time	OFF↔ON: Approx. 10 ms
Output operation display	LED on panel turns on when output.

*1 The total load current of resistance loads per common terminal should be the following value.
- 3 output points/common terminal: 6 A or less
- 4 output points/common terminal: 8 A or less
As for the number of outputs per common terminal, refer to Chapter 4 and the following manual.
→ Refer to MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

3.5.2 Example of relay output wiring




3.6 Transistor output specifications and external wiring

3.6.1 Transistor output specifications

Item	Specification	
Output form	FX5UJ-□MT/ES, FX5-□EYT/ES, FX5-32ET/ES: Transistor (Sink) FX5UJ-□MT/ESS, FX5-□EYT/ESS, FX5-32ET/ESS: Transistor (Source)	
External power supply	5-30 V DC	
Max. load	0.5 A/point*1	
Min. load	—	
Open circuit leakage current	0.1 mA or less/30 V DC	
ON voltage	CPU module Y0 to Y2	1.0 V or less
	Y3 and subsequent	1.5 V or less
I/O module	1.5 V or less	
Response time	CPU module Y0 to Y2	2.5 μs or less/10 mA or more (5-24 V DC)
	Y3 and subsequent	0.2 ms or less/200 mA or more (at 24 V DC)
I/O module	0.2 ms or less/200 mA or more (at 24 V DC)	
Output operation display	LED on panel turns on when output.	

*1 The total load current of resistance loads per common terminal should be the following value.
- 3 output point/common terminal: 0.6 A or less
- 4 output point/common terminal: 0.8 A or less
As for the number of outputs per common terminal, refer to Chapter 4 and the following manual.
→ Refer to MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

3.6.2 External wiring of transistor output



3.7 Built-in Ethernet communication specifications and wiring

As for the details on the built-in Ethernet communication specifications and wiring, refer to the following manual.
→ Refer to MELSEC IQ-F FX5 User's Manual (Ethernet Communication).

3.7.1 Communication specification

Item	Specification	
Data transmission speed	100/10 Mbps	
Communication mode	Full-duplex (FDX)/Half-duplex (HD ^X)*1	
Interface	RJ45 connector	
Transmission method	Base band	
Maximum segment length (The distance between hub and node)	100 m	
Cascade connection	100BASE-TX	Max. 2 stages*2
	10BASE-T	Max. 4 stages*2
Protocol type	*3	
Number of connections	Total of 8 connections*3	
Hub*1	Hubs with 100BASE-TX or 10BASE-T ports can be used.	
Insulation method	Pulse transformer	
IP address	Initial value: 192.168.3.250	

*1 IEEE802.3x flow control is not supported.
*2 The value indicates the number of connectable stages when a repeater hub is used. Contact the manufacturer of the switching hub for the number of connectable stages when using a switching hub.
*3 For details, refer to MELSEC IQ-F FX5 User's Manual (Ethernet Communication).


3.7.2 Wiring

For the wiring, refer to the following manual.
→ Refer to MELSEC IQ-F FX5 User's Manual (Ethernet Communication).

3.7.3 Pin configuration

The connector of the built-in Ethernet communication are arranged as follows:

Pin No.	Signal	Contents
1	TXD+	Transmit data (+)
2	TXD-	Transmit data (-)
3	RXD+	Receive data (+)
4	Not used	—
5	Not used	—
6	RXD-	Receive data (-)
7	Not used	—
8	Not used	—



Applicable cable

For 10BASE-T connection	Cable conforming to Ethernet standard practice: Category 3 or higher (STP cable)
For 100BASE-TX connection	Cable conforming to Ethernet standard practice: Category 5 or higher (STP cable)

A straight cable is used. A cross cable can also be used when using direct connection between a personal computer and the CPU module.

3.8 Built-in USB communication specifications


Item	Specification
Data transmission speed	Full Speed (Max. 12 Mbps)
Interface	Mini-B

4. Terminal layouts

For details on the terminal layout, refer to the following manual.
→ Refer to MELSEC IQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware).

Interpretation of partition

The partition of the output terminals (see following figure) indicates the range of the output connected to the same common.



This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty

Exclusion of loss in opportunity and secondary loss from warranty liability. Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to: (1) Damages caused by any cause found not to be the responsibility of Mitsubishi. (2) Loss in opportunity, lost profits incurred to the user by failures of Mitsubishi products. (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products. (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.