



MELSEC IQ-F FX5-ENET/IP

Hardware Manual



Table with Manual Number IB(NA)-0800599, Revision D, Date April 2021

This manual describes the part names, dimensions, installation, and specifications of the product. Before use, read this manual and manuals of relevant products fully to acquire proficiency in handling and operating the product.

And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

Registration: The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies. In some cases, trademark symbols such as 'TM' or '®' are not specified in this manual.

Effective April 2021
Specifications are subject to change without notice.
© 2018 MITSUBISHI ELECTRIC CORPORATION

Safety Precautions (Read these precautions before use.)

This manual classifies the safety precautions into two categories: WARNING and CAUTION.

Table defining WARNING and CAUTION symbols and their corresponding hazard levels.

Depending on the circumstances, procedures indicated by CAUTION may also cause severe injury. It is important to follow all precautions for personal safety.

Associated Manual

Table listing various manuals such as MELSEC IQ-F FX5 User's Manual, MELSEC IQ-F FX5 SLMP, MELSEC IQ-F FX5 BACnet, etc.

Table with Manual name, Manual No., and Description for MELSEC IQ-F FX5 Programming Manual.

How to obtain manuals: For the necessary product manuals or documents, consult with your local Mitsubishi Electric representative.

Applicable standards

FX5-ENET/IP comply with the EC Directive (EMC Directive) and UL standards (UL, cUL). Further information can be found in the following manual.

MELSEC IQ-F FX5-ENET/IP User's Manual: Regarding the standards that relate to the CPU module, please refer to either the product catalog or consult with your local Mitsubishi Electric representative.

Attention: This product is designed for use in industrial applications.

1. Outline


FX5-ENET/IP Ethernet module (hereinafter referred to as FX5-ENET/IP) is an intelligent function module for connecting to a EtherNet/IP network and general-purpose Ethernet.

1.1 Incorporated items

Check that the following product and items are included in the package:

Table listing product (FX5-ENET/IP Ethernet module) and included items like dust proof protection sheet, hardware manual, etc.

1.2 External Dimensions, Part Names



- Legend for the diagram: [1] External ground terminal, [2] Link status display LEDs, [3] Extension cable, [4] Direct mounting hole: 2 holes of φ4.5, [5] Module/network status display LEDs, [6] Operation status display LEDs, [7] Extension connector for next module, [8] Modular jack for P1 (RJ-45) with cap, [9] Modular jack for P2 (RJ-45) with cap, [10] Name plate, [11] DIN rail mounting groove (DIN rail: DIN 46277, 35 mm wide), [12] DIN rail mounting hook, [13] Pullout tab.

1.3 Indications of LEDs

Table showing LED display (MS, NS, POWER, RUN, ERROR), LED color (Green, Red), Status (On, Off, Flashing), and Indication (Data communication possible, No parameter setting, etc.).

2. Installation

INSTALLATION PRECAUTIONS WARNING: Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

INSTALLATION PRECAUTIONS CAUTION: Do not touch the conductive parts of the product directly. Do not enter the ventilation slits of the PLC. Failure to do so may cause fire, equipment failures or malfunctions.

- For further information on mounting, refer to the following manual: MELSEC IQ-F FX5UJ User's Manual, MELSEC IQ-F FX5U User's Manual, MELSEC IQ-F FX5UC User's Manual.

3. Wiring

WIRING PRECAUTIONS WARNING: Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

WIRING PRECAUTIONS CAUTION: Make sure to observe the following precautions in order to prevent any damage to the machinery or accidents due to malfunction of the PLC caused by abnormal data written to the PLC.

3.1 Connector to be used and cable

3.1.1 Pin configuration: The pin configuration of RJ45 type modular jack on FX5-ENET/IP is as follows. Table showing Pin No., Signal, and Contents.

3.1.2 Cables to be used: Use Ethernet cable that meets the following standards. Table showing Ethernet standard (100BASE-TX, 10BASE-T) and Specifications (Category 5 or higher, etc.).

3.2 Grounding: Ground the PLC as stated below. Diagram showing Independent grounding (Best condition), Shared grounding (Good condition), and Common grounding (Not allowed).

3.2.1 Grounding of FX5-ENET/IP


Diagram showing the grounding connection for the FX5-ENET/IP module to a D grounding terminal block. Includes a table for terminal name and content.

The connection destination for the FG terminal of FX5-ENET/IP is a spring clamp terminal block. To connect to the terminal block, there are two ways: by using single wires/strand wires or by using ferrules.


Table showing wire ferrules and its associated tools compatible with the terminal block. Columns include Manufacturer, Sleeve, Ferrules model, Suitable wiring size, and Crimp tool.

Table showing wire end treatment specifications: No. of wire per terminal, Wire size, and Temperature rating.

Wire end treatment: Strip the cable about 10 mm from the tip to connect a wire ferrule at the striped area. Failure to do so may result in electric shock due to the conductive part.



Check the shape of the wire insertion opening with the following chart, and use the smaller wire ferrule than the described size. Also, insert the wire with care so that the wire ferrule is in proper orientation.



- Connecting a cable: When ferrules with insulation sleeve are used, insert a wire with the ferrule with insulation sleeve into the wire insertion opening and push the wire. When stranded wires and solid wires are used, push the open/close button of the terminal block with a flathead screwdriver.

Table for manufacturer and model of the ferrules used in the terminal block.

- Disconnection of the cable: Push the open/close button of the wire to be disconnected with a flathead screwdriver. Pull out the wire with the open/close button pushed.

4. Specification

DESIGN PRECAUTIONS WARNING: Make sure to set up the following safety circuits outside the PLC to ensure safe system operation even during external power supply problems or PLC failure.

- Make sure to set up the following safety circuits outside the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents. Most importantly, set up the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements, and an interlock circuit to prevent damage to the equipment at the upper and lower positioning limits.

DESIGN PRECAUTIONS CAUTION: Simultaneously turn on and off the power supplies of the CPU module and extension modules.

SECURITY PRECAUTIONS WARNING: To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from unreliable networks and devices via network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.

STARTUP AND MAINTENANCE PRECAUTIONS CAUTION: Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric representative. Do not drop the product or exert strong impact to it.

DISPOSAL PRECAUTIONS CAUTION: Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device.

TRANSPORTATION PRECAUTIONS CAUTION: The product is a precision instrument. During transportation, avoid impacts larger than those specified in the general specifications by using dedicated packaging boxes and shock-absorbing pallets.

4.1 Applicable CPU module

Table showing Model name and Applicability for FX5UJ CPU module, FX5U CPU module, and FX5UC CPU module.

- *1 FX5-CNV-IFC or FX5-C1PS-5V is necessary to connect FX5-ENET/IP to the FX5UC CPU module. *2 Available functions differ depending on the version of the CPU module. For details, refer to the following manual.

Table showing Software and Applicability for GX Works3, EtherNet/IP Configuration Tool, and EtherNet/IP Configuration Tool for FX5-ENET/IP.

- *1 Available functions differ depending on the version of the software. For details, refer to the following manual. *2 Contact your local Mitsubishi Electric representative for information on how to obtain the EtherNet/IP Configuration Tool for FX5-ENET/IP.

4.2 Applicable Software Package

Table showing Software and Applicability for GX Works3, EtherNet/IP Configuration Tool, and EtherNet/IP Configuration Tool for FX5-ENET/IP.

4.3 General Specifications

Table showing Items and Specifications for Dielectric withstand voltage, Insulation resistance, etc.

4.4 Power Supply Specifications

Table showing Items and Specifications for Internal power supply, Current consumption.

4.5 Performance Specifications

Table showing Items and Specifications for EtherNet/IP communication, Protocol type, Number of ports, etc.

- *1 When each protocol is used, the version applicable to each of the CPU module, FX5-ENET/IP and software is necessary. For details, refer to the following manual. *2 Since the IP address is shared by two ports, only one address can be set.

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warning: Exclusion of loss in opportunity and secondary loss from warranty liability. Regardless of the gratis warranty term, Mitsubishi Electric shall not be liable for compensation to: (1) Damages caused by any cause found not to be the responsibility of Mitsubishi. (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products. (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products. (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

For safe use: This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.