

FACTORY AUTOMATION

Mitsubishi Electric Programmable Controller MELSEC iQ-F Series

Quick Connection Guide

FREQROL-A800/F800/E800 Series for CC-Link IE Field Network Basic



MELSEC iQ-F
series



FREQROL
E800

INTRODUCTION

Thank you for purchasing the Mitsubishi Electric MELSEC iQ-F series programmable controllers.

This manual describes the communication settings with inverters using the CC-Link IE Field Network Basic function of the FX5 CPU module.

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the specifications to handle the product correctly.

When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Regarding use of this product

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, please contact Mitsubishi Electric sales office.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions into the system.

Note


- If in doubt at any stage during the installation of the product, always consult a professional electrical engineer who is qualified and trained to the local and national standards. If in doubt about the operation or use, please contact your local Mitsubishi Electric representative.
- Mitsubishi Electric will not accept responsibility for actual use of the product based on these illustrative examples. Please use it after confirming the function and safety of the equipment and system.
- The content, specifications etc. of this manual may be changed, for improvement, without notice.
- The information in this manual has been carefully checked and is believed to be accurate; however, if you notice a doubtful point, an error, etc., please contact your local Mitsubishi Electric representative. When doing so, please provide the manual number given at the end of this manual.
- The term "Slave station" and "Authentication Class" have been replaced with "Device station" and "CC-Link IE TSN Class" in accordance with CC-Link Partner Association's policy. However, the terms have not been replaced yet in some areas in the engineering tool, and there may be differences between some window images of the engineering tool and the corresponding description in this manual. In that case, read the terms in the engineering tool's windows as follows.

Network name	Term used in software window	Term after change
CC-Link IE Field Network Basic function	Slave station	Remote station



Quick and satisfying browsing

e-Manual Viewer



e-Manual Viewer allows users to browse optimized FA-related documents such as Mitsubishi Electric FA product manuals.

e-Manual Viewer can be downloaded for free from the Mitsubishi Electric FA website.

Easy on-demand download of latest documents

All necessary documents can be easily downloaded with one click. The latest documents are available at any time.

Quick cross document search for necessary information

Refine search and fuzzy search are available for all downloaded documents.

Intuitive search using illustrations is available for hardware specifications of the product.

Copying program examples to an engineering tool

Program examples contained in a document can be directly copied to an engineering tool, eliminating the need of inputting the programs.

Sharing information among multiple users

The documents can be customized by adding useful information as a note freely.

Latest documents and notes can be shared with multiple users using the document sharing function.

■ Introduction for the concept and features of e-Manual Viewer is available on the following website.

www.mitsubishielectric.com/fa/ref/ref.html?k=plceng&smerit=emaviewer_win

■ The installation file for Windows® can be downloaded from the following website.

www.mitsubishielectric.com/fa/ref/ref.html?k=plceng&software=emaviewer_en

CONTENTS

INTRODUCTION	1
RELEVANT MANUALS	4
KEY FEATURES	5
CHAPTER 1 PREPARATION	6
1.1 Applicable Models	6
1.2 Operation Flow Diagram	6
1.3 Required Products	7
1.4 System Configuration	8
CHAPTER 2 INVERTER SETTINGS	9
2.1 Names of the Parts on the Operation Panel	9
2.2 List of Related Parameters	10
2.3 Ethernet Parameter Settings	11
2.4 Parameter Settings	13
2.5 Writing Data to the Inverters	16
2.6 Inverter Reset	17
CHAPTER 3 PROGRAMMABLE CONTROLLER SETTINGS	18
3.1 Part Names	18
3.2 Downloading the FB Library	18
3.3 Importing the FB Library	19
3.4 Parameter Settings	21
3.5 Adding Global Labels	27
3.6 Communication Settings of GX Works3	29
3.7 Writing Data to the Programmable Controller	31
CHAPTER 4 COUMMUNICATION CHECK OVER CC-Link IE Field Network Basic	33
CHAPTER 5 PROGRAM EXAMPLES	35
5.1 Operation	35
5.2 How to Use the FB Library	36
5.3 Program Examples	38
5.4 Operation Check	45
CHAPTER 6 TROUBLESHOOTING	46
6.1 Checking Procedure	46
6.2 Checking the Programmable Controller	47
6.3 Checking the Inverters	49
APPENDICES	50
Appendix 1 Example Applications of the FB Library	50
Appendix 2 How to Use the Program Copy Function of e-Manual	54
Appendix 3 Downloading and Registering a Profile	56
Appendix 4 Supplementary Information	57
REVISIONS	61
WARRANTY	62
SAFETY PRECAUTIONS	62
TRADEMARKS	62

RELEVANT MANUALS

The following relevant manuals can be downloaded from the Mitsubishi Electric FA site.

www.mitsubishielectric.co.jp/fa/ref/ref.html?kisyu=plcf&manual=download_all

[○: Available, —: Not available]


Manual name <manual number>	Available form	
	e-Manual	PDF
MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware) <SH-082452ENG>	○	○
MELSEC iQ-F FX5 User's Manual (Application) <JY997D55401>	○	○
MELSEC iQ-F FX5 User's Manual (Ethernet Communication) <JY997D56201>	○	○
CC-Link IE Field Network Basic Reference Manual <SH-081684ENG>	○	○
FB Library Reference Manual for CC-Link IE Field Network Basic Compatible Inverters <FBM-1065/1066>	—	○
GX Works3 Operating Manual <SH-081215ENG>	○	○
Programmable Controller Engineering Software MELSOFT GX Works3 FB Quick Start Guide <L-08475ENG>	—	○
FR Configurator2 Instruction Manual <IB-0600516ENG>	○	○
E800-E Inverter Safety Guideline <IB-0600860ENG>	—	○
FR-E800 Instruction Manual (Connection) <IB-0600865ENG>	○	○
FR-E800 Instruction Manual (Function) <IB-0600868ENG>	○	○
FR-E800 Instruction Manual (Communication) <IB-0600871ENG>	○	○
FR-E800 Instruction Manual (Maintenance) <IB-0600874ENG>	○	○
FR-A800 Instruction Manual (Detailed) <IB-0600503ENG>	○	○
FR-F800 Instruction Manual (Detailed) <IB-0600547ENG>	○	○
A800-E / F800-E Ethernet Function Manual <IB-0600628ENG>	—	○

KEY FEATURES

Point1

Easy programming using FB library*1

FB (function block) library is a collection of FBs that are used in GX Works3. Various programs required to operate the MELSEC iQ-F series modules can be designed easily by dragging and dropping FBs from the FB library to a program editor and inputting devices, drastically reducing the cost and time required for programming.




*1 FB libraries can be downloaded for free from the Mitsubishi Electric FA website.
www.mitsubishielectric.co.jp/fa/ref/ref.html?kisyu=plcf&samplelibrary=download_all

Point2

Easy system construction


Using the CC-Link IE Field Network Basic function equipped in the FX5 CPU module eliminates the need of extension devices. Parameter settings can be easier because the entire setting is performed on GX Works3 and automatically detected inverter station information via Ethernet is reflected to corresponding parameters.



Point3

Easy inverter setting using FR Configurator2

Operations from startup to maintenance of inverters can be easily performed on a personal computer by using FR Configurator2. Various convenient functions of FR Configurator2 support every phase such as design, operation, and maintenance.









*2 Number of connectable inverters differs depending on firmware version.

1 PREPARATION


1.1 Applicable Models

The models described in this guide are shown in the following table.


Programmable controller			Inverter (Ethernet model)		
					
FX5U CPU module	FX5UC CPU module	FX5UJ CPU module	FR-E800-E	FR-A800-E	FR-F800-E

1.2 Operation Flow Diagram

1. Preparing the required products
2. INVERTER SETTINGS
3. PROGRAMMABLE CONTROLLER SETTINGS








4. Checking the communication status
5. Program examples and checking the operation



1.3 Required Products

In a system configuration example of this manual, two inverters (FR-E800-E) are connected to the FX5U CPU module.

FX5U CPU module	FR-E800-E × 2	Personal computer and software
 <p>Use an FX5U CPU module that meets the following conditions.</p> <ul style="list-style-type: none"> • Serial number: 17X**** or later • Firmware version: 1.110 or later 	 <p>First inverter (Station number 1) Second inverter (Station number 2)</p> <p>The PU port can be found when the front cover is removed.</p> <p>■FR-E800-E models</p> <ul style="list-style-type: none"> • FR-E820-□EPA/EPB • FR-E840-□EPA/EPB • FR-E860-□EPA/EPB 	 <p>GX Works3</p> <ul style="list-style-type: none"> • Supported software version: 1.050C or later <p>FR Configurator2</p> <ul style="list-style-type: none"> • Supported software version: 1.19V or later

Ethernet cable × 4	Hub
 <p>Use Ethernet cables compliant with the following standards.</p> <ul style="list-style-type: none"> • Category 5 or higher straight cable (double shielded / STP) • IEEE 802.3 (100BASE-TX) • ANSI/TIA/EIA-568-B (Category 5) 	 <p>Use a hub that meets the following conditions.</p> <ul style="list-style-type: none"> • Compliance with the IEEE 802.3 (100BASE-TX) • Equipped with the auto MDI/MDI-X function • Equipped with the auto-negotiation function • Switching hub (layer 2 switch)^{*1}


*1 A repeater hub cannot be used.

1.4 System Configuration

This section describes the system configuration in which two inverters (FR-E800-E) are connected to the FX5U CPU module. The inverters are connected into a star type using a switching hub and standard Ethernet cables.

When multiple inverters communicate with each other in a same network, the first three values of the IP addresses (first to third octets) need to be the same. Assign IP addresses to the inverters to be used in advance. Assign a same subnet mask value to the modules to be used.

In this manual, IP addresses 192.168.50.□ and a subnet mask 255.255.255.0 are assigned to the inverters and the FX5U CPU module.



For the power supply wiring of FR-E800-E series, refer to the following.

📖 Chapter 2 Installation and Wiring in the FR-E800 Instruction Manual (Connection)

For the power supply wiring of FR-A800-E/F800-E, refer to the following.

📖 Page 58 Power supply wiring


For the power supply wiring of the FX5U, FX5UC, and FX5UJ CPU modules, refer to the following.

📖 Section 13.4 Power Supply Wiring in the MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

2 INVERTER SETTINGS

2.1 Names of the Parts on the Operation Panel

Inverter parameter settings and error content can be checked on the operation panel.



*: The operation panel cannot be removed from the inverter.

No.	Name	Description								
[1]	Monitor (4-digit LED)	Shows a numeric value (readout) of a monitor item such as the frequency and a parameter number.								
[2]	Unit indication	Hz: ON when the actual frequency is monitored. (Blinks when the set frequency is monitored.) A: ON when the current is monitored. (Both "Hz" and "A" are OFF to indicate a value other than the frequency or the current.)								
[3]	Inverter operation mode LEDs	<table border="1"> <tr> <td>PU</td> <td>ON when the inverter is in the PU operation mode.</td> </tr> <tr> <td>EXT</td> <td>ON when the inverter is in the External operation mode. (Lit at power-ON at initial setting.)</td> </tr> <tr> <td>NET</td> <td>ON when the inverter is in the Network operation mode.</td> </tr> </table>	PU	ON when the inverter is in the PU operation mode.	EXT	ON when the inverter is in the External operation mode. (Lit at power-ON at initial setting.)	NET	ON when the inverter is in the Network operation mode.		
PU	ON when the inverter is in the PU operation mode.									
EXT	ON when the inverter is in the External operation mode. (Lit at power-ON at initial setting.)									
NET	ON when the inverter is in the Network operation mode.									
	Operation panel status LEDs	<table border="1"> <tr> <td>MON</td> <td>ON or blinks only when the first, second, or third monitor is displayed.</td> </tr> <tr> <td>PRM</td> <td>Lit to indicate parameter setting mode. The LED blinks when the inverter is in the easy setting mode.</td> </tr> </table>	MON	ON or blinks only when the first, second, or third monitor is displayed.	PRM	Lit to indicate parameter setting mode. The LED blinks when the inverter is in the easy setting mode.				
MON	ON or blinks only when the first, second, or third monitor is displayed.									
PRM	Lit to indicate parameter setting mode. The LED blinks when the inverter is in the easy setting mode.									
	PLC function LED	P.RUN ON when the PLC function of the inverter is valid.								
	Operating status LED	RUN ON or blinks during inverter running. ON: During forward rotation operation. Blinks slowly (1.4-second cycle): During reverse rotation operation. Blinks quickly (0.2-second cycle): Operation is disabled although the start command is given.								
	Controlled motor type LED	PM ON when the inverter is set to control the PM motor. The LED blinks during test operation.								
[4]	PU/EXT key	Switches between the PU operation mode, the PUJOG operation mode, and the External operation mode.								
[5]	MODE key	Switches the operation panel to a different mode.								
[6]	RUN key	Executes a start command.								
[7]	SET key	Confirms each selection. When this key is pressed during the monitor mode, the monitor item changes.								
[8]	STOP/RESET key	Stops the operation commands. Resets the inverter when the protective function is activated.								
[9]	UP/DOWN key (↑↓ key)	Changes the frequency and parameter settings.								
[10]	Operation status LEDs	<table border="1"> <tr> <td>NS</td> <td>Shows communication status.</td> </tr> <tr> <td>MS</td> <td>Shows inverter status.</td> </tr> <tr> <td>LINK1</td> <td>Shows connector for communication (PORT1) status.</td> </tr> <tr> <td>LINK2</td> <td>Shows connector for communication (PORT2) status.</td> </tr> </table>	NS	Shows communication status.	MS	Shows inverter status.	LINK1	Shows connector for communication (PORT1) status.	LINK2	Shows connector for communication (PORT2) status.
NS	Shows communication status.									
MS	Shows inverter status.									
LINK1	Shows connector for communication (PORT1) status.									
LINK2	Shows connector for communication (PORT2) status.									

For details on the FR-E800-E operation panel, refer to the following.

📖 Section 2.1 Operation panel in the FR-E800 Instruction Manual (Function)

For details on the FR-A800-E/F800-E operation panel, refer to the following.

📖 Page 58 Operation panel

2.2 List of Related Parameters

The following tables list the parameters which are required to be set.

To make communications between an inverters and a connected device, set the inverter parameters to match the communication specifications of the connected device. Data communications cannot be made if the settings are not made or if there is any setting error.


Required parameter settings

Parameter	Name	Initial value	Setting value (Inverter station number 1)	Setting value (Inverter station number 2)	Description
Pr.77	Parameter write selection	0	2		Parameter write is set to [enable].
Pr.544	CC-Link extended setting	0	18		Set the function of the remote register for the CC-Link IE Field Network Basic to [Compatible with the octuple setting of CC-Link Ver.2].
Pr.1424	Ethernet communication network number	1	1		Set this parameter when making communications between the inverters and FR Configurator2.
Pr.1425	Ethernet communication station number	1	1	2	Set a network number to Pr.1424 and a station number to Pr.1425.
Pr.1427	Ethernet function selection 1	5001	5001		Set this parameter when making communications between the inverters and FR Configurator2. In this manual, use Pr.1427 and Pr.1428 with the initial values.
Pr.1428	Ethernet function selection 2	45237	45237		
Pr.1429	Ethernet function selection 3	45238	61450		Change the settings of the application to [CC-Link IE Field Network Basic].
Pr.1430	Ethernet function selection 4	9999	9999		Use this parameter with the initial value.
Pr.1434	Ethernet IP address 1	192	192		Set an IP address of the inverter to be connected to Ethernet.
Pr.1435	Ethernet IP address 2	168	168		
Pr.1436	Ethernet IP address 3	50	50		
Pr.1437	Ethernet IP address 4	1	11	12	
Pr.1438	Subnet mask 1	255	255		
Pr.1439	Subnet mask 2	255	255		Set a subnet mask which the IP address of the inverter belongs to.
Pr.1440	Subnet mask 3	255	255		
Pr.1441	Subnet mask 4	0	0		
Pr.1449	Ethernet command source selection IP address 1	0	192		Set an IP address of the FX5U CPU module.
Pr.1450	Ethernet command source selection IP address 2	0	168		
Pr.1451	Ethernet command source selection IP address 3	0	50		
Pr.1452	Ethernet command source selection IP address 4	0	2		

Parameter settings (for adjustment and operation)

Parameter	Name	Initial value	Setting value (Common for both inverters)	Description
Pr.1432	Ethernet communication check time interval	1.5 (= 1.5 seconds)	5.0 (= 5 seconds)	Set "9999" during adjustment, and set a value in accordance with the system specification during operation. <ul style="list-style-type: none"> • 9999: No communication check (signal loss detection) • 0: Ethernet communication is available, but the inverter output is shut off in the NET operation mode. • 1 to 9998: Set the interval of the communication check (signal loss detection) time for all devices with IP addresses in the range specified for Ethernet command source selection (Pr.1449 to Pr.1454).

For the FR-A800-E/F800-E parameters, refer to the following.


 Page 58 Parameters

2.3 Ethernet Parameter Settings


Parameters are set by connecting the inverters and the personal computer over Ethernet.

In this manual, FR Configurator2 is used to set the parameters. The following describes how to set the parameters using FR Configurator2.


FR Configurator2



1. Start FR Configurator2, and select [Ethernet parameter setting] from the [Tool] menu bar.




2. When the inverters connected to the personal computer are detected automatically, their information, such as the model and capacity, are displayed. Check that displayed information is correct, and click the [Batch assign] button.



Point

When the personal computer has multiple Ethernet ports or uses a USB converter, the following window appears. On this window, select a network adapter which is connected to the inverters.



3. Select the checkboxes of "Network No. / station No.", "Station No.", and "IP address / subnet mask", and click the [OK] button. In this manual, the following setting values are used.


Parameter	Setting value
Network No.	1
Station No.	1
IP address	192.168.50.11
Subnet mask	255.255.255.0

4. Click the [Write] button, and click the [Yes] button on the window, which asks whether to write the setting values to the inverters, to reflect the setting values.


5. When the inverters are reset, the Ethernet parameter setting is complete. Click the [Close] button to close the "Ethernet parameter setting" window, and move to the parameter setting.

2.4 Parameter Settings

1. Select [Project] on the toolbar ⇨ [New].




2. In the "Connection setting" field, select "Ethernet" for "PC-side port" and "Not used" for "Through", and click the [Auto recognize] button. Click the [Yes] button on the window, which asks whether to clear the current settings, to execute automatic recognition.



Point

When the personal computer has multiple Ethernet ports or uses a USB converter, the following window appears. On this window, select a network adapter which is connected to the inverters.



3. When the auto-recognized inverter information is displayed, check that the displayed model, capacity, and other information are correct. Click the [OK] button.

System setting

Connection setting

PC-side port: Ethernet
Through: Not used
Protocol: -
COM Port No.: 1
St. No. (GOT): 1
Detailed setting...

-GOT
Model: -
OUT port: -
IP address / host name: 0.0.0.0
Port No.: 5014

Programmable controller
Module: -
Model: -
Ethernet port direct connect:
IP address / host name: 0.0.0.0
Network number: 1
St. No.: 1

Model setting

Select the inverter network No., model, capacity, and connection option, and press the Network setting button. Press the Auto recognize button to detect the connected inverter. Inverter network No.: 1

St. No.	Model	Capacity	Connector 1	Connector 2	Connector 3	Terminal block	Comment
1	FR-E820-EPA	0.2K(0015)	-	-	-	FR-EBETA	
2	FR-E820-EPA	0.75K(0050)	-	-	-	FR-EBETA	
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-

Auto recognize Network setting... Clear Filter by model

Help OK Cancel

4. In the [Project] window, the inverter models of station number 1 and station number 2 are displayed. Double-click "Parameter" under the inverter model to open the parameter list.

MELSOFT Series FR Configurator2 New project - [Parameter list]

Project View File Parameter list (2) Parameter Safety Monitor Diagnose Test operation Tool Window Help

Project

New project
System setting
Graph
Batch read
St. No. 1: FR-E820-0.2K(0015)EPA
St. No. 2: FR-E820-0.75K(0050)EPA
Parameter

Parameter list


All parameters Filter selection Edit individual list Display related parameters Settings by function


No.	Name	Setting range	Min. unit	Initial value	Setting value
0	Torque boost	0 to 30	0.1%	6	
1	Maximum frequency	0 to 120	0.01Hz	120	
2	Minimum frequency	0 to 120	0.01Hz	0	
3	Base frequency	0 to 590	0.01Hz	60	
4	Multi-speed setting (high speed)	0 to 590	0.01Hz	60	
5	Multi-speed setting (middle speed)	0 to 590	0.01Hz	30	
6	Multi-speed setting (low speed)	0 to 590	0.01Hz	10	
7	Acceleration time	0 to 3600	0.1s	5	
8	Deceleration time	0 to 3600	0.1s	5	
9	Electronic thermal O/L, relay/Rated motor current	0 to 500	0.01A	1.27	
10	DC injection brake operation frequency	0 to 120	0.01Hz	3	
11	DC injection brake operation time	0 to 10	0.1s	0.5	
12	DC injection brake operation voltage	0 to 30	0.1%	6	
13	Starting frequency	0 to 60	0.01Hz	0.5	
14	Load pattern selection	0 to 3	1	0	
15	Jog frequency	0 to 590	0.01Hz	5	
16	Jog acceleration/deceleration time	0 to 3600	0.1s	0.5	
17	MRSX10 terminal input selection	0 to 5	1	0	
18	High speed maximum frequency	0 to 590	0.01Hz	120	

Ready | St. No. 1: FR-E820-0.2K(0015)EPA | CAP INUM

Point


If the [Project] window is not displayed, select [Project window] from [Docking Window] in the [View] menu to open the window.

5. Enter the parameter setting values. For parameters and setting values to be used, refer to  Page 10 List of Related Parameters.




No.	Name	Setting range	Min. unit	Initial value	Setting value
1429	Ethernet function selection 3	502,5000 to 5002,5006 to 5008,5010 to 5013,44818,45237,45238,47808,61450,9999	1	45238	61450
1430	Ethernet function selection 4	502,5000 to 5002,5006 to 5008,5010 to 5013,44818,45237,45238,47808,61450,9999	1	9999	
1431	Ethernet signal loss detection function selection	0 to 3	1		
1432	Ethernet communication check time interval	0 to 999.8,9999	0.1s	1.5	
1434	Ethernet IP address 1	0 to 255	1	192	
1435	Ethernet IP address 2	0 to 255	1	168	
1436	Ethernet IP address 3	0 to 255	1	50	
1437	Ethernet IP address 4	0 to 255	1		
1438	Subnet mask 1	0 to 255	1	255	
1439	Subnet mask 2	0 to 255	1	255	
1440	Subnet mask 3	0 to 255	1	255	
1441	Subnet mask 4	0 to 255	1	0	
1442	Ethernet IP filter address 1	0 to 255	1	0	
1443	Ethernet IP filter address 2	0 to 255	1	0	
1444	Ethernet IP filter address 3	0 to 255	1	0	
1445	Ethernet IP filter address 4	0 to 255	1	0	
1446	Ethernet IP filter address 2 range specification	0 to 255,9999	1	9999	
1447	Ethernet IP filter address 3 range specification	0 to 255,9999	1	9999	
1448	Ethernet IP filter address 4 range specification	0 to 255,9999	1	9999	
1449	Ethernet command source selection IP address 1	0 to 255	1	0	192
1450	Ethernet command source selection IP address 2	0 to 255	1	0	168
1451	Ethernet command source selection IP address 3	0 to 255	1	0	50
1452	Ethernet command source selection IP address 4	0 to 255	1	0	2

For parameter setting on the operation panel, refer to the following.

 Section 2.1.2 Basic operation of the operation panel in the FR-E800 Instruction Manual (Function).

Point 


The following parameters are set during Ethernet parameter setting, therefore, entering their setting values is not necessary. ( Page 11 Ethernet Parameter Settings)

- Pr.1424 (Ethernet communication network number)
- Pr.1425 (Ethernet communication station number)
- Pr.1434 to Pr.1437 (Ethernet IP address)
- Pr.1438 to Pr.1441 (Subnet mask)


2.5 Writing Data to the Inverters

The parameter setting values entered in the parameter list are written to each inverter.

1. Click the following icon on the toolbar to go online.




2. Click [Batch write], and click the [Yes] button on the window which asks whether to write the parameters. After the parameters are written to the inverter, reset the inverter.



Point


A parameter list can be switched between the station number 1 and the station number 2 by selecting the following station number list.




2.6 Inverter Reset

After the parameters are changed, the inverters must be reset. Otherwise, the changed settings are not reflected. In this manual, FR Configurator2 is used to reset the inverters. The following describes how to reset the inverters using FR Configurator2.

1. Select [Fault history] from the [Diagnose] menu bar on the toolbar.




2. Click [Inverter reset], and click the [Yes] button on the window which asks whether to reset the inverter. When the inverter (station number 1) is reset, the parameter setting is complete.



3. Set the parameters for the inverter station number 2 using the same procedure as the inverter station number 1. For the parameter setting of the inverter station number 2, start from the step 4 of in 2.4 Parameter Setting. (For the parameter setting procedure, refer to [Page 13 Parameter Settings](#).)

Point

An alarm history can be switched between the station number 1 and the station number 2 by selecting the following station number list.



3 PROGRAMMABLE CONTROLLER SETTINGS

3.1 Part Names

For the part names of the FX5U, FX5UC, and FX5UJ CPU modules, refer to the following.

📖 Chapter 3 PART NAMES in the MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

3.2 Downloading the FB Library

In this manual, the FB library for CC-Link IE Field Network Basic compatible inverters is used.

To obtain the FB library, please contact your local Mitsubishi Electric representative.


3.3 Importing the FB Library

This section describes how to register the obtained FB library to GX Works3.
Decompress the FB library folder (zip file) before registering the FB library.


1. Start GX Works3, and select [Project] on the toolbar ⇒ [New].

In this manual, the following setting values are used.


Item	Setting value
Series	FX5CPU
Type	FX5U
Program Language	Ladder




2. Select [Project] on the toolbar ⇒ [Library Operation] ⇒ [Register to Library List] ⇒ [Library].




3. When the following window appears, click the [OK] button.



4. Select the "INVERTER-CC-IEF-Basic_F.mslm" file in the decompressed FB library folder, and click the [Open] button.



5. The selected file is added to [Library] in the "Element Selection" window.




Point


If the "Element Selection" window is not displayed, select [View] on the toolbar ⇒ [Docking Window] ⇒ [Element Selection] to open the window.

3.4 Parameter Settings

This section describes how to set parameters required for the programmable controller using GX Works3. To set the parameters, connect the personal computer, the programmable controller, and the inverters over Ethernet.




1. In the "Navigation" window, select [Parameter] ⇒ [FX5UCPU] ⇒ [Module Parameter] ⇒ [Ethernet Port].




Point

If the "Navigation" window is not displayed, select [View] on the toolbar ⇒ [Docking Window] ⇒ [Navigation] to open the window.

2. Set an IP address and a subnet mask in "Own Node Settings" of "Basic Settings".


In this manual, the following setting values are used. (For the setting values, refer to  Page 8 System Configuration.)

Item	Setting value
IP Address	192.168.50.2
Subnet Mask	255.255.255.0




An IP address is not set by default. When an IP address is not set, the IP address 192.168.3.250 is set.


3. Select "Use" for "To Use or Not to Use CC-Link IEF Basic Setting" in "CC-Link IEF Basic Settings", and double-click "<Detailed Setting>" of "Network Configuration Settings".



4. Click the [Detect Now] button.




When the FR-E800-E profile is not registered, refer to the following.

 Page 56 Downloading and Registering a Profile


5. The information of the inverters connected to the programmable controller is reflected in the table. Check the settings of model name, reserved station, IP address, and subnet mask, and click [Close with Reflecting the Setting].

In this manual, the following setting values are used. (For the setting values, refer to Page 8 System Configuration.)

Model Name	STA#	RSVD STA	IP Address	Subnet Mask
FR-E800-E	1	No Setting	192.168.50.11	255.255.255.0
FR-E800-E	2	No Setting	192.168.50.12	255.255.255.0




6. Next, set parameters to perform data transfer automatically between link devices of the inverters and devices of the programmable controller. Double-click "<Detailed Setting>" of "Refresh Settings".




7. Select "Specify Device" for the refresh target on the CPU module side, and set the name and start address of the device to be assigned. After the device is set, click the [Apply] button. In this manual, the following setting values are used.

Target	Device Name	Start
Specify Device	X	100
Specify Device	Y	100
Specify Device	W	00000
Specify Device	W	00080



Data flow between the master station and remote stations using link devices


In this manual, since [Compatible with the octuple setting of CC-Link Ver.2] is selected for the CC-Link extended setting (Pr.544) of the inverters, assign the link devices of each inverter to the following devices of the programmable controller. (For the inverter settings, refer to  Page 10 List of Related Parameters.)

■FR-E800-E (Station number 1)

Assignment target device on the programmable controller side	Number of points	Link device on the inverter side
X100 to X177	64	RX0 to RX3F
Y100 to Y177	64	RY0 to RY3F
W0 to W1F	32	RWr0 to RWr1F
W80 to W9F	32	RWw0 to RWw1F

■FR-E800-E (Station number 2)

Assignment target device on the programmable controller side	Number of points	Link device on the inverter side
X200 to X277	64	RX40 to RX7F
Y200 to Y277	64	RY40 to RY7F
W20 to W3F	32	RWr20 to RWr3F
WA0 to WBF	32	RWw20 to RWw3F



Precautions

The above areas are used as the link devices for network. Do not use these areas.

Mainly-used devices

The following tables list the functions and the assignment target device numbers of the mainly-used link devices (remote input, remote output, and remote registers).

■Bit device (X)

Device number (Station number 1)	Device number (Station number 2)	Description
X100	X200	Forward running
X101	X201	Reverse running
X102	X202	Running (terminal RUN function)
X104	X204	Overload warning
X105	X205	Pr.193 assignment function (NET Y1)
X107	X207	Fault (terminal ABC function)
X114	X214	Monitoring
X115	X215	Frequency setting completion (RAM)
X116	X216	Frequency setting completion (RAM, EEPROM)
X117	X217	Instruction code execution completed
X132	X232	Error status flag
X133	X233	Remote station ready


■Bit device (Y)

Device number (Station number 1)	Device number (Station number 2)	Description
Y100	Y200	Forward rotation command
Y101	Y201	Reverse rotation command
Y102	Y202	High-speed operation command (terminal RH function)
Y103	Y203	Middle-speed operation command (terminal RM function)
Y104	Y204	Low-speed operation command (terminal RL function)
Y110	Y210	Pr.185 assignment function (NET X1)
Y111	Y211	Output stop (terminal MRS function)
Y113	Y213	Pr.184 assignment function (RES)
Y114	Y214	Monitor command
Y115	Y215	Frequency setting command (RAM)
Y116	Y216	Frequency setting command (RAM, EEPROM)
Y117	Y217	Instruction code execution request
Y132	Y232	Error reset request flag


Word device

Device number (Station number 1)	Device number (Station number 2)	Description	
		Upper 8 bits	Lower 8 bits
W0000	W0020	First monitor value	
W0001	W0021	Second monitor value	
W0002	W0022	Reply code 2	Reply code 1
W0003	W0023	Data to be read	
W0008	W0028	Fault record No.	Fault record (fault data)
W0009	W0029	Fault record (output frequency)	
W000A	W002A	Fault record (output current)	
W000B	W002B	Fault record (output voltage)	
W000C	W002C	Fault record (energization time)	
W0080	W00A0	Monitor code 2	Monitor code 1
W0081	W00A1	Set frequency (0.01 Hz increments)	
W0082	W00A2	Link parameter extended setting	Instruction code
W0083	W00A3	Data to be written	
W0088	W00A8	Fault record No.	H00
W008C	W00AC	Torque command or torque limit	

For details on the remote input, remote output, and remote register areas not listed in this manual, refer to the following.

 Section 2.6.4 Parameters related to CC-Link IE Field Network Basic in the INVERTER FR-E800 Instruction Manual (Communication)


For details on the remote input, remote output, and remote registers of FR-A800-E and FR-F800-E, refer to the following.

 Page 58 Remote input, remote output, and remote registers


3.5 Adding Global Labels

This section describes how to add the global labels in the FB library to the project.

1. In the "Element Selection" window, select [Global Label] ⇒ [INVERTER-CC-IEF-Basic_F] of the imported FB library. Right-click [INVERTER-CC-IEF-Basic_F], and select [Add to Project].



2. In the "Navigation" window, [INVERTER-CC-IEF-Basic_F] is added to [Global Label].




How to check the global label assignment areas

To display the global labels used in the FB library, select [Global Label] ⇒ [INVERTER-CC-IEF-Basic_F] in [Label], and double-click [INVERTER-CC-IEF-Basic_F]. The following table lists the initial settings of the devices used in the global labels.

Label Name	Data Type	Class	Assign (Device/Label)
M_RX	Bit	VAR_GLOBAL	X100Z8
M_RY	Bit	VAR_GLOBAL	Y100Z7
M_RWw	Double Word [Signed]	VAR_GLOBAL	W0Z9
M_RWw	Word [Signed]	VAR_GLOBAL	W80Z6

3




For how to change global labels, refer to the following.


📖 Section 1.5.1 Recommended global label settings in the FB Library Reference Manual for CC-Link IE Field Network Basic Compatible Inverters

3.6 Communication Settings of GX Works3


This section describes the communication settings of GX Works3. Directly connect an Ethernet port of the personal computer where GX Works3 has been installed to the FX5U CPU module as shown below. To write data to the FX5U CPU module, a communication test needs to be performed first.



1. Select [Online] ⇒ [Current Connection Destination].




2. Select "Direct Coupled Setting".




- Specify an Ethernet adapter of the personal computer which is used when the personal computer is directly connected to the CPU module.


When "Not Specified" is set, select an adapter to be used from the drop-down list.



- After the adapter is selected, click the [Communication Test] button.



- When the following window appears, click the [OK] button.




For the connection via a hub, refer to the following.

Section 4.2 Connection Via a Hub in the MELSEC iQ-F FX5 User's Manual (Ethernet Communication)


3.7 Writing Data to the Programmable Controller

This section describes how to write programs and parameters to the programmable controller. The programs and the parameters must be determined before writing them to the programmable controller.


1. Select [Convert] ⇒ [Rebuild All].




2. Click the [OK] button.




3. Select [Online] ⇒ [Write to PLC].



4. Click the [Parameter + Program] button, and click the [Execute] button.




5. When the following window appears, click the [Yes to all] button.




6. After the programs and the parameters are written to the programmable controller, reset or power OFF and ON the programmable controller.

4 COUmmUNICATION CHECK OVER CC-Link IE Field Network Basic


This chapter describes how to check communications over CC-Link IE Field Network Basic in the system where the inverters and the programmable controller are connected.



1. On GX Works3, select [Online] on the toolbar ⇒ [Monitor] ⇒ [Device/Buffer Memory Batch Monitor].



2. Enter "X100" in "Device Name", and click the [Start Monitoring] button. To make sure that the inverters and the programmable controller are communicating properly, check X133 of the station number 1 and X233 of the station number 2 which are the "Remote station ready" signals of these stations.



■ Normal communications

X133 of the station number 1 and X233 of the station number 2 are ON (set to "1" on the monitor window).

■ Faulty communications

X133 of the station number 1 and X233 of the station number 2 are OFF (set to "0" on the monitor window). Check the error status.

For how to check the error status, refer to the following.

☞ Page 46 TROUBLESHOOTING


5 PROGRAM EXAMPLES

5.1 Operation


FR-E800-E (Station number 1)

This program allows forward rotation (X1) and reverse rotation (X2) to control operations of the station number 1. The frequency setting can be changed by changing a value set in D20.

1) Setting a running frequency




2) Switching between forward and reverse rotation or stopping the operation




FR-E800-E (Station number 2)

This program allows forward rotation (X11) and reverse rotation (X12) to control operations of the second inverter (station number 2). The frequency setting can be changed by changing a value set in D120.

1) Setting a running frequency



2) Switching between forward and reverse rotation or stopping the operation



In this manual, the FB library provided by Mitsubishi Electric is used.

For how to set the FB library, refer to the following.

☞ Page 18 Downloading the FB Library


☞ Page 19 Importing the FB Library

5.2 How to Use the FB Library


The FBs in the imported FB library can be used by selecting an applicable FB in the "Element Selection" window and dragging it to the program editor. After the FB is pasted, create an input ladder and an output ladder of the pasted FB, and complete a program.

Insert FB input circuits to the left side and output circuits to the right side of the ladder window in the same manner as standard ladder programs.


1. To display the FB list, click the [Library] ⇒ [INVERTER-CC-IEF-Basic_F] ⇒ [FB] ⇒ [MELSOFT_FBFILE] in the "Element Selection" window. Select an FB to be used, and drop it in the program editor. When the "FB Instance Name" window appears, click the [OK] button.




2. The FB is pasted to the program editor.




3. Insert a contact and input to B:i_BEN.



4. Insert an FB Word device input to the left side of the FB. Insert an FB Word device output to the right side of the FB.



5. Repeat these steps to create ladders.



5.3 Program Examples


The following programs are designed to control the inverters (station numbers 1 and 2) using the FB library for CC-Link IE Field Network Basic compatible inverters.




This section provides the program examples for the station numbers 1 and 2.


When using e-Manual Viewer, the program copy function is available to perform programming. For details, refer to the following.

 Page 54 How to Use the Program Copy Function of e-Manual


Program example for the station number 1











Program example for the station number 2








5.4 Operation Check

To check that the programmable controller and inverters communicate data without an error, write the programs and parameters to the programmable controller by following the procedure.


Change the programmable controller state from STOP to RUN and check the following.

Turning ON the forward rotation command input



*1: The LINK1 or LINK2 LED will blink according to the connected port.

Changing the frequency to 40 Hz (when the forward rotation command remains ON)



Point

The operation command (such as X1) and the frequency change command (such as X3) can be turned ON forcibly by following the procedure below.

- ① Make sure that the ladder diagram is displayed on GX Works3, and press the **[F3]** key. (The status is changed to monitoring.)
 - ② Place a cursor on the device (such as X1 and X3) to be turned ON.
 - ③ Hold down the **[Shift]** key and press the **[Enter]** key to turn ON the device. (Hold down the **[Shift]** key and press the **[Enter]** key again to turn it OFF.)
- Press the **[F2]** key to clear the monitor execution status.

6 TROUBLESHOOTING

6.1 Checking Procedure

This section describes how to check the status of the programmable controller and the inverters.

1. Checking the LED status

Check the communication status with the LEDs of the programmable controller and the inverters.

Programmable controller: Page 47 Checking the LED status

Inverter: Page 49 Checking the LED status on the operation panel

2. Checking the error code

Take an action in accordance with the error code.

Programmable controller: Page 47 Checking the error details

Inverter: Page 49 Checking on FR Configurator2

■Wiring

Page 8 System Configuration


- Are the Ethernet cables fully inserted?

■Communication settings

Programmable controller: Page 21 Parameter Settings


Inverter: Page 11 Ethernet Parameter Settings

- Do the parameter settings on GX Works3 match with the parameter settings on the inverters?
- Are the IP addresses and the subnet masks of the programmable controller and the inverters set properly?



Programmable controller

* After the parameter values are changed, reset (or power OFF and ON) the programmable controller to reflect new values.




Inverter

* After the parameter values are changed, reset (or power OFF and ON) the inverter to reflect new values.

■Programs

Page 38 Program Examples


- Are the programs created as shown in the program examples?



6.2 Checking the Programmable Controller

Checking the LED status


The communication status is checked with the SD/RD LED of the programmable controller.




Normal communications: Flashes at high speed.
Faulty communications: ON (Flicks at regular interval.)
Disconnection of Ethernet cable of the programmable controller: OFF

Checking the error details

Select [Diagnostics] on the toolbar ⇒ [CC-Link IEF Basic Diagnostics]. The error details of the programmable controller can be checked at "Network Status".




Click "Error Details" of the station number whose error details to be checked.




List of error codes

Error code	Error name	Error details and cause	Action
CFC0H	Cyclic transmission error (master station)	Unable to execute cyclic transmission because multiple master stations exist in the same network address.	Check the existence status of master stations in network.
CFC1H	Cyclic transmission error (master station)	Unable to execute cyclic transmission because the error occurred in cyclic transmission.	Take measures to reduce noise. If the same error is displayed again, please contact your local Mitsubishi representative.
CFC8H	Cyclic transmission error (master station)	Unable to execute cyclic transmission because a remote station controlled by other master station exists.	Check the existence status of master stations in network. Check the remote station where the error has occurred.
CFC9H	Cyclic transmission error (master station)	Unable to execute cyclic transmission because two or more remote stations having the same IP address exist in the same network address.	Check the status of remote stations in the networks. Check the remote stations where the error has occurred.
CFD0H	Master station error	The port No. (61450) used in CC-Link IE Field Network Basic has already been used.	Check the port No. used in Ethernet function.
CFD1H	Master station error	Invalid value has been set in subnet mask.	Check the parameter setting.
CFE0H	Cyclic transmission error (remote station)	The cyclic transmission was executed for the remote station controlled by another master station.	Check the existence status of master station in network. Check the remote station where the error has occurred.
CFE1H	Cyclic transmission error (remote station)	The unusable number of occupied stations has been specified from master station.	Check the number of occupied stations setting in master station parameter (Network Configuration Settings).
CFE8H	Cyclic transmission error (remote station)	There is no response from the remote station.	Check the remote station disconnection detection setting in the master station parameter (Network Configuration Settings). Check the status of remote stations in the networks. Check the remote station which is disconnected. Take measures to reduce noise.
CFE9H	Cyclic transmission error (remote station)	Two or more remote stations having the same IP address exist in the same network address.	Check the remote stations where the error has occurred.
CFF0H	Remote station error	An error has occurred in a remote station.	Check the remote station where the error has occurred.

For details on troubleshooting, refer to the following.

 Chapter 9 TROUBLESHOOTING in the CC-Link IE Field Network Basic Reference Manual

For details on the error codes, refer to the following.

 Appendix 3 Error Codes in the MELSEC iQ-F FX5 User's Manual (Application)

6.3 Checking the Inverters

Checking the LED status on the operation panel

The operating status of the inverter is checked with the corresponding LEDs on the operation panel of the inverter.



For the LED status of the inverter, refer to the following.

☞ Page 9 Names of the Parts on the Operation Panel

For the operation panel display of the inverter, refer to the following.

☞ Page 58 Operation panel

Checking on FR Configurator2

The settings of the inverter are checked depending on an error occurred. Refer to the following table.

(For how to check the settings on FR Configurator2, refer to ☞ Page 11 Ethernet Parameter Settings.)

Error	Check point
Communications are not established.	Check that the communication speed is not set to 10 Mbps.
Operation mode does not switch to the Network operation mode.	<ul style="list-style-type: none"> • Check that the Ethernet cable is installed correctly. (Check for contact fault, break in the cable, etc.) • Check that the inverter is in the External operation mode. • Check that the operation mode switching program is running. • Check that the operation mode switching program has been written correctly.
The inverter does not start in the Network operation mode.	<ul style="list-style-type: none"> • Check that the inverter starting program is running. • Check that the inverter starting program has been written correctly. • Check that Pr.338 Communication operation command source is not set to External.

For details on the error messages, refer to the following.

☞ Section 2.4 List of fault displays in the FR-E800 Instruction Manual (Maintenance)

For details on the error messages of FR-A800-E/F800-E, refer to the following.

☞ Page 58 Error messages

APPENDICES

Appendix 1 Example Applications of the FB Library

The following table lists the FBs included in the FB library for CC-Link IE Field Network Basic compatible inverters. Programs are created by combining FBs according to each application.

This section provides the program examples for the station number 1.

List of FBs for CC-Link IE Field Network Basic compatible inverters

Name	Description
M+INVERTER-CC-IEF-Basic_Running	Outputs inverter operation control commands to operate inverters.
M+INVERTER-CC-IEF-Basic_ResetError	Resets fault of the inverter with the specified station number.
M+INVERTER-CC-IEF-Basic_StopRunning	Stops output of the inverter with the specified station number. (The output is stopped by turning ON the MRS signal.)
M+INVERTER-CC-IEF-Basic_WriteFRQ_TRQ	Writes the frequency/torque command value in RAM or EEPROM. Writing to EEPROM depends on the FB input signal.
M+INVERTER-CC-IEF-Basic_ExecuteCommandCode	Writes an instruction code and processes the instruction.
M+INVERTER-CC-IEF-Basic_SetParameter	Specifies the CC-Link IE Field Network Basic station number and the parameter number and changes the inverter parameter setting.
M+INVERTER-CC-IEF-Basic_MonitorStatus	Obtains the whole 16-bit data of operating status of the inverter with the specified station number.
M+INVERTER-CC-IEF-Basic_MonitorFRQ	Monitors the whole data of output frequency of the inverter.
M+INVERTER-CC-IEF-Basic_MonitorAlarm	Indicates the fault record and the warning record of the inverter with the specified station number.
M+INVERTER-CC-IEF-Basic_ReadParameter	Specifies the CC-Link IE Field Network Basic channel number and the parameter number and reads the inverter parameter setting.


Program examples using FBs

Program example	FB used	Reference
Sending the operation command to the inverter and changing and monitoring a frequency of the inverter	<ul style="list-style-type: none"> M+INVERTER-CC-IEF-Basic_Running M+INVERTER-CC-IEF-Basic_StopRunning M+INVERTER-CC-IEF-Basic_WriteFRQ_TRQ M+INVERTER-CC-IEF-Basic_MonitorStatus M+INVERTER-CC-IEF-Basic_MonitorFRQ 	☞ Page 38 Program Examples
Changing and checking the parameter	<ul style="list-style-type: none"> M+INVERTER-CC-IEF-Basic_SetParameter M+INVERTER-CC-IEF-Basic_ReadParameter 	☞ Page 51 Changing and checking the parameter
Switching the operation mode	<ul style="list-style-type: none"> M+INVERTER-CC-IEF-Basic_ExecuteCommandCode 	☞ Page 52 Switching the operation mode
Resetting an inverter error	<ul style="list-style-type: none"> M+INVERTER-CC-IEF-Basic_ResetError M+INVERTER-CC-IEF-Basic_MonitorAlarm 	☞ Page 53 Resetting an inverter error

A


Changing and checking the parameter

This program changes the parameter of the inverter (station number 1). This program example changes an acceleration time.




Switching the operation mode

This program sends an instruction code to the inverter (station number 1). This program example reads the current operation mode and switches it to the PU operation mode.



Resetting an inverter error


This program checks an error occurred in the inverter (station number 1) and resets the error.




Appendix 2 How to Use the Program Copy Function of e-Manual

Program examples in e-Manual can be copied and pasted to GX Works3.


1. Click "Copy Ladder Program (for GX Works3)" in e-Manual.



2. Right-click the mouse on the ladder editor of GX Works3, and select [Paste].



3. The copied program is pasted in undefined state. Select the FB used in the program example from [Library] on the "Element Selection" window, and drag and drop it to the FB area on the ladder editor.



Point

When an FB is used in the program example, the definition of the FB will be unclear immediately after the program is pasted to the ladder editor. Drag and drop the FB from the "Element Selection" window to define the FB properly.


Unclear definition of FB	
M_INVERTER_CC_EF_Basic_Running_F_00A_1 (M-INVERTER-CC-EF-Basic_Running_F_00A_1)	
L_bEN	o_bENO
L_wStationNo	o_bOK
L_bForward	o_bErr
L_bReverse	o_wErrID
L_bHigh	
L_bMiddle	
L_bLow	

Properly defined FB	
M_INVERTER_CC_EF_Basic_Running_F_00A_1 (M-INVERTER-CC-EF-Basic_Running_F_00A_1)	
B_L_bEN	o_bENO B
W_L_wStationNo	o_bOK B
B_L_bForward	o_bErr B
B_L_bReverse	o_wErrID V
B_L_bHigh	
B_L_bMiddle	
B_L_bLow	

- Click the [OK] button on the "FB Instance Name" window.



- When the FB is properly defined, the FB instance name is highlighted in gray.



Point

Label items (label name, data type, and others) are copied in the order defined as an example in this manual. Therefore, define label items in the same order as shown on the label editor of the engineering tool.

■ **Labels to be defined**
Define global labels as follows.

	Label Name	Data Type	Class	Assign (Device/Label)
1	bStartDirection_1	Bit	VAR_GLOBAL	M200
2	bStartDirection_2	Bit	VAR_GLOBAL	M201

[Copy labels \(for GX Works3\)](#)

Simple display

Switch simple display and detailed display using the [Easy Display] and [Show Details] buttons.

■ **Same label item order**

■ **Different label item order** If the label items copied are different order from the order used at the pasting destination, incorrect items are pasted or some items will not be defined.


Appendix 3 Downloading and Registering a Profile

A profile is the data that stores information of a connected device (such as a model).


A profile can be used on a personal computer after it is registered using GX Works3 and shared with other MELSOFT products. Once a profile is registered using GX Works3, the profile data is reflected to other MELSOFT products.

To register or delete a profile, log on to the personal computer as a user with the administrator privilege, and close the project in advance.

1. To obtain the profile data, please contact your local Mitsubishi Electric representative.
2. Start GX Works3, and select [Tool] ⇒ [Profile Management] ⇒ [Register].



3. Select the downloaded file on the "Register Profile" window, and click the [Register] button. A profile is a compressed file (such as *.zip, *.ipar, and *.cspp). Register the profile without decompressing.



Appendix 4 Supplementary Information

Supplementary information of the programmable controller

For the power supply wiring and the part names of the FX5UC and FX5UJ CPU modules, refer to the following.

■Power supply wiring

📖Section 13.4 Power Supply Wiring in the MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

■Part names

📖Chapter 3 PART NAMES in the MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

Supplementary information of the inverter

For the power supply wiring and the operation panel of the FR-A800-E and FR-F800-E, refer to the following.

■Power supply wiring

📖 Section 2.5 Main circuit terminals in the FR-A800 Instruction Manual (Detailed)

📖 Section 2.5 Main circuit terminals in the FR-F800 Instruction Manual (Detailed)

■Operation panel

Digital characters displayed on the operation panel are as follows.

FR-E800-E													FR-A800-E/F800-E														
0	1	2	3	4	5	6	7	8	9	A	B	C	0	1	2	3	4	5	6	7	8	9	A	B(b)	C	c	D(d)
0	1	2	3	4	5	6	7	8	9	A	b	C	0	1	2	3	4	5	6	7	8	9	A	b	C	c	d
D	E	F	G	H	I	J	K	L	M	N	O	P	E(e)	F(f)	G(g)	H	h	I(i)	J(j)	K(k)	L(l)	M(m)	N	n	O	o	P(p)
d	E	F	G	H	I	J	K	L	M	N	O	P	E	F	G	H	h	I	J	K	L	M	N	n	O	o	P
Q	R	S	T	U	V	W	X	Y	Z	-	_	Q(q)	R	r	S(s)	T(t)	U	u	V	v	W	w	X(x)	Y(y)	Z(z)		
q	r	s	t	u	v	w	x	y	z	-	_	Q	R	r	S	T	U	u	V	v	W	w	X	Y	Z		

📖 Section 4.1 Operation panel (FR-DU08) in the FR-A800 Instruction Manual (Detailed)

📖 Section 4.1 Operation panel (FR-DU08) in the FR-F800 Instruction Manual (Detailed)

■Parameters

📖 Section 5.1 Parameter list in the FR-A800 Instruction Manual (Detailed)

📖 Section 5.1 Parameter list in the FR-F800 Instruction Manual (Detailed)

■Remote input, remote output, and remote registers

📖 Section 2.5.5 CC-Link IE Field Network Basic in the A800-E/F800-E Ethernet Function Manual

■Error messages


📖 Section 6.4 List of the fault displays in the FR-A800 Instruction Manual (Detailed)

📖 Section 6.4 List of the fault displays in the FR-F800 Instruction Manual (Detailed)

QR code on the front panel of the FR-E800-E: FR-E800 series start-up support

The website for the FR-E800 series startup support can be accessed by reading a QR code on the front panel of the FR-E800-E using a smartphone or a tablet.

The relevant manuals and the outline dimension drawings are available on the website.



MEMO

A

REVISIONS

Revision date	Version	Description
June 2020	A	First edition
November 2020	B	■Added or modified parts Section 5.1, 5.3
January 2023	C	■Added or modified parts Front cover, INTRODUCTION, RELEVANT MANUALS, Section 1.4, 3.1, 3.4, 6.2, Appendix 4, WARRANTY, TRADEMARKS

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2020 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

📖 WARRANTY in the FR-E800 Instruction Manual (Maintenance)

SAFETY PRECAUTIONS

- Before using the product introduced in this manual, please read the manuals for the product carefully to handle the product correctly.
- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, please contact Mitsubishi Electric sales office.
- The product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions into the system.
- For design, wiring, and other precautions, read "SAFETY PRECAUTIONS" in the relevant manuals.

TRADEMARKS

Microsoft and Windows are trademarks of the Microsoft group of companies.

QR Code is either a registered trademark or a trademark of DENSO WAVE INCORPORATED in the United States, Japan, and/or other countries.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.

Country/Region	Sales office	Tel/Fax
USA	<p> MITSUBISHI ELECTRIC AUTOMATION, INC. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A. </p>	<p> Tel : +1-847-478-2100 Fax : +1-847-478-2253 </p>
Mexico	<p> MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch Boulevard Miguel de Cervantes Saavedra 301, Torre Norte Piso 5, Ampliacion Granada, Miguel Hidalgo, Ciudad de Mexico, Mexico, C.P.115200 </p>	<p> Tel : +52-55-3067-7512 </p>
Brazil	<p> MITSUBISHI ELECTRIC DO BRASIL COMERCIO E SERVICOS LTDA. Avenida Adelino Cardana, 293, 21 andar, Bethaville, Barueri SP, Brasil </p>	<p> Tel : +55-11-4689-3000 Fax : +55-11-4689-3016 </p>
Germany	<p> MITSUBISHI ELECTRIC EUROPE B.V. German Branch Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany </p>	<p> Tel : +49-2102-486-0 Fax : +49-2102-486-7780 </p>
UK	<p> MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K. </p>	<p> Tel : +44-1707-28-8780 Fax : +44-1707-27-8695 </p>
Ireland	<p> MITSUBISHI ELECTRIC EUROPE B.V. Irish Branch Westgate Business Park, Ballymount, Dublin 24, Ireland </p>	<p> Tel : +353-1-4198800 Fax : +353-1-4198890 </p>
Italy	<p> MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Centro Direzionale Colleoni - Palazzo Sirio, Viale Colleoni 7, 20864 Agrate Brianza (MB), Italy </p>	<p> Tel : +39-039-60531 Fax : +39-039-6053-312 </p>
Spain	<p> MITSUBISHI ELECTRIC EUROPE, B.V. Spanish Branch Carretera de Rubi, 76-80-Apdo. 420, E-08190 Sant Cugat del Valles (Barcelona), Spain </p>	<p> Tel : +34-935-65-3131 Fax : +34-935-89-1579 </p>
France	<p> MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets, 92741 Nanterre Cedex, France </p>	<p> Tel : +33-1-55-68-55-68 Fax : +33-1-55-68-57-57 </p>
Czech Republic	<p> MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch, Prague Office Pekarska 621/7, 155 00 Praha 5, Czech Republic </p>	<p> Tel : +420-255-719-200 </p>
Poland	<p> MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch ul. Krakowska 48, 32-083 Balice, Poland </p>	<p> Tel : +48-12-347-65-00 </p>
Sweden	<p> MITSUBISHI ELECTRIC EUROPE B.V. (Scandinavia) Hedvig Mollersgata 6, 223 55 Lund, Sweden </p>	<p> Tel : +46-8-625-10-00 Fax : +46-46-39-70-18 </p>
Russia	<p> MITSUBISHI ELECTRIC (RUSSIA) LLC St. Petersburg Branch Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; 195027 St. Petersburg, Russia </p>	<p> Tel : +7-812-633-3497 Fax : +7-812-633-3499 </p>
Turkey	<p> MITSUBISHI ELECTRIC TURKEY A.S. Umraniye Branch Serifali Mah. Kale Sok. No:41 34775 Umraniye - Istanbul, Turkey </p>	<p> Tel : +90-216-969-2500 Fax : +90-216-661-4447 </p>
UAE	<p> MITSUBISHI ELECTRIC EUROPE B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E. </p>	<p> Tel : +971-4-3724716 Fax : +971-4-3724721 </p>
South Africa	<p> ADROIT TECHNOLOGIES 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa </p>	<p> Tel : +27-11-658-8100 Fax : +27-11-658-8101 </p>
China	<p> MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China </p>	<p> Tel : +86-21-2322-3030 Fax : +86-21-2322-3000 </p>
Taiwan	<p> SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan </p>	<p> Tel : +886-2-2299-2499 Fax : +886-2-2299-2509 </p>
Korea	<p> MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. 7F to 9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea </p>	<p> Tel : +82-2-3660-9569 Fax : +82-2-3664-8372 </p>
Singapore	<p> MITSUBISHI ELECTRIC ASIA PTE. LTD. 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943 </p>	<p> Tel : +65-6473-2308 Fax : +65-6476-7439 </p>
Thailand	<p> MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand </p>	<p> Tel : +66-2682-6522-31 Fax : +66-2682-6020 </p>
Vietnam	<p> MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam </p>	<p> Tel : +84-28-3910-5945 Fax : +84-28-3910-5947 </p>
Indonesia	<p> PT. MITSUBISHI ELECTRIC INDONESIA Gedung Jaya 8th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia </p>	<p> Tel : +62-21-31926461 Fax : +62-21-31923942 </p>
India	<p> MITSUBISHI ELECTRIC INDIA PVT. LTD. Pune Branch Emerald House, EL-3, J Block, M.I.D.C., Bhosari, Pune-411026, Maharashtra, India </p>	<p> Tel : +91-20-2710-2000 Fax : +91-20-2710-2100 </p>
Australia	<p> MITSUBISHI ELECTRIC AUSTRALIA PTY. LTD. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia </p>	<p> Tel : +61-2-9684-7777 Fax : +61-2-9684-7245 </p>

MITSUBISHI ELECTRIC CORPORATION
HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
www.MitsubishiElectric.com