

MITSUBISHI

A1SJ71UC24-R4/A1SJ71C24-R4

Computer Link Module

MITSUBISHI

General-Purpose PROGRAMMABLE CONTROLLER

User's Manual

(Hardware)

Thank you for buying the Mitsubishi general-purpose programmable controller MELSEC-A Series.

Prior to use, please read this manual thoroughly and familiarize yourself with the product.



MODEL	A1SJ71C24-R4(H/W)- U-E
MODEL CODE	13JE52
IB(NA)-66491-D (0902) MEE	

● SAFETY PRECAUTIONS ●

(Read these precautions before using.)


When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in the manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual used for a description of the programmable controller system safety precautions.


These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]

DANGER

- When performing the control of the programmable controller in operation (especially changing data, program and operation status (Remote RUN/STOP)) by connecting a personal computer, etc. to the special function module, configure an interlock circuit in a sequence program so the safety of the overall system is always maintained.
Particularly in the above described control for a remote site programmable controller from an external device, troubles occurring on the programmable controller side may not be immediately handled due to a data communication error. Construct an interlock circuit in the sequence program and determine between the external device and programmable controller CPU the system's error handling procedure and other items regarding data communication errors.

CAUTION

- Do not bunch the control wires or communication cables with the main circuit or power wires, or install them close to each other.
They should be installed 100 mm (3.9 inch) or more from each other.
Not doing so could result in noise that would cause malfunction.

[INSTALLATION PRECAUTIONS]

CAUTION

- Use the programmable controller in the environment given in the general specifications section of the applicable User's Manual for the CPU module used.

Using this programmable controller in an environment outside the range of the general specifications could result in electric shock, fire, malfunction, and damage to or deterioration of the product.

- Shut off the external power supply for the system in all phases before wiring.
If you do not switch off the external power supply, it will cause electric shock or damage to the product.
- Insert the tabs at the bottom of the module into the mounting holes in the base module, and tighten the module installation screws with the specified torque.
If the module is not properly installed it may result in malfunction, failure or fallout.
- Tighten the screw within the range of specified torque.
If the screw are loose, it may result in fallout, short circuit or malfunction.
Tightening the screws too far may cause damage to the screw and /or the module, resulting in fallout, short circuit or malfunction.
- Do not directly touch the module's conductive parts or electronic components. Doing so could cause malfunction or failure in the module.
- Perform correct pressure-displacement, crimp-contact or soldering for wire connections using the tools specified by the manufactures.
Attach connectors to the module securely.

[WIRING PRECAUTIONS]

CAUTION

- Be sure that the communication cable connected to the module is kept in a duct or fixed with cramps.
Failure to do so may cause a damage to the module or cables due to dangling, shifting or inadvertent handling of cables, or misoperation because of bad cable contacts.
- Before connecting the cables, check the type of interface to be connected. Connection, or erroneous wiring to the wrong interface may damage the module and external device.
- When connecting an external device to RS-422 interface of this module, do not connect a device that must receive power from this module. The module or external device may be damaged.
- Tighten the terminal screw within the range of specified torque. If the screws are loose it may result in short circuit or malfunction. Tightening the screws too far may cause damage to the screw and/or the module, resulting in fallout, short circuit or malfunction.
- Do not grab on the cable when removing the communication cable connected to the module.
When removing the cable without connector, loose the screw on the side that is connected to the module.
Pulling the cable that is still connected to the module may cause malfunction or damage to the module or cable due to bad cable contacts.
- Be sure there are no foreign substances such as sawdust or wiring debris inside the unit.
Such debris could cause fire, damage or malfunction.

[STARTING AND MAINTENANCE PRECAUTION]

DANGER

- Do not touch the terminals while the power is on.
Doing so may cause malfunction.
- Always switch OFF the external supply power used by the system in all phases before cleaning or retightening screws.
If you do not switch off the external power supply, it will cause failure or malfunction of the module.
If the screws are loose, it may result in fallout, short circuit or malfunction.
Tightening the screws too far may cause damage to the screws and/ or the module, resulting in fallout, short circuit or malfunction.

CAUTION

- Do not disassemble or modify the modules.
Doing so could cause failure, malfunction, injury or fire.
- Shut off the external power supply for the system in all phases before mounting or removing the module.
If you do not switch off the external power supply, it will cause failure or malfunction of the module.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body.
Not doing so may cause a failure or malfunction of the module.

[OPERATION PRECAUTIONS]

DANGER

- Do not write data to the "system area" in the buffer memory of the special function module.
Also, do not output (or turn on) a "use prohibited" signal from the programmable controller CPU to the special function module. If data is written to the "system area" or if the "use prohibited" signal is output, there is a risk that the programmable controller system will operate incorrectly.

CAUTION

- Before performing the control of the programmable controller in operation (especially changing data, program and operation status (Remote RUN/STOP)) by connecting a personal computer, etc. to the special function module, read User's Manual (Com. link func. /Print. func.) carefully and confirm if the overall safety is maintained.
Failure to perform correct operations to change data, program or the status may result in system malfunction, machine damage or an accident.

[DISPOSAL PRECAUTIONS]

CAUTION

- When disposing the product, treat it as industrial waste.

About Manuals

The following product manuals are available. Please use this table as a reference to request the appropriate manual as necessary.

Related Manuals

Manual Names	Manual No. (Model Code)
Computer Link Module Guide Book	SH-3510 (13JE76)
Computer Link Module (Com. link func. /Print. func.) User's Manual	SH-3511 (13JE77)

When using this module, be sure to read Computer Link Module User's Manual (Com. link func. /Print. func.) as well as this manual.

A1SJ71UC24-R4 computer link function is the same as AJ71UC24.

When you refer to the following manual to use A1SJ71UC24-R4, replace the module model name to refer.

- Computer Link Module User's Manual (Com. link func. /Print. func.)
..... Version C or before

AJ71UC24 → A1SJ71UC24-R4

Conformation to the EMC Directive and Low Voltage Instruction

For details on making Mitsubishi programmable controller conform to the EMC directive and low voltage instruction when installing it in your product, please see Chapter 3, "EMC Directive and Low Voltage Instruction" of the User's Manual (Hardware) of the programmable controller CPU to use.

The CE logo is printed on the rating plate on the main body of the programmable controller that conforms to the EMC directive and low voltage instruction.

By making this product conform to the EMC directive and low voltage instruction, it is not necessary to make those steps individually.

1. Overview

This manual is intended for installing the computer link module and performing wiring for external devices.

After unpacking the module, check that the following products are included:

Model name	Item name	Quantity
A1SJ71UC24-R4	A1SJ71UC24-R4 computer link module	1
	Terminal resistor for RS-422 communication 330 Ω 1/4 W (orange-orange-brown □)	2
	Terminal resistor for RS-485 communication 110 Ω 1/2 W (brown-brown-brown □)	2
A1SJ71C24-R4	A1SJ71C24-R4 computer link module	1
	Terminal resistor for RS-422 communication 330 Ω 1/4 W (orange-orange-brown □)	2
	Terminal resistor for RS-485 communication 110 Ω 1/2 W (brown-brown-brown □)	2


* In the explanation hereafter, the computer link/multi-drop link module is abbreviated as the "C24" except when differentiate specially.

* The following accesses to the programmable controller CPU with a dedicated protocol of the computer link function are possible by using A1SJ71UC24-R4.

- Access to the device extended by AnACPU, AnUCPU and A2US(H)CPU.
- Access to the other stations via MELSECNET/10.

Other specifications are the same as A1SJ71C24-R4.

* Differentiate the terminal resistors as follows:



2. Transmission Specifications

The following table indicates the transmission specifications when using the C24 computer link function.

For general specifications of the UC24, see the user's manual for the CPU module used.

Item		Specification	
Interface		Conform to RS-422/485	
Transmission method	Dedicated protocol	Half duplex communication method *1	
	No protocol/ Bidirectional	1 : 1 connection	Full duplex communication method
		1 : n, m : n connection	Half duplex communication method
Synchronization system	Start-stop synchronization method		
Transmission speed	300, 600, 1200, 2400, 4800, 9600, 19200 bps (Selected via the switch)		
Data format	Start bit	1	
	Data bit	7 or 8	Selected via the switch
	Parity bit	1 or none	
	Stop bit	1 or 2	
Access cycle	Processing for one request is performed during the END processing of the sequence program. Therefore, the access cycle is one scan time.		
Error detection	Parity check yes (odd/even) or no		
	Sum check yes or no		
DTR/DSR control (ER/DR)	No		
DC1/DC3, DC2/DC4 control	Yes/No (selected by setting to the buffer memory)		
Line configuration (external device: programmable controller CPU)	Dedicated protocol	1 : 1, 1 : n, m : n	
	No protocol	1 : 1, 1 : n	
	Bidirectional	1 : 1	
Transmission distance	RS-422/485 Overall distance 500m (1640 ft.) or less		
Current consumption	5VDC 0.1A		
Occupied I/O points	32 points *2		
Weight	0.25 kg(0.56 lb.)		


*1 When data communication can be performed using the full duplex transmission method, this transmission method is used whenever the on-demand function is used.

*2 When performing I/O assignment using the GPP function, set as special 32 points.

The model name to register when using the dedicated commands, the following model name should be set depending on C24 and programmable controller CPU mounted to C24.


Programmable controller CPU mounted to C24	Types of C24 to mount	
	A1SJ71UC24-R4	A1SJ71C24-R4
AnUCPU	A1SJ71UC24	AJ71C24S3
AnACPU	AJ71C24S3	
Other than AnU/AnACPU	(Model name setting is not necessary as the dedicated command cannot be used.)	

3. Name of Each Part and Setting



Number	Name	Description	
1)	Indicator LEDs	RUN	Normal operation indicator Normal : lit Error : unlit
		SD	Transmission status Data being transmitted : flashing
		RD	Reception status Data being received : flashing
		CPU	Communication Status with CPU main module. Communicating with programmable controller CPU : flashing
		MD	Multi-droplink Multi-droplink : lit Computer link : unit
		NEU	Neutral status Transmission sequence initial status (waiting for ENQ) : lit ENQ reception complete : unlit
			RUN <input type="checkbox"/> NEU <input type="checkbox"/> SCAN SD <input type="checkbox"/> ACK <input type="checkbox"/> SET E. RD <input type="checkbox"/> NAK <input type="checkbox"/> SCAN E. CPU <input type="checkbox"/> C/N <input type="checkbox"/> SIO E. <input type="checkbox"/> MD P/S <input type="checkbox"/> <input type="checkbox"/> PRO <input type="checkbox"/> ST.DWN <input type="checkbox"/> SIO <input type="checkbox"/> <input type="checkbox"/> COM <input type="checkbox"/> MD L



Number	Name	Description	
1)	Indicator LEDs (continued) RUN <input type="checkbox"/> NEU <input type="checkbox"/> SCAN SD <input type="checkbox"/> ACK <input type="checkbox"/> SET E. RD <input type="checkbox"/> NAK <input type="checkbox"/> SCAN E. CPU <input type="checkbox"/> C/N <input type="checkbox"/> SIO E. <input type="checkbox"/> MD P/S <input type="checkbox"/> <input type="checkbox"/> PRO <input type="checkbox"/> ST.DWN <input type="checkbox"/> SIO <input type="checkbox"/> <input type="checkbox"/> COM <input type="checkbox"/> MD L	ACK	ACK transmission status ACK transmitted : lit NAK transmitted : unlit
		NAK	NAK transmission status NAK transmitted : lit ACK transmitted : unlit
		C/N	Result of communication with programmable controller CPU Error in communication with the programmable controller CPU : lit Normal communication : unlit
		P/S	Parity/sum check error Parity/sum check error : lit Normal : unlit
		PRO	Protocol error Normal protocol error : lit Normal : unlit
		SIO	SIO error When overrun or framing error : lit When received data has been discarded due to OS receive area full : lit Normal : unlit
		COM	Computer link Computer link or multi-drop link (local station) : lit Multi-drop link (master station) : unlit

Number	Name	Description			
2)	Transmission setting switch 	Transmission settings (all are set to OFF at the time of shipment)			
		SW	Setting item	Status	
				ON	OFF
		01	Not used	—	—
		02	Computer link/multi-drop link selection	Computer link	Setting impossible
		03	A1ADP-SP setting *1	A1ADP-SP used	A1ADP-SP not used
		04	Setting for write during RUN	Enabled	Disabled
		05	Transmission speed setting	See *2	
		06			
		07			
		08	Data bit setting	8 bits	7 bits
		09	Parity bit setting	YES	NO
		10	Even/odd parity setting	Even	Odd
		11	Stop bit setting	2 bits	1 bit
12	Sum check setting	YES	NO		

*1 This setting is available when software version of the A1SJ71UC24-R4 is X or later, and not available for the A1SJ71C24-R4.

*2 Transmission speed settings

	Transmission speed (unit: bps)							
Setting switch	300	600	1200	2400	4800	9600	19200	Setting prohibited
SW05	OFF	ON	OFF	ON	OFF	ON	OFF	ON
SW06	OFF	OFF	ON	ON	OFF	OFF	ON	ON
SW07	OFF	OFF	OFF	OFF	ON	ON	ON	ON

Number	Name	Description																						
3)	Station number setting switch 	Module station number setting (set to 00 at time of shipment) <Setting range> 00 to 31 X10 — set the station number ten's place X1 — set the station number unit's place																						
4)	Mode setting switch 	<table border="1"> <thead> <tr> <th colspan="2" data-bbox="453 569 898 588">Mode setting (set to 0 at the time of shipment)</th> </tr> <tr> <th data-bbox="453 588 505 612">Mode</th> <th data-bbox="505 588 898 612">Setting contents</th> </tr> </thead> <tbody> <tr> <td data-bbox="453 612 505 642">0</td> <td data-bbox="505 612 898 642">Use prohibited</td> </tr> <tr> <td data-bbox="453 642 505 722">1 to 3</td> <td data-bbox="505 642 898 722">Use prohibited</td> </tr> <tr> <td data-bbox="453 722 505 746">4</td> <td data-bbox="505 722 898 746">Non procedure mode</td> </tr> <tr> <td data-bbox="453 746 505 771">5</td> <td data-bbox="505 746 898 771">Type 1 dedicated protocol mode</td> </tr> <tr> <td data-bbox="453 771 505 796">6</td> <td data-bbox="505 771 898 796">Type 2 dedicated protocol mode</td> </tr> <tr> <td data-bbox="453 796 505 821">7</td> <td data-bbox="505 796 898 821">Type 3 dedicated protocol mode</td> </tr> <tr> <td data-bbox="453 821 505 845">8</td> <td data-bbox="505 821 898 845">Type 4 dedicated protocol mode</td> </tr> <tr> <td data-bbox="453 845 505 1006">9 to E</td> <td data-bbox="505 845 898 1006">Use prohibited</td> </tr> <tr> <td data-bbox="453 1006 505 1030">F</td> <td data-bbox="505 1006 898 1030">For module test</td> </tr> </tbody> </table>	Mode setting (set to 0 at the time of shipment)		Mode	Setting contents	0	Use prohibited	1 to 3	Use prohibited	4	Non procedure mode	5	Type 1 dedicated protocol mode	6	Type 2 dedicated protocol mode	7	Type 3 dedicated protocol mode	8	Type 4 dedicated protocol mode	9 to E	Use prohibited	F	For module test
Mode setting (set to 0 at the time of shipment)																								
Mode	Setting contents																							
0	Use prohibited																							
1 to 3	Use prohibited																							
4	Non procedure mode																							
5	Type 1 dedicated protocol mode																							
6	Type 2 dedicated protocol mode																							
7	Type 3 dedicated protocol mode																							
8	Type 4 dedicated protocol mode																							
9 to E	Use prohibited																							
F	For module test																							
5)	RS-422/485 interface	RS-422/485 interface for external device connection																						

4. Loading and Installation

This section explains precautionary items regarding handling of the C24 from unpacking up to installation, and the installation environment that are common to all modules.

See the user's manual for the programmable controller CPU module used for further details regarding module loading and installation.

4.1 Precautionary Items when Handling

The following explains precautionary items when handling the module:

- (1) Do not drop or apply severe shock to the module case since it is made of resin.
- (2) Tighten the module installation screws within the specified torque range as follows:

Screw Area	Tightening Torque Range
RS-422 / 485 terminal block terminal screws (M3.5 screw)	59 to 88N · cm (5.2 to 7.8lb · inch)
Module installation screws (M4 screw)	78 to 118N · cm (6.9 to 10.4lb · inch)
RS-422 / 485 terminal block installation screws (M3.5 screw)	49 to 78N · cm (4.3 to 6.9lb · inch)


4.2 Installation Environment

Avoid the following conditions for the installing location of the AnS Series programmable controller:


- (1) Location where the ambient temperature exceeds the range of 0 to 55 °C.
- (2) Location where the ambient humidity exceeds the range of 10 to 90% RH.
- (3) Location where condensation occurs due to a sudden temperature change.
- (4) Location where corrosive or inflammable gas exists.
- (5) Location where a lot of conductive powdery substance such as dust and iron filing, oil mist, salt, or organic solvent exists.
- (6) Location exposed to direct sunlight.
- (7) Location where strong electric fields or magnetic fields form.
- (8) Location where vibration or impact is directly applied to the main module.

5. External Wiring

The standard method for connecting the RS-422/485 line is shown below.



(Function block diagram for the C24)



Point

If the C24 serves as the first or the last station on the RS-422/485 line, connect a terminal resistor as shown below to the RS-422/485 interface according to the communication specification.


When a terminal resistor is not connected, an error may result during data communication.

- For RS-422 communication 330 Ω , 1/4W
- For RS-485 communication 110 Ω , 1/2W

- (1) When an external device and the C24 are connected in 1:1 or 1:n, connect a terminal resistor between SDA and SDB as well as between RDA and RDB.
- (2) When an external device and C24 are connected in m:n, connect a terminal resistor between RDA and RDB.


The **R** in the following wiring diagram represents a terminal resistor.

- (1) Example of connecting external devices and C24 by 1:1




- (2) Example of connecting external devices and C24 by 1:n

* Connecting external devices and C24 modules via RS-485



- (3) Example of connecting external devices and C24 by m:n


* Connecting external devices and C24 modules via RS-485



- (4) Countermeasure for data reception errors in the external device with the RS-422 or RS-422/485 connection

During data communication with external devices via C24 RS-422/485 interface, if there is a possibility that the external device receives an error data, install pull-up and pull-down resistors to the external device side (about $4.7\text{k}\Omega$, $1/4\text{ W}$ as a reference of resistor value).

Installation of pull-up and pull-down resistors will prevent data reception errors.



Point

Installation of pull-up and pull-down resistors will prevent data reception errors.


Remarks

The following explains the case in which pull-up and pull-down resistors are not installed to the external device:

- 1) When none of the stations are receiving, the transmission line is in a state of high impedance, causing the transmission line to become unstable due to noise and a possibility that the data will be received incorrectly at the external device.
When this happens, a parity error or framing error is likely to occur. Therefore, skip the data when the error has occurred.
- 2) For data communication using the dedicated protocol, the first data will be determined based on the format used by the user.
Skip the data received prior to the first data as determined.

(5) Precautionary items when wiring


- 1) When connecting the SG and FG signals of the C24 to an external device, follow the specification of the external device.
- 2) If data communication cannot be performed normally due to external noise even if the wiring is done according to this section, perform wiring as follows:
(Connect nnA and nnB in each signal of the connector cable as a pair.)



- * When data communication cannot be performed normally even if this wiring is done, connect the connector cable shield to either one of the FG terminals on the connected device. (when connect to the external device, refer to the handling manual of the external device.)

Point
(1) In the explanation of the terminal resistor setting/connection in this section, when an RS-232C - RS-422 converter or other equipment is used for the device which serves as either of the line terminating stations, setting and wiring for a terminal resistor is required on the converter (or the equipment).
(2) The devices connected to the C24's RS-422/RS485 interface must use all RS-422 or all RS-485, including 1:n and m:n connections.

6. External Dimensions



- R1 (Bending radius near terminal block) : Cable diameter × 4
 r1 (Bending radius near crimp contact) : Can be connected in a range without extreme bend

External dimensions of A1S71UC24-R4 and A1SJ71C24-R4 are the same. The diagram above is of A1S71UC24-R4 external dimensions.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A. Tel : +1-847-478-2100	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	China	Mitsubishi Electric Automation (Shanghai) Ltd. 4/F Zhi Fu Plaza, No.80 Xin Chang Road, Shanghai 200003, China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd.Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire., AL10 8XB, U.K. Tel : +44-1707-276100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gayang-dong, Gangseo-ku Seoul 157-200, Korea Tel : +82-2-3660-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, I-20041 Agrate Brianza., Milano, Italy Tel : +39-039-60531	Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road #05-01/02, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2-517-1326
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045 Jakarta, 11050 Indonesia Tel : +62-21-6630833
South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-928-2000	India	Messung Systems Pvt. Ltd. Electronic Sadan NO:III Unit No15, M.I.D.C Bhosari, Pune-411026, India Tel : +91-20-2712-3130
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777



MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHYOGA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.
Printed in Japan on recycled paper.