


MITSUBISHI

CC-Link System Master/Local Module

Type AJ61BT11/A1SJ61BT11 User's Manual



Mitsubishi Programmable Controller

● SAFETY PRECAUTIONS ●

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only.

For the safety precautions of the programmable controller system, refer to the user's manual for the CPU module used.

In this manual, the safety precautions are classified into two levels: "⚠ WARNING" and "⚠ CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety. Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Design Precautions]

⚠ WARNING

- For the operating status of each station after a communication failure in the data link, refer to Chapter 5 in this manual.
- The master station or local station cannot detect errors when a station specified as an error-invalidated station becomes communication error.

⚠ CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100mm (3.94 inches) or more between them. Failure to do so may result in malfunction due to noise.

[Installation Precautions]

CAUTION

- Use the module in an environment that meets the general specifications in the user's manual for the CPU module used.
Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- Insert the tabs at the bottom of the module into the holes in the base unit before mounting the module. (To fix an AnS series module to the base unit, tighten the screws within the specified torque range).
Incorrect mounting may cause malfunction, failure or drop of the module.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module.
Failure to do so may result in damage to the product.
- Do not directly touch any conductive parts and electronic components of the module.
Doing so can cause malfunction or failure of the module.

[Wiring Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before wiring.
Failure to do so may result in electric shock or damage to the product.
- After wiring, attach the included terminal cover to the module before turning it on for operation.
Failure to do so may result in malfunction.

CAUTION

- Tighten the terminal screw within the specified torque range.
Undertightening the terminal screws can cause short circuit or malfunction.
Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Prevent foreign matter such as dust or wire chips from entering the module.
Such foreign matter can cause a fire, failure, or malfunction.
- Place the cables in a duct or clamp them.
If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact.
- Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may cause malfunction due to noise.
- Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.

[Wiring Precautions]

CAUTION

- When disconnecting the cable from the module, do not pull the cable by the cable part.
For the cable with connector, hold the connector part of the cable.
When removing the cable without a connector, loose the screws on the side that is connected to the module.
Failure to do so may result in damage to the module or cable or malfunction due to poor contact.

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on.
Doing so will cause electric shock.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws or module fixing screws.
Failure to do so may result in electric shock.
Undertightening can cause drop of the screw, short circuit or malfunction.
Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.

CAUTION

- Do not disassemble or modify the module.
Doing so may cause failure, malfunction, injury, or a fire.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module.
Failure to do so may cause the module to fail or malfunction.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module more than 50 times (IEC 61131-2 compliant) respectively.
Exceeding the limit of 50 times may cause malfunction.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body.
Failure to do so may cause the module to fail or malfunction.

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.

• CONDITIONS OF USE FOR THE PRODUCT •

- (1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi representative in your region.

REVISIONS

*The manual number is noted at the lower left of the back cover.

Print Date	*Manual Number	Revision
Nov. 1996	IB (NA)-66721-A	First printing
Jan. 1997	IB (NA)-66721-B	<p>Addition Section 3.2.1, 4.12.3, 13.2</p> <p>Correction Chapter 1, Section 1.1, 3.2, 3.4.1, 7.3, 7.6.3, 8.3.2, 13.1, 13.5.8</p>
Aug. 1997	IB (NA)-66721-C	<p>Addition Section 1.1, 5.3.4, 5.4, Chapter 14, 15, 16</p> <p>Correction Section 1.4, 1.5, 2.1, 2.2.1, 2.2.3, 3.2, 3.2.1, 3.4.1, 3.4.2, 5.1, 7.1, 7.2.1, 7.3, 7.5, 7.6.1, 7.6.3, 7.6.4, 7.7.1, 7.7.2, 7.8</p>
Jan. 1998	IB (NA)-66721-D	<p>Addition model Section 1.4, 2.2.3</p> <p>Correction Section 1.1, 3.3, 3.4.1, 3.5.1, 3.5.2, 4.3, 4.5, 5.2, 7.6.4, 13.1, Chapter 14, 15.1, 15.2.1, 15.6, 15.6.1, 15.6.3, 15.6.4, 15.6.5, 15.6.10, 16.2.3, App2</p>
Mar. 2000	IB (NA)-66721-E	<p>Addition model Section 2.2.3</p> <p>Addition Section 7.6, 15.7</p> <p>Correction SAFETY PRECAUTIONS, Section 1.1, 1.5, 3.3, 3.5.1, 5.1, 5.2, 5.4.3, 7.3, 7.5, 8.3.2, 10.2.2, 12.2.2, 13.3, Chapter 14, Section 15.1, 15.2.1, 15.5.2, 15.5.4, 15.5.5, 15.6, 15.8, Chapter 16</p>
Jul. 2000	IB (NA)-66721-F	<p>Addition Section 2.2.4, 3.2.2</p> <p>Correction Section 1.4, 2.2.1, 3.2, 3.2.1, 3.3, 3.4.2, 3.5.1, 7.3, 7.6.2, 7.7.4, 8.3.1, 9.1.1, 10.1.1, 10.2.2, 11.1.1, 11.1.2, 12.1.1, 12.1.4, 15.2.1, App1.1, App1.2</p>
Jul. 2001	IB (NA)-66721-G	<p>Addition Section 8.2</p> <p>Correction Section 2.2.3, 3.4.1, 3.4.2, 4.12.1, 5.4, 5.4.1, 5.4.2, 5.4.3, 7.2.1, 7.3, 7.5, 8.4.2, 9.1.1, 9.2.1, 10.1.1, 10.2.1, 11.1.1, 11.1.2, 11.2.1, 12.1.1, 12.1.4, 12.2.1, 13.1, 13.3, 13.4.2, 13.4.3, Chapter 14, Section 15.1, 15.2.1, 15.6, 15.7.1</p>

*The manual number is noted at the lower left of the back cover.

Print Date	*Manual Number	Revision
Jul. 2002	IB (NA)-66721-H	<p>Correction</p> <p>Section 2.2.3, 3.3, 3.4.2, 4.10, 8.1, 13.3, 15.6</p>
Oct. 2002	IB (NA)-66721-I	<p>Correction</p> <p>Section 3.1, 3.5.2</p>
Oct. 2003	IB (NA)-66721-J	<p>Addition</p> <p>Conformation to the EMC Directive and Low Voltage Instruction</p> <p>Correction</p> <p>SAFETY PRECAUTIONS, Section 3.5.1, 7.8, 7.9, 13.3</p>
Apr. 2006	IB (NA)-66721-K	<p>Correction</p> <p>SAFETY PRECAUTIONS, Conformation to the EMC Directive and Low Voltage Instruction, Chapter 1, Section 2.2.2, 2.2.4, 3.2, 3.4.1, 3.4.2, 4.1, 4.8, 6.3, 7.5, 13.1, 13.3, 15.2.1, App2</p>
Sep. 2007	IB (NA)-66721-L	<p>Correction</p> <p>Section 1.4, 1.5, 2.1, 2.2.3, 3.5.2, 4.4, 7.3, 7.7.4, 8.4.1, App1.2</p>
Sep. 2009	IB (NA)-66721-M	<p>"PLC" and "PC" were changed to "programmable controller".</p> <p>Correction</p> <p>SAFETY PRECAUTIONS, Compliance with the EMC and Low Voltage Directives, Chapter 1, Section 1.5, 2.2.4, 3.1, 3.3, 3.4.2, 7.2.1, 7.3, 7.5, 7.6.2, 13.3, 15.2.1, App 2</p>
Apr. 2012	IB (NA)-66721-N	<p>Correction</p> <p>SAFETY PRECAUTIONS, COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES, Section 3.1, 3.4.1, 3.5.1, 7.5, 8.4.2, 13.3</p> <p>Addition</p> <p>CONDITIONS OF USE FOR THE PRODUCT</p>
Mar. 2016	IB (NA)-66721-O	<p>Correction</p> <p>Section 2.2.4, 7.3, 8.4.1, 8.4.2, 10.2.2, 12.2.1, 13.3, App1</p>

Japanese Manual Version SH-3603-O

This manual does not imply guarantee or implementation right for industrial ownership or implementation of other rights. Mitsubishi Electric Corporation is not responsible for industrial ownership problems caused by use of the contents of this manual.

INTRODUCTION

Thank you for purchasing the MELSEC-A Series programmable controller.

Before using the product, please read this manual thoroughly to gain an understanding of its functions so you can use it properly.

Please forward a copy of this manual to the end user.

Table of Contents

SAFETY PRECAUTIONS.....	A- 1
CONDITIONS OF USE FOR THE PRODUCT	A- 4
REVISIONS.....	A- 5
INTRODUCTION.....	A- 7
MANUAL.....	A-13
COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES	A-13
1. Overview 1- 1 to 1-15	
1.1 How to Use This Manual.....	1- 3
1.2 Characteristics.....	1- 4
1.3 Communication Overview.....	1- 9
1.3.1 Communication between the master station and remote I/O station.....	1- 9
1.3.2 Communication between the master station and remote device station.....	1-10
1.3.3 Communication between the master station and local station.....	1-11
1.3.4 Compound system communication.....	1-12
1.4 Number of Occupied Stations and Station Number, Number of Modules and Number of Stations...	1-13
1.5 Generic Terms and Abbreviations	1-14
2. System Configuration 2- 1 to 2- 8	
2.1 Total Configuration.....	2- 1
2.2 Applicable System.....	2- 2
2.2.1 Applicable CPU and number of modules that can be installed.....	2- 2
2.2.2 Precautions when configuring a system.....	2- 3
2.2.3 List of system equipment restricted by master/local module versions	2- 6
2.2.4 About Ver. 1.10.....	2- 7
3. Specification..... 3- 1 to 3-37	
3.1 General Specification.....	3- 1
3.2 Performance Specifications	3- 1
3.2.1 Maximum overall cable distance (for Ver. 1.00).....	3- 2
3.2.2 Maximum overall cable distance (for Ver. 1.10).....	3- 4
3.3 CC-Link Dedicated Cable.....	3- 5
3.4 I/O Signals to the Programmable Controller CPU.....	3- 6
3.4.1 I/O signal list	3- 6
3.4.2 I/O signal details	3- 8
3.5 Buffer Memory.....	3-18
3.5.1 Buffer memory list.....	3-18

3.5.2 Buffer memory details.....	3-21
----------------------------------	------

4. Functions.....	4- 1 to 4-30
-------------------	--------------

4.1 Function List	4- 1
4.2 Communication Between the Master Station and Remote I/O Station	4- 2
4.3 Communication Between the Master Station and Remote Device Station	4- 4
4.4 Communication Between the Master Station and Local Station	4-10
4.5 Communication in Compound Systems	4-16
4.6 Reserved Station Function.....	4-22
4.7 Error Invalid Station Function.....	4-23
4.8 Data Link Status Setting when the Master Station Programmable Controller CPU has an Error	4-24
4.9 Setting the Status of Input Data from a Data Link Faulty Station	4-25
4.10 Module Reset Function from a Sequence Program.....	4-26
4.11 Data Link Stop/Restart	4-27
4.12 RAS Function	4-28
4.12.1 Automatic return function	4-28
4.12.2 Slave station cut-off function	4-29
4.12.3 Station number overlap checking function.....	4-30

5. Data Link Processing Time	5- 1 to 5-24
------------------------------------	--------------

5.1 Status of Each Station when an Error has Occurred	5- 1
5.2 Link Scan Time.....	5- 4
5.3 Transmission Delay Time.....	5- 5
5.3.1 Master station ↔ remote I/O station.....	5- 5
5.3.2 Master station ↔ remote device station	5- 7
5.3.3 Master station ↔ local station.....	5-11
5.3.4 Master station ↔ intelligent device station	5-15
5.4 Dedicated Instruction Processing Time	5-16
5.4.1 Master station ↔ local station	5-16
5.4.2 Local station ↔ local station	5-20
5.4.3 Master station ↔ intelligent device station	5-22

6. Parameter Setting.....	6- 1 to 6-10
---------------------------	--------------

6.1 Procedure from Parameter Setting to Data Link Startup	6- 1
6.1.1 Relationship between buffer memory, E ² PROM and internal memory	6- 1
6.1.2 Procedure from parameter setting to data link start	6- 3
6.2 Parameter Settings.....	6- 4
6.3 Setting from a Sequence Program	6- 5

7. Data Link Procedure.....7- 1 to 7-24

7.1 Data Link Procedure..... 7- 1

7.2 Installation and Setting 7- 2

 7.2.1 Precautions when handling the module..... 7- 2

 7.2.2 Setting environment..... 7- 3

7.3 Name of Each Part and Settings 7- 4

7.4 Checking Module Condition (Hardware Test) 7- 9

7.5 Module Wiring with CC-Link Dedicated Cable 7-11

7.6 T-Branch Connection with the CC-Link Dedicated Cable..... 7-12

 7.6.1 T-Branch system configuration 7-12

 7.6.2 T-Branch communication specifications list..... 7-12

7.7 Switch Settings 7-14

 7.7.1 Station number setting (master station, local station, standby master station, remote station, and intelligent device station)..... 7-14

 7.7.2 Mode setting 7-16

 7.7.3 Transmission speed setting 7-16

 7.7.4 Condition setting 7-17

7.8 Checking the Connection Condition (Line Test)..... 7-18

 7.8.1 Checking connection and communication status with remote station/intelligent device station/local station/standby master station (Line Test 1) 7-18

 7.8.2 Checking communication status with specific remote station/intelligent device station/local station/standby master station (Line Test 2) 7-20

7.9 Checking Parameters (Parameter Confirmation Test)..... 7-22

8. Programming8- 1 to 8-22

8.1 Precautions when Programming..... 8- 1

8.2 Precautions for Registering Parameters to E²PROM..... 8- 3

 8.2.1 Target module and versions..... 8- 3

 8.2.2 Precautions 8- 3

 8.2.3 Program for registering parameters to E²PROM 8- 4

8.3 Programming Procedure 8- 6

 8.3.1 Communication between the master station and remote I/O station..... 8- 6

 8.3.2 Communication between the master station and remote device station 8- 7

 8.3.3 Communication between the master station and local station..... 8- 8

 8.3.4 Communication in a compound system..... 8-10

8.4 Link Special Relay/Register (SB/SW)..... 8-12

 8.4.1 Link special relay (SB)..... 8-12

 8.4.2 Link special register (SW) 8-16

9. Communication Between the Master Station and the Remote I/O Station 9- 1 to 9-12

9.1	System Configuration	9- 1
9.1.1	Setting of the master station.....	9- 2
9.1.2	Setting of the remote I/O station	9- 3
9.2	Creating a Program	9- 4
9.2.1	Program for parameters	9- 4
9.2.2	Communication program	9- 7
9.3	Performing the Data Link	9-10
9.3.1	Confirming the operation by LED display	9-10
9.3.2	Confirming the operation by the program	9-11

10. Communication Between the Master Station and the Remote Device Station..... 10- 1 to 10-14

10.1	System Configuration	10- 1
10.1.1	Setting of the master station	10- 2
10.1.2	Setting of the remote device station.....	10- 3
10.2	Creating a Program	10- 4
10.2.1	Program for parameters	10- 4
10.2.2	Communication program	10- 7
10.3	Performing the Data Link	10-12
10.3.1	Confirming the operation by LED display	10-12
10.3.2	Confirming the operation by the program	10-13

11. Communication Between the Master Station and the Local Station 11- 1 to 11-14

11.1	System Configuration	11- 1
11.1.1	Setting of the master station	11- 2
11.1.2	Setting of the local station	11- 3
11.2	Creating a Program	11- 4
11.2.1	Program for the mater station	11- 4
11.2.2	Local station program	11-10
11.3	Performing the Data Link	11-12
11.3.1	Confirming the operation by LED display	11-12
11.3.2	Confirming the operation by the program	11-13

12. Communication in the Compound System 12- 1 to 12-16

12.1	System Configuration	12- 1
12.1.1	Setting of the master station	12- 2
12.1.2	Setting of the remote I/O station	12- 3
12.1.3	Setting of the remote device station.....	12- 3
12.1.4	Setting of the local station	12- 4
12.2	Creating a Program	12- 5
12.2.1	Program for the master station	12- 5
12.2.2	Local station program	12-13
12.3	Performing the Data Link	12-14
12.3.1	Confirming the operation by LED display	12-14
12.3.2	Confirming the operation by the program	12-16

13. Troubleshooting 13- 1 to 13-18

13.1 Verification when a Trouble Occurs 13- 1
13.2 Troubleshooting when the "ERR" LED on the Master Station is Flashing 13- 4
13.3 Error Codes 13- 6
13.4 LED Display Status 13-12
 13.4.1 When data link is normal 13-12
 13.4.2 When a cable is disconnected 13-12
 13.4.3 When a cable is shorted 13-13
 13.4.4 When the link is stopped at the master station 13-13
 13.4.5 When power supply to a remote I/O station is turned off 13-14
 13.4.6 When the power supply to a remote device station is turned off 13-14
 13.4.7 When the power supply to the local station (Programmable controller CPU) is turned off 13-15
 13.4.8 When the station numbers are duplicate 13-15
 13.4.9 When the transmission speed is set incorrectly 13-16
 13.4.10 When the switch setting is changed during data link 13-16
 13.4.11 When data link is started with the switch set outside the range 13-17
 13.4.12 When the remote I/O station is not set by the parameter (i.e., is set as reserved) 13-17
 13.4.13 When the remote device station is not set by the parameter (i.e., is set as reserved) 13-18
 13.4.14 When the local station is not set by the parameter (i.e., is set as reserved) 13-18

14. Overview (Function Version B or Later) 14- 1 to 14- 2

15. Functions (Function Version B or Later) 15- 1 to 15-16

15.1 List of Functions 15- 1
15.2 Parameter Registration Function 15- 1
 15.2.1 Network parameters 15- 1
 15.2.2 Automatic refresh parameters 15- 3
15.3 Automatic Refresh Function 15- 3
15.4 Scan Synchronous Function 15- 4
 15.4.1 Synchronous mode 15- 4
 15.4.2 Asynchronous mode 15- 5
15.5 Standby Master Function 15- 6
 15.5.1 Operation overview 15- 6
 15.5.2 Settings on using the standby master function 15- 7
 15.5.3 Link special relays/registers (SB,SW) relating to the standby master function 15- 8
 15.5.4 Notes on using the standby master function 15- 9
 15.5.5 Program example on using the standby master function 15-10
15.6 Dedicated Instructions 15-11
15.7 Remote I/O Net Mode 15-12
 15.7.1 Features 15-12
 15.7.2 Software version corresponding to master module and its CPU 15-12
 15.7.3 Set items 15-12
 15.7.4 Link scan time 15-13
 15.7.5 Precaution 15-13

15.8	Temporary Error Invalid Station Specification Function.....	15-14
15.8.1	I/O status of the temporary error invalid station specification	15-14
15.8.2	Link special relay/registers (SB,SW) relating to the temporary error invalid station specification function	15-14
15.8.3	Execution procedure for the temporary error invalid station specification.....	15-16

16.	Communication with the Intelligent Device (Function Version B or Later)	16- 1 to 16- 2
-----	---	----------------

Appendices	App- 1 to App- 4
------------------	------------------

Appendix 1	External Dimensions Diagram	App- 1
1.1	AJ61BT11	App- 1
1.2	A1SJ61BT11.....	App- 2
Appendix 2	Parameter Setting Sheet	App- 3

MANUAL

The manual related to this product is shown below.
Please place an order as needed.

RELEVANT MANUALS

Manual name	Manual number (model code)
AnSHCPU/AnACPU/AnUCPU Programming Manual (Dedicated instructions) Describes the instruction that were extended for AnSHCPU/AnACPU/AnUCPU. (Sold separately)	IB-66251 (13J742)

COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

(1) Method of ensuring compliance

To ensure that Mitsubishi programmable controllers maintain EMC and Low Voltage Directives when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to one of the following manuals.

- User's manual for the CPU module used
- User's manual (hardware) for the CPU module or base unit used


(2) Additional measures

To ensure that this product maintains EMC and Low Voltage Directives, please refer to one of the manuals listed under (1).

1. Overview

The CC-Link system is a system that connects distributed modules such as I/O modules, intelligent function modules, and special function modules using dedicated cables so that these modules can be controlled by a programmable controller CPU. This chapter explains outline of the CC-Link.

- ① By distributing each module to the equipment device such as the conveyor line and machine devices, the wiring conservation of the entire system can be accomplished.
- ② Simple, high-speed communication can be accomplished with modules that handle on/off data such as I/O or numeric data.
- ③ By connecting multiple programmable controller CPUs, a simple distributed system can be configured.
- ④ Connections can be made to different types of devices made by partner manufacturers, giving flexibility to the system.



- Master station Station which controls the remote I/O station, remote device station, and local stations
- Remote I/O station Remote station which handles only on/off data
- Remote device station Remote station which handles both on/off data and numeric data
- Local station Station which has a CPU and can communicate with the master station and other local stations

When applying any of the program examples to the actual system, examine the applicability and confirm that it will not cause system control problems.

After unpacking, please check that the following components are included.

	Product name	Quantity
AJ61BT11 CC-Link System Master/Local Module	AJ61BT11	1
	AJ61BT11 CC-Link System Master/Local Module User's Manual (Hardware)	1
	Terminating resistor 110 Ω , 1/2 W (All brown)	2
	Terminating resistor 130 Ω , 1/2 W (Brown, orange, brown)	2
A1SJ61BT11 CC-Link System Master/Local Module	A1SJ61BT11	1
	A1SJ61BT11 CC-Link System Master/Local Module User's Manual (Hardware)	1
	Terminating resistor 110 Ω , 1/2 W (All brown)	2
	Terminating resistor 130 Ω , 1/2 W (Brown, orange, brown)	2

1.1 How to Use This Manual

The master/local module has the following functions added from the function version B or later. The detailed descriptions of the additional functions are provided in Chapter 14 or later.


- (1) **Scan synchronous function**
Link scan can be executed synchronized with the sequence scan.
- (2) **Standby master function**
With this function, the data link can be continuously executed even if an error occurs in the master station, by automatically switching to the standby master station.
- (3) **Dedicated instructions**
Transient transmission with the intelligent device and local station is possible. In addition, read/write of data with handshake to/from the remote device is feasible.
- (4) **Temporary error invalid station specification function**
By specifying the corresponding remote station as a temporary error invalid station, an error is not detected even if the module is replaced while in communication.
- (5) **Parameter registration function**
Parameters such as total number of connected stations and station information can be set using dedicated instructions.
- (6) **Automatic refresh function**
Data transferred by cyclic transmissions, such as RX and RY, can be refreshed by the END processing to a desired device, when set up with the dedicated instruction.
- (7) **Dedicated instruction (software version J or later)**
Reading and writing of device with respect to the CPU of the specified station are possible.
- (8) **Remote I/O net mode (applicable to software version P or later)**
When the system is configured only with the master station and remote I/O stations, if the remote I/O net mode is used, the setting of the network parameters will be unnecessary and the link scanning time will be shortened.

1.2 Characteristics

The characteristics of the CC-Link are described below:


(1) Remote I/O station communication

The communication is performed with only on/off data (remote input RX and remote output RY).




(2) Remote device station communication

The communication is performed with on/off data (remote input RX and remote output RY) and numeric data (remote register).



(3) Local station communication

The data communication between programmable controller CPUs can be performed in N:N relationship with bit data (remote input RX and remote output RY) and word data (remote register)



(4) Establishing high-speed transmission

When the transmission speed of 10Mbps is set, the link scan time (communication time with the master station and remote station/local station) is still at high speed, even when the maximum 64 stations are connected.

- Remote I/O (RX, RY) 2048 points 4 ms
- Remote I/O (RX, RY) 2048 points
+ remote register (RWw, RWr) 512 points 7 ms

(5) System configurations are possible, according to requirements.

(a) Transmission distance

The total extended distance depends on the transmission speed, but connections can be made between 100 m (at 10 Mbps) and 1.2 km (at 156 kbps).

(b) Number of connected stations


A maximum of 64 stations, including remote I/O stations, remote device stations, and local stations can be connected to one master station. Up to 64 remote I/O stations, 42 remote device stations, and 26 local stations can be connected. (Refer to Section 2.1.)

(6) Link points

2048 points of remote input (RX), 2048 points of remote output (RY), and 512 points of remote register (RW) can be used for communication in one system. For one remote station or local station, 32 points of remote input (RX), 32 points of remote output (RY), and 8 points of remote register (RW) (RWw: 4 points, RWr: 4 points) can be handled.


(7) System down prevention (Station cutoff function)

Because the system employs the bus method, even if there is a remote station or local station which goes down due to power off, etc., it won't affect the communication with other functioning remote/local stations. Also, for the module using with the 2-piece terminal block, the module can be replaced during data link.



(8) Reserved station function


By setting the station which is not actually connected (station planned for connection in the future) as a reserved station, the station will not be handled as a faulty station.



(9) Error invalid station function


A station that cannot perform data links because the power is turned off, etc., can be handled as other than a "data-link faulty station" on the master station and the local station.

Be careful, however, for errors will not be detected.



(10) Parameter registration to the E²PROM

By registering the parameters to the E²PROM, the parameter settings do not have to be performed at each master station startup (power off → on). Because this is the E²PROM, parameters are stored even if the module's power is turned off.

**(11) Data-link status setting for when a master station programmable controller CPU error occurs**

The data-link status can be set (stop/continue) to either stop or continue for when a "operation stop error" occurs at the master station's programmable controller CPU, such as SP. UNIT ERROR.

The data link between local stations can be continued.

"Operation continue errors" such as a BATTERY ERROR continue the data link regardless of the setting.

(12) Input data from data-link faulty station status setting

The data input (received) from the data-link faulty station can be cleared or kept (status right before an error is caused).

(13) Module reset function from the sequence program

When the switch setting is changed or an error occurs in the module, the module can be reset from the sequence program without resetting the programmable controller CPU.

(This excludes when the module has a module faulty (Xn0 is on).)

(14) RAS function**(a) Automatic return function**

When a station is disconnected from the link due to power off, etc., and returns to the normal status, the station can join the data link again automatically.

(b) Link status check

Using the link special relay (SB) and link special register (SW) in the buffer memory, the current data-link status can be checked.

(c) Diagnosis function


Using the switch setting, the hardware and cable conditions can be checked.

1.3 Communication Overview

1.3.1 Communication between the master station and remote I/O station

The overview of the communication between the master station and remote I/O station is described below.

Refer to Section 4.2 for details.




- ① Turn on the refresh instruction.
- ② Startup the data link.
- ③ By the link scan, the remote I/O station's input information is stored in the master station's remote input (RX).
- ④ By the FROM instruction, read from the remote input (RX).
- ⑤ By the TO instruction, write the on/off data to the remote output (RY).
- ⑥ By the link scan, the remote I/O station's output is turned on/off.

1.3.2 Communication between the master station and remote device station

The overview of the communication between the master station and remote device station is described below.

Refer to Section 4.3 for details.




- ① Turn on the refresh instruction.
- ② Startup the data link.
- ③ By the link scan, the remote device station's remote input (RX) is stored in the master station's remote input (RX).
- ④ By the FROM instruction, read data from the remote input (RX).
- ⑤ By the TO instruction, write data to the remote output (RY).
- ⑥ By the link scan, the remote device station's remote output (RY) is turned on/off.
- ⑦ By the TO instruction, write data to the remote register (RWw).
- ⑧ By the link scan, the data is sent to the remote device station's remote register (RWw).
- ⑨ By the link scan, the remote device station's remote register (RWr) is sent to the master station's remote register (RWr).
- ⑩ By the TO instruction, read data from the remote register (RWr).

1.3.3 Communication between the master station and local station

The overview of the communication between the master station and local station is described below.


Refer to Section 4.4 for details.



- ① Turn on the refresh instruction.
- ② Startup the data link.
- ③ By the link scan, the data in the local station's remote output (RY) is sent to the master station's remote input (RX) and other local stations' remote output (RY).
- ④ By the link scan, the data in the master station's remote output (RY) is sent to all local station's remote input (RY).
- ⑤ By the link scan, the data in the master station's remote register (RWw) is sent to all local stations' remote register (RWw).
- ⑥ By the link scan, the data in the local station's remote register (RWw) is sent to the master station's remote register (RWw) and other local stations' remote register (RWw).

1.3.4 Compound system communication

The overview of compound system communication with remote I/O stations, remote device stations, and local stations is described below. Refer to Section 4.5 for details.



- ① Turn on the refresh instruction.
- ② Startup the data link.
- ③ By the link scan, data in the remote I/O station's and remote device station's remote input (RX) and local station's remote output (RY) is sent to the master station's remote input (RX) and local station's remote output (RY).
- ④ By the link scan, data in the master station's remote output (RY) is sent to the remote I/O station's and remote device station's remote output (RY) and local station's remote input (RX).
- ⑤ By the link scan, data in the master station's remote register (RWw) is sent to the remote device station's remote register (RWw) and local station's remote register (RWw).
- ⑥ By the link scan, data in the remote device station's remote register (RWw) and local station's remote register (RWw) is sent to the master station's remote register (RWw) and local station's remote register (RWw).

1.4 Number of Occupied Stations and Station Number, Number of Modules and Number of Stations

The relationship between number of occupied station and station number, and between number of modules and number of stations is described below.

(1) Number of occupied stations

The number of occupied stations is fixed for each module (remote I/O station, remote device station, and local station).

However, the number of occupied stations can be set (1 to 4 stations*) for local stations.


Module		Number of occupied stations
Remote I/O station (16 points and 32 points module)		1 station
Remote device station	AJ65BT-64AD	2 stations
	AJ65BT-64DAV	2 stations
	AJ65BT-64DAI	2 stations
	AJ65BT-D62	4 stations
	AJ65BT-D62D(S1)	
A852GOT	2 or 4 stations	
Local station		1 to 4 stations* (changed by switch)
Intelligent device station	AJ65BT-R2(N)	1 station
	AJ65BT-G4	1 station
	AJ65BT-D75P2-S3	4 stations

* The AJ61BT11 of hardware version F or later and the A1SJ61BT11 of hardware version G or later are compatible with this setting. For other than the above, the setting is 1 or 4 stations only.

(2) Station number

When the number of occupied station for all connected stations is set to "1 station," the station number is set continuously from 1 (e.g. 1, 2, 3,...).

However, when a station which occupies more than 2 stations is connected, the setting must be performed considering the number of occupied stations.



(3) Number of modules and number of stations

Number of modules is a physical module count.

Number of stations is a number of occupied stations for each module as stated in (1).

In the system configuration example in (2), the number of modules is 5 and number of stations is 9.

1.5 Generic Terms and Abbreviations

Generic terms and abbreviations used in this manual are shown below.

Generic Term/Abbreviation	Description
AJ61BT11	Abbreviation for the AJ61BT11 CC-Link System Master/Local Module
A1SJ61BT11	Abbreviation for the A1SJ61BT11 CC-Link System Master/Local Module
Master station	Station that controls the data link system. One master station is required for each system.
Local station	Station having a programmable controller CPU and the ability to communicate with the master and other local stations.
Remote I/O station	Remote station that handles bit unit data only. (Performs input and output with external devices.) (AJ65BTB1-16D, AJ65SBTB1-16D)
Remote device station	Remote station that handles bit unit and word unit data only. (Performs input and output with external devices, and analog data conversion.) (AJ65BT-64AD, AJ65BT-64DAV, AJ65BT-64DAI)
Remote station	Generic term for remote I/O station and remote device station. (Controlled by a master station)
Intelligent device station	Station that can perform transient transmission, such as the AJ65BT-R2(N) (Including local station)
Standby master station	Backup station for data link control when the link to the master station is disconnected due to a programmable controller CPU or power supply problem.
Slave station	Generic term for remote I/O station, remote device station, local station, intelligent device station and standby master station.
Master/local module	Generic term for the AJ61BT11 and A1SJ61BT11.
Master module	Generic term for the AJ61BT11 and A1SJ61BT11 when they are used as master station.
Local module	Generic term for the AJ61BT11 and A1SJ61BT11 when they are used as local station.
Remote module	Generic term for the AJ65BTB1-16D, AJ65SBTB1-16D, AJ65BT-64AD, AJ65BT-64DAV, AJ65BT-64DAI, and A852GOT.
AJ65BT-R2(N)	Generic term for the AJ65BT-R2 and AJ65BT-R2N.
Intelligent device module	Module that can perform transient transmission such as AJ65BT-R2(N) (including local module).
Remote I/O net mode	Dedicated mode for sending and receiving data to and from the remote I/O station at high speed.
Remote net mode	Mode that can communicate with all stations used for CC-Link. (remote I/O station, remote device station, local station, intelligent device station, and standby master station)
I/O mode	In this mode the programmable controller CPU cannot accept transient requests from an intelligent device station. There is no limit in the number of installable modules.
Intelligent mode	In this mode the programmable controller CPU can accept transient requests from an intelligent device station. There is a limit in the number of mountable modules.
Cyclic transmission	Transmission method by which to periodically communicate the contents of remote I/O and remote register.
Transient transmission	Transmission method with which the counterpart is specified and 1:1 communication is used at an arbitrary timing.
AnSCPU	Generic term for the A1SCPU, A1SCPU-S3, A1SJCPU, A1SJCPU-S3, A2SCPU, and A1SCPUC24-R2.
AnCPU	Generic term for the A1CPU, A2CPU, A2CPUS1, and A3CPU.
AnNCPU	Generic term for the A1NCPU, A2NCPU, A2NCPUS1, and A3NCPU.
AnACPU	Generic term for the A2ACPU, A2ACPUS1, and A3ACPU.
A2USCPU	Generic term for the A2USCPU, and A2USCPUS1.
AnUCPU	Generic term for the A2UCPU, A2UCPUS1, A3UPU, and A4UCPU.
Q2ASCPU	Generic term for the Q2ASCPU, Q2ASCPUS1, Q2ASHCPU, and Q2ASHCPUS1.
QnACPU	Generic term for the Q2ACPU, Q2ACPUS1, Q3ACPU, and Q4ACPU.
SB	Link special relay (for CC-Link) Bit unit information that indicates the module operating status and data link status of the master station/local station.
SW	Link special register (for CC-Link) 16-bit unit information that indicates the module operating status and data link status of the master station/local station.

Generic Term/Abbreviation	Description
RX	Remote input (for CC-Link) Information entered in bit units from the slave stations to the master station.
RY	Remote output (for CC-Link) Information output in bit units from the master station to the slave station.
RWw	Remote register (Write area for CC-Link) Information output in 16-bit units from the master station to the slave station.
RWr	Remote register (Read area for CC-Link) Information entered in 16-bit units from the slave station to the master station.

2. System Configuration


The system configuration for the CC-Link is described in this chapter.

2.1 Total Configuration

A total of 64 remote I/O stations, remote device stations, local stations, standby master stations, and intelligent device stations can be connected for one master station.

However, the following conditions must be satisfied:

- (1) $\{(1 \times a) + (2 \times b) + (3 \times c) + (4 \times d)\} \leq 64$
 a : Number of modules occupying 1 station c : Number of modules occupying 3 stations
 b : Number of modules occupying 2 stations d : Number of modules occupying 4 stations
- (2) $\{(16 \times A) + (54 \times B) + (88 \times C)\} \leq 2304$
 A : Number of remote I/O stations ≤ 64
 B : Number of remote device stations ≤ 42
 C : Number of local stations, standby master stations, intelligent device stations ≤ 26



Total 64

2.2 Applicable System

The applicable CPU modules and the precautions for system configuration are described below.

2.2.1 Applicable CPU and number of modules that can be installed

The applicable programmable controller CPU, data link system/network system, and the number of modules that can be installed are shown in Table 2.1.

However, intelligent mode cannot be used for future plan.

Table 2.1 Number of modules that can be installed

Installation area		A1SJ61BT11		AJ61BT11		Remarks				
		I/O mode	Intelligent mode	I/O mode	Intelligent mode					
Programmable controller CPU	A0J2CPU	Unusable	Unusable	No restrictions	2	In the intelligent mode, the following special function modules AD51(S3) AD51H(S3) AD57G(S3) AJ71C21(S1): In the BASIC program mode AJ71C23(S3) AJ71C24(S3/S6/S8) AJ71UC24 AJ71P41 AJ71E71(S1) A1SJ71C24-R2 A1SJ71C24-PRF A1SJ71C24-R4 A1SJ71UC24-R2 A1SJ71UC24-PRF A1SJ71UC24-R4 A1SD51S A1SJ71E71-B2(S3) A1SJ71E71-B5(S3) A0J2-C24				
	A0J2HCPU									
	A1SCPU	No restrictions	1							
	A1SHCPU						2			
	A1SJCPU(E/S3/S3-E)									
	A1SJHCPU									
	A1SCPUC24-R2									
	A2SCPU(S1)									
	A2SHCPU(S1)	Unusable	Unusable					Unusable	Unusable	
	A2ASCPU(S1)									
	A2USHCPU-S1									
	Q2ASCPU(S1)									
	Q2ASHCPU(S1)									
	A1CPU			Unusable	Unusable		No restrictions			2
	A2CPU(S1)									
	A3CPU									
	A1NCPU									
	A2NCPU(S1)									
	A3NCPU									
	A3MCPU									
	A3HCPU									
	A2ACPU(S1)	6								
	A3ACPU									
	A2UCPU(S1)									
	A3UCPU									
	A4UCPU									
	Q2ACPU(S1)									
Q3ACPU										
Q4ACPU										
Q4ARCPU	Unusable	Unusable	Unusable	Unusable						
MELSECNET remote I/O station										
Data link and network	MELSECNET/B remote I/O station	Unusable	Unusable	No restrictions	2					
	MELSECNET/10 remote I/O station					AJ72LP25	Unusable	Unusable	No restrictions	2
		AJ72BR15								
		AJ72QLP25								
	A1SJ72QLP25	No restrictions	2	No restrictions	2					
A1SJ72QBR15										

POINT


The module can be installed to any of the slots. However, the module cannot be installed to the final slot of the 7th extension base unit of the A3CPU.

2.2.2 Precautions when configuring a system

Design the system with the following considerations to prevent mis-input from the remote I/O module:

(1) During power on and power off

Start the data link after turning on the power for the remote I/O module.
Turn off power for the remote I/O module after stopping the data link.



(2) During momentary power failure of the remote I/O module

When momentary power failure occurs with the power (24VDC) supplied to the remote I/O module, mis-input may occur.


(a) Cause for mis-input due to a momentary power failure

The remote I/O module hardware uses the power after internally converting the module power (24VDC) in to 5VDC.

When momentary power failure occurs with the remote I/O module, the following condition occurs:


(Time for the 5VDC in the internal remote I/O module to turn off) > (input module on → off response time)

Therefore, mis-input is caused when a refresh is performed within the time indicated by ① in the diagram below.




(b) Countermeasure for mis-input

Wire the power supply cable for the power supply module, stabilized power, and input/external-supply power of the AC input from the same power source.



REMARK

When supplying power from one power source to multiple remote I/O modules, select the cable and perform the wiring with considerations to the voltage decline from the cables. Connections can be established if the remote I/O module's receiving port voltage is within the specification range of the used remote I/O module.



POINT
<p>To utilize the functions described in Chapter 14 or later, use a module with "9707B*" or later is shown as a DATE code on the rating plate.</p> <p>* "9707B" indicates that the module was manufactured in July 1997 and its function version is B.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Manufactured date</p> <p>Function version</p> </div> <div style="text-align: center;">  <p>Manufactured date</p> <p>Function version</p> </div> </div>

(3) Access to station No.64

- (a) To a local station of No. 64, other station access from GX Developer or GOT is not allowed.
If the station No. is changed to other than 64, other station access is executable.
- (b) The CC-Link board is not allowed to access a local station or intelligent device station whose station No. is 64.
If the station No. is changed to other than 64, other station access is executable.

(4) Precautions for use on remote I/O stations

Transient transmissions using dedicated instructions are not allowed to local stations and intelligent device stations.

2.2.3 List of system equipment restricted by master/local module versions

Table 2.2 lists the CC-Link system equipment restricted by the function, hardware and software versions of the master/local modules.

Table 2.2 System equipment list

Product name	Model	Description	Number of occupied stations	Station type
Master/local module	A1SJ61BT11	Master/local module for AnS/A2US series	When local station → 1 to 4 stations * 1	Master or local station
	AJ61BT11	Master/local module for A series		
	A1SJ61QBT11	Master/local module for Q2AS series		
	AJ61QBT11	Master/local module for QnA series		
	QJ61BT11	Master/local module for Q series		
High-speed counter module	AJ65BT-D62 * 2	24 bit binary, 5/12/24VDC input type, 200kPPS, 2 channels	4 stations	Remote device station
	AJ65BT-D62D(S1) * 2	24 bit binary, differential input type, 400kPPS, 2 channels		
Thermocouple temperature input module	AJ65BT-68TD * 2	For connecting thermocouple Temperature input 8 channels		
Platinum temperature measuring resistor Pt100 temperature input module	AJ65BT-64RD3 * 2	For connecting Pt 100 (3 wire type) Temperature input 4 channels		
	AJ65BT-64RD4 * 2	For connecting Pt 100 (4 wire type) Temperature input 4 channels		
ID interface module	AJ65BT-D32ID2 * 2	Number of readers/writers that can be connected is 2		
RS-232C interface module	AJ65BT-R2(N) * 2	Computer link function RS-232C, 1 channel	1 station	Intelligent device station
Positioning module	AJ65BT-D75P2-S3 * 2	For positioning control, Pulse chain output 2 axes (independent, simultaneous 2 axial, 2 axial linear interpolation and 2 axial circular interpolation)	4 stations	
Peripheral device connection module	AJ65BT-G4-S3 * 3	For peripheral device connection RS-422, 1 channel	1 station	

* 1 Supported by the hardware version F and later of the AJ61BT11 and AJ61QBT11, the hardware version G and later of the A1SJ61BT11 and A1SJ61QBT11, and the function version B and later of the QJ61BT11.
For other than the above, the setting is one station or four stations only.

* 2: Can be used with function version B or later.

* 3: Can be used with software version J (manufactured in Jan., 1998) or later.

For a list of products by partner manufacturers, refer to the following CC-Link Partner Association website.

www.cc-link.org

2.2.4 About Ver. 1.10

The module of which the station to station cable length is uniformly 20cm or more by improving the conventional limit of the station to station cable length is defined as Ver.1.10.

The conventional modules are defined as Ver.1.00.

Refer to Section 3.2.2 for the maximum overall cable distance of Ver. 1.10.

The conditions for setting the station to station cable length uniformly to 20cm or more are indicated below.


- 1) All modules configuring the CC-Link system must use Version 1.10.
- 2) All data link cables must be Version 1.10 compatible CC-Link dedicated cable.

POINT	<p>In a system where the modules of Ver. 1.00 and Ver. 1.10 are used together, the maximum overall cable distance and station to station cable length are as specified for Ver. 1.00. Refer to Section 3.2.1 for the maximum overall cable distance and station to station cable length of Ver. 1.00.</p>
--------------	---


(1) Checking Version 1.10

The "CC-Link" logo is printed on the front of the module or on the "rating plate" for the Version 1.10 modules.


(a) Front of the AJ61BT11




(b) Rating plate of AJ61BT11



(c) Front of the A1SJ61BT11



(d) Rating plate of A1SJ61BT11



3. Specifications

3.1 General Specifications

For general specifications, refer to the user's manual for the CPU module used.

3.2 Performance Specifications

The performance specifications of the CC-Link is shown in Table 3.1.

Table 3.1 Performance specifications

Item	AJ61BT11	A1SJ61BT11
Transmission speed	Can select from 156 kbps/ 625 kbps/ 2.5 Mbps/ 5 Mbps/ 10 Mbps	
Maximum overall cable distance (Maximum transmission distance)	Different from the transmission speed: (Refer to Section 3.2.1, 3.2.2)	
Maximum number of connected modules (when master station)	64 modules (However, the following conditions must be satisfied: $\{(1 \times a) + (2 \times b) + (3 \times c) + (4 \times d)\} \leq 64$ a: number of modules occupying 1 station b: number of modules occupying 2 stations c: number of modules occupying 3 stations d: number of modules occupying 4 stations $\{(16 \times A) + (54 \times B) + (88 \times C)\} \leq 2304$ A: Number of remote I/O stations ≤ 64 B: Number of remote device stations ≤ 42 C: Number of local stations, standby master stations, intelligent device stations ≤ 26	
Number of occupied stations (when local station)	1 to 4 stations * 1 (switched using DIP switch)	
Maximum link points for one system	Remote I/O (RX, RY) : 2048 points Remote register (RWw) : 256 points (master station → remote/local station) Remote register (RWr) : 256 points (remote/local station → master station)	
Link points for one remote/local station	Remote I/O (RX, RY) : 32 points (local station: 30 points) Remote register (RWw) : 4 points (master station → remote/local station) Remote register (RWr) : 4 points (remote/local station → master station)	
Communication method	Broadcast polling method	
Synchronous method	Frame synchronous method	
Encoding method	NRZI method	
Transmission path	Bus (RS-485)	
Transmission format	HDLC standard	
Error control system	CRC ($X^{16} + X^{12} + X^5 + 1$)	
Connection cable * 2	CC-Link dedicated cable (Ver.1.00)/CC-Link dedicated high performance cable/Version 1.10 compatible CC-Link dedicated cable	
RAS function	<ul style="list-style-type: none"> • Automatic return function • Slave station cutoff function • Error detection by the link special relay/register 	
Number of parameter registration to E ² PROM	10,000 times	
I/O occupied points	32 points (I/O allocation: 32 special points)	
Internal current consumption (5VDC)	0.45 A	0.4 A
Weight	0.4 kg	0.25 kg

*1 : The AJ61BT11 of hardware version F or later and the A1SJ61BT11 of hardware version G or later are compatible with this setting. For other than the above, the setting is 1 or 4 stations only.

*2 : Each of Ver.1.10 compatible CC-Link cables, CC-Link dedicated cables (Ver.1.00), and CC-Link dedicated high performance cables must not be used together with other cable types.


If different cable types are used together, normal data transmission is not guaranteed.

Also attach the terminating resistor which matches the kind of the cable. (Refer to section 7.5)

3.2.1 Maximum overall cable distance (for Ver. 1.00)

The relationship between the transmission speed and the maximum overall cable distance is described below:

- (1) For a system consisting of only remote I/O stations and remote device stations



- *1 Cable length between remote I/O stations or remote device stations.
- *2 Cable length between the master station and the adjacent stations.

CC-Link dedicated cable (terminating resistor 110 Ω)


Transmission rate	Station-to-station cable length		Maximum overall cable distance
	*1	*2	
156 kbps	30 cm (11.81 in.) or more	1 m (3.28 ft.) or more	1200 m (3937.2 ft.)
625 kbps			600 m (1968.6 ft.)
2.5 Mbps			200 m (656.2 ft.)
5 Mbps	30 cm (11.81 in.) to 59 cm (23.23 in.) *		110 m (360.9 ft.)
	60 cm (23.62 in.) or more		150 m (492.15 ft.)
10 Mbps	30 cm (11.81 in.) to 59 cm (23.23 in.) *		50 m (164.1 ft.)
	60 cm (23.62 in.) to 99 cm (38.98 in.) *		80 m (262.5 ft.)
	1 m (3.28 ft.) or more		100 m (328.1 ft.)

CC-Link dedicated high performance cable (terminating resistor 130 Ω)


Transmission rate	Station-to-station cable length		Maximum overall cable distance	
	*1	*2		
156 kbps	30 cm (11.81 in.) or more	1 m (3.28 ft.) or more	1200 m (3937.2 ft.)	
625 kbps			900 m (2952.9 ft.)	
2.5 Mbps			400 m (1312.4 ft.)	
5 Mbps			160 m (524.96 ft.)	
10 Mbps			Number of connected stations: 1 to 32	100 m (328.1 ft.)
	Number of connected stations: 33 to 48		30 cm (11.81 in.) to 39 cm (15.35 in.) *	80 m (262.5 ft.)
			40 cm (15.75 in.) or more	100 m (328.1 ft.)
	Number of connected stations: 49 to 64		30 cm (11.81 in.) to 39 cm (15.35 in.) *	20 m (65.52 ft.)
			40 cm (15.75 in.) to 69 cm (27.17 in.) *	30 m (98.43 ft.)
70 cm (27.56 in.) or more			100 m (328.1 ft.)	

* The cable length between remote I/O stations or remote device stations is within this range and if even one location is wired, the maximum overall cable distance will be as indicated above.

(Example) When the transmission rate is 10 Mbps, and 43 remote I/O stations and remote device stations are connected using the CC-Link dedicated high performance cable, because the cable connecting the second and third stations is "35 cm (13.78 in.)", the maximum overall cable distance will be "80 cm (31.5 in.)".



(2) For a system consisting of remote I/O stations, remote device stations, local stations and intelligent device stations



- *1 Cable length between remote I/O stations or remote device stations
- *2 Cable length between the master, local, or intelligent device station and the adjacent stations

CC-Link dedicated cable (terminating resistor 110 Ω)

Transmission rate	Station-to-station cable length		Maximum overall cable distance
	*1	*2	
156 kbps	30 cm (11.81 in.) or more	2 m (6.56 ft.) or more	1200 m (3937.2 ft.)
625 kbps			600 m (1968.6 ft.)
2.5 Mbps			200 m (656.2 ft.)
5 Mbps	30 cm (11.81 in.) to 59 cm (23.23 in.) *		110 m (360.9 ft.)
10 Mbps	60 cm (23.62 in.) or more		150 m (492.15 ft.)
	30 cm (11.81 in.) to 59 cm (23.23 in.) *		50 m (164.1 ft.)
	60 cm (23.62 in.) to 99 cm (38.98 in.) *	80 m (262.5 ft.)	
	1 m (3.28 ft.) or more	100 m (328.1 ft.)	


CC-Link dedicated high performance cable (terminating resistor 130 Ω)

Transmission rate	Station-to-station cable length		Maximum overall cable distance
	*1	*2	
156 kbps	30 cm (11.81 in.) or more	2 m (6.56 ft.) or more	1200 m (3937.2 ft.)
625 kbps			600 m (1968.6 ft.)
2.5 Mbps			200 m (656.2 ft.)
5 Mbps	30 cm (11.81 in.) to 59 cm (23.23 in.) *		110 m (360.9 ft.)
	60 cm (23.62 in.) or more		150 m (492.15 ft.)
10 Mbps	70 cm (27.56 in.) to 99 cm (38.98 in.) *		50 m (164.1 ft.)
	1 m (3.28 ft.) or more	80 m (262.5 ft.)	

* The cable length between remote I/O stations or remote device stations is within this range and if even one location is wired, the maximum overall cable distance will be as indicated above.

3.2.2 Maximum overall cable distance (for Ver. 1.10)

The relation of the transmission speed and maximum overall cable distance when configuring the entire system with Version 1.10 modules and cable is shown below.



Version 1.10 compatible CC-Link dedicated cable (terminating resistor 110Ω)

Transmission speed	Station to station cable length	Maximum overall cable distance
156kbps	20cm or longer	1200m
625kbps		900m
2.5Mbps		400m
5Mbps		160m
10Mbps		100m

3.3 CC-Link Dedicated Cable

Use the CC-Link dedicated cables for the CC-Link system. If a cable other than the CC-Link dedicated cable is used, the performance of the CC-Link system cannot be guaranteed.

For the specifications of the CC-Link dedicated cables or any other inquiries, visit the following website:

CC-Link Partner Association: www.cc-link.org

REMARK

For details, refer to the CC-Link cable wiring manual issued by CC-Link Partner Association.

3.4 I/O Signals to the Programmable Controller CPU

The I/O signals for the master/local module's programmable controller CPU is described.

3.4.1 I/O signal list

The list of I/O signals is described in Table 3.2.

The "n" in the table indicates the master/local module's first I/O number, and it is determined by the installation position and the module installed before the master/local module.

<Example> When the master/local module's first I/O number is "X/Y30":

Xn0 to X(n+1)F → X30 to X4F

Yn0 to Y(n+1)F → Y30 to Y4F

Table 3.2 I/O signal list

Signal direction: programmable controller CPU ← master/local module				Signal direction: programmable controller CPU → master/local module			
Input number	Signal name	Availability		Output number	Signal name	Availability	
		Master station	Local station			Master station	Local station
Xn0	Module error	○	○	Yn0	Refresh instruction	○	○
Xn1	Data link status at host station	○	○	Yn1	(Prohibited to use)	—	—
Xn2	Parameter setting status	○	×	Yn2			
Xn3	Data link status at other stations	○	○	Yn3			
Xn4	Module reset acceptance complete	○	○	Yn4	Module reset request	○	○
Xn5	(Prohibited to use)	—	—	Yn5	(Prohibited to use)	—	—
Xn6	Data link startup by buffer memory parameter normal completion	○	×	Yn6	Data link startup request from buffer memory parameters	○	×
Xn7	Data link startup by buffer memory parameter error completion	○	×	Yn7	(Prohibited to use)	—	—
Xn8	Data link startup by E ² PROM parameter normal completion	○	×	Yn8	Data link startup request from the E ² PROM parameters	○	×
Xn9	Data link startup by E ² PROM parameter error completion	○	×	Yn9	(Prohibited to use)	—	—
XnA	Parameter registration to E ² PROM normal completion	○	×	YnA	Parameter registration request to E ² PROM	○	×
XnB	Parameter registration to E ² PROM error completion	○	×	YnB	(Prohibited to use)	—	—
XnC	Data link priority signal	○	○	YnC			
XnD	E ² PROM erasure normal completion	○	×	YnD	E ² PROM erasure request	○	×
XnE	E ² PROM erasure abnormal completion	○	×	YnE	(Prohibited to use)	—	—
XnF	Module ready	○	○	YnF			

○: Usable ×: Prohibited to use

Table 3.2 I/O signal list

Signal direction: programmable controller CPU ← master/local module				Signal direction: programmable controller CPU → master/local module						
Input number	Signal name	Availability		Output number	Signal name	Availability				
		Master station	Local station			Master station	Local station			
X(n+1)0	(Prohibited to use)	-	-	Y(n+1)0	(Prohibited to use)	-	-			
X(n+1)1				Y(n+1)1						
X(n+1)2				Y(n+1)2						
X(n+1)3				Y(n+1)3						
X(n+1)4				Y(n+1)4						
X(n+1)5				Y(n+1)5						
X(n+1)6				Y(n+1)6						
X(n+1)7				Y(n+1)7						
X(n+1)8				Y(n+1)8						
X(n+1)9				Y(n+1)9						
X(n+1)A				Y(n+1)A						
X(n+1)B				Y(n+1)B						
X(n+1)C				Y(n+1)C				Bank switch specification of buffer	○	-
X(n+1)D				Y(n+1)D				memory		
X(n+1)E				Y(n+1)E				(Prohibited to use)	-	-
X(n+1)F				Y(n+1)F						

○: Usable ×: Prohibited to use

Important

The output signals that are prohibited to use as shown in Table 3.2 are used by the system, so users may not use them. When a user does use (on/off) these signals, a normal operation cannot be guaranteed.

3.4.2 I/O signal details

The on/off timing, conditions, etc. of I/O signals shown in Table 3.2 are described.

(1) Module error: Xn0


Indicates if the module is normal or not.

Turns ON when a watchdog timer error occurs due to a hardware fault or the like. If the module is abnormal (Xn0 is ON), do not execute the FROM/TO instruction for the module.

When making a reset, reset the programmable controller CPU.

OFF : module normal

ON : module error



(2) Data link status at host station: Xn1

Indicates data link status at the host station.


SB006E also represents the same meaning. For programming, use either Xn1 or SB006E.

Note that the ON/OFF condition for Xn1 is opposite to that for SB006E.

When Xn1 is used, the condition is as follows:

OFF : data link stopped

ON : data link in progress



(3) Parameter setting status: Xn2

Indicates parameter setting status at host station.

SB006D represents the same meaning. For programming, use either Xn2 or SB006D.

OFF : normal

ON : error in setting (An error code is stored in SW0068.)

Turns off when Yn6 or Yn8 is executed in the status that error does not occur.

(4) Data link status at other stations: Xn3

Indicates data link status at other stations (remote/local stations).

SB0080 represents the same meaning. For programming, use either Xn3 or SB0080.

OFF : all stations normal

ON : error station exists (An error station status is stored in SW0080 to 83.)

(5) Module reset acceptance complete: Xn4


Indicates the acceptance status of reset request by the module reset request (Yn4). Reset cannot be performed when module error (Xn0 on).

(a) When module reset request (Yn4) is turned on, module ready (XnF) turns off and initialization is executed.

When the initialization is completed normally, module ready (XnF) turns on.


Module reset request (Yn4) is turned off by turning on the module reset acceptance complete (Xn4).

To make a data link, set the data link startup request (Yn6/Yn8) again.




(b) When module reset request (Yn4) is turned on, module ready (XnF) turns off and initialization is executed.


When the initialization is completed abnormally, module ready (XnF) does not turn on, but module error (Xn0) turns on.




- (6) **Data link startup by buffer memory parameter normal completion: Xn6**
 Indicates normal completion in data link startup requested by the buffer-memory parameter data link startup request (Yn6).
- (a) When (Yn6) is turned on, the parameter contents at the (address 0H to 5FH) in buffer memory are checked. If the check result is normal data link is started automatically.
 - (b) When data link is normally started, the signal for "data link startup by buffer-memory parameter normal completion" (Xn6) is turned on.
 - (c) (Xn6) is turned off by turning off (Yn6).




- (7) **Data link startup by buffer memory parameter error completion: Xn7**
 Indicates abnormal completion in data link startup requested by the buffer-memory parameter data link startup request (Yn6).
- (a) When (Yn6) is turned on, the parameter contents at the (address 0H to 5FH) in buffer memory are checked. If error is detected the signal for "data link startup by buffer-memory parameter abnormal completion" (Xn7) is turned on.
 - (b) Parameter setting status (Xn2) is turned on and the error code is stored in the host station parameter status in buffer memory (SW0068).
 - (c) (Xn7) is turned off by turning off (Yn6).



- (8) Data link startup by E²PROM parameter normal completion: Xn8
 Indicates normal completion in data link startup requested by the E²PROM parameter data link startup request (Yn8).
- (a) When (Yn8) is turned on, the E²PROM parameter contents are checked. If the check result is normal data link is started automatically.
 - (b) When data link is normally started, the signal for "data link startup by E²PROM parameter normal completion" (Xn8) is turned on.
 - (c) (Xn8) is turned off by turning off (Yn8).




- (9) Data link startup by E²PROM parameter error completion: Xn9
 Indicates abnormal completion in data link startup requested by the E²PROM parameter data link startup request (Yn8).
- (a) When (Yn8) is turned on, the E²PROM parameter contents are checked. If error is detected the signal for "data link startup by E²PROM parameter abnormal completion" (Xn9) is turned on.
 - (b) Parameter setting status (Xn2) is turned on and the error code is stored in the host station parameter status in buffer memory (SW0068).
 - (c) (Xn9) is turned off by turning off (Yn8).



(10) Parameter registration to E²PROM normal completion: XnA

Indicates normal completion in registering parameters at (buffer-memory address 0H to 5FH) to E²PROM requested by the parameter registration request to E²PROM (YnA).


- (a) When (YnA) is turned on, the parameter contents stored in the parameter information area buffer memory (address 0H to 5FH) are checked. If the parameters are registered to E²PROM.
- (b) When registration is normally completed, the signal for "parameter registration to E²PROM normal completion" (XnA) is turned on.
- (c) (XnA) is turned off by turning off (YnA).



(11) Parameter registration to E²PROM error completion: XnB

Indicates abnormal completion in registering parameters at (buffer-memory address 0H to 5FH) to E²PROM requested by the parameter registration request to E²PROM (YnA).

- (a) When the parameter registration request (YnA) to the E²PROM is turned on, the parameters stored in the buffer-memory "parameter information area (address 0H to 5FH)" are written to the E²PROM.
- (b) When the registration ends error, the E²PROM parameter registration error (XnB) turns on and the error code is stored in the buffer memory E²PROM registration status (SW00B9).
- (c) (XnB) is turned off by turning off (YnA).




(12) Data link priority signal: XnC

This signal suppresses the FROM/TO instructions and gives priority to data link. Utilize this signal when a problem shown in section 13.1, such as "Xn1 (host station data link status) does not turn ON" or "Link special relay (SB) /link special register (SW) is not updated correctly", has occurred. (Refer to Section 13.1.)

(13) E²PROM erasure normal completion: XnD

This signal indicates the normal completion of erasing the parameters in the E²PROM in response to the E²PROM erasure request (YnD).


- (a) When the E²PROM erasure request (YnD) turns on, the parameters in the E²PROM are erased.
- (b) On normal completion of erasure, the E²PROM erasure normal completion (XnD) turns on.
- (c) By turning off the E²PROM erasure request (YnD), the E²PROM erasure normal completion (XnD) turns off.



(14) E²PROM erasure abnormal completion: XnE

This signal indicates the abnormal completion of erasing the parameters in the E²PROM in response to the E²PROM erasure request (YnD).

- (a) When the E²PROM erasure request (YnD) turns on, the parameters in the E²PROM are erased.
- (b) On abnormal completion of erasure, the E²PROM erasure abnormal completion (XnE) turns on and the error code is stored into the E²PROM erasure result (SW00BA) of the buffer memory.
- (c) By turning off the E²PROM erasure request (YnD), the E²PROM erasure abnormal completion (XnE) turns off.




(15) Module ready: XnF

Indicates if the module is ready for operation.

Used as an interlock signal when a sequence program is used to make access to the master/local module.

- (a) Turns on automatically when the module becomes ready for operation.
- (b) Turns off when one of the following conditions occur:
 - There is an error in the module switch settings.
 - The module reset request signal (Yn4) is turned on.
 - The module error signal (Xn0) is turned on.

If the module is inoperative (XnF is OFF), do not execute the FROM/TO instruction for the module.



(19) Data link startup request from E²PROM parameter: Yn8

Starts data link according to the parameter contents registered in E²PROM.

Do not turn on this signal during RUN of the programmable controller CPU and during a data link.

If you are going to change any parameter data during RUN of the programmable controller CPU and during a data link, always turn on SB0002 (data link stop) to stop the data link, change the parameter data, and then turn on this signal to restart the data link.

Refer to (8) and (9) for signal timing.

POINT

The factory-set E²PROM values are indefinite. Before making a data link startup using the Yn8 signal, always execute parameter registration using the YnA signal at least once.

(20) Parameter registration request to E²PROM: YnA

The signal for registering parameter (address 0H to 5FH) in buffer memory to E²PROM.

Since the number of times parameters are registered to E²PROM is limited to 10,000, execute parameter registration using the YnA signal by the minimum number of times required.

Refer to (10) and (11) for signal timing.

(21) E²PROM erasure request: YnD

The signal for erasing the parameters in the E²PROM.

Refer to (13) and (14) for the signal timing.

(22) Bank switch specification of buffer memory : Y(n+1) C, Y(n+1)D

Specifies bank switch of buffer memory.

Y(n+1)C	Y(n+1)D	Buffer memory	Application
OFF	OFF	Specify 0 bank	Parameter, status information, etc.
ON	OFF	Specify 1 bank	Intelligent device station Send/receive buffer
OFF	ON	Specify 2 bank	Intelligent device station Automatic update buffer
ON	ON	—	Prohibited to use

3.5 Buffer Memory

The buffer memory is used to swap data between the master/local module and the programmable controller CPU.

In the programmable controller CPU, the FROM/TO instructions are used to read/write data.

The contents of the buffer memory return to the default values when the power is turned off and the programmable controller CPU is reset.

3.5.1 Buffer memory list

The buffer memory list is shown in Table 3.3.

When using a master/local module as a standby master station, refer to the applicable column under "Availability" as explained below.

- When a standby master station is operating as a master station: "Master station" column
- When a standby master station is operating as a standby master station: "Local station" column

Table 3.3 (1) Buffer memory list (bank 0)

Address		Item	Details	Read/write possibility	Availability		Reference
Hex.	Dec.				Master station	Local station	
0H to 5FH	0 to 95	Parameter information area	Stores the information (parameters) to execute the data link.	Read/write enabled	○ *1	×	Section 3.5.2 (1)
60H to 7FH	96 to 127	(Prohibited to use) *2	—	—	—	—	—
80H to CDH	128 to 205	Parameter information area	Stores the information (parameters) to execute the data link.	Read/write enabled	○ *1	×	Section 15.2.1
CEH to DFH	206 to 223	(Prohibited to use) *2	—	—	—	—	—
E0H to 15FH	224 to 351	Remote input (RX)	As the master station: Stores the input status from the remote/local station.	Read only	○	—	Section 3.5.2 (2)
			As a local station: stores the input status from the master station.		—	○	
160H to 1DFH	352 to 479	Remote output (RY)	As the master station: Stores the output status of the output to the remote/local station.	Write only	○	—	Section 3.5.2 (2)
			As a local station: Stores the output status of the output to the master station.	Read/write enabled	—	○	
1E0H to 2DFH	480 to 735	Remote register (RWw) (Master station: for sending Local station: for sending/receiving)	As the master station: Stores the transmission data to the remote/all local stations.	Write only	○	—	Section 3.5.2 (3)
			As a local station: Stores the transmission data to the master/other local stations. Also, stores the received data from the remote/other local stations.	Read/write enabled	—	○	
2E0H to 3DFH	736 to 991	Remote register (RWr) (Master station: for receiving Local station: for receiving)	As the master station: Stores the received data from the remote/local station.	Write only	○	—	Section 3.5.2 (3)
			As a local station: Stores the received data from the master station.		—	○	
3E0H to 5DFH	992 to 1503	(Prohibited to use) *2	—	—	—	—	—

○: Usable ×: Prohibited to use

*1: These areas can be used for the master station only, and cannot be used for the standby master station (control status).

*2: Do not write data to these areas. Doing so may cause an error.

Table 3.3 (1) Buffer memory list (bank 0) (continued)

Address		Item	Details	Read/write possibility	Availability		Reference
Hex.	Dec.				Master station	Local station	
5E0 _H to 5FF _H	1504 to 1535	Link special relay (SB)	Stores the data-link status.	Read/write enabled (write disabled depending on the device)	○	○	Section 3.5.2 (4)
600 _H to 7FF _H	1536 to 2047	Link special register (SW)	Stores the data-link status.	Read/write enabled (write disabled depending on the device)	○	○	Section 3.5.2 (5)
800 _H to 9FF _H	2048 to 2559	(Prohibited to use) *2	—	—	—	—	—
A00 _H to FFF _H	2560 to 4095	Random access buffer	Used for dedicated instructions such as RIRD and RIWT.	Read/write enabled	○	○	Section 15.6

○: Usable ×: Prohibited to use

*1: These areas can be used for the master station only, and cannot be used for the standby master station (control status).

*2: Do not write data to these areas. Doing so may cause an error.

Table 3.3 (2) Buffer memory list (bank 1)

Address		Item	Details	Read/write possibility	Availability		Reference
Hex.	Dec.				Master station	Local station	
0 _H to FFF _H	0 to 4095	Communication buffer	When the transient transmission (communication using communication buffer) is performed with the intelligent device stations, this stores the communication data and control data. The area for each intelligent device station is set with the network parameters.	Read/write enabled	○	○	Section 15.2.1

Table 3.3 (3) Buffer memory list (bank 2)

Address		Item	Details	Read/write possibility	Availability		Reference
Hex.	Dec.				Master station	Local station	
0 _H to FFF _H	0 to 4095	Automatic updating buffer	When the transient transmission (communication using automatic updating buffer) is performed with the intelligent device stations, this stores the automatic updating data. The area for each intelligent device station is set with the network parameters.	Read/write enabled	○	—	Section 15.2.1

3.5.2 Buffer memory details

The details of each item shown in Table 3.3 of Section 3.5.1 is described.

(1) Parameter information area

The conditions to perform data link is set.

Also, these can be registered in the E²PROM.

Table 3.4 Parameter information area list

Address		Item	Description	Default
Hex.	Dec.			
0H	0	(Prohibited to use)*	–	–
1H	1	Number of connected modules	Set the number of connected remote/local station modules. (including reserved stations)	64
2H	2	Number of retries	Set the number of retries to the communication faulty station.	3
3H	3	Number of automatic return modules	Set the number of remote/local stations modules that can return with 1 link scan.	1
4H	4	(Prohibited to use)*	–	–
5H	5	(Prohibited to use)*	–	–
6H	6	Operation specification when CPU is down	Specify the data-link status when there is a master station programmable controller CPU error.	0 (Stop)
7H to FH	7 to 15	(Prohibited to use)*	–	–
10H to 13H	16 to 19	Reserved station specification	Set a reserved station.	0 (No specification)
14H to 17H	20 to 23	Invalid station specification	Specify an invalid station.	0 (No specification)
18H to 1FH	24 to 31	(Prohibited to use)*	–	–
20H to 5FH	32 to 95	Station information	Set the connected remote/local station type.	Station type: Remote I/O station Number of occupied stations: 1 Station numbers: 1 to 64

* Do not write to areas that are prohibited to use. An error may occur.

(a) Number of connected modules

This sets the number of remote/local station modules connected to the master station (including reserved stations).

This is not a station count.

The setting range is "1 to 64 (modules)."

POINT

The station information (address 20H to 5FH) for the specified "number of connected" stations becomes valid.

(b) Number of retries

This sets the number of retries to the remote/local station with a data link error.

The setting range is "1 to 7(times)."

If the remote/local station cannot recover a normal data link after performing specified number of retries, the station becomes a "data-link faulty station."

(c) Number of automatic return modules

This sets the number of remote/local stations that can return to the system during 1 link scan.

The range is "1 to 10 (modules)."

(d) Operation specification when CPU is down

This specifies the data-link status when the master station programmable controller CPU has an error which "stops the error operation".

"0" is stop and "1" is continue.

(e) Reserved station specification

This is set to include the remote/local stations that are not actually connected in the number of connected modules, so that a data link error does not occur.

① When a connected remote/local station is set as a reserved station, the station cannot perform any data link at all.

② Turn on the bit corresponding to the station number to be set as reserved.


However, for the remote/local station that occupies more than 2 stations, turn on the only bit for the station numbers set by the module's station number setting switch.

1 to 64 in the table below indicate the station numbers.

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
10 _H	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
11 _H	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
12 _H	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33
13 _H	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49

<Setting example>

When setting a local station with station number 4 and a remote station with station number 9 as reserved in the system configuration below:



(f) Error invalid station specification

This is set so that the remote/local station that can no longer perform data link due to power off, etc. will not be treated as a "data-link faulty station" on the master station and the local station.

Be careful, however, for errors will not be detected.


- ① When the same station number is specified as a reserved station, the reserved station specification has the priority.
- ② Turn on the bit corresponding to the station number of the invalid station. However, for remote/local stations that occupy more than 2 stations, turn on the only bit for the station numbers set by the module's station number setting switch.

1 to 64 in the table below indicate the station numbers.

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
14 _H	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
15 _H	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
16 _H	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33
17 _H	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49

<Setting example>


When setting a local station with station number 4 and a remote station with station number 9 as invalid in the system configuration below:



(g) Station information

This sets the remote/local station type for connected remote/local stations and reserved stations.

① The data configuration to be set is shown below.




② The buffer memory address for each module is shown in the table below.

For example, when setting for the 25th module, write to the buffer memory address "38H."

Module	Address	Module	Address	Module	Address	Module	Address
1st module	20H	17th module	30H	33rd module	40H	49th module	50H
2nd module	21H	18th module	31H	34th module	41H	50th module	51H
3rd module	22H	19th module	32H	35th module	42H	51st module	52H
4th module	23H	20th module	33H	36th module	43H	52nd module	53H
5th module	24H	21st module	34H	37th module	44H	53rd module	54H
6th module	25H	22nd module	35H	38th module	45H	54th module	55H
7th module	26H	23rd module	36H	39th module	46H	55th module	56H
8th module	27H	24th module	37H	40th module	47H	56th module	57H
9th module	28H	25th module	38H	41st module	48H	57th module	58H
10th module	29H	26th module	39H	42nd module	49H	58th module	59H
11th module	2AH	27th module	3AH	43rd module	4AH	59th module	5AH
12th module	2BH	28th module	3BH	44th module	4BH	60th module	5BH
13th module	2CH	29th module	3CH	45th module	4CH	61st module	5CH
14th module	2DH	30th module	3DH	46th module	4DH	62nd module	5DH
15th module	2EH	31st module	3EH	47th module	4EH	63rd module	5EH
16th module	2FH	32nd module	3FH	48th module	4FH	64th module	5FH

<Setting example>

When connecting a remote I/O station, a remote device station and a local station:




(2) Remote input (RX) and remote output (RY)

(a) Master station ← Remote I/O station/remote device station/local station

① Master station

- Input status from remote I/O station, remote device station (RX) and local station (RY) are stored.
- Two words are used per station.




Master station's buffer memory and station number correspondence table

Station number	Buffer memory address	Station number	Buffer memory address	Station number	Buffer memory address	Station number	Buffer memory address	Station number	Buffer memory address
1	E0 _H to E1 _H	14	FA _H to FB _H	27	114 _H to 115 _H	40	12E _H to 12F _H	53	148 _H to 149 _H
2	E2 _H to E3 _H	15	FC _H to FD _H	28	116 _H to 117 _H	41	130 _H to 131 _H	54	14A _H to 14B _H
3	E4 _H to E5 _H	16	FE _H to FF _H	29	118 _H to 119 _H	42	132 _H to 133 _H	55	14C _H to 14D _H
4	E6 _H to E7 _H	17	100 _H to 101 _H	30	11A _H to 11B _H	43	134 _H to 135 _H	56	14E _H to 14F _H
5	E8 _H to E9 _H	18	102 _H to 103 _H	31	11C _H to 11D _H	44	136 _H to 137 _H	57	150 _H to 151 _H
6	EA _H to EB _H	19	104 _H to 105 _H	32	11E _H to 11F _H	45	138 _H to 139 _H	58	152 _H to 153 _H
7	EC _H to ED _H	20	106 _H to 107 _H	33	120 _H to 121 _H	46	13A _H to 13B _H	59	154 _H to 155 _H
8	EE _H to EF _H	21	108 _H to 109 _H	34	122 _H to 123 _H	47	13C _H to 13D _H	60	156 _H to 157 _H
9	F0 _H to F1 _H	22	10A _H to 10B _H	35	124 _H to 125 _H	48	13E _H to 13F _H	61	158 _H to 159 _H
10	F2 _H to F3 _H	23	10C _H to 10D _H	36	126 _H to 127 _H	49	140 _H to 141 _H	62	15A _H to 15B _H
11	F4 _H to F5 _H	24	10E _H to 10F _H	37	128 _H to 129 _H	50	142 _H to 143 _H	63	15C _H to 15D _H
12	F6 _H to F7 _H	25	110 _H to 111 _H	38	12A _H to 12B _H	51	144 _H to 145 _H	64	15E _H to 15F _H
13	F8 _H to F9 _H	26	112 _H to 113 _H	39	12C _H to 12D _H	52	146 _H to 147 _H	-	-

② Local station

- Data to be sent to master station is stored in the remote output (RY) corresponding to the host station.
- Input status from remote I/O station, remote device station (RX) and other local station are stored.
- Two words are used per station.
- ▮ ... The last 2 bits cannot be used when the master station and the local station are communicating.




Local station's buffer memory address and station number correspondence table

Station number	Buffer memory address								
1	160 _H to 161 _H	14	17A _H to 17B _H	27	194 _H to 195 _H	40	1AE _H to 1AF _H	53	1C8 _H to 1C9 _H
2	162 _H to 163 _H	15	17C _H to 17D _H	28	196 _H to 197 _H	41	1B0 _H to 1B1 _H	54	1CA _H to 1CB _H
3	164 _H to 165 _H	16	17E _H to 17F _H	29	198 _H to 199 _H	42	1B2 _H to 1B3 _H	55	1CC _H to 1CD _H
4	166 _H to 167 _H	17	180 _H to 181 _H	30	19A _H to 19B _H	43	1B4 _H to 1B5 _H	56	1CE _H to 1CF _H
5	168 _H to 169 _H	18	182 _H to 183 _H	31	19C _H to 19D _H	44	1B6 _H to 1B7 _H	57	1D0 _H to 1D1 _H
6	16A _H to 16B _H	19	184 _H to 185 _H	32	19E _H to 19F _H	45	1B8 _H to 1B9 _H	58	1D2 _H to 1D3 _H
7	16C _H to 16D _H	20	186 _H to 187 _H	33	1A0 _H to 1A1 _H	46	1BA _H to 1BB _H	59	1D4 _H to 1D5 _H
8	16E _H to 16F _H	21	188 _H to 189 _H	34	1A2 _H to 1A3 _H	47	1BC _H to 1BD _H	60	1D6 _H to 1D7 _H
9	170 _H to 171 _H	22	18A _H to 18B _H	35	1A4 _H to 1A5 _H	48	1BE _H to 1BF _H	61	1D8 _H to 1D9 _H
10	172 _H to 173 _H	23	18C _H to 18D _H	36	1A6 _H to 1A7 _H	49	1C0 _H to 1C1 _H	62	1DA _H to 1DB _H
11	174 _H to 175 _H	24	18E _H to 18F _H	37	1A8 _H to 1A9 _H	50	1C2 _H to 1C3 _H	63	1DC _H to 1DD _H
12	176 _H to 177 _H	25	190 _H to 191 _H	38	1AA _H to 1AB _H	51	1C4 _H to 1C5 _H	64	1DE _H to 1DF _H
13	178 _H to 179 _H	26	192 _H to 193 _H	39	1AC _H to 1AD _H	52	1C6 _H to 1C7 _H	-	-

(b) Master station → remote I/O station/remote device station/local station

① Master station

- Output status to remote I/O station, remote device station (RY) and all local stations (RX) are stored.
- Two words are used per station.



Master station's buffer memory and station number correspondence table


Station number	Buffer memory address								
1	160 _H to 161 _H	14	17A _H to 17B _H	27	194 _H to 195 _H	40	1AE _H to 1AF _H	53	1C8 _H to 1C9 _H
2	162 _H to 163 _H	15	17C _H to 17D _H	28	196 _H to 197 _H	41	1B0 _H to 1B1 _H	54	1CA _H to 1CB _H
3	164 _H to 165 _H	16	17E _H to 17F _H	29	198 _H to 199 _H	42	1B2 _H to 1B3 _H	55	1CC _H to 1CD _H
4	166 _H to 167 _H	17	180 _H to 181 _H	30	19A _H to 19B _H	43	1B4 _H to 1B5 _H	56	1CE _H to 1CF _H
5	168 _H to 169 _H	18	182 _H to 183 _H	31	19C _H to 19D _H	44	1B6 _H to 1B7 _H	57	1D0 _H to 1D1 _H
6	16A _H to 16B _H	19	184 _H to 185 _H	32	19E _H to 19F _H	45	1B8 _H to 1B9 _H	58	1D2 _H to 1D3 _H
7	16C _H to 16D _H	20	186 _H to 187 _H	33	1A0 _H to 1A1 _H	46	1BA _H to 1BB _H	59	1D4 _H to 1D5 _H
8	16E _H to 16F _H	21	188 _H to 189 _H	34	1A2 _H to 1A3 _H	47	1BC _H to 1BD _H	60	1D6 _H to 1D7 _H
9	170 _H to 171 _H	22	18A _H to 18B _H	35	1A4 _H to 1A5 _H	48	1BE _H to 1BF _H	61	1D8 _H to 1D9 _H
10	172 _H to 173 _H	23	18C _H to 18D _H	36	1A6 _H to 1A7 _H	49	1C0 _H to 1C1 _H	62	1DA _H to 1DB _H
11	174 _H to 175 _H	24	18E _H to 18F _H	37	1A8 _H to 1A9 _H	50	1C2 _H to 1C3 _H	63	1DC _H to 1DD _H
12	176 _H to 177 _H	25	190 _H to 191 _H	38	1AA _H to 1AB _H	51	1C4 _H to 1C5 _H	64	1DE _H to 1DF _H
13	178 _H to 179 _H	26	192 _H to 193 _H	39	1AC _H to 1AD _H	52	1C6 _H to 1C7 _H	-	-

② Local station

- Data received from remote I/O station, remote device station (RY) and master station (RY) are stored.

- Two words are used per station.

▬ ... The last 2 bits cannot be used when the master station and the local station are communicating.




Local station's buffer memory address and station number correspondence table

Station number	Buffer memory address								
1	E0H to E1H	14	FAH to FBH	27	114H to 115H	40	12EH to 12FH	53	148H to 149H
2	E2H to E3H	15	FBH to FDH	28	116H to 117H	41	130H to 131H	54	14AH to 14BH
3	E4H to E5H	16	FEH to FFH	29	118H to 119H	42	132H to 133H	55	14CH to 14DH
4	E6H to E7H	17	100H to 101H	30	11AH to 11BH	43	134H to 135H	56	14EH to 14FH
5	E8H to E9H	18	102H to 103H	31	11CH to 11DH	44	136H to 137H	57	150H to 151H
6	EAH to EBH	19	104H to 105H	32	11EH to 11FH	45	138H to 139H	58	152H to 153H
7	ECH to EDH	20	106H to 107H	33	120H to 121H	46	13AH to 13BH	59	154H to 155H
8	EEH to EFH	21	108H to 109H	34	122H to 123H	47	13CH to 13DH	60	156H to 157H
9	F0H to F1H	22	10AH to 10BH	35	124H to 125H	48	13EH to 13FH	61	158H to 159H
10	F2H to F3H	23	10CH to 10DH	36	126H to 127H	49	140H to 141H	62	15AH to 15BH
11	F4H to F5H	24	10EH to 10FH	37	128H to 129H	50	142H to 143H	63	15CH to 15DH
12	F6H to F7H	25	110H to 111H	38	12AH to 12BH	51	144H to 145H	64	15EH to 15FH
13	F8H to F9H	26	112H to 113H	39	12CH to 12DH	52	146H to 147H	-	-

(3) Remote register (RWw) and remote register (RWr)
 (a) Master station (RWw) → Remote device station (RWw)/
 local station (RWr)


① Master station

- Data to be sent to remote register at remote device station (RWw) and remote registers of all local stations (RWr) are stored.
- Four words are used per station.



② Local station

- Data sent to the remote register(RWw) of remote device station can also be received.
- Four words are used per station.



Following tables show the relationship between station numbers and buffer memory addresses used.

[Master station]

Station number and buffer memory correspondence table

Station number	Buffer memory address	Station number	Buffer memory address
1	1E0 _H to 1E3 _H	33	260 _H to 263 _H
2	1E4 _H to 1E7 _H	34	264 _H to 267 _H
3	1E8 _H to 1EB _H	35	268 _H to 26B _H
4	1EC _H to 1EF _H	36	26C _H to 26F _H
5	1F0 _H to 1F3 _H	37	270 _H to 273 _H
6	1F4 _H to 1F7 _H	38	274 _H to 277 _H
7	1F8 _H to 1FB _H	39	278 _H to 27B _H
8	1FC _H to 1FF _H	40	27C _H to 27F _H
9	200 _H to 203 _H	41	280 _H to 283 _H
10	204 _H to 207 _H	42	284 _H to 287 _H
11	208 _H to 20B _H	43	288 _H to 28B _H
12	20C _H to 20F _H	44	28C _H to 28F _H
13	210 _H to 213 _H	45	290 _H to 293 _H
14	214 _H to 217 _H	46	294 _H to 297 _H
15	218 _H to 21B _H	47	298 _H to 29B _H
16	21C _H to 21F _H	48	29C _H to 29F _H
17	220 _H to 223 _H	49	2A0 _H to 2A3 _H
18	224 _H to 227 _H	50	2A4 _H to 2A7 _H
19	228 _H to 22B _H	51	2A8 _H to 2AB _H
20	22C _H to 22F _H	52	2AC _H to 2AF _H
21	230 _H to 233 _H	53	2B0 _H to 2B3 _H
22	234 _H to 237 _H	54	2B4 _H to 2B7 _H
23	238 _H to 23B _H	55	2B8 _H to 2BB _H
24	23C _H to 23F _H	56	2BC _H to 2BF _H
25	240 _H to 243 _H	57	2C0 _H to 2C3 _H
26	244 _H to 247 _H	58	2C4 _H to 2C7 _H
27	248 _H to 24B _H	59	2C8 _H to 2CB _H
28	24C _H to 24F _H	60	2CC _H to 2CF _H
29	250 _H to 253 _H	61	2D0 _H to 2D3 _H
30	254 _H to 257 _H	62	2D4 _H to 2D7 _H
31	258 _H to 25B _H	63	2D8 _H to 2DB _H
32	25C _H to 25F _H	64	2DC _H to 2DF _H

[Local station]


Station number and buffer memory correspondence table

Station number	Buffer memory address	Station number	Buffer memory address
1	2E0 _H to 2E3 _H	33	360 _H to 363 _H
2	2E4 _H to 2E7 _H	34	364 _H to 367 _H
3	2E8 _H to 2EB _H	35	368 _H to 36B _H
4	2EC _H to 2EF _H	36	36C _H to 36F _H
5	2F0 _H to 2F3 _H	37	370 _H to 373 _H
6	2F4 _H to 2F7 _H	38	374 _H to 377 _H
7	2F8 _H to 2FB _H	39	378 _H to 37B _H
8	2FC _H to 2FF _H	40	37C _H to 37F _H
9	300 _H to 303 _H	41	380 _H to 383 _H
10	304 _H to 307 _H	42	384 _H to 387 _H
11	308 _H to 30B _H	43	388 _H to 38B _H
12	30C _H to 30F _H	44	38C _H to 38F _H
13	310 _H to 313 _H	45	390 _H to 393 _H
14	314 _H to 317 _H	46	394 _H to 397 _H
15	318 _H to 31B _H	47	398 _H to 39B _H
16	31C _H to 31F _H	48	39C _H to 39F _H
17	320 _H to 323 _H	49	3A0 _H to 3A3 _H
18	324 _H to 327 _H	50	3A4 _H to 3A7 _H
19	328 _H to 32B _H	51	3A8 _H to 3AB _H
20	32C _H to 32F _H	52	3AC _H to 3AF _H
21	330 _H to 333 _H	53	3B0 _H to 3B3 _H
22	334 _H to 337 _H	54	3B4 _H to 3B7 _H
23	338 _H to 33B _H	55	3B8 _H to 3BB _H
24	33C _H to 33F _H	56	3BC _H to 3BF _H
25	340 _H to 343 _H	57	3C0 _H to 3C3 _H
26	344 _H to 347 _H	58	3C4 _H to 3C7 _H
27	348 _H to 34B _H	59	3C8 _H to 3CB _H
28	34C _H to 34F _H	60	3CC _H to 3CF _H
29	350 _H to 353 _H	61	3D0 _H to 3D3 _H
30	354 _H to 357 _H	62	3D4 _H to 3D7 _H
31	358 _H to 35B _H	63	3D8 _H to 3DB _H
32	35C _H to 35F _H	64	3DC _H to 3DF _H

(b) Master station (RWr) ← Remote device station (RWr)/ local station (RWw)


① Master station

- Data to be sent to remote register (RWr) of remote device station and remote register (RWw) of local station are stored.
- Four words are used per station.



② Local station

- Data is sent to the master station and other local stations by storing in the address corresponding to the host station number.
- Data in the remote register (RWw) of remote device station can also be received.



Following tables show the relationship between station numbers and buffer memory addresses used.

[Master station]

Station number and buffer memory correspondence table

Station number	Buffer memory address								
1	2E0 _H to 2E3 _H	14	314 _H to 317 _H	27	348 _H to 34B _H	40	37C _H to 37F _H	53	3B0 _H to 3B3 _H
2	2E4 _H to 2E7 _H	15	318 _H to 31B _H	28	34C _H to 34F _H	41	380 _H to 383 _H	54	3B4 _H to 3B7 _H
3	2E8 _H to 2EB _H	16	31C _H to 31F _H	29	350 _H to 353 _H	42	384 _H to 387 _H	55	3B8 _H to 3BB _H
4	2EC _H to 2EF _H	17	320 _H to 323 _H	30	354 _H to 357 _H	43	388 _H to 38B _H	56	3BC _H to 3BF _H
5	2F0 _H to 2F3 _H	18	324 _H to 327 _H	31	358 _H to 35B _H	44	38C _H to 38F _H	57	3C0 _H to 3C3 _H
6	2F4 _H to 2F7 _H	19	328 _H to 32B _H	32	35C _H to 35F _H	45	390 _H to 393 _H	58	3C4 _H to 3C7 _H
7	2F8 _H to 2FB _H	20	32C _H to 32F _H	33	360 _H to 363 _H	46	394 _H to 397 _H	59	3C8 _H to 3CB _H
8	2FC _H to 2FF _H	21	330 _H to 333 _H	34	364 _H to 367 _H	47	398 _H to 39B _H	60	3CC _H to 3CF _H
9	300 _H to 303 _H	22	334 _H to 337 _H	35	368 _H to 36B _H	48	39C _H to 39F _H	61	3D0 _H to 3D3 _H
10	304 _H to 307 _H	23	338 _H to 33B _H	36	36C _H to 36F _H	49	3A0 _H to 3A3 _H	62	3D4 _H to 3D7 _H
11	308 _H to 30B _H	24	33C _H to 33F _H	37	370 _H to 373 _H	50	3A4 _H to 3A7 _H	63	3D8 _H to 3DB _H
12	30C _H to 30F _H	25	340 _H to 343 _H	38	374 _H to 377 _H	51	3A8 _H to 3AB _H	64	3DC _H to 3DF _H
13	310 _H to 313 _H	26	344 _H to 347 _H	39	378 _H to 37B _H	52	3AC _H to 3AF _H	—	—

[Local station]

Station number and buffer memory correspondence table

Station number	Buffer memory address								
1	1E0 _H to 1E3 _H	14	214 _H to 217 _H	27	248 _H to 24B _H	40	27C _H to 27F _H	53	2B0 _H to 2B3 _H
2	1E4 _H to 1E7 _H	15	218 _H to 21B _H	28	24C _H to 24F _H	41	280 _H to 283 _H	54	2B4 _H to 2B7 _H
3	1E8 _H to 1EB _H	16	21C _H to 21F _H	29	250 _H to 253 _H	42	284 _H to 287 _H	55	2B8 _H to 2BB _H
4	1EC _H to 1EF _H	17	220 _H to 223 _H	30	254 _H to 257 _H	43	288 _H to 28B _H	56	2BC _H to 2BF _H
5	1F0 _H to 1F3 _H	18	224 _H to 227 _H	31	258 _H to 25B _H	44	28C _H to 28F _H	57	2C0 _H to 2C3 _H
6	1F4 _H to 1F7 _H	19	228 _H to 22B _H	32	25C _H to 25F _H	45	290 _H to 293 _H	58	2C4 _H to 2C7 _H
7	1F8 _H to 1FB _H	20	22C _H to 22F _H	33	260 _H to 263 _H	46	294 _H to 297 _H	59	2C8 _H to 2CB _H
8	1FC _H to 1FF _H	21	230 _H to 233 _H	34	264 _H to 267 _H	47	298 _H to 29B _H	60	2CC _H to 2CF _H
9	200 _H to 203 _H	22	234 _H to 237 _H	35	268 _H to 26B _H	48	29C _H to 29F _H	61	2D0 _H to 2D3 _H
10	204 _H to 207 _H	23	238 _H to 23B _H	36	26C _H to 26F _H	49	2A0 _H to 2A3 _H	62	2D4 _H to 2D7 _H
11	208 _H to 20B _H	24	23C _H to 23F _H	37	270 _H to 273 _H	50	2A4 _H to 2A7 _H	63	2D8 _H to 2DB _H
12	20C _H to 20F _H	25	240 _H to 243 _H	38	274 _H to 277 _H	51	2A8 _H to 2AB _H	64	2DC _H to 2DF _H
13	210 _H to 213 _H	26	244 _H to 247 _H	39	278 _H to 27B _H	52	2AC _H to 2AF _H	—	—

(4) Link special relay (SB)

Data link status is stored in the form of bit on/off information.

Buffer memory address 5E0_H to 5FF_H corresponds to SB0000 to SB01FF.

Refer to Section 8.4.1 for details of link special relay (SB0000 to SB01FF).

Following table shows the relationship between buffer memory address 5E0_H to 5FF_H and SB0000 to SB01FF.

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
5E0 _H	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0
5E1 _H	1F	1E	1D	1C	1B	1A	19	18	17	16	15	14	13	12	11	10
5E2 _H	2F	2E	2D	2C	2B	2A	29	28	27	26	25	24	23	22	21	20
5E3 _H	3F	3E	3D	3C	3B	3A	39	38	37	36	35	34	33	32	31	30
5E4 _H	4F	4E	4D	4C	4B	4A	49	48	47	46	45	44	43	42	41	40
5E5 _H	5F	5E	5D	5C	5B	5A	59	58	57	56	55	54	53	52	51	50
5E6 _H	6F	6E	6D	6C	6B	6A	69	68	67	66	65	64	63	62	61	60
5E7 _H	7F	7E	7D	7C	7B	7A	79	78	77	76	75	74	73	72	71	70
5E8 _H	8F	8E	8D	8C	8B	8A	89	88	87	86	85	84	83	82	81	80
5E9 _H	9F	9E	9D	9C	9B	9A	99	98	97	96	95	94	93	92	91	90
5EA _H	AF	AE	AD	9AC	AB	AA	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
5EB _H	BF	BE	BD	BC	BB	BA	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0
5EC _H	CF	CE	CD	CC	CB	CA	C9	C8	C7	C6	C5	C4	C3	C2	C1	C0
5ED _H	DF	DE	DD	DC	DB	DA	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0
5EE _H	EF	EE	ED	EC	EB	EA	E9	E8	E7	E6	E5	E4	E3	E2	E1	E0
5EF _H	FF	FE	FD	FC	FB	FA	F9	F8	F7	F6	F5	F4	F3	F2	F1	F0
5F0 _H	10F	10E	10D	10C	10B	10A	109	108	107	106	105	104	103	102	101	100
5F1 _H	11F	11E	11D	11C	11B	11A	119	118	117	116	115	114	113	112	111	110
5F2 _H	12F	12E	12D	12C	12B	12A	129	128	127	126	125	124	123	122	121	120
5F3 _H	13F	13E	13D	13C	13B	13A	139	138	137	136	135	134	133	132	131	130
5F4 _H	14F	14E	14D	14C	14B	14A	149	148	147	146	145	144	143	142	141	140
5F5 _H	15F	15E	15D	15C	15B	15A	159	158	157	156	155	154	153	152	151	150
5F6 _H	16F	16E	16D	16C	16B	16A	169	168	167	166	165	164	163	162	161	160
5F7 _H	17F	17E	17D	17C	17B	17A	179	178	177	176	175	174	173	172	171	170
5F8 _H	18F	18E	18D	18C	18B	18A	189	188	187	186	185	184	183	182	181	180
5F9 _H	19F	19E	19D	19C	19B	19A	199	198	197	196	195	194	193	192	191	190
5FA _H	1AF	1AE	1AD	1AC	1AB	1AA	1A9	1A8	1A7	1A6	1A5	1A4	1A3	1A2	1A1	1A0
5FB _H	1BF	1BE	1BD	1BC	1BB	1BA	1B9	1B8	1B7	1B6	1B5	1B4	1B3	1B2	1B1	1B0
5FC _H	1CF	1CE	1CD	1CC	1CB	1CA	1C9	1C8	1C7	1C6	1C5	1C4	1C3	1C2	1C1	1C0
5FD _H	1DF	1DE	1DD	1DC	1DB	1DA	1D9	1D8	1D7	1D6	1D5	1D4	1D3	1D2	1D1	1D0
5FE _H	1EF	1EE	1ED	1EC	1EB	1EA	1E9	1E8	1E7	1E6	1E5	1E4	1E3	1E2	1E1	1E0
5FF _H	1FF	1FE	1FD	1FC	1FB	1FA	1F9	1F8	1F7	1F6	1F5	1F4	1F3	1F2	1F1	1F0

(5) Link special register (SW)

Data link status is stored in the form of word information.

Buffer memory address 600_H to 7FF_H corresponds to SW0000 to SW01FF.

Refer to Section 8.4.2 for details of link special register (SW0000 to 01FF).

4. Functions

This chapter describes the functions.

4.1 Function List


The function list is shown in Table 4.1.

Table 4.1 Function list

Item	Function summary	Reference	Function availability		
			Master station	Local station	
Communication between master and remote I/O stations	Performs on/off data communication with remote I/O station.	Section 4.2	○	×	
Communication between master and remote device stations	Performs on/off data and numeric data communication with remote device station.	Section 4.3	○	×	
Communication between master and local stations	Performs on/off data and numeric data communication with local station.	Section 4.4	○	○	
Communication with compound system	Performs communication with remote I/O, remote device and local stations.	Section 4.5	○	○	
Reserved station function	By setting the remote and local stations planned to be connected in the future as reserved stations, these stations will not be treated as error. When specified to an already connected module, data link cannot be performed at all.	Section 4.6	○	×	
Error invalid station function	Remote and local stations that can no longer perform data link due to power off ,etc., will not be treated as data-link faulty stations.	Section 4.7	○	×	
Data-link status setting when a master station programmable controller CPU error occurs	Data-link status can be set when an operation-stop error occurs with the master station programmable controller CPU.	Section 4.8	○	○	
Parameter registration to E ² PROM	By registering the parameters in the master module's E ² PROM, the parameters do not have to be written every time the master module is started up.	Section 6.1	○	×	
Input data from a data-link faulty station status setting	The status (clear/store) of the input (received) data from the data-link faulty station caused by power off, etc. can be set.	Section 4.9	○	○	
Module reset function from a sequence program	When the switch setting is changed or an error occurred with the module, the module can be reset from the sequence program instead of resetting the programmable controller CPU.	Section 4.10	○	○	
Data link stop/restart	When executing the data link from Yn6 or Yn8, the data link can be stopped or restarted.	Section 4.11	○	○	
RAS function	Automatic return function	When the module removed from the data link due to power off, etc. recovers to normal status, the module automatically joins the data link.	Section 4.12.1	○	○
	Slave station cutoff function	The module which no longer can continue the data link due to power off, etc. is removed from the data link, and the data link is continued with only the normal modules.	Section 4.12.2	○	×
	Data link status check (SB/SW)	The data link status can be checked. Can be used for sequence program interlocking, etc.	Section 8.4	○	○
	Offline test	The following tests can be conducted: <ul style="list-style-type: none"> • Hardware test..... Operation check for the individual module • Line test..... Module connection condition check • Parameter verification test..... Verify the set parameter contents 	Section 7.4 Section 7.7 Section 7.8	○	○

4.2 Communication Between the Master Station and Remote I/O Station

The overview of the communication between the master station and remote I/O station is described.



[Data link startup]


- ① Turn on the refresh instruction (Yn0) and make the remote output (RY) data valid. When the refresh instruction (Yn0) is off, all the remote output (RY) data is treated as 0 (off).
- ② Turn on the data link startup by the E²PROM parameters (Yn8), and start the data link. However, the parameters must be set in E²PROM beforehand. When the data link is started normally, the host data link status (Xn1) turns on.

POINT

The data link can be started from the parameters written in the "parameter information area" in the buffer memory. (Refer to Chapter 6.)


[Remote input]

- ③ The remote I/O station's input status is automatically (for each link scan) stored in the master station's "remote input (RX)" in the buffer memory.
- ④ The input status stored in the "remote input (RX)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.




[Remote output]

- ⑤ With the TO instruction, the on/off data output from the remote I/O station is written to the "remote output (RY)" in the buffer memory.
- ⑥ The output status stored in the "remote output (RY)" in the buffer memory is automatically output (for each link scan) from the remote I/O station.



4.3 Communication Between the Master Station and Remote Device Station

The overview of the communication between the master station and remote device station is described.




[Data link startup]

- ① Turn on the refresh instruction (Yn0) and make the remote output (RY) data valid.
When the refresh instruction (Yn0) is off, all the remote output (RY) data is treated as 0 (off).
- ② Turn on the data link startup by the E²PROM parameters (Yn8), and start the data link.
However, the parameters must be set in E²PROM beforehand.
When the data link is started normally, the host data link status (Xn1) turns on.

POINT
The data link can be started from the parameters written in the "parameter information area" in the buffer memory. (Refer to Chapter 6.)


[Remote input]

- ③ The remote device station's remote input (RX) is automatically (for each link scan) stored in the master station's "remote input (RX)" in the buffer memory.
- ④ The input status stored in the "remote input (RX)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.



[Remote output]


- ⑤ With the TO instruction, the on/off data in the remote device station's remote output (RY) is written to the "remote output (RY)" in the buffer memory.
- ⑥ Depending on the output status stored in the "remote output (RY)" in the buffer memory, the remote device station's remote output (RY) is turned on/off.



[Written to the remote register (RWw)]


⑦ With the TO instruction, the transmission data is written to the "remote register (RWw)" in the buffer memory.

⑧ The data stored in the "remote register (RWw)" in the buffer memory is sent to the remote device station's remote register (RWw).




[Reading from the remote register (RWr)]

- ⑨ The data in the remote device station's remote register (RWr) is automatically stored in the master station's "remote register (RWr)" in the buffer memory
- ⑩ The remote device station's remote register (RWr) data stored in the "remote register (RWr)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.




4.4 Communication Between the Master Station and Local Station

The overview of the communication between the master and local stations is described.



POINT
 The master station sends only the data for the stations that have started the data link.
 The data for the stations that have not started the data link are not sent.




[Data link startup]

- ① Turn on the refresh instruction (Yn0) and make the remote output (RY) data valid.
When the refresh instruction (Yn0) is off, all the remote output (RY) data is treated as 0 (off).
- ② Turn on the data link startup by the E²PROM parameters (Yn8) and start the data link.
However, the parameters must be set in the E²PROM beforehand.
When the data link is started normally, the host data link status (Xn1) turns on.

POINT
The data link can also be started from the parameters written in the "parameter data area" in the buffer memory. (Refer to chapter 6.)

[On/off data from local station → master and other local stations]


- ③ With the TO instruction, write the on/off data to be sent to the master and other local stations to the local station's "remote output (RY)" in the buffer memory.
- ④ The data in local station's "remote output (RY)" in the buffer memory is automatically (for each link scan) stored in the master station's "remote input (RX)" in the buffer memory and other local station's "remote output (RY)" in the buffer memory.
- ⑤ The input status stored in the "remote input (RX)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.
- ⑥ The input status stored in the "remote output (RY)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.



... The last 2 bits cannot be used when the master station and the local station are communicating.

[On/off data from the master station → the local station]


- ⑦ With the TO instruction, the on/off data to be sent to the local station is written to the master station's "remote output (RY)" in the buffer memory.
- ⑧ The data in the "remote output (RY)" in the buffer memory is automatically (for each link scan) stored in the local station's remote input (RX) in the buffer memory.
- ⑨ The input status stored in the "remote input (RX)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.



...The last 2 bits cannot be used when the master station and the local station are communicating.

[Word data from the master station to all local stations]

- ⑩ With the TO instruction, the word data to be sent to all local station is written to the master station's "remote register (RWw)" in the buffer memory.
- ⑪ The data in the "remote register (RWw)" in the buffer memory is automatically (for each link scan) stored to all local station's "remote registers (RWr)".
- ⑫ The word data stored in the "remote register (RWr)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.



[Word data from the local station → the master station/other local stations]


⑬ With the TO instruction, the word data to be sent to the master station or other local stations is written to the local station's "remote register (RWw)" in the buffer memory.

However, only writing can be performed to the area corresponding to the host station number.

⑭ The data in the "remote register (RWw)" in the buffer memory is automatically (for each link scan) stored in the master station's "remote register (RWr)" and other local station's "remote register (RWw)".


⑮ The word data stored in the "remote register (RWr)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.


⑯ The word data stored in the "remote register (RWw)" in the buffer memory is received to the programmable controller CPU with the FROM instruction.



4.5 Communication in Compound Systems

The overview of the communication where the remote I/O station, remote device station and local station coexist in the system.






[Data link startup]

- ① Turn on the refresh instruction (Yn0) and make the remote output (RY) data valid.
When the refresh instruction (Yn0) is off, all the remote output (RY) data is treated as 0 (off).
- ② Turn on the data link startup by the E²PROM parameters (Yn8) and start the data link.
However, the parameters must be set in the E²PROM beforehand.
When the data link is started normally, the host data link status (Xn1) turns on.

POINT
The data link can also be started from the parameters written in the "parameter data area" in the buffer memory. (Refer to chapter 6.)

[On/off data from remote I/O station/remote device station/local station → the master station]


- ③ The input of remote I/O station, remote input (RX) of the remote device station and the remote output (RY) of the local station are automatically (for each link scan) stored in the master station's "remote input (RX)" in the buffer memory and local station's "remote output (RY)" in the buffer memory.
- ④ The data in local station's "remote output (RY)" is also stored in other local station's "remote output (RY)".
- ⑤ The input status stored in the "remote input (RY)" in the buffer memory is written to the programmable controller CPU with the FROM instruction.



...The last 2 bits cannot be used when the master station and the local station are communicating.

[On/off data from the master station → the remote I/O station/remote device station/local station]


- ⑥ With the TO instruction, the on/off data to be sent to the remote I/O station, remote device station and local station is written to the master station's "remote output (RY)" in the buffer memory.
- ⑦ The output status in the master station's "remote output (RY)" in the buffer memory is automatically (for each link scan) stored in the remote I/O station and remote device station's "remote output (RX)" and local station's remote input (RY).



...The last 2 bits cannot be used when the master station and the local station are communicating.


[Word data from the master station → remote device station/all local stations]

- ⑧ With the TO instruction, the word data to be sent to remote device station and all local station is written to the master station's "remote register (RWw)" in the buffer memory.
- ⑨ The data in the "remote register (RWw)" in the buffer memory is automatically (for each link scan) stored to remote device station's remote register (RWw) and all local stations' remote registers (RWr).
- ⑩ The transmission data to the remote device station's remote register (RWw) is also sent to the local stations.



[Word data from the remote device station/local station → the master station]

- ⑪ The data in the remote device station's remote register (RWr) is automatically (for each link scan) stored in the master station's remote register (RWr) and all local stations' remote registers (RWw).
- ⑫ The data in the local station's "remote register (RWw)" in the buffer memory is automatically (for each link scan) stored in the master station's remote register (RWr) and other local station's remote register (RWr).
- ⑬ The data of the remote device and local stations stored in the "remote register (RWr)" in the buffer memory is written to the programmable controller CPU with the FROM instruction.



4.6 Reserved Station Function

This is a function to treat the remote and local stations that are not actually connected (but planned for connection in the future) not as "data-link faulty stations".

POINT
If already connected remote and local stations are set as reserved station, the specified remote and local stations cannot perform data link at all.

(1) Setting method

The reserved station specification is performed with parameters (buffer memory address 10H to 13H).

Turn on the bit corresponding to the station number of the station to be reserved. However, for remote/local stations that occupy more than 2 stations, turn on the only bit corresponding to the station number set in the module's station number setting switch.


The buffer memory configuration is shown below. (1 to 64 indicates station numbers.)

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
10H	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
11H	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
12H	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33
13H	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49

(2) Setting example

(a) System configuration example

When one local station and one remote station are to be connected in the future to the system with three remote stations:



(b) Buffer memory setting example

Turn on the 3rd bit, corresponding to station No. 4, and 8th bit, corresponding to station No. 9. (Set "264" for address 10H.)

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
10H	0	0	0	0	0	0	0	1	0	0	0	0	1	0	0	0
11H	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
12H	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
13H	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

4.7 Error Invalid Station Function

This is a function to treat the remote and local stations that cannot perform data links due to power off, etc. not as "data-link faulty stations" on the master station and the local station.

Be careful, however, for errors will not be detected at all if set so.

POINT
 If the remote or local station set as the invalid station and also "specified as a reserved station", the reserved station function has priority.

(1) Setting method

The invalid station specification is performed with parameters (buffer memory address 14H to 17H).

Turn on the bit corresponding to the station number to be set as invalid.

However, for the remote/local station which occupies more than 2 stations, turn on the only bit corresponding to the station number set with the module's station number setting switch.


The buffer memory configuration is shown below. (1 to 64 indicates station numbers.)

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
14H	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
15H	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
16H	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33
17H	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49

(2) Setting example

(a) System configuration example

When specifying the remote station No.3 and local station No.7 as invalid stations in a system where three remote and two local stations are connected:



(b) Buffer memory setting example

Turn on the 2nd bit, corresponding to station No. 3, and 6th bit, corresponding to station No. 7. (Set "68" for address 14H.)

Address	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
14H	0	0	0	0	0	0	0	1	0	0	0	0	1	0	0	0
15H	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
16H	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
17H	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

4.8 Data Link Status Setting when the Master Station Programmable Controller CPU has an Error

The data link status for when the master station's programmable controller CPU has an "operation-stop error" can be set.

The data link between local stations can be continued.

POINT

Even if the master station programmable controller CPU has an "operation-stop error", the data link continues.
--

[Setting method]

Set to the "operation specification when the CPU is down (address 6H)" in the parameter information area of the master station's buffer memory

0..... Stop (default)


1..... Continue

4.9 Setting the Status of Input Data from a Data Link Faulty Station

The input (received) data status from a data-link faulty station can be set.

(1) Target input (received) data

The target buffer-memory area is shown below:



.....Target area of keep/clear.
Area that is kept regardless of setting.

(2) Setting method

This is set with the master/local module's "condition setting switch (DIP switch) SW4".

OFFClear (setting at shipment)

ONKeep the status right before error

POINT

When the data-link faulty station is set as an error-invalid station, the input data from that station (remote input RX, remote output RY) are kept, regardless of the SW4 setting.


4.10 Module Reset Function from a Sequence Program

When the switch setting is changed or an error occurs with the module, the module can be reset from the sequence program instead of resetting the programmable controller CPU.

However, reset cannot be performed when there is module error (Xn0 is on). While the module reset request is being executed, do not execute the FROM/TO instruction for the module. When executing the FROM/TO instruction, provide interlocks using Xn0 (module error), XnF (module ready) and Yn4 (module reset request).

POINT
 Because the programmable controller CPU is not reset, other modules will not be affected at all.

A program example for resetting is shown below.
 This example assumes that the module's first I/O No. is X/Y30.



REMARK

The following changes cannot be performed by the module reset request (Yn4). Turn the power off then on, or reset the programmable controller CPU.

- 1) Station No. 0 (master station) → change to station No. 1 to 64 (local station)
- 2) Station No. 1 to 64 (local station) → change to station No. 0 (master station)
- 3) Mode 0 or 2 → change to test mode

4.11 Data Link Stop/Restart

The data link in the host station can be stopped or restarted.

When the data link is stopped for the master station, the data link for the entire system stops.


(1) The link special relay used in the program is shown below:

- SB0000: Data link restart request
- SB0002: Data link stop request
- SB0041: Data link restart complete
- SB0045: Data link stop complete


(2) A program example to stop/restart the data link is shown below.

This example assumes that the module's first I/O No. is X/Y30.

① Relationship between the programmable controller CPU and master station



② Program example



POINT

SB0000 must be used to start a data link if it has been stopped with SB0002.

4.12 RAS Function

RAS is an abbreviation for Reliability, Availability and Serviceability. This refers to the total ease of use in an automated facility.

4.12.1 Automatic return function


This function allows the remote and local station disconnected from the data link due to power off, etc. to be recovered to the data link automatically when the module returns to normal operation.

When using the automatic return function, set the mode setting switch to "0" or "1".

Mode setting switch	Setting details	Remark
0	Online (remote net mode)	–
1	Online (remote I/O net mode)	–
2	Offline	Data link not possible (disconnected)

4.12.2 Slave station cut-off function

This function allows data link to continue with the normal remote and local stations by cutting off the remote and local stations which cannot perform data links due to power off, etc.



POINT


When the cable is disconnected, the data link cannot be performed because the terminal resistor is missing.

The diagram shows a data link topology with a Master station on the left and two Local stations on the right. Between them are two Remote stations. A wire breakage, indicated by a large 'X', is shown between the second Remote station and the first Local station. Terminating resistors are located at the ends of the data link.

4.12.3 Station number overlap checking function

Checks whether the number of occupied stations overlap, by observing the status of the stations actually connected during data link startup (turn on Yn6 and Yn8).


(Example)



Remote device station (station number 4, occupied stations: 2)

However, if the starting head number overlaps, this would not be a part of the overlap checking.

(Example)



Remote device station (station number 1, occupied stations: 2)

- (1) When there is an overlap, the "M/S" LED flashes, and the overlap status is stored in SW0098 to SW009B.
- (2) Even if overlap exists, data link can be continued with other normally functioning stations.
- (3) By correcting the switch setting to the normal status and starting up the data link (turn on Yn6 and Yn8) again, the "M/S" LED is turned off and the data in SW0098 to SW009B are cleared.

5. Data Link Processing Time

5.1 Status of Each Station when an Error has Occurred

The status of each station when an error has occurred is shown in the table below.

Data link status				Master station				Remote I/O station	
				Remote input (RX)	Remote output (RY)	Remote register (RWw)	Remote register (RWr)	Input	Output
When the master station's programmable controller CPU is stopped (data link continuous)				Continue	All "0" * 1	Continue	Continue	Continue	All points OFF
When the local station's programmable controller CPU is stopped (data link continuous)				All points off in the receive area from the stopped local station * 1		Continue	Continue	Continue	Continue
When the data link is stopped in the entire system	Input-data status setting of faulty station (SW4)	Master station	Clear	Clear	-	-	Keep	-	All points OFF
			Keep	Keep					
		Local station	Clear						
			Keep						
When a communication error (power off, etc.) occurred in a remote I/O station.	Input-data status setting of faulty station (SW4)	Master station	Clear	Clear the receive area from the remote I/O station with communication error.	Continue	Continue	Continue	-	All points OFF
			Keep	Keep the receive area from the remote I/O station with communication error.					
		Local station	Clear						
			Keep						
When a remote communication error (power off, etc.) occurred in a remote device station	Input-data status setting of faulty station (SW4)	Master station	Clear	Clear the receive area from the remote device station with communication error.	Continue	Continue	Keep the receive area from the remote device station with communication error.	Continue	Continue
			Keep	Keep the receive area from the remote device station with communication error.					
		Local station	Clear						
			Keep						
When there is a communication error (power off, etc.) with the local station.	Input-data status setting of faulty station (SW4)	Master station	Clear	Clear the receive area from the local station with communication error.	Continue	Continue	Keep the receive area from the local station with communication error.	Continue	Continue
			Keep	Keep the receive area from the local station with communication error.					
		Local station	Clear						
			Keep						

* 1 : Because Yn0 (refresh instruct) is turned OFF.

Data link status				Remote device station				Local station, standby master station, intelligent device station				
				Remote input (RX)	Remote output (RY)	Remote register (RWw)	Remote register (RWr)	Remote input (RX)	Remote output (RY)	Remote register (RWw)	Remote register (RWr)	
When the master station's programmable controller CPU is stopped (data link continuous)				Continue	All points OFF	Continue	Continue	All points OFF	Continue	Continue	Continue	
When the local station's programmable controller CPU is stopped (data link continuous)				Continue	Continue	Continue	Continue	Continue	All station's transmission areas are treated as "0". *1 All points off in the receive area from the stopped local station	Continue	Continue	
When the data link is stopped in the entire system	Input-data status setting of faulty station (SW4)	Master station	Clear	-	All points OFF	-	-	Clear	Clear the receive area from the other station.	Keep the receive area from the other station.	Keep	
		Local station	Keep									
When a communication error (power off, etc.) occurred in a remote I/O station	Input-data status setting of faulty station (SW4)	Master station	Clear	Continue	Continue	Continue	Continue	Continue	Clear the receive area from the remote I/O station with communication error.	Keep the receive area from the remote I/O station with communication error.	Continue	Continue
		Local station	Keep									
When a communication error (power off, etc.) occurred in a remote device station	Input-data status setting of faulty station (SW4)	Master station	Clear	-	-	-	-	Continue	Clear the receive area from the remote device station with communication error.	Keep the receive area from the remote device station with communication error.	Continue	Continue
		Local station	Keep									

* 1 : Because Yn0 (refresh instruct) is turned OFF.

Data link status				Remote device station				Local station, standby master station, intelligent device station			
				Remote input (RX)	Remote output (RY)	Remote register (RWw)	Remote register (RWr)	Remote input (RX)	Remote output (RY)	Remote register (RWw)	Remote register (RWr)
When there is a communication error (power off, etc.) with the local station.	Input-data status setting of faulty station (SW4)	Master station	Clear	Continue	Continue	Continue	Continue	Continue	Clear the receive area from the local station with communication error.	Keep the receive area from the local station with communication error.	Continue
		Local station	Keep								

5.2 Link Scan Time

The link scan time of CC-Link is calculated as follows using :

[Link scan time (LS)]

$$LS = BT \{29.4 + (NI \times 4.8) + (NW \times 9.6) + (N \times 32.4) + (ni \times 4.8) + (nw \times 9.6)\} + ST + \{\text{Number of communication faulty stations} \times 48 \times BT \times \text{Number of retries}\}^* \quad [\mu s]$$

BT: Constant (Transmission speed)

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
BT	51.2	12.8	3.2	1.6	0.8

NI : Last station number in a, b, and c
(including number of occupied stations and excluding number of reserved stations)

NW : Last station in b and c
(Including number of occupied stations and excluding number of reserved stations)

It should be the multiple of 8.

Last station number	1 to 8	9 to 16	17 to 24	25 to 32	33 to 40	41 to 48	49 to 56	57 to 64
NI, NW	8	16	24	32	40	48	56	64

N : Number of connected stations (excluding reserved stations)

ni : a + b + c (excluding reserved stations)

nw : b + c (excluding reserved stations)

ST: Constant (It should be the largest value from (1) to (3). When b = 0, (2) should be ignored and, when c = 0, (3) should be ignored.)

① 800 + (a × 15)

② 900 + (b × 50)

③ When c ≤ 26: 1200 + (c × 100)
When c > 26: 3700 + {(c - 26) × 25}


a : Total number of occupied stations for remote I/O stations

b : Total number of occupied stations for remote device stations

c : Total number of occupied stations for intelligent device stations (including local stations)

* : Only when there exist communication faulty stations (including error invalid stations and temporary error invalid stations)

(Example) When the transmission speed is at 2.5 Mbps in the following system configuration:



*1: 1 station occupied *2: 2 stations occupied *3: 4 stations occupied

BT = 3.2 ST = 1700

NI = 13 → 16 ① 800 + (4 × 15) = 860

NW = 12 → 16 ② 900 + (4 × 50) = 1100

N = 8 ③ 1200 + (5 × 100) = 1700

ni = 13 a=4 b=4 c=5

nw = 9

LS = 3.2 {29.4 + (16 × 4.8) + (16 × 9.6) + (8 × 32.4) + (13 × 4.8) + (9 × 9.6)} + 1700

= 3836.96 [μs]

= 3.84 [ms]

5.3 Transmission Delay Time

Indicates transmission delay time (time required for data transmission).

5.3.1 Master station ↔ remote I/O station

(1) Master station (RX) ← remote I/O station (input)


[Expression]

$$SM + LS \times 3 + \text{Remote I/O station response time [ms]}$$

SM: Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

[Data flow]



(2) Master station (RY) → remote I/O station (output)


[Expression]

$$SM + LS \times 3 + \text{Remote I/O station response time [ms]}$$

SM: Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

[Data flow]



5.3.2 Master station ↔ remote device station

(1) Master station (RX) ← remote device station (RX)


[Expression]

$$SM + LS \times 2 + \text{Remote device station process time [ms]}$$

SM: Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

[Data flow]



(2) Master station (RY) → remote device station (RY)


[Expression]

$$SM + LS \times 3 + \text{Remote device station process time [ms]}$$

SM: Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

[Data flow]



(3) Master station (RWw) → remote device station (RWw)


[Expression]

$$SM + LS \times 3 + \text{Remote device station process time [ms]}$$

SM: Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

[Data flow]



(4) Master station (RWr) ← remote device station (RWr)


[Expression]

$$SM + LS \times 2 + \text{Remote device station process time [ms]}$$

SM: Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

[Data flow]



5.3.3 Master station ↔ local station

(1) Master station (RY) → local station (RX)

[Expression]


$$SM + LS \times 3 + SL \text{ [ms]}$$

SM : Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

SL : Scan time of the local station's sequence program

[Data flow]



(2) Master station (RX) ← local station (RY)

[Expression]


$$SM + LS \times 3 + SL \text{ [ms]}$$

SM : Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

SL : Scan time of the local station's sequence program

[Data flow]



(3) Master station (RWw) → local station (RWr)

[Expression]


$$SM + LS \times 3 + SL \text{ [ms]}$$

SM : Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

SL : Scan time of the local station's sequence program

[Data flow]



(4) Master station (RWr) ← local station (RWw)

[Expression]


$$SM + LS \times 3 + SL \text{ [ms]}$$

SM : Scan time of the master station's sequence program

LS : Link scan time (See Section 5.2.)

SL : Scan time of the local station's sequence program

[Data flow]



5.3.4 Master station ↔ intelligent device station

The transmission delay time between the master station and intelligent device station varies depending on the type of intelligent device station.

Refer to the user's manual of the intelligent device used.

5.4 Dedicated Instruction Processing Time

Indicates the dedicated instruction processing time (time from when an instruction is issued until a reply is received).

5.4.1 Master station ↔ local station

(1) Master station → local station

Indicates the time from when the master station issues an instruction until it receives a reply from a local station.

[Expression]

(a) For reading

$$MB = [SM + LS \times 2 + \alpha + SL + LS \times 2 + \{(No. \text{ of reading points} + 16)/16\}^{*1} \times LS + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SM : Master station sequence scan time

SL : Local station sequence scan time

LS : Link scan time (Refer to section 5.2)

α : Send end internal processing time

No. of reading points	1 to 120 points	121 to 240 points	241 to 360 points	361 to 480 points
α	LS	LS × 2	LS × 3	LS × 4

β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When master station sequence scan time is 10ms, local station sequence scan time is 10ms, link scan time is 5ms, no. of reading points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SM + LS \times 2 + \alpha + SL + LS \times 2 + \{(No. \text{ of reading points} + 16)/16\}^{*1} \times LS + \beta + \text{constant bps}] \times N \\ &= [10 + 5 \times 2 + 5 + 10 + 5 \times 2 + \{(20 + 16)/16\}^{*1} \times 5 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 \times 2 + 5 + 10 + 5 \times 2 + 3 \times 5 + 5 + 5 \times 7] \times 1 \\ &= 100 \text{ [ms]} \end{aligned}$$

(b) For writing

$$MB = [SM + LS + \{(No. \text{ of writing points} + 16)/72\}^{*1} \times LS + \alpha + SL + LS \times 3 + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SM : Master station sequence scan time

SL : Local station sequence scan time

LS : Link scan time (Refer to section 5.2)

α : Send end internal processing time

LS

β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When master station sequence scan time is 10ms, local station sequence scan time is 10ms, link scan time is 5ms, no. of writing points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SM + LS + \{(No. \text{ of writing points} + 16)/72\}^{*1} \times LS + \alpha + SL + LS \times 3 + \beta + \text{constant bps}] \times N \\ &= [10 + 5 + \{(20 + 16)/72\}^{*1} \times 5 + 5 + 10 + 5 \times 3 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 + 1 \times 5 + 5 + 10 + 5 \times 3 + 5 + 5 \times 7] \times 1 \\ &= 90 \text{ [ms]} \end{aligned}$$

(2) Local station → master station

Indicates the time from when a local station issues an instruction until it receives a reply from the master station.

[Expression]

(a) For reading

$$MB = [SL + LS \times 3 + \alpha + SM + LS + \{(No. \text{ of reading points} + 16)/72\}^{*1} \times LS + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SM : Master station sequence scan time

SL : Local station sequence scan time

LS : Link scan time (Refer to section 5.2)

α : Send end internal processing time

LS

β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When master station sequence scan time is 10ms, local station sequence scan time is 10ms, link scan time is 5ms, no. of reading points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SL + LS \times 3 + \alpha + SM + LS + \{(No. \text{ of reading points} + 16)/72\}^{*1} \times LS + \beta + \text{constant bps}] \times N \\ &= [10 + 5 \times 3 + 5 + 10 + 5 + \{(20 + 16)/72\} \times 5 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 \times 3 + 5 + 10 + 5 + 1 \times 5 + 5 + 5 \times 7] \times 1 \\ &= 90 \text{ [ms]} \end{aligned}$$

(b) For writing

$$MB = [SL + LS \times 2 + \{(No. \text{ of writing points} + 16)/16\}^{*1} \times LS + \alpha + SM + LS \times 2 + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SM : Master station sequence scan time

SL : Local station sequence scan time

LS : Link scan time (Refer to section 5.2)

 α : Send end internal processing time

No. of writing points	1 to 120 points	121 to 240 points	241 to 360 points	361 to 480 points
α	LS	LS × 2	LS × 3	LS × 4

 β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When master station sequence scan time is 10ms, local station sequence scan time is 10ms, link scan time is 5ms, no. of writing points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SL + LS \times 2 + \{(No. \text{ of writing points} + 16)/16\}^{*1} \times LS + \alpha + SM + LS \times 2 + \beta + \text{constant bps}] \times N \\ &= [10 + 5 \times 2 + \{(20 + 16)/16\} \times 5 + 5 + 10 + 5 \times 2 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 \times 2 + 3 \times 5 + 5 + 10 + 5 \times 2 + 5 + 5 \times 7] \times 1 \\ &= 100 \text{ [ms]} \end{aligned}$$

5.4.2 Local station ↔ local station

(1) Local station → local station

Indicates the time from when a local station issues an instruction until it receives a reply from another local station.

[Expression]

(a) For reading

$$MB = [SL_1 + LS \times 3 + \alpha + SL_2 + LS \times 2 + \{(No. \text{ of reading points} + 16)/16\}^{*1} \times LS + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SL₁: Send end local station sequence scan time

SL₂: Receive end local station sequence scan time

LS : Link scan time (Refer to section 5.2)

α : Send end internal processing time

No. of reading points	1 to 120 points	121 to 240 points	241 to 360 points	361 to 480 points
α	LS	LS × 2	LS × 3	LS × 4

β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When send end local station sequence scan time is 10ms, receive end local station sequence scan time is 10ms, link scan time is 5ms, no. of reading points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SL_1 + LS \times 3 + \alpha + SL_2 + LS \times 2 + \{(20 + 16)/16\}^{*1} \times LS + \beta + \text{constant bps}] \times N \\ &= [10 + 5 \times 3 + 5 + 10 + 5 \times 2 + \{(20 + 16)/16\}^{*1} \times 5 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 \times 3 + 5 + 10 + 5 \times 2 + 3 \times 5 + 5 + 5 \times 7] \times 1 \\ &= 105 \text{ [ms]} \end{aligned}$$

(b) For writing

$$MB = [SL_1 + LS \times 2 + \{(No. \text{ of writing points} + 16)/16\}^{*1} \times LS + \alpha + SL_2 + LS \times 3 + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SL₁: Send end local station sequence scan time

SL₂: Receive end local station sequence scan time

LS : Link scan time (Refer to section 5.2)

α : Send end internal processing time

No. of writing points	1 to 120 points	121 to 240 points	241 to 360 points	361 to 480 points
α	LS	LS × 2	LS × 3	LS × 4

β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When send end local station sequence scan time is 10ms, receive end local station sequence scan time is 10ms, link scan time is 5ms, no. of writing points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SL_1 + LS \times 2 + \{(No. \text{ of writing points} + 16)/16\}^{*1} \times LS + \alpha + SL_2 + LS \times 3 + \beta + \text{constant bps}] \times N \\ &= [10 + 5 \times 2 + \{(20 + 16)/16\}^{*1} \times 5 + 5 + 10 + 5 \times 3 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 \times 2 + 3 \times 5 + 5 + 10 + 5 \times 3 + 5 + 5 \times 7] \times 1 \\ &= 105 \text{ [ms]} \end{aligned}$$

5.4.3 Master station ↔ intelligent device station

(1) Master station → intelligent device station

Indicates the time from when the master station issues an instruction until it receives a reply from an intelligent device station.

[Expression]

(a) For reading

$$MB = [SM + LS \times 2 + \alpha + SM + LS \times 2 + \{(No. \text{ of reading points} + 16)/16\}^{*1} \times LS + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SM : Master station sequence scan time

LS : Link scan time (Refer to section 5.2)

α : Send end internal processing time

No. of reading points	1 to 120 points	121 to 240 points	241 to 360 points	361 to 480 points
α	LS	LS × 2	LS × 3	LS × 4

β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When master station sequence scan time is 10ms, link scan time is 5ms, no. of reading points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SM + LS \times 2 + \alpha + SM + LS \times 2 + \{(No. \text{ of reading points} + 16)/16\}^{*1} \times LS + \beta + \text{constant bps}] \times N \\ &= [10 + 5 \times 2 + 5 + 10 + 5 \times 2 + \{(20 + 16)/16\}^{*1} \times 5 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 \times 2 + 5 + 10 + 5 \times 2 + 3 \times 5 + 5 + 5 \times 7] \times 1 \\ &= 100 \text{ [ms]} \end{aligned}$$

(b) For writing

$$MB = [SM + LS + \{(No. \text{ of writing points} + 16)/72\}^{*1} \times LS + \alpha + SM + LS \times 3 + \beta + \text{constant bps}] \times N \text{ [ms]}$$

SM: Master station sequence scan time

LS : Link scan time (Refer to section 5.2)

 α : Send end internal processing time

LS

 β : Receive end internal processing time

LS

[Constant bps]

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
constant bps	LS	LS × 2	LS × 4	LS × 6	LS × 7

N : No. of execution instructions simultaneously

*1 : Raise the decimals to a unit

(Example) When master station sequence scan time is 10ms, link scan time is 5ms, no. of writing points is 20 words, transmission speed is 10Mbps, no. of execution instructions simultaneously is 1

$$\begin{aligned} MB &= [SM + LS + \{(No. \text{ of writing points} + 16)/72\}^{*1} \times LS + \alpha + SM + LS \times 3 + \beta + \text{constant bps}] \times N \\ &= [10 + 5 + \{(20 + 16)/72\}^{*1} \times 5 + 5 + 10 + 5 \times 3 + 5 + 5 \times 7] \times 1 \\ &= [10 + 5 + 1 \times 5 + 5 + 10 + 5 \times 3 + 5 + 5 \times 7] \times 1 \\ &= 90 \text{ [ms]} \end{aligned}$$

6. Parameter Setting

The parameter setting necessary to perform data link with CC-Link is described.

6.1 Procedure from Parameter Setting to Data Link Startup

The flow from setting the parameters to starting the data link is described.

6.1.1 Relationship between buffer memory, E²PROM and internal memory

The relationship between the master station buffer memory, E²PROM and the internal memory is described.

(1) Buffer memory

This is a temporary storage area to write the parameter information to E²PROM or internal memory.

When the module power is turned off, the parameter information is erased.

(2) E²PROM

By just turning on the data-link start request by the E²PROM parameters (Yn8), data link can be started.

This eliminates having to write parameters to the buffer memory every time when starting up the master station.

However, the parameters must be stored in E²PROM by the parameter storage request to E²PROM (YnA) beforehand.


Even when the power is turned off, the E²PROM parameter information will be kept.

The registration limit to E²PROM is "10,000 times".

(3) Internal memory

Data link is executed using the parameter information stored in the internal memory.

When the module power is turned off, the parameters are erased.


**POINT**

"Data link by buffer-memory parameters" is recommended for starting system debugging, and "data link by E²PROM parameters" is recommended for the operation after debugging.

Therefore, the number of steps in the operation program can be reduced (thus, shortens the scan time).

6.1.2 Procedure from parameter setting to data link start

Follow the procedure below:



6.2 Parameter Settings

The items to set in the master station's "parameter information area (address 0H to 5FH)" in the buffer memory is shown in Table 6.1.
Refer to Section 3.5.2 for details of each item.

Table 6.1 Parameter setting items

Setting item	Description	Buffer memory address	Reference						
Number of connected modules	Sets the number of modules in the remote and local stations connected to the master station (including reserved stations) Default : 64 (modules) Setting range : 1 to 64 (modules)	1H	Section 3.5.2 (1) (a)						
Number of retries	Sets the number of retries when there is a communication error. Default : 3 (times) Setting range : 1 to 7 (times)	2H	Section 3.5.2 (1) (b)						
Number of automatic return modules	Sets the number of remote and local stations that can be recovered with one link scan. Default : 1 (modules) Setting range : 1 to 10 (modules)	3H	Section 3.5.2 (1) (c)						
Operation specification when CPU is down	Specifies the data-link status when the master station programmable controller CPU has an error. Default : 0 (stop) Setting range : 0 (stop) 1 (continue)	6H	Section 3.5.2 (1) (d)						
Reserved station specification	Specifies reserved stations. Default : 0 (no setting) Setting range : Turn on the bit corresponding to the station number.	10H to 13H	Section 3.5.2 (1) (e)						
Invalid station specification	Specifies invalid stations. Default : 0 (no setting) Setting range : Turn on the bit corresponding to the station number.	14H to 17H	Section 3.5.2 (1) (f)						
Station information	Sets the connected remote and local station type. Default : 0101H (remote I/O station, occupies 1 station, station No. 1) to 0140H (remote I/O station, occupies 1 station, station No. 64) Setting range : As follows. <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%; text-align: center;">b15 to b12</td> <td style="width: 33%; text-align: center;">b11 to b8</td> <td style="width: 33%; text-align: center;">b7 to b0</td> </tr> <tr> <td style="text-align: center;">Station type</td> <td style="text-align: center;">Number of occupied stations</td> <td style="text-align: center;">Station number</td> </tr> </table> </div> <ul style="list-style-type: none"> 1: Occupies 1 station 2: Occupies 2 stations 3: Occupies 3 stations 4: Occupies 4 stations <ul style="list-style-type: none"> 0: Remote I/O station 1: Remote device station 2: Intelligent device station (including local stations) 	b15 to b12	b11 to b8	b7 to b0	Station type	Number of occupied stations	Station number	20H (1st station) to 5FH (64th station)	Section 3.5.2 (1) (g)
b15 to b12	b11 to b8	b7 to b0							
Station type	Number of occupied stations	Station number							


6.3 Setting from a Sequence Program


The parameter setting from a sequence program is described.

(1) Program overview


This program assumes that the master station's first I/O number is X/Y20 to 3F.

(a) When debugging






(b) During operation



(2) Program example


A parameter-setting program example with the following system configuration is shown below:


(a) System configuration example



(b) Program example


① When debugging





* : Refer to Section 8.2 when using the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.


② During operation



7. Data Link Procedure

7.1 Data Link Procedure

The procedure of performing CC-Link's data link is shown below:



7.2 Installation and Setting

The following section explains the precautions when handling the master and local modules, from the time they are unpacked until they are installed.

For more details on the module installation, refer to the user's manual for the CPU module used.

7.2.1 Precautions when handling the module

- (1) Do not drop the module case or subject it to heavy impact since it is made of resin.
- (2) Do not remove the PCB of each module from its case. This may cause a failure in the module.
- (3) Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- (4) Solderless terminals with insulation sleeve cannot be used for the terminal block. It is recommended that the wiring connecting sections of the solderless terminals will be covered with a marking tube or an insulation tube.
- (5) Before handling the module, touch a grounded metal object to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.
- (6) Tighten the module mounting screws and terminal screws within the following torque ranges.

Screw location	Tightening torque range
Module mounting screws (M4 screws)	0.78 to 1.18 N · m
Terminal block screws (M3.5 screws)	0.59 to 0.88 N · m
Terminal block installation screws (M3.5 screws)	0.49 to 0.78 N · m

- (7) Insert the tabs at the bottom of the module into the holes in the base unit before mounting the module. (For the AnS series modules, tighten the screws to the base unit with the specified torque.)
Incorrect mounting may cause malfunction, failure, or drop of the module.

POINT
<p>(1) Turn off the power supply to the applicable station before installing or removing the terminal block. If the terminal block is installed or removed without turning off the power supply to the applicable station, correct data transmission cannot be guaranteed.</p> <p>(2) Power off the system in advance when removing the terminating resistor to change the system. If the terminating resistor is removed and installed while the system is energized, normal data transmission will not be guaranteed.</p>


7.2.2 Setting environment

To install the A-series programmable controller, avoid the following environment:

- (1) Areas where the ambient temperature exceeds the range of 0 to 55°C
- (2) Areas where the ambient humidity exceeds the range of 10 to 90%RH
- (3) Areas where condensation appears from sudden temperature changes
- (4) Areas with corrosive or flammable gas
- (5) Areas with a lot of dust, conductive metal pieces, oil mist, sodium or organic solvents
- (6) Areas with direct sunlight
- (7) Areas where strong electric or magnetic fields are formed
- (8) Areas where direct vibration or shock is applied

7.3 Name of Each Part and Settings





The name of each part in the master/local module, contents of LED display and the setting method of each switch are described.







No.	Name	Description																																	
①	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p style="text-align: center; font-weight: bold; font-size: 1.2em;">AJ61BT11</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">RUN</td> <td style="width: 50%;">156K</td> <td rowspan="2" style="text-align: center; font-weight: bold; font-size: 0.8em;">B R A T E</td> </tr> <tr> <td>ERR.</td> <td>625K</td> </tr> <tr> <td>MST</td> <td>2.5M</td> <td rowspan="4" style="text-align: center; font-weight: bold; font-size: 0.8em;">R O R R I E</td> </tr> <tr> <td>S MST</td> <td>5M</td> </tr> <tr> <td>LOCAL</td> <td>10M</td> </tr> <tr> <td>CPU R/W</td> <td></td> </tr> <tr> <td>SW</td> <td>TEST</td> <td rowspan="4" style="text-align: center; font-weight: bold; font-size: 0.8em;">T E S T</td> </tr> <tr> <td>M/S</td> <td>S0</td> </tr> <tr> <td>PRM</td> <td>S1</td> </tr> <tr> <td>TIME</td> <td>S2</td> </tr> <tr> <td>LINE</td> <td></td> <td></td> </tr> <tr> <td colspan="3" style="padding-top: 10px;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">L RUN</td> <td style="width: 50%;">SD</td> </tr> <tr> <td>L ERR.</td> <td>RD</td> </tr> </table> </td> </tr> </table></div>	RUN	156K	B R A T E	ERR.	625K	MST	2.5M	R O R R I E	S MST	5M	LOCAL	10M	CPU R/W		SW	TEST	T E S T	M/S	S0	PRM	S1	TIME	S2	LINE			<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">L RUN</td> <td style="width: 50%;">SD</td> </tr> <tr> <td>L ERR.</td> <td>RD</td> </tr> </table>			L RUN	SD	L ERR.	RD	Data link status can be checked from the LED on status.
		RUN	156K		B R A T E																														
		ERR.	625K																																
		MST	2.5M	R O R R I E																															
		S MST	5M																																
		LOCAL	10M																																
		CPU R/W																																	
		SW	TEST	T E S T																															
		M/S	S0																																
		PRM	S1																																
		TIME	S2																																
		LINE																																	
		<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">L RUN</td> <td style="width: 50%;">SD</td> </tr> <tr> <td>L ERR.</td> <td>RD</td> </tr> </table>			L RUN	SD	L ERR.	RD																											
		L RUN	SD																																
		L ERR.	RD																																
				LED display status																															
				<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="2">Master station (Standby master station (control status))</th> <th colspan="2">Local station (Standby master station (standby status))</th> </tr> <tr> <th>When normal</th> <th>When error</th> <th>When normal</th> <th>When error</th> </tr> </table>	Master station (Standby master station (control status))		Local station (Standby master station (standby status))		When normal	When error	When normal	When error																							
		Master station (Standby master station (control status))		Local station (Standby master station (standby status))																															
		When normal	When error	When normal	When error																														
		LED name	Description																																
		RUN	ON: Module is normal. OFF: Watchdog timer error.	On	Off	On	Off																												
		ERR.	Indicates the communication status with the station set in the parameter. ON: Communication error at all stations. Flashing: Communication faulty station exists.	Off	On or flashing	Off	On or flashing																												
		MST	ON: Set as master station.	On	-	Off	-																												
		S MST	ON: Set as a standby master station (planned in the future).	(On)	-	(On)	-																												
LOCAL	ON: Set as a local station.	Off	-	On	-																														
CPU R/W	ON: Communicating with programmable controller CPU. (FROM/TO)	On	Off	On	Off																														
ERROR	SW	ON: Switch setting error	Off	On	Off	On																													
	M/S	ON: Master station already exists on the same line. Flashing: Occupied station count overlapping (With the exception of the first station number overlapping)	Off	On or flashing	-	-																													
	PRM	ON: Parameter setting error.	Off	On	-	-																													
	TIME	ON: Cable disconnection, or no response from all stations due to noise in a communication path.	Off	On	-	-																													
	LINE	ON: Cable disconnection, or transmission path is affected by noise, etc.	Off	On	Off	On																													
	L RUN	ON: In data link (host). *1	On	Off	On	Off																													
L ERR.	ON: Communication error (host) Flashing at regular intervals : The setting(s) of switches ② to ⑤ was changed while the power was on. *2 Flashing at irregular intervals : Terminating resistor is not connected, or module and/or CC-Link dedicated cable is affected by noise.	Off	On or flashing	Off	On or flashing																														
B RATE	156K	ON: Transmission speed is set to "156 kbps"	④ Transmission speed set by the transmission speed setting switch is turned on.																																
	625K	ON: Transmission speed is set to "625 kbps"																																	
	2.5M	ON: Transmission speed is set to "2.5 Mbps"																																	
	5M	ON: Transmission speed is set to "5 Mbps"																																	
10M	ON: Transmission speed is set to "10 Mbps"																																		
TEST	TEST	ON: Offline test in progress	Refer to Sections 7.4 and 7.8.		Refer to Section 7.4.																														
	S0	(Not used)																																	
	S1																																		
	S2																																		
SD	ON: Sending data	On	Off	On	Off																														
RD	ON: Receiving data	On	Off	On	Off																														

* 1: When the module is operated in the synchronous mode, the "L RUN" LED may be lit dimly.

* 2: When all stations are in error, changes on switches may not be detected.

No.	Name	Description																																																																																							
②	<p>Station number setting switch AJ61BT11</p>  <p>A1SJ61BT11</p> 	<p>Set the module's station number (setting at shipment: 0)</p> <p><Range></p> <ul style="list-style-type: none"> In the remote net mode <ul style="list-style-type: none"> Master station : 0 Local station : 1 to 64 Standby master station : 1 to 63 The "SW" and "L ERR." LEDs are turned on when a value other than 0 to 64 is set. In the remote I/O net mode <ul style="list-style-type: none"> Master station : 1 to 64 (Set the last station number of remote I/O stations) When set to 0, the "PLM" LED is turned on. 																																																																																							
③	<p>Mode setting switch AJ61BT11</p>  <p>A1SJ61BT11</p> 	<p>Sets the module operation status. (setting at shipment: 0)</p> <table border="1" data-bbox="579 745 1439 1366"> <thead> <tr> <th rowspan="2">Number</th> <th rowspan="2">Name</th> <th rowspan="2">Description</th> <th colspan="2">Setting</th> </tr> <tr> <th>Master station</th> <th>Local station</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Online (remote net mode)</td> <td>Used when data link is performed in remote net mode</td> <td>Enabled</td> <td>Enabled</td> </tr> <tr> <td>1</td> <td>Online (remote I/O net mode)</td> <td>Used when data link is performed in remote I/O net mode</td> <td>Enabled</td> <td>Disabled</td> </tr> <tr> <td>2</td> <td>Offline</td> <td>Data-link disconnection status</td> <td>Enabled</td> <td>Enabled</td> </tr> <tr> <td>3</td> <td>Line Test 1</td> <td>Refer to Section 7.7.1.</td> <td>Enabled</td> <td>Disabled</td> </tr> <tr> <td>4</td> <td>Line Test 2</td> <td>Refer to Section 7.7.2.</td> <td>Enabled</td> <td>Disabled</td> </tr> <tr> <td>5</td> <td>Parameter verification test</td> <td>Refer to Section 7.8.</td> <td>Enabled</td> <td>Disabled</td> </tr> <tr> <td>6</td> <td>Hardware test</td> <td>Refer to Section 7.4.</td> <td>Enabled</td> <td>Enabled</td> </tr> <tr> <td>7</td> <td>(Unusable)</td> <td>Setting error (the "SW" LED on)</td> <td>-</td> <td>-</td> </tr> <tr> <td>8</td> <td>(Unusable)</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>9</td> <td>(Unusable)</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>A</td> <td>(Unusable)</td> <td>-</td> <td>-</td> <td>-</td> </tr> <tr> <td>B</td> <td>(Unusable)</td> <td>Setting error (the "SW" LED on)</td> <td>-</td> <td>-</td> </tr> <tr> <td>C</td> <td>(Unusable)</td> <td>Setting error (the "SW" LED on)</td> <td>-</td> <td>-</td> </tr> <tr> <td>D</td> <td>(Unusable)</td> <td>Setting error (the "SW" LED on)</td> <td>-</td> <td>-</td> </tr> <tr> <td>E</td> <td>(Unusable)</td> <td>Setting error (the "SW" LED on)</td> <td>-</td> <td>-</td> </tr> <tr> <td>F</td> <td>(Unusable)</td> <td>Setting error (the "SW" LED on)</td> <td>-</td> <td>-</td> </tr> </tbody> </table>	Number	Name	Description	Setting		Master station	Local station	0	Online (remote net mode)	Used when data link is performed in remote net mode	Enabled	Enabled	1	Online (remote I/O net mode)	Used when data link is performed in remote I/O net mode	Enabled	Disabled	2	Offline	Data-link disconnection status	Enabled	Enabled	3	Line Test 1	Refer to Section 7.7.1.	Enabled	Disabled	4	Line Test 2	Refer to Section 7.7.2.	Enabled	Disabled	5	Parameter verification test	Refer to Section 7.8.	Enabled	Disabled	6	Hardware test	Refer to Section 7.4.	Enabled	Enabled	7	(Unusable)	Setting error (the "SW" LED on)	-	-	8	(Unusable)	-	-	-	9	(Unusable)	-	-	-	A	(Unusable)	-	-	-	B	(Unusable)	Setting error (the "SW" LED on)	-	-	C	(Unusable)	Setting error (the "SW" LED on)	-	-	D	(Unusable)	Setting error (the "SW" LED on)	-	-	E	(Unusable)	Setting error (the "SW" LED on)	-	-	F	(Unusable)	Setting error (the "SW" LED on)	-	-
Number	Name	Description				Setting																																																																																			
			Master station	Local station																																																																																					
0	Online (remote net mode)	Used when data link is performed in remote net mode	Enabled	Enabled																																																																																					
1	Online (remote I/O net mode)	Used when data link is performed in remote I/O net mode	Enabled	Disabled																																																																																					
2	Offline	Data-link disconnection status	Enabled	Enabled																																																																																					
3	Line Test 1	Refer to Section 7.7.1.	Enabled	Disabled																																																																																					
4	Line Test 2	Refer to Section 7.7.2.	Enabled	Disabled																																																																																					
5	Parameter verification test	Refer to Section 7.8.	Enabled	Disabled																																																																																					
6	Hardware test	Refer to Section 7.4.	Enabled	Enabled																																																																																					
7	(Unusable)	Setting error (the "SW" LED on)	-	-																																																																																					
8	(Unusable)	-	-	-																																																																																					
9	(Unusable)	-	-	-																																																																																					
A	(Unusable)	-	-	-																																																																																					
B	(Unusable)	Setting error (the "SW" LED on)	-	-																																																																																					
C	(Unusable)	Setting error (the "SW" LED on)	-	-																																																																																					
D	(Unusable)	Setting error (the "SW" LED on)	-	-																																																																																					
E	(Unusable)	Setting error (the "SW" LED on)	-	-																																																																																					
F	(Unusable)	Setting error (the "SW" LED on)	-	-																																																																																					
④	<p>Transmission speed setting switch AJ61BT11</p>  <p>A1SJ61BT11</p> 	<p>Sets the module transmission speed (setting at shipment: 0)</p> <table border="1" data-bbox="579 1400 1439 1736"> <thead> <tr> <th>Number</th> <th>Setting details</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>156kbps</td> </tr> <tr> <td>1</td> <td>625kbps</td> </tr> <tr> <td>2</td> <td>2.5Mbps</td> </tr> <tr> <td>3</td> <td>5Mbps</td> </tr> <tr> <td>4</td> <td>10Mbps</td> </tr> <tr> <td>5</td> <td>Setting error (the "SW" and "L ERR." LED on)</td> </tr> <tr> <td>6</td> <td>Setting error (the "SW" and "L ERR." LED on)</td> </tr> <tr> <td>7</td> <td>Setting error (the "SW" and "L ERR." LED on)</td> </tr> <tr> <td>8</td> <td>Setting error (the "SW" and "L ERR." LED on)</td> </tr> <tr> <td>9</td> <td>Setting error (the "SW" and "L ERR." LED on)</td> </tr> </tbody> </table>	Number	Setting details	0	156kbps	1	625kbps	2	2.5Mbps	3	5Mbps	4	10Mbps	5	Setting error (the "SW" and "L ERR." LED on)	6	Setting error (the "SW" and "L ERR." LED on)	7	Setting error (the "SW" and "L ERR." LED on)	8	Setting error (the "SW" and "L ERR." LED on)	9	Setting error (the "SW" and "L ERR." LED on)																																																																	
Number	Setting details																																																																																								
0	156kbps																																																																																								
1	625kbps																																																																																								
2	2.5Mbps																																																																																								
3	5Mbps																																																																																								
4	10Mbps																																																																																								
5	Setting error (the "SW" and "L ERR." LED on)																																																																																								
6	Setting error (the "SW" and "L ERR." LED on)																																																																																								
7	Setting error (the "SW" and "L ERR." LED on)																																																																																								
8	Setting error (the "SW" and "L ERR." LED on)																																																																																								
9	Setting error (the "SW" and "L ERR." LED on)																																																																																								

No.	Name	Description						
⑤	Condition setting switch AJ61BT11  A1SJ61BT11 	Sets the operation condition (setting at shipment: SW1 to 7 are OFF, SW8 is ON)						
		Number	Setting contents	Description	Setting valid/not valid			
					Master station (Standby master station (control status))	Local station (Standby master station (standby status))		
		SW1	Station type	OFF : Master station/local station ON : Standby master station	(Valid)	(Valid)		
		SW2	(Unusable)	Always off	-	-		
		SW3	(Unusable)	Always off	-	-		
		SW4	Input data status of the data link error station	OFF : Clear ON : Hold	Valid	Valid		
		SW5 SW6	Number of occupied stations	Number of occupied stations	SW5	SW6	-	-
				1 station	OFF	OFF	Invalid	Valid
				2 stations * 3	OFF	ON		
3 stations * 3	ON			ON				
4 stations	ON	OFF						
SW7	(Unusable)	Always off	-	-				
SW8	Module mode	OFF : Intelligent mode ON : I/O mode	Valid	Valid				

No.	Name	Description
⑥	<p>Terminal block AJ61BT11</p>  <p>A1SJ61BT11</p> 	<p>Connect the CC-Link dedicated cable for data link. Refer to Section 7.5 for how to connect the cables.</p> <p>Note that the following terminals are connected inside of the module.</p> <p>SLD (terminal No.8) — FG (terminal No.10) NC (terminal No.7) — NC (terminal No.9)</p> <p>2-piece type terminal block. The module can be replaced with another without removing the signal lines from the terminal block. (Replace the module after turning off its power.)</p>

* 3: The AJ61BT11 of hardware version F or later and the A1SJ61BT11 of hardware version G or later are compatible with this setting.
For other than the above, only SW5 is used to set the number of occupied stations.
OFF : 1 station occupied
ON : 4 stations occupied
Keep SW6 OFF as it is unusable.

POINT

The setting of switches ② to ⑤ become valid after the module power supply is turned on from off or after the programmable controller CPU is reset.
When the setting is changed while the module power supply is on, turn off and then on the module power supply or reset the programmable controller CPU again.


Important

Do not use station number 64 in a system where the standby master station exists.
When it is used, the station number 64 will not communicate correctly.

7.4 Checking Module Condition (Hardware Test)

The hardware test checks if the module alone operates normally.
Always perform a hardware test before configuring the system.

Perform a hardware test by following the procedure below:




Continued from the previous page

The test results are displayed on the "LEDs" of master-local module.

[When normal]

The LEDs are turned on in the following order:
 "SW" → "M/S" → "PRM" → "TIME".



[When error]

The error description for each check item is shown below.
 Replace the module if an error occurs.

Check item	LED item	Description
Self-loopback check	"SW" on	Module error
ROM check	"M/S" on	ROM error
RAM check	"PRM" on	RAM error

The "RUN" LED turns off.

End

7.5 Module Wiring with CC-Link Dedicated Cable

This section explains how to connect the master module, local modules, standby master module, remote modules and intelligent device modules with the CC-Link dedicated cables.


- (1) Ver.1.10-compatible CC-Link dedicated cables, CC-Link dedicated cables (Ver.1.00), and CC-Link dedicated high-performance cables cannot be used together. If used together, correct data transmission will not be guaranteed.
- (2) CC-Link cables can be connected from any station number.
- (3) Connect the shielded wire of the CC-Link dedicated cable to "SLD" of each module, and ground both ends of the shielded wire to the protective ground conductor via "FG".
The SLD and FG are connected within the module.
- (4) Connect the "terminating resistors" supplied with each module at both ends of the CC-Link system.
Connect the terminating resistors across "DA" and "DB".
When a T-branch system is configured, some restrictions are applied to the use of the A(1S)J61BT11/A(1S)J61QBT11 as the master station. Refer to Section 7.6.1 for details.
- (5) The terminating resistors to be connected vary depending on the cable type used in the CC-Link system.

Cable type	Terminating resistor
CC-Link dedicated cable (Ver.1.00)	110 Ω 1/2 W (brown - brown - brown)
Version 1.10 compatible CC-Link dedicated cable	
CC-Link dedicated high-performance cable	130 Ω 1/2 W (brown - orange - brown)

- (6) For the terminal block screws, M3.5 screws are used.
- (7) The following table describes an applicable solderless terminal connected to the terminal block. Use the following cable and tighten the terminal within the applicable tightening torque range.
Use a UL-approved solderless terminal and a tool recommended by the manufacturer for processing the terminal. A sleeved solderless terminal with insulation sleeve cannot be used.

Solderless terminal		Wire			
Model	Applicable tightening torque	Diameter	Type	Material	Temperature rating
1.25-3.5	0.59 to 0.88N·m	22 to 16 AWG	Stranded	Copper	60°C or more

- (8) The master module can be connected at other points than both ends.
- (9) Star connection is not allowed.
- (10) The connection method is shown below.




7.6 T-Branch Connection with the CC-Link Dedicated Cable

This section explains how to perform a T-branch connection using the CC-Link dedicated cable.

7.6.1 T-Branch system configuration

The following shows a system configuration using T-branch connection.




* The number of branch lines is determined by the branch line length per branch line and the overall branch line length.

7.6.2 T-Branch communication specifications list

The following describes the communication specifications for T branch connection. For communication specifications not listed below, see Section 3.2.


Item	Specification		Remarks
Transmission speed	625kbps	156kbps	10 Mbps, 5 Mbps, and 2.5 Mbps are not allowed.
Maximum length of the main line	100 m (328.1 ft.)	500 m (1640.5 ft.)	Indicates the length of the cable between terminating resistors. The length of the T branch cable (branch line length) is not included.
Maximum length of the branch line	8 m (26.25 ft.)		Indicates the overall cable length per branch.
Overall branch line length	50 m (164.05 ft.)	200 m (656.2 ft.)	Indicates the overall length of the entire branch cable.
Maximum number of connected modules on the branch line	6 stations per branch		The total number of connected modules depends on the CC-Link specifications.
Connection cable	CC-Link dedicated cable Version 1.10 compatible CC-Link dedicated cable		<ul style="list-style-type: none"> The CC-Link dedicated high-performance cable cannot be used. Mixing of different brands of CC-Link dedicated cables is not allowed. Mixing of different brands of Ver. 1.10 compatible CC-Link dedicated cables is allowed.

Item	Specification	Remark
Terminating resistor (connection method)	When the hardware version of the master module is as follows: AJ61BT11 : Hardware version D or later AJ61QBT11 : Hardware version D or later A1SJ61BT11 : Hardware version E or later A1SJ61QBT11: Hardware version E or later Connect the 110Ω terminating resistor supplied with the master module. For connecting, refer to Section 7.5.	<ul style="list-style-type: none"> The method of connecting terminating resistors across DA and DG, and across DB and DG can be used.
	When the hardware version of the master module is other than above: 110 Ω ± 5 %, 1/2 W × 4 (Connect across DA and DG, and across DB and DG) both ends [Connection] 	<ul style="list-style-type: none"> Use a commercially available terminating resistor of 110 Ω ± 5 % and 1/2 W resistance. 110 Ω and 130 Ω terminating resistors supplied with the master/local modules cannot be used.

T branch terminal block/connector	<ul style="list-style-type: none"> Terminal block: Off-the-shelf terminal block Connector : Connector for FA sensor (IEC947-5-2) comparable product is recommended 	<ul style="list-style-type: none"> When wiring cables for the main line side, try not to remove the covering as much as possible.
-----------------------------------	--	--

Maximum length of main line, distance between T branches, and length of cable between stations	CC-Link dedicated cable, Version 1.10 compatible CC-Link dedicated cable (terminating resistor 110 Ω)			
	Transmission speed	Maximum length of main line	Distance between T branches	Length of cable between the remote I/O stations or remote device stations * 1
	625 kbps	100 m (328.1 ft.)	No limit	30 cm (11.8 in.) or longer
156 kbps	500 m (1640.5 ft.)	1 m (3.28 ft.) or longer (* 3)/ 2 m (6.56 ft.) or longer (* 4)		

* 3: The cable length of 1m (3.28 ft.) or longer is for a system configured only with remote I/O stations and remote device stations.
 * 4: The cable length of 2m (6.56 ft.) or longer is for a system configuration that contains local stations and intelligent device stations.



7.7 Switch Settings

The setting method for each switch on the module is described.

7.7.1 Station number setting (master station, local station, standby master station, remote station, and intelligent device station)

The station number setting method is described for the master station, local station, standby master station, remote station, and intelligent device station.

POINT
 Set the data so that it matches the setting in the "station information (address 20H to 5FH)" in the parameter information area in the buffer memory.



(1) Set the station number to be consecutive.

The station number can be set regardless of the connection order.

Also, for modules that occupy more than 2 stations, set the first station number.

Station type	Station number to set
Master station	0 (Fix)
Local station	1 to 64
Standby master station	1 to 63
Remote station, intelligent device station	1 to 64

[Setting example] When setting the station numbers in the connection order:




(2) Do not skip station numbers.

The skipped station number is treated as a "data-link faulty station (link special register SW0080 to 0083: can be checked with buffer memory address 680H to 683H)".


However, by setting as a reserved station, the station number will not be treated as a data-link faulty station.

[Setting example] When a station number is skipped:



- (3) There cannot be duplicate station numbers.
If there are duplicate numbers, it results in Loading status error. (Error code is stored in SW0069.)

[Setting example] When a station number is duplicated:



7.7.2 Mode setting

When performing data link, "0 (online)" should be set normally.

7.7.3 Transmission speed setting

The transmission speed setting differs depending on the overall distance.
Refer to Section 3.2.1, 3.2.2 for details.

POINT	<p>Set the same transmission speed for all of master, local, standby master, remote, and intelligent device stations.</p> <p>When the setting is different even at just one station, normal data link cannot be performed.</p>
--------------	--

7.7.4 Condition setting

The setting method of the condition setting switch (DIP switch) is shown in Table 7.2.

Table 7.2 Condition setting

Number	Description	Switch status			Setting	
					Master station	Local station
SW1	Station type	OFF : Master/local station ON : Standby master station			OFF (station number 0)	OFF (station number 1 to 64)
SW2	(Unusable)	-			Always OFF	
SW3	(Unusable)	-			Always OFF	
SW4	Input data status of the data link faulty station	OFF : Clear ON : Hold			OFF	When setting all input data from the data-link faulty station to all off. (Refer to Section 4.9.)
					ON	When keeping the input data from the data-link faulty station in the status right before the error. (Refer to Section 4.9.)
SW5 SW6	Number of occupied stations	Number of occupied stations	SW5	SW6	Setting not necessary (OFF)	-
		1 stations	OFF	OFF		<ul style="list-style-type: none"> • Remote input RX : 32 points • Remote output RY : 32 points • Remote register RWw : 4 points • Remote register RWr : 4 points
		2 stations * 1	OFF	ON		<ul style="list-style-type: none"> • Remote input RX : 64 points • Remote output RY : 64 points • Remote register RWw : 8 points • Remote register RWr : 8 points
		3 stations * 1	ON	ON		<ul style="list-style-type: none"> • Remote input RX : 96 points • Remote output RY : 96 points • Remote register RWw : 12 points • Remote register RWr : 12 points
		4 stations	ON	OFF		<ul style="list-style-type: none"> • Remote input RX : 128 points • Remote output RY : 128 points • Remote register RWw : 16 points • Remote register RWr : 16 points
SW7	(Unusable)	-			Always OFF	
SW8 * 2	Module mode	OFF : Intelligent mode ON : I/O mode			When intelligent mode : OFF When I/O mode : ON	

* 1 : The AJ61BT11 of hardware version F or later and the A1SJ61BT11 of hardware version G or later are compatible with this setting.
For other than the above, only SW5 is used to set the number of occupied stations.

OFF : 1 station occupied

ON : 4 stations occupied

Keep SW6 OFF as it is unusable.

* 2 : Choose the intelligent mode when:

(1) Intelligent device station is connected.

To check whether the module connected is an intelligent device station or not, refer to the user's manual of the corresponding module, e.g. AJ65BT-R2(N), AJ65BT-G4, AJ65BT-D75P2-S3, etc.; or

(2) When transient transmission is used.


7.8 Checking the Connection Condition (Line Test)

The Line Test is performed after all modules have been wired with CC-Link dedicated cables to check if the connection is correctly established to perform data link with each remote station, intelligent device station, local station, and standby master station.

POINT
 Line Test 2 is performed when an error has occurred in Line Test 1.
 Therefore, there is no need to perform Line Test 2 if no error was detected in Line Test 1.

7.8.1 Checking connection and communication status with remote station/intelligent device station/local station/standby master station (Line Test 1)


Confirms if data link can be performed normally with all (64 stations) the remote, intelligent device, local, and standby master stations.
 Perform Line Test by following the procedure below:




Continued from the previous page

The test results are displayed on the "LEDs" of master module.

[When at least one station is communicating normally]
 The LEDs are turned on in the following order: "SW" → "M/S" → "PRM" → "TIME".
 The test result is stored in SW00B4 to B7. However, the test is performed for 64 stations, so ignore the bits for the unconnected stations.



LED on	Cause	Error code storage area
PRM	• All stations have error, or cable is disconnected.	SW00B8
none	• Test cannot start. (Cable is disconnected before the test, or power is off at all stations.)	—




7.8.2 Checking communication status with specific remote station/intelligent device station/local station/standby master station (Line Test 2)

Confirms if data link can be performed normally with specific remote, intelligent device, local, and standby master stations.

There is no need to set parameters.

Perform Line Test 2 by following the procedure below:



Continued to the next page


Continued from the previous page

The test results are displayed on the "LEDs" of master module.

[When normal]
 The LEDs are turned on in the following order: "SW" → "M/S" → "PRM" → "TIME".
 It is judged as normal when this repeats five times or more.

[When error]


LED on	Cause	Error code storage area
PRM	<ul style="list-style-type: none"> • Cable is disconnected, or the corresponding station has error. • Test transmission text is corrupt. 	SW00B8
none	• Test cannot start. (Cable is disconnected before the test, or power is off at all stations.)	—



7.9 Checking Parameters (Parameter Confirmation Test)

Contents of the parameters registered in the master module's E²PROM can be confirmed.

Perform the test by following the procedure below:




Continued from the previous page

The test results are displayed on the "LEDs" of master module.
 By switching the mode setting switch, the parameter content corresponding to each mode number is displayed on LED.

Mode setting switch	Parameter item	Used LEDs and contents
0	Total number of stations	Tens digit: MST, S MST, LOCAL
1	Number of linked modules	Units digit: SW, M/S, PRM, TIME
2	Number of retries	MST ○ 40 S SMT ○ 20 LOCAL ○ 10 SW ○ 8 M/S ○ 4 PRM ○ 2 TIME ○ 1 <div style="display: inline-block; vertical-align: middle; text-align: center;"> When 26 → </div> MST ○ S SMT ● LOCAL ○ SW ○ M/S ● PRM ● TIME ○
3	(Unusable)	
4	Reserved station specification	SW (off: no specification, on: specification exists)
5	Invalid station specification	SW (off: no specification, on: specification exists)
6	Station type*1 *2	SW: remote I/O station M/S: remote device station PRM: local station, standby master station, and intelligent device station
7	Number of occupied stations*1 *2	SW: 1 station M/S: 2 stations PRM: 3 stations TIME: 4 stations
8	Station number*1	Tens digit: MST, S MST, LOCAL Units digit: SW, M/S, PRM, TIME MST ○ 40 S SMT ○ 20 LOCAL ○ 10 SW ○ 8 M/S ○ 4 PRM ○ 2 TIME ○ 1 <div style="display: inline-block; vertical-align: middle; text-align: center;"> When 26 → </div> MST ○ S SMT ● LOCAL ○ SW ○ M/S ● PRM ● TIME ○
9 to F	(Unusable)	

*1: Set the module's station number by the station number setting switch.
 *2: For modules that occupy more than two stations, the same LED details are displayed for the number of occupied stations.




8. Programming

8.1 Precautions when Programming


Precautions when creating programs are described below:

POINT	The time to return to the system automatically is influenced by the number of sequence scans, link scans and FROM/TO instructions. Execute the FROM/TO instruction once or so per link scan. The number of FROM/TO instructions can be reduced by batch-execution of read/write from/to RX/RX/RWw/RWr/SB/SW.
--------------	--


- (1) When using the FROM/TO instruction to access the module, provide interlocks using Xn0 (module error) and XnF (module ready).




- (2) Create a read program from the remote input RX (address E0H to 15FH) after data link is started.
Also, create a write program to the remote output RY (address 160H to 1DFH) at the last of the entire program.



(3) In a program, reading received data and writing transmission data should be performed after the host station becomes the data link status (Xn1 is on).



(4) Create a program which checks and interlocks the data-link status at remote I/O station, remote device station and local station.
Also, create an error-handling program.



8.2 Precautions for Registering Parameters to E²PROM

This section explains the precautions for registering parameters to E²PROM.

This section may be read by only those who will use the module indicated in Section 8.2.1 and register parameters to E²PROM more than 127 times without switching power off or resetting the CPU.

The number of times when parameters can be registered to E²PROM is cleared by switching power off or resetting the CPU.

8.2.1 Target module and versions

The target module and versions are as indicated below.

Target Module	Hardware version	Software version
A1SJ61BT11	H or later	E (manufactured in Aug., 2001) or later

8.2.2 Precautions


The following are the precautions for registering parameters to E²PROM.


- (1) The number of times when parameters can be registered to E²PROM consecutively without switching power off or resetting the CPU is up to 127.
- (2) The link special register (SW00BB) stores the number of times when parameters can be registered to E²PROM.
- (3) When the number of times when parameters can be registered to E²PROM is zero, turn on the E²PROM erasure request (YnD) after a data link stop to erase the parameters in the E²PROM.

8.2.3 Program for registering parameters to E²PROM

The program for registering parameters to E²PROM is shown below.

This example assumes that the master module is installed to the head I/O number 40.






8.3 Programming Procedure

The procedure for creating a program is described.

8.3.1 Communication between the master station and remote I/O station

The basic procedure for creating a program to communicate with remote I/O station is shown below.


Refer to Chapter 9 for a program example.



8.3.2 Communication between the master station and remote device station

The basic procedure for creating a program to communicate with remote device station is shown below.

Refer to Chapter 10 for a program example.




8.3.3 Communication between the master station and local station


The basic procedure for creating a program to communicate with local station is shown below.

Refer to Chapter 11 for a program example.

(1) Master station



(2) Local station




8.3.4 Communication in a compound system


The basic procedure for creating a program to remote I/O, remote device and local stations is shown below.

Refer to Chapter 12 for a program example.

(1) Master station



(2) Local station



8.4 Link Special Relay/Register (SB/SW)

The data link status can be checked with bit data (link special relay SB) and word data (link special register SW).

The SB and SW show the information on the buffer memories of the master and local modules for convenience. They are read and written before use with FROM/TO instructions.

- Link special relay (SB).....Buffer memory address 5E0H to 5FFH
- Link special register (SW)Buffer memory address 600H to 7FFH

8.4.1 Link special relay (SB)

Refer to Section 3.5.2 (4) for correspondence with buffer memory.

Table 8.1 Link special relay list

Number	Name	Description	Availability (○ : available, × : not available)		
			Online		Offline
			Master station	Local station	
SB0000	Data link restart	When parameter data change is not made to the data link which was stopped by SB0002, restart it with this signal. (If you have changed parameter data during a data link stop, turn on Yn6 and Yn8 to restart a data link.) OFF : No restart specification ON : Restart specification	○	○	×
SB0001 * 1	Master station switching data link start	The output information is switched from the standby master station to the master station to start the data link (Usable in standby master station). OFF : No switch instruction ON : Switch instruction	×	×	×
SB0002	Data link stop	Stops the host station's data link. However, when the master station executes this, the entire system stops. OFF : No stop specification ON : Stop specified	○	○	×
SB0004 * 1	Temporary error invalid station request	Confirms the station which had been specified by SW0003 to SW0007 to temporary error invalid station. OFF : No request ON : Request	○	×	×
SB0005 * 1	Temporary error invalid station cancelling request	Cancels the station which had been specified by SW0003 to SW0007 from temporary error invalid station. OFF : No request ON : Request	○	×	×
SB0008 * 1	Line test request	Performs the line test to station which had been specified by SW0008. OFF : No request ON : Request	○	×	×
SB0009 * 1	Parameter setting test request	Reads the parameter setting information for actual system configuration. OFF : Requested ON : Not requested	○	×	×
SB0020 * 1	Module status	Indicates the status of communications between the master/local module and the CPU module. OFF : Normal ON : Error	○	○	○

* 1: Link special relay added to the function version B or later

Table 8.1 Link special relay list (continued)

Number	Name	Description	Availability (○ : available, × : not available)		
			Online		Offline
			Master station	Local station	
SB0030 * 2	Communication instruction (1) acceptance	Indicates the acceptance status of SEND/RCV/READ/WRITE/REQ instructions (when channel 1 is used). (Usable on AJ61QBT11 and A1SJ61QBT11) OFF : Not accepted ON : Accepted	○	○	×
SB0031 * 2	Communication instruction (1) complete	Indicates the complete status of SEND/RCV/READ/WRITE/REQ instructions (when channel 1 is used). (Usable on AJ61QBT11 and A1SJ61QBT11) OFF : Not completed ON : Completed	○	○	×
SB0032 * 2	Communication instruction (2) acceptance	Indicates the acceptance status of SEND/RCV/READ/WRITE/REQ instructions (when channel 2 is used). (Usable on AJ61QBT11 and A1SJ61QBT11) OFF : Not accepted ON : Accepted	○	○	×
SB0033 * 2	Communication instruction (2) complete	Indicates the complete status of SEND/RCV/READ/WRITE/REQ instructions (when channel 2 is used). (Usable on AJ61QBT11 and A1SJ61QBT11) OFF : Not completed ON : Completed	○	○	×
SB0040	Data link restart acceptance	Indicates data link restart specification acceptance status. OFF : Not accepted ON : Startup specification accepted	○	○	×
SB0041	Data link restart complete	Indicates data link restart specification acceptance complete status. OFF : Not complete ON : Startup complete	○	○	×
SB0042 * 1	Master station switch data link start acceptance	Indicates the acceptance status of data link start switch instruction from the standby master station to the master station (Usable on the standby master station). OFF : Not accepted ON : Accepted	×	×	×
SB0043 * 1	Master station switch data link start complete	Indicates the acceptance status of data link start switch instruction from the standby master station to the master station (Usable on the standby master station). OFF : Not completed ON : Completed	×	×	×
SB0044	Data link stop acceptance	Indicates data link stop specification acceptance status. OFF : Not accepted ON : Stop specification accepted	○	○	×
SB0045	Data link stop complete	Indicates data link stop specification acceptance complete status. OFF : Not complete ON : Stop complete	○	○	×
SB0048 * 1	Temporary error invalid station acceptance	Indicates the acceptance status of the temporary error invalid station request instruction. OFF : Not accepted ON : Accepted	○	×	×
SB0049 * 1	Temporary error invalid station complete status	Indicates the acceptance complete status of the temporary error invalid station request instruction. OFF : Not executed ON : Temporary error invalid station confirmed	○	×	×
SB004A * 1	Temporary error invalid station cancelling acceptance status	Indicates the acceptance status of the temporary error invalid station cancelling request instruction. OFF : Not executed ON : Instruction accepted	○	×	×

* 1: Link special relay added to the function version B or later

* 2: Link special relay added to the software version J (manufactured in Jan., 1998) or later

Table 8.1 Link special relay list (continued)

Number	Name	Description	Availability (○ : available, × : not available)																	
			Online		Offline															
			Master station	Local station																
SB004B * 1	Temporary error invalid station cancelling complete status	Indicates the acceptance complete status of the temporary error invalid station cancelling request instruction. OFF : Not executed ON : Temporary error invalid station cancelling complete	○	×	×															
SB004C * 1	Line test acceptance status	Indicates the line test request acceptance status. OFF : Not executed ON : Specification accepted	○	×	×															
SB004D * 1	Line test complete status	Indicates the line test complete status. OFF : Not completed ON : Test complete	○	×	×															
SB004E * 1	Parameter setting test acceptance status	Indicates the parameter setting test request acceptance status. OFF : Not accepted ON : Specification accepted	○	×	×															
SB004F * 1	Parameter setting test complete status	Indicates the parameter setting test complete status. OFF : Not completed ON : Test complete	○	×	×															
SB0050	Offline test status	Indicates the offline-test execution status. OFF : Not executed ON : In progress	×	×	○															
SB0060	Mode	Indicates the module's mode setting switch setting status. OFF : Online (0) ON : Other than online (0)	○	○	○															
SB0061	Station type	Indicates the setting status of the module station number setting switch. OFF : Master station (station number 0) ON : Local station (station numbers 1 to 64)	○	○	×															
SB0062 * 1	Standby master station setting	Indicates the setting status of the standby master station. OFF : Not set ON : Set	○	×	×															
SB0065	Input data status of a data link error station	Indicates the setting status of the module's condition setting switch (DIP switch) SW4. OFF : Clear ON : Keep	○	○	×															
SB0066	Number of occupied stations	Indicates the setting of the module's condition setting switch (DIP switch) SW5, SW6. <table border="1" data-bbox="582 1317 1161 1473"> <thead> <tr> <th>Number of occupied stations</th> <th>SB0066 (SW5)</th> <th>SB0067 (SW6)</th> </tr> </thead> <tbody> <tr> <td>1 station</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>2 stations</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>3 stations</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>4 stations</td> <td>ON</td> <td>OFF</td> </tr> </tbody> </table>	Number of occupied stations	SB0066 (SW5)	SB0067 (SW6)	1 station	OFF	OFF	2 stations	OFF	ON	3 stations	ON	ON	4 stations	ON	OFF	×	○	×
Number of occupied stations			SB0066 (SW5)	SB0067 (SW6)																
1 station	OFF	OFF																		
2 stations	OFF	ON																		
3 stations	ON	ON																		
4 stations	ON	OFF																		
SB0067 * 2																				
SB0069	Module mode	Indicates the setting status of the module's condition setting switch (DIP switch) SW8. (Usable on AJ61BT11 and A1SJ61BT11) OFF : Intelligent mode ON : I/O mode	○	○	×															
SB006A	Switch setting status	Indicates the switch setting status. OFF : Normal ON : Setting error exists (Store the error code in SW006A)	○	○	○															
SB006D	Parameter setting status	Indicates the parameter setting status. OFF : Normal ON : Setting error exists (Store the error code in SW0068)	○	×	×															
SB006E	Host station operation status	Indicates the data link communication status with other stations. OFF : In operation ON : Not in operation	○	○	×															
SB0070 * 1	Master station data link status	Indicates data link status. OFF : Data link for master station ON : Data link for standby master station	○	○	×															
SB0071 * 1	Standby master station information	Indicates whether there is standby master station or not. OFF : Not present ON : Present	○	○	×															

* 1 : Link special relay added to the function version B or later

* 2 : Link special relay added to the AJ61BT11 of hardware version F or later and the A1SJ61BT11 of hardware version G or later

Table 8.1 Link special relay list (continued)

Number	Name	Description	Availability (○ : available, × : not available)		
			Online		Offline
			Master station	Local station	
SB0072 * 1	Scan mode setting	Indicates the scan mode setting status. OFF : Asynchronous mode ON : Synchronous mode	○	×	×
SB0073	Operation specification when CPU is down status	Indicates specification when CPU is down status by parameter. OFF : Stop ON : Continue	○	×	×
SB0074	Reserved station specified status	Indicates the reserved station specified status by parameters (SW0074 to SW0077). OFF : No specification ON : Specification exists,	○	○	×
SB0075	Error invalid station specified status	Indicates the error invalid station specified status by parameters (SW0078 to SW007B). OFF : No specification ON : Specification exists	○	○	×
SB0076 * 1	Temporary error invalid station setting information	Indicates the setting of yes/no for temporary error invalid station. OFF : No ON : Yes	○	○	×
SB0077	Parameter receive status	Indicates the parameter receive status from the master station. OFF : Receive complete ON : Receive not complete	×	○	×
SB0078 * 1	Host station switch change	Detects the setting switch change of the host station during data link. OFF : Not change ON : Change	○	○	×
SB0080	Other station's data link status	Indicates the communication status of the other stations. (SW0080 to SW0083). OFF : All stations normal ON : Faulty station exists	○	○	×
SB0081 * 1	Other station watchdog timer error status	Indicates the watch dog timer error occurrence status in the other station (SW0084 to SW0087). OFF : No error ON : Error	○	○	×
SB0082 * 1	Other station fuse blown status	Indicates the fuse blow occurrence status in the other station (SW0088 to SW008B). OFF : Not blown ON : Blown	○	○	×
SB0083 * 1	Other station switch change status	Detects the setting switch change of the other station during data link. OFF : Not change ON : Change	○	○	×
SB0090	Host line status	Indicates the host station line status. OFF : Normal ON : Error (disconnection)	×	○	×
SB0094 * 1	Transient transmission status	Indicates the transient transmission error occurrence status (SW0094 to SW00897). OFF : No error ON : Error	○	○	×
SB0095 * 1	Master station transient transmission status	Indicates the transient transmission status of the master station. OFF : Normal ON : Error	×	○	×
SB00A0 * 2	RECV instruction (1) execution request flag	Indicates the RECV instruction execution request status (when channel 1 is used). (Usable on AJ61QBT11 and A1SJ61QBT11) OFF : No execution request ON : Execution request	○	○	×
SB00A1 * 2	RECV instruction (2) execution request flag	Indicates the RECV instruction execution request status (when channel 1 is used). (Usable on AJ61QBT11 and A1SJ61QBT11) OFF : No execution request ON : Execution request	○	○	×

* 1: Link special relay added to the function version B or later

* 2: Link special relay added to the software version J (manufactured in Jan., 1998) or later

8.4.2 Link special register (SW)

The value in the () next to the number indicates the buffer memory address.


Table 8.2 Link special register list

Number	Name	Description	Availability (○ : available, × : not available)																																																			
			Online		Offline																																																	
			Master station	Local station																																																		
SW0003* (603H)	Multiple temporary error invalid station specification	Selects whether to specifies multiple temporary error invalid stations: 00 : Specifies multiple stations as indicated in SW0004 to SW0007. 01 to 64 : Specifies a single station from 1 to 64. ※ Specifies the station number used as the temporary error invalid station.	○	×	×																																																	
SW0004* (604H) SW0005* (605H) SW0006* (606H) SW0007* (607H)	Temporary error invalid station specification *1	Specifies the temporary error invalid station. 0 : Not specified as a temporary error invalid station. 1 : Specified as a temporary error invalid station. <table border="1" style="margin-left: 40px;"> <tr> <td>b15</td><td>b14</td><td>b13</td><td>b12</td><td>to</td><td>b3</td><td>b2</td><td>b1</td><td>b0</td> </tr> <tr> <td>SW0004</td><td>16</td><td>15</td><td>14</td><td>13</td><td>to</td><td>4</td><td>3</td><td>2</td><td>1</td> </tr> <tr> <td>SW0005</td><td>32</td><td>31</td><td>30</td><td>29</td><td>to</td><td>20</td><td>19</td><td>18</td><td>17</td> </tr> <tr> <td>SW0006</td><td>48</td><td>47</td><td>46</td><td>45</td><td>to</td><td>36</td><td>35</td><td>34</td><td>33</td> </tr> <tr> <td>SW0007</td><td>64</td><td>63</td><td>62</td><td>61</td><td>to</td><td>52</td><td>51</td><td>50</td><td>49</td> </tr> </table> 1 to 64 in the table indicates station numbers.	b15	b14	b13	b12	to	b3	b2	b1	b0	SW0004	16	15	14	13	to	4	3	2	1	SW0005	32	31	30	29	to	20	19	18	17	SW0006	48	47	46	45	to	36	35	34	33	SW0007	64	63	62	61	to	52	51	50	49	○	×	×
b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW0004	16	15	14	13	to	4	3	2	1																																													
SW0005	32	31	30	29	to	20	19	18	17																																													
SW0006	48	47	46	45	to	36	35	34	33																																													
SW0007	64	63	62	61	to	52	51	50	49																																													
SW0008* (608H)	Line test station setting	Sets the station to perform line tests. 0 : Entire system (performed for all stations) 01 to 64 : Specified station Default value : 0	○	×	×																																																	
SW0009* (609H)	Watchdog time setting	Sets the response monitoring time for transient transmission. Default value : 5 (s) Setting range : 0 to 360 (s) ※ When a value out of the range is set, the value will be set to 360 seconds.	○	×	×																																																	
SW000A* (60AH)	CPU watchdog time setting	Sets the CPU watchdog time when an access to CPU is gained through the AJ65BT-G4 using the dedicated instructions. Default value : 5 (s) Setting range : 0 to 3600 (s) ※ If a value out of the range is set, the value will be set to 3600s. Note: Set on the CC-Link master station or local station connected to the applicable CPU.	○	○	×																																																	
SW0020* (620H)	Module status	Indicates the status of communications between the master/local module and the CPU module. 0 : Normal Other than 0 : Stores error code (Refer to the manual for the CPU module used.)	○	○	○																																																	
SW0041 (641H)	Data link restart result	Stores the execution results of the data link restart specification by SB0000. 0 : Normal 1 to : Stores error code (Refer to Section 13.3.)	○	○	×																																																	
SW0043* (643H)	Master station switch data link start result	Indicates the switch specification execution result and stores the execution results of the master station switch data link start specification by SB0001.(Usable on standby master station) 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	×	×	×																																																	
SW0045 (645H)	Data link stop result	Stores the execution results of the data link stop specification by SB0002. 0 : Normal 1 to : Error code (Refer to Section 13.3.)	○	○	×																																																	

* : Link special relay added to the function version B or later

*1 : Turns on only the bit for the head station number.

Table 8.2 Link special register list (continued)

Number	Name	Description	Availability (○ : available, × : not available)		
			Online		Offline
			Master station	Local station	
SW0049 (649H)	Temporary error invalid station request result	Stores the execution results of the temporary error invalid station request specification by SB0004. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	○	×	×
SW004B (64BH)	Temporary error invalid station cancelling request result	Stores the execution results of the temporary error invalid station cancelling request specification by SB0005. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	○	×	×
SW004D* (64DH)	Line test request result	Stores the execution results of the line test request specification by SB0008. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	○	×	×
SW004F* (64FH)	Parameter setting test request result	Stores the execution results of the parameter setting test request by SB0009. 0 : Normal Other than 0 : Stores error code	○	×	×
SW0060 (660H)	Mode setting switch status	Stores the setting status of the mode setting switch. 0: Online (remote net mode) 1: Online (remote I/O net mode) 2: Offline 3: Line test 1 4: Line test 2 5: Parameter verification test 6: Hardware test	○	○	○
SW0061 (661H)	Station number setting switch status	Stores the station number setting switch's setting status. 0 : Master station 1 to 64 : Local station	○	○	○
SW0062 (662H)	Condition setting switch status	The setting status of the condition setting switch (DIP switch) is stored. 0: OFF 1: ON 	○	○	○
SW0064* (664H)	No. of retries setting information	Stores the number of retries setting information when responding to an error. 1 to 7 (times)	○	×	×
SW0065* (664H)	No. of automatic return stations information	Stores the number of automatic return stations setting information during one link scan. 1 to 10 (modules)	○	×	×
SW0066* (666H)	Delay timer information	Stores the delay time setting information.	○	×	×
SW0067 (667H)	Parameter information	The parameter information area to be used is stored. 1: Buffer memory (data link startup by Yn6) 2: E ² PROM (data link startup by Yn8)	○	×	○
SW0068 (668H)	Host parameter status	Parameter setting status is stored. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	○	×	×

* : Link special relay added to the function version B or later

Table 8.2 Link special register list (continued)

Number	Name	Description	Availability (○ : available, × : not available)																																																				
			Online		Offline																																																		
			Master station	Local station																																																			
SW0069 (669H)	Loading status *2	The station number overlap and consistency with the parameters are stored for each module. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.) ※ Details are stored in SW0098 to 9B and SW009C to 9F.	○	×	×																																																		
SW006A (66AH)	Switch setting status	Switch setting status is stored. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	○	○	×																																																		
SW006D (66DH)	Max. link scan time	Stores the maximum value of the link scan time (in 1 ms units).	○	○	×																																																		
SW006E (66EH)	Current link scan time	Stores the current value of the link scan time (in 1 ms units).	○	○	×																																																		
SW006F (66FH)	Min. link scan time	Stores the minimum value of the link scan time (in 1 ms units).	○	○	×																																																		
SW0070 (670H)	Total number of stations	Stores the final station number set in the parameter. 1 to 64 stations	○	×	×																																																		
SW0071 (671H)	Max. communication station number	Stores the maximum station number (station number of the station number setting switch) in the data link. 1 to 64 (stations)	○	×	×																																																		
SW0072 (672H)	Number of connected modules	Stores the number of modules in the data link. 1 to 64 (modules)	○	×	×																																																		
SW0073 * (673H)	Standby master station number	Stores the standby master station number. 1 to 64 (stations)	○	○	×																																																		
SW0074 (674H) SW0075 (675H) SW0076 (676H) SW0077 (677H)	Reserved station specified status *1	Stores the setting status of reserved station. 0: Not reserved station 1: Reserved station <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0074</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0075</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0076</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0077</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW0074	16	15	14	13	to	4	3	2	1	SW0075	32	31	30	29	to	20	19	18	17	SW0076	48	47	46	45	to	36	35	34	33	SW0077	64	63	62	61	to	52	51	50	49	○	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW0074	16	15	14	13	to	4	3	2	1																																														
SW0075	32	31	30	29	to	20	19	18	17																																														
SW0076	48	47	46	45	to	36	35	34	33																																														
SW0077	64	63	62	61	to	52	51	50	49																																														
SW0078 (678H) SW0079 (679H) SW007A (67AH) SW007B (67BH)	Error invalid station specified status *1	Stores the error invalid station setting status. 0: Not error invalid station 1: Error invalid station <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0078</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0079</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW007A</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW007B</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW0078	16	15	14	13	to	4	3	2	1	SW0079	32	31	30	29	to	20	19	18	17	SW007A	48	47	46	45	to	36	35	34	33	SW007B	64	63	62	61	to	52	51	50	49	○	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW0078	16	15	14	13	to	4	3	2	1																																														
SW0079	32	31	30	29	to	20	19	18	17																																														
SW007A	48	47	46	45	to	36	35	34	33																																														
SW007B	64	63	62	61	to	52	51	50	49																																														
SW007C * (67CH) SW007D * (67DH) SW007E * (67EH) SW007F * (67FH)	Temporary error invalid station specified status *1	Stores the temporary error invalid station specified status. 0 : Not temporary error invalid station 1 : Temporary error invalid station <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW007C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW007D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW007E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW007F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW007C	16	15	14	13	to	4	3	2	1	SW007D	32	31	30	29	to	20	19	18	17	SW007E	48	47	46	45	to	36	35	34	33	SW007F	64	63	62	61	to	52	51	50	49	○	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW007C	16	15	14	13	to	4	3	2	1																																														
SW007D	32	31	30	29	to	20	19	18	17																																														
SW007E	48	47	46	45	to	36	35	34	33																																														
SW007F	64	63	62	61	to	52	51	50	49																																														

* : Link special register added to the function version B or later
*1 : Turns on only the bit for the head station number.
*2 : Check is performed only when the link is started up, and stored.

Table 8.2 Link special register list (continued)

Number	Name	Description	Availability (○ : available, × : not available)																																																				
			Online		Offline																																																		
			Master station	Local station																																																			
SW0080 (680H) SW0081 (681H) SW0082 (682H) SW0083 (683H)	Other station data link status *3*6	Stores the data link status of each station. 0: Normal 1: Data link error occurred <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0080</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0081</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0082</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0083</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW0080	16	15	14	13	to	4	3	2	1	SW0081	32	31	30	29	to	20	19	18	17	SW0082	48	47	46	45	to	36	35	34	33	SW0083	64	63	62	61	to	52	51	50	49	○	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW0080	16	15	14	13	to	4	3	2	1																																														
SW0081	32	31	30	29	to	20	19	18	17																																														
SW0082	48	47	46	45	to	36	35	34	33																																														
SW0083	64	63	62	61	to	52	51	50	49																																														
SW0084* (684H) SW0085* (685H) SW0086* (686H) SW0087* (687H)	Other station watchdog timer error occurrence status *1	Stores the other station watchdog timer error occurrence status. 0: Normal 1: Watchdog timer error occurrence <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0084</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0085</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0086</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0087</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW0084	16	15	14	13	to	4	3	2	1	SW0085	32	31	30	29	to	20	19	18	17	SW0086	48	47	46	45	to	36	35	34	33	SW0087	64	63	62	61	to	52	51	50	49	○	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW0084	16	15	14	13	to	4	3	2	1																																														
SW0085	32	31	30	29	to	20	19	18	17																																														
SW0086	48	47	46	45	to	36	35	34	33																																														
SW0087	64	63	62	61	to	52	51	50	49																																														
SW0088 (688H) SW0089 (689H) SW008A (68AH) SW008B (68BH)	Other station fuse blown status *3	Stores the fuse blown status of each station. 0: Normal 1: Fuse blown <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0088</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0089</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW008A</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW008B</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW0088	16	15	14	13	to	4	3	2	1	SW0089	32	31	30	29	to	20	19	18	17	SW008A	48	47	46	45	to	36	35	34	33	SW008B	64	63	62	61	to	52	51	50	49	○	×	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW0088	16	15	14	13	to	4	3	2	1																																														
SW0089	32	31	30	29	to	20	19	18	17																																														
SW008A	48	47	46	45	to	36	35	34	33																																														
SW008B	64	63	62	61	to	52	51	50	49																																														
SW008C* (68CH) SW008D* (68DH) SW008E* (68EH) SW008F* (68FH)	Other station switch change status *1	Stores the switch change status of other station during data link. 0: Not change 1: Change <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW008C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW008D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW008E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW008F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicates station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW008C	16	15	14	13	to	4	3	2	1	SW008D	32	31	30	29	to	20	19	18	17	SW008E	48	47	46	45	to	36	35	34	33	SW008F	64	63	62	61	to	52	51	50	49	○	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																														
SW008C	16	15	14	13	to	4	3	2	1																																														
SW008D	32	31	30	29	to	20	19	18	17																																														
SW008E	48	47	46	45	to	36	35	34	33																																														
SW008F	64	63	62	61	to	52	51	50	49																																														
SW0090 (690H)	Host station line status	Stores the host station line status. 0: Normal 1: Data link not possible (wire breakage)	×	○	×																																																		

* : Link special register added to the function version B or later

*1 : Turns on only the bit for the head station number.

*3 : Turns on the bit for the number of occupied stations.

*6 : For the data link status of a CC-Link Ver.2.00-compatible slave station, values that are stored change depending on the hardware version of an A1SJ61BT11.

Hardware with version M or earlier: "1: Data link error occurred"

Hardware with version N or later: "0: Normal"

Note, however, that an A1SJ61BT11 cannot perform cyclic transmission and transient transmission with a CC-Link Ver.2.00-compatible slave station, regardless of hardware version.

Table 8.2 Link special register list (continued)

Number	Name	Description	Availability (○ : available, × : not available)																																						
			Online		Offline																																				
			Master station	Local station																																					
SW0094* (694H) SW0095* (695H) SW0096* (696H) SW0097* (697H)	Transient transmission error status * 1	Stores the transient transmission error occurrence status for each station. 0: Normal 1: Transient transmission error occurrence b15 b14 b13 b12 to b3 b2 b1 b0 SW0094 <table border="1"><tr><td>16</td><td>15</td><td>14</td><td>13</td><td>to</td><td>4</td><td>3</td><td>2</td><td>1</td></tr></table> SW0095 <table border="1"><tr><td>32</td><td>31</td><td>30</td><td>29</td><td>to</td><td>20</td><td>19</td><td>18</td><td>17</td></tr></table> SW0096 <table border="1"><tr><td>48</td><td>47</td><td>46</td><td>45</td><td>to</td><td>36</td><td>35</td><td>34</td><td>33</td></tr></table> SW0097 <table border="1"><tr><td>64</td><td>63</td><td>62</td><td>61</td><td>to</td><td>52</td><td>51</td><td>50</td><td>49</td></tr></table> 1 to 64 in the table indicates station numbers.	16	15	14	13	to	4	3	2	1	32	31	30	29	to	20	19	18	17	48	47	46	45	to	36	35	34	33	64	63	62	61	to	52	51	50	49	○	○	×
16	15	14	13	to	4	3	2	1																																	
32	31	30	29	to	20	19	18	17																																	
48	47	46	45	to	36	35	34	33																																	
64	63	62	61	to	52	51	50	49																																	
SW0098 (698H) SW0099 (699H) SW009A (69AH) SW009B (69BH)	Station number overlap status * 4	The overlapping status is stored when each module's first station number dose not overlap. 0: Normal 1: Station number overlaps (only for the first station number) b15 b14 b13 b12 to b3 b2 b1 b0 SW0098 <table border="1"><tr><td>16</td><td>15</td><td>14</td><td>13</td><td>to</td><td>4</td><td>3</td><td>2</td><td>1</td></tr></table> SW0099 <table border="1"><tr><td>32</td><td>31</td><td>30</td><td>29</td><td>to</td><td>20</td><td>19</td><td>18</td><td>17</td></tr></table> SW009A <table border="1"><tr><td>48</td><td>47</td><td>46</td><td>45</td><td>to</td><td>36</td><td>35</td><td>34</td><td>33</td></tr></table> SW009B <table border="1"><tr><td>64</td><td>63</td><td>62</td><td>61</td><td>to</td><td>52</td><td>51</td><td>50</td><td>49</td></tr></table> 1 to 64 in the table indicates station numbers.	16	15	14	13	to	4	3	2	1	32	31	30	29	to	20	19	18	17	48	47	46	45	to	36	35	34	33	64	63	62	61	to	52	51	50	49	○	×	×
16	15	14	13	to	4	3	2	1																																	
32	31	30	29	to	20	19	18	17																																	
48	47	46	45	to	36	35	34	33																																	
64	63	62	61	to	52	51	50	49																																	
SW009C (69CH) SW009D (69DH) SW009E (69EH) SW009F (69FH)	Loading/parameter consistency status * 4	The consistency status with the parameters are stored. 0: Normal 1: Consistency error b15 b14 b13 b12 to b3 b2 b1 b0 SW009C <table border="1"><tr><td>16</td><td>15</td><td>14</td><td>13</td><td>to</td><td>4</td><td>3</td><td>2</td><td>1</td></tr></table> SW009D <table border="1"><tr><td>32</td><td>31</td><td>30</td><td>29</td><td>to</td><td>20</td><td>19</td><td>18</td><td>17</td></tr></table> SW009E <table border="1"><tr><td>48</td><td>47</td><td>46</td><td>45</td><td>to</td><td>36</td><td>35</td><td>34</td><td>33</td></tr></table> SW009F <table border="1"><tr><td>64</td><td>63</td><td>62</td><td>61</td><td>to</td><td>52</td><td>51</td><td>50</td><td>49</td></tr></table> 1 to 64 in the table indicates station numbers.	16	15	14	13	to	4	3	2	1	32	31	30	29	to	20	19	18	17	48	47	46	45	to	36	35	34	33	64	63	62	61	to	52	51	50	49	○	×	×
16	15	14	13	to	4	3	2	1																																	
32	31	30	29	to	20	19	18	17																																	
48	47	46	45	to	36	35	34	33																																	
64	63	62	61	to	52	51	50	49																																	
SW00B4 (6B4H) SW00B5 (6B5H) SW00B6 (6B6H) SW00B7 (6B7H)	Line test 1 result * 3	Line test 1 test results are stored. 0: Normal 1: Error b15 b14 b13 b12 to b3 b2 b1 b0 SW00B4 <table border="1"><tr><td>16</td><td>15</td><td>14</td><td>13</td><td>to</td><td>4</td><td>3</td><td>2</td><td>1</td></tr></table> SW00B5 <table border="1"><tr><td>32</td><td>31</td><td>30</td><td>29</td><td>to</td><td>20</td><td>19</td><td>18</td><td>17</td></tr></table> SW00B6 <table border="1"><tr><td>48</td><td>47</td><td>46</td><td>45</td><td>to</td><td>36</td><td>35</td><td>34</td><td>33</td></tr></table> SW00B7 <table border="1"><tr><td>64</td><td>63</td><td>62</td><td>61</td><td>to</td><td>52</td><td>51</td><td>50</td><td>49</td></tr></table> 1 to 64 in the table indicates station numbers.	16	15	14	13	to	4	3	2	1	32	31	30	29	to	20	19	18	17	48	47	46	45	to	36	35	34	33	64	63	62	61	to	52	51	50	49	×	×	○
16	15	14	13	to	4	3	2	1																																	
32	31	30	29	to	20	19	18	17																																	
48	47	46	45	to	36	35	34	33																																	
64	63	62	61	to	52	51	50	49																																	
SW00B8 (6B8H)	Line test 2 result	Stores the line test 2 results. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	×	×	○																																				
SW00B9 (6B9H)	E ² PROM registration status	E ² PROM parameter registration status is stored. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3.)	○	×	×																																				
SW00BA*5 (6BAH)	E ² PROM erasure result	The result of E ² PROM erasure request (YnD) is stored. 0 : Normal Other than 0 : Stores the error code.	○	×	×																																				
SW00BB*5 (6BBH)	Checks the number of times when parameters can be registered to E ² PROM.	The number of times when parameters can be registered to E ² PROM is stored. Decrementd when the parameter registration request to E ² PROM (YnA) is given.	○	×	×																																				

* : It is the link special relay which had been added by function version B or later.

*1 : Turns on only the bit for the head station number.

*3 : Turns on the bit for the number of occupied stations.

*4 : Turns on only the bit for the head station number. And check is performed only when the link is started up, and stored.

*5 : Link special register added to the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.

The timing when the link special register (SW) data is updated differs depending on the number.

The update timing is indicated in Table 8.3.

Table 8.3 Update timing of the link special register


Link special register	Data update timing	Link special register	Data update timing	
SW0041	Updated independently regardless of SB	SW0071	Updated independently regardless of SB (Update after each station is stabilized.)	
SW0045		SW0072	When SB0074 changes	
SW0060	When SB0060 changes	SW0074 to SW0077	When SB0075 changes	
SW0061	When SB0061 changes	SW0078 to SW007B	When SB0080 changes	
SW0062	Updated independently regardless of SB	SW0080 to SW0083	Updated independently regardless of SB	
SW0067		SW0088 to SW008B	When SB0090 changes	
SW0068		SW0090	Updated independently regardless of SB	
SW0069		SW0098 to SW009B		
SW006A		SW009C to SW009F		
SW006D		SW00B4 to SW00B7		
SW006E		SW00B8		
SW006F		SW00B9		
SW0070			-	-

9. Communication Between the Master Station and the Remote I/O Station

How to set, program, and confirm the operation of the module is described using a system configuration example.


9.1 System Configuration

A system with five remote I/O stations is used as an example.




9.1.1 Setting of the master station

The settings of the switches on the master station are shown below:



9.1.2 Setting of the remote I/O station

The settings of the switches on the remote I/O station are shown below:




9.2 Creating a Program

9.2.1 Program for parameters


This program automatically initiates the data link when the programmable controller CPU starts running.

[When debugging]




9 COMMUNICATION BETWEEN THE MASTER STATION AND THE REMOTE I/O STATION

MELSEC-A




* : Refer to Section 8.2 when using the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.



9.2.2 Communication program


A program to control the remote I/O stations is shown below.

The following configuration of the programmable controller CPU, master station's buffer memory and the remote I/O stations is assumed.




9 COMMUNICATION BETWEEN THE MASTER STATION AND THE REMOTE I/O STATION

MELSEC-A



9 COMMUNICATION BETWEEN THE MASTER STATION AND THE REMOTE I/O STATION

MELSEC-A



9.3 Performing the Data Link


Turn on the power supply of the remote I/O station first, then the power supply of the master station to start the data link.

9.3.1 Confirming the operation by LED display

The following diagram shows the LED display status of the master station and the remote I/O station when the data link is performed normally.


(1) LED display of the master station

Confirm that the LED display shows the following status:



(2) LED display of the remote I/O station


Confirm that the LED display shows the following status:



9.3.2 Confirming the operation by the program

Using the sequence program, confirm that the data link is proceeding normally.

- ① For example, when X00 of the remote I/O station AJ65BTB1-16D (station No.1) is turned on, Y20 (AY41) of the master station is turned on.
- ② When X10 (AX41) of the master station is turned on, Y00 of the remote I/O station AJ65BTB1-16T (station No.3) is turned on.




10. Communication Between the Master Station and the Remote Device Station

How to set, program, and confirm the operation of the module is described using a system configuration example.


10.1 System Configuration

A system with two remote device stations is used as an example.




10.1.1 Setting of the master station

The settings of the switches on the master station are shown below:



10.1.2 Setting of the remote device station

The settings of the switches on the remote device station are shown below:





10.2 Creating a Program

10.2.1 Program for parameters


This program automatically initiates the data link when the programmable controller CPU starts running.

[When debugging]






* : Refer to Section 8.2 when using the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.



10.2.2 Communication program

A program to control the remote device stations is shown below.
 The following configuration of the programmable controller CPU, master station's buffer memory and the remote device stations is assumed.
 For details of each device station, refer to the user's manual of each module.

[Remote input (RX), remote output (RY)]




[Remote register (RWw, RWr)]

Programmable controller
CPU


Master station


Remote device station (station No.1)
AJ65BT-64AD



10 COMMUNICATION BETWEEN THE MASTER STATION AND THE REMOTE DEVICE STATION


MELSEC-A





10 COMMUNICATION BETWEEN THE MASTER STATION AND THE REMOTE DEVICE STATION

MELSEC-A



10.3 Performing the Data Link


Turn on the power supply of the remote device station first, then the power supply of the master station to start the data link.

10.3.1 Confirming the operation by LED display

The following diagram shows the LED display status of the master station and the remote device station when the data link is performed normally.

(1) LED display of the master station


Confirm that the LED display shows the following status:



(2) LED display of the remote device station

Confirm that the LED display shows the following status:


The LED display in AJ65BT-64AD and AJ65BT-64DAV are the same.



10.3.2 Confirming the operation by the program

Using the sequence program, confirm that the data link is proceeding normally.

- ① The digital value which was converted by AJ65BT-64AD is stored in D210 (CH1 digital value) and D211 (CH2 digital value).
- ② When X60 is turned on, the output voltage appears on CH1 of AJ65BT-64DAV.




11. Communication Between the Master Station and the Local Station

How to set, program, and confirm the operation of the module is described using a system configuration example.

11.1 System Configuration

A system with two local stations is connected as an example.



11.1.1 Setting of the master station

The settings of the switches on the master station are shown below:

AJ61BT11

RUN 158K
ERR. 625K
MST 2.5M
S MST 5M
LOCAL 10M
CPU R/W

SW TEST
M/S S0
PRM S1
TIME S2
LINE

L RUN SD
L ERR. RD

B RATE

STATION NO.
X10
X1

MODE
0: ONLINE (A. R.)
1: ONLINE (RIM)
2: OFFLINE

B RATE

0	158K
1	625K
2	2.5M
3	5M
4	10M

OFF	ON	ON	SW
M/L	S MST	<input type="checkbox"/>	1
—	—	<input type="checkbox"/>	2
—	—	<input type="checkbox"/>	3
CLEAR	HOLD	<input type="checkbox"/>	4
1/2	3/4	<input type="checkbox"/>	5
1/4	2/3	<input type="checkbox"/>	6
ISFM	SFM	<input type="checkbox"/>	7
—	—	<input type="checkbox"/>	8


SW	Setting	Description
1	OFF	Master station
2	OFF	—
3	OFF	—
4	OFF	Clear
5	OFF	(Invalid when master station)
6	OFF	(Invalid when master station)
7	OFF	—
8	ON	I/O mode

NC
DA
DB
DG
SLD
(FG)

CC-Link

11.1.2 Setting of the local station

The settings of the switches on the local station are shown below:




11.2 Creating a Program

11.2.1 Program for the master station


(1) Program for parameter

This program automatically initiates the data link when the programmable controller CPU starts running.




11 COMMUNICATION BETWEEN THE MASTER STATION AND THE LOCAL STATION

MELSEC-A




*: Refer to Section 8.2 when using the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.



(2) Communication program

The following configuration of the programmable controller CPU device, master station's buffer memory and local station's buffer memory is assumed.


[Remote input (RX), remote output (RY)]



11 COMMUNICATION BETWEEN THE MASTER STATION AND THE LOCAL STATION


MELSEC-A

[Remote register (RWw, RWr)]



11 COMMUNICATION BETWEEN THE MASTER STATION AND THE LOCAL STATION

MELSEC-A



11.2.2 Local station program


(1) Program for parameters

Local stations do not need this.


(2) Program for communication

Refer to Section 11.2.1 (2), for the relationship among the programmable controller CPU device, master station's buffer memory, and the local station's buffer memory.

(a) Local station No.1



(b) Local station No.2



11.3 Performing the Data Link


Turn on the power supply of the local station first, then the power supply of the master station to start the data link.

11.3.1 Confirming the operation by LED display

The following diagram shows the LED display status of the master station and the local station when the data link is performed normally.


(1) LED display of the master station

Confirm that the LED display shows the following status:



(2) LED display of the local station


Confirm that the LED display shows the following status:



11.3.2 Confirming the operation by the program

Using the sequence program, confirm that the data link is proceeding normally.

- ① When M200 of the master station is turned on, M200 of the local station No.1 and the local station No.2 are turned on.
- ② When M0 of the local station No.1 is turned on, M0 of the master station and the local station No.2 are turned on.
- ③ When M32 of the local station No.2 is turned on, M32 of the master station and the local station No.1 are turned on.
- ④ When the data is written into D200 of the master station, it is stored in D200 of the local station No.1 and station No.2.
- ⑤ When the data is written into D300 of the local station No.1, it is stored in D300 of the master station and the local station No.2.
- ⑥ When the data is written into D304 of the local station No.2, it is stored in D304 of the master station and the local station No.1.




12. Communication in the Compound System

How to set, program, and confirm the operation of the module in a system where the remote I/O station, remote device station and local station coexist is described.


12.1 System Configuration

A system with a remote I/O station, a remote device station and a local station is used as an example.




12.1.1 Setting of the master station

The settings of the switches on the master station are shown below:




12.1.2 Setting of the remote I/O station

The settings of the switches on the remote I/O station are shown below:




12.1.3 Setting of the remote device station

The settings of the switches on the remote device station are shown below:



12.1.4 Setting of the local station

The settings of the switches on the local station are shown below:





12.2 Creating a Program

12.2.1 Program for the master station

(1) Parameter program


This program automatically initiates the data link when the programmable controller CPU starts running.





* : Refer to Section 8.2 when using the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.


[During operation]




(2) Communication program


The following configuration of the programmable controller CPU device, master station's buffer memory and local station's buffer memory is assumed.


[Remote input (RX), remote output (RY)]




[Remote register(RWw, RWr)]







Communication program with the local station




12.2.2 Local station program

(1) Program for parameters

Local stations do not need this.

(2) Program for communication

Refer to Section 12.2.1 (2), for the relationship among the programmable controller CPU device, master station's buffer memory, and the local station's buffer memory.



12.3 Performing the Data Link


Turn on the power supply of the remote I/O station/remote device station/local station first, then the power supply of the master station to start the data link.

12.3.1 Confirming the operation by LED display

The following diagram shows the LED display status of the master station, the remote I/O station, the remote device station, and the local station when the data link is performed normally.


(1) LED display of the master station

Confirm that the LED display shows the following status:




(2) LED display of the remote I/O station

Confirm that the LED display shows the following status:




(3) LED display of the remote device station

Confirm that the LED display shows the following status:



(4) LED display of the local station


Confirm that the LED display shows the following status:



12.3.2 Confirming the operation by the program

Confirm if the data link can be performed normally using a sequence program.

- ① When X00 of the remote I/O station is turned on, Y20 of the master station is turned on.
- ② When X10 of the master station is turned on, Y08 of the remote I/O station is turned on.
- ③ The digital value which was converted by the remote device station is stored in D210 (CH1) and D211 (CH2) of the master station and the local station.
- ④ When M160 of the master station is turned on, M160 of the local station is turned on.
- ⑤ When the data is written into D100 of the master station, it is stored in D100 of the local station.
- ⑥ When M60 of the local station is turned on, M60 of the master station is turned on.
- ⑦ When the data is written into D310 of the local station, it is stored in D310 of the master station.



13. Troubleshooting

13.1 Verification when a Trouble Occurs

Details to be checked and corrective actions for each trouble are shown below:

Trouble description	Details to be checked	Confirmation action
Unable to perform data link for the entire system.	Are there any disconnected cables?	<ul style="list-style-type: none"> Check the cable status visually or with a line test. Verify the line status (SW0090).
	Are terminating resistors connected properly to both end stations?	Connect terminating resistors attached to AJ61BT11 and A1SJ61BT11 to both end stations.
	Has an error occurred at the master station's programmable controller CPU?	Verify the error code of programmable controller CPU and perform the corrective action.
	Are parameters set for the master station?	Verify the parameter details.
	Is a request for data link startup (Yn6 or Yn8) turned on?	Verify the sequence program.
	Did an error occur at the master station?	Verify the following: <ul style="list-style-type: none"> The parameter status at the host station (SW0068) The switch setting status (SW006A) Loading status (SW0069) Is the master station "ERR" flashing? (Refer to Section 13.2.)
Unable to get input from a remote I/O station.	Is the remote I/O station performing data link?	Verify using the following means: <ul style="list-style-type: none"> LED display at the module The master station's communication status with other stations (SW0080 to SW0083)
	Is data read from the correct address of remote input RX (buffer memory)?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify parameters.
	Did the station number overlap?	Verify the station number.
Cannot output data from a remote I/O station.	Is the remote I/O station performing data link?	Verify using the following means: <ul style="list-style-type: none"> LED display of the module The master station's communications status with other stations (SW0080 to SW0083)
	Is the refresh instruction (Yn0) at the master station turned on?	Verify the sequence program.
	Is data written to the correct address of remote output RY (buffer memory)?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify parameters.
	Did the station number overlap?	Verify the station number.
Unable to get remote input (RX) from a remote device station.	Is the remote device station performing data link?	Verify using the following means: <ul style="list-style-type: none"> LED display of the module The master station's communications status with other stations (SW0080 to SW0083)
	Is data read from the correct address of remote input RX (buffer memory)?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify parameters.
	Did the station number overlap?	Verify the station number.


13


- Things to do after checking for the communication status with other stations (SW0080 to 83)
- ① Check if the wiring is correct.
 - ② Check if the terminating resistors are connected correctly to the modules on both ends.
 - ③ Confirm if the communication is successful after slowing down the transmission speed.
 - ④ Confirm if the settings of the parameter and the startup station match each other.
 - ⑤ Confirm if the station numbers do not overlap.
 - ⑥ Replace with a correctly operating module, and check to see if it is a module malfunction.

Trouble description	Details to be checked	Confirmation action
Cannot turn on/off remote output (RY) from a remote device station.	Is the remote device station performing data link?	Verify using the following means: • LED display of the module • The master station's communications status with other stations (SW0080 to SW0083)
	Is the refresh instruction (Yn0) turned on at the master station?	Verify the sequence program.
	Is data written to the correct address of remote output RY (buffer memory)?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify parameters.
	Did the station number overlap?	Verify the station number.
Unable to get the remote register (RW _r) data from a remote device station.	Is the remote device station performing data link?	Verify using the following means: • LED display of the module • The master station's communications status with other stations (SW0080 to SW0083)
	Is data read from the correct address of the remote register RW _r (buffer memory)?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify the parameters.
	Did the station number overlap?	Verify the station number.
Unable to write data onto the remote register (RW _w) at a remote device station.	Is the remote device station performing data link?	Verify using the following means: • LED display of the module • The master station's communications status with other stations (SW0080 to SW0083)
	Is data written to the correct address of remote register RW _w (buffer memory)?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify the parameters.
	Did the station number overlap?	Verify the station number.
Unable to communicate from the master station (remote output RY) to the local station (remote input RX).	Is the corresponding local station performing data link?	• Check the LED indication of the corresponding local station. • Check the communication status of the master station with other stations (SW0080 to SW0083).
	Is the refresh instruction (Yn0) at the master station turned on?	Verify the sequence program.
	Is data written to the correct address of the remote output RY (buffer memory) at the master station?	Verify the sequence program.
	Is data read from the correct address of the remote input RX (buffer memory) at the local station?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify the parameters.
	Did the station number overlap?	Verify the station number.
Unable to communicate from the local station (remote output RY) to the master station (remote input RX).	Is the corresponding local station performing data link?	• Check the LED indication of the corresponding local station. • Check the communication status of the master station with other stations (SW0080 to SW0083).
	Is the refresh instruction (Yn0) at the local station turned on?	Verify the sequence program.
	Is data written to the correct address of remote output RY (buffer memory) at the local station?	Verify the sequence program.
	Is data read from the correct address of the remote input RX (buffer memory) at the master station?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify the parameters.
	Did the station number overlap?	Verify the station number.

Trouble description	Details to be checked	Confirmation action
Unable to communicate from the master station (remote register RWw) to the local station (remote register RWr).	Is the corresponding local station performing data link?	• Check the LED indication of the corresponding local station.
	Does the occupied station count setting of the local station match the station information of the master station?	• Check the communication status of the master station with other stations (SW0080 to SW0083).
	Is data written to the correct address of remote register RWw (buffer memory) at the master station?	Verify the sequence program.
	Is data read from the correct address of the remote register RWr (buffer memory) at the local station?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify the parameters.
	Did the station number overlap?	Verify the station number.
Unable to communicate from the local station (remote register RWw) to the master station (remote register RWr).	Is the corresponding local station performing data link?	• Check the LED indication of the corresponding local station. • Check the communication status of the master station with other stations (SW0080 to SW0083).
	Is data written to the correct address of remote register RWw (buffer memory) at the local station?	Verify the sequence program.
	Is data read from the correct address of the remote register RWr (buffer memory) at the master station?	Verify the sequence program.
	Is the station incorrectly set as reserved?	Verify the parameters.
	Did the station number overlap?	Verify the station number.
Unable to stop data link.	Is the data link stop (SB0002) turned on?	Verify the sequence program.
	Did an error occur?	Verify the data link stop result (SW0045).
Unable to restart data link.	Is the data link stop (SB0000) turned on?	Verify the sequence program.
	Did an error occur?	Verify the data link restart result (SW0041).
Parameter cannot be registered in E ² PROM.	Is the parameter registration request (YnA) to the E ² PROM on?	Verify the sequence program.
	Any errors occurred?	Verify the E ² PROM registration status (SW00B9).
Remote/local station does not start up.	Are the station information in the parameters and the settings as the module which does not start up consistent?	Verify the parameters.
	Overlapping with other module's station number?	Verify the station number setting switch.
Faulty stations cannot be detected.	Set as an error-invalid station?	Verify the parameters.
	Did the station number overlap?	Verify the station number.
Faulty stations arise due to transmission speed.	Is it possible to specify faulty station from the communication status with other stations (SW0080 to 83)?	• Verify the faulty station switch setting. • Verify if the wiring is correct. • Verify if the cable shield has been grounded.
	Can communicate normally when changed to slower transmission speed like 156 kbps?	
The abnormal completion bit turns on when executing a dedicated	Did an error occur?	• Verify the CPU's error code. • Verify the master station's error code.
	Is an automatic refresh parameter set?	Set the automatic refresh parameter using an RRA instruction.
Xn1 (host station data link status) does not turn ON.	• Is the program not created so that it executes the FROM/TO instruction multiple times during one sequence scan? • Is the sequence scanning speed not far higher than the link scanning speed when the FROM/TO instruction is present?	• Reduce the number of FROM/TO instructions in the program. • Add the data link priority signal (XnC), as b contact, to the start contact of the FROM/TO instruction.
Link special relay (SB)/link special register (SW) are not updated correctly.		

13.2 Troubleshooting when the "ERR" LED on the Master Station is Flashing





* 1 Check for a short, reversed connection, wire breakage, terminating resistor, FG connection, overall distance and station-to-station distance.

13.3 Error Codes

Table 13.1 lists the error codes that are stored in the link special registers (SW). When using a master/local module as a standby master station, refer to the respective columns under "Detectability" in the table as explained below.

- When a standby master station is operating as a master station: "Master station" column
- When a standby master station is operating as a standby master station: "Local station" column

Table 13.1 Error code list (1/6)

Error code (hexadecimal)	Error details	Cause of error occurrence (details)	Corrective action	Detectability	
				Master station	Local station
7000 to 7FFF	(Errors detected by serial communication module, etc)	—	Handle by referring to the troubleshooting section of the Serial Communication Module User's manual.	—	—
B104	Data link restart error	Data link restart (SB0000) was executed for the station that was performing a data link.	Execute Data link restart (SB0000) for the station that has stopped a data link with Data link stop (SB0002).	○	○
B105	Data link stop error	Data link stop (SB0002) was executed for the station that had stopped a data link.	Execute Data link stop (SB0002) for the station that is performing a data link.	○	○
B110 * 1	Transient data can not be received	A line error has occurred.	Check the line.	○	○
B111 * 1	Transient data receiving order error	A line error has occurred.	Check the line.	○	○
B112 * 1	Transient data length error	A line error has occurred.	Check the line.	○	○
B113 * 1	Transient data ID error	A line error has occurred or an instantaneous power failure has occurred at the send station.	Check the line, or check the supply power and power supply module of the send station.	○	○
B115 * 1	Link error	A line error has occurred.	Check the line.	○	○
B116 * 1	Packet error	A line error has occurred.	Check the line.	○	○
B201 * 1	Corresponding station error during sending	A data link error occurred at the corresponding station during transient transmission.	Check the communication status of other stations, whether or not a temporary error invalid station is specified, or if the corresponding station is stopped.	○	○
B205	Transient target station error	A transient request was issued to other than the intelligent device station.	Check the target station.	○	○
B301	Processing request error during link stop	Line test request was issued while the link was stopped.	Perform a line test while the link is being established.	○	○
B302	Specified station number setting error	The specified station number exceeded the highest communication station number during temporary error invalid request/temporary error invalid cancel request.	Specify a station number that is no greater than the highest communication station number.	○	×
B303	Specified station number not set error	The station number was not specified during temporary error invalid request/temporary error invalid cancel request.	Set a specified station number. (SW0003, SW0004 to SW0007)	○	×
B304	Line test error station detected	An error was detected in a remote station, intelligent device station or standby master station when a line test was performed.	Check that the remote station, intelligent device station or standby master station is operational and that the cable is not disconnected.	○	×
B306	Specified station number setting error	A station number other than the head station number was specified during temporary error invalid request/temporary error invalid cancel request.	Specify a head station when temporary error invalid request/temporary error invalid cancel request is requested.	○	×
B307	All stations data link error	All stations were in data link error status when one of the following requests was made: <ul style="list-style-type: none"> • SB0000 (data link restart) • SB0002 (data link stop) 	Request again after the data link becomes normal.	○	○
B308	Station number setting error (installation status)	The station number of the slave station is outside of the range between "1 and 64".	Set the station number of the slave station within the range between "1 and 64".	○	×
B309	Station number overlap error	The station number of the connected module was duplicated (including number of occupied stations). However, this excludes the duplicate head station number.	Check the module station number.	○	×

*1: Error code added to the function version B or later.

Table 13.1 Error code list (2/6)

Error code (hexadecimal)	Error details	Cause of error occurrence (details)	Corrective action	Detectability									
				Master station	Local station								
B30A	Loading/parameter compatibility error	The station types of the module are different from parameter settings. Example) <table border="1" style="margin-left: 20px;"> <tr> <td>Connected module</td> <td>Parameter setting</td> </tr> <tr> <td>Remote device</td> <td>Remote I/O</td> </tr> <tr> <td>Intelligent device</td> <td>Remote I/O</td> </tr> <tr> <td></td> <td>Remote device</td> </tr> </table>	Connected module	Parameter setting	Remote device	Remote I/O	Intelligent device	Remote I/O		Remote device	Set the correct parameters.	○	×
Connected module	Parameter setting												
Remote device	Remote I/O												
Intelligent device	Remote I/O												
	Remote device												
B30B * 1	Loading/parameter compatibility error	The contents of the installation status and network parameters do not match.	Set the contents of the installation status and network parameters to match.	○	×								
B30C * 1	Standby master station specification error	Master station switching was instructed to a station other than the standby master station.	Specify the station number that corresponds to the standby master station.	○	○								
B30D * 1	Initial status	Temporary error invalid station specification, line test request, or data link stop/restart request, etc. was issued before starting the link.	Issue the requests after the data link is started.	○	○								
B30E	Unsupported error	In the function started by SB/SW, an attempt was made to execute the function, which is supported by only the master station, at the local station.	Execute the corresponding function from the master station.	×	○								
B381	Station number switch setting error	The station number switch was outside of the setting range.	Set the station number switch within the setting range.	○	○								
B383	Transmission rate setting switch setting error	The transmission rate setting switch is set outside the range.	Set the transmission rate setting switch to within the setting range.	○	○								
B384	Station number setting error (parameter)	The station number (including the number of occupied stations) of the station information parameters (address 20H to 5FH) was set to "other than 1H to 40H".	Set within the range of "1H to 40H".	○	×								
B385	Total number of stations error (parameter)	The total number of occupied stations set with the station information parameter (address 20H to 5FH) exceeded 64.	Set a parameter value of 64 or less.	○	×								
B386	Number of occupied stations setting error (parameter)	The number of all occupied stations in the station information parameter (address 20H to 5FH) was set to "0".	Set the occupied station number to a value between "1 and 4".	○	×								
B387	Delay time setting error (parameter)	The delay time setting in the master station network parameters is out of the setting range.	Set a value within the setting range.	○	×								
B388	Station type setting error (parameter)	The station type in the station information parameter (address 20H to 5FH) was set to "other than 0 to 2".	Set to a value between "0 and 2".	○	×								
B38B	Remote device station setting error (parameter)	The number of remote device stations was set to "43 stations or more" with the station information parameter (address 20H to 5FH).	Set the remote device station to "42 stations or less" with the station information parameter.	○	×								
B38C	Intelligent device station setting error (parameter)	The number of intelligent device stations (including local stations) was set to "27 stations or more" with the station information parameter (address 20H to 5FH).	Set the intelligent device station to "26 stations or less" with the station information parameter.	○	×								
B38E * 1	Communication buffer assignment error (parameter)	The total size of the communication buffers in the station information parameter (address 20H to 5FH) exceeded 4 k words.	Set the total size of the communication buffers to 4 k words or less.	○	×								
B38F * 1	Automatic update buffer assignment error (parameter)	The total size of the automatic update buffer in the station information parameter (address 20H to 5FH) exceeded 4 k words.	Set the total size of the automatic update buffer to 4 k words or less.	○	×								
B390	Standby master station specification error (parameter)	The standby master station parameter (address 4H) was set to a value other than "1 to 64".	Specify the standby master station to a value within the range from "1 to 64".	○	×								

* 1: Error code added to the function version B or later.

Table 13.1 Error code list (3/6)

Error code (hexadecimal)	Error details	Cause of error occurrence (details)	Corrective action	Detectability	
				Master station	Local station
B391	Retry count setting error (parameter)	The retry count parameter (address 2H) was set to a value other than "1 to 7".	Set a value within the range from "1 to 7".	○	×
B392	Operation when CPU is down specified error (parameter)	The operation when the CPU is down specification parameter (address 6H) was set to a value other than "0 or 1".	Set "0 or 1".	○	×
B393	Scan mode specification error (parameter)	The scan mode parameter (address 7H) was set to a value other than "0 or 1".	Set "0 or 1".	○	○
B394	Number of automatic return stations setting error (parameter)	The number of automatic return stations parameter (address 3H) was set to a value other than "1 to 10".	Set a value within the range from "1 to 10".	○	×
B396	Station number overlap error (parameter)	A duplicate station number was specified with the station information parameter (address 20H to 5FH).	Set so that station numbers are not duplicated.	○	×
B397	Station information setting error (parameter)	The station information parameter (address 20H to 5FH) setting does not meet the following condition: $(16 \times A) + (54 \times B) + (88 \times C) \leq 2304$ A: Number of remote I/O stations B: Number of remote device stations C: Number of intelligent device stations (including local stations)	Set the parameter so that it meets the condition shown on left.	○	×
B398	Number of occupied stations setting error (parameter)	The number of occupied stations in the station information parameter (address 20H to 5FH) was set to a value other than "1 to 4".	Set a value within the range from "1 to 4".	○	×
B399	Number of connected modules setting error (parameter)	The number of connected modules parameter (address 1H) was set to a value other than "1 to 64".	Set a value within the range from "1 to 64".	○	×
B39A * 1	Standby master station specification error (loading status)	The status setting switch of the station number different from that specified with the parameter is set in the standby master station.	Confirm the parameter or status setting switch.	×	○
B39B	Reserved station setting error (parameter)	The parameter's reserve station specification is set to all reserve stations.	Check the parameter's reserve station specification.	○	×
B39C * 1	Standby master station setting error	The station information of the station number specified as the standby master station has been set to other than the intelligent device station.	Correct the station information of the station specified as the standby master station to be the intelligent device station.	○	×
B401 * 1	Parameter change error	Parameter change was executed during transient request.	Change the parameter after all transient requests are completed or before any are requested.	○	○
B404 * 1	Response error	A response from the requested station was not returned within the watchdog time period.	Set a longer watchdog time. If an error persists, check the requested module and cables.	○	○
B405 * 1	Transient request error	A transient request was made to a remote I/O station or a remote device station. Or, there are too many transient requests to the corresponding station.	Set the corresponding station to a local station or an intelligent device station. Or, wait a while and then send the requests (transient overload status).	○	○
B406 * 1	RY simultaneous ON error	RY is turned ON before the response is complete, or a request is issued without turning RY off.	After the response is complete, always turn RY off before sending a request.	○	○
B407 * 1	Transient communication number unmatched error	The request data number is different from the response data number.	Check the line.	○	○

* 1: Error code added to the function version B or later.

Table 13.1 Error code list (4/6)

Error code (hexadecimal)	Error details	Cause of error occurrence (details)	Corrective action	Detectability	
				Master station	Local station
B510 *2	Transmission channel in use (host station)	A channel being used was used.	The same channel cannot be used simultaneously. Change the channel number, or try not to use the same channel simultaneously.	○	○
B511 *2	Receive channel in use	The channel of the target station is in use.	Wait for a while before executing the SEND instruction again. Check whether there are multiple requests to the same channel of the target station from the local station or multiple stations.	○	○
B512 *2	Arrival wait time out	The arrival watchdog time has elapsed (when the number of retransmission is 0), or the RECV instruction was executed even though the RECV instruction execution request flag was not on.	When the error occurs with a RECV instruction, increase the value of arrival watchdog time if other stations are executing SEND instructions. If the local station is executing instructions, increase the value of arrival watchdog time. If the error persists, check the network and the target station.	○	○
B513 *2	Number of retries count over	When the send/receive instruction was used, the number of retries exceeded the set number.	Increase the arrival watchdog time. If the error persists, check the network and the target station.	○	○
B515 *2	Channel number error	The channel number is out of the setting range.	Set the channel at the local and target stations to either 1 or 2.	○	○
B519 *2	Number of retransmissions error	The number of retransmissions is out of the setting range.	Set it in the range of 0 to 15 (times).	○	○
B51A *2	Arrival watchdog time error	The arrival watchdog time is out of the setting range.	Set it in the range of 0 to 32767 (seconds).	○	○
B520 *2	Transmission destination station number error	The value "other than 0" is set for the target station number.	Set the target station number to "0".	○	○
B524 *2	Transmission destination station CPU error	There is an error in the CPU at the transmission destination station.	Check the CPU of the transmission destination station.	○	○
B601 *1	Request type error	An unsupported request was received.	Check the contents of the request, as well as the target station number.	○	○
B602 *1	Transient request overload error	There are too many transient requests to the corresponding station.	Wait a while and then send the requests (transient overload status).	○	○
B603 *1	Transient request overload error	There are too many transient requests to the corresponding station.	Wait a while and then send the requests (transient overload status).	○	○
B604 *1	Line test in processing	Transient transmission was sent when a line test was in progress.	Wait a while and then retransmit.	○	×
B605 *1	Transient storage buffer could not be obtained	Transient storage buffer could not be obtained.	Wait a while and then retransmit.	○	○
B607 *2	Target station CPU error	There is an error in the target station's CPU.	Check the target CPU.	○	○
B608 *2	Mode setting error	A transient request addressed to the host station programmable controller CPU was received in the I/O mode.	Set SW8 of the condition setting switch to OFF (intelligent mode).	○	○

*1: Error code added to the function version B or later.

*2: Error code added to the software version J (manufactured in Jan., 1998) or later.

Table 13.1 Error code list (5/6)

Error code (hexadecimal)	Error details	Cause of error occurrence (details)	Corrective action	Detectability	
				Master station	Local station
B771 *2	Transient request overload error	There are too many transient requests to the corresponding station.	Wait a while and then retransmit (transient overloaded status).	○	○
B774 *2	Transient request error	The target station was not an intelligent device station.	Check if the target station is an intelligent device station.	○	○
B778 *2	Response time out	A response was not received from the requested station.	Check the requested module and cables.	○	○
B783	Transient storage buffer error	An error occurred in the transient storage buffer when a transient transmission of greater than 1 k was being performed.	Wait a while and then retransmit.	○	○
B801 *1	Access code setting error	A non-existing access code/attribute was set.	Set a correct access code/attribute.	○	○
B802 *2	Access code error	An access code that does not exist was used.	Use the correct access code.	○	○
B803 *1	Data points error	The number of data points were out of range.	Set the number of data points to within 1 to 960 bytes.	○	○
B804 *1	Attribute definition error Transient transmission unsupported station specification error	The attribute definition was invalid. Alternatively, transient transmission was performed even though the target station does not support transient transmission.	Review the attribute definition. Check the designation of the target station number, as well as the function version and software version of the target local station.	○	○
B805 *1	Data points error	The number of data was out of range.	Set the range to within 1 to 100 when writing, and 1 to 160 when reading.	○	○
B807 *1	Device No. error	The start device No. is out of range. Or, the address was not a multiple of 16 when the bit device was accessed.	Correct the start device No. Or, set the address to a multiple of 16 when accessing the bit device.	○	○
B80D *2	Setting range error	The specified combination (addresses and points) exceeded the valid processing range.	Set so that the number of processing points does not exceed the device range.	○	○
B814 *2	File register capacity setting error	The file register capacity was not specified.	Specify the file register capacity.	○	○
B815 *2	Module mode setting error	A transient transmission was executed when the target station was set to the I/O mode.	Set to the intelli mode.	○	○
B823	Remote control mode error	The mode setting of the remote control was incorrect.	Check the mode specification.	○	○
B901	E ² PROM error	When a parameter registration request (YnA) to E ² PROM was executed, E ² PROM was out of order or exceeded its write limit (10,000 times).	Replace the module.	○	×
B902	Error in data link startup by E ² PROM parameter	Data link start request by E ² PROM parameter (YnB) was executed even though the parameter was not registered in E ² PROM.	Register the parameter to E ² PROM by a parameter entry request (YnA).	○	×
B903 *1	Transient request error	A transient request was issued to a station that has not secured a communication buffer area.	Secure a communication buffer area with a parameter.	○	○
B904 *1	Communication buffer size setting error	The communication buffer size of the corresponding station was out of range when a dedicated instruction was executed.	Set the communication buffer size of the corresponding station within the range.	○	○
B905 *1	Transient data length error	When the dedicated instruction is executed, the transient data length is greater than the communication buffer size of the corresponding station.	Make the communication buffer size of the corresponding station greater than the transient data length.	○	○

*1: Error code added to the function version B or later.

*2: Error code added to the software version J (manufactured in Jan., 1998) or later.

Table 13.1 Error code list (6/6)

Error code (hexadecimal)	Error details	Cause of error occurrence (details)	Corrective action	Detectability	
				Master station	Local station
B907 *3	Execution disabled during data link	E ² PROM erasure request (YnD: ON) was executed during data link (SB006E: ON).	Execute a data link stop using SB0002.	○	×
B912 *3	No registration area	The parameter registration request to E ² PROM (YnA: ON) was executed in excess of a maximum of 127 registration times.	Execute the E ² PROM erasure request (YnD: ON), switch power off, or reset the CPU.	○	×
B913 *3	E ² PROM fault	The parameter registration request to E ² PROM (YnA: ON) was executed but E ² PROM is faulty.	Change the module.	○	×
BA19	Corresponding station error	The corresponding station that is being tested stopped communication during line test 1.	Check the cable and the corresponding station.	○	×
BA1B	All stations error	All stations stopped communications during line test 1.	Check the cables.	○	×
BBC1	Mode setting error (switch)	The mode setting switch is set outside the range.	Set it within the range.	○	○
BBC2	Station number setting error (switch)	The station number setting switch setting of the module is other than "0 to 64". Alternatively, the last station number is greater than 64.	Check the station number and the number of occupied stations of the module.	○	○
BBC3	Transmission speed setting error (switch)	Module's transmission speed setting switch is set out of the range of "0 to 4".	Set it in the range of "0 to 4."	○	○
BBC4	Station type change error (station number)	An attempt was made to change the master station (0) to the local station (1 to 64), or the local station (1 to 64) to the master station (0) by executing a module reset (Yn4).	Change by resetting the programmable controller CPU.	○	○
BBC5	Master station overlapping error	Multiple master stations exist on the same line. Alternatively, line noise was detected at power on.	Reduce the number of master stations on the same line to one. Alternatively, check the line status.	○	×
BBC6	Mode change error	An attempt was made to change the mode from 0 or 2 to the test mode by executing a module reset (Yn4).	Change by resetting the programmable controller CPU.	○	○
BBC7	Module error	Module is defective.	Replace the module.	○	○
BD85	Hardware error detection	A hardware error was detected.	There is most likely a hardware error in either the AJ61BT11/A1SJ61BT11, the CPU module, the base unit or other modules. Please consult your local Mitsubishi representative.	○	○
BFFE	CPU monitoring timer time out	The CPU monitoring timer timed out.	Check the operation of the target station.	○	○
C000 to CFFF	(Errors detected by the Ethernet module)	—	Handle by referring to the troubleshooting section of the Ethernet Interface Module User's manual.	—	—
F000 to FFFF	(Error detected by the MELSECNET/H, MELSECNET10 network system)	—	Handle by referring to the troubleshooting section of the MELSECNET/H, MELSECNET/10 network system reference manual	—	—


*3: Error code added to the software version E (manufactured in Aug., 2001) or later of the A1SJ61BT11.

13.4 LED Display Status

The LED display status of each station for each data-link (system) status is shown below, where the transmission speed is set at 2.5 Mbps. Refer to Troubleshooting.


13.4.1 When data link is normal

The "PW", "RUN", "L RUN", "SD" and "RD" LEDs are on.



13.4.2 When a cable is disconnected


Data link for all the stations is lost. You cannot identify the location of wire breakage by the LED indications.



13.4.3 When a cable is shorted

Data link for all the stations is lost.


You cannot identify a short circuit occurred by the LED indications.



13.4.4 When the link is stopped at the master station


All stations will not be able to perform data link.

The "L RUN" LED turns off for all stations except for the master station.




13.4.5 When power supply to a remote I/O station is turned off

Data link is continued excluding that remote I/O station.
 "ERR." LEDs at the master station and the local station flash.




13.4.6 When the power supply to a remote device station is turned off

Data links is continued excluding that remote device station.
 The "ERR." LEDs at the master station and the local station flash.




13.4.7 When the power supply to the local station (Programmable controller CPU) is turned off

Data link is continued excluding the local station.
The "ERR." LED at the master station flashes.



13.4.8 When the station numbers are duplicate


This is a case where the settings for a remote I/O station and a remote device station are duplicate. A skipped number (no slave station exists) result in the system because of overlapped station number, so the "ERR." LED on the master station flashes.



13.4.9 When the transmission speed is set incorrectly

This is a case where the transmission speed for the remote device station is set incorrectly.


The "L RUN" LED for the remote device station with the incorrect transmission-speed setting turns off.



13.4.10 When the switch setting is changed during data link


This is a case where the switch setting for the remote I/O station was changed.

The "L ERR." LED for the remote I/O station whose switch setting was changed flashes. However, data link can be continued. Also, if returned to the previous state, "L ERR" turns off.




13.4.11 When data link is started with the switch set outside the range

This is a case where data link was started with the switch set outside the range. The "L RUN" and "SD" LEDs at the remote device station turn off and "L ERR." LED is turn on.



13.4.12 When the remote I/O station is not set by the parameter (i.e., is set as reserved)


No data links can be performed with the remote I/O station at all, and no error occurs. The "L RUN", "SD" LEDs at the remote I/O station turn off.



13.4.13 When the remote device station is not set by the parameter (i.e., is set as reserved)

No data link can be performed with the remote device station at all, and no error occurs.


The "L RUN", "SD" LEDs at the remote device station turn off.



13.4.14 When the local station is not set by the parameter (i.e., is set as reserved)

No data link can be performed with the local station at all, and no error occurs.

The "L RUN", "SD" LEDs at the local station turn off.



14. Overview (Function Version B or Later)

The functions available with the master and local modules depend on their function versions and CPU types, as shown in Table 14.1.

Table 14.1 List of available functions with different function versions

Function	Description	Detailed description	Function version	
			A	B or later
Parameter registration	CPU module	The method to use dedicated instructions to set the CC-Link parameters and receive notification when the power is turned on or at STOP → RUN.	–	○ * 1 * 2
	Buffer memory	The method to write directly into the buffer memory in the module and receive notification.	○	○
	E ² PROM	The method to register to the E ² PROM in the module and receive notification.	○	○
Automatic refresh		RX, RY and other cyclically transmitted data can be refreshed to a desired device through the END processing, using dedicated instructions.	–	○ * 2 * 3
Scan synchronization	Synchronous mode	Data link can be performed using the scan synchronized with the sequence program.	–	○ * 1 * 2
	Asynchronous mode	Data link can be performed using the scan not synchronized with the sequence program.	○	○
Cyclic transmission	Bit transmission	Data communication can be performed at 32 points per station.	○	○
	Word transmission	Data communication can be performed at 4 points per station.	○	○
Transient transmission	Dedicated instructions	Transient transmission can be performed to the intelligent device and local station using dedicated instructions.	–	○ * 1 * 2
		Device can be read from/written to the CPU of the specified station using dedicated instructions.	–	○ * 1 * 2 * 4
Remote I/O net mode		Communication can be performed only with the remote I/O station without setting parameters.	–	○ * 5
Reserved station setting		Stations to be connected later can be skipped and set in advance.	○	○
Error detection invalid station setting		Data link error can be ignored when data link is disabled at any station.	○	○
Temporary error invalid station setting		Replacement of modules can be performed online without detecting an error at the corresponding remote station.	–	○
Module reset		Only CC-Link can be reset when changing switches, etc., without stopping the CPU.	○	○
Data link stop/restart		Stop/restart can be performed during data link.	○	○
RAS	Automatic return	The station which has been disconnected from data link can be returned automatically to the data link through normal return.	○	○
	Standby master	Data link can be continued when an error occurs at the master station, by switching to the standby master station.	–	○
	Slave station disconnection	The station at which data link has been disabled can be disconnected so that data link can be continued using normal stations only.	○	○
	Confirmation of data link status	The data link status can be confirmed using the special relay and special register.	○	○
	Off-line test	A hardware test, line test, etc., can be performed.	○	○

POINT

The functions denoted *1 can be used only when the following CPUs are used:

- A1SHCPU, A1SJHCPU, A2SHCPU : Not limited by software version
- A2UCPU(S1), A3UCPU, A4UCPU : Software version Q (manufactured in Jul., 1999) or later
- A2USCPU(S1) : Software version E (manufactured in Jul., 1999) or later
- A2USHCPU-S1 : Software version L (manufactured in Jul., 1999) or later

The functions denoted *2 cannot be used when a remote I/O station of MELSECNET/10 is installed.

The functions denoted *3 can be used only when the following CPUs are used.

- A1SHCPU, A1SJHCPU, A2SHCPU : Not limited by software version
- A2UCPU (S1), A3UCPU, A4UCPU : Software version K (manufactured in Aug., 1998) or later
- A2ASCPU (S1) : Software version A (manufactured in Aug., 1998) or later
- A2USHCPU-S1 : Software version G (manufactured in Aug., 1998) or later

The functions denoted *4 can be used for software version J (manufactured in Jan., 1998) or later.

The functions denoted *5 can be used through a combination of the master module of software version P (manufactured in Sep., 1998) or later and the CPUs listed in Section 15.7.

15. Functions (Function Version B or Later)

The functions added in the function version B or later are explained.

15.1 List of Functions

A list of functions is shown in Table 15.1.

Table 15.1 List of functions

Item	Function overview		Reference section	Availability of functions		
				Master station	Local station	Standby master station
Parameter registration function	The function to set values as part of the parameters in the CPU, using dedicated instructions. There are two types of parameters as below: • Network parameters • Automatic refresh parameters		Section 15.2	○	○*1	○*1
Automatic refresh function	RX, RY and other cyclically transmitted data can be refreshed to a desired device through the END processing, using dedicated instructions.		Section 15.3	○	○	○
Scan synchronous function	Synchronous mode	Data link can be performed using the scan synchronized with the sequence program.	Section 15.4	○	×	×
	Asynchronous mode	Data link can be performed using the scan not synchronized with the sequence program.	Section 15.4	○	○	○
Standby master function	Data link can be continued when an error occurs at the master station, by switching to the standby master station.		Section 15.5	×	×	○
Dedicated instructions	Transient transmission can be performed to the intelligent device and local stations using dedicated instructions. Dedicated instructions also facilitate read/write of data with handshake from/to remote devices.		Section 15.6	○	○	○
	Device can be read from/written to the CPU of the specified station using dedicated instructions			○*2	○*2	○*2
Remote I/O net mode	Communication can be performed only with the remote I/O station without setting parameters.		Section 15.7	○*3	×	×
Temporary error invalid station specification function	Replacement of modules can be performed online without detecting an error at the corresponding remote station.		Section 15.7	○	×	×

*1 It is not necessary to set the network parameters.

*2 It can be used with software version J (manufactured in Jan., 1998) or later.

*3 It can be used with software version P (manufactured in Sep., 1998) or later.

15.2 Parameter Registration Function

This is a function to set values as part of the parameters in the CPU, using dedicated instructions. There are two types of parameters: network parameters and automatic refresh parameters.

As for dedicated instructions, refer to the programming manual of the CPU.

POINT

- | |
|---|
| <ul style="list-style-type: none"> • The "Y" at the master module will be ignored while using the parameter registration function. |
|---|

15.2.1 Network parameters

Network parameters are used for performing data link. The items that are set by the network parameters are shown in Table 15.2.

Table 15.2 Network parameters

Setting item	Description	Buffer memory address									
		Hex.	Dec.								
Number of connected modules	Sets the number of remote stations, local stations, intelligent device stations, and standby master station connected to the master station. (Includes reserved stations.) Default value : 64 (modules) Setting range : 1 to 64 (modules)	1H	1								
Number of retries	Sets the number of retries during the communication error. Default value : 3 (times) Setting range : 1 to 7 (times)	2H	2								
Number of automatic return modules	Sets the number of remote stations, local stations, intelligent device stations, and standby master station that can be returned by one link scan. Default value : 1 (module) Setting range : 1 to 10 (modules)	3H	3								
Standby master station specification	Specifies the station number of the standby master station. Default value : 0 (0: No standby master station specified) Setting range : 0 to 63 (0: No standby master station specified.)	4H	4								
Operation specification when CPU becomes faulty	Specifies the data link status when a master station programmable controller CPU error occurs. Default value : 0 (stop) Setting range : 0 (stop) 1 (continue)	6H	6								
Scan mode specification	Specifies the synchronous or asynchronous mode for sequence scan. Default value : 0 (asynchronous) Setting range : 0 (asynchronous) 1 (synchronous)	—	—								
Delay time setting	Set 0 for the delay time.	8H	8								
Reserved station specification	Specifies the reserved station. Default value : 0 (Not set) Setting range : Turn on the bit corresponding to the station number.	10H to 13H	16 to 19								
Error invalid station specification	Specifies the error invalid station. Default value : 0 (Not set) Setting range : Turn on the bit corresponding to the station number.	14H to 17H	20 to 23								
Station information	Sets the type of the connected remote stations, local stations, intelligent device stations, and standby master station. Default value : 0101H (remote I/O station, 1 station occupied, station number 1) to 0140H (remote I/O station, 1 station occupied, station number 64) Setting range : See below. <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%; text-align: center;">b15 to b12</td> <td style="width: 25%; text-align: center;">b11 to b8</td> <td style="width: 25%; text-align: center;">b7</td> <td style="width: 25%; text-align: center;">to b0</td> </tr> <tr> <td style="text-align: center;">Station type</td> <td style="text-align: center;">Occupied stations</td> <td colspan="2" style="text-align: center;">Station No.</td> </tr> </table> </div> 1 : 1 station occupied 2 : 2 stations occupied 3 : 3 stations occupied 4 : 4 stations occupied 0 : Remote I/O station 1 : Remote device station 2 : Intelligent device station, Local stations and standby master station	b15 to b12	b11 to b8	b7	to b0	Station type	Occupied stations	Station No.		20H (first module) to 5FH (64th module)	32 (first module) to 95 (64th module)
b15 to b12	b11 to b8	b7	to b0								
Station type	Occupied stations	Station No.									

Table 15.2 Network parameters (continued)

Setting item	Description	Buffer memory address			
		Hex.	Dec.		
Allocation of communication buffer and automatic update buffer	Specifies the size of the buffer memory that is allocated during the transient transmission to local, standby master or intelligent device stations. Default value Send buffer: 40 _H (64) (word) Receiving buffer: 40 _H (64) (word) Automatic updating buffer: 80 _H (128) (word) Setting range •Send/receive buffer : 0 _H (0) (word) (no setting) or 40 _H (64) (word) to 1000 _H (4096) (word) Note that the total size of the send/receive buffer is within 1000 _H (4096) (word). •Automatic update buffer : 0 _H (0) (word) (no setting) or 80 _H (128) (word) to 1000 _H (4096) (word) Note that the total size of the automatic update buffers is within 1000 _H (4096) (word).	80 _H (send buffer)	128(send buffer)		
		81 _H (receive buffer) 82 _H (automatic update buffer)	129(receive buffer) 130(automatic update buffer)	} The first intelligent device } to	} The first intelligent device } to
		CB _H (send buffer) CC _H (receive buffer) CD _H (automatic update buffer)	203(send buffer) 204(receive buffer) 205(automatic update buffer)	} The 26th intelligent device } to	} The 26th intelligent device } to

POINT
(1) The data link start request need not be set.
(2) For the communication buffer size, specify the size of the data to be sent or received plus 7 words.
(3) For the automatic update buffer size, allocate the size necessary for each intelligent device.

15.2.2 Automatic refresh parameters

Automatic refresh parameters are used to refresh all of the devices in the CC-Link to the CPU device during the END processing. The devices that can be set by the automatic refresh parameters are shown in Table 15.3.

Table 15.3 Automatic refresh parameters (Device that can be set)

CPU device CC-Link device	Bit device								Word device					
	X	Y	M	B	T	ST	C	F	D	W	T	ST	C	R
RX	○		○	○					○	○				○
RY		○	○	○	○	○	○		○	○	○	○	○	○
RWw			○	○					○	○				○
RWr			○	○					○	○				○
SB			○	○					○	○				○
SW			○	○					○	○				○

15.3 Automatic Refresh Function

This function uses dedicated instructions to refresh RX, RY and other cyclic transmitted data to a desired device through the END processing. This function eliminates the need to access the buffer memory using the FROM/TO instruction.

As for dedicated instructions, refer to the programming manual of the CPU.

15.4 Scan Synchronous Function

This function sets whether link scan is synchronized with the sequence scan, using the network parameter setting.

15.4.1 Synchronous mode

Performs data link using the scan synchronized with the sequence program. The operation overview in the synchronous mode is shown in Figure 15.1.

In general, the transmission delay is smaller in the synchronous mode than in the asynchronous mode. Select the synchronous mode if the transmission delay is noticeably long.

However, as sequence scan is synchronized with link scan in the synchronous mode, the link scan is prolonged if the sequence scan is long. In this case, select the asynchronous mode.

Important

While in the synchronous mode, the scan time must not exceed the time specified for the corresponding transmission speed, as shown below. If the specified time is exceeded, a time out error occurs at each station and the station becomes faulty.

Transmission speed	Scan time
10Mbps	50ms
5Mbps	50ms
2.5Mbps	100ms
625kbps	400ms
156kbps	800ms




Figure 15.1 Operation overview in the synchronous mode

15.4.2 Asynchronous mode

Performs data link without synchronizing with the sequence program. The operation overview in the asynchronous mode is shown in Figure 15.2.




Figure 15.2 Operation overview in the asynchronous mode


15.5 Standby Master Function

This function allows data link to continue when an error occurs at the master station, by switching to the standby master station.

However, switching from the standby master station to the master station will not occur automatically when the master station returns.

15.5.1 Operation overview

The operation overview of the standby master function is shown in Figure 15.3.



*1: Accepts refresh from the CPU by the switching instruction of the link special relay (SB0001).

*2: The host area is retained/cleared (by the DIP switch).

Figure 15.3 Operation overview of the standby master function

15.5.2 Settings on using the standby master function

The settings on using the standby master function are as follows:

- (1) **Setting of the standby master station**
 - 1) Set the station number setting switch in the range of 1 to 64.
 - 2) Turn on the condition setting switch SW1.
- (2) **Setting of the master station**
 - 1) Change the standby master station specification in the network parameter to the station number of the standby master station.
- (3) **Setting of the local station and remote station**

Same as when no standby master station is used.

Important

Do not use the station number "64" in the system where a standby master station exists. If this number is used, the station to which the number "64" was assigned cannot perform normal communication.
--

15.5.3 Link special relays/registers (SB,SW) relating to the standby master function

The link special relays and link special registers relating to the standby master function are explained.

They are stored in the buffer memory.

(1) Link special relays (SB)

The link special relays (SB) relating to the standby master function are as follows. The figures in parentheses in the number column indicate buffer memory address and bit location.

Example: When buffer memory address is 5E0H and bit location is 0: (5E0H, b0)

Table 15.4 List of link special relays relating to the standby master function

Number	Name	Description	Availability (○ : available, × : not available)	
			Master station	Standby master station
SB0001 (5E0H, b1)	Master station switch data link start	Switches the output information from the standby master station to the master station to start the data link. OFF : No request ON : Request	×	○
SB0042 (5E4H, b2)	Master station switch data link start acceptance status	Indicates the acceptance status specified for switching data link start from the standby master station to the master station. OFF : Not accepted ON : Accepted	×	○
SB0043 (5E4H, b3)	Master station switch data link start complete status	Indicates the acceptance complete status specified for switching data link start from the standby master station to the master station. OFF : Not completed ON : Completed	×	○
SB0070 (5E7H, b0)	Master station data link status	Indicates the data link status. OFF : Data link by the master station ON : Data link by the standby master station	○	○
SB0071 (5E7H, b1)	Standby master station information	Indicates whether there is standby master station or not. OFF : No ON : Yes	○	○

(2) Link special registers (SW)

The link special registers (SW) relating to the standby master function are as follows.

The figures in parentheses in the number column indicate buffer memory address.

Table 15.5 List of link special registers relating to the standby master function

Number	Name	Description	Availability (○ : available, × : not available)	
			Master station	Standby master station
SW0043 (643H)	Master station switch data link start result	Stores the results of execution of the master station switch data link start instruction by SB0001. 0 : Normal Other than 0 : Stores error code (Refer to Section 13.3)	×	○
SW0073* (673H)	Standby master station number	Stores the standby master station number. 1 to 63 (stations)	○	○


15.5.4 Notes on using the standby master function

The following are the notes on using the standby master function.

- ① There can be only one standby master station in a data link system.
- ② The total number of stations is 64 including the standby master station. The number of occupied stations for the standby master station is one or four.
- ③ Parameter registration to the standby master station is not necessary.
- ④ If an error is detected at the master station in the initial status (before parameter communication starts), switching to the standby master station will not be executed.
- ⑤ When the master station becomes faulty, the polling issuing authority will switch automatically to the standby master station, but the cyclic data transmission will not switch. The switch must be enabled using the sequence program. Once the switch has been enabled, the information up to the error detection at the master station will be outputted to each remote station.
- ⑥ Parameters cannot be updated during the data link by the standby master station.
- ⑦ Once the standby master station fails, the master station cannot recover its normal operation even if the standby master station recovers its normal operation.
- ⑧ When the master station becomes faulty, and the polling issuing authority is switched to the standby master station, the standby master station number causes an error. (Applicable bits of SB0080 and SW0080 to SW0083 are turned ON)
When the standby master station is specified as the error invalid station, the error detection function can be disabled.

15.5.5 Program example on using the standby master function

The following is a program example on using the standby master function.



15.6 Dedicated Instructions

Transient transmission can be performed to the intelligent device station and local station using dedicated instructions.

Dedicated instructions also facilitate read/write of data with handshake from/to remote devices.

The dedicated instructions that can be used from different types of stations are shown in Table 15.6. Refer to the AnSHCPU/AnACPU/AnUCPU Programming Manual (Dedicated Instructions) for the detail of each instruction.

Table 15.6 List of available dedicated instructions at different stations

Applicable station	Instruction	Description	Availability (○ : available, × : not available)		
			Master station	Local station	Standby master station
Master station, local station	RLPA	Sets the network parameters. All items which cannot be set by RLPA instructions are operated by default.	○	×	×
	RRPA	Sets the automatic refresh parameters.	○	○	○
	RIRD	Reads data in the buffer memory of the specified station.	○	○	○
		Reads device data in the CPU of the specified station.	○*	○*	○*
	RIWT	Wires data into the buffer memory of the specified station.	○	○	○
Wires data into the CPU device of the specified station.		○*	○*	○*	
Intelligent device station	RIRD	Reads contents in the buffer memory of the specified station.	○	○	○
	RIWT	Writes data into the buffer memory of the specified station.	○	○	○
	RISEND	Writes data with handshake into the buffer memory of the specified station.	○	×	×
	RIRCV	Reads contents with handshake in the buffer memory of the specified station.	○	×	×
	RIFR	Reads contents in the automatic refresh buffer of the specified station. (Random access buffer can be specified.)	○	○	○
	RITO	Writes data into the automatic refresh buffer of the specified station. (Random access buffer can be specified.)	○	○	○

* It can be used with software version J (manufactured in Jan., 1998) or later.

POINT

- (1) Execute the dedicated instructions during data link.
If any of them is executed in the offline mode, an error does not occur but the dedicated instruction is not completed. After changing the offline mode to the online mode, reset the CPU.
- (2) When the dedicated instructions (RIRD, RIWT, RISEND, RIRCV) are used, RY(n+1)E and RY(n+1)F are used with the dedicated instructions. Therefore, the user must be careful not to rewrite these signal data.

15.7 Remote I/O Net Mode

When the system is configured only with the master station and the remote I/O stations, communication can be performed without setting parameters.

15.7.1 Features

When the system is configured only with the master station and the remote I/O stations, if the remote I/O net mode is used, the following advantages can be attained.

- (1) The network parameters are not required to be set.
- (2) The data link start request need not be set.
- (3) By a reduction in link scan time, the I/O response becomes higher than in the remote net mode.

15.7.2 Software version corresponding to master module and its CPU

Table 15.7 shows the software versions corresponding to the master modules and their CPUs in the remote I/O net mode.

Table 15.7 Software Version corresponding to Master Module and Its CPU

Master module and CPU type	Corresponding software version
AJ61BT11, AJ61QBT11, A1SJ61BT11, A1SJ61QBT11	P (manufactured on Sep., 1998) or later
A2UCPU (S1), A3UCPU, A4UCPU	K (manufactured on Aug., 1998) or later
A2USCPU (S1)	A (manufactured on Aug., 1998) or later
A2USHCPU-S1	G (manufactured on Aug., 1998) or later
A1SHCPU, A2SHCPU, A1SJHCPU	L (manufactured on Sep., 1998) or later

15.7.3 Set items

When the remote I/O net mode is used, set the following three items.

- (1) Set the master station's mode setting switch at 1 (remote I/O net mode).
- (2) Set the master station's station number setting switch at the last station number of the last remote I/O station.
- (3) Set the automatic refresh parameter using the RRPA instruction.

15.7.4 Link scan time

When the remote I/O net mode is used, the link scan time (LS) is given by the following expression.

$$LS = BT \{25.0 + (NI \times 4.0) + (N \times 28.0) + (ni \times 4.0)\} + ST + \{ \text{Number of communication faulty stations} \times 48 \times BT \times \text{Number of retries} \} * [\mu s]$$

BT : Constant (transmission speed)

Transmission speed	156kbps	625kbps	2.5Mbps	5Mbps	10Mbps
BT	51.2	12.8	3.2	1.6	0.8

NI : Last station number (shall be the multiple of 8)

N : Number of connected modules

ni : Total number of occupied stations

ST : Constant

$$ST = 200 + (ni \times 20)$$

* : Only when there is a communication faulty station.

A difference in link scan time between the operations in the remote I/O net mode and the remote net mode (conventional mode) is shown below.




Figure 15.4 Link scan time

15.7.5 Precaution

Set the remote I/O station number sequentially. Otherwise the unset station will be detected as an error, thus affecting the link scan time.

15.8 Temporary Error Invalid Station Specification Function

Replacement of modules can be performed online without detecting an error of the corresponding remote station.

15.8.1 I/O status of the temporary error invalid station specification

All of the cyclic transmission data of the station specified as a temporary error invalid station will be refreshed.

When the station specified as a temporary error invalid station becomes faulty, input is retained and output is turned off.

15.8.2 Link special relays/registers (SB, SW) relating to the temporary error invalid station specification function

The link special relays and link special registers relating to the temporary error invalid station specification function are explained.

They are stored in the buffer memory.

(1) Link special relays (SB)

The link special relays (SB) relating to the temporary error invalid station specification function are as follows.

The figures in parentheses in the number column indicate buffer memory address and bit location.

Example: When buffer memory address is 5E0H and bit is 0: (5E0H, b0)

Table 15.8 List of link special relays relating to the temporary error invalid station specification function

Number	Name	Description	Availability (○ : available, × : not available)	
			Master station	Local station
SB0004 (5E0H, b4)	Temporary error invalid station request	Confirms the station which had been specified by SW0003 to SW0007 to temporary error invalid station. OFF : No request ON : Request	○	×
SB0005 (5E0H, b5)	Temporary error invalid station cancelling request	Cancels the station which had been specified by SW0003 to SW0007 from temporary error invalid station. OFF : No request ON : Request	○	×
SB0048 (5E4H, b8)	Temporary error invalid station acceptance status	Indicates the acceptance status of the temporary error invalid station request instruction. OFF : Not executed ON : Instruction accepted	○	×
SB0049 (5E4H, b9)	Temporary error invalid station complete status	Indicates the acceptance complete status of the temporary error invalid station request instruction. OFF : Not executed ON : Temporary error invalid station confirmed	○	×
SB004A (5E4H, b10)	Temporary error invalid station cancelling acceptance status	Indicates the acceptance status of the temporary error invalid station cancelling request instruction. OFF : Not executed ON : Instruction accepted	○	×
SB004B (5E4H, b11)	Temporary error invalid station cancelling complete status	Indicates the acceptance complete status of the temporary error invalid station cancelling request instruction. OFF : Not executed ON : Temporary error invalid station cancelling complete	○	×

(2) Link special registers (SW)

The link special registers (SW) relating to the temporary error invalid station specifying function are as follows. The figures in parentheses in the number column indicate buffer memory address.

Table 15.9 List of link special registers relating to temporary error invalid station specifying function


Number	Name	Description	Availability (○ : available, × : not available)																																																			
			Master station	Local station																																																		
SW0003 * (603H)	Multiple temporary error invalid station specification	Selects whether to specify multiple temporary error invalid stations. 00 : Specifies multiple stations as indicated in SW0004 to SW0007. 01 to 64 : Specifies a single station from 1 to 64. ※ Specifies the station number used as the temporary invalid station.	○	×																																																		
SW0004 * (604H) . SW0005 * (605H) . SW0006 * (606H) . SW0007 * (607H)	Temporary error invalid station specification * 1	Specifies the temporary error invalid station. 0: Not specified as a temporary error invalid station. 1: Specified as a temporary error invalid station. <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW0004</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0005</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0006</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0007</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicate station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW0004	16	15	14	13	to	4	3	2	1	SW0005	32	31	30	29	to	20	19	18	17	SW0006	48	47	46	45	to	36	35	34	33	SW0007	64	63	62	61	to	52	51	50	49	○	×
	b15	b14	b13	b12	to	b3	b2	b1	b0																																													
SW0004	16	15	14	13	to	4	3	2	1																																													
SW0005	32	31	30	29	to	20	19	18	17																																													
SW0006	48	47	46	45	to	36	35	34	33																																													
SW0007	64	63	62	61	to	52	51	50	49																																													
SW0049 (649H)	Temporary error invalid station request result	Stores the results of execution of the temporary error invalid station request instruction by SB0004. 0 : Normal Other than 0 : Store error code (See Section 13.3)	○	×																																																		
SW004B (64BH)	Temporary error invalid station cancelling request result	Stores the results of execution of the temporary error invalid station cancelling request instruction by SB0005. 0 : Normal Other than 0 : Store error code (See Section 13.3)	○	×																																																		
SW007C * (67CH) . SW007D * (67DH) . SW007E * (67EH) . SW007F * (67FH)	Temporary error invalid station specifying status * 1	Stores the temporary error invalid station specifying status. 0: Other than temporary error invalid station 1: Temporary error invalid station <table border="1"> <thead> <tr> <th></th> <th>b15</th> <th>b14</th> <th>b13</th> <th>b12</th> <th>to</th> <th>b3</th> <th>b2</th> <th>b1</th> <th>b0</th> </tr> </thead> <tbody> <tr> <td>SW007C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW007D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW007E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW007F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </tbody> </table> 1 to 64 in the table indicate station numbers.		b15	b14	b13	b12	to	b3	b2	b1	b0	SW007C	16	15	14	13	to	4	3	2	1	SW007D	32	31	30	29	to	20	19	18	17	SW007E	48	47	46	45	to	36	35	34	33	SW007F	64	63	62	61	to	52	51	50	49	○	○
	b15	b14	b13	b12	to	b3	b2	b1	b0																																													
SW007C	16	15	14	13	to	4	3	2	1																																													
SW007D	32	31	30	29	to	20	19	18	17																																													
SW007E	48	47	46	45	to	36	35	34	33																																													
SW007F	64	63	62	61	to	52	51	50	49																																													

* 1 Turns on only the bit for the head station number.

POINT
(1) If both a temporary error invalid station request and a temporary error invalid station cancelling request are made, the temporary error invalid station cancelling request will be given a priority.
(2) For a station that occupies multiple stations, only the head station number becomes valid.

15.8.3 Execution procedure for the temporary error invalid station specification function

The execution procedure for the temporary error invalid station specification function is as follows:



16. Communication with the Intelligent Device (Function Version B or Later)


The method of communication between the master station and the intelligent device stations varies depending on the intelligent device station.

Refer to the applicable intelligent device station manual for the communication between the master station and the intelligent device stations.

Appendices

Appendix 1 External Dimensions Diagram


1.1 AJ61BT11



App

unit: mm

1.2 A1SJ61BT11



unit: mm

Appendix 2 Parameter Setting Sheet

Item	Setting range	Buffer memory address	Remark	Default value	Setting value
Number of linked modules	1 to 64	1H	–	64	
Number of retries	1 to 7	2H	–	3	
Number of automatic return modules	1 to 10	3H	–	1	
Standby master station specification	0 to 63 (0: No specification)	4H	–	0	
Operation when CPU down	0: stop 1: continue	6H	–	0 (stop)	
Delay time setting	Set 0.	8H	–	0	
Reserved station specification	Turn on the corresponding bit for station to reserve.	10H	Station No. 16 to 1	0000H	
		11H	Station No. 32 to 17	0000H	
		12H	Station No. 48 to 33	0000H	
		13H	Station No. 64 to 49	0000H	
Invalid station specification	Turn on the corresponding bit for station to invalidate.	14H	Station No. 16 to 1	0000H	
		15H	Station No. 32 to 17	0000H	
		16H	Station No. 48 to 33	0000H	
		17H	Station No. 64 to 49	0000H	
Station information	b15 to b12 (station type) 0: remote I/O station 1: remote device station 2: intelligent device station, local station b11 to b8 (number of occupied stations) 1: occupies one station 2: occupies two stations 3: occupies three stations 4: occupies four stations b7 to b0 (station number) 01H to 40H (1 to 64)	20H	1st module	0101H	
		21H	2nd module	0102H	
		22H	3rd module	0103H	
		23H	4th module	0104H	
		24H	5th module	0105H	
		25H	6th module	0106H	
		26H	7th module	0107H	
		27H	8th module	0108H	
		28H	9th module	0109H	
		29H	10th module	010AH	
		2AH	11th module	010BH	
		2BH	12th module	010CH	
		2CH	13th module	010DH	
		2DH	14th module	010EH	
		2EH	15th module	010FH	
		2FH	16th module	0110H	
		30H	17th module	0111H	
		31H	18th module	0112H	
		32H	19th module	0113H	
		33H	20th module	0114H	
		34H	21st module	0115H	
		35H	22nd module	0116H	
		36H	23rd module	0117H	
		37H	24th module	0118H	
		38H	25th module	0119H	
		39H	26th module	011AH	
		3AH	27th module	011BH	
		3BH	28th module	011CH	

Item	Setting range	Buffer memory address	Remark	Default value	Setting value
Station information		3CH	29th module	011DH	
		3DH	30th module	011EH	
		3EH	31st module	011FH	
		3FH	32nd module	0120H	
		40H	33rd module	0121H	
		41H	34th module	0122H	
		42H	35th module	0123H	
		43H	36th module	0124H	
		44H	37th module	0125H	
		45H	38th module	0126H	
		46H	39th module	0127H	
		47H	40th module	0128H	
		48H	41st module	0129H	
		49H	42nd module	012AH	
		4AH	43rd module	012BH	
		4BH	44th module	012CH	
		4CH	45th module	012DH	
		4DH	46th module	012EH	
		4EH	47th module	012FH	
		4FH	48th module	0130H	
		50H	49th module	0131H	
		51H	50th module	0132H	
		52H	51st module	0133H	
		53H	52nd module	0134H	
		54H	53rd module	0135H	
		55H	54th module	0136H	
		56H	55th module	0137H	
		57H	56th module	0138H	
		58H	57th module	0139H	
		59H	58th module	013AH	
		5AH	59th module	013BH	
		5BH	60th module	013CH	
5CH	61st module	013DH			
5DH	62nd module	013EH			
5EH	63rd module	013FH			
5FH	64th module	0140H			

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

Ethernet is a registered trademark of Fuji Xerox Corporation in Japan.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as TM or [®] are not specified in this manual.

CC-Link System Master/Local Module

Type AJ61BT11/A1SJ61BT11 User's Manual

MODEL	A(1S)J61BT11-U-E
MODEL CODE	13J872
IB(NA)-66721-O(1603)MEE	



HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.