

MITSUBISHI

PROGRAMMABLE CONTROLLER


MELSEC-A

User's Manual

GI-62.5/125 Cable Correspondence Network Module type A1SJ71QLP21GE (Hardware)

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-A Series of General Purpose Programmable Controllers. Please read this manual carefully so that the equipment is used to its optimum. A copy of this manual should be forwarded to the end user.

Model	A1SJ71QLP21GE-U-E	 IB (NA)66880 -A
Part Number	13JL71	

The United States	Mitsubishi Electronics America, Inc., (Industrial Automation Division) 500 Corporate Woods Parkway Vernon Hills, IL 60061 U.S.A. Phone: (847) 478-2100
Canada	Mitsubishi Electric Sales Canada, Inc., (Industrial Automation Division) 4290 14th Avenue, Markham, Ontario L3R 0J2 Phone: (416)475-7728
United Kingdom	Mitsubishi Electric UK Ltd., (Industrial Sales Division) Travellers Lane, Hatfield, Hertfordshire., AL10 8XB Phone: (1707)276100
Germany	Mitsubishi Electric Europe GmbH, (Industrial Automation Division) Gothaer Strasse 8, 40880 Ratingen, Germany Phone: (02102)4860
Taiwan	Setsuyo Enterprise Co., Ltd., 2/F No. 124, Wu Kung 2nd Rd., Wu-Ku Hsiang, Taipei Phone: (02) 299-2499
Hongkong (& China)	Ryoden International Ltd., (Industrial & Electrical Controls Division) 10/F., Manulife Tower, 169 Electric Rd., North Point, Hong Kong. Phone: 2887-8870
Singapore (& Malaysia)	MELCO Sales Singapore Pte. Ltd., (Industrial Division) 307 Alexandra Rd., #04-01/02, Mitsubishi Electric Bldg., Singapore 159943. Phone: 473-2308
Thailand	F.A. Tech Co., Ltd., 1138/33-34 Rama 3 Rd., Yannawa, Bangkok 10120. Phone: (02)295-2861
Australia	Mitsubishi Electric Australia Pty. Ltd., (Industrial Controls Division) 348 Victoria Rd., Rydalmere, N.S.W. 2116. Phone: (02)9684-7777
Republic of South Africa	M.S.A. Manufacturing (Pty) Ltd., (Factory Automation Division) P.O. Box 39733, Bramley, Johannesburg 2018. Phone: (011)444-8080

 MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: MITSUBISHI DENKO BLDG. MARUNOUCHI 4 TOKYO 100 TEL: 03-5638-3111 FAX: 03-5638-3112
INDIA: WORDS: 1-14, TOWER: 14, HUDA: 14, NAGDA, JALGAON

When imported from Japan, this manual does not require application to the Ministry of International Trade and Industry for service transaction permission.

IB (NA)66880 -A (8810)MEE

Specifications subject to change without notice.
Printed in Japan on recycled paper.

Cautions on Safety


(Read these precautions before using)

When using a MELSEC-QnA series PC, you are requested to read the manuals supplied with each product and the related manuals cited in these manuals, and also pay due attention to safety and handle the product correctly.
The cautions in this cautions on safety are classified into two ranks, "DANGER" and "CAUTION", according to their importance.



DANGER

A warning given when improper operation could result in a dangerous situation causing death or serious injuries.



CAUTION

A caution given when improper operation could result in a dangerous situation causing moderate or injuries, and physical damage to the module, etc.

Even failure to observe a caution marked ! CAUTION may bring about a serious accident depending on the situation. Do not fail to follow the cautions. Retain this manual for consultation whenever necessary, and provide a copy to the end user.

Cautions on Design



DANGER

- When there is a communication fault in the data link system, the following happens at the faulty station. Using the communications status information, create an interlock circuit in the sequence program to ensure that the system will operate safely despite such faults.

- The data link data that existed before the fault is retained.
- All outputs of MELSECNET /10 remote I/O stations go OFF.

For details on the method for confirming the faulty station and the operating status when a communication fault occurs, see the manual for the relevant data link.

- For a Q2ASCPU and AnUCPU compound system, absolutely do not execute the transient transmissions indicated below, which cannot be executed from the Q2ASCPU to another AnUCPU station. The AnUCPU in which the transmission was executed results in MAIN CPU DOWN or WDT ERROR, and the operation may stop.


- GPPQ
 - Remote operation (such as remote RUN, STOP, PAUSE, and RESET)
 - Clock setting
 - Online mode device testing
- Link dedicated instruction (SEND, READ, SPEAD, WRITE, SWRITE, and REQ)



CAUTION

- Do not bundle the control wire and the communication cable with the main circuit or power line or keep them close to one another. Keep the control wire and the communication cable at least 100 mm away from the main circuit or power line; otherwise, noise or malfunctions will occur.

Cautions on Installation



CAUTION

- Use the PC in the environment specified in the General Specifications section in this manual. Using it in an environment which does not meet the general specifications could cause electric shock, fire or malfunctions, and damage or deterioration of the module.

- Connect extension cables with the base unit and module connectors securely. After making the connections, check them for looseness. Loose contacts can cause erroneous inputs and outputs.

- Do not directly touch the electrically conductive areas and electronic parts. Direct touch can cause malfunctions and failure of the module.

- Install the module by securely inserting the module clamp hook under the module to the hole in the base unit, then tighten the module clamp screws at the specified torque. If the module is not correctly installed and clamped securely with the screws, it could cause malfunctions, failure, and fall of the module.

Cautions on Wiring



DANGER

- Always switch off all power supply phases externally before attempting installation or wiring work. If all power supply phases are not switched off, there will be a danger of electric shock or damage to the product.
- After completing installation or wiring work, be sure to fit the terminal cover provided as an accessory before supplying power or attempting operation. If the terminal cover is not fitted there will be a danger of electric shock.



CAUTION

- Ground the FG and LG terminal using grounding exclusively for the PC. If you do not, the PC will malfunction.
- Before connecting wires to the PC, check the rated voltage and the terminal arrangement. Connecting power of a different voltage or wiring incorrectly will result in fire or failure.
- Do not connect the outputs of multiple power supply modules in parallel. The power supply modules could overheat, catch fire, or fail.
- Tighten the terminal screws to the specified torque. Loose terminal screws will cause a short, fire or malfunctions.
- Take all possible measures to prevent chips or wire scraps from entering the module. Entry of foreign material will cause fire, failure of malfunctions.
- Crimp, pressure weld, or correctly solder connectors for external connections, using the correct tools. For details on crimping and pressure welding tools, refer to the User's Manual for the I/O module. An imperfect connection could cause short circuiting, fire, or malfunction.

Cautions on Start-Up and Maintenance



DANGER

- Do not touch the terminals while they are live. This will cause malfunctions.
- Switch the power off before cleaning the module or retightening the terminal screws. If the power is left on, the module will break down or malfunction.



CAUTION

- Before conducting operations such as changing the program while the module is operating, force output, run, stop, pause, etc., be sure to thoroughly read the manual and take due consideration for safety. Operation mistakes could cause damage to the equipment and other problems.
- Do not disassemble or tamper with the module. This will cause failure, malfunctions, injuries or fire.
- Turn the power off for entire system when removing a module. Trying to remove the module while the power is on could damage the module or result in erroneous operation.
- Always secure the cables connected to the module, e.g. run them in conduits or clamp them. Not doing so can cause module or cable damage due to dangling, moved or accidentally pulled cables or can cause a malfunction due to a cable contact fault.
- Do not hold the cable part when unplugging any cable connected to the module. Doing so can cause module or cable damage or a malfunction due to a cable contact fault.

Cautions on Disposal



CAUTION

Dispose of the module as industrial waste.

1. GENERAL DESCRIPTION

1. GENERAL DESCRIPTION

This manual describes the specifications and nomenclature of the A1SJ71QLP21GE type GI-62.5/125 cable correspondence network module used for a MELSEC-QnA series MELSECNET/10 network system. See the Reference Manual for the performance and functions of the module, except for the station-to-station distance requirement of 1.5 km.

1.1 Related Manual

- For QnA/Q4AR MELSECNET/10 Network system Reference Manual (IB-66690)

Correspondence to EMC DIRECTIVE

To make the PCs compliant with the EMC directive, refer to Chapter 2 "EMC AND LOW-VOLTAGE DIRECTIVE" in the PC user's manual (Hardware).

- When the PC CPU user's manual (Hardware) does not include Chapter 2 "EMC AND LOW-VOLTAGE DIRECTIVE", refer to QnA Series CPU Compatible High-Speed Accessing Basic Base Unit-Additional Explanation for Product Conforming to EMC Standards (IB-68837)(optional)

2. PERFORMANCE SPECIFICATIONS

2. PERFORMANCE SPECIFICATIONS

The following table shows the performance specifications of the A1SJ71QLP21GE.

Item	A1SJ71QLP21GE	
	LX/LY	8192 points
Maximum number of link points per network	LB	8192 points
	LW	8192 points
	In PC-to-PC network	$\left(\frac{LB+LY}{8} + (2 \times LW)\right) \leq 2000$ bytes
Maximum number of link points per station	In remote I/O network	• Master station → Remote I/O station $\left(\frac{LB+LY}{8} + (2 \times LW)\right) \leq 1600$ bytes
		• Remote I/O station → Master station $\left(\frac{LB+LY}{8} + (2 \times LW)\right) \leq 1600$ bytes
Communication speed	10 Mbps (20 Mbps: multiple transmission)	
Communication method	Token-ring method	
Synchronization system	Frame synchronization	
Transmission channel type	Duplex loop	
Overall extension distance	30 km	
Maximum number of networks	255 (total number of PC-to-PC and remote I/O networks)	
Maximum number of groups	9 (PC-to-PC networks only)	
Number of stations connectable per network	In PC-to-PC network	64 stations (control station: 1; normal station: 63)
	In remote I/O network	65 stations (master station: 1; remote I/O station: 64)
Maximum number of modules installed per CPU	Q2ASCPU(S1), Q2ASHCPU(S1): 4	
Coding system	NRZI coding (Non Return to Zero Inverted)	
Transmission format	Conforms to HDLC (frame format)	
Error control system	Retry by CRC ($X^{16} + X^5 + 1$) and overtime	
RAS function	• Loopback function in response to error detection and cable disconnection • Diagnosis function for self-station link line check • System down prevention by control station shift (PC-to-PC network only) • Error detection using special relays and registers • Network monitor and other diagnosis functions	
Transient transmission	• N: N communication (monitor, program upload/download, etc.) • ZNRD/ZNWR instructions (N:N): Q2ASCPU dedicated instructions	
Connection cable	GI-62.5/125	
Applicable connector	CA9003S (for 2-core cable) CA9103S (for single-core cable)	
Cable transmission loss	3 dB/km or less	
Current consumption (5 VDC)	0.47 A	
Weight kg (lb)	0.27 (0.59)	
Number of occupied I/O points	32 points	

For general specifications, refer to the user's manual for the PC CPU used for the network system.

3. GI TYPE FIBER-OPTIC CABLE SPECIFICATIONS


3. GI TYPE FIBER-OPTIC CABLE SPECIFICATIONS

3.1 plicable Cable Specifications

- The specifications for the 62.5GI cable are given below.
- If you prepare a 62.5GI cable yourself, it must comply with the specifications indicated below.

Item	Specification
Fiber type	GI (graded index) type multimode quartz glass
Core diameter	62.5 μm
Clad diameter	125 μm
Transmission loss	3 dB/km or less
Wave length	0.85 μm
Transmission band	300 MHz·km or more

3.2 Cable Loss



*1 Conversion cable


Conversion Type	Cable
CA type ↔ FC type	AGE-1P-CA/FC1.5M-A
CA type ↔ ST type	AGE-1P-CA/ST1.5M-A
CA type ↔ SMA type	AGE-1P-CA/SMA1.5M-A

Purchased from :Mitsubishi Electric Europe GmbH

4. NOMENCLATURE AND SETTINGS

4. NOMENCLATURE AND SETTINGS

This section gives the names of each part of the A1SJ71QLP21GE and explains their settings.



No.	Name	Description	
(1)	LED	RUN	When the module is normal: On When a WDT error occurs: Off
		MNG	When a control or master station is set: On When normal stations are set: Off
		S.MNG	After shift to a sub-control station: On
		DUAL	During duplex transmission: On
		D.LINK	During data link: On
		T.PAS.	When taking part in baton passing (during transient transmission): On
		F.E.	When an error occurs while forward (F.E.)/reverse (R.E.) loop is faulty: On <Cause> Power off of adjacent station, disconnected or unconnected cable, etc.
		R.E.	
		PW	When power is supplied: On
		PC	When PC-to-PC network is set: On (SW1 off)
		REM.	When remote I/O network is set: On (SW1 on)
		SW.E.	When settings of switches (2) to (5) are incorrect: On
		M/S.E.	When two or more stations have the same number or two or more control stations exist in the same network: On
		PRM.E.	On occurrence of a common parameter/station specific parameter matching error, and when parameters received from a sub-control station do not match self-station parameters: On
		CPU R/W	During CPU communication: On
		CRC	When there is a code check error in the received data: On <Cause> Timing when the station that is sending data to a specific station is set off-line, hardware fault, cable fault, noise, etc.
		OVER	When an error occurs due to delay in processing of received data: On <Cause> Hardware fault, cable fault, noise, etc.
		AB.IF	When the number of "1"s received in succession exceeds the specified number, or when an error occurs due to short data length of received data: On <Cause> Timing when the station that is sending data to a specific station is set off-line, WDT setting too short, cable fault, noise, etc.
		TIME	When an error occurs when the data link monitoring timer operates: On <Cause> Short WDT time, cable fault, noise, etc.
		DATA	When an error occurs due to receipt of more than 2 Kbytes of data: On <Cause> Cable fault, noise, etc.
UNDER	When an error occurs due to internal processing of sent data at irregular intervals: On <Cause> Hardware fault		
SD	During data transmission: On		
RD	During data reception: On		
(2)	Network number setting switch	Network number setting (setting on delivery: 1) <Setting range> 1 to 255 Any number out of the range will result in an error (the SW.E LED comes on).	
(3)	Group number setting switch	Group number setting (setting on delivery: 0) <Setting range> 1 to 9: Group No. The number "0" means that no group is specified. (This setting is not required for a remote I/O network.)	
(4)	Station number setting switch	Station number setting (setting on delivery: 1) <Setting range> For PC-to-PC network 1 to 64 Any number outside the range will result in an error (the SW.E LED will come on). For remote I/O network 0 (master station) Any number other than 0 will result in an error (the SW.E LED will come on).	


No.	Name	Description		
(5)	Mode setting switch	Mode setting (setting on delivery: 0)		
		Mode	Name	Description
		0	Online (automatic online return effective)	Data link with automatic online return effective
		1	Unusable	
		2	Offline	Disconnects the host station.
		3	Forward loop test	Checks the forward loop line of the entire data link system.
		4	Reverse loop test	Checks the reverse loop line of the entire data link system.
		5	Station-to-station test (master station)	The mode for a line check between two stations, in which the station with the smaller number is regarded as the master station and the other is considered the slave station.
		6	Station-to-station test (slave station)	
		7	Self-loopback test	Checks the hardware of a module in isolation, including the communication circuit and cables of the transmission system.
8	Internal self-loopback test	Checks the hardware of a module in isolation, including the communication circuit of the transmission system.		
9	Hardware test	Checks the hardware inside the network module.		
A to F		Unusable		
(6)	LED display selector switch	Switches the LED display.		
(7)	Condition setting switch	Operation condition setting (setting at delivery: all OFF)		
(8)	Connector	An optical fiber cable is connected. Viewing the module from the front, the connectors are arranged in the following order from the front to the rear. IN R-SD (reverse loop send), IN F-RD (forward loop receive), OUT F-SD (forward loop send), OUT R-RD (reverse loop receive) Connect IN R-SD to OUT R-RD of preceding station Connect IN F-RD to OUT F-SD of preceding station Connect OUT F-SD to IN F-RD of preceding station Connect OUT R-RD to IN R-SD of preceding station		

*1: Reset the QnACPU after changing the settings of (2), (3), (4), (5) and (7) with the QnACPU power on.

*2: The switches need not be set when a remote I/O network is configured (SW1 on).

5. OUTSIDE DIMENSIONS

5. A1SJ71QLP21GE



* Take account of the bending radius of the cable. (Refer to the Reference Manual.)

Under no circumstances will Mitsubishi Electric be liable or responsible for any consequential damage that may arise as a result of the installation or use of this equipment.

All examples and diagrams shown in this manual are intended only as an aid to understanding the text, not to guarantee operation. Mitsubishi Electric will accept no responsibility for actual use of the product based on these illustrative examples.

Owing to the very great variety in possible applications of this equipment, you must satisfy yourself as to its suitability for your specific application.