

MELSEC Q Series

Programmable Logic Controller

User's Manual
(Hardware)

**QJ71LP21-25, QJ71LP21S-25,
QJ71LP21G, QJ71BR11
MELSECNET/H Network Module**

● SAFETY PRECAUTIONS ●

(Always read these instructions before using this equipment.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly.

Precautionary notes in this manual cover only the installation of this product.

For precautions on designing and discarding this product, refer to "Safety Precautions" in the MELSECNET/H Reference Manual.

For safety precautions on the PLC system, refer to the CPU User's Manual.

In this manual, the safety instructions are ranked as "DANGER" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Note that the  **CAUTION** level may lead to a serious consequence according to the circumstances.

Always follow the instructions of both levels because they are important to personal safety.

Please store this manual in a safe place and make it accessible when required.

Always forward it to the end user.

[INSTALLATION PRECAUTIONS]

CAUTION

- Use the PLC in the operating environment that meets the general specifications given in the user's manual of the CPU module. Using the PLC in any other operating environment may cause an electric shock, fire or malfunction, or may damage or degrade the product.
- While pressing the installation lever located at the bottom of module, insert the module fixing tab into the fixing hole in the base unit until it stops. Then, securely mount the module with the fixing hole as a supporting point. If the module is not installed properly, it may cause the module to malfunction, fail or fall off.
Secure the module with screws especially when it is used in an environment where constant vibrations or strong impact may be expected. Be sure to tighten the screws using the specified torque. If the screws are loose, it may cause the module to malfunction or fall off. If the screws are tightened excessively, it may damage the screws and/or the module, and cause the module to malfunction or fall off.
- Before mounting or dismounting the module, make sure to shut off all phases of the external power supply. Failure to do so may damage the product.
- Do not directly touch the conducting parts and electronic parts of the module. This may cause the module to malfunction or fail.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body. Failure to do so may cause malfunction or failure of the module.

[WIRING PRECAUTIONS]

DANGER

- Before starting any installation or wiring work, make sure to shut off all phases of the external power supply.
Failure to do so may cause electric shocks or damage the product.

CAUTION

- Always connect the FG terminals to the ground using class D (class 3) or higher grounding exclusively designed for PLC.
Failure to do so may cause malfunctions.
- When connecting cables to the terminal block for external power supply, check the rated voltage and terminal layout of the product for correct wiring.
Connecting a cable to power supply of different voltage or incorrect wiring may cause a fire or fault.
- Tighten the terminal screws with the specified torque.
Loose tightening may lead to a short circuit, fire or malfunction.
- Solder coaxial cable connectors properly. Incomplete soldering may result in malfunction.
- Be careful not to let foreign objects such as dust and wire chips get inside the module. They may cause a fire, mechanical breakdown or malfunction.
- The top surface of the module is covered with a protective film to prevent foreign objects such as wire chips from entering the module during wiring work. Do not remove this film until all the wiring work is complete. Before operating the system, be sure to remove the film to release the heat.
- Make sure to place the communication and power cables into a duct or fasten them using a clamp. Failure to do so may damage the module or cables by pulling a dangling cable inadvertently or cause the module to malfunction due to bad connection.
- When disconnecting the communication and power cables from the module, do not pull a cable part by hand.
When disconnecting a cable with a connector, hold the connector connected to the module by hand and pull it out to remove the cable. When disconnecting a cable connected to a terminal block, loosen the screws on the terminal block first before removing the cable. If a cable is pulled while being connected to the module, it may cause the module to malfunction or damage the module and cables.

Revisions

*The manual number is given on the bottom left of the back cover.

| Print Date | *Manual Number | Revision |
|------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sep., 2000 | IB(NA)-0800144-A | First edition |
| Mar., 2001 | IB(NA)-0800144-B | Model addition QJ71LP21G |
| Nov., 2001 | IB(NA)-0800144-C | Partial correction Contact address (Back cover) |
| Aug., 2002 | IB(NA)-0800144-D | Model addition QJ71LP21S-25 |
| Mar., 2004 | IB(NA)-0800144-E | Partial correction SAFETY PRECAUTIONS, Section 3.1, Compliance with the EMC Directive and the Low Voltage Directive, Chapter 4 (a), (b), (c), Section 5.3, Chapter 6 |
| May, 2004 | IB(NA)-0800144-F | Partial correction SAFETY PRECAUTIONS, Chapter 2, Section 5.2 |
| | | |

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2000 MITSUBISHI ELECTRIC CORPORATION

CONTENTS

| | |
|----------------------------------------------------------|----|
| 1. Overview..... | 1 |
| 2. Performance Specifications | 2 |
| 3. Handling | 6 |
| 3.1 Handling Precautions | 6 |
| 4. Part Identification Names..... | 7 |
| 5. Wiring | 10 |
| 5.1 Precautions for Laying Optical Fiber Cables..... | 11 |
| 5.2 Precautions when Installing the Coaxial Cables | 12 |
| 5.3 Connecting the Connector for the Coaxial Cable..... | 13 |
| 6. External Dimensions..... | 15 |

About the Manuals

The following manuals are also related to this product.
If necessary, order them by quoting the details in the tables below.

Related Manuals

| Manual name | Manual No. (Model code) |
|----------------------------------------------------------------------------------|----------------------------|
| Q corresponding MELSECNET/H Network System Reference Manual (PLC to PLC network) | SH-080049 (13JF92) |
| Q corresponding MELSECNET/H Network System Reference Manual (Remote I/O network) | SH-080124 (13JF96) |
| Q/QnA/Q4AR corresponding MELSECNET/10 Network System Reference Manual | IB-66690 (13JF78) |

Compliance with the EMC Directive and the Low Voltage Directive

When incorporating Mitsubishi PLC into other machine or equipment and making it comply with the EMC directive and the low voltage directive, refer to Chapter 3, "EMC Directive and Low Voltage Directive" of the User's Manual (Hardware) for the CPU module.

The CE logo is printed on the rating plate of the PLC, indicating compliance with the EMC directive and the low voltage directive.

For making this product comply with the EMC directive and the low voltage directive, please refer to Section 3.1.3. "Cable" in Chapter 3 "EMC Directive and Low Voltage Directive" of the User's Manual (Hardware) for the CPU module.

1. Overview

This manual explains how to handle the MELSECNET/H network module, model numbers QJ71LP21-25, QJ71LP21S-25, QJ71LP21G and QJ71BR11 (hereinafter referred to as the network module).

The network module is used as a control/normal station in the PLC to PLC network and as a remote master station in the remote I/O network in the MELSECNET/H system.

After unpacking the network module, confirm that any of the following products is enclosed.

| Model | Description | Quantity |
|--------------|-----------------------------------------------------------------------------------------------|----------|
| QJ71LP21-25 | Model QJ71LP21-25 MELSECNET/H network module (optical loop type) | 1 |
| QJ71LP21S-25 | QJ71LP21S-2S MELSECNET/H network module (optical loop type, with external power supply input) | 1 |
| QJ71LP21G | Model QJ71LP21G MELSECNET/H network module (optical loop type) | 1 |
| QJ71BR11 | Model QJ71BR11 MELSECNET/H network module (coaxial bus type) | 1 |
| | F-type connector | 1 |

Important

The coaxial bus-type network system requires terminal resistors at both terminal stations of the network. The user should arrange for terminal resistors, since the QJ71BR11 does not come with terminal resistors.

* Terminal resistor (75Ω)

- A6RCON-R75
- BNC-TMP-05 (75) (Manufactured by Hirose Electric Co., Ltd.)

2. Performance Specifications

The following table shows the performance specifications for the network module:

| Item | Specifications | | |
|-------------------------------------------|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| | QJ71LP21-25 | QJ71LP21S-25 | QJ71LP21G |
| Maximum number of link points per network | (1) PLC to PLC network | | |
| | | MELSECNET/H mode *1 | MELSECNET/10 mode *1 |
| | LX/LY | 8192 points | 8192 points |
| | LB | 16384 points | 8192 points |
| | LW | 16384 points | 8192 points |
| | (2) Remote I/O network | | |
| | LX/LY | 8192 points | |
| | LB | 16384 points (Remote master station to Remote submaster station, Remote I/O station: 8192 points), (Remote submaster station, Remote I/O station to Remote master station: 8192 points) | |
| | LW | 16384 points (Remote master station to Remote submaster station, Remote I/O station: 8192 points), (Remote submaster station, Remote I/O station to Remote master station: 8192 points) | |
| | Maximum number of link points per station | PLC to PLC network | $\{(LB + LY) / 2 + LW \times 2\} \leq 2000$ bytes |
| Remote I/O network | | Remote master station to Remote I/O station Remote I/O station to Remote Master station $\{(LB + LY) / 2 + LW \times 2\} \leq 1600$ bytes | |
| Communication speed | 10Mbps/25Mbps *2 (Switch changing) | | 10Mbps |
| Communication method | Token ring | | |
| Synchronous method | Frame synchronous method | | |
| Transmission path format | Duplex loop | | |
| Maximum number of networks | 239 | | |
| Maximum number of groups | 32 | | |
| Number of connected stations | PLC to PLC network | 64 stations (control station: 1, normal station: 63) | |
| | Remote I/O network | 65 stations (Remote master station: 1, Remote I/O station: 64) | |
| Overall distance | 30 km (98430 ft.) | | |

*1: Mode selection is performed using network parameters.

*2: 25Mbps is only for MELSECNET/H mode.

| Item | | Specifications | | |
|--------------------------------|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------|
| | | QJ71LP21-25 | QJ71LP21S-25 | QJ71LP21G |
| Distance between stations *3 | 10Mbps | SI optical cable: 500 m (1640.5 ft.) SI type H-PCF optical cable :1 km (3281 ft.) GI type H-PCF optical cable :1 km (3281 ft.) QSI optical cable:1 km (3281 ft.) | | GI optical cable: 2 km (36562 ft.) |
| | 25Mbps | SI optical cable:200 m (656.2 ft.) SI type H-PCF optical cable :400m (1312.4 ft.) GI type H-PCF optical cable :1 km (3281 ft.) QSI optical cable:1 km (3281 ft.) | | - |
| Connection cable | | Optical fiber cable (Arranged by user *4) | | |
| Applicable connector | | 2-core optical connector plug (Arranged by user *4) | | |
| No. of occupied I/O points | | 32 points (I/O assignment: 32 points as intelligent) | 48 points (I/O assignment: first 16 points as empty, last 32 points as intelligent) *5 | 32 points (I/O assignment: 32 points as intelligent) |
| External supply power | Voltage (V) | - | 20.4 to 31.2 V DC | - |
| | Current (A) | - | 0.20 | - |
| | Terminal screw size | - | M3 screw | - |
| | Applicable solderless terminal | - | R1. 25-3 (with no sleeve) | - |
| | Applicable wire size | - | 0.3 to 1.25 mm ² | - |
| | Tightening torque | - | 42 to 58N•cm | - |
| 5 VDC current consumption (A) | | 0.55 | | |
| External dimensions (mm (in.)) | | 98 (3.86) (H) × 27.4 (1.08) (W) × 90 (3.54) (D) | | |
| Weight (kg) | | 0.11 | | |

*3: There are restrictions to the distance between stations, being determined according to the type of cable and number of stations. See sections 5.1 .

*4: Specialised skill and specific tools are required to connect the connector to the optical-fiber cable; the connector itself is a custom product. Please contact your nearest Mitsubishi Electric System Service Corporation when purchasing these items.

*5: Two slots are occupied.

Set the numeric value resulted from adding 10H to the I/O No. of the slot where a module mounted as the "Starting I/O No." of the "Network parameter". The first empty 16 points can be set to "0" on the "I/O assignment" tab screen within the "Qn(H) Parameter" screen. Example: Set 10H as the "Starting I/O No." when the module is mounted on slot 0. (Set 0H as the "Starting I/O No." when 0 has been set to slot 0 on the "I/O assignment" tab screen.)

| Item | | Specifications | | |
|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|----------------------|
| | | QJ71BR11 | | |
| Maximum number of link points per network | | (1) PLC to PLC network | | |
| | | | MELSECNET/H mode *1 | MELSECNET/10 mode *1 |
| | | LX/LY | 8192 points | 8192 points |
| | | LB | 16384 points | 8192 points |
| | | LW | 16384 points | 8192 points |
| | | (2) Remote I/O network | | |
| | | LX/LY | 8192 points | |
| LB | 16384 points (Remote master station to Remote submaster station, Remote I/O station: 8192 points), (Remote submaster station, Remote I/O station to Remote master station: 8192 points) | | | |
| LW | 16384 points (Remote master station to Remote submaster station, Remote I/O station: 8192 points), (Remote submaster station, Remote I/O station to Remote master station: 8192 points) | | | |
| Maximum number of link points per network | PLC to PLC network | LX/LY | NET/10H mode: 8192 points, NET/10 mode: 8192 *1 | |
| | | LB | NET/10H mode: 16384 points, NET/10 mode: 8192 *1 | |
| | | LW | NET/10H mode: 16384 points, NET/10 mode: 8192 *1 | |
| | Remote I/O network | LX/LY | 8192 points | |
| | | LB | 16384 points | |
| | | LW | 16384 points | |
| Maximum number of link points per station | PLC to PLC network | $\{(LB + LY) / 2 + LW \times 2\} \leq 2000$ bytes | | |
| | Remote I/O network | Remote master station to Remote I/O station Remote I/O station to Remote Master station $\{(LB + LY) / 2 + LW \times 2\} \leq 2000$ bytes | | |
| Communication speed | | 10 Mbps | | |
| Communication method | | Token bus | | |
| Synchronous method | | Frame synchronous method | | |
| Transmission path format | | Single bus | | |
| Maximum number of networks | | 239 | | |
| Maximum number of groups | | 32 | | |
| Number of connected stations | | 32 stations (control station: 1, normal station: 31) | | |
| Overall distance | | 500 m (1640.5 ft.) (5C-2V) 300 m (984.3 ft.) (3C-2V) Can be extended to a maximum of 2.5 km (8202.5 ft.) using maximum 4 repeater modules *3 (A6BR10, A6BR10-DC). | | |
| Distance between stations *2 | | 500 m (1640.5 ft.) (5C-2V) 300 m (984.3 ft.) (3C-2V) | | |
| Connection cable | | Coaxial cable Equivalent to 3C-2V, 5C-2V *3 (Arranged by user) | | |

*1: Mode selection is performed using network parameters.

*2: There are restrictions to the distance between stations, being determined according to the type of cable and number of stations. See sections 5.2.

*3: When creating the multiplexed remote I/O network for the redundant system, use double-shielded coaxial cables. See sections 5.2.

| Item | Specifications |
|--------------------------------|-------------------------------------------------------------------------------|
| | QJ71BR11 |
| Applicable connector | BNC-P-3-Ni-CAU (For 3C-2V), BNC-P-5-Ni-CAU (For 5C-2V) Equivalent to (DDK) |
| Number of I/O occupied points | 32 points (I/O assignment: intelligent 32 points) |
| 5VDC current consumption (A) | 0.75 |
| External dimensions (mm (in.)) | 98 (3.86) (H) × 27.4 (1.08) (W) × 90 (3.54) (D) |
| Weight (kg) | 0.11 |

For general specifications of the network module, refer to the user's manual for the CPU that is to be used.

3. Handling

CAUTION


- Use the PLC in the operating environment that meets the general specifications given in the user's manual of the CPU module. Using the PLC in any other operating environment may cause an electric shock, fire or malfunction, or may damage or degrade the product.
- To install the module, securely insert the module fastening latch in the installation hole in the base unit while holding down the module installation lever on the lower part of the module. If the module is not installed properly, it may cause the module to malfunction, fail or fall off.
Secure the module with screws especially when it is used in an environment where constant vibrations or strong impact may be expected. Be sure to tighten the screws using the specified torque. If the screws are loose, it may cause the module to malfunction or fall off. If the screws are tightened excessively, it may damage the screws and/or the module, and cause the module to malfunction or fall off.
- Before mounting or dismounting the module, make sure to shut off all phases of the external power supply. Failure to do so may damage the product.
- Do not directly touch the conducting parts and electronic parts of the module. This may cause the module to malfunction or fail.

3.1 Handling Precautions


- (1) Since the module case is made of resin, do not drop it or subject it to strong impact.
- (2) The module can easily be secured to the base unit using the hooks located at the top of the module. However, if the module is to be placed in an area that is subject to strong vibration or impact, we recommend it to be secured with module fixing screws. In that case, tighten the module fixing screws within the following range.
Module fixing screws (M3): Tightening torque range is 36 to 48 N·cm .
- (3) The following range must be applied when tightening the external supply power terminal screws for the QJ71LP21S-25. For specifications of the external supply power terminal screws, refer to chapter 2.
External supply power terminal screws (M3): Tightening torque range is 42 to 58 N·cm.

4. Part Identification Names


(a) QJ71LP21-25, QJ71LP21G



(b) QJ71LP21S-25



(c) QJ71BR11



| Number | Name | Number | Name |
|--------|---------------------------------|--------|--------------------------------------|
| 1) | Display LED | 4) | Connector |
| 2) | Station number setting switches | 5) | External power supply terminal block |
| 3) | Mode setting switch | - | - |

(1) Display contents for LEDs

<QJ71LP21S-25>

| | |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| QJ71LP21S-25 | |
| <input type="checkbox"/> EXT.PW | <input type="checkbox"/> RUN <input type="checkbox"/> MNG <input type="checkbox"/> T.PASS <input type="checkbox"/> D.LINK <input type="checkbox"/> SD <input type="checkbox"/> RD <input type="checkbox"/> ERR. <input type="checkbox"/> L.ERR. |

<QJ71LP21-25, QJ71BR11>

| | |
|---------------------------------|---------------------------------|
| QJ71LP21-25 | |
| <input type="checkbox"/> RUN | <input type="checkbox"/> MNG |
| <input type="checkbox"/> T.PASS | <input type="checkbox"/> D.LINK |
| <input type="checkbox"/> SD | <input type="checkbox"/> RD |
| <input type="checkbox"/> ERR. | <input type="checkbox"/> L.ERR. |

| LED name | Display contents |
|----------|----------------------------------------------------------------------------------------------------------------------|
| RUN | On : Operating normally Off : WDT error occurred |
| T. PASS | On : Executing baton pass Flicker: Executing test Off : Baton pass not yet executed (host is disconnecting) |
| SD | On : Data being transmitted Off : Data not yet transmitting |
| ERR. | On : Setting error occurred Flicker: Error detected by a test Off : No setting error |
| MNG | On : Operating as a control station or sub control station Off : Operating as a normal station |
| D. LINK | On : Data link being executed Off : Data link not yet executed |
| RD | On : Data being received Off : Data not yet received |
| L. ERR. | On : Communication error occurred Off : No communication error |
| EXT.PW. | On : Power being supplied externally. Off : Power not yet supplied externally. |

(2) Setting contents for each switch

(a) Station number setting switches

STATION NO.
10s unit → X10 
1s unit → X1 

| Switch name | Setting content | Type | Setting range | Setting at time of shipment |
|---------------------------------|-------------------------|--------------------|--------------------------------------------------------------------------------------------------------------------|-----------------------------|
| Station number setting switches | Sets the station number | PLC to PLC network | QJ71LP21-25, QJ71LP21S-25, QJ71LP21G: 1 to 64 QJ71BR11: 1 to 32 Setting error for other than the above | 1 |
| | | Remote I/O network | All module 0: Remote master station Setting error for other than the above | |

(b) Mode setting switch

1) QJ71LP21G, QJ71BR11

MODE 

| Switch name | Setting content | Type | Setting range | Setting at time of shipment |
|---------------------|-------------------------|-----------------------------------------------|---------------------------------------------------------------------------------------------------------------------|-----------------------------|
| Mode setting switch | Sets the operating mode | PLC to PLC network • Remote I/O network | 0: On-line 1: Self-loopback test 2: Internal self-loopback test 3: Hardware test 4 to F: Use prohibited | 0 |

2) QJ71LP21-25, QJ71LP21S-25

| Switch name | Setting content | Type | Setting range | Setting at time of shipment |
|------------------------|-------------------------|-----------------------------------------------|---------------------------------------------------------------------------------------------------------------------|-----------------------------|
| Mode setting switch *1 | Sets the operating mode | PLC to PLC network • Remote I/O network | 0: On-line 1: Self-loopback test 2: Internal self-loopback test 3: Hardware test | 10Mbps used |
| | | | 4: On-line 5: Self-loopback test 6: Internal self-loopback test 7: Hardware test 8 to F: Use prohibited | |

*1: When setting it to online with the Mode setting switch, the same setting must be made for control station and normal stations of PLC to PLC network, or remote master station and remote I/O stations of remote I/O network.

5. Wiring

DANGER

- Before starting any installation or wiring work, make sure to shut off all phases of the external power supply.
Failure to do so may cause electric shocks or damage the product.

CAUTION

- Always connect the FG terminals to the ground using class D (class 3) or higher grounding exclusively designed for PLC.
Failure to do so may cause malfunctions.
- When connecting cables to the terminal block for external power supply, check the rated voltage and terminal layout of the product for correct wiring.
Connecting a cable to power supply of different voltage or incorrect wiring may cause a fire or fault.
- Tighten the terminal screws with the specified torque.
Loose tightening may lead to a short circuit, fire or malfunction.
- Solder coaxial cable connectors properly. Incomplete soldering may result in malfunction.
- Be careful not to let foreign objects such as dust and wire chips get inside the module. They may cause a fire, mechanical breakdown or malfunction.
- The top surface of the module is covered with a protective film to prevent foreign objects such as wire chips from entering the module during wiring work. Do not remove this film until all the wiring work is complete. Before operating the system, be sure to remove the film to release the heat.
- Make sure to place the communication and power cables into a duct or fasten them using a clamp. Failure to do so may damage the module or cables by pulling a dangling cable inadvertently or cause the module to malfunction due to bad connection.
- When disconnecting the communication and power cables from the module, do not pull a cable part by hand.
When disconnecting a cable with a connector, hold the connector connected to the module by hand and pull it out to remove the cable. When disconnecting a cable connected to a terminal block, loosen the screws on the terminal block first before removing the cable. If a cable is pulled while being connected to the module, it may cause the module to malfunction or damage the module and cables.

5.1 Precautions for Laying Optical Fiber Cables

(1) The distance between stations varies depending on the type of optical fiber cable used.

(a) QJ71LP21-25, QJ71LP21S-25

| Type | | Distance between stations (m) | |
|----------------------------------------------|--------|-------------------------------|------------------|
| | | 10Mbps | 25Mbps |
| SI optical fiber cable (Old type: A-2P-□) | L type | 500 (1640.5 ft.) | 200 (656.2 ft.) |
| | H type | 300 (984.3 ft.) | 100(328.1 ft.) |
| SI optical fiber cable | | 500 (1640.5 ft.) | 200 (656.2 ft.) |
| SI type H-PCF optical fiber cable | | 1000 (3281 ft.) | 400 (1312.4 ft.) |
| GI type H-PCF optical fiber cable | | 1000 (3281 ft.) | 1000 (3281 ft.) |
| QSI optical fiber cable | | 1000 (3281 ft.) | 1000 (3281 ft.) |

(b) QJ71LP21G

| Type | Distance between stations (m) |
|------------------------|-------------------------------|
| GI optical fiber cable | 2000 (6562 ft.) |

- (2) When connecting an optical fiber cable, the following restrictions on the bending radius must be observed. Please confirm bending radius of the cable with the cable used.
- (3) Please maintain the optical fiber cable permissible bending radius with a checking tool.
Enquiries for the checking tool for optical fiber cable bending radius maintenance are handled by Mitsubishi Electric System Service Corporation. Please contact your nearest Mitsubishi Electric System Service Corporation for detail.
- (4) When laying the optical-fiber cable, do not touch the fiber core of the cable connector or module connector, or let dirt or dust collect on it. If oil from the hands, dirt or dust should adhere to the core, the transmission loss will increase, causing a malfunction in the data link.
- (5) When attaching or detaching the optical-fiber cable to/from the module, hold the cable connector securely with the hands.
- (6) Connect the cable connector and module connector securely until you hear a "click" sound.


5.2 Precautions when Installing the Coaxial Cables

- (1) Between stations, use the cable length indicated in the table below according to the number of stations connected.

There is the possibility of communication errors if the cable length other than the table listed below is used.

| Number of stations connected | Cable length between stations | Total extension distance |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|
| 2 to 9 stations | 1 to 300 m (3C-2V) (3.28 to 984.3 ft.) 1 to 500 m (5C-2V) (3.28 to 1640.5 ft.) | 300 m (984.3 ft.) (3C-2V) |
| 10 to 33 stations | 1 to 5 m (3C-2V, 5C-2V) (3.28 to 16.41 ft.) 13 to 17 m (3C-2V, 5C-2V) (42.65 to 55.78 ft.) 25 to 300 m (3C-2V) (82.03 to 984.3 ft.) 25 to 500 m (5C-2V) (82.03 to 164.5 ft.) | 500 m (1640.5 ft.) (5C-2V) |


- (2) If there is the possibility of an increase in the number of stations due to system expansion, install the cables with advance consideration of the restrictions.
- (3) When using a repeater module (models A6BR10 or A6BR10-DC), use the station-to-station cable length indicated by "10 to 33" stations, regardless of the number of stations connected or the number of repeater modules.
- (4) Install the coaxial cables at least 100 mm (3.94 ft.) away from other power cables and control cables.
- (5) Consider wiring using double-shielded coaxial cable in places that are subject to large amounts of noise.
- (6) When creating the multiplexed remote I/O network for the redundant system, use double-shielded coaxial cables.



The 5C-2V connector plug is applicable to double-shielded coaxial cable. Connect the 5C-2V connector plug to the coaxial cable inside a double-shielded coaxial cable. Ground the shielded part outside a double-shielded coaxial cable as shown in the above figure.

- (7) When connecting a coaxial cable, the following restrictions on the bending radius must be observed.

| Cable type | Allowable bending radius r [mm (in.)] | Connector A [mm (in.)] |
|------------|--------------------------------------------|---------------------------|
| 3C-2V | 23 (0.91) | 55 (2.17) |
| 5C-2V | 30 (1.18) | |




- (8) Do not pull any of the connected coaxial cables.
This will cause a faulty contact, cable disconnection, or damage to the module.
- (9) Make sure to connect a terminal resistor to both terminal stations of the coaxial bus type network system.
- (10) Depending on the usage environment, some white oxidation deposits may be seen on the F type connector. However, oxidation will not occur on the connection area, so there will be no problems with the function of the unit.

5.3 Connecting the Connector for the Coaxial Cable

The following section explains how to connect the BNC connector (connector plug for the coaxial cable) to the cable.


(1) Structure of the BNC connector and coaxial cable

The structure of the BNC connector and coaxial cable are shown in the figure below.




(2) How to connect the BNC connector and the coaxial cable

(a) Cut off the outer sheath of the coaxial cable to the length shown in the diagram below.




Cut this portion of the outer sheath


(b) Feed the nut, washer, gasket and clamp on the coaxial cable through, as shown below, then unfasten the external conductor.




- (c) Cut the external conductor, insulation material and internal conductor to the dimensions shown below. However, cut the external conductor to the same dimension as the tapered section of the clamp and smooth it down to the clamp.



- (d) Solder the contact to the internal conductor.



- (e) Insert the connector assembly in (d) into the plug shell and screw the nut into the plug shell.




Important

- (1) Note the following precautions when soldering the internal conductor and contact.
- Make sure that the solder does not bead up at the soldered section.
 - Make sure there are no gaps between the connector and cable insulator or they do not cut into each other.
 - Perform soldering quickly so the insulation material does not become deformed.
- (2) Before connecting or disconnecting the coaxial connector, touch a grounded metal object to discharge the static electricity from the human body. Failure to do so may result in a module malfunction.


6. External Dimensions

(1) QJ71LP21-25, QJ71LP21G




*1: Please contact your nearest Mitsubishi Electric System Service Corporation for detail.
Unit: mm (in.)

(2) QJ71LP21S-25



Unit: mm (in.)

(3) QJ71BR11



Unit: mm (in.)

Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

| Country/Region | Sales office/Tel | Country/Region | Sales office/Tel |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U.S.A | Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Tel : +1-847-478-2100 | Hong Kong | Ryoden Automation Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, HongKong Tel : +852-2887-8870 |
| Brazil | MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. AV. Paulista 1471, Conj. 308, Sao Paulo City, Sao Paulo State, Brazil Tel : +55-11-283-2423 | China | Ryoden Automation Shanghai Ltd. 3F Block5 Building Automation Instrumentation Plaza 103 Cao Bao Rd. Shanghai 200233 China Tel : +86-21-6475-3228 |
| Germany | Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0 | Taiwan | Setsuyo Enterprise Co., Ltd. 6F., No.105 Wu-Kung 3rd.RD, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499 |
| U.K | Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Herts., AL10 8XB,UK Tel : +44-1707-276100 | Korea | HAN NEUNG TECHNO CO.,LTD. 1F Dong Seo Game Channel Bldg., 660-11, Deungchon-dong Kangsec-ku, Seoul, Korea Tel : +82-2-3660-9552 |
| Italy | Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, 20041 Agrate B., Milano, Italy Tel : +39-039-6053344 | Singapore | Mitsubishi Electric Asia Pte, Ltd. 307 ALEXANDRA ROAD #05-01/02, MITSUBISHI ELECTRIC BUILDING SINGAPORE 159943 Tel : +65-6473-2308 |
| Spain | Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80 08190 - Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131 | Thailand | F. A. Tech Co.,Ltd. 898/28,29,30 S.V.City Building,Office Tower 2,Floor 17-18 Rama 3 Road, Bangkpongpan, Yannawa, Bangkok 10120 Tel : +66-2-682-6522 |
| France | Mitsubishi Electric Europe B.V. French Branch 25 Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568 | Indonesia | P.T. Autoteknindo SUMBER MAKMUR Jl. Muara Karang Selatan Block A Utara No.1 Kav. No.11 Kawasan Industri/ Pergudangan Jakarta - Utara 14440 Tel : +62-21-663-0833 |
| South Africa | Circuit Breaker Industries LTD. Tripswitch Drive, Elandsfontein Gauteng, South Africa Tel : +27-11-928-2000 | India | Messung Systems Put,Ltd. Electronic Sadan NO:111 Unit No15, M.I.D.C BHOSARI,PUNE-411026 Tel : +91-20-712-2807 |
| | | Australia | Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, PostalBag, No 2, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777 |

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : 1-8-12, OFFICE TOWER Z 14F HARUMI CHUO-KU 104-6212, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.
Printed in Japan on recycled paper.

HEADQUARTERS

MITSUBISHI ELECTRIC EUROPE B.V. **EUROPE**
 German Branch
 Gothaer Straße 8
D-40880 Ratingen
 Phone: +49 (0)2102 / 486-0
 Fax: +49 (0)2102 / 486-1120

MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. **CZECH REP.**
 Czech Branch
 Avenir Business Park, Radlická 714/113a
CZ-158 00 Praha 5
 Phone: +420 - 251 551 470
 Fax: +420 - 251-551-471

MITSUBISHI ELECTRIC EUROPE B.V. **FRANCE**
 French Branch
 25, Boulevard des Bouvets
F-92741 Nanterre Cedex
 Phone: +33 (0)1 / 55 68 55 68
 Fax: +33 (0)1 / 55 68 57 57

MITSUBISHI ELECTRIC EUROPE B.V. **IRELAND**
 Irish Branch
 Westgate Business Park, Ballymount
IRL-Dublin 24
 Phone: +353 (0)1 4198800
 Fax: +353 (0)1 4198890

MITSUBISHI ELECTRIC EUROPE B.V. **ITALY**
 Italian Branch
 Viale Colleoni 7
I-20041 Agrate Brianza (MB)
 Phone: +39 039 / 60 53 1
 Fax: +39 039 / 60 53 312

MITSUBISHI ELECTRIC EUROPE B.V. **POLAND**
 Poland Branch
 Krakowska 50
PL-32-083 Balice
 Phone: +48 (0)12 / 630 47 00
 Fax: +48 (0)12 / 630 47 01

MITSUBISHI ELECTRIC EUROPE B.V. **RUSSIA**
 52, bid. 3 Kosmodamianskaya nab 8 floor
RU-115054 Moscow
 Phone: +7 495 721-2070
 Fax: +7 495 721-2071

MITSUBISHI ELECTRIC EUROPE B.V. **SPAIN**
 Spanish Branch
 Carretera de Rubí 76-80
E-08190 Sant Cugat del Vallés (Barcelona)
 Phone: 902 131121 // +34 935653131
 Fax: +34 935891579

MITSUBISHI ELECTRIC EUROPE B.V. **UK**
 UK Branch
 Travellers Lane
UK-Hatfield, Herts. AL10 8XB
 Phone: +44 (0)1707 / 27 61 00
 Fax: +44 (0)1707 / 27 86 95

MITSUBISHI ELECTRIC CORPORATION **JAPAN**
 Office Tower "Z" 14 F
 8-12,1 chome, Harumi Chuo-Ku
Tokyo 104-6212
 Phone: +81 3 622 160 60
 Fax: +81 3 622 160 75

MITSUBISHI ELECTRIC AUTOMATION, Inc. **USA**
 500 Corporate Woods Parkway
Vernon Hills, IL 60061
 Phone: +1 847 478 21 00
 Fax: +1 847 478 22 53

EUROPEAN REPRESENTATIVES

GEVA **AUSTRIA**
 Wiener Straße 89
AT-2500 Baden
 Phone: +43 (0)2252 / 85 55 20
 Fax: +43 (0)2252 / 488 60

TEHNIKON **BELARUS**
 Oktyabrskaya 16/5, Off. 703-711
BY-220030 Minsk
 Phone: +375 (0)17 / 210 46 26
 Fax: +375 (0)17 / 210 46 26

ESCO DRIVES & AUTOMATION **BELGIUM**
 Culliganlaan 3
BE-1831 Diegem
 Phone: +32 (0)2 / 717 64 30
 Fax: +32 (0)2 / 717 64 31

Koning & Hartman b.v. **BELGIUM**
 Woluwelaan 31
BE-1800 Vilvoorde
 Phone: +32 (0)2 / 257 02 40
 Fax: +32 (0)2 / 257 02 49

INEA BH d.o.o. **BOSNIA AND HERZEGOVINA**
 Aleja Lipa 56
BA-71000 Sarajevo
 Phone: +387 (0)33 / 921 164
 Fax: +387 (0)33 / 524 539

AKHNATON **BULGARIA**
 4 Andrej Ljapchev Blvd. Pb 21
BG-1756 Sofia
 Phone: +359 (0)2 / 817 6044
 Fax: +359 (0)2 / 97 44 06 1

INEA CR d.o.o. **CROATIA**
 Losinjka 4 a
HR-10000 Zagreb
 Phone: +385 (0)1 / 36 940 -01 / -02 / -03
 Fax: +385 (0)1 / 36 940 -03

AutoCont C.S. s.r.o. **CZECH REPUBLIC**
 Technologická 374/6
CZ-708 00 Ostrava-Pustkovce
 Phone: +420 595 691 150
 Fax: +420 595 691 199

Beijer Electronics A/S **DENMARK**
 Lykkegårdsvej 17
DK-4000 Roskilde
 Phone: +45 (0)46 / 75 76 66
 Fax: +45 (0)46 / 75 56 26

Beijer Electronics Eesti OÜ **ESTONIA**
 Pärnu mnt.160i
EE-11317 Tallinn
 Phone: +372 (0)6 / 51 81 40
 Fax: +372 (0)6 / 51 81 49

Beijer Electronics OY **FINLAND**
 Peltoie 37
FIN-28400 Ulvila
 Phone: +358 (0)207 / 463 540
 Fax: +358 (0)207 / 463 541

UTEKO **GREECE**
 5, Mavrogenous Str.
GR-18542 Piraeus
 Phone: +30 211 / 1206 900
 Fax: +30 211 / 1206 999

MELTRADE Kft. **HUNGARY**
 Fertő utca 14.
HU-1107 Budapest
 Phone: +36 (0)1 / 431-9726
 Fax: +36 (0)1 / 431-9727

Beijer Electronics SIA **LATVIA**
 Rītausmas iela 23
LV-1058 Rīga
 Phone: +371 (0)784 / 2280
 Fax: +371 (0)784 / 2281

Beijer Electronics UAB **LITHUANIA**
 Savanorių Pr. 187
LT-02300 Vilnius
 Phone: +370 (0)5 / 232 3101
 Fax: +370 (0)5 / 232 2980

EUROPEAN REPRESENTATIVES

ALFATRADE Ltd. **MALTA**
 99, Paola Hill
Malta- Paola PLA 1702
 Phone: +356 (0)21 / 697 816
 Fax: +356 (0)21 / 697 817

INTEHSIS srl **MOLDOVA**
 bld. Traian 23/1
MD-2060 Kishinev
 Phone: +373 (0)22 / 66 4242
 Fax: +373 (0)22 / 66 4280

HIFLEX AUTOM.TECHNIEK B.V. **NETHERLANDS**
 Wolweverstraat 22
NL-2984 CD Ridderkerk
 Phone: +31 (0)180 - 46 60 04
 Fax: +31 (0)180 - 44 23 55

Koning & Hartman b.v. **NETHERLANDS**
 Haarderbergweg 21-23
NL-1101 CH Amsterdam
 Phone: +31 (0)20 / 587 76 00
 Fax: +31 (0)20 / 587 76 05

Beijer Electronics AS **NORWAY**
 Postboks 487
NO-3002 Drammen
 Phone: +47 (0)32 / 24 30 00
 Fax: +47 (0)32 / 84 85 77

Fonseca S.A. **PORTUGAL**
 R. João Francisco do Casal 87/89
PT - 3801-997 Aveiro, Esgueira
 Phone: +351 (0)234 / 303 900
 Fax: +351 (0)234 / 303 910

Sirius Trading & Services srl **ROMANIA**
 Aleea Lacul Morii Nr. 3
RO-060841 Bucuresti, Sector 6
 Phone: +40 (0)21 / 430 40 06
 Fax: +40 (0)21 / 430 40 02

Craft Con. & Engineering d.o.o. **SERBIA**
 Bulevar Svetog Cara Konstantina 80-86
SER-18106 Nis
 Phone: +381 (0)18 / 292-24-4/5
 Fax: +381 (0)18 / 292-24-4/5

INEA SR d.o.o. **SERBIA**
 Izletnicka 10
SER-113000 Smederevo
 Phone: +381 (0)26 / 617 163
 Fax: +381 (0)26 / 617 163

SIMAP s.r.o. **SLOVAKIA**
 Jána Derku 1671
SK-911 01 Trenčín
 Phone: +421 (0)32 743 04 72
 Fax: +421 (0)32 743 75 20

PROCONT, spol. s r.o. Prešov **SLOVAKIA**
 Kúpeľná 1/A
SK-080 01 Prešov
 Phone: +421 (0)51 7580 611
 Fax: +421 (0)51 7580 650

INEA d.o.o. **SLOVENIA**
 Stegne 11
SI-1000 Ljubljana
 Phone: +386 (0)1 / 513 8100
 Fax: +386 (0)1 / 513 8170

Beijer Electronics AB **SWEDEN**
 Box 426
SE-20124 Malmö
 Phone: +46 (0)40 / 35 86 00
 Fax: +46 (0)40 / 93 23 01

Omni Ray AG **SWITZERLAND**
 Im Schörl 5
CH-8600 Dübendorf
 Phone: +41 (0)44 / 802 28 80
 Fax: +41 (0)44 / 802 28 28

GTS **TURKEY**
 Bayraktar Bulvarı Nutuk Sok. No:5
TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL
 Phone: +90 (0)216 526 39 90
 Fax: +90 (0)216 526 39 95

CSC Automation Ltd. **UKRAINE**
 4-B, M. Raskovoyi St.
UA-02660 Kiev
 Phone: +380 (0)44 / 494 33 55
 Fax: +380 (0)44 / 494-33-66

EURASIAN REPRESENTATIVES

TOO Kazpromavtomatika **KAZAKHSTAN**
 Ul. Zhambyla 28
KAZ-100017 Karaganda
 Phone: +7 7212 / 50 10 00
 Fax: +7 7212 / 50 11 50

MIDDLE EAST REPRESENTATIVES

ILAN & GAVISH Ltd. **ISRAEL**
 24 Shenkar St., Kiryat Arie
IL-49001 Petah-Tiqva
 Phone: +972 (0)3 / 922 18 24
 Fax: +972 (0)3 / 924 0761

TEXEL ELECTRONICS Ltd. **ISRAEL**
 2 Ha'umanut, P.O.B. 6272
IL-42160 Netanya
 Phone: +972 (0)9 / 863 39 80
 Fax: +972 (0)9 / 885 24 30

CEG INTERNATIONAL **LEBANON**
 Cebaco Center/Block A Autostrade DORA
Lebanon - Beirut
 Phone: +961 (0)1 / 240 430
 Fax: +961 (0)1 / 240 438

AFRICAN REPRESENTATIVE

CBI Ltd. **SOUTH AFRICA**
 Private Bag 2016
ZA-1600 Isando
 Phone: +27 (0)11 / 977 0770
 Fax: +27 (0)11 / 977 0761