MITSUBISHI

General Purpose Inverter



Instruction Manual

(Multi-function Series)



Thank you for choosing this Mitsubishi Inverter.

This manual gives handling, safety and operating instructions.

This section is specifically about safety matters

Read this manual carefully and become familiar with the inverterbefore operation, pay special attention to the safety information marked Warning.



This warning symbol indicates the presence of dangerous voltage. It informs you of high voltage conditions, situations and locations that may cause death or serious injury if you do not follow precautions.



This symbol indicates a general warning. Serious injury may occur if precautions are not followed.

Where these Wamings are written, pay special attention to the precautions detailed.

Operator Safety

1. Electric shock prevention

A WARNING HIGH VOLTAGE

- ⚠ Do not remove the front cover while there is power supplied to the inverter, there are high voltage terminals which can be accessed. Please check the wiring when the inverter is not powered.
- There are high voltage capacitors in the main circuit which remain charged after the inverter has been turned off, wait 10 minutes after the Power Lamp has gone out and check for no residual voltage actoss terminals "P/+" and "-" ("P" and "N") before touching wires.
- Use good earthing. Earth the inverter before wiring the Power circuits and control circuits.
- ♠ Do not operate with wet hands.
- ⚠ Do not damage, cut, trap, or degrade the cables.

2. Fire Prevention

M WARNING

- ⚠ Do not mount on or near combustible material (such as wood)
- ⚠ Use a circuit breaker on the supply side of the inverter to prevent high current flow in the case of a fault.
- △ Do not connect a resistor directly to terminals "P" and "N".

3. Injury Prevention

MWARNING

- △ Only supply the inverter with the voltage on the nameplate and in the Manual Specification section.
- ⚠ Other voltages may cause the inverter to fail.
- △ Care should be taken when wiring to ensure correct terminals are used. Check polarity etc.,
- ⚠ Do not touch the inverter while it is powered as certain parts become hot.

4. Other points

To prevent injury, damage, or product failure please note the following points.

(1) Transportation and mounting

⚠ WARNING

- ⚠ Take care when carrying products, use correct lifting gear.
- ⚠ Do not stack the inverter boxes higher than the number recommended.
- △ Ensure the installation position and material can with stand the weight of the inverter. Install according to the information in the Instruction Manual.
- A Do not operate if the inverter is damaged or has parts missing.
- ⚠ Do not life the inverter with the front cover attached, it may fall off.
- ⚠ Do not stand or rest heavy objects on the inverter.
- ⚠ Check the inverter mounting orientation is correct.
- △ Prevent any dust, wire fragments or other foreign bodies from dropping into the inverter during wiring up and commissioning.

⚠ WARNING

△ Do not drop the inverter, or subject it to impacts.

⚠ Environmental limitations, Check the ambient temperature, humidity, storage temperature, atmosphere, altitude, vibration. −10°C to +50°C (without freezing) −10°C to +40°C for enclosed specification.

Less than 90% Relative Humidity without condensation. Ensure the environment is -20° C to $+65^{\circ}$ C (short time storage temperature), no corrosive or flammable gasses, altitude less than 1000m above sea level, vibration is less than 5.9m/s 2 {0.6 G} (based on JIS C 0911)

(2) Wiring

⚠ WARNING

- △ Do not fit power factor correction capacitor, or RFI filter to the output of the inverter.
- ⚠ The connection orientation of the output cables U, V, W to the motor will effect the direction of rotation of the motor.

(3) Trial run

A WARNING

A Check all parameters, and ensure that the machine will not be damaged by sudden start-up.

(4) Operation

⚠ WARNING

- A When retry function is selected the inverter will try to restart the machine up to 10 times over a 1 hour period. Ensure operator safety with other devices.
- ⚠ The stop key can only be used at all times to stop the inverter when a parameter has been set, therefore use an external emergency stop button. Switch off start signal when resetting the inverter, failure to do so may start the motor immediately after reset
- The Electronic motor thermal protection does not guarantee to prevent motor burn out.

MARNING

- ⚠ Do not use a contactor in the inverter input for frequent start /stopping of the inverter, use control signals.
- ⚠ To reduce the effect of mains conducted electromagnetic interference use a RFI noise filter.
- ⚠ Take care to ensure electromagnetic radiation from the inverter does not damage or effect the operation of nearby electrical equipment.
- ⚠ Use an input line reactor when the power supply capacity is large, or where harmonics from the inverter will cause problems.
- A Take countermeasures to prevent motor insulation damage from micro surge voltages in the supply cable.
- A Reset the inverter before starting set-up, initialises the parameters to factory set values.
- ⚠ Do not use the inverter and motor at high speed until the machine has been checked.
- ⚠ The inverter does not have a holding stop facility. For emergency stop another circuit must be used.

(5) Emergency stop

⚠ WARNING

Let use a circuit and mechanical brake etc. which will protect the operator of the machine should the inverter fail.

(6) Maintenance and inspection

⚠ WARNING

⚠ Do not carry out a megga (insulation resistance) test on the control circuit of the inverter.

(7) Disposing of the inverter.

$oldsymbol{\Lambda}$ WARNING

A Treat as industrial waste.

(8) General

Many of the diagrams and drawings in the instruction manual show the inverter without a cover, or partially open, never run the inverter like this. Always replace the cover and ensure adequate cooling etc. before using the inverter. Thank you for purchasing the Mitsubishi general purpose inverter FREQROL-U100. For safe operation, please read this manual thoroughly before using this device.

Table of Contents

1.	INSPECTION AT DELIVERY	1
2.	NAMES AND FUNCTIONS OF EACH PART	3
3.	INSTALLATION	7
	WIRING Precautions for wiring Connecting power supply and motor Connecting control signals Wire size and peeling length	9 9 10 11 13
	OPERATION I Operation methods I How to use the key pad I Monitor and parameter settings	17 17 20 21
	FUNCTIONS List of functions Explanation of functions	23 23 27

7. SPECIFICATIONS	. 6!
■ Standard series ······	. 6!
Low-acoustic noise series	. 6
■ Single phase 100V input series ·······	. 6
■ Single phase 200V input series ·······	. 6
■ Common specifications ······	. 69
■ Terminal wiring diagram	. 7
■ Explanation of terminal specifications	. 73
■ Protective function ······	. 7
8. DIMENSIONAL OUTLINE DRAWING	. 81
■ Standard series ······	. 81
Low-acoustic noise series	. 83
Single phase 200V power input series	. 85
■ Single phase 100V power input series ·······	. 87
■ Fully enclosed type series ······	. 88
Multi-function law acquetic noise, fully analyzed type conice	~


9. SELECTION OF PERIPHERAL DEVICES


1. INSPECTION AT DELIVERY

Confirm the following points when unpacking the device.

- (1) Check the model plate on the front of the inverter and the rating plate on the side and check that the delivered device is the same as that ordered.
- (2) Check for damage caused during shipment.

If there any unclear points or damage is found in the device, please contact the place of purchase or your nearest Mitsubishi dealer.







Details of model plate


Details of rating plate

Details of model




2. NAMES AND FUNCTIONS OF EACH PART






How to remove / mount front cover



The cover can be removed by pushing the top and pulling it forward. To mount the cover, insert the two installation clasps on the bottom of the cover into the inlets on the main unit cover, and press on the cover.

Specifications for totally enclosed type

There is an exclusive wiring cover as shown below. Cut the wiring cover windows with nippers or cutters when wiring,



trivem of the second of the se

3. INSTALLATION

 Install the inverter vertically. Non-vertical installation methods will cause the inverter's heat dissipating effect to decrease, and may cause unforeseen problems and breakdowns.









Horizontal

 Keep the ambient temperature within the permissible temperature range.


If the inverter's ambient temperature rises due to installation near a heat generating object or installation in a panel will cause the inverter life to decrease remarkably.

Take cooling methods and panel dimensions into consideration when installing the inverter in a panel.

- Tolerable ambient temperature: -10 to 50℃ $(-10 \text{ to } +40^{\circ}\text{C} \text{ for totally enclosed type})$
- Points for measuring ambient temperature

Note: The inverter was designed for use in separately earthed enclosure.

Precautions must therefore be taken at point of installation to minimise risk of hezard to users.



 Ambient space 10cm or more 1cm 1cm or more or more 10cm or mo

- Avoid installation in the following places
- Where the inverter is subject to direct sunlight
- Humid places



- Places contaminated with oil mist, dust, lint or corrosive gases. Where the inverter is subject to wind containing salt.

· Places that vibrate



Pay attention to carriages or press machines, etc.

Places where explosive gases exist.



 Installation on flammable material such as wood.



4. WIRING


■ Precautions for wiring

Pay attention to the following items during wiring to prevent mistaken wiring and mistaken usages.

- Precautions for wiring

- (1) When the power supply is applied on the inverter output terminals (U. V and W), the inverter will be damaged. Never wire the power supply to these terminals.
- (2) Use a shield or twisted wire for the wiring to the control circuit terminal, and separate the wires from the main circuit or power distribution circuit (200V relay sequence circuit, etc.).
- (3) Cover the slits on the inverter so that the wire waste does not enter the inverter during wiring.
- (4) Confirm that the display lamp on the key pad has gone out before changing the wiring after operation, and wait at least two minutes before starting the wiring. (It takes more than one minutes for discharge of the internal capacitors after disconnecting power supply.)

■ Connecting power supply and motor



Always connect the power supply wires to R, S and T. Never connect to U, V and W as the inverter will be damaged.

(The phases do not need to


be matched.)

.


Connect the motor to U, V and W.

The motor rotation direction will be counterclockwise(direction of the arrow, shown above)looking from the load shaft when the wires are connected as shown above and the forward rotation switch (signal) is turned on.


Single phase input series



■ Connecting control signals



- (Note 1) The function of the AUX input terminals (X1, X2, X3) is selected with the input terminal function selector [60].
- (Note 2) 2W1kΩ is recommended if the frequency setting is to be changed frequently.
- (Note 3) The terminal block TB1 and TB2 terminals SD are connected inside the inverter.




Connection of main circuit terminals

Use a small minus screwdriver (with blade width 2.5 to 3 mm).

It is introduced in the upper slot \odot and it's blade holds the spring open so that the stripped power supply wire can be introduced into the terminal \odot .

Withdraw the screwdriver, the conductor is clamped.



Connection of control circuit terminal

Insert a small minus screwdriver (with blade width 2.5 to 3 mm) into the right hole ⑤, and insert the stripped wire into ⑥ while pressing the screwdriver in the direction of the arrow. Remove the screwdriver when the wire has been inserted.

(Note) Use a small flat-blade screwdriver (blade width 2.5 to 3mm).

■ Wire size and peeling length

Applicable wire size for terminal block

	Main circuit (Note 1)	Control circuit		
Wire size	Solid wire: \$\phi 0.3 to \$\phi 1.8 mm Strand: 0.08 to 2.5 mm	Solid wire: \$0.4 to \$1.0 mm Strand: 0.3 to 0.75 mm		
Wire sheath peeling length	5 to 6 mm	8 to 10 mm		

Screwless terminal is standard feature for the terminal blocks excluding the grounding terminal.

Connected with rod terminals* or with only the wire instead of using crimp terminals.

(When using strands, make sure that the strands do not loosen to avoid a short circuit,)

Use a crimp terminal for only the grounding terminal.

(Note 1)


The wire sizes shown above are available, but a 2 mi wire is recommended in terms of reliability.

*Example of rod terminals

Circuit	Applicable	Applicable wire size			
	terminal name	Solid wire (mm)	Strand wire (mi)	Manufacturer	
Main circuit terminal	TC-1.25 (S)	♦ 0.57 to ♦ 1.44	0.25 to 1.65		
	TC-2 (S)	φ 1.14 to φ 1.82	1.04 to 2.36	Nichifu Terminal	
	TUB-1.25	\$ 0.57 to \$ 1.44	0.55 to 1.65	Japan Solderless Termina	
Control	TC-0.5	ф 0.57 to ф 0.7	0.25 to 0.75	Nichifu Terminal	
circuit terminal	H0.25/10	ф 0.57	0.25	Japan Weidmuller	

Details to be checked in wiring planning


(1) When the circuit has current loop in the power supply due to a mistaken connection as well as to a commercial selector circuit as shown on the right, the inverter will be damaged. Always create an electrical and mechanical interlock for MC1 and MC2.




- (2) If a power failure occurs and the start signal (start switch) is retained, the inverter will automatically resume operation when the power is restored. If the machine must be prevented from restarting with power restoration, install a magnetic contactor MC on the primary side of the inverter, and design a sequence to prevent the start signal from turning ON.
- (3) Use two contacts in parallel or a twin contact to prevent an imperfect contact for the input signal of the control circuit.
- (4) Do not input a voltage on the contact input terminal (STF, etc.) of the control circuit.
- (5) Do not apply the voltage directly onto the alarm output signal terminal (B, C). Pass the voltage through a relay coil or ramp.
- (6) When directly connecting the open collector output such as that from a sequence controller into the inverter input terminal, make sure that a backflow current does not occur.

Use of PC terminal

If the external power common for transistor output is connected to this terminal, malfunctions caused by a backflow currents can be prevented.






(Note) A DC24V power supply is required for the AY40 type unit.

Use the following countermeasures to prevent a backflow current when not using the PC terminal.

- (1) Insert a diode to prevent the backflow current.
- (2) Use an all-point isolated type output unit. (Ex. AY40A, etc.)
- (3) The external power supply voltage must be higher than the inverter's control power supply.
- (4) Use a PC terminal (external transistor common).



▲ [CAUTION] REMOVAL OF COVER WHEN UNIT IS POWERED GIVES ACCESS TO HIGH VOLTAGES.

PLEASE ISOLATE INVERTER FROM POWER BEFORE PERFORMING ANY ADJUSTMENTS TO WIRING, ETC. WAIT AT LEAST 3 MINUTES AFTER ISOLATION BEFORE REMOVING FRONT COVER.

5. OPERATION

■ Operation methods

The following operation methods can be used. Select the method according to the application and operation specifications.

Operation method	Details	Remarks		
Operation with key pad	Start/stop and operation frequency setting with key pad.	Factory-set to select this mode at power on.	Inverter Key pad	
Operation with external input signal	Start with external switch and operation frequency is adjusted with the external frequency setter connected to the inverter control terminal.		Start ownizer in yearlest SD STF SD 10 2 2 Fraquency acres	
Combined use of Operation with externel input	Start with external switch and setting of operation frequency with key pad.	The external frequency setter and key pad RUN and STOP keys are not accepted.	Start pwitch Inverter	
signals and key pad. (Refer to Pr.79)	Start/stop with key pad. setting of operation frequency with external frequency setter.	The external start switch command is ignored.	Frequency 5	

Operation with key pad

The key pad operation (parameter No. 79 "1") is selected as the factory setting.

(Note)

To drive the motor in the reverse direction with the RUN key, short-circuit between STR and SD on the terminal block, or set parameter No.78 to "2".


Operation with external input signal

• Set external operation mode (parameter No.79 "2").

(Refer to the following explanation for the setting method.)


The start signals and frequency are input with external switches and frequency setting potentiometer.

The motor will operate when a signal is input into STF (forward rotation) or STR (reverse rotation) and the frequency setter is operated.




Note

The start signal self-holding function can be slected (for details see Pr.61)





How to use the key pad



▲[CAUTION] DO NOT USE ANY SHARP OBJECTS ON THE KEY PAD.
OR IT MAY DAMAGE THE MEMBRANE.


■ Monitor and parameter settings





(Note)

- Pressing UP or DOWN key will increment or decrement displayed parameter number by one in order of the parameter list.
 (PO will display if the UP key is pressed when CLr is displayed.)
- The current monitor displays only when the SET key is pressed in the frequency monitor mode.



 When alarm (Er 1 to 3) is displayed
 (The alarm can be canceled by pressing the mode key, not canceled by RESET key.)

Alarm display					
Erl	Write prohibit alarm	Writing was attempted during the pr.77 "1" state (write prohibit)			
Erz	Write alarm during operation	Pr.79 was rewritten or all clear was executed during operation.			
8-3	Calibration error	The calibration value for C-2 and C-3 was too close. *			

The calibration error will occur if the difference of the input voltage for the C-2 to C-3 calibration value is approximately 0.5V or less.

6. Functions

■ List of functions

Function No. (peremeter)	Function name	Setting range	Setting unit	Factory setting	User setting
0	Torque boost (manual)	0 to 15%	1.%	6 %	
1	Upper limit frequency	0 to 120 Hz	0.1 Hz	120 Hz	
2	Lower limit frequency	0 to 60 Hz	0.1 Hz	0 Hz	
3	Base frequency	50 to 120 Hz	0.1 Hz	60 Hz	
4	3-speed setting (high)	0 to 120 Hz	0.1 Hz	60 Hz	
5	3-speed setting (medium)	0 to 120 Hz	0.1 Hz	30 Hz	
6	3-speed setting (low)	0 to 120 Hz	0.1 Hz	10 Hz	
7	Acceleration time	0, 0.1 to 999 sec.	0.1 sec.	5.0 sec	
8	Deceleration time	0, 0.1 to 999 sec.	0.1 sec.	5.0 sec	
9	Electronic thermal relay	0 to 15A	0.1 A	Rated current	
10	PWM mode (Note 6)	0 to 15,	1	3	
11	DC dynamic braking operation time	0 to 10 sec.	0.1 sec.	0.5 sec.	
12	DC dynamic braking voltage	0 to 15%	1 %	8 %	
15	JOG frequency	0 to 120 Hz	0.1 Hz	5 Hz	

Function No. (perameter)	Function name	Setting range	Setting unit	Fectory setting	User setting
16	JOG acceleration/deceleration time	0, 0.1 to 999 sec.	0.1 sec	0.5 sec	
17	External thermal relay input selection	0, 1	1	0	
19	Basa frequency voltage	0 to 500V,	1 V		
20	Acceleration/deceleration reference frequency	1 to 120 Hz	0.1 Hz	60 Hz	
21	Frequency setting voltage bias	0 to 60 Hz	0.1 Hz	0 Hz	
22	Frequency setting voltage gain	0 to 120 Hz	0.1 Hz	60 Hz	
23	Stall prevention operation level	0 to 10	1	5	
24	Multi-speed setting (4th speed)	0 to 120Hz,	0.1 Hz		
25	Multi-speed setting (5th speed)	0 to 120Hz,	0.1 Hz		
26	Multi-speed setting (6th speed)	0 to 120Hz,	0.1 Hz		
27	Multi-speed setting (7th speed)	0 to 120Hz,	0.1 Hz		
37	Speed display	0, 0.1 to 999	0.1	0	
42	Up-to-frequency sensitivity	1 to 100%	1 %	10%	
43	Output frequency detection	1 to 120 Hz	0.1 Hz	6 Hz	
44	Output frequency detection during reverse rotation	1 to 120Hz,	0.1 Hz		

Function No. (perameter)	Function name	Setting range	Setting unit	Factory setting	User setting
46	No.2 acceleration/deceleration time	0, 0.1 to 999 sec.,	0.1 sec.		
47	No.2 deceleration time	0, 0.1 to 999 sec.,	0,1 sec.		
48	No.2 torque boost	0 to 15%,	1 %		
49	No.2 V/F (Base frequency)	50 to 120 Hz,	0.1 Hz		
50	Retry selection	0, 1, 2, 3	1	0	
51	No. of retries at alarm	0, 1 to 10, 101 to 110	1	0	
52	Retry execution wait time	0 to 360 sec.	0.1sec.	1 sec.	
53	No. of retry execution time display clear	0	0	Ò	
55	Frequency monitor reference	0 to 120 Hz	0.1 Hz	60 Hz	
56	Current monitor reference	0 to 200%	1 %	150%	
59	Remote setting function selection	0, 1	1	0	
60	Input terminal function selection	0 to 8	1	0	
61	Input terminal allocation	0 to 999	1		
70	FM output terminal function selection	0, 1	1	0	
★71	Tone selection	0, 1	1	0	


Function No. (perentister)	Function name	Setting range	Setting unit	Factory setting	User setting	
★ 72	PWM carrier frequency	2.3 to 14.5 kHz	0.1 kHz	7.0 kHz		
75	Stop key function	0, 14	1	14		
76	Output signal selection	0, 1, 2	1	0		
77	77 Write prohibit selection		1	0		
78	78 Reverse rotation prevention selection		1	0		
79	Operation mode selection	1, 2, 3, 4	1	1		
CLr	Parameter clear	0, 1, 2	1	0		
C-1	Frequency meter scale calibration	_	_	_		
C-2 Frequency setting bias calibration		0 to 60 Hz	0.1 Hz	0 Hz		
C-3	Frequency setting gain calibration	0 to 120 Hz	0.1 Hz	60 Hz		

(Note)

- 1. The factory setting for Pr.79 operation mode selection is "1" (key pad mode).
- 2. The reset key on the key pad is accepted only during an alarm stop.
- All parameters, excluding Pr.79, Pr.80 and Pr.CLr parameter clear, can be written during operation. (When Pr.77 = 0)
 Writing is invalid when Pr.77=1, except for Pr.77.
- 4. The setting value "---" indicates "no function operation".
- 5. The parameters marked with * are displayed only for the low-acoustic noise model.
- 6. The Pr.10 setting "---" can be set only for the low-acoustic noise model. Pr.72 can be read and written when "---" is set in Pr.10. The factory setting for the low-acoustic noise model is ---.

Explanation of functions

- Torque boost (manual)0
 - No.2 torque boost (manual) 48 The low frequency band motor torque can be adjusted to the load. (Note)




If the setting value is too large, the overcurrent protective function may activate. The setting value can be adjusted while confirming the motor current with the monitor function. The No.2 torque boost is valid when terminals RT-SD3) close if the No.2 acceleration/deceleration time Pr.46 is set. [Factory setting]

Torque boost (manual) 6 % No.2 torque boost (manual) ---

● Upper limit frequency 1 ● Lower limit frequency 2 The upper and lower limit clamps of the output frequency can be set.

[Factory setting]

- · Upper limit frequency ····· 120Hz
- Lower limit frequency 0 Hz




● V/F (base frequency) 3

● Base frequency voltage 19


● No.2 V/F (base frequency) 49

The base frequency (reference frequency at motor rated power) can be set freely between 50 and 120Hz according to the motor rating. The No.2 V/F is valid when terminals RT-SD³ Close if the No.2 acceleration/deceleration time Pr.46 is set. "



(Note)

- If the No.2 acceleration/deceleration time is not set, the No.2 V/F will not function even if No.2 V/F value is set and terminals RT-SD are closed.
- 2) The maximum output voltage will be the power supply voltage when "---" (factory setting) is set in Pr.19.
- Terminal MRS/RT function is specified with the input terminal function selection Pr.60.



• 3-speed setting (high) 4

• 3-speed setting (medium) 5

• 3-speed setting (low) 6

• Multi-speed setting (4th speed) 24

● Multi-speed setting (5th speed)

Multi-speed setting (7th speed)

● Multi-speed setting (7th speed)


Each speed can be selected (between terminals X1-SD, X2-SD, and X3-SD) by changing the contact signal from an external switch. Each speed (frequency) can be set freely within 0 to 120Hz during the inverter (motor) operation.

(Note)

- The 4th to 7th speed cannot be selected if "---" is set (factory setting).
- If two or three speeds are selected for the 3-speed setting, the low speed side frequency will be selected.
 (Example) If high speed (X1) 40Hz and low speed (X3) 50Hz are set, when X1-SD and

X3-SD turn ON simultaneously. 50Hz will be output.

- If the multi-speed signal and external frequency signal are input, the multi-speed signal has priority.
- The terminals X1 (high), X2 (medium) and X3 (low) are selected with the input terminal function selection 60




● Acceleration time 7

- Deceleration time 8
- Acceleration/deceleration reference frequency [20]

Pr.7 and 8 can be set between 0.1 and 999 seconds.

Acceleration time is the time (inclination) taken for acceleration to the frequency (fm) set in acc. / dec. reference frequency Pr.20.

If the acceleration/deceleration time is set to 0, the time will be 0.04 seconds.



[Factory setting]	
Acceleration time	5.0 sec.
Deceleration time	5.0 sec.
Acceleration / deceleration	
reference frequency	60Hz

• Electronic thermal relay 9

The setting value can be set as a current value (A) for the motor's overheating protection. Optimum protection characteristics, including a drop in the motor cooling performance at low speed operation, can be obtained. The motor protection function will not operate when set to 0 (A). (The output transistor protection function will operate.)

Set the motor rating current at 50Hz for a triple-rating motor.

Set to 0 (A) when using the external thermal relay.

[Factory setting] ····· (Inverter rated output current)

● PWM mode 10


By changing PWM mode setting, it is possible to select motor sound appropriate for load and to reduce resonant vibration for the standard acoustic noise model. Available in sixteen settings.

Setting value	Carrier frequency	Setting value	Carrier frequency	Setting value	Carrier frequency
0	0.7 kHz	6	1.3 kHz	12	1.9 kHz
1	0.8 kHz	7	1.4 kHz	13	2.0 kHz
2	0.9 kHz	8	1.5 kHz	14	2.1 kHz
3	1.0 kHz	9	1.6 kHz	15	2.2 kHz
4	1.1 kHz	10	1.7 kHz	(Note) 2.	For the low-acoustic
5	1.2 kHz	11	1.8 kHz	7 '	noise model

[Factory setting] ····· 3 (Low accoustic noise type ····· '---')

(Note)

- 1. The motor tone will increase in pitch when the setting value is increased.
- If the carrier frequency is changed for the low-acoustic noise type, set "---".
 If "---" is set, the carrier frequency Pr.72 can be read and changed.
- The setting cannot be changed from "---" to "0 to 15" during operation. Always stop
 before making changes. Note that the setting can be changed from "0 to 15" to "0 to 15".
- DC dynamic braking operation time 11
 DC dynamic braking voltage 12
 By setting the DC dynamic braking torque (voltage) and the operation time, accuracy in stop position can be adjusted matching the load.



(Note)

The DC dynamic braking operation frequency is fixed to 3Hz. Set the operation time to "0" when the DC dynamic braking is not required.

[Factory setting]

DC dynamic braking operation time ··· 0.5 sec.
DC dynamic braking voltage ········· 8 %

● JOG frequency 15

● JOG acceleration / deceleration time 16


Jogging operation will start and stop when the JOG mode is selected (short circuit between terminals JOG-SD), and the start signal (terminal STF or STR) is input. (Note)

1. JOG operation via key pad is also available. When using she terminal JOG/OH for "JOG", set the external thermal relay input selection 17 to "0". If set to "1", the setting will be for the external thermal relay input selection.

[Factory setting]	
JOG frequency	5Hz
JOG acceleration/deceleration time	0.5 sec.

(Note)

 Terminal JOG OH is selected with the input terminal selection function 60.



● External thermal relay input selection 17

Set 1 in this parameter and set 0 in Pr.9 when external motor overload protector is used. Trip of an overload relay installed or motor thermostat, which opens on an overtemperature condition, prevents drive operation.


(The alarm signal will also be output.)
Restarting will not be possible unless resetting is performed even if the thermal relay contact is restored. Therefore, this can be used as an emergency stop signal input from an external source. The inverter will stop when terminals JOG/OHSD open.

- Frequency setting voltage bias 21
- ► Frequency setting voltage gain 22

 The output frequency (ratio) for the

The output frequency (ratio) for the frequency setting signal (DC 0 to 5V) can be set freely.


★When setting the bias and gain, the frequency setting signal need not be input.



(Note)
When using terminal
JOG/OH
as an "external thermal ralay input", set
Pr.17 to "1"

(Note)

 Select terminal JOG / OH with input terminal function selection 60



● Stall prevention operation levie 23

An overload (excessive torque) can be prevented when driving a motor with a capacity smaller than the inverter by changing the stall prevention operation current level. This will also function during acceleration/deceleration. The operation current level is set with setting values (codes).

Setting value	Operation level	Setting value	Operation level	Setting value	Operation level
1	110%	5	150%	9	190%
2	120%	6	160%	10	200%
3	130%	7	170%		Stall prevention
4	140%	8	180%	0	is not activated.

[Factory setting] 5 (150%)

- . The operation level % indicates the ratio to the inverter rated output current
- Multi-speed setting 24. 25, 26, 27 → Refer to 3-speed setting 4
- Speed display 37

The monitor display can be changed from frequency (Hz) to the speed of the load axis or to the line speed (m/min)

Example

(Line speed display)

• For 55m/min at 60Hz

Setting value 0	Output frequency (Hz) display
Setting value 0.1 to 999	Display of load speed*

[Factory setting] 0

Setting value → 5 5

* Input the speed during 60Hz.
The display may not match the actual speed due to the effect of motor slippage. When the load speed display has been selected, any function to be set in frequency (Hz) must be set in frequency.


● Up-to-frequency sensitivity 42

An output signal is available whenever the output frequency reaches a value selectable between ±100% of the operating frequency. (Setting from ±1% is possible)

[Factory setting] ····· 10%

(Note)

Always set the speed at 60Hz. An input out of the range 0.1 to 999 is not possible.




• Output frequency detection 43

The frequency to be detected can be set between 1 to 120Hz. When the output frequency exceeds this frequency, the terminals FU-SD will become the L level, and when lower, will become the H level. This can be used as a signal for actuation and release of a mechanical brake.

[Factory setting] 6Hz

● Output frequency detection during reverse rotation 44

The timing for the electromagnetic brake operation during forward rotation (lifting) and reverse rotation (lowering) can be changed. The factory setting is "---" that detects output frequency of 6Hz for both forward and reverse rotation.



value 44

L level

Output signal

FU-SD

rotation

L level

H level

Pr.43 set value.

Output

frequency


● No.2 acceleration / deceleration time 46

The No.2 acceleration / deceleration time can be selected with an external contact signal. To do so, set Pr.46 and close terminals RT and SD. *1

When using the terminal MRS/RT for the "No.2 function", set the No.2 acceleration / deceleration time 46 within the range of "0 to 999". MRS (output stop function)

will be applied if the setting is "---".





To set deceleration time different from acceleration time, set function
 No. 46 as the acceleration time and 47 as the deceleration time.

(Note)

- *1 Terminal MRS/RT is selected with the input terminal function selection [60].
- *2 If function No. 47 is set to "---" (factory setting), the acceleration/deceleration time will be the same as that set in 48.

[Factory setting]

No.2 acceleration/deceleration time ······ *---* (terminal MRS/RT has output stop function)
No.2 deceleration time ······· *---*

• Retry selection 50

This is set to automatically reset the inverter when an inverter alarm occurs so that operation is resumed and continued. "OPT" will display during the retry operation.

Setting value 0	No retry function
Setting value 1	Retry after regenerative overvoltage trip (OVT) only
Setting value 2	Retry after overcurrent trip (OCT) only
Setting value 3	Retry after regenerative overvoltage trip (OVT) and overcurrent trip (OCT).

[Factory setting] ····· 0

● No. of retries at alarm 51

Set the number of retries and select the alarm signal output or not at alarm occurrence.

Setting value	Alarm signal output during alarm	No. of retries
0	-	No retry
1 to 10	Not available	1 to 10
101 to 110	Available	1 to 10

[Factory setting] 0

• Retry execution wait time 52

The time to wait before restarting after an inverter alarm occurs can be set,

[Factory setting] ····· 1 sec.

● No. of retry execution time display clear 53


The cumulative number of restart times made by retry can be read through reading this parameter and it can be cleared by setting 0.

(Note)

- 1. The monitor display after retrying will be the operation frequency display.
- If an alarm other than that set in Pr.50 (retry selection) occurs during retry waiting, an alarm will display and the retry will stop.
- The inverter will automatically start operation after the time set in Pr.52 (retry execution wait time), and thus caution is required by the operators when using this function.

● Frequency monitor reference 55 Current monitor reference 56

Terminal FM provides the frequency or current monitor function. Set the frequency or current value which is referenced for monitor in Pr.55 or Pr.56. (The frequency or current can be selected with Pr.70 (FM output terminal function selection).)



Remote setting function selection 59


The functions for terminals X1, X2 and X3 can be changed to the remote setting input function by setting 1 in Pr.60 (input terminal function selection). This allows the acceleration, deceleration and setting clear setting operations in the remote setting box FR-FK (optional) to be done just with parameter settings.

Pr. 59	Operation description				
setting value	Remote setting function	Frequency setting value storage function (Note)			
0	V	ν			
1	ν	-			

ー: No function レ: Function available

(Note)

If the terminals of acceleration-SD and deceleration-SD are left open for approximately one minute or longer, the operation frequency setting value of that point will be registered in the memory. Operation will restart with that setting value even if the power supply is turned off and on once.



(Note)

The frequency setting value up/down times with the acc./dec. operation are set in Pr.46 (No.2 acceleration/deceleration time) and Pr.47 (No.2 deceleration time), but the output frequency acc./dec. times in Pr.7 and Pr.8.

Therefore, the actual acc./dec. times become the longer setting values respectively.

● Input terminal function selection 60

The functions of terminals (X1, X2, X3) can be selected from the following nine types.

	Setting value										
Terminal	0	1	2	3	4	5	6	7	8		
X1	RH	Acceleration	RES	RH	RH	RH	RH	RH	RH		
X2	RM	Deceleration	MRS/RT	RM	RM	RM	MRS/RT	JOG/OH	MRS/RT		
ХЗ	RL	CLR	JOG/OH	JOG/OH	MRS/RT	RES	RES	RES	JOG/OH		
	Multi speed	Remote setting									

(Note)

This parameter cannot be written during operation (writing is possible only when stopped).

Refer to the following page for the functions selected with the X1, X2 and X3 input terminals.

List of function selections

Pr. 60	Mode	X1	X2	X3	Function	Related parameters
		OFF	OFF	OFF	Frequency reference 0 to 5V	T
	l i	ON	OFF	OFF	3-speed setting (high)	Pr. 4
		OFF	ON	OFF	3-speed setting (middle)	Pr. 5
^	Multi-	OFF	OFF	ON	3-speed setting (low)	Pr. 6
0	speed	OFF	ON	ON	Multi-speed setting (4th speed)	Pr.24
	111000	ON	OFF	ON	Multi-speed setting (5th speed)	Pr.25
		ON	ON	OFF	Multi-speed setting (6th speed)	Pr.26
	ĺ	ON	ON	ON	Multi-speed setting (7th speed)	Pr.27
		OFF	OFF	OFF	0 to 5V input setting	_
	1 [ON	OFF	OFF	Frequency rise	T -
		OFF	ON	OFF	Frequency lower	
	Remote	OFF	OFF	ON	Frequency setting clear	_
1	setting	OFF	ON	ON	Frequency setting clear	_
	1,,,,,,,	ON	OFF	ON	Frequency setting clear	_
		ON	ON	OFF	No operation	
		ON	ON	ON	Frequency setting clear	—
	RES	OFF	OFF	OFF	0 to 5V input setting	_
2	MRS/OH	ON	OFF	OFF	RES	-
	JOG/DH	OFF	ON	OFF	MRS/RT	Pr.46

Pr. 60	Mode	X1	X2	Х3	Function	Related perameters
	RES	OFF	OFF	ON	JOG/OH	Pr.17
		OFF	ON	ON	MRS/RT, JOG/OH	Pr.17, Pr.46
2	MRS/OH	ON	OFF	ON	RES	
	JOG/OH mode	ON	ON	OFF	RES	_
	moge	ON	ON	ON	RES	
		OFF	OFF	OFF	0 to 5V input setting	_
		ON	OFF	OFF	3-speed setting (high)	Pr. 4
	JOG/OH	OFF	ON	OFF	3-speed setting (middle)	Pr. 5
3	Multi- speed mode	OFF	OFF	ON	JOG/OH	Pr.17
		OFF	ON	ON	JOG/OH	Pr.17
		ON	OFF	ON	JOG/OH	Pr.17
		ON	ON	OFF	Multi-speed setting (6th speed)	Pr.26
		ON	ON	ON	JOG/OH	Pr.17
	MRS/RT Multi- speed mode	OFF	OFF	OFF	0 to 5V input setting	_
		ON	OFF	OFF	3-speed setting (high)	Pr. 4
		OFF	ON	OFF	3-speed setting (middle)	Pr. 5
4		OFF	OFF	ON	MRS/RT	Pr.46
7		OFF	ON	ON	MRS or middle speed, RT	Pr. 5 , Pr. 46
		ON	OFF	ON	MRS or hight speed, RT	Pr. 4, Pr.46
		ON	ON	OFF	Multi-speed setting (6th speed)	Pr.26
		ON	ON	ON	MRS or 6th speed, RT	Pr.26, Pr.48

Pr. 60	Mode	X1	X2	X3	Function	Related parameters
		OFF	OFF	OFF	0 to 5V input setting	
		ON	OFF	OFF	3-speed setting (high)	Pr. 4
	RES	OFF	ON	OFF	3-speed setting (middle)	Pr. 5
5		OFF	OFF	ON	RES	
5	Multi- speed	OFF	ON	ON	RES	
	mode	ON	OFF	ON	RES	
		ON	ON	OFF	Multi-speed setting (6th speed)	Pr.26
		ON	ON	ON	RES	
	MRS/RT	OFF	OFF	OFF	0 to 5V input setting	
		ON	OFF	OFF	3-speed setting (high)	Pr. 4
		OFF	ON	OFF	MRS/RT	Pr.46
6		OFF	OFF	ON	RES	
0	Multi-	OFF	ON	ON	RES	_
	speed	ON	OFF	ON	RES	
	mode	ON	ON	OFF	MRS or high speed, RT	Pr. 4 , Pr.46
		ON	ON	ON	RES	

Pr. 60	Mode	X1	X2	X3	Function	Related parameters
	JOG/OH	OFF	OFF	OFF	0 to 5V input setting	
		ON	OFF	OFF	3-speed setting (high)	Pr. 4
	•	OFF	ON	OFF	JOG/OH	Pr.17
7	RES	OFF	OFF	ON	RES	_
,	Multi-	OFF	ON	ON	RES	
	speed	ON	OFF	ON	RES	-
	mode ON	ON	ON	OFF	JOG/OH	Pr.17
		ON	ON	ON	RES	_
		OFF	OFF	OFF	0 to 5V input setting	
	MRS/RT	ON	OFF	OFF	3-speed setting (high)	Pr. 4
	JOG/OH Multi- speed mode	OFF	ON	OFF	MRS/RT	Pr.46
8		OFF	OFF	ON	JOG/OH	Pr.17
8		OFF	ON	ON	MRS/RT, JOG/OH	Pr.46, Pr.17
		ON	OFF	ON	JOG/OH	Pr.17
		ON	ON	OFF	MRS or high speed, RT	Pr. 4 , Pr. 46
		ON	ON	ON	MRS/RT, JOG/OH	Pr.46, Pr.17

(Note) ON : Short with terminal SD.

OFF: Open

(When function OH has been selected (1 in Pr.17), ON indicates open.)


● Allocation input terminals 61

The function of the input to terminals RH, RM, RL, OH, STOP, MRS, RT, and JOG can be allocated from the 8 functions in the table below.

Pr. No	Setting range	Setting Unit	Factory Setting	Function
61	0 to 999	1		——— : The functions are as terminal name.
				1 : RH
	,			2 : RM
				3 : RL
			ļ į	4 : OH
				5 : STOP
	ļ			6 : MRS
i	ľ			7 : RT
	1		1	9 : JOG

Setting is made by a 3 digit number set in Pr61, each digit represents the function to be allocated to individual terminals. (note1)

contorol terminals




- Note 1) When two or more digits of Pr.61 are set to the same number, the function is actived by turning on one of them.
- Note 2) When a value "0 to 999" is set in Pr.61, the set values of Pr.60 is ignored.

● FM output terminal function selection 70

Terminal FM provides pulse output and is used to connect an indicator that monitors frequency or current. (Refer to p.56. 57) The frequency or current can be selected through this parameter.

Setting value 0	Output frequency
Setting value 1	Motor current (output current)



[Factory setting] 0

(Note)

When the frequency has been selected, terminal FM output can be adjusted with Pr.55, when the current has been selected, it can be adjusted with Pr.58.

● Tone modulation selection 71

(This parameter is a function number for the low-acoustic noise series)

The tone control that changes the motor tone can be selected with the key pad.

Setting value	Tone selection
0	No tone control
1	Tone control

- 7 The tone control changes the motor noise from a metallic tone to a composite sound that is easy to listen to.

 When the tone control is selected, the motor tone will be

 - easy to listen to even with the same carrier frequency.

 The tone control is effective when the carrier frequency

[Factory setting] 0

● PWM carrier frequency 72

(This parameter is a function number for the low-acoustic noise series)

The PWM carrier frequency is 7.0 kHz but this frequency can be changed with Pr. 72 if necessary in relation to the load or motor resonance frequency. (Note) If the PWM carrier frequency is lowered, the motor noise will increased, but the noise generated from the inverter and the leakage current will decrease. (Refer to the precautions on page 58 when setting the PWM carrier frequency to

a higher value,)

(Note)

This parameter can be read and written when the PWM mode Pr.10 setting is "---".

[Factory setting] 7.0 kHz

● Stop key function 75

When "stop key" is pressed in external operation mode, motor is decelerated to a stop.

Setting value	Stop key function
0	The stop key only functions in PU op or countinel mode
14	When stop key is pressed in any operation mode, motor stops.

Note 1) To restart after "stop key stopping" in ext mode.

- ① Turn off the start signal (STF/STR) after the motor has stopped.
- 2 Press the "SET" key.
- 3 Turn on the start signal (STF/STR).


Note 2) When motor is stoped by using the stop key in external operation mode, "E 0" is displyed.

Output signal selection [76]

The inveter running, up-to-frequency or frequency detection signal can be selected for the open collector output signal (terminal RUN/SU/FU).

Setting value 0	Inverter running (RUN)
Setting value 1	Up-to-frequency (SU)
Setting value 2	Frequency detection signal (FU)

[Factory setting] 0



(Note) The inverter will be damaged if the voltage application direction is mistaken.
Also, take care to prevent mis-wiring such as of the diode connection direction.

● Parameter write prohibit selection 77

Prevents parameters from being written via the key pad.

Setting value	Write prohibition function
0	Parameter writing permitted (during operation and stop)
1	Parameter write prohibited (Note)

[Factory setting] ····· 0

(Note)

Parameter No. [77] can be written in. Er1 will display when writing of other parameters is attempted. (Release the error display with the MODE key.)

● Reverse rotation prevention selection 78

This is set to prevent reverse rotation fault resulting from the mis-input of the start signal.

Setting value	Rotation direction
0	Both forward/reverse rotation
1	Reverse rotation prohibited
2	Forward rotation prohibited (Note)

(Note)

The inverter will drive the motor in reverse with the RUN key when set to "2".

[Factory setting] (

This function is valid for both the key pad operation and external operation.

• Operation mode selection 79

The inverter operation modes include operation with external signals and operation with key pad. Operation can be limited to one mode or can be carried out with both modes.

Setting value 1	Operation only with key pad
Setting value 2	Operation only with external signals
Setting value 3	Operation frequency ··· Set with key pad (direct setting or A keys) Start signal ··· External signal input (STF, STR terminals)
Setting value 4	Operation frequency ··· External signal input (DC0 to 5V between terminals2-5) Start signal ··· Input with key pad (RUN key) (Note) 4.

[Factory setting] ····· 1

(Note)

- 1. This parameter cannot be rewritten during operation. Er2 will display if writing is attempted.
- Setting values 3 and 4 are set to use the external signals and key pad operation for the operation frequency setting and start signals.
- 3. When set to 3, the operating frequency is set via key pad and analog signal input is ignored.
- When set to 4, the operating frequency is set via analog signal input, multi-speed setting or JOG frequency setting.

● Parameter clear/calibration CLr

The parameter-all-clear or frequency setting signal calibration mode can be selected. The parameter-clear cannot be executed during operation, and Er2 will display.


Setting value	Details
0	Not executed.
1	Parameters are all cleared (initialized). *
2	Frequency setting signal calibration mode is selected.

* Parameter No. 77, 21, 22 cannot be cleared.

- The following adjustment can be performed by selecting the calibration mode (setting value 2).
 - (Refer to page 55 for details.)
 - C-1 Display: Frequency meter scale calibration
 - C-2 Display: Frequency setting bias calibration (Pr.21 will be rewritten simultaneously.)
 - C-3 Display: Frequency setting gain calibration (Pr.22 will be rewritten simultaneously.)


If the difference of the input voltages for the bias and gain calibration is less than 0.5V, the calibration error will occur (Er3 will display).

O Example of parameter-all-clear/calibration operation



• Frequency meter scale calibration C-1


Allows a meter connected to FM to be calibrated through this parameter, without a calibration potentiometer. Using Pr. C-1, press or wkey to vary pulse train frequency. Then average of output voltage changes, and the meter is calibrated.



(Note)

- 1. Terminal FM output is a 1440Hz at output frequency of 60Hz as the factory setting.
- If terminal FM-SD is measured with a tester, approx. 5V (average value) will be indicated at the max. Output frequency. (When indicator is not connected.)


FM terminal pulse output specifications



- Frequency setting bias calibration C-2
- Frequency setting gain calibration [C-3]
 Allows the output frequency to be set in relation to the frequency setting signal (DC 0 to 5V).

(Bias)

The output frequency for the setting signal input between terminals 2-5 will be set.




(Gain)

The output frequency for the setting signal input between terminals 2-5 will be set. If the input signal is 0V, it is judged to be 5V input.


(Note)

 When this C-2 or C-3 is specified, value set for "frequency setting voltage bias" (function No. 21) or "frequency setting voltage gain" (function No.22) will be automatically rewritten.

Remarks To set frequency with current input (4 to 20mA)




- Place a resistor between 2-5, and convert the current into a voltage. (4 to 20ma → 1 to 5V)
- Adjust C-2 (bias) as below.
 (Pr.21 will be rewritten simultaneously.)



Precautions

- It is necessary to accept a reduction of load torque when setting the PWW carrier frequency to a higher value.
- (1) When setting the PWM carrier frequency (Pr.72) to 7.1kHz or more to lower the motor acoustic noise, the rated output should be derated as shown on the right. Also change the electronic thermal relay (Pr. 9) setting.
- (2) If the PWM carrier frequency is increased, the acoustic noise from the motor will lower, but the noise generated by the inverter and the leakage current will increase.




PWM carrier frequency (kHz)

2. Noise

There is noise that enters from outside and causes the inverter to malfunction and that which is generated from the inverter and causes the peripheral equipment to malfunction. The inverter is designed so that it is not easily affected by noise, but as it is an electronic device which handles weak signals, the following general countermeasures will be required.

- ◆ General countermeasures
 - Avoid laying the inverter's power cables (input/output) in parallel with the signal wires and avoid bundling the power cables and signal wires.
 - Use twisted pair shield wires for the connection wires with the sensor and for the control signal wires. Connect the sheath of the shield wire to terminal SD.
 - Use one-point grounding for the inverter and motor, etc.


◆Example of noise countermeasures



3. Leakage current

Leakage current will flow through stray capacity which exists between the ground and a cable, motor, etc. The value of the leakage current depends on the cable length, wiring method and inverter carrier frequency, and will increase when using a low-acoustic noise inverter, so use the following countermeasures.

(1) Leakage current to the ground The leakage current will not affect only the inverter but may pass into other equipments through the grounding cables and may cause a leakage breaker or relay unnecessary trip.



■ Countermeasures


- Lower the inverter's carrier frequency (Pr. 72). Note that this will increase the motor acoustic noise.
- Use a leakage breaker that corresponds to high harmonics and surges
 (Mitsubishi New Super NV Series, etc.) for the inverter or other lines when
 using the low-acoustic noise model (with high carrier frequency).

(2) Leakage current across the line

The harmonics of leakage current which flows through stray capacity across the inverter output lines may cause an external thermal overload protector trip. When the cable length is long (50m or more), the ratio of leakage current to the motor's rated current becomes large, and trip is liable to occur.

■ Countermeasures

- Use the electronic thermal relay on the inverter.
- Lower the carrier frequency.
 Note that this will increase the motor noise.



Against the trip due to leakage current, the preferred method of motor overload protection is a thermistor protection with temperature detectors in the motor or motor protection switch with bi-metal release, etc.

7. SPECIFICATIONS

■ Standard series

Model f	FR-U120F(C), -(UF)	0.1K	0.2K	0.4K	0.75K	1.5K	
Applica	ble motor capacity (kW)/(HP) *1	0.1/1/8	0.2/1/4	0.4/1/2	0.75/1	1.5/2	
	Rated capacity (kVA) *2	0.3	0.5	0.9	1.5	2.6	
	Rated output current (A)	0.8	1.4	2.4	4.1	7	
Output	Overload current rating *3	150% 60 s	ec. 200% 0	5 sec. (inver	se time char	racteristic)	
.,	Rated output voltage *4	(The 1.5k		nase 200 to 2 fully enclose		0 to 220V.)	
	Rated input AC voltage	3-phase 200 to 230V, 50/60Hz (The 1.5k model of the fully enclosed type is 3-phase 200V 50Hz, 3-phase 200 to 220V 60Hz.)					
Power supply	Tolerable AC voltage fluctuation	(The 1.5	k model of	253V, 50/ the fully endo 242V 60Hz	closed type	is 180 to	
	Tolerable frequency fluctuation	± 5 %					
	Power supply capacity (kVA) *5	0.4	0.7	1.2	2.1	4.0	
Enclosure		Enclosed type (1P20) Fully enclosed type is 1P40.)					
Cooling method		(The 1.5k i		(Without of			
Weight (kg)		0.5	0.6	0.7	0.9	1.7	

■ Low-acoustic noise series

Model F	R-U.120-NF(C), -(UF)	0.1K	0.2K	0.4K	0.75K	1.5K	
Applica	ble motor capacity (kW)/(HP) *1	0.1/1/8	0.2/1/4	0.4/1/2	0.75/1	1.5/2	
-	Rated capacity (kVA) #2	0.3	0.5	0.9	1.5	2.6	
	Rated output current (A)	0.8	1.4	2.4	4.1	7	
Output	Overload current rating #3	150%	80 sec. 20	9% 0.5 see	c. (invers	time characteristic)	
	Rated output voltage *4	3	-phase 20	00 to 230		3-phase 200 to 220V (The 1.5K model of UF type is 200 to 230V)	
	Rated input AC voltage	3-phase 200 to 230V, 50/60Hz				3-phase 200V, 50Hz 200 to 220V, 60Hz (UF type is 200V, 50Hz 200 to 230V, 50Hz)	
Power supply	Tolerable AC voltage fluctuation	180 to 2253V, 50 / 60Hz 180 to 2253V, 50H 180 to 2253V, 50H 180 to 2253V, 50H 180 to 2253V, 50H 180 to 235V, 50H					
	Tolerable frequency fluctuation	± 5 %					
	Power supply capacity (kVA) *5	0.4	0.7	1.2	2.1	4.0	
Enclosure		Enclosed type (IP20) (Fully enclosed type is IP40.)					
Cooling	method	Self-coo	ling (Wit	hout cool	ing fan)	Fan cooled	
Weight	(kg)	0.6 *7	0.7 *7	0.9 *7	1.7	5-1. 9 %*	

(Note) The power supply specifications for 1.5K differ from those for 0.75K or less, caution should be observed.

■ Single phase 100V input series

**	Standard series FR-U110WF, -(UF)	0.1K	0.2K	0.4K	
Model	Low-acoustic noise series FR-U110W-NF, -(UF)	0.1K	0.2K	0.4K	
Applica	ble motor capacity (kW)/(HP) #1	0.1/1/8	0.2/1/4	0.4/1/2	
	Rated capacity (kVA) *2	0.3	0.5	0.9	
	Rated output current (A)	0.8	1.4	2.4	
Output	Overload current rating *3	150% 60 sec. 2009	6 0.5 sec. (inverse tir	ne characteristic)	
	Rated output voltage *4	3-phase 200 to 220V *6 (The model of UF type is 200 to 230V)			
	Rated input AC voltage	Single phase 100V 50Hz, 100 to 110V 80Hz (UF type is 100 to 115V, 50/60Hz)			
Power supply	Tolerable AC voltage fluctuation	90 to 110∨ 50Hz, 90 to 121∨ 60Hz (UF type is 90 to 126.5∨, 50∕60Hz)			
pp.,	Tolerable frequency fluctuation	5 %			
	Power supply capacity (kVA) *5	0.5	0.9	1.5	
Enclosure			Enclosed type (IP20))	
Cooling	method	Self-co	oling (without cooling	ng fan)	
Weight	(kg)	0.6	0.7	0.9	

■ Single phase 200V input series

	0.1K	0.2K	0.4K	0.75K		
Low-acoustic noise series FR-U120S-N -F, -(UF)	0.1K	0.2K	0.4K	0.75K		
ble motor capacity (kW)/(HP) *1	0.1/1/8	0.2/1/4	0.4/1/2	0.75/1		
Rated capacity (kVA) *2	0.3	0.5	0.9	1.5		
Rated output current (A)	0.8	1.4	2.4	4.1		
Overload current rating *3	150% 60 sec.	150% 60 sec. 200% 0.5 sec. (inverse time characteristic)				
Rated output voltage *4	3-phase 200 to 220V (The model of UF type is 200 to 230V)					
Rated input AC voltage	Single phess 200V 50Hz, 200 to 220V 80Hz (UF type is 200 to 230V, 56/80Hz) 180 to 220V 50Hz, 180 to 242V 60Hz (UF type is 180 to 253V, 50/80Hz) 5 96					
Tolerable AC voltage fluctuation						
Tolerable frequency fluctuation						
Power supply capacity (kVA) +5	0.5	0.9	1.5	2.5		
Enclosure		Enclosed type (IP20)				
method	Self-cooling (without cooling fan)					
(kg)	0.6	0.7	0.9	1.7		
֡	Low-acoustic noise series FR-U120S-N -F,-(UF) ble motor capacity (kW)/(HP) *1 Rated capacity (kVA) *2 Rated output current (A) Overload current rating *3 Rated output voltage *4 Rated input AC voltage Tolerable AC voltage fluctuation Tolerable frequency fluctuation Power supply capacity (kVA) *5 re method	Low-acoustic noise series FR-U120S-N -F, -(UF) ble motor capacity (kW)/(HP) *1 Rated capacity (kVA) *2 Rated output current (A) Overload current rating *3 Rated output voltage *4 Rated input AC voltage Tolerable AC voltage fluctuation Tolerable frequency fluctuation Power supply capacity (kVA) *5 re method 0.1K 0.1/1/8 0.8 150% 60 sec. Single phase 200V Single phase 200V 50H 0.5 50 50 50 50 50 50 50 50 50 50 50 50 50	Low-acoustic noise series FR-U120S-N -F,-(UF) 0.1K 0.2K	Low-acoustic noise series FR-U120S-N -F, -(UF) 0.1K 0.2K 0.4K 0.4K 0.1/20S-N -F, -(UF) 0.1/1/8 0.2/1/4 0.4/1/2 0.3 0.5 0.9 0.8 1.4 2.4 0.8 1.4 2.4 0.8 1.4 2.4 0.9		

(Note)

- *1. The maximum applicable capacity is for the Mitsubishi standard motor 4P. This may not apply to the 6P motor, so refer to the rated output current.
- *2. The rated capacity is shown for the output voltage of 220V (60Hz).
- #3. The overload current value % shows the ratio to the inverter's rated output current.

#4. The output voltage cannot exceed the power supply voltage.

- *5. The necessary power capacity will differ according to the impedance on the power supply side (including reactor and
- power white on input side). Presers a power supply capacity higher than the noted value.

 8. If a load is applied on the motor, the output voltage will drop approx. 10 to 15%, so the load must be reduced which using a general purpose motor.
- *7. The low-accustic noise, fully enclosed type will be 0.1kg heavier.

■ Common specifications

	Control met	nod	Sinusoidal wave PWM control *10		
	Output frequ	ency range	0.5 to 120Hz (starting frequency fixed at 0.5Hz)		
	Frequency setting	Digital input	0.1Hz (less than 100Hz), 1Hz (100Hz and more) with key pad operations		
2	resolution	Analog input	1/500 of maximum setting frequency		
specifications	Frequency	Digital input	Within $\pm 0.5\%$ of set output frequency (-10 to $+50\%$) with key pad operations		
j i	stability	Analog input	Within ±1% of maximum output frequency (25℃±10℃)		
eds	Voltage/free	uency characteristics	Base frequency between 50 and 120Hz selectable		
<u> 5</u>	Torque boos	t	Manual torque boost 0 to 15% selectable		
Control	Acceleration deceleration characteristics		0, 0.1 to 999 sec. selectable (acceleration / deceleration set separately)		
	Braking	Regenerative *8	0.1K, 0.2K150% or more, 0.4K, 0.75K100% or more, 1.5K50% or more		
1	torque	DC injection	3Hz or less Operation time, operation voltage adjustable		
	Stall prevent	ion operation level	Operation current level (110 to 200%) selectable		
	Frequency se	tting signal	DC 0 to 5V		
		Starting signal	Forward/reverse rotation commanded separately		
Operation specifications	Input signal	Input signal selection (X1, X2, X3)	Select RH, RM, RL, JOG/OH, MRS/RT, RES, accelerations, deceleration and CLR from the combination shown on page 44.		
era		Alarm	1c contact output		
O &	Output signal	Operation status	Select from operating (RUN), frequency reached (SU) and frequency detection (FU)		
		Monitor *12	For analog (1mA full scale) or digital (1440Hz/60Hz) meter		
			^^		

Display	Key pad	Operation status	Output frequency, output current #11, operation speed selectable				
Dis		Alarm	Alarm code when protective function has been activated.				
Pro	Protection/warning function		Overcurrent shut down (during acceleration/deceleration/constant speed), regenerative overvoltage shut off, electronic thermal overload, stall prevention				
	Ambient te	mperature	-10 to +50℃ (with no freezing)				
Ħ	Ambient hu	ımidity	90% RH or less (with no dew condensation)				
Ē	Storage ten	nperature *9	-20 to +65℃				
Environment	Atmosphere		Indoors with no corrosive or flammable gases, oil mist or dust				
ш	Altitude/v	ribration	Less than 1660m above sea level, 5.9m/S²(0.8G) or less				

(Note)

*8. The braking torque shows the short time average deceleration torque when the motor without load is decelerated in the shortest time from 60Hz (changes due to motor's loss), and is not the continuous recenerative torque. For deceleration from a frequency that exceeds the base frequency, the average deceleration torque value will decrease. A brake resister is not built-in and cannot be externally installed.

1.5K is not available for the single phase input series.


*9. This is a short time temperature for during transportation, etc.

- *10. The low-acoustic noise series use the high carrier frequency sinusoidal PWM control. #11. The output current is displayed only while the SET key is being pressed.
- *12. Select the monitor of either the output frequency or motor current via the key pad (function No.70).
- *13. Short Cirunit Ratings

The drive is suitable for use on a circuit capable of delivering not move than * RMS symmetrical Amperes.

HP rating	*
0 to 1	1,000
2	5,000

III Terminal wiring diagram



- *1. Short-circuit between terminals STR-SD to perform reverse rotation with key pad operation. When Pr.78 is set to "2" (forward rotation prohibited), the motor will rotate in the reverse direction with the key pad operation even if STR-SD are not short circuited. (When Pr.79 is 1 or 4)
- *2. Valid when parameter No.79 is set to "2" or "3" via key pad.
- *3. Valid when parameter No.79 is set to "2" or "4" via key pad.
- *4. Input terminals X1, X2 and X3 are selection input terminals, specified with Pr.60. (Refer to page 44.)
- *5. 2W1kQ is recommended if the frequency setting is to be changed frequently.
 - (Note 1) For single phase 100V power input series.
 - (Note 2) For single phase 200V power input series.
 - (Note 3) When using the low-acoustic, fully enclosed type multi-function series, or 0.1K to 0.75K models of the low-acoustic noise, fully enclosed type series.
 - (Note 4) When using the low-acoustic noise, fully enclosed type or 1.5K model of the low-acoustic noise, fully enclosed type series.

■ Explanation of terminal specifications

Termin	i symbol	Terminal name	Details
	R. S. T	AC power input terminal	Connect to a commercial power supply.
Main circuit	u, v, w	Inverter output terminal	Connect a 3-phase motor.
	<u></u>	Grounding terminal	Ground for inverter body. Ground this,
	STF	Forward rotation starting terminal	Contact input terminal for the forward run command. The motor will forward rotate when STF-SD are short circuited, and will stop when released.
	STR	Reverse rotation starting terminal	Contact input terminal for the reverse run command. The motor will reverse rotate when STR-SD are short circuited, and will stop when released.
Control circuit (Input	SD (Note 1)	Contact input common terminal	Common terminal for the contact input signal. This is not insulated from the frequency setting input common terminal 5.
signal)	10	Power supply teminal for frequency setting	DC5V. Tolerable load current 10mA.
	2	Frequency setting terminal (Voltage signal)	Output frequency will be the maximum when DC 5V is input, and the input/output will be in proportion. Input resistance : 10k Ω Max. tolerable input voltage : 10V

Termin	al symbol	Terminal name	Details
	5	Frequency setting input common terminal	Common terminal for the frequency setting signal. This is not insulated from the contact input common SD.
	X1, X2, X3	AUX input terminal	The terminal specifications will change according to the parameter No.60 setting. (Refer to page44 for the selection). (The specification will be RH, RM, RL, JOG/OH, MRS/RT, RES, acceleration, deceleration or CLR.)
Control	₽C	External transistor common terminal	When connecting to the transistor output (open collector output) of a sequencer, etc., if the external power common for transistor output is connected to this terminal, malfunctions caused by backflow currents can be prevented. (Refer to page 16.)
(Input signal)		Multi-speed selection terminal	A maximum of seven speeds selectable with the combination of RH-SD, RM-SD and RL-SD short circuiting.
	JOG/OH (Note 2)	JOG mode selection or external thermal relay	JOG operation is selected when terminals JOG-SD turn ON, and jog operation starts with the start signal (STF or STR). The thermal relay contact input terminal can be selected for stopping the inverter by operating the externally connected thermal relay.
,		Output stop or No.2 acceleration / deceleration time selection	The inverter output will stop when MRS-SD are short-circuited. This teminal is set with Pr.46 for the No.2 acceleration/deceleration time selection (RT). The No.2 acceleration/deceleration time can be selected by short-circuiting between RT-SD.

Termina	l symbol	Terminal name	Details
	RES (Note 2)	Reset terminal	This is used to reset the hold state during operation of the protection circuit. Short-circuit between RES-SD for 0.1sec. or longer, and then open. (Resetting is also possible with the RESET key on the key pad.)
Control circuit (Input signal)	Acceler- ation, deceler- ation, CLR (Note 2)	Remote setting terminal	These can provide remote operator control for the following functions. When terminals acceleration-SD are short-circuited, the frequency will increase, and will decrease when terminals of deceleration-SD are short-circuited. When CLR-SD are short-circuited, the speed will return to the reference speed (frequency set with frequency setting signal or input from key pad.) The frequency increment/decrement speed is set with Pr.46 (acceleration) and Pr.47 (deceleration).
Control	A, B, C	Alarm output terminal	1c contact output that indicates that the inverter protection circuit has functioned and output has stopped. B-C opened, A-C closed during alarm B-C closed, A-C opened during normal operation Contact capacity AC230V 0.3A, DC30V 0.3A
circuit (Output signal)	FM	Display meter connection terminal	The output is set to be approximately 5V at 60Hz without display meter, and will be proportional to the output frequency. The output voltage has a pulse waveform, so a digital display meter can be connected. Pulse specifications: 8V (peak), 1440Hz/60Hz. (Refer to page 55.56.57)

Termina	Terminal symbol Terminal name		Details
Control circuit (Output signal)	RUN SU FU	Operation state output terminal	One of the inverter operating (RUN), frequency reached (SU) or frequency detection (FU) output selectable. • Inverter operating (RUN) is at L level when above the starting frequency, and is at H level when stopped or during DC braking. • Frequency reached (SU) is at L level when the output frequency reaches the set frequency, and is at H level when stopped or during acceleration/deceleration. • The frequency detection (FU) is at L level when the output frequency exceeds the set detection frequency, and is at H level when lower than the set frequency. Open collector output tolerable load: DC24V 0.1A
	SD (Note 1)	Output common terminal	Common terminal for RUN, SU, FU, FM

(Note)

- *1 The input and output common terminal SD are connected in the inverter.
- *2 This terminal is selected with the Pr.60 setting. (Refer to page 44.)
 (The X1, X2, X3 selection input terminal will change to the selected function.)

The terminals are screwless type, so prepare a small flat-tip screwdriver (tip width 2.5 to 3mm) before wiring.

■ Protective function

The following protection functions are built in to protect the inverter. If the protective circuit functions, the inverter output will stop, alarm will display, and alarm signal will be output. The motor will coast to a stop. The inverter must be reset to resume operations.

Function name		Details		Display (Key ped)	
Overcurrent shut down		The protective circuit functions during acceleration acceleration, deceleration or constant		130	(OC1)
		speed when the motor output current exceeded approximately 200% of the	During constant speed	00.5	(OC2)
		rated current, and the inverter output stops.		003	(OC3)
Regenera overvolta shut dow	ge	The protective circuit functions when th circuit of the inverter exceeds the trip polynergy during braking, and the inverter	oint with the regenerative	סטר	(OVT)
Overload shut down (Electronic thermal relay in the inverter detects overheating of the motor caused by overload or the additional heating at low speeds due to fan action, and stops the inverter output. Install a thermal relay on the output side of the inverter when using a 6 or more pole motor or when groups of motors are connected to one drive.		rxn	(THM)		

Function	name	Details	Disp (Key	
(Libert Ollie	In- verter	The electronic thermal relay functions with the inverse time characteristic to protect the output translator when 150% or more of the inverter rated output current flows but the overcurrent abut down is not activated (under 200%).	far ((тнт)
External to		System can be designed to prevent drive operation when external motor overload protector or thermoswitch in the motor opens on an overtamperature condition. Even if the relay contact is automatically restored, the inverter will not restart unless reset.	פאר ((ОНТ)
EEPROM breakage		The output will stop when the EEPROM which stores the parameter set values breaks.	۶٤	(PE)
Stall prevention		When 150% (*2) or more of the inverter rated current flows to the motor during acceleration (or constant speed operation), this function stops increasing of frequency (or reduces frequency) until the load current decreases, to prevent the inverter from overcurrent tripping. When the load current has decreased below 150%, this function allows the inverter to return to and continue the previous operation. During deceleration, in contrast, if DC voltage in the inverter exceeds the rated value, this function stops reducing frequency to prevent the regenerative overvoltage shut off from being activated. When the regenerative energy becomes low, this function continues deceleration again.	ULT (When str due to th function constant operation	opped ns from a

Function name	Details		Display (Key pad)	
Insufficient voltage warning (*4)	The control circuit will not function properly if the inverter power voltage drops, and will also cause an insufficient motor torque and increased heat generation. The inverter output will stop when the power voltage drops below approx. AC 115V. Operation will resume when the power voltage is restored to a correct value.	Uu	(UV)	
In retry	Retry is executed when the retry function is selected, and that inverter alarm occurs. This indicates that the retry is functioning. (The display will show the time set in Pr.52 retry execution wait time.)	ספר	(OPT)	

(Note)

- *1. The heat cumulative data in the electronic thermal relay will be initialized when the inverter is reset.
- *2. The stall prevent operation current can be set freely. The default setting is 150%.
- *3. This functions only when the function "external thermal relay input selection" is set.
- *4. An alarm signal will not be output when this protective function activates. If the voltage is insufficient (main circuit DC voltage is 230V or less) when the power is turned on, " () () " will display for approximately 10 seconds and then the insufficient voltage display " () " will appear. (No key pad operation will be accepted during the display of " () () ".)

If the main circuit DC voltage is higher than standard tolerance when the power is turned on, the display " F_rU " will appear, and if the voltage does not lower within 10 seconds, the display " G_{r} " (overvoltage shut down) will appear.

• Retention of alarm output signal

If the he-fuse breaker on the inverter's power supply side is turned OFF when the protective function activates, the inverter control power supply will be lost, and the alarm output will not be held. If the output must be held, create a sequence that will hold the alarm output signal with an external equipment.

Alarm display

The display on the key pad will automatically change when the protective function operates. (Only during monitoring.)

Resetting methods


The inverter output stop state will be retained if the protective function operates, and the inverter will not restart unless it is reset. Turn the power off and on once or press the RESET key on the key pad. If the RES terminal is set with Pr.60 (input terminal function selection), resetting will be possible by opening reset terminal RES-SD after short-circuiting for approximately 0.1 second or more. If the short circuited state between terminal RES-SD is continued, " Fru " will display (light) and indicate that the reset state has been entered.

8. DIMENSIONAL OUTLINE DRAWING

■ Standard series FR-U120- -F, -(UF)

0.1 to 0.75K Installation screw M4 (Q'ty 3 mounting holes)

(Unit: mm)




Keyhole slot dimensions



Capacity	Α
0.1K	81
0.2K	86
0.4K	101
0.75K	121

*4.5 only for 0.1K.

1.5K Installation screw M4 (4 places) (Unit : ##)




(Note)

For 1.5K drive, heatsink is provided on the left and right and it will get HOT at heavy loads. Do not hold heatsink with bare hand.

■ Low-acoustic noise series FR-U120-N -F, - (UF)

0.1 to 0.4K Installation screw M4 (3 places)

(Unit: mm)




Keyhole slot dimensions



Α
86
101
121



(Unit: mm)



	Capacity	Α	В
į	0.75K	147	В
	1.5K	155	14

(Note)
The 1.5K drive comes equipped with a fan.


(Note)

For 0.75K and 1.5K drive, heatsink is standard on the left and right and it will get HOT at heavy loasd. Do not hold heatsink with bare hand.

■ Single phase 200V power input series FR-U120S- -F, - (UF)

0.1 to 0.4K Installation screw M4 (3 places)

(Unit: mm)



Keyhole slot dimensions


٠.	4.6
	4.6
	A -1
	7151
	TIT.
	1_10_1

Capacity	Α
0.1K	86
0.2K	101
0.4K	141

(Plate) For 1975K attau. Deeplak is centriant on the 1918 and high and it will get \$100 colour glascie.

(Unit: 48) Installation screw M4 (4 places) 0.75K 2- \$5 hole 110 (Note) For 0.75K drive, heatsink is standard on the left and right and it will get HOT at heavy loads.

■ Single phase 100V power input series FR-U110W- F, - (UF)



0.1 to 0.4K Installation screw M4 (3 places)


Keyhole slot dimensions


(Unit: mm)




Capacity	Α
0.1K	86
0.2K	121
0.4K	141

■ Fully enclosed type series FR-U120-FC






■ Multi-function low-acoustic noise, fully enclosed type series FR-U120-N -FC



(Unit: mm) 1.5K Installation screw M4 (4 places)



(Note) For 0.75 and 1.5K drive, heatsink is standard, (Note) The 1.5K drive comes equipped so the temprerature will rise by approx. 30 degrees depending on the usage conditions.

with a fan.

9. SELECTION OF PERIPHERAL DEVICES

■ Selection of peripheral devices

(The selection will differ according to the inverter power supply input specifications.)

Power	Motor output (kW)	tput Applicable inverter	No-fuse breaker (NFB) or	Magnetic contactor (MC)			Wining (mil)	
input			Leakage breaker (NV)	A area	B area	C area	R.S.T	u, v. w
	0.1	FR-U120-N0.1K-F(c), -(UF)	NF30 model, NV30 model 5A	S-K11	S-K 18	S-K20	2	2
	0.2	FR-U120-000.2K-F(c), -(UF)	NF30 model, NV30 model 5A	S-K18	S-K20	S-K29	2	2
3-phase 200∨	0.4	FR-U120-N0.4K-F(5)(UF)	NF30 model, NV30 model 5A	S-K18	S-K21	S-K21	2	2
2000	0.75	FR-U120-N0.75K-F(c), -(UF)	NF30 model, NV30 model 10A	S-K 18	S-K21	S-K21	2	2
	1.5	FR-U120-N1.5K-F(c), -(UF)	NF30 model, NV30 model 15A	S-K21	S-K25	S-K50	2	2
Single phase 200V	0.1	FR-U120S-N00.1K-F, -(UF)	NF30 model, NV30 model 5A	S-K18	S-K20	S-K20	2	2
	0.2	FR-U120S-N/0.2K-F, -(UF)	NF30 model, NV30 model 10A	S-K 18	S-K21	S-K21	2	2
	0.4	FR-U120S-N)0.4K-F, -(UF)	NF30 model, NV30 model 10A	S-K21	S-K25	S-K50	2	2
	0.75	FR-U120S-N)0.75K-F, -(UF)	NF30 model, NV30 model 15A	S-K21	S-K25	S-K50	2	2
Single phase	0.1	FR-U110W-N)0.1K-F, -(UF)	BH-K model, NV30 model 10A	S-K18	S-K21	S-K21	2	2
	0.2	FR-U110W-N10.2K-F, -(UF)	BH-K model, NV30 model 15A	S-K21	S-K25	S-K25	2	2
	0.4	FR-U110W-N)0.4K-F, -(UF)	BH-K model, NV30 model 20A	S-K21	S-K25	S-K50	2	2


Power	Motor	Applicable inverter	Power factor improve-	Low-acoustic noise	Fuse Rating	
input	output (kW)	model	ment AC reactor	output reactor	Class	Amp./Volt
	0.1	FR-U120-N0.1K-F(c), -(UF)	FR-BAL-0.4K (Note 4)	FR-BOL-9.4K	K5 or H	3A/250V
	0.2	FR-U120-000.2K-F(c), -(UF)	FR-BAL-0.4K (Note 4)	FR-BOL-0.4K	K5 or H	5A / 250V
3-phase 200V	0.4	FR-U120-940.4K-F(c), -(UF)	FR-BAL-0.4K	FR-BOL-0.4K	K5 or H	8A / 250V
200 7	0.75	FR-U120-040.75K-F(c), -(UF)	FR-BAL-0.75K	FR-BOL-0.75K	K5 or H	15A / 250V
	1.5	FR-U120-N1.5K-F(c), -(UF)	FR-BAL-1.5K	FR-BOL-1.5K	K5 or H	25A / 250V
	0.1	FR-U120S-N/0.1K-F, -(UF)	FR-BAL-0.4K (Note4)	FR-BOL-0.4K	K5 or H	5A/250V
Single	0.2	FR-U120S-N)0.2K-F, -(UF)	FR-BAL-0.4K (Note 4)	FR-BOL-0.4K	K5 or H	8A / 250V
phase 200∨	0.4	FR-U120S-M0.4K-F, -(UF)	FR-BAL-0.75K (Nots 4)	FR-BOL-0.4K	K5 or H	15A / 250V
	0.75	FR-U120S-N00.75K-F, -(UF)	FR-BAL-1.5K (Note 4)	FR-BOL-0.75K	K5 or H	25A / 250V
Single	0.1	FR-U110W-Ni0.1K-F, -(UF)	FR-BAL-0.4K (Note 4)	FR-BOL-0.4K	K5 or H	8A / 250V
phase	0.2	FR-U110W-N00.2K-F, -(UF)	FR-BAL-0.75K (Nots4)	FR-BOL-0.4K	K5 or H	15A / 250V
100∨	0.4	FR-U110W-N/0.4K-F, -(UF)	FR-BAL-1.5K (Note 4)	FR-BOL-0.4K	K5 or H	25A/250V

(Note)

- 1. The wiring sizes are shown for a 20m length.
- When installing an MC on the inverter power supply; select the model according to power supply capacity and wiring distance as shown on the right.

The A, B, C areas in the figure correspond to those in the above table. S-K10 is selected when using a power factor improvement reactor FR-BAL on the 0.4 to 1.5K models.


- Use a \$\phi 0.4 to \$\phi 1.0 solid wire or 0.3 to 0.75mi stranded wire for the control lead.
- 4. The power factor may drop slightly below 0.9.




(Note)


The figure shown is based upon wire sizes recommended in the above table.

● An excessive peak current will flow to the power supply input circuit when the inverter is directly connected to a large capacity power supply transformer (500kVA or more, wiring 10m or less), and the inverter may be damaged. Always install the optional power factor improvement reactor FR-BAL in this case. (Use the 0.4kW FR-BAL for 0.1K and 0.2K.)



- The wiring length between the inverter and motor must be less than 100m.
 The control line must be 30m or less and must be separated from the main power wire. Use a twisted pair wire for external frequency setting signal input.
- Connect as shown below when installing.





Revision

Publication date	Instruction menual No.	Details of revision
SEPT. 1994	IB(NA)-66443-A	First edition
MAR. 1995	IB(NA)-66443-B	Addition: Page 20, 64, 65, 66, 69
JULY, 1995	IB(NA)-66443-C	Addition: Stop key function Pr.75 3 Wire control

AMITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE:MITSUBISHI DENKI BLDG. MARUNOUCHI TOKYO 100 TELEX:J24532 CABLE MELCO TOKYO

TYPE	FR-U120-F EIBUN TORISETU
CODE	1A2-G34

