



VECTOR INVERTER

-INSTRUCTION MANUAL-

16-BIT DIGITAL INPUT

FR-V5AH

Thank you for choosing the Mitsubishi vector inverter option unit.

This instruction manual gives handling information and precautions for use of this equipment. Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use the equipment to its optimum.

Please forward this manual to the end user.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this instruction manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that the CAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

SAFETY INSTRUCTIONS

1. Electric Shock Prevention



- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover removed. Otherwise, you may access the exposed high-voltage terminals and charging part and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for no residual voltage with a tester or the like.



WARNING

- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the option unit before wiring. Otherwise, you may get an electric shock or be injured.
- Handle this option unit with dry hands to prevent an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise, you may get an electric shock.

2. Injury Prevention



CAUTION

- Apply only the voltage specified in the instruction manual to each terminal to prevent burst, damage, etc.
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent burst, damage, etc.
- While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.

3. Additional instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.:

(1) Transportation and mounting



CAUTION

- Do not install or operate the option unit if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the product.
- Check that the mounting orientation is correct.
- Prevent screws, metal fragments or other conductive bodies or oil or other flammable substance from entering the inverter.

(2) Test operation and adjustment



CAUTION

- Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

(3) Usage



WARNING

- Do not modify the equipment.



CAUTION

- When parameter clear or all parameter clear is performed, each parameter returns to the factory setting. Re-set the required parameters before starting operation.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

(4) Maintenance, inspection and parts replacement



CAUTION

- Do not test the equipment with a megger (measure insulation resistance).

(5) Disposal



CAUTION

- Treat as industrial waste.

(6) General instruction

All illustrations given in this manual may have been drawn with covers or safety guards removed to provide in-depth description. Before starting operation of the product, always return the covers and guards into original positions as specified and operate the equipment in accordance with the manual.

CONTENTS

1.PRE-OPERATION INSTRUCTIONS	1
1.1 Unpacking and Product Confirmation	1
1.2 Packing Confirmation	1
1.3 Structure	2
2.INSTALLATION	3
2.1 Pre-Installation Instructions.....	3
2.2 Installation Procedure	3
2.3 Wiring.....	5
3.16-BIT DIGITAL INPUT	8
3.1 Wiring Examples	8
3.2 Terminals	10
3.3 Code Input	11
4.DIGITAL SPEED COMMAND	12
4.1 Digital Speed Command Parameter	12
4.2 Parameter Setting	13
4.3 Instructions.....	17

5.DIGITAL TORQUE COMMAND	18
5.1 Digital Torque Command Parameters	18
5.2 Parameter Setting	18
5.3 Instructions.....	20
6.ORIENTATION POSITION COMMAND	21
6.1 Orientation Position Command Parameter	21
6.2 Parameter Setting	21
7.SPECIFICATIONS	23
7.1 Specifications.....	23

1. PRE-OPERATION INSTRUCTIONS

1.1 Unpacking and Product Confirmation

Take the option unit out of the package, check the unit name, and confirm that the product is as you ordered and intact.

This product is an option unit designed for exclusive use in the Mitsubishi FR-V500 series vector inverter.

- SERIAL number check

This product may be used with the FR-V500 series manufactured in and after March 2002. Any of the models may be used with this unit if its SERIAL number indicated on the rating plate and package has "O23OOOOOO" or later version. For details of the SERIAL number, please contact your sales representative.

SERIAL is made up of 1 version symbol, 1 alphabet letter or numeric character indicating month, and 7 numeric characters indicating the year and control number as shown below. (Only the first three digits of the control number are printed on the package.)


<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>	<u> </u>
Symbol	Year	Month	Control number					
SERIAL number								

1.2 Packing Confirmation

Make sure that the package includes the following

- Instruction manual.....1
- Mounting screws M3 × 102

1.3 Structure



2.INSTALLATION

2.1 Pre-Installation Instructions

Make sure that the input power of the inverter is off.



CAUTION




With input power on, do not install or remove the option unit. Otherwise, the inverter and option unit may be damaged.

2.2 Installation Procedure

- (1) Securely insert the connector of the option unit far into the connector of the inverter. At this time, fit the option fixing holes snugly. For the position of slot, refer to the next page.
Also be sure to fit the unit into the option fixing hook.
- (2) Securely fix the option unit to the inverter on both sides with the accessory mounting screws. If the screw holes do not match, the connector may not have been plugged snugly. Check for loose plugging.

INSTALLATION



CAUTION


1. Only one type of option per inverter may be used. When two or more options are mounted, priority is in order of slots 1, 2 and 3, the options having lower priority are inoperative.
2. When the inverter cannot recognize that the option is mounted, it displays the option error. The errors shown differ according to the mounting slots 1, 2, 3.

Mounting Position	Error Display
Slot 1	E.OP1
Slot 2	E.OP2
Slot 3	E.OP3

2.3 Wiring

Wiring method

- 1) For wiring the control circuit, use cables after stripping their sheaths.
Strip the sheaths to the following dimensions. If the sheath is stripped too much, its cable may be shorted with the adjoining cable. If the sheath is stripped too little, the cable may come off.



*Information on bar terminals


Introduced products (as of Mar., 2002): Phoenix Contact Co.,Ltd.

Terminal Screw Size	Bar Terminal Model (With Insulation Sleeve)	Bar Terminal Model (Without Insulation Sleeve)	Wire Size (mm ²)
M2	AI 0.5-6WH	A 0.5-6	0.3 to 0.5

- Bar terminal crimping terminal: CRIMPFOX ZA3 (Phoenix Contact Co., Ltd.)

CAUTION

When using the bar terminal (without insulation sleeve), use care so that the twisted wires do not come out.



INSTALLATION

- 2) Loosen the terminal screw and insert the cable into the terminal.
Screw size: M2
Tightening torque: 0.22N·m to 0.25N·m

CAUTION


Undertightening can cause cable disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.

Cable size: 0.3mm² to 0.75mm²

Screwdriver: Small flat-blade screwdriver

(Tip thickness: 0.4mm (0.02inches)/tip width: 2.5mm (0.10inches))

Route the wires so that they do not take up a lot of space in the control circuit terminal block of the option unit. During wiring, do not leave wire off-cuts in the inverter. They may cause a fault, failure or malfunction. Use the space on the left side of the control circuit terminal unit to route the wires.



Cable routing

REMARKS

The wires with large gauge may not be connected to the terminal block. When connected in parallel, all wires may not fit in the wiring space due to the increased number of wires. In such cases, perform wiring by using a junction terminal block.




CAUTION



When installing the inverter front cover, the cables to the inverter's control circuit terminals and option terminals should be routed properly in the wiring space to prevent them from being caught between the inverter and its cover.

REMARKS

1. As the input signals are at low level, use two parallel micro signal contacts or a twin contact for relay contact inputs to prevent a contact fault.



Micro signal contacts



Twin contacts

2. A transistor of the following specifications should be selected for the open collector signal: Electrical characteristics of the transistor used
 - $I_c \geq 10\text{mA}$
 - Leakage current: $100\mu\text{A}$ maximum
 - $V_{CE} \geq 30\text{V}$
 - If $I_c \geq 10\text{mA}$, $V_{CE}(\text{sat})$ voltage is 3V maximum
3. The control logic is the same as that of the inverter (factory-set to sink). When the logic of the inverter is changed to source, the option logic also switches to source. For details on changing the control logic, refer to the inverter instruction manual (basic).

3.2 Terminals

Terminal Location	Terminal Symbol	Description
Option unit	X0 to X15	Digital signal input terminals (speed setting signal terminals) Used to input a 4-digit BCD (9999 maximum) or 16-bit binary (FFFF _H maximum) relay contact or open collector signal. (refer to page 11)
	DY	Data read timing input signal Used when a digital signal read timing signal is necessary. Data is only read while the DY signal is on. By switching the DY signal off, the X0 to X15 data before signal-off is retained. (Refer to page 13.)
	SD	Common terminal (sink) Common terminal for digital and data read timing signals. This terminal is the SD terminal of the inverter. Common terminal for the SD terminal of the inverter.
Inverter	PC	External transistor common terminal (source) When connecting the transistor output (open collector output) of a programmable controller (PC), etc., connect the external power common (+) to this terminal to prevent a fault occurring due to leakage current. When you have selected the source logic, this terminal is used as a common terminal. This terminal is the PC terminal of the inverter.

3.3 Code Input

The following lists examples of terminal input state and input value for BCD code and binary code input.

In the case where BCD code is "6325"

BCD Code Input			
Digit	Terminal	Terminal input state	Input value
1	X0	ON	5
	X1	OFF	
	X2	ON	
	X3	OFF	
10	X4	OFF	2
	X5	ON	
	X6	OFF	
	X7	OFF	
100	X8	ON	3
	X9	ON	
	X10	OFF	
	X11	OFF	
1000	X12	OFF	6
	X13	ON	
	X14	ON	
	X15	OFF	

In the case where Binary code is "AB65H"

Binary code input			
Terminal	Terminal input state	Input value (hexadecimal)	Input value (decimal)
X0	ON	5	43877
X1	OFF		
X2	ON		
X3	OFF		
X4	OFF	6	
X5	ON		
X6	ON		
X7	OFF		
X8	ON	B	
X9	ON		
X10	OFF		
X11	ON		
X12	OFF	A	
X13	ON		
X14	OFF		
X15	ON		

CAUTION

Range of each digit is from 0 to 9. If the value of a digit is greater than 9, the value is invalid and the previous value is kept.

4.DIGITAL SPEED COMMAND

4.1 Digital Speed Command Parameter

Use the following parameters to give a speed command using the FR-V5AH. The following parameters can be set when the FR-V5AH is fitted.

This option unit does not function if the parameter values are factory setting values. When Pr.304 ≠ "9999", a speed command by the 16-bit digital input is made valid.

Set the following parameter values according to the application:

Parameter Number	Function name		Setting Range	Setting Increments	Factory Setting
300	BCD code input	Bias	0 to 3600r/min	0.1r/min	0r/min
301		Gain	0 to 3600r/min, 9999	1r/min	1500r/min
302	Binary input	Bias	0 to 3600r/min	0.1r/min	0r/min
303		Gain	0 to 3600r/min, 9999	1r/min	1500r/min
304	Selection of digital input type and analog compensation input enable/disable		0, 1, 2, 3, 9999	1	9999
305	Data read timing signal on-off selection		0, 1	1	0
329	Digital input unit selection		0, 1, 2	1	1

REMARKS

- For Pr.329, write is disabled during operation even when "2" is set in Pr.77. When changing the parameter setting, stop the operation.
- Binary input. load input data in hexadecimal
BCD code input . . . load input data in decimal

4.2 Parameter Setting

- (1) Input selection (Pr.304 "selection of digital input type and analog compensation input enable / disable.") You can select the digital input signal type and whether compensation for digital input by analog input is enabled or not. When the setting is "9999" (factory setting), the 16-bit digital input speed command is invalid.

[Relationship between the Pr. 304 setting and analog compensation input enable/disable]

Digital Input Signal Type	Analog Compensation Input*	
	Compensation disable	Compensation enable
BCD code input	0	2
Binary input	1	3


- *: The analog compensation input signal is entered across inverter 1-5. For the setting of "0" or "1", the analog compensation input is not accepted.

DIGITAL SPEED COMMAND

(2) Data read timing signal on-off selection (Pr.305)

Pr.305 setting	Description
0	The set speed data entered from the digital signal input terminals is always imported independently of whether the DY signal is on or off.
1	The set speed data entered from the digital signal input terminals is imported only when the DY signal is on. The set speed data is not imported when the DY signal is off. Therefore, if the input status of the X0-X15 signal changes, the set speed data before off of the DY signal is valid.

● How to use DY signal



REMARKS

When Pr. 305 = "1", all the X0 to X15 terminals are regarded as off if the inverter is switched on with the DY terminal off. For example, when bias is set to 500r/min, powering on the inverter with the DY signal off and turning the start signal on makes the speed command valid, starting the inverter to operate at 500r/min.

(3) Bias adjustment (Pr.300), (Pr.302)

Bias adjustments can be made for the digital input signal.
Set the set speed at the digital input of 0.


- BCD code input. Set the output speed in Pr.300.
- Binary input. Set the output speed in Pr.302.

(4) Gain adjustment (Pr.301), (Pr.303)

The gain may be set in either of the following two ways:

- How to set the output speed at the input signal of 9999 (BCD code) or FFFFH (binary)
 - BCD code input Set the output speed in Pr.301.
 - Binary input Set the output speed in Pr.303.

The factory setting is 1500r/min. for this input signal.




CAUTION

The maximum operation speed for operation with the digital input is the "gain" value set in Pr.301 and Pr.303.

To set the maximum operation speed to 1500r/min or more, change the "gain" from the control panel or parameter unit.

DIGITAL SPEED COMMAND

- How to set the BCD code or binary value as the output speed setting
When "9999" is set in Pr.301 (BCD code) or Pr.303 (binary), the digital input value is set (unchanged) as output speed.
(For example, to set the output speed to 1500r/min at the BCD code input of "1500")



REMARKS

When this setting method is used, "bias" setting (Pr.300 or Pr.302) cannot be made.

- (5) Digital input unit selection (Pr.329)
When "9999" is set in Pr.301(BCD code input gain) or Pr.303(binary input gain), the increment when the digital signal is set as output speed can be set.
speed command value = digital input signal value × Pr. 329 input increment

Pr.329 setting	Input Value Increments
0	0.1r/min
1 (factory setting), 2 *	1r/min

* The setting "2" is for the 12-bit digital input option unit FR-A5AX. The input increment is 1r/min.

<Example>

Pr.329=0

BCD code = 111 → 11.1r/min

binary = 100H (256 in decimal) → 25.6r/min

Pr.329=1

BCD code = 111 → 111r/min

binary = 100H (256 in decimal) → 256r/min

REMARKS

When the values other than "9999" are set in Pr.301 or Pr.303, Pr.329 is made invalid.

4.3 Instructions

- (1) Acceleration/deceleration time
When the speed is set with the digital input signal, the acceleration/deceleration time is the period of time required to reach the Pr. 20. This is the same as when using the analog signal input.
- (2) There are the following restrictions on the digital input signal:
When the signal is used to enter a BCD code, 0AH to 0FH entries are ignored during operation and the previous inputs are used to continue operation.
- (3) When the 16-bit digital input is valid (Pr. 304 setting is other than "9999"), the signals below are made invalid.
Terminal assignment of input signal is determined according to input terminal function selection (Pr.180 to Pr.183 and Pr.187).

Signal Name	Description
RL	Low speed operation command
RM	Middle speed operation command
RH	High speed operation command
REX	15-speed setting (combination with RL, RM, RH)

- (4) When the FR-V5AH and 12-bit digital input option unit FR-A5AX are used at the same time, the digital input of the FR-V5AH overrides the FR-A5AX.
- (5) If 0 to $\pm 10V$ is entered into terminal 1 of the inverter from the external volume with the option (FR-V5AH) mounted on the inverter, operation is performed at the speed, which is the sum of the BCD code input of the FR-V5AH and the auxiliary input from terminal 1, only when 2 or 3 is set in Pr. 304.
When switching the inputs e.g. between volume input to perform manual operation and BCD code input to perform automatic operation, set the BCD code input to "0" under manual operation.

REMARKS

When performing an auxiliary input using terminal 1 with the FR-V500 series, set "0" (factory setting) in Pr.868 "Terminal 1 function assignment".

5.DIGITAL TORQUE COMMAND

5.1 Digital Torque Command Parameters

Use the following parameters to give the torque command using the FR-V5AH. The following parameters can be set when the FR-V5AH is mounted.


Set the parameter values according to the application:

Parameter Number	Function name	Setting Range	Setting Increments	Factory Setting
304	Selection of digital input type and analog compensation input enable/disable	0, 1, 2, 3, 9999	1	9999
447	Digital torque command bias	0 to 400%	1%	0%
448	Digital torque command gain	0 to 400%	1%	150%
804	Torque command right selection	0 to 4	0	1

5.2 Parameter Setting

When "9999" (factory setting) is set in Pr.304 and "4" in Pr.804 "torque command selection" (The parameter setting can be made only when the FR-V5AH is mounted on the inverter.), digital torque command of the FR-V5AH (16 bit) is made valid.

The input signal uses the last 15 bits as torque command and the most significant bit as sign. (When the most significant bit is "1", torque command value is negative.)




(1) Bias adjustment (Pr. 447)

Bias adjustments can be made for the digital input signal.
Set the torque command value at the digital input of 0.

(2) Gain adjustment (Pr. 448)


The gain may be set in either of the following two ways:

- How to set the output torque command value at the input signal of FFFFH



DIGITAL TORQUE COMMAND

- How to set the digital input value as the torque command value
When "9999" is set in Pr. 448, the digital input value is set (unchanged) as the torque command value.



REMARKS

When the method to set the digital input value as the torque command value is used, "bias" setting (Pr. 447) cannot be made.

5.3 Instructions

When the FR-V5AH and 12-bit digital input option unit FR-A5AX are used at the same time, the digital input of the FR-V5AH overrides the FR-A5AX.

6. ORIENTATION POSITION COMMAND

6.1 Orientation Position Command Parameter

The orientation stop position by the 16-bit data input can be given using the FR-V5AH. Refer to the inverter manual for details of orientation control.

Parameter Number	Function Name	Setting Range	Factory Setting	Setting Increments
350	Stop position command selection	0, 1, 2, 3, 9999	9999	1
360	External position command selection	0, 1, 2 to 127	0	1

6.2 Parameter Setting

- (1) Selecting stop position command (Pr. 350 "stop position command selection")
Set Pr. 350 to "3" to give the orientation stop position command using the FR-V5AH.
- (2) Setting stop position (Pr. 360 "external position command selection")
Mount the FR-V5AH and set a stop position using 16-bit data (binary input).

- The value set in Pr. 360 "external position command selection" should be the number of stop positions less 1.

Pr. 360 Setting	Description
0	External position command is made invalid (speed command or torque command with the FR-V5AH)
1	Set 65536 stop positions at regular intervals
2 to 127	Set the stop position command dividing up to 128 stop positions at regular intervals. If the external stop command entered is greater than the setting, the stop positions are the same as those in the maximum external stop command value. <Example> When the number of stop positions is 90 (divided at intervals of 4°), $90 - 1 = 89$. Hence, set "89".

<p align="center">[Example 1] 4 stop positions</p> <p align="center">Pr. 360 = "3"</p>	<p align="center">[Example 2] 8 stop positions</p> <p align="center">Pr. 360 = "7"</p>	<p align="center">[Example 3] 120 stop positions</p> <p align="center">Pr. 360 = "119"</p>
--	--	--

CAUTION

- Values in parentheses indicate binary data entered from the input terminals. If the position pulse monitoring (Pr. 52 "DU/PU main display screen data selection" = 19) is selected, the data monitored is not the number of stop positions but is 0 to 65535 pulses.
- When any of "1 to 127" is set in Pr. 360, parameters (Pr. 300 to Pr. 305) of the FR-V5AH are made invalid. (Parameters are valid when Pr. 360="0".)
- Terminal DY (Data read timing input signal) is made invalid. (The position data is downloaded at the start of orientation.)
- When the option is not fitted or Pr. 360="0", the stop position is 0 even if the external stop position command is selected with the Pr. 350 setting.

7.SPECIFICATIONS

7.1 Specifications

- Digital input signal type 4-digit BCD code or 16-bit binary
- Digital input signal selection From operation panel or parameter unit
- Input current 5mA (24VDC) per circuit
- Input Contact signal or open collector input
- Adjustment functions (1) Bias and gain
(2) Analog compensation input
(Use control panel or parameter unit for setting.)

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Mar., 2002	IB(NA)-0600110E-A	First edition