



INSTRUCTION MANUAL

FR-E740-016(SC) to 300(SC) - EC FR-E720S-008(SC) to 110(SC) - EC


(1) (10 110(56) - E6

OUTLINE 1

WIRING 2

PRECAUTIONS FOR USE OF THE INVERTER

4



TROUBLESHOOTING

PARAMETERS

5

PRECAUTIONS FOR MAINTENANCE AND INSPECTION

6

SPECIFICATIONS

7

Thank you for choosing this Mitsubishi Inverter.

This Instruction Manual provides instructions for advanced use of the FR-E700 series inverters.

Incorrect handling might cause an unexpected fault. Before using the inverter, always read this Instruction Manual and the Installation Guideline [IB-0600335ENG] packed with the product carefully to use the equipment to its optimum performance.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through the Instruction Manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

⚠WARNING

Incorrect handling may cause hazardous conditions, resulting in death or severe injury.

⚠CAUTION

Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

The <u>ACAUTION</u> level may even lead to a serious consequence according to conditions. Both instruction levels must be followed because these are important to personal safety.

1. Electric Shock Prevention

⚠WARNING

- While power is ON or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise you may access the exposed highvoltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. You may accidentally touch the charged inverter circuits and get an electric shock.
- Before wiring or inspection, power must be switched OFF. To confirm that, LED indication of the operation panel must be checked. (It must be OFF.) Any person who is involved in wiring or inspection shall wait for at least 10 minutes after the power supply has been switched OFF and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.
- This inverter must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, IEC 536 class 1 and other applicable standards).
- A neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard must be used.
- Any person who is involved in wiring or inspection of this equipment shall be fully competent to do the work.
- The inverter must be installed before wiring. Otherwise you may get an electric shock or be injured.
- Setting dial and key operations must be performed with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.
- Do not change the cooling fan while power is ON. It is dangerous to change the cooling fan while power is ON.
- Do not touch the printed circuit board or handle the cables with wet hands. Otherwise you may get an electric shock.
- When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering OFF. Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.

2. Fire Prevention

MCAUTION

- Inverter must be installed on a nonflammable wall without holes (so that nobody touches the inverter heatsink on the rear side, etc.). Mounting it to or near flammable material can cause a fire.
- If the inverter has become faulty, the inverter power must be switched OFF. A continuous flow of large current could cause a fire.
- When using a brake resistor, a sequence that will turn OFF power when a fault signal is output must be configured. Otherwise the brake resistor may overheat due to damage of the brake transistor and possibly cause a fire.
- Do not connect a resistor directly to the DC terminals P/+ and N/-. Doing so could cause a fire.

3.Injury Prevention

⚠CAUTION

- The voltage applied to each terminal must be the ones specified in the Instruction Manual. Otherwise burst, damage, etc. may occur.
- The cables must be connected to the correct terminals.
 Otherwise burst, damage, etc. may occur.
- Polarity must be correct. Otherwise burst, damage, etc. may occur.
- While power is ON or for some time after power-OFF, do not touch the inverter as they will be extremely hot. Doing so can cause burns.

4. Additional Instructions

Also the following points must be noted to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and Mounting

ACAUTION

- The product must be transported in correct method that corresponds to the weight. Failure to do so may lead to injuries.
- Do not stack the boxes containing inverters higher than the number recommended.
- The product must be installed to the position where withstands the weight of the product according to the information in the Instruction Manual.
- Do not install or operate the inverter if it is damaged or has parts missing.
- When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.
- Do not stand or rest heavy objects on the product.
- The inverter mounting orientation must be correct.
- Foreign conductive objects must be prevented from entering the inverter. That includes screws and metal fragments or other flammable substance such as oil.
- As the inverter is a precision instrument, do not drop or subject it to impact.
- The inverter must be used under the following environment. Otherwise the inverter may be damaged.

	Surrounding air temperature	-10°C to +50°C (non-freezing)	
ment	Ambient humidity	90%RH or less (non-condensing)	
onme	Storage temperature	-20°C to +65°C *1	
Environ	Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)	
	Altitude/ vibration	Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (91%). 5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)	
٠1	Tomporatur	o applicable for a short time of a in transit	

↑CAUTION

- Do not install a power factor correction capacitor or surge suppressor/capacitor type filter on the inverter output side. These devices on the inverter output side may be overheated or burn out.
- The connection orientation of the output cables U, V, W to the motor affects the rotation direction of the motor.

(3) Trial run

ACAUTION

 Before starting operation, each parameter must be confirmed and adjusted. A failure to do so may cause some machines to make unexpected motions.

(4) Usage

MWARNING

- Any person must stay away from the equipment when the retry function is set as it will restart suddenly after trip.
- Since pressing (STOP) key may not stop output depending on the function setting status, separate circuit and switch that make an emergency stop (power OFF, mechanical brake operation for emergency stop, etc.) must be provided.
- OFF status of the start signal must be confirmed before resetting the inverter fault. Resetting inverter alarm with the start signal ON restarts the motor suddenly.
- The inverter must be used for three-phase induction motors.
 Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.

⚠CAUTION

- The electronic thermal relay function does not guarantee protection of the motor from overheating. It is recommended to install both an external thermal and PTC thermistor for overheat protection.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter. Otherwise the life of the inverter decreases.
- The effect of electromagnetic interference must be reduced by using a noise filter or by other means.
 Otherwise nearby electronic equipment may be affected.
- Appropriate measures must be taken to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/damage the power factor correction capacitor and generator.
- When driving a 400V class motor by the inverter, the motor must be an insulation-enhanced motor or measures must be taken to suppress surge voltage. Surge voltage attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all parameter clear is performed, the required parameters must be set again before starting operations because all parameters return to the initial value.
- The inverter can be easily set for high-speed operation.
 Before changing its setting, the performances of the motor and machine must be fully examined.
- Stop status cannot be hold by the inverter's brake function. In addition to the inverter's brake function, a holding device must be installed to ensure safety.
- Before running an inverter which had been stored for a long period, inspection and test operation must be performed.
- For prevention of damage due to static electricity, nearby metal must be touched before touching this product to eliminate static electricity from your body.

(5) Emergency stop

↑ CAUTION

- A safety backup such as an emergency brake must be provided to prevent hazardous condition to the machine and equipment in case of inverter failure.
- When the breaker on the inverter input side trips, the wiring must be checked for fault (short circuit), and internal parts of the inverter for a damage, etc. The cause of the trip must be identified and removed before turning ON the power of the breaker.
- When any protective function is activated, appropriate corrective action must be taken, and the inverter must be reset before resuming operation.

(6) Maintenance, inspection and parts replacement

⚠CAUTION

 Do not carry out a megger (insulation resistance) test on the control circuit of the inverter. It will cause a failure.

(7) Disposal

ACAUTION

• The inverter must be treated as industrial waste.

General instruction

Many of the diagrams and drawings in this Instruction Manual show the inverter without a cover or partially open for explanation. Never operate the inverter in this manner. The cover must be always reinstalled and the instruction in this Instruction Manual must be followed when operating the inverter.

1

CONTENTS-

1 (OU	TL	INE
-----	----	----	-----

	1.1	Product checking and parts identification	2
	1.2	Inverter and peripheral devices	3
	1.2.	1 Peripheral devices	4
	1.3	Removal and reinstallation of the cover	5
1. 1. 2. 2. 2.	1.3.	1 Front cover	5
1.2 Inv. 1.2.1 1.3 Re 1.3.1 1.3.2 1.4 Ins 1.4.1 1.4.2 1.4.3 2 WIRII 2.1 Win 2.1.1 2.2 Ma 2.2.1 2.2.2 2.2.3 2.3 Co 2.3.1 2.3.2 2.3.3 2.3.4 2.3.5 2.4 Co 2.4.1 2.4.2 2.4.3 2.4.4 2.4.5 3 PREC. 3.1 EM	Installation of the inverter and enclosure design	8	
	1.4.		
	1.4.		
2	WI	RING	13
	2.1	Wiring	14
	2.1.	1 Terminal connection diagram	14
	2.2	Main circuit terminal specifications	16
	2.2.	1 Specification of main circuit terminal	16
	2.2.		
	2.2.	3 Cables and wiring length	18
	2.3	Control circuit specifications	21
	2.3.	1 Control circuit terminal	21
	2.3.	2 Changing the control logic	24
	2.3.	3 Wiring of control circuit	26
	2.3.	4 Safety stop function (available only for the safety stop function model)	30
	2.3.	5 Connection to the PU connector	32
	2.4	Connection of stand-alone option unit	34
	2.4.	1 Connection of a dedicated external brake resistor (MRS type, FR-ABR) (FR-E740-016(SC more, FR-E720S-030(SC) or more)	
	2.4.	2 Connection of the brake unit (FR-BU2)	36
	2.4.	3 Connection of the high power factor converter (FR-HC)	37
	2.4.	4 Connection of the power regeneration common converter (FR-CV)	38
	2.4.	5 Connection of the DC reactor (FR-HEL)	38
3	PR	ECAUTIONS FOR USE OF THE INVERTER	39
	3.1	EMC and leakage currents	40
	3.1.	1 Leakage currents and countermeasures	40

3.1		
3.1	1.3 Power supply harmonics	44
3.2	Installation of power factor improving reactor	45
3.3	Power-OFF and magnetic contactor (MC)	46
3.4	Inverter-driven 400V class motor	47
3.5	Precautions for use of the inverter	
3.6	Failsafe of the system which uses the inverter	
	ARAMETERS	53
4.1	Operation panel	
4.1	a contract the contract product of the contract product produc	
4.1 4.1	1	
4. i 4.1	, , , , , , , , , , , , , , , , , , , ,	
4.1		
4.2		
4.2	2.1 Parameter list	58
4.3	Control mode	79
4.3		
4.4	Adjustment of the output torque (current) of the motor	81
4.4	I.1 Manual torque boost (Pr. 0, Pr. 46)	81
4.4		
4.4	General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)	85
4.4	,	
4.4	5.5 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157, Pr. 277)	88
4.5	Limiting the output frequency	92
4.5	5.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	92
4.5	Avoiding mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	93
4.6	V/F pattern	94
4.6	8.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	94
4.6	6.2 Load pattern selection (Pr. 14)	96
4.7	Frequency setting by external terminals	98
4.7	7.1 Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	98
4.7		
4.7	7.3 Remote setting function (Pr. 59)	102
4.8	Setting of acceleration/deceleration time and acceleration/	
	deceleration pattern	105

4.8.1	Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 147)	105
4.8.2	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	
4.8.3	Acceleration/deceleration pattern (Pr. 29)	
4.8.4	Shortest acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)	
4.9 S	election and protection of a motor	112
4.9.1	Motor overheat protection (Electronic thermal O/L relay) (Pr. 9, Pr. 51)	112
4.9.2	Applied motor (Pr. 71, Pr. 450)	114
4.9.3	Exhibiting the best performance for the motor (offline auto tuning) (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859)	116
4.10 M	lotor brake and stop operation	124
4.10.1	DC injection brake (Pr. 10 to Pr. 12)	124
4.10.2	Selection of a regenerative brake (Pr. 30, Pr. 70)	126
4.10.3	Stop selection (Pr. 250)	128
4.10.4	Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276)	129
4.10.5	Brake sequence function (Pr. 278 to Pr. 283, Pr. 292)	131
4.11 F	unction assignment of external terminal and control	135
4.11.1	Input terminal function selection (Pr. 178 to Pr. 184)	135
4.11.2	Inverter output shutoff signal (MRS signal, Pr. 17)	137
4.11.3	, ,	
4.11.4		
4.11.5	,	
4.11.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	
4.11.7		
4.11.8	Remote output selection (REM signal, Pr. 495 to Pr. 497)	148
4.12 M	lonitor display and monitor output signal	149
4.12.1	Speed display and speed setting (Pr. 37)	149
4.12.2	Monitor display selection of DU/PU and terminal AM (Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)	150
4.12.3	Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)	155
4.12.4	Terminal AM calibration (calibration parameter Pr. 645, C1 (Pr.901))	156
	peration selection at power failure and instantaneous pow	
		130
4.13.1	Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	158
4.13.2	Power-failure deceleration stop function (Pr. 261)	164
4.14 O	peration setting at fault occurrence	166
4.14.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	166
4.14.2		
4.14.3	Earth (ground) fault detection at start (Pr. 249)	168

4.15 E	nergy saving operation	169
4.15.1	Optimum excitation control (Pr. 60)	169
4.16 M	otor noise, EMI measures, mechanical resonance	170
4.16.1	PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240)	170
	Speed smoothing control (Pr. 653)	
4.17 F	requency setting by analog input (terminal 2, 4)	172
4.17.1	Analog input selection (Pr. 73, Pr. 267)	172
	Response level of analog input and noise elimination (Pr. 74)	
4.17.3		
4.18 M	isoperation prevention and parameter setting restriction	180
4.18.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	180
4.18.2	Parameter write disable selection (Pr. 77)	183
4.18.3	Reverse rotation prevention selection (Pr. 78)	184
4.18.4	Extended parameter display and user group function (Pr. 160, Pr. 172 to Pr. 174)	184
4.18.5	Password function (Pr. 296, Pr. 297)	187
4.19 S	election of operation mode and operation location	190
4.19.1	Operation mode selection (Pr. 79)	190
4.19.2	Operation mode at power-ON (Pr. 79, Pr. 340)	200
4.19.3	Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)	201
4.20 C	ommunication operation and setting	207
4.20.1	Wiring and configuration of PU connector	207
4.20.2	Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	210
4.20.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	211
4.20.4	Communication EEPROM write selection (Pr. 342)	214
4.20.5	Mitsubishi inverter protocol (computer link communication)	215
4.20.6	Modbus-RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	228
4.20.7	USB communication (Pr. 547, Pr. 548)	
4.21 S	pecial operation and frequency control	242
4.21.1	PID control (Pr. 127 to Pr. 134)	242
4.21.2		
4.21.3	Droop control (Pr. 286 to Pr. 287)	256
4.21.4	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	257
4.22 U	seful functions	259
4.22.1	Cooling fan operation selection (Pr. 244)	259
4.22.2	Display of the life of the inverter parts (Pr. 255 to Pr. 259)	260
4 22 3	Maintenance timer alarm (Pr. 503, Pr. 504)	264

	4.22.4	Current average value monitor signal (Pr. 555 to Pr. 557)	265
	4.22.5	Free parameter (Pr. 888, Pr. 889)	267
	4.23 S	etting from the parameter unit and operation panel	268
	4.23.1	RUN key rotation direction selection (Pr. 40)	268
		PU display language selection(Pr.145)	
		Operation panel frequency setting/key lock operation selection (Pr. 161)	
	4.23.4		
	4.23.5	Buzzer control (Pr. 990)	272
	4.23.6	PU contrast adjustment (Pr. 991)	272
	4.24 Pa	arameter clear/ All parameter clear	273
	4.25 In	itial value change list	274
	4.26 C	heck and clear of the faults history	275
5	TRO	JBLESHOOTING	277
	1100		<u></u>
	5.1 R	eset method of protective function	. 278
	5.2 Li	st of fault or alarm indications	. 279
	5.3 C	auses and corrective actions	. 280
	5.4 C	orrespondences between digital and actual characters	. 290
	5.5 C	heck first when you have a trouble	. 291
	5.5.1	Motor does not start	291
	5.5.2	Motor or machine is making abnormal acoustic noise	293
	5.5.3	Inverter generates abnormal noise	293
	5.5.4	Motor generates heat abnormally	293
	5.5.5	Motor rotates in the opposite direction	
	5.5.6	Speed greatly differs from the setting	
	5.5.7	Acceleration/deceleration is not smooth	
	5.5.8	Speed varies during operation	
	5.5.9	Operation mode is not changed properly	
	5.5.10	Operation panel display is not operating	
	5.5.11	Motor current is too large	
	5.5.12	Speed does not accelerate	
		Unable to write parameter setting	297
6	PR	RECAUTIONS FOR MAINTENANCE AND INSPECTION	299
	6.1 In	spection items	. 300
	6.1.1	Daily inspection	
	6.1.2	Periodic inspection	
	6.1.3	Daily and periodic inspection	

6.1.4	Display of the life of the inverter parts	302
6.1.5	Checking the inverter and converter modules	303
6.1.6	Cleaning	303
6.1.7	Replacement of parts	304
6.1.8	Inverter replacement	306
6.2 N	leasurement of main circuit voltages, currents and powers	s 307
6.2.1	Measurement of powers	309
6.2.2	Measurement of voltages and use of PT	309
6.2.3	Measurement of currents	310
6.2.4		
6.2.5	Measurement of inverter input power factor	310
6.2.6	Measurement of converter output voltage (across terminals P/+ and N/-)	310
6.2.7	Insulation resistance test using megger	311
6.2.8	Pressure test	311
7 SPE	CIFICATIONS	313
7.1 R		
7.2 C	common specifications	316
7.3 C	Outline dimension drawings	317
APPEN	IDIX	321
Append	### 314 ### arter rating	
Apper	ndix 1-1 Replacement of the FR-E500 series	322
Append	dix 2 Specification change	324
Apper	ndix 2-1 SERIAL number check	324
Apper	ndix 2-2 Changed Functions	324
Append	dix 3 Index	325

OUTLINE

This chapter explains the "OUTLINE" for use of this product. Always read the instructions before using the equipment.


1.1	Product checking and parts identification 2)
1.2	Inverter and peripheral devices3	;
1.3	Removal and reinstallation of the cover5	;
1.4	Installation of the inverter and enclosure design 8	;

<abbreviations></abbreviations>	
PU	. Operation panel and parameter unit (FR-PU04/FR-PU07)
Inverter	. Mitsubishi inverter FR-E700 series
FR-E700	. Mitsubishi inverter FR-E700 series
Pr	. Parameter number (Function number of inverter)
PU operation	. Operation using the PU (operation panel/FR-PU04/FR-PU07)
External operation	. Operation using the control circuit signals
Combined operation	Operation using both the PU (operation panel/FR-PU04/FR-
	PU07) and external operation
Operation panel for E500, PA02	. FR-E500 series operation panel (FR-PA02-02)
Mitsubishi standard motor	. SF-JR
Mitsubishi constant-torque motor	. SF-HRCA
<trademarks></trademarks>	

- · Microsoft and Visual C++ are registered trademarks of Microsoft Corporation in the United States
- LonWorks® is a registered trademark of Echelon Corporation in the U.S.A and other countries.
- DeviceNet[®] is a registered trademark of ODVA (Open DeviceNet Vender Association, Inc.).
- · Other company and product names herein are the trademarks and registered trademarks of their respective owners.

<Mark>

▶ **REMARKS** :Additional helpful contents and relations with other functions are stated






Parameters referred to: related parameters are stated. Ver. IP Specifications differ according to the date assembled. Refer to page 324 to check the SERIAL number.


6

1.1 Product checking and parts identification

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.

•Inverter model





Location of the capacity plate and the rating plate differs according to the inverter capacity.
 Refer to the outline dimension drawing. (Refer to page 317)

Accessory


· Fan cover fixing screws (M3 × 35mm)

These screws are necessary for compliance with the EU Directive (Refer to the Installation Guideline)

Туре	Number
FR-E740-040(SC) to 095(SC), FR-E720S-050(SC) to 110(SC)	1
FR-E740-120(SC) to 300(SC)	2



Inverter and peripheral devices





- The life of the inverter is influenced by surrounding air temperature. The surrounding air temperature should be as low as possible within the permissible range. This must be noted especially when the inverter is installed in an enclosure. (Refer
- Wrong wiring might lead to damage of the inverter. The control signal lines must be kept fully away from the main circuit to protect them from noise. (Refer to page 14)
- Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- Electromagnetic wave interference The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install options among the capacitor type EMC filter FR-BIF (for use in the input side only), the ferrite core type EMC filter FR-BSF01/FR-BLF, filterpack, and EMC filter to minimize the interference. (Refer to page 42).


 Refer to the instruction manual of each option and peripheral devices for details of peripheral devices.

1.2.1 Peripheral devices

Check the inverter model of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity. Refer to the following list and prepare appropriate peripheral devices:

Applicable Inverter Model		Motor Output	Moulded Case Circuit Breaker (MCCB) *1 or Earth Leakage Circuit Breaker (ELB) *2		Magnetic Contactor (MC) *3		Reactor	
		(kW)	Reactor connection		Reactor connection		FR-HAL	FR-HEL
			without	with	without	with		
	FR-E740-016(SC)	0.4	5A	5A	S-N10	S-N10	H0.4K	H0.4K
>	FR-E740-026(SC)	0.75	5A	5A	S-N10	S-N10	H0.75K	H0.75K
400V	FR-E740-040(SC)	1.5	10A	10A	S-N10	S-N10	H1.5K	H1.5K
se 4	FR-E740-060(SC)	2.2	15A	10A	S-N10	S-N10	H2.2K	H2.2K
Ja	FR-E740-095(SC)	3.7	20A	15A	S-N10	S-N10	H3.7K	H3.7K
급	FR-E740-120(SC)	5.5	30A	20A	S-N20, S-N21	S-N11, S-N12	H5.5K	H5.5K
Thre	FR-E740-170(SC)	7.5	30A	30A	S-N20, S-N21	S-N20, S-N21	H7.5K	H7.5K
F	FR-E740-230(SC)	11	50A	40A	S-N20, S-N21	S-N20, S-N21	H11K	H11K
	FR-E740-300(SC)	15	60A	50A	S-N25	S-N20, S-N21	H15K	H15K
200V	FR-E720S-008(SC)	0.1	5A	5A	S-N10	S-N10	0.4K *4	0.4K *4
	FR-E720S-015(SC)	0.2	5A	5A	S-N10	S-N10	0.4K *4	0.4K *4
ase	FR-E720S-030(SC)	0.4	10A	10A	S-N10	S-N10	0.75K *4	0.75K *4
-Phase	FR-E720S-050(SC)	0.75	15A	10A	S-N10	S-N10	1.5K *4	1.5K *4
Single-	FR-E720S-080(SC)	1.5	20A	20A	S-N10	S-N10	2.2K *4	2.2K *4
Sin	FR-E720S-110(SC)	2.2	40A	30A	S-N20, S-N21	S-N10	3.7K *4	3.7K *4

^{*1 •}Select an MCCB according to the power supply capacity.



- *2 For the use in the United States or Canada, select a UL and cUL certified fuse with Class T fuse equivalent cut-off speed or faster with the appropriate rating for branch circuit protection. Alternatively, select a UL489 molded case circuit breaker (MCCB).
- Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.

 When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class
 - When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.
- *4 The power factor may be slightly lower.



- When the inverter capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the inverter model and cable and reactor according to the motor output.
- When the breaker on the inverter input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.

[•]Install one MCCB per inverter.


Removal and reinstallation of the cover 1.3

1.3.1 Front cover

FR-E740-170(SC) or less, FR-E720S


●Removal (Example of FR-E740-095)


Remove the front cover by pulling it toward you in the direction of arrow.



●Reinstallation (Example of FR-E740-095)

To reinstall, match the cover to the inverter front and install it straight.






FR-E740-230(SC), 300(SC)


●Removal (Example of FR-E740-230)

- 1) Loosen the installation screws of the front cover 1.
- 2) Remove the front cover 1 by pulling it toward you in the direction of arrow.
- 3) Remove the front cover 2 by pulling it toward you in the direction of arrow.



● Reinstallation (Example of FR-E740-230)

- 1) Match the front cover 2 to the inverter front and install it straight.
- 2) Insert the two fixed hooks on the lower side of the front cover 1 into the sockets of the inverter.
- 3) Tighten the screw of the front cover 1.



7


- Fully make sure that the front cover has been reinstalled securely.
- The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.



1.3.2 Wiring cover

•Removal and reinstallation

The cover can be removed easily by pulling it toward you. To reinstall, fit the cover to the inverter along the guides.



1.4 Installation of the inverter and enclosure design

When an inverter enclosure is to be designed and manufactured, heat generated by contained equipment, etc., the environment of an operating place, and others must be fully considered to determine the enclosure structure, size and equipment layout. The inverter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

1.4.1 Inverter installation environment

As the inverter installation environment should satisfy the standard specifications indicated in the following table, operation in any place that does not meet these conditions not only deteriorates the performance and life of the inverter, but also causes a failure. Refer to the following points and take adequate measures.

Environmental standard specifications of inverter

Item	Description
Surrounding air temperature	-10 to +50°C (non-freezing)
Ambient humidity	90%RH or less (non-condensing)
Atmosphere	Free from corrosive and explosive gases, free from dust and dirt
Maximum altitude	1,000m or less
Vibration	5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)

(1) Temperature

The permissible surrounding air temperature of the inverter is between -10 and +50°C. Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures so that the surrounding air temperature of the inverter falls within the specified range.

- 1) Measures against high temperature
 - Use a forced ventilation system or similar cooling system. (Refer to page 10)
 - Install the panel in an air-conditioned electrical chamber.
 - · Block direct sunlight.
 - Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
 - Ventilate the area around the panel well.
- 2) Measures against low temperature
 - Provide a space heater in the enclosure.
 - Do not power off the inverter. (Keep the start signal of the inverter off.)
- 3) Sudden temperature changes
 - · Select an installation place where temperature does not change suddenly.
 - Avoid installing the inverter near the air outlet of an air conditioner.
 - If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

(2) Humidity

Normally operate the inverter within the 45 to 90% range of the ambient humidity. Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may produce a spatial electrical breakdown. The insulation distance specified in JEM1103 "Control Equipment Insulator" is defined as humidity 45 to 85%.

- 1) Measures against high humidity
 - Make the panel enclosed, and provide it with a hygroscopic agent.
 - · Take dry air into the enclosure from outside.
 - Provide a space heater in the enclosure.
- 2) Measures against low humidity

What is important in fitting or inspection of the unit in this status is to discharge your body (static electricity) beforehand and keep your body from contact with the parts and patterns, besides blowing air of proper humidity into the panel from outside.

3) Measures against condensation

Condensation may occur if frequent operation stops change the in-panel temperature suddenly or if the outside-air temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- Take the measures against high humidity in 1).
- Do not power OFF the inverter. (Keep the start signal of the inverter OFF.)



(3) Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contact of contact points, reduced insulation or reduced cooling effect due to moisture absorption of accumulated dust and dirt, and in-panel temperature rise due to clogged filter. In the atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time.

Since oil mist will cause similar conditions, it is necessary to take adequate measures.

Countermeasures

- Place in a totally enclosed enclosure.
 Take measures if the in-enclosure temperature rises. (Refer to page 10)
- Purge air.

Pump clean air from outside to make the in-panel pressure higher than the outside-air pressure.

(4) Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the measures given in Section 3.

(5) Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

(6) Highland

Use the inverter at the altitude of within 1000m. If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

(7) Vibration, impact

The vibration resistance of the inverter is up to 5.9m/s^2 at 10 to 55 Hz frequency and 1mm amplitude for the directions of X, Y, Z axes. Vibration or impact, if less than the specified value, applied for a long time may make the mechanism loose or cause poor contact to the connectors.

Especially when impact is imposed repeatedly, caution must be taken as the part pins are likely to break.

Countermeasures

- · Provide the panel with rubber vibration isolators.
- Strengthen the structure to prevent the panel from resonance.
- · Install the panel away from sources of vibration.

1.4.2 Cooling system types for inverter panel

From the panel that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-panel temperature lower than the permissible temperatures of the in-panel equipment including the inverter.

The cooling systems are classified as follows in terms of the cooling calculation method.

- 1) Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- 2) Cooling by heat sink (aluminum fin, etc.)
- 3) Cooling by ventilation (forced ventilation type, pipe ventilation type)
- 4) Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)

	Cooling System	Panel Structure	Comment
Notirel	Natural ventilation (enclosed, open type)	INV	Low in cost and generally used, but the panel size increases as the inverter capacity increases. For relatively small capacities.
Natural cooling	Natural ventilation (totally enclosed type)	INV	Being a totally enclosed type, the most appropriate for hostile environment having dust, dirt, oil mist, etc. The panel size increases depending on the inverter capacity.
	Fin cooling	Heatsink NV	Having restrictions on the heatsink mounting position and area, and designed for relative small capacities.
Forced cooling	Forced ventilation		For general indoor installation. Appropriate for panel downsizing and cost reduction, and often used.
	Heat pipe	Heat pipe	Totally enclosed type for panel downsizing.




1.4.3 Inverter placement


(1) Installation of the inverter Enclosure surface mounting

Remove the front cover and wiring cover to fix the inverter to the surface.

• FR-E720S-008(SC) to 030(SC)

- FR-E740-016(SC) or more
- FR-E720S-050(SC) or more








NOTE


- When encasing multiple inverters, install them in parallel as a cooling measure.
- Install the inverter vertically.




(2) Clearances around inverter

To ensure ease of heat dissipation and maintenance, leave at least the shown clearances around the inverter. At least the following clearances are required under the inverter as a wiring space, and above the inverter as a heat dissipation space.

Surrounding air temperature and humidity




Leave enough clearances and take cooling measures.



* When using the inverters at the surrounding air temperature of 40 °C or less, the inverters can be installed without any clearance between them (0cm clearance).

When surrounding air temperature exceeds 40 °C, clearances between the inverters should be 1cm or more (5cm or more for the FR-E740-120(SC) or more).



* 5cm or more for the FR-E740-120(SC) or more

(3) Inverter mounting orientation

Mount the inverter on a wall as specified. Do not mount it horizontally or any other way.


(4) Above inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.

(5) Arrangement of multiple inverters

When multiple inverters are placed in the same enclosure, generally arrange them horizontally as shown in the right figure (a). When it is inevitable to arrange them vertically to minimize space, take such measures as to provide guides since heat from the bottom inverters can increase the temperatures in the top inverters, causing inverter failures.

When mounting multiple inverters, fully take caution not to make the surrounding air temperature of the inverter higher than the permissible value by providing ventilation and increasing the panel size.




(a) Horizontal arrangement

(b) Vertical arrangement

Arrangement of multiple inverters

(6) Arrangement of ventilation fan and inverter

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



Placement of ventilation fan and inverter

2 WIRING

This chapter describes the basic "WIRING" for use of this product.

Always read the instructions before using the equipment.

2.1	Wiring	14
	Main circuit terminal specifications	
2.3	Control circuit specifications	21
	Connection of stand-alone option unit	

1

2

3

L


6

7

2.1 Wiring

2.1.1 Terminal connection diagram


(1) Standard control circuit terminal model



` }|

- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables. Also separate the main circuit wire of the input side and the output side.
- After wiring, wire offcuts must not be left in the inverter.
 Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- The output of the single-phase power input model is three-phase 200V.

(2) Safety stop function model



•

- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables. Also separate the main circuit wire of the input side and the output side.
- After wiring, wire offcuts must not be left in the inverter.
 Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- The output of the single-phase power input model is three-phase 200V.

2.2 Main circuit terminal specifications


2.2.1 Specification of main circuit terminal

Terminal	Towning! Nows	Description
Symbol	Terminal Name	Description
R/L1,		Connect to the commercial power supply.
S/L2,	AC power input	Keep these terminals open when using the high power factor converter (FR-HC) or
T/L3 *1		power regeneration common converter (FR-CV).
U, V, W	Inverter output	Connect a three-phase squirrel-cage motor.
P/+*2. PR	Brake resistor connection	Connect a brake resistor (FR-ABR, MRS type) across terminals P/+ and PR.
F/T*2, FK	Brake resistor connection	(The brake resistor can not be connected to the FR-E720S-008(SC) and 015(SC).)
P/+*2. N/-*3	Brake unit connection	Connect the brake unit (FR-BU2), power regeneration common converter (FR-CV)
F/T*2, IN/-*3	Brake unit connection	or high power factor converter (FR-HC).
P/+*2, P1	DC reactor connection	Remove the jumper across terminals P/+ and P1 and connect a DC reactor.
	Earth (Ground)	For earthing (grounding) the inverter chassis. Must be earthed (grounded).


- *1 When using single-phase power input, terminals are L1, N.
- *2 Indicated as "+" on the terminal block of the single-phase power input model.
- *3 Indicated as "-" on the terminal block of the single-phase power input model.

2.2.2 Terminal arrangement of the main circuit terminal, power supply and the motor wiring

Three-phase 400V class



Single-phase 200V class



7

- Make sure the power cables are connected to the R/L1, S/L2, T/L3. (Phase need not be matched.) Never connect the power cable to the U, V, W of the inverter. Doing so will damage the inverter.
- Connect the motor to U, V, W. Turning ON the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.

2.2.3 Cables and wiring length

(1) Applicable cable size

Select the recommended cable size to ensure that a voltage drop will be 2% max.

If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.

The following table indicates a selection example for the wiring length of 20m.

Three-phase 400V class (when input power supply is 440V)

			Crimping		Cable Size							
Applicable Inverter		Tightening	Ter	Terminal		HIV Cables, etc. (mm²) *1		AWG *2		PVC Cables, etc		c. (mm²) *3
Model	Screw Size *4	Torque N·m	R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earthing cable	R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earthing cable
FR-E740-016(SC) to	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
095(SC)	1714	1.5	Z- 4	2-4	_			14	14	2.5	2.5	2.5
FR-E740-120(SC)	M4	1.5	5.5-4	2-4	3.5	2	3.5	12	14	4	2.5	4
FR-E740-170(SC)	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	12	12	4	4	4
FR-E740-230(SC)	M4	1.5	5.5-4	5.5-4	5.5	5.5	8	10	10	6	6	10
FR-E740-300(SC)	M5	2.5	8-5	8-5	8	8	8	8	8	10	10	10

Single-phase 200V class (when input power supply is 220V)

		T' . 1.4	Cri	mping				Cab	le Size			
Applicable Inverter	Screw	Tightening Torque			HIV Cables, etc. (mm ²) *1			AWG *2		PVC Cables, etc. (mm ²) *3		
Model	Size *4	N·m	L1 N	U, V, W	L1 N	U, V, W	Earthing cable	L1 N	U, V, W	L1 N	U, V, W	Earthing cable
FR-E720S-008(SC) to 030(SC)	M3.5	1.2	2-3.5	2-3.5	2	2	2	14	14	2.5	2.5	2.5
FR-E720S-050(SC)	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-E720S-080(SC)	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-E720S-110(SC)	M4	1.5	5.5-4	2-4	3.5	2	2	12	14	4	2.5	2.5

- *1 The cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 50°C or less and the wiring distance is 20m or less.
- *2 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less. (Selection example for use mainly in the United States.)
- *3 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 70°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less. (Selection example for use mainly in Europe.)
- *4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, and a screw for earthing (grounding).

 For single-phase power input, the terminal screw size indicates the size of terminal screw for L1, N, U, V, W, PR, +, -, P1 and a screw for earthing (grounding).



NOTE

- Tighten the terminal screw to the specified torque. A screw that has been tighten too loosely can cause a short circuit or malfunction. A screw that has been tighten too tightly can cause a short circuit or malfunction due to the unit breakage.
- Use crimping terminals with insulation sleeve to wire the power supply and motor.

The line voltage drop can be calculated by the following formula:

Line voltage drop [V]= $\frac{\sqrt{3} \times \text{wire resistance}[\text{m}\Omega/\text{m}] \times \text{wiring distance}[\text{m}] \times \text{current}[\text{A}]}{1000}$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.



(2) Earthing (Grounding) precautions

- Always earth (ground) the motor and inverter.
 - 1) Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use. An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flow into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operator from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

2) Earthing (grounding) methods and earthing (grounding) work


As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-affected malfunction prevention type. Therefore, these two types should be discriminated clearly, and the following work must be done to prevent the leakage current having the inverter's high frequency components from entering the malfunction prevention type earthing (grounding):


(a) If possible, use (I) independent earthing (grounding) in figure below for the inverter. If independent earthing (grounding) is not available, use (II) joint earthing (grounding) in the figure below which the inverter is connected with the other equipment at an earthing (grounding) point. The (III) common earthing (grounding) as in the figure below, which inverter shares a common earthing cable with the other equipment, must be avoided.


A leakage current including many high frequency components flows in the earthing cables of the inverter and inverter-driven motor. Therefore, use the independent earthing (grounding) and separated the earthing (grounding) cable of the inverter from equipments sensitive to EMI.

In a high building, it may be effective to use the EMI prevention type earthing (grounding) connecting to an iron structure frame, and electric shock prevention type earthing (grounding) with the independent earthing (grounding) together.

- (b)This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards). Use an neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard.
- (c)Use the thickest possible earthing cable. The earthing cable should be of not less than the size indicated in the table on the previous *page 18*.
- (d)The grounding point should be as near as possible to the inverter, and the ground wire length should be as short as possible.
- (e)Run the earthing cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.









POINT

To be compliant with the EU Directive (Low Voltage Directive), [refer to the Installation Guideline.



(3) Total wiring length


The overall wiring length for connection of a single motor or multiple motors should be within the value in the table below.

200V class

Pr. 72 PWM frequency selection Setting (carrier frequency)	008	015	030	050	080	110
1 (1kHz) or less	200m	200m	300m	500m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m	500m

400V class

Pr. 72 PWM frequency selection Setting (carrier frequency)	016	026	040	060	095 or More
1 (1kHz) or less	200m	200m	300m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m



When driving a 400V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor. (Refer to page 92)



- Especially for long-distance wiring, the inverter may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function, fast response current limit function, or stall prevention function or a malfunction or fault of the equipment connected on the inverter output side. If malfunction of fast-response current limit function occurs, disable this function. If malfunction of stall prevention function occurs, increase the stall level. (Refer to page 88 for Pr. 22 Stall prevention operation level and Pr. 156 Stall prevention operation selection)
- Refer to page 170 for details of Pr. 72 PWM frequency selection. Refer to the manual of the option for details of surge voltage suppression filter (FR-ASF-H/FR-BMF-H).
- When using the automatic restart after instantaneous power failure function with wiring length exceeding 100m, select without frequency search (Pr. 162 = "1, 11"). (Refer to page 158)




2.3 Control circuit specifications

2.3.1 Control circuit terminal

indicates that terminal functions can be selected using *Pr. 178 to Pr. 184, Pr. 190 to Pr. 192 (I/O terminal function selection). (Refer to page 135).*

(1) Input signal

Туре	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to Page
	STF	Forward rotation start Reverse rotation start	turn it OFF to stop. Turn ON the STR signal to	When the STF and STR signals are turned ON simultaneously, the stop command is given.		139
	RH, RM, RL	Multi-speed selection	turn it OFF to stop. Multi-speed can be selected combination of RH, RM and	d according to the	Input resistance 4.7kΩ Voltage when contacts are	98
	MRS *	Output stop	Turn ON the MRS signal (20 inverter output. Use to shut off the inverter of motor by electromagnetic bits a Terminal MRS is only availal circuit terminal model.	output when stopping the rake.	open 21 to 26VDC When contacts are short- circuited 4 to 6mADC	137
¥	RES	Reset	Used to reset fault output pro Turn ON the RES signal for it OFF. Factory setting is for reset a reset can be set to enabled Recover about 1s after rese	more than 0.1s, then turn always. By setting <i>Pr. 75</i> , only at fault occurrence.		180
Contact input	SD	Contact input common (sink) External transistor common (source) (initial setting)	Common terminal for contact logic). When connecting the transist output), such as a programm source logic is selected, cor supply common for transisto prevent a malfunction cause.	stor output (open collector mable controller, when nnect the external power or output to this terminal to	_	_
		24VDC power supply common	currents. Common output terminal for supply (PC terminal). Isolated from terminals 5 an	r 24VDC 0.1A power		
		External transistor common (sink)	When connecting the transistor output (open collector output), such as a programmable controller, when sink logic is selected, connect the external power supply common for transistor output to this terminal to prevent a malfunction caused by undesirable currents.		Power supply voltage range 22 to 26.5VDC permissible load current	24
	PC	Contact input common (source) (initial setting) 24VDC power supply	Common terminal for contact logic). Can be used as 24VDC 0.1.	,	1100mA	
		Safety stop input terminal common *	Common terminal for safety and S2. * Terminal S1 and S2 are only stop function model.		_	30





NOTE

common

Set *Pr. 267* and a voltage/current input switch correctly, then input analog signals in accordance with the settings. Applying a voltage with voltage/current input switch in "I" position (current input is selected) or a current with switch in "V" position (voltage input is selected) could cause component damage of the inverter or analog circuit of output devices. *Refer to page 172 for details.*

not earth (ground).



(2) Output signal

Туре	Terminal Symbol	Terminal Name	Description		Rated Specifications	Reference Page
Relay	A, B, C	Relay output (fault output)	1 changeover contact output indicates that the inverter protective function has activated and the output stopped. Fault: discontinuity across B-C (continuity across A-C), Normal: continuity across B-C (discontinuity across A-C)		Contact capacity:230VAC 0.3A (power factor =0.4) 30VDC 0.3A	141
ctor	RUN	Inverter running	Switched low when the inverter output equal to or higher than the starting free value 0.5Hz). Switched high during sto injection brake operation.*	Permissible load 24VDC (maximum 27VDC) 0.1A (a voltage drop is 3.4V maximum when the signal is ON)	141	
Open collector	FU	Frequency detection	Switched low when the inverter output equal to or higher than the preset deter and high when less than the preset defrequency.*	cted frequency	 Low indicates that the open collector output transistor is ON (conducts). High indicates that the transistor is OFF (does not conduct). 	145
	SE	Open collector output common	Common terminal of terminal RUN and FU.		_	_
Analog	АМ	Analog signal output	during inverter reset. The output signal is proportional	maa ootang,	Output signal 0 to 10VDC Permissible load current 1mA (load impedance $10k\Omega$ or more) Resolution 8 bit	150

(3) Communication


_	Terminal			Reference
Туре	Symbol	Terminal Name	Description	Page
			With the PU connector, communication can be made through RS-485.	
35			Conforming standard: EIA-485 (RS-485)	
RS-485	_	PU connector	Transmission format: Multidrop link	207
쭚	<u> </u>		Communication speed: 4800 to 38400bps	
			Overall length: 500m	
			The FR Configurator can be operated by connecting the inverter to the personal	
			computer through USB.	
JSB	_	USB connector	Interface: conforms to USB1.1	241
			Transmission speed: 12Mbps	
			Connector: USB mini B connector (receptacle mini B type)	

2.3.2 Changing the control logic


The input signals are set to source logic (SOURCE) when shipped from the factory.

To change the control logic, the jumper connector above the control terminal must be moved to the other position.

● To change to sink logic, change the jumper connector in the source logic (SOURCE) position to sink logic (SINK) position using tweezers, a pair of long-nose pliers etc. Change the jumper connector position before switching power ON.



Standard control circuit terminal model (Example of FR-E740-095)




Safety stop function model (Example of FR-E740-095SC)



- · Fully make sure that the front cover has been reinstalled securely.
- The capacity plate is placed on the front cover and the rating plate is on the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.
- The sink-source logic change-over jumper connector must be fitted in only one of those positions. If it is fitted in both positions at the same time, the inverter may be damaged.
- Terminal PC is always the common terminal for the safety stop input terminals (S1 and S2) of the inverter with safety stop function regardless of sink/source logic.
- (1) Sink logic type and source logic type
 - In sink logic, a signal switches ON when a current flows from the corresponding signal input terminal.

 Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
 - In source logic, a signal switches ON when a current flows into the corresponding signal input terminal.
 Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.
- Current flow concerning the input/output signal when sink logic is selected
- Current flow concerning the input/output signal when source logic is selected






•When using an external power supply for transistor output


· Sink logic type

Use terminal PC as a common terminal, and perform wiring as shown below. (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



Source logic type

Use terminal SD as a common terminal, and perform wiring as shown below. (Do not connect terminal PC of the inverter with terminal +24V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



2.3.3 Wiring of control circuit


(1) Standard control circuit terminal model

Terminal layout

Terminal screw size

M3: (Terminal A, B, C)

M2: (Other than the above)




Wiring method

1) Strip off the sheath of the wire of the control circuit to wire.

Strip off the sheath about the length below. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.

Wire the stripped wire after twisting it to prevent it from becoming loose. In addition, do not solder it. Use a blade terminal as necessary.







	L(mm)
Terminal A, B, C	6
Other than the above	5

Blade terminals available on the market: (as of Mar. 2008)

Phoenix Contact Co.,Ltd.

Terminal Screw Size	Wire Size (mm ²)	Blade Terminal Model		Blade terminal
		With Insulation Sleeve	Without Insulation Sleeve	crimping tool
M3 (terminal A, B, C)	0.3, 0.5	AI 0,5-6WH	A 0,5-6	
	0.75	AI 0,75-6GY	A 0,75-6	CRIMPFOX ZA3
M2 (other than the above)	0.3, 0.5	AI 0,5-6WH	A 0,5-6	

●NICHIFU Co.,Ltd.

Terminal Screw Size	Wire Size (mm ²)	Blade terminal product number	Insulation product number	Blade terminal crimping tool
M3 (terminal A, B, C)	0.3 to 0.75	BT 0.75-7	VC 0.75	NH 67
M2 (other than the above)	3.3 13 0.70	B1 6.76 7	V 0 0.7 0	107

- 2) Loosen the terminal screw and insert the wire into the terminal.
- 3) Tighten the screw to the specified torque.

Undertightening can cause wire disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.

Tightening torque: 0.5N·m to 0.6N·m (terminal A, B, C)

0.22N·m to 0.25N·m (other than the above)


Screwdriver: ⊖Small flathead screwdriver (Tip thickness: 0.4mm/tip width: 2.5mm)



(2) Safety stop function model

Terminal layout

Recommend wire size: 0.3mm² to 0.75mm²



Wiring method

Use a blade terminal and a wire with a sheath stripped off for the control circuit wiring. For a single wire, strip off the sheath of the wire and apply directly.


Insert the blade terminal or the single wire into a socket of the terminal.

 Strip off the sheath about the size below. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.
 Wire the stripped wire after twisting it to prevent it from becoming loose. In addition, do not solder it.



2) Crimp the blade terminal.

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve. Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.



Blade terminals available on the market: (as of Oct. 2008)

Phoenix Contact Co.,Ltd.

Wire Size (mm ²)	Blade Terminal Model			Blade terminal
	with insulation sleeve	without insulation sleeve	for UL wire*1	crimping tool
0.3	AI 0,5-10WH	_	_	CRIMPFOX ZA3
0.5	AI 0,5-10WH	_	AI 0,5-10WH-GB	
0.75	AI 0,75-10GY	A 0,75-10	AI 0,75-10GY-GB	
1	AI 1-10RD	A1-10	AI 1-10RD/1000GB	CKIIVIFFOX ZAS
1.25, 1.5	AI 1,5-10BK	A1,5-10	AI 1,5-10BK/1000GB*2	
0.75 (for two wires)	AI-TWIN 2 x 0,75-10GY	_	_	


- *1 A blade terminal with an insulation sleeve compatible with MTW wire which has a thick wire insulation
- *2 Applicable for terminal ABC.

●NICHIFU Co.,Ltd.


Wire Size (mm ²)	Blade terminal product number	Insulation product number	Blade terminal crimping tool
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 67

 \mathbb{Z}

3) Insert the wire into a socket.



When using a single wire or stranded wire without a blade terminal, push an open/close button all the way down with a flathead screw driver, and insert the wire.






NOTE

- When using a stranded wire without a blade terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause to damage of inverter or injury.

Wire removal

Pull the wire with pushing the open/close button all the way down firmly with a flathead screwdriver.





NOTE

- Pulling out the terminal block forcefully without pushing the open/close button all the way down may damage the terminal block.
- Use a small flathead screwdriver (Tip thickness: 0.4mm/tip width: 2.5mm).
 If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.

Introduced products :(as of Oct. 2008)

Product	Туре	Maker
Flathead screwdriver	SZF 0- 0,4 x 2,5	Phoenix Contact Co.,Ltd.

 Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause to damage of inverter or injury.



(3) Control circuit common terminals (PC, 5, SE)

Terminals PC, SE and 5 are common terminals for I/O signals.(All common terminals are isolated from each other.) Do not earth them. Avoid connecting the terminal PC and 5 and the terminal SE and 5.


Terminal PC is a common terminal for the contact input terminals (STF, STR, RH, RM, RL, MRS, RES). The open collector circuit is isolated from the internal control circuit by photocoupler

Terminal 5 is a common terminal for the frequency setting signals (terminal 2 or 4) and analog signal output (AM). It should be protected from external noise using a shielded or twisted wire.

Terminal SE is a common terminal for the open collector output terminal (RUN, FU). The contact input circuit is isolated from the internal control circuit by photocoupler.

(4) Signal inputs by contactless switches


The contacted input terminals of the inverter (STF, STR, RH, RM, RL, MRS, RES) can be controlled using a transistor instead of a contacted switch as shown on the right.




External signal input using transistor

(5) Wiring instructions

- 1) It is recommended to use the wires of 0.3mm² to 0.75mm² gauge for connection to the control circuit terminals.
- 2) The maximum wiring length should be 30m.
- 3) Do not short terminal PC and SD. Inverter may be damaged.
- 4) Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.
- 5) Use shielded or twisted wires for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).





6) Do not apply a voltage to the contact input terminals (e.g. STF) of the control circuit.

7) Always apply a voltage to the fault output terminals (A, B, C) via a relay coil, lamp, etc.

2.3.4 Safety stop function (available only for the safety stop function model)

(1) Description of the function

The terminals related to the safety stop function are shown below.

Terminal Symbol		Description		
S1 *1		For input of safety stop channel 1.	Between S1 and PC / S2 and PC Open: In safety stop state.	
S2 *1		For input of safety stop channel 2.	Short: Other than safety stop state.	
PC *1		Common terminal for terminal S1 and S2.		
FU *2	SAFE signal	Outputs the safety stop status The signal is output when inverter output is shut off due to the safety stop function.	OFF: Drive enabled or drive stop (at an internal safety circuit failure*4) ON: Drive stop (no internal safety circuit failure*4)	
RUN *3 SAFE2 Signal Outputs when an alarm or failure is detected. The signal is output when no internal safety circuit		Outputs when an alarm or failure is detected. The signal is output when no internal safety circuit failure*4 exists.	OFF: Internal safety circuit failure*4 ON: No internal safety circuit failure*4	
SE Common terminal for open collector outputs (terminal RUN and FU)		J)		

- *1 In the initial status, terminal S1 and S2 are shorted with terminal PC by shortening wire. Remove the shortening wire and connect the safety relay module when using the safety stop function.
- *2 In the initial setting, output frequency detection (FU signal) is assigned to terminal FU. Set "80" to *Pr.191 FU terminal function selection* to assign SAFE signal. The function can be assigned to other terminals by setting "80 (positive logic) or 180 (negative logic)" to any of *Pr.190 to Pr.192 (Output terminal function selection)*. (*Refer to page 141*)
- *3 In the initial setting, inverter running (RUN signal) is assigned to terminal RUN. Set "81" to Pr.190 RUN terminal function selection to assign SAFE2 signal. The function can be assigned to other terminals by setting "81 (positive logic) or 181 (negative logic)" to any of Pr.190 to Pr.192 (Output terminal function selection). (Refer to page 141)
- *4 At an internal safety circuit failure, one of E.SAF, E.6, E.7, and E.CPU is displayed on the operation panel.




NOTE

- Hold the ON or OFF status for 2ms or longer to input signal to terminal S1 or S2. Signal input shorter than 2ms is not recognized.
- Use SAFE signal to monitor safety stop status. SAFE signal cannot be used as safety stop input signal to other devices (other than the safety relay module).
- SAFE 2 signal can only be used to output an alarm or to prevent restart of an inverter. The signal cannot be used as safety stop input signal to other devices.

(2) Wiring connection diagram

To prevent restart at fault occurrence, connect terminals RUN (SAFE 2 signal) and SE to terminals XS0 and XS1, which are the feedback input terminals of the safety relay module.

By setting Pr. 190 RUN terminal function selection = "81 (SAFE2 signal)", terminal RUN is turned OFF at fault occurrence.



1

NOTE

• Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



(3) Safety stop function operation

Input Input signal		signal	Internal safety circuit*1	Output signal		Inverter operation enable signal
power	S1-PC	S2-PC	internal Salety Circuit*1	SAFE*3	SAFE2*3	inverter operation enable signal
OFF		_	_	OFF	OFF	Output shutoff (Safe state)
Short		Short	No failure	OFF	ON	Drive enabled
	Short	SHOIL	Failure	OFF	OFF	Output shutoff (Safe state)
ON Open	Open	Onon	No failure *2	ON	ON	Output shutoff (Safe state)
ON Open		Open	Failure	OFF	OFF	Output shutoff (Safe state)
	Short		Failure	OFF	OFF	Output shutoff (Safe state)
	Open	Short	Failure	OFF	OFF	Output shutoff (Safe state)


- *1 At an internal safety circuit failure, one of E.SAF, E.6, E.7, and E.CPU is displayed on the operation panel.
- *2 SA is displayed when both of the S1 and S2 signals are in open status and no internal safety circuit failure exists.
- *3 ON: Transistor used for an open collector output is conducted. OFF: Transistor used for an open collector output is not conducted.

For more details, refer to the Safety stop function instruction manual (BCN-A211508-004). (Please contact your sales representative for the manual.)

2.3.5 Connection to the PU connector

Using the PU connector, you can perform communication operation from the parameter unit (FR-PU07), enclosure surface operation panel (FR-PA07) or a personal computer etc.


Refer to the figure below to open the PU connector cover.



•When connecting the parameter unit or enclosure surface operation panel using a connection cable

Use the optional FR-CB2□□ or connector and cable available on the market.

Insert the cable plugs securely into the PU connector of the inverter and the connection connector of the FR-PU07 or FR-PA07 along the guide until the tabs snap into place.



• REMARKS

- Overall wiring length when the parameter unit is connected: max. 20m
- Refer to the following when fabricating the cable on the user side. Examples of product available on the market (as of October 2008)

	Product Type		Maker
1)	10BASE-T cable	SGLPEV-T (Cat5e/300m) 24AWG × 4P	Mitsubishi Cable Industries, Ltd.
2)	RJ-45 connector	5-554720-3	Tyco Electronics Corporation




●RS-485 communication

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

The protocol can be selected from Mitsubishi inverter and Modbus-RTU.

· PU connector pin-outs



Pin Number	Name	Description	
1)	SG	Earth (ground)	
''	36	(connected to terminal 5)	
2)	_	Parameter unit power supply	
3)	RDA	Inverter receive+	
4)	SDB	Inverter send-	
5)	SDA	Inverter send+	
6)	RDB	Inverter receive-	
7)	SG	Earth (ground)	
''	36	(connected to terminal 5)	
8)	_	Parameter unit power supply	



NOTE

- Pins No. 2 and 8 provide power to the parameter unit. Do not use these pins for RS-485 communication.
- When making RS-485 communication with a combination of the FR-E700 series, FR-E500 series and FR-S500 series, incorrect connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in inverter malfunction or failure.
- Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector.

 The product could be damaged due to differences in electrical specifications.

For further details, refer to page 207.

•Conforming standard: EIA-485 (RS-485)

•Transmission form: Multidrop link

•Communication speed: Maximum 38400 bps

•Overall extension: 500m

2.4 Connection of stand-alone option unit


The inverter accepts a variety of stand-alone option units as required.

Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

2.4.1 Connection of a dedicated external brake resistor (MRS type, FR-ABR) (FR-E740-016(SC) or more, FR-E720S-030(SC) or more)

Install a dedicated brake resistor (MRS type, FR-ABR) outside when the motor is made to run by the load, quick deceleration is required, etc. Connect a dedicated brake resistor (MRS type, FR-ABR) to terminal P/+ and PR. (For the locations of terminal P/+ and PR, refer to the terminal block layout (page 16).) Set parameters below.


Connected Brake Resistor	Pr. 30 Regenerative function selection Setting	Pr. 70 Special regenerative brake duty Setting		ke duty Setting
MRS type	0 (initial value)	_		
		FR-E740-170(SC) or less	10%	
FR-ABR	1	FR-E720S-110(SC) or less	1076	Refer to page 126
		FR-E740-230(SC) or more	6%	



- *1 Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.
- *2 The shape of jumper differs according to capacities.



It is recommended to configure a sequence, which shuts off power in the input side of the inverter by the external thermal relay as shown below, to prevent overheat and burnout of the brake resistor (MRS type) and high duty brake resistor (FRABR) in case the regenerative brake transistor is damaged. (The brake resistor cannot be connected to the FR-E720S-008(SC) and 015(SC).)




- *3 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection.

 (Always install a thermal relay when using a brake resistor whose capacity is 11K or more)
- *4 When the power supply is 400V class, install a step-down transformer.

Power Supply Voltage	Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
	MRS120W200	TH-N20CXHZ-0.7A	110VAC 5A,
200V	MRS120W100	TH-N20CXHZ-1.3A	220VAC 2A(AC11 class)
2000	MRS120W60	TH-N20CXHZ-2.1A	110VDC 0.5A,
	MRS120W40	TH-N20CXHZ-3.6A	220VDC 0.25A(DC11class)

Power Supply Voltage	High-duty Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating	
	FR-ABR-0.4K	TH-N20CXHZ-0.7A	110VAC 5A,	
200V	FR-ABR-0.75K	TH-N20CXHZ-1.3A	220VAC 2A(AC11 class) 110VDC 0.5A,	
	FR-ABR-2.2K	TH-N20CXHZ-2.1A	220VDC 0.25A(DC11 class)	
	FR-ABR-H0.4K	TH-N20CXHZ-0.24A		
	FR-ABR-H0.75K	TH-N20CXHZ-0.35A		
	FR-ABR-H1.5K	TH-N20CXHZ-0.9A	110VAC 5A,	
	FR-ABR-H2.2K	TH-N20CXHZ-1.3A	220VAC 2A(AC11 class)	
400V	FR-ABR-H3.7K	TH-N20CXHZ-2.1A	110VDC 0.5A,	
	FR-ABR-H5.5K	TH-N20CXHZ-2.5A	·	
	FR-ABR-H7.5K	TH-N20CXHZ-3.6A	220VDC 0.25A(DC11 class)	
	FR-ABR-H11K	TH-N20CXHZ-6.6A		
	FR-ABR-H15K	TH-N20CXHZ-6.6A		






NOTE

- The brake resistor connected should only be the dedicated brake resistor.
- · Perform wiring and operation according to the Instruction Manual of each option unit.
- Brake resistor can not be used with the brake unit, high power factor converter, power supply regeneration converter,
- Do not use the brake resistor (MRS type, MYS type) with a lead wire extended.
- Do not connect a resistor directly to the terminals P/+ and N/-. This could cause a fire.

2.4.2 Connection of the brake unit (FR-BU2)

Connect the brake unit (FR-BU2(-H)) as shown below to improve the braking capability at deceleration. If the transistors in the brake unit should become faulty, the resistor can be unusually hot. To prevent unusual overheat and fire, install a magnetic contactor on the inverter's input side to configure a circuit so that a current is shut off in case of fault.


(1) Connection example with the GRZG type discharging resistor



- Connect the inverter terminals (P/+ and N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other.
 - (Incorrect connection will damage the inverter and brake unit.)
- When the power supply is 400V class, install a step-down transformer.
- The wiring distance between the inverter, brake unit (FR-BU2) and discharging resistor should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- It is recommended to install an external thermal relay to prevent overheat of discharging resistors.
- Refer to FR-BU2 manual for connection method of discharging resistor.

<Recommended external thermal relay>

Brake Unit	Discharging Resistor	Recommended External	
Drake Unit	Discharging Resistor	Thermal Relay	
FR-BU2-1.5K	GZG 300W-50Ω (one)	TH-N20CXHZ 1.3A	
FR-BU2-3.7K	GRZG 200-10 Ω (three in series)	TH-N20CXHZ 3.6A	
FR-BU2-7.5K	GRZG 300-5 Ω (four in series)	TH-N20CXHZ 6.6A	
FR-BU2-15K	GRZG 400-2 Ω (six in series)	TH-N20CXHZ 11A	
FR-BU2-H7.5K	GRZG 200-10 Ω (six in series)	TH-N20CXHZ 3.6A	
FR-BU2-H15K	GRZG 300-5 Ω (eight in series)	TH-N20CXHZ 6.6A	






- Set "1" in *Pr. 0 Brake mode selection* of the FR-BU2 to use GRZG type discharging resistor.
 Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

t 🦵

(2) Connection example with the FR-BR(-H) type resistor



- *1 Connect the inverter terminals (P/+ and N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other
 - (Incorrect connection will damage the inverter and brake unit.)
- *2 When the power supply is 400V class, install a step-down transformer.
- *3 The wiring distance between the inverter, brake unit (FR-BU2) and resistor unit (FR-BR) should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- *4 Normal: across TH1-TH2...close, Alarm: across TH1-TH2...open
- *5 A jumper is connected across BUE and SD in the initial status.




NOTE

• Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

2.4.3 Connection of the high power factor converter (FR-HC)

When connecting the high power factor converter (FR-HC) to suppress power harmonics, perform wiring securely as shown below. Incorrect connection will damage the high power factor converter and inverter.



- *1 Keep input terminals (R/L1, S/L2, T/L3) open. Incorrect connection will damage the inverter.
- *2 Do not insert an MCCB between the terminals P/+ and N/- (between P and P/+, between N and N/-). Opposite polarity of terminals N/- and P/+ will damage the inverter.
- *3 Use Pr. 178 to Pr. 184 (input terminal function selection) to assign the terminals used for the X10, RES signal. (Refer to page 135)
- *4 Be sure to connect terminal RDY of the FR-HC to the X10 signal or MRS signal assigned terminal of the inverter, and connect terminal SE of the FR-HC to terminal SD of the inverter. Without proper connecting, FR-HC will be damaged.




NOTE

- The voltage phases of terminals R/L1, S/L2, T/L3 and terminals R4, S4, T4 must be matched.
- Use sink logic when the FR-HC is connected. The FR-HC cannot be connected when source logic (factory setting) is selected.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

2.4.4 Connection of the power regeneration common converter (FR-CV)

When connecting the power regeneration common converter (FR-CV), connect the inverter terminals (P/+, N/-) and power regeneration common converter (FR-CV) terminals as shown below so that their symbols match with each other.



- *1 Keep input terminals (R/L1, S/L2, T/L3) open. Incorrect connection will damage the inverter.
- *2 Do not insert an MCCB between the terminals P/+ and N/- (between P/L+ and P/+, between N/L- and N/-). Opposite polarity of terminals N/- and P/+ will damage the inverter.
- *3 Always connect the power supply and terminals R/L11, S/L21, T/MC1.
 - Operating the inverter without connecting them will damage the power regeneration common converter.
- *4 Use Pr. 178 to Pr. 184 (input terminal function selection) to assign the terminals used for the X10, RES signal. (Refer to page 135)
- *5 Be sure to connect terminal RDYB of the FR-CV to the X10 signal or MRS signal assigned terminal of the inverter, and connect terminal SE of the FR-CV to terminal SD of the inverter. Without proper connecting, FR-CV will be damaged.




NOTE

- The voltage phases of terminals R/L11, S/L21, T/MC1 and terminals R2/L1, S2/L2, T2/L3 must be matched.
- Use sink logic when the FR-CV is connected. The FR-CV cannot be connected when source logic (factory setting) is selected.
- Do not remove a jumper across terminal P/+ and P1.

2.4.5 Connection of the DC reactor (FR-HEL)

When using the DC reactor (FR-HEL), connect it across terminals P/+ and P1.

In this case, the jumper connected across terminals P/+ and P1 must be removed. Otherwise, the reactor will not exhibit its performance.





NOTE

- The wiring distance should be within 5m.
- The size of the cables used should be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3). (Refer to page 18)

PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the "PRECAUTIONS FOR USE OF THE INVERTER" for use of this product.

Always read the instructions before using the equipment.

3.1	EMC and leakage currents	40
	Installation of power factor improving reactor	
3.3	Power-OFF and magnetic contactor (MC)	46
3.4	Inverter-driven 400V class motor	47
3.5	Precautions for use of the inverter	48
3.6	Failsafe of the system which uses the inverter	50

3.1 EMC and leakage currents

3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following measures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

(1) To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earthing cable, etc. These leakage currents may operate earth (ground) leakage circuit breakers and earth leakage relays unnecessarily.

Suppression technique

- If the carrier frequency setting is high, decrease the *Pr. 72 PWM frequency selection* setting.

 Note that motor noise increases. Selecting *Pr. 240 Soft-PWM operation selection* makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).
- To-earth (ground) leakage currents
 - Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
 - Increasing the motor capacity increases the leakage current. The leakage current of the 400V class is larger than that of the 200V class.

(2) Line-to-line leakage currents


Harmonics of leakage currents flowing in static capacitances between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50m or more) for the 400V class small-capacity model (FR-E740-170(SC) or less), the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.

•Line-to-line leakage current data example

Motor Capacity	Rated Motor	Leakage Current (mA)		
(kW)	Current (A)	Wiring length 50m	Wiring length 100m	
0.4	1.1	620	1000	
0.75	1.9	680	1060	
1.5	3.5	740	1120	
2.2	4.1	800	1180	
3.7	6.4	880	1260	
5.5	9.7	980	1360	
7.5	12.8	1070	1450	

Motor: SF-JR 4PCarrier frequency: 14.5kHzUsed wire: 2mm², 4 cores

Cabtyre cable



Line-to-line leakage currents path

Measures

- Use Pr. 9 Electronic thermal O/L relay.
- If the carrier frequency setting is high, decrease the Pr. 72 PWM frequency selection setting.
 Note that motor noise increases. Selecting Pr. 240 Soft-PWM operation selection makes the sound inoffensive.
 To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.

•Installation and selection of moulded case circuit breaker

Install a moulded case circuit breaker (MCCB) on the power receiving side to protect the wiring of the inverter input side. Select the MCCB according to the inverter input side power factor (which depends on the power supply voltage, output frequency and load). Especially for a completely electromagnetic MCCB, one of a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.



(3) Selection of rated sensitivity current of earth (ground) leakage current breaker

When using the earth leakage current breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

 Breaker designed for harmonic and surge suppression
 Rated sensitivity current:


I∆n≥10×(lg1+lgn+lgi+lg2+lgm)

· Standard breaker


Rated sensitivity current:

 $I\Delta n \ge 10 \times \{Ig1 + Ign + Igi + 3 \times (Ig2 + Igm)\}$

Example of leakage current of cable path per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (200V 60Hz)



Example of leakage current of three-phase induction motor during the commercial power supply operation (200V 60Hz)



Ig1, Ig2: Leakage currents in wire path during commercial power supply operation


Ign: Leakage current of inverter input side noise filter

Igm: Leakage current of motor during commercial power


supply operation

lgi: Leakage current of inverter unit

Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (Three-phase three-wire delta connection 400/60Hz)




Example of leakage current of threephase induction motor during the commercial power supply operation (Totally-enclosed fan-cooled type motor 400V60Hz)



For "_" connection, the amount of leakage current is appox.1/3 of the above value.

<Example>



	Breaker Designed for Harmonic and Surge Suppression	Standard Breaker
Leakage current lg1 (mA)	$\frac{1}{3} \times 66 \times \frac{5m}{1000m} = 0.11$	
Leakage current Ign (mA)	0 (without noise filter)	
Leakage current Igi (mA)	1	
Leakage current lg2 (mA)	$\frac{1}{3} \times 66 \times \frac{60}{100}$)m = 1.32
Leakage current ig2 (IIIA)	3 ^ 00 ^ 100	00m
Motor leakage current Igm (mA)	0.36	
Total leakage current (mA)	2.79	6.15
Rated sensitivity current (mA) (\geq lg \times 10)	30	100



NOTE


- Install the earth leakage breaker (ELB) on the input side of the inverter.
- In the A connection earthed-neutral system, the sensitivity current is blunt against an earth (ground) fault in the
 inverter output side. Earthing (Grounding) must conform to the requirements of national and local safety regulations
 and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is less than the rating.
- In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- General products indicate the following models. BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F earth leakage relay (except NV-ZHA), NV with AA neutral wire open-phase protection
 - The other models are designed for harmonic and surge suppressionNV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2, earth leakage alarm breaker (NF-Z), NV-ZHA, NV-H


3.1.2 EMC measures

Some electromagnetic noises enter the inverter to malfunction it and others are radiated by the inverter to malfunction peripheral devices. Though the inverter is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate electromagnetic noises. If these electromagnetic noises cause peripheral devices to malfunction, EMI measures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

- (1) Basic techniques
 - Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle them.
 - Use twisted shield cables for the detector connecting and control signal cables and connect the sheathes of the shield cables to terminal SD.
 - · Earth (Ground) the inverter, motor, etc. at one point.
- (2) Techniques to reduce electromagnetic noises that enter and malfunction the inverter (Immunity measures) When devices that generate many electromagnetic noises (which use magnetic contactors, magnetic brakes, many relays, for example) are installed near the inverter and the inverter may be malfunctioned by electromagnetic noises, the following measures must be taken:
 - Provide surge suppressors for devices that generate many electromagnetic noises to suppress electromagnetic noises.
 - Fit data line filters (page 43) to signal cables.
 - · Earth (Ground) the shields of the detector connection and control signal cables with cable clamp metal.
- (3) Techniques to reduce electromagnetic noises that are radiated by the inverter to malfunction peripheral devices (EMI measures)

Inverter-generated electromagnetic noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.








Propagation Path	Measures
	When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g.
	instruments, receivers and sensors, are contained in the enclosure that contains the inverter or when their signal
	cables are run near the inverter, the devices may be malfunctioned by air-propagated electromagnetic noises. The
	following measures must be taken:
(1)(2)(3)	Install easily affected devices as far away as possible from the inverter.
	Run easily affected signal cables as far away as possible from the inverter and its I/O cables.
	Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
	Insert common mode filters into I/O and capacitors between the input lines to suppress cable-radiated noises.
	• Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises
	may be propagated to the signal cables to malfunction the devices and the following measures must be taken:
(4)(5)(6)	Install easily affected devices as far away as possible from the inverter.
(4)(3)(0)	Run easily affected signal cables as far away as possible from the I/O cables of the inverter.
	• Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
	• Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.
	When the power supplies of the peripheral devices are connected to the power supply of the inverter in the same line,
(7)	inverter-generated noises may flow back through the power supply cables to malfunction the devices and the
(1)	following measures must be taken:
	Install the common mode filter (FR-BLF, FR-BSF01) to the power cables (output cable) of the inverter.
	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage currents may
(8)	flow through the earthing cable of the inverter to malfunction the device. In such a case, disconnection of the earthing
	cable of the device may cause the device to operate properly.

●Data line filter

Data line filter is effective as an EMC measure. Provide a data line filter for the detector cable, etc.

●EMC measures



NOTE

For compliance with the EU EMC directive, please $\it refer$ the $\it Installation$ $\it Guideline$.

3.1.3 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


•The differences between harmonics and RF noises are indicated below:

Item	Harmonics	Noise		
Frequency	Normally 40th to 50th degrees or less	High frequency (several 10kHz to 1GHz order)		
rrequency	(up to 3kHz or less)	Thigh hequency (several TOKEZ to TGEZ Order)		
Environment	To-electric channel, power impedance	To-space, distance, wiring path		
Quantitative understanding	Theoretical calculation possible	Random occurrence, quantitative grasping difficult		
Generated amount	Nearly proportional to load capacity	Change with current variation ratio (larger as switching		
Generated amount	Nearly proportional to load capacity	speed increases)		
Affected equipment immunity	Specified in standard per equipment	Different depending on maker's equipment specifications		
Suppression example	Provide reactor.	Increase distance.		

Suppression technique

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that they should be calculated in the conditions under the rated load at the maximum operating frequency.





NOTE


The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the inverter input side or in the DC circuit.




3.2 Installation of power factor improving reactor


When the inverter is connected near a large-capacity power transformer (500kVA or more) or when a power capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an optional reactor (FR-HAL, FR-HEL).

Three-phase power input





Single-phase power input



* When connecting the FR-HEL, remove the jumper across terminals P/+ and P1.
The wiring length between the FR-HEL and inverter should be 5m maximum and minimized.

> REMARKS

• Use the same wire size as that of the power supply wire (R/L1, S/L2, T/L3). (Refer to page 18)

current when making an emergency stop during normal operation.

3.3 Power-OFF and magnetic contactor (MC)

(1) Inverter input side magnetic contactor (MC)


On the inverter input side, it is recommended to provide an MC for the following purposes. (Refer to *page 4* for selection.)

- 1) To release the inverter from the power supply when the fault occurs or when the drive is not functioning (e.g. emergency stop operation). For example, MC avoids overheat or burnout of the brake resistor when heat capacity of the resistor is insufficient or brake regenerative transistor is damaged with short while connecting an optional brake resistor.
- 2) To prevent any accident due to an automatic restart at restoration of power after an inverter stop by a power failure
- 3) To separate the inverter from the power supply to ensure safe maintenance and inspection work.

 The inverter's input side MC is used for the above purpose, select class JEM1038-AC3 MC for the inverter input side

• REMARKS

Since repeated inrush currents at power ON will shorten the life of the converter circuit (switching life is about 1,000,000 times.), frequent starts and stops of the magnetic contactor must be avoided. Turn ON/OFF the inverter start controlling terminals (STF, STR) to run/stop the inverter.



• Inverter start/stop circuit example

As shown on the left, always use the start signal (ON or OFF of STF (STR) signal) to make a start or stop.

*When the power supply is 400V class, install a step-down transformer.

(2) Handling of inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned ON while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided for switching to the commercial power supply, for example, switch it ON/OFF after the inverter and motor have stopped.



Inverter-driven 400V class motor 3.4

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially for a 400V class motor, the surge voltage may deteriorate the insulation. When the 400V class motor is driven by the inverter, consider the following measures:

Measures

It is recommended to take either of the following measures:

(1) Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length

For the 400V class motor, use an insulation-enhanced motor.

Specifically,

- 1) Specify the "400V class inverter-driven insulation-enhanced motor".
- 2) For the dedicated motor such as the constant-torque motor and low-vibration motor, use the "inverter-driven, dedicated
- 3) Set Pr. 72 PWM frequency selection as indicated below according to the wiring length

		Wiring Length	
	50m or less	50m to 100m	exceeding 100m
Pr. 72 PWM frequency selection	15 (14.5kHz) or less	8 (8kHz) or less	2 (2kHz) or less

(2) Suppressing the surge voltage on the inverter side

Connect the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) on the inverter output side.



NOTE

- For details of *Pr. 72 PWM frequency selection*, *refer to page 170*.
 For explanation of surge voltage suppression filter (FR-ASF-H/FR-BMF-H), refer to the manual of each option.

3.5 Precautions for use of the inverter

The FR-E700 series is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following points.

- (1) Use crimping terminals with insulation sleeve to wire the power supply and motor.
- (2) Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.
- (3) After wiring, wire offcuts must not be left in the inverter.
 - Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
 - When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- (4) Use cables of the size to make a voltage drop 2% maximum.
 - If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.
 - Refer to page 18 for the recommended wire sizes.
- (5) The overall wiring length should be 500m maximum.
 - Especially for long distance wiring, the fast-response current limit function may decrease or the equipment connected to the secondary side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. (*Refer to page 20*)
- (6) Electromagnetic wave interference
 - The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install options among the capacitor type EMC filter FR-BIF (for use in the input side only), the ferrite core type EMC filter FR-BSF01/FR-BLF, filterpack, and EMC filter to minimize the interference.
- (7) Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them. (When using capacitor type filter (FR-BIF) for single-phase power input model, make sure of secure insulation of T/L3-phase, and connect to the input side of the inverter.)
- (8) For some short time after the power is switched OFF, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the inverter is not more than 30VDC using a tester, etc. The capacitor is charged with high voltage for some time after power OFF and it is dangerous.
- (9) A short circuit or earth (ground) fault on the inverter output side may damage the inverter modules.
 - Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation resistance may damage the inverter modules.
 - Fully check the to-earth (ground) insulation and phase to phase insulation of the inverter output side before power-ON. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.
- (10) Do not use the inverter input side magnetic contactor to start/stop the inverter.
 - Always use the start signal (turn ON/OFF of STF, STR signal) to start/stop the inverter. (Refer to page 46)




(11) Across terminals P/+ and PR, connect only an external regenerative brake discharging resistor.

Do not connect a mechanical brake.

The brake resistor can not be connected to the FR-E720S-008(SC) and 015(SC). Leave terminals P/+ and PR open. Also, never short between these terminals.

- (12) Do not apply a voltage higher than the permissible voltage to the inverter I/O signal circuits.

 Application of a voltage higher than the permissible voltage to the inverter I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10-5.
- (13) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for bypass operation. When the wiring is incorrect and if there is a bypass operation circuit as shown right, the inverter will be damaged when the power supply is connected to the inverter U, V, W terminals, due to arcs generated at the time of switch-over or chattering caused by a sequence error.



- (14) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's input side and also make up a sequence which will not switch ON the start signal.
 If the start signal (start switch) remains ON after a power failure, the inverter will automatically restart as soon as the power is restored.
- (15) Instructions for overload operation

When performing operation of frequent start/stop of the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, choose the inverter which has enough allowance for current (up to 2 rank larger in capacity).

- (16) Make sure that the specifications and rating match the system requirements.
- (17) If electromagnetic noise generated from the inverter causes frequency setting signal to fluctuate and motor rotation speed to be unstable when changing motor speed with analog signal, the following countermeasures are effective.
 - Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
 - Run signal cables as far away as possible from power cables (inverter I/O cables).
 - Use shield cables as signal cables.
 - Install a ferrite core on the signal cable (Example: ZCAT3035-1330 TDK).

3.6 Failsafe of the system which uses the inverter

When a fault occurs, the inverter trips to output a fault signal. However, a fault output signal may not be output at an inverter fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi assures best quality products, provide an interlock which uses inverter status output signals to prevent accidents such as damage to machine when the inverter fails for some reason and at the same time consider the system configuration where failsafe from outside the inverter, without using the inverter, is enabled even if the inverter fails.


(1) Interlock method which uses the inverter status output signals By combining the inverter status output signals to provide an interlock as shown below, an inverter alarm can be detected.

No	Interlock Method	Check Method	Used Signals	Refer to Page
1)	Inverter protective function operation	Operation check of an alarm contact Circuit error detection by negative logic	Fault output signal (ALM signal)	144
2)	Inverter running status	Operation ready signal check	Operation ready signal (RY signal)	143
3)	Inverter running status	Logic check of the start signal and running signal	Start signal (STF signal, STR signal) Running signal (RUN signal)	139, 143
4)	Inverter running status	Logic check of the start signal and output current	Start signal (STF signal, STR signal) Output current detection signal (Y12 signal)	139, 146

1) Check by the output of the inverter fault signal When the fault occurs and trips the inverter, the fault output signal (ALM signal) is output (ALM signal is assigned to terminal ABC in the initial setting).

Check that the inverter functions properly.

In addition, negative logic can be set (ON when the inverter is normal, OFF when the fault occurs).




Inverter fault occurrence

- 2) Checking the inverter operating status by the inverter operation ready completion signal Operation ready signal (RY signal) is output when the inverter power is on and the inverter becomes operative. Check if the RY signal is output after powering ON the inverter.
- 3) Checking the inverter operating status by the start signal input to the inverter and inverter running signal.

The inverter running signal (RUN signal) is output when the inverter is running (RUN signal is assigned to terminal RUN in the initial setting).

Check if RUN signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). For logic check, note that RUN signal is output for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time





4) Checking the motor operating status by the start signal input to the inverter and inverter output current detection signal. The output current detection signal (Y12 signal) is output when the inverter operates and currents flows in the motor. Check if Y12 signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). Note that the current level at which Y12 signal is output is set to 150% of the inverter rated current in the initial setting, it is necessary to adjust the level to around 20% using no load current of the motor as reference with *Pr.150 Output current detection level*.

For logic check, as same as the inverter running signal (RUN signal), the inverter outputs for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time.

Output	Pr. 190 to Pr.	. 192 Setting
signal	Positive logic	Negative logic
ALM	99	199
RY	11	111
RUN	0	100
Y12	12	112

 When using various signals, assign functions to Pr.190 to Pr.192 (output terminal function selection) referring to the table on the left.



NOTE

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.

(2) Backup method outside the inverter

Even if the interlock is provided by the inverter status signal, enough failsafe is not ensured depending on the failure status of the inverter itself. For example, when the inverter CPU fails, even if the interlock is provided using the inverter fault output signal, start signal and RUN signal output, there is a case where a fault output signal is not output and RUN signal is kept output even if an inverter fault occurs.


Provide a speed detector to detect the motor speed and current detector to detect the motor current and consider the backup system such as checking up as below according to the level of importance of the system.

1) Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the inverter by comparing the start signal to the inverter and detected speed of the speed detector or detected current of the current detector. Note that the motor current runs as the motor is running for the period until the motor stops since the inverter starts decelerating even if the start signal turns off. For the logic check, configure a sequence considering the inverter deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

2) Command speed and actual operation check

Check if there is no gap between the actual speed and commanded speed by comparing the inverter speed command and detected speed of the speed detector.



MEMO

4 / PARAMETERS

This chapter explains the "PARAMETERS" for use of this product.

Always read the instructions before using the equipment.

The following marks are used to indicate the controls as below.

W/FV/F control

ADMINICALAdvanced magnetic flux vector control

GPMFVCGeneral-purpose magnetic flux vector control

(Parameters without any mark are valid for all controls.)

1

2

3

1

5

6

7

Operation panel

4.1.1 Names and functions of the operation panel

The operation panel cannot be removed from the inverter.

Operation mode indication

PU: Lit to indicate PU operation mode.

EXT: Lit to indicate External operation mode. (Lit at power-ON at initial setting.)

NET: Lit to indicate Network operation mode.

PU, EXT: Lit to indicate External/PU combined operation mode 1, 2.

These turn OFF when command source is not on operation panel (Refer to page 201).

Unit indication

Hz: Lit to indicate frequency. (Flickers when the set frequency monitor is displayed.)

A: Lit to indicate current.

(Both "Hz" and "A" turn OFF when other than the above is displayed.)

Monitor (4-digit LED)

Shows the frequency, parameter number,

Setting dial

(Setting dial: Mitsubishi inverter dial) Used to change the frequency setting and parameter values.

Press to display the following.

- Displays the set frequency in the monitor mode
- · Present set value is displayed during calibration
- · Displays the order in the faults history

Mode switchover

Used to change each setting mode.




Pressing $\frac{PU}{EXT}$ simultaneously changes


the operation mode. (Refer to page 56) Pressing for a while (2s) can lock operation.

(Refer to page 269)

Determination of each setting

If pressed during operation, monitor changes as below;





Operating status indication

Lit or flicker during inverter operation. *

ON: Indicates that forward rotation operation is being performed. Slow flickering (1.4s cycle):

Reverse rotation operation Fast flickering (0.2s cycle):

(RUN) was pressed or the

start command was given, but the operation can not be made.

- •When the frequency command is less than the starting frequency.
- •When the MRS signal is input.

Parameter setting mode

Lit to indicate parameter setting mode.

Monitor indication

Lit to indicate monitoring mode.

Stop operation

Used to stop Run command. Fault can be reset when protective function is activated (fault).

Operation mode switchover

Used to switch between the PU and External operation mode.

When using the External operation mode (operation using a separately connected frequency setting potentiometer and start signal), press this key to light up the EXT indication.


(Press (MODE) simultaneously (0.5s) (Refer

to page 56), or change Pr. 79 setting to change to combined mode .) PU: PU operation mode EXT: External operation mode Cancels PU stop also.

Start command

The rotation direction can be selected by setting Pr. 40.

4.1.2 Basic operation (factory setting)



Easy operation mode setting (easy setting mode)

Setting of Pr. 79 Operation mode selection according to combination of the start command and speed command can be easily made.

Operation example

Start command: external (STF/STR), frequency command: operate with



1. Screen at powering ON The monitor display appears.

Display -

2. Press $\left(\frac{PU}{FXT}\right)$ and $\left(MODE\right)$ for 0.5s.

Flickering

3. Turn \bigcirc until 79 - 3 appears. (refer to the table below for other settings)

Operation -





Operation Panel Indication	Operatio	n Method
Operation Failer indication	Start command	Frequency command
Flickering Flickering	RUN	
Flickering	External (STF, STR)	Analog voltage input
Flickering	External (STF, STR)	
Flickering	RUN	Analog voltage input

4. Press(SET) to set.







Flicker ··· Parameter setting complete!! , The monitor display appears after 3s.





> REMARKS

Pr. 79 is not registered in user group with "1" in Pr. 160 User group read selection.

Parameter write is disabled with "1" set in Pr. 77.

? Er∂ is displayed ... Why?


Setting can not be made during operation. Turn the start switch ((RUN), STF or STR) OFF.

- If (MODE) is pressed before pressing (SET), the easy setting mode is terminated and the display goes back to the monitor display. If the easy setting mode is terminated while Pr. 79 = "0 (initial setting)," the operation mode switches between the PU operation mode and the External operation mode. Check the operation mode.
- Reset can be made with
 RESET
- The priorities of the frequency commands when Pr.79 = "3" are "Multi-speed operation (RL/RM/RH/REX) > PID control (X14) > terminal 4 analog input (AU) > digital input from the operation panel".

4.1.4 Changing the parameter setting value

Changing example


Change the Pr. 1 Maximum frequency setting.



Flicker...Parameter setting complete!!

- to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.
- Press (MODE) twice to return the monitor to frequency monitor.

(I) REMARKS



The number of digits displayed on the operation panel is four. Only the upper four digits of values can be displayed and set. If the values to be displayed have five digits or more including decimal places, the fifth or later numerals can not be displayed nor set. (Example) For Pr. 1

When 50Hz is set, 50.00 is displayed.

When 120Hz is set, 120.0 is displayed and second decimal place is not displayed nor set.

4.1.5 Setting dial push



Push the setting dial () to display the set frequency* currently set.

* Appears when PU operation mode or External/PU combined operation mode 1 is selected (Pr. 79 ="3").

4.2 Parameter list

4.2.1 Parameter list

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check are available from the operation panel.

• REMARKS

- @ indicates simple mode parameters. (initially set to extended mode)
- The parameters surrounded by a black border in the table allow its setting to be changed during operation even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	© 0	Torque boost	0 to 30%	0.1%	6/4/3/2% *1	81	
	⊚ 1	Maximum frequency	0 to 120Hz	0.01Hz	120Hz	92	
	@ 2	Minimum frequency	0 to 120Hz	0.01Hz	0Hz	92	
ω	@ 3	Base frequency	0 to 400Hz	0.01Hz	50Hz	94	
ion	© 4	Multi-speed setting (high speed)	0 to 400Hz	0.01Hz	50Hz	98	
ınct	© 5	Multi-speed setting (middle speed)	0 to 400Hz	0.01Hz	30Hz	98	
c fu	© 6	Multi-speed setting (low speed)	0 to 400Hz	0.01Hz	10Hz	98	
asi	⊚ 7	Acceleration time	0 to 3600/360s	0.1/0.01s	5/10/15s *2	105	
ш	@ 8	Deceleration time	0 to 3600/360s	0.1/0.01s	5/10/15s *2	105	
	© 9	Electronic thermal O/L relay	0 to 500A	0.01A	Rated inverter current	112	
tion	10	DC injection brake operation frequency	0 to 120Hz	0.01Hz	3Hz	124	
injec	11	DC injection brake operation time	0 to 10s	0.1s	0.5s	124	
DC	12	DC injection brake operation voltage	0 to 30%	0.1%	6/4/2% *3	124	
	13	Starting frequency	0 to 60Hz	0.01Hz	0.5Hz	108	
_	14	Load pattern selection	0 to 3	1	0	96	
oG ation	15	Jog frequency	0 to 400Hz	0.01Hz	5Hz	100	
JC	16	Jog acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	0.5s	100	
_	17	MRS input selection	0, 2, 4	1	0	137	
_	18	High speed maximum frequency	120 to 400Hz	0.01Hz	120Hz	92	
_	19	Base frequency voltage	0 to 1000V, 8888, 9999	0.1V	8888	94	
Acceleration/ deceleration time	20	Acceleration/deceleration reference frequency	1 to 400Hz	0.01Hz	50Hz	105	
Accele decelera	21	Acceleration/deceleration time increments	0, 1	1	0	105	
all	22	Stall prevention operation level	0 to 200%	0.1%	150%	88	
Stall	23	Stall prevention operation level compensation factor at double speed	0 to 200%, 9999	0.1%	9999	88	
p	24	Multi-speed setting (speed 4)	0 to 400Hz, 9999	0.01Hz	9999	98	
pee	25	Multi-speed setting (speed 5)	0 to 400Hz, 9999	0.01Hz	9999	98	
ulti-spee setting	26	Multi-speed setting (speed 6)	0 to 400Hz, 9999	0.01Hz	9999	98	
Multi-speed setting	27	Multi-speed setting (speed 7)	0 to 400Hz, 9999	0.01Hz	9999	98	
_	29	Acceleration/deceleration pattern selection	0, 1, 2	1	0	109	



Ver.UP ... Specifications differ according to the date assembled. *Refer to page 324* to check the SERIAL number.

- Symbols in the table indicate parameters which function when an option is mounted.
- AX FR-A7AX E kit, AY FR-A7AY E kit, AR FR-A7AR E kit, NC FR-A7NC E kit, ND FR-A7ND E kit, NLFR-A7NL E kit, NP FR-A7NP E kit
- These instruction codes are used for parameter read and write by using Mitsubishi inverter protocol with the RS-485 communication. (Refer to page 210 for RS-485 communication)
- "O" indicates valid and "x" indicates invalid of "control mode-based correspondence table", "parameter copy", "parameter clear", and "all parameter clear".

Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba spondence			Parameter		
		Read	Write	Extended	_V/F _	AD-MFVC	GP-MFVC	Сору	Clear	All clear	
⊚ 0		00	80	0	0	×	×	0	0	0	
© 1		01	81	0	0	0	0	0	0	0	
@ 2		02	82	0	0	0	0	0	0	0	
© 3		03	83	0	0	×	×	0	0	0	
© 4		04	84	0	0	0	0	0	0	0	
© 5		05	85	0	0	0	0	0	0	0	
© 6		06	86	0	0	0	0	0	0	0	
© 7		07	87	0	0	0	0	0	0	0	
@ 8		08	88	0	0	0	0	0	0	0	
© 9		09	89	0	0	0	0	0	0	0	
10		0A	8A	0	0	0	0	0	0	0	
11		0B	8B	0	0	0	0	0	0	0	
12		0C	8C	0	0	0	0	0	0	0	
13		0D	8D	0	0	0	0	0	0	0	
14		0E	8E	0	0	×	×	0	0	0	
15		0F	8F	0	0	0	0	0	0	0	
16		10	90	0	0	0	0	0	0	0	
17		11	91	0	0	0	0	0	0	0	
18		12	92	0	0	0	0	0	0	0	
19		13	93	0	0	×	×	0	0	0	
20		14	94	0	0	0	0	0	0	0	
21		15	95	0	0	0	0	0	0	0	
22		16	96	0	0	0	0	0	0	0	
23		17	97	0	0	0	0	0	0	0	
24		18	98	0	0	0	0	0	0	0	
25		19	99	0	0	0	0	0	0	0	
26		1A	9 <i>A</i>	0	0	0	0	0	0	0	
27		1B	9B	0	0	0	0	0	0	0	
29		1D	9D	0	0	0	0	0	0	0	

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	30	Regenerative function selection	0, 1, 2	1	0	126, 158	
0	31	Frequency jump 1A	0 to 400Hz, 9999	0.01Hz	9999	93	
Frequency jump	32	Frequency jump 1B	0 to 400Hz, 9999	0.01Hz	9999	93	
i y	33	Frequency jump 2A	0 to 400Hz, 9999	0.01Hz	9999	93	
enc	34	Frequency jump 2B	0 to 400Hz, 9999	0.01Hz	9999	93	
nbe	35	Frequency jump 3A	0 to 400Hz, 9999	0.01Hz	9999	93	
Ē	36	Frequency jump 3B	0 to 400Hz, 9999	0.01Hz	9999	93	
	37	Speed display	0, 0.01 to 9998	0.001	0	149	
_	40	RUN key rotation direction selection	0, 1	1	0	268	
>	41	Up-to-frequency sensitivity	0 to 100%	0.1%	10%	145	
ion	42	Output frequency detection	0 to 400Hz	0.01Hz	6Hz	145	
Frequency detection	43	Output frequency detection for reverse rotation	0 to 400Hz, 9999	0.01Hz	9999	145	
	44	Second acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	5/10/15s *2	105, 249	
Second functions	45	Second deceleration time	0 to 3600/360s, 9999	0.1/0.01s	9999	105, 249	
fun	46	Second torque boost	0 to 30%, 9999	0.1%	9999	81	
puc	47	Second V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	94	
Sec	48	Second stall prevention operation current	0 to 200%, 9999	0.1%	9999	88	
	51	Second electronic thermal O/L relay	0 to 500A, 9999	0.01A	9999	112	
SL	52	DU/PU main display data selection	0, 5, 7 to 12, 14, 20, 23 to 25, 52 to 57, 61, 62, 100	1	0	150	
ži Į	55	Frequency monitoring reference	0 to 400Hz	0.01Hz	50Hz	155	
Monitor functions	56	Current monitoring reference	0 to 500A	0.01A	Rated inverter current	155	
omatic restart functions	57	Restart coasting time	0, 0.1 to 5s, 9999	0.1s	9999	158	
Automa	58	Restart cushion time	0 to 60s	0.1s	1s	158	
_	59	Remote function selection	0, 1, 2, 3	1	0	102	
_	60	Energy saving control selection	0, 9	1	0	169	
ration	61	Reference current	0 to 500A, 9999	0.01A	9999	110	
matic acceler /deceleration	62	Reference value at acceleration	0 to 200%, 9999	1%	9999	110	
Automatic acceleration /deceleration	63	Reference value at deceleration	0 to 200%, 9999	1%	9999	110	
_	65	Retry selection	0 to 5	1	0	166	
_	66	Stall prevention operation reduction starting frequency	0 to 400Hz	0.01Hz	50Hz	88	
	67	Number of retries at fault occurrence	0 to 10, 101 to 110	1	0	166	
Retry	68	Retry waiting time	0.1 to 360s	0.1s	1s	166	
ď	69	Retry count display erase	0	1	0	166	
_	70	Special regenerative brake duty	0 to 30%	0.1%	0%	126	
_	71	Applied motor	0, 1, 3 to 6, 13 to 16, 23, 24, 40, 43, 44, 50, 53, 54	1	0	82, 85, 114, 116,	
_	72	PWM frequency selection	0 to 15	1	1	170	
		-					
	73	Analog input selection	0, 1, 10, 11	1	1	172	l i

Parameter	Remarks	Inst	ruction C	Code		trol Mode-ba		l	Paramete	r
1 drameter	Remarks	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
30		1E	9E	0	0	0	0	0	0	0
31		1F	9F	0	0	0	0	0	0	0
32		20	A0	0	0	0	0	0	0	0
33		21	A1	0	0	0	0	0	0	0
34		22	A2	0	0	0	0	0	0	0
35		23	A3	0	0	0	0	0	0	0
36		24	A4	0	0	0	0	0	0	0
37		25	A5	0	0	0	0	0	0	0
40		28	A8	0	0	0	0	0	0	0
41 42		29 2A	A9 AA	0	0	0	0	0	0	0
42		2A	AA	U	0	0	0	0	0	O
43		2B	AB	0	0	0	0	0	0	0
44		2C	AC	0	0	0	0	0	0	0
45		2D	AD	0	0	0	0	0	0	0
46		2E	AE	0	0	×	×	0	0	0
47		2F	AF	0	0	×	×	0	0	0
48		30	В0	0	0	0	0	0	0	0
51		33	В3	0	0	0	0	0	0	0
52		34	B4	0	0	0	0	0	0	0
55		37	B7	0	0	0	0	0	0	0
56		38	В8	0	0	0	0	0	0	0
57		39	B9	0	0	0	0	0	0	0
58		3A	BA	0	0	0	0	0	0	0
59		3B	BB	0	0	0	0	0	0	0
60		3C	BC	0	0	×	×	0	0	0
61		3D	BD	0	0	0	0	0	0	0
62		3E	BE	0	0	0	0	0	0	0
63		3F	BF	0	0	0	0	0	0	0
65		41	C1	0	0	0	0	0	0	0
66		42	C2	0	0	0	0	0	0	0
67		43	СЗ	0	0	0	0	0	0	0
68		44	C4	0	0	0	0	0	0	0
69		45	C5	0	0	0	0	0	0	0
70		46	C6	0	0	0	0	0	0	0
71		47	C7	0	0	0	0	0	0	0
72		48	C8	0	0	0	0	0	0	0
73		49	C9	0	0	0	0	0	×	0
74		4A	CA	0	0	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
_	75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17	1	14	180	
_	77	Parameter write selection	0, 1, 2	1	0	183	
_	78	Reverse rotation prevention selection	0, 1, 2	1	0	184	
_	© 79	Operation mode selection	0, 1, 2, 3, 4, 6, 7	1	0	190, 200	
	80	Motor capacity	0.1 to 15kW, 9999	0.01kW	9999	80, 82, 85, 116	
	81	Number of motor poles	2, 4, 6, 8, 10, 9999	1	9999	80, 82, 85, 116	
	82	Motor excitation current	0 to 500A (0 to ****), 9999 *6	0.01A (1) *6	9999	116	
	83	Rated motor voltage	0 to 1000V	0.1V	200V/400V *5	116	
Ω	84	Rated motor frequency	10 to 120Hz	0.01Hz	50Hz	116	
Motor constants	89	Speed control gain (Advanced magnetic flux vector)	0 to 200%, 9999	0.1%	9999	82	
otor co	90	Motor constant (R1)	0 to 50Ω (0 to ****), 9999 *6	0.001Ω (1) *6	9999	116	
Σ	91	Motor constant (R2)	0 to 50Ω (0 to ****), 9999 *6	0.001Ω (1) *6	9999	116	
	92	Motor constant (L1)	0 to 1000mH (0 to 50Ω, 0 to ****), 9999 *6	0.1mH (0.001Ω, 1) *6	9999	116	
	93	Motor constant (L2)	0 to 1000mH (0 to 50 Ω , 0 to ****) , 9999 $_{*6}$	0.1mH (0.001Ω, 1) *6	9999	116	
	94	Motor constant (X)	0 to 100% (0 to 500Ω, 0 to ****) , 9999 *6	0.1% (0.01Ω, 1) *6	9999	116	
	96	Auto tuning setting/status	0, 1, 11, 21	1	0	116, 158	
c	117	PU communication station number	0 to 31 (0 to 247)	1	0	210, 228	
PU connector communication	118	PU communication speed	48, 96, 192, 384	1	192	210, 228	
nwı	119	PU communication stop bit length	0, 1, 10, 11	1	1	210	
or corr	120	PU communication parity check	0, 1, 2	1	2	210, 228	
ect	121	Number of PU communication retries	0 to 10, 9999	1	1	211	
J conr	122	PU communication check time interval	0, 0.1 to 999.8s, 9999	0.1s	0	211, 228	
۵	123	PU communication waiting time setting	0 to 150ms, 9999	1	9999	210	
	124	PU communication CR/LF selection	0, 1, 2	1	1	210	
_	© 125	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	175	
	@126	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	175	
	127 128	PID control automatic switchover frequency PID action selection	0 to 400Hz, 9999 0, 20, 21, 40 to 43,	0.01Hz 1	9999	242 242,	
	129	PID proportional band	50, 51, 60, 61 0.1 to 1000%, 9999	0.1%	100%	249 242,	
uo	130	PID integral time	0.1 to 3600s, 9999	0.1s	1s	249 242,	
PID operation	131	PID upper limit	0 to 100%, 9999	0.1%	9999	249 242,	
PID 0	132	PID lower limit	0 to 100%, 9999	0.1%	9999	249 242,	
	133	PID action set point	0 to 100%, 9999	0.1%	9999	249 242,	
	134	PID differential time	0.01 to 10.00s, 9999	0.01% 0.01s	9999	249 242,	
	134	FID UNIERCHILAL LITTE	0.01 to 10.008, 9999	0.018	9999	249	

Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba		I	Paramete	r
Parameter	Remarks	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
75		4B	СВ	0	0	0	0	0	×	×
77		4D	CD *4	0	0	0	0	0	0	0
78		4E	CE	0	0	0	0	0	0	0
© 79		4F	CF *4	0	0	0	0	0	0	0
80		50	D0	0	×	0	0	0	0	0
81		51	D1	0	×	0	0	0	0	0
82		52	D2	0	×	0	0	0	×	0
83		53	D3	0	×	0	0	0	0	0
84		54	D4	0	×	0	0	0	0	0
89		59	D9	0	×	0	×	0	×	0
90		5A	DA	0	0	0	0	0	×	0
91		5B	DB	0	×	0	0	0	×	0
92		5C	DC	0	×	0	0	0	×	0
93		5D	DD	0	×	0	0	0	×	0
94		5E	DE	0	×	0	0	0	×	0
96		60	E0	0	0	0	0	0	×	0
117		11	91	1	0	0	0	0	O *9	O *9
118		12	92	1	0	0	0	0	O *9	O *9
119		13	93	1	0	0	0	0	O *9	O *9
120		14	94	1	0	0	0	0	O *9	O *9
121		15	95	1	0	0	0	0	O *9	O *9
122		16	96	1	0	0	0	0	O *9	O *9
123 124		17	97 98	1	0	0	0 0	0	O *9	O *9
© 125		18 19	99	1	0	0	0	0	O *9	0 *9
© 126		1A	9 <i>A</i>	1	0	0	0	0	×	0
127		1B	9B	1	0	0	0	0	0	0
128		1C	9C	1	0	0	0	0	0	0
129		1D	9D	1	0	0	0	0	0	0
130		1E	9E	1	0	0	0	0	0	0
131		1F	9F	1	0	0	0	0	0	0
132		20	Α0	1	0	0	0	0	0	0
133		21	A1	1	0	0	0	0	0	0
134		22	A2	1	0	0	0	0	0	0

Parameter list 🥌

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting			
PU	145	PU display language selection	0 to 7	1	1	268				
_	146	Parameter for manufacturer setting. Do	not set.							
_	147	Acceleration/deceleration time switching frequency	0 to 400Hz, 9999	0.01Hz	9999	105				
	150	Output current detection level	0 to 200%	0.1%	150%	146				
Current	151	Output current detection signal delay time	0 to 10s	0.1s	0s	146				
g E	152	Zero current detection level	0 to 200%	0.1%	5%	146				
	153	Zero current detection time	0 to 1s	0.01s	0.5s	146				
_	156	Stall prevention operation selection	0 to 31, 100, 101	1	0	88				
	157	OL signal output timer	0 to 25s, 9999	0.1s	0s	88				
_	158	AM terminal function selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	1	1	150				
	160	User group read selection	0, 1, 9999	1	0	184				
_	161	Frequency setting/key lock operation selection	0, 1, 10, 11	1	0	269				
c restart ions	Automatic restart after instantaneous power failure selection		0, 1, 10, 11	1	1	158				
Automatic restart functions	165	Stall prevention operation level for restart	0 to 200%	0.1%	150%	158				
_	168	Parameter for manufacturer setting. Do	not not			•	•			
_	169	Farameter for manufacturer setting. Do	not oot.							
Cumulative monitor clear	170	Watt-hour meter clear	0, 10, 9999	1	9999	150				
Cumu	171	Operation hour meter clear	0, 9999	1	9999	150				
User group	172	User group registered display/batch clear	9999, (0 to 16)	1	0	184				
User	173	User group registration	0 to 999, 9999	1	9999	184				
	174	User group clear	0 to 999, 9999	1	9999	184				
gnment	178	STF terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 60, 62, 65 to 67, 9999	1	60	135				
Input terminal function assignment	179	STR terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 61, 62, 65 to 67, 9999	1	61	135				
ınct	180	RL terminal function selection		1	0	135				
al fc	181	RM terminal function selection		1	1	135				
nin	182	RH terminal function selection	0 to 5, 7, 8, 10, 12,	1	2	135				
tern	183	MRS terminal function selection	14 to 16, 18, 24, 25, 62, 65 to 67, 9999	1	24	135				
Input	184	RES terminal function selection	, , , , , , , , , , , , , , , , , , , ,	1	62	135				

Parameter	Remarks	Instruction Code			Control Mode-based Correspondence Table			Parameter		
1 didilictor	Remarks	Read	Write	Extended	V/F	AD MFVC	GP MFVC	Сору	Clear	All clear
145		2D	AD	1	0	0	0	0	×	×
146	Parameter for manufa	acturer set	ting. Do no	ot set.						•
147		2F	AF	1	0	0	0	0	0	0
150		32	B2	1	0	0	0	0	0	0
151		33	В3	1	0	0	0	0	0	0
152		34	B4	1	0	0	0	0	0	0
153		35	B5	1	0	0	0	0	0	0
156		38	B8	1	0	0	0	0	0	0
157		39	B9	1	0	0	0	0	0	0
158		3A	BA	1	0	0	0	0	0	0
© 160		00	80	2	0	0	0	0	0	0
161		01	81	2	0	0	0	0	×	0
162		02	82	2	0	0	0	0	0	0
165		05	85	2	0	0	0	0	0	0
168 169	Parameter for manufa	acturer set	ting. Do no	ot set.						
170		0A	8A	2	0	0	0	0	×	0
171		0B	8B	2	0	0	0	×	×	×
172		0C	8C	2	0	0	0	0	×	×
173		0D	8D	2	0	0	0	×	×	×
174		0E	8E	2	0	0	0	×	×	×
178		12	92	2	0	0	0	0	×	0
179		13	93	2	0	0	0	0	×	0
180		14	94	2	0	0	0	0	×	0
181		15	95	2	0	0	0	0	×	0
182		16	96	2	0	0	0	0	×	0
183		17	97	2	0	0	0	0	×	0
184		18	98	2	0	0	0	0	×	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
190 191 192		RUN terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 80 *7, 81 *7, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108,	1	0	141	
		FU terminal function selection	111 to 116, 120, 125, 126, 146, 147, 164, 180 *7, 181 *7, 190, 191, 193, 195, 196, 198, 199, 9999	1	4	141	
Output terminal f	192	A,B,C terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 80 *7, 81 *7, 90, 91, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 180 *7, 181 *7, 190, 191, 195, 196, 198, 199, 9999	1	99	141	
	232 Multi-speed setting (speed 8)		0 to 400Hz, 9999	0.01Hz	9999	98	
ing	233	Multi-speed setting (speed 9)	0 to 400Hz, 9999	0.01Hz	9999	98	
Multi-speed setting	234	Multi-speed setting (speed 10)	0 to 400Hz, 9999	0.01Hz	9999	98	
s pe	235	Multi-speed setting (speed 11)	0 to 400Hz, 9999	0.01Hz	9999	98	
)be(236	Multi-speed setting (speed 12)	0 to 400Hz, 9999	0.01Hz	9999	98	
Iti-s			0 to 400Hz, 9999	0.01Hz	9999	98	
M	238 Multi-speed setting (speed 14)		0 to 400Hz, 9999	0.01Hz	9999	98	
	239	Multi-speed setting (speed 15)	0 to 400Hz, 9999	0.01Hz	9999	98	
_	240	Soft-PWM operation selection	0, 1	1	1	170	
	241	Analog input display unit switchover	0, 1	1	0	175	
_	244	Cooling fan operation selection	0, 1	1	1	259	
ation	245	Rated slip	0 to 50%, 9999	0.01%	9999	87	
Slip compensation	246	Slip compensation time constant Constant-power range slip	0.01 to 10s	0.01s	0.5s	87	
8	247	compensation selection	0, 9999	1	9999	87	
_	249	Earth (ground) fault detection at start	0, 1	1	1	168	
_	250	Stop selection	0 to 100s, 1000 to 1100s, 8888, 9999	0.1s	9999	128, 139	
	251	Output phase loss protection selection	0, 1	1	1	168	
Sis	255	Life alarm status display	(0 to 15)	1	0	260	
gue	256	Inrush current limit circuit life display	(0 to 100%)	1%	100%	260	
Life diagnosis	257	Control circuit capacitor life display	(0 to 100%)	1%	100%	260	
<u>i</u> e	258	Main circuit capacitor life display	(0 to 100%)	1%	100%	260	
Power failure L stop	259 261	Main circuit capacitor life measuring Power failure stop selection	0, 1 (2, 3, 8, 9)	1	0	260 164	
	267	Terminal 4 input selection	0, 1, 2	1	0	172	
	268	Monitor decimal digits selection	0, 1, 9999	1	9999	150	
	269	Parameter for manufacturer setting. Do		•	3000	150	
	270	Stop-on contact control selection	0, 1	1	0	129	
-on act rol	275	Stop-on contact excitation current low- speed multiplying factor	0 to 300%, 9999	0.1%	9999	129	
Stop-on contact control	276	PWM carrier frequency at stop-on contact	0 to 9, 9999	1	9999	129	
_	277	Stall prevention operation current switchover	0, 1	1	0	88	

Parameter lis	st 🚿
---------------	------

Parameter	Remarks	Instruction Code			Control Mode-based Correspondence Table			Parameter			
1 dramotor	Romano	Read	Write	Extended	_V/F _	AD MFVC	GP MFVC	Сору	Clear	All clear	
190		1E	9E	2	0	0	0	0	×	0	
191		1F	9F	2	0	0	0	0	×	0	
			<i>.</i>	_							
192		20	A0	2	0	0	0	0	×	0	
232		28	A8	2	0	0	0	0	0	0	
233		29	A9	2	0	0	0	0	0	0	
234		2A	AA	2	0	0	0	0	0	0	
235 236		2B 2C	AB AC	2	0	0	0	0	0	0	
237		2D	AD	2	0	0	0	0	0	0	
238		2E	AE	2	0	0	0	0	0	0	
239		2F	AF	2	0	0	0	0	0	0	
240		30	B0	2	0	0	0	0	0	0	
241 244		31 34	B1 B4	2	0	0	0	0	0	0	
245		35	B5	2	0	×	0	0	0	0	
246		36	B6	2	0	×	0	0	0	0	
247		37	B7	2	0	×	0	0	0	0	
249		39	В9	2	0	0	0	0	0	0	
2.0				_							
250		<i>3A</i>	BA	2	0	0	0	0	0	0	
251 255		3B 3F	BB BF	2	0	0	0	0	0	0	
256		40	C0	2	0	0	0	×	×	×	
257		41	C1	2	0	0	0	×	×	×	
258		42	C2	2	0	0	0	×	×	×	
259		43	C3	2	0	0	0	0	0	0	
001		45	65		•	6	6	-			
261		45	C5	2	0	0	0	0	0	0	
267		4B	СВ	2	0	0	0	0	×	0	
268		4C	CC	2	0	0	0	0	0	0	
269	Parameter for manufa	cturer sett	ing. Do no	ot set.							
270		4E	CE	2	×	0	0	0	0	0	
275		53	D3	2	×	0	0	0	0	0	
070		F.4	5.1					-			
276		54	D4	2	×	0	0	0	0	0	
277		55	D5	2	0	0	0	0	0	0	

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
ø	278	Brake opening frequency	0 to 30Hz	0.01Hz	3Hz	131	
n	279	Brake opening current	0 to 200%	0.1%	130%	131	
ce seque function	280	Brake opening current detection time	0 to 2s	0.1s	0.3s	131	
Brake sequence function	281 282	Brake operation time at start Brake operation frequency	0 to 5s 0 to 30Hz	0.1s 0.01Hz	0.3s 6Hz	131 131	
Bra	283	Brake operation time at stop	0 to 5s	0.01112 0.1s	0.3s	131	
0. 0	286	Droop gain	0 to 100%	0.1%	0%	256	
Droop	287	Droop filter time constant	0 to 1s	0.01s	0.3s	256	
_	292	Automatic acceleration/deceleration	0, 1, 7, 8, 11	1	0	110	
_	293	Acceleration/deceleration separate selection	0 to 2	1	0	110	
_	295	Magnitude of frequency change setting	0, 0.01, 0.1, 1, 10	0.01	0	271	
word	296	Password lock level	0 to 6, 99, 100 to 106, 199, 9999	1	9999	187	
Password function	297	Password lock/unlock	(0 to 5), 1000 to 9998, 9999	1	9999	187	
_	298	Frequency search gain	0 to 32767, 9999	1	9999	158	
_	299	Rotation direction detection selection at restarting	0, 1, 9999	1	0	158	
	300	BCD input bias	0 to 400Hz	0.01Hz	0	_	
	301	BCD input gain	0 to 400Hz, 9999	0.01Hz	50Hz	_	
put	302	BIN input bias	0 to 400Hz	0.01Hz	0	_	
al ir	303	BIN input gain	0 to 400Hz, 9999	0.01Hz	50Hz	_	
Digital input	304	Digital input and analog input compensation enable/disable selection	0, 1, 10, 11, 9999	1	9999	_	
	305	Read timing operation selection	0, 1, 10	1	0	_	
	306	Analog output signal selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	1	2	_	
	307	Setting for zero analog output	0 to 100%	0.1%	0	_	
	308	Setting for maximum analog output	0 to 100%	0.1%	100	_	
output	309	Analog output signal voltage/current switchover	0, 1, 10, 11	1	0	_	
Analog	310	Analog meter voltage output selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	1	2	_	
	311	Setting for zero analog meter voltage output	0 to 100%	0.1%	0	_	
	312	Setting for maximum analog meter voltage output	0 to 100%	0.1%	100	_	
	313	DO0 output selection	0, 1, 3, 4, 7, 8, 11 to 16,	1	9999	_	
	314	DO1 output selection	20, 25, 26, 46, 47, 64,	1	9999	_	
tput	315	DO2 output selection	80 *7, 81 *7, 90, 91, 93, 95, 96, 98, 99, 100, 101,	1	9999	_	
no II	316	DO3 output selection	103, 104, 107, 108, 111 to 116, 120, 125,	1	9999	_	
Digital output	317	DO4 output selection	126, 146, 147, 164,	1	9999	_	
	318	DO5 output selection	180 *7, 181 *7, 190, 191, 193, 195, 196, 198, 199,	1	9999	_	
	319	DO6 output selection	9999	1	9999	_	
put	320	RA1 output selection	0, 1, 3, 4, 7, 8, 11 to 16,	1	0	_	
Relay output	321	RA2 output selection	20, 25, 26, 46, 47, 64, 80 *7, 81 *7, 90, 91, 95,	1	1	_	
Rek	322	RA3 output selection	96, 98, 99, 9999	1	4	_	
Analog output	323	AM0 0V adjustment	900 to 1100%	1%	1000	_	
An	324	AM1 0mA adjustment	900 to 1100%	1%	1000	_	
	329	Digital input unit selection	0, 1, 2, 3	1	1	_	

Parameter	Remarks	Instruction Code			Control Mode-based Correspondence Table			Parameter			
arameter		Read	Write	Extended	_V/F _	AD-MFVC	GP MFVC	Сору	Clear	All clear	
278		56	D6	2	×	0	0	0	0	0	
279		57	D7	2	×	0	0	0	0	0	
280		58 59	D8	2	×	0	0	0	0	0	
281		59 5A	D9 DA	2	×	0	0	0	0	0	
283		5B	DB	2	×	0	0	0	0	0	
286		5E	DE	2	×	0	×	0	0	0	
287		5F	DF	2	×	0	×	0	0	0	
292		64	E4	2	0	0	0	0	0	0	
293		65	E5	2	0	0	0	0	0	0	
295		67	E7	2	0	0	0	0	0	0	
296	(Ver.UP)	68	E8	2	0	0	0	0	×	0	
297	(Ver.UP)	69	E9	2	0	0	0	0	O *10	0	
298		6A	EA	2	0	0	0	0	×	0	
299		6B	EB	2	0	0	0	0	0	0	
300	AX	00	80	3	0	0	0	0	0	0	
301	AX	01	81	3	0	0	0	0	0	0	
302	AX	02	82	3	0	0	0	0	0	0	
303	AX	03	83	3	0	0	0	0	0	0	
304	AX	04	84	3	0	0	0	0	0	0	
305	AX	05	85	3	0	0	0	0	0	0	
306	AY	06	86	3	0	0	0	0	0	0	
307	AY	07	87	3	0	0	0	0	0	0	
308	AY	08	88	3	0	0	0	0	0	0	
309	AY	09	89	3	0	0	0	0	0	0	
310	AY	0A	8A	3	0	0	0	0	0	0	
311	AY	0B	8B	3	0	0	0	0	0	0	
312	AY	ос	8C	3	0	0	0	0	0	0	
313	AY NC	0D	8D	3	0	0	0	0	0	0	
314	AY NC	0E	8E	3	0	0	0	0	0	0	
315	AY NC	0F	8F	3	0	0	0	0	0	0	
316	AY	10	90	3	0	0	0	0	0	0	
317	AY	11	91	3	0	0	0	0	0	0	
318	AY	12	92	3	0	0	0	0	0	0	
319	AY	13	93	3	0	0	0	0	0	0	
320	AR	14	94	3	0	0	0	0	0	0	
321	AR	15	95	3	0	0	0	0	0	0	
322	AR	16	96	3	0	0	0	0	0	0	
323	AY	17	97	3	0	0	0	0	×	0	
324	AY	18	98	3	0	0	0	0	×	0	
329	AX	1D	9D	3	0	0	0	0	×	0	

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
ation	338	Communication operation command source	0, 1	1	0	201	
ımunio	339	Communication speed command source	0, 1, 2	1	0	201	
200	340	Communication startup mode selection	0, 1, 10	1	0	200	
RS-485 communication	342	Communication EEPROM write selection	0, 1	1	0	214	
Ř	343	Communication error count	_	1	0	228	
Net ication	345	DeviceNet address	0 to 4095	1	63	_	
DeviceNet communication	346	DeviceNet baud rate	0 to 4095	1	132	_	
_	349	Communication reset selection	0, 1	1	0	_	
	387	Initial communication delay time	0 to 120s	0.1s	0s	_	
S	388	Send time interval at heart beat	0 to 999.8s	0.1s	0s	_	
LowWorks communication	389	Minimum sending time at heart beat	0 to 999.8s	0.1s	0.5s	_	
NNC Januar	390	% setting reference frequency	1 to 400Hz	0.01Hz	50Hz	_	
LC COM	391	Receive time interval at heart beat	0 to 999.8s	0.1s	0s	_	
	392	Event driven detection width	0.00 to 163.83%	0.01%	0%	_	
Second motor constant	450	Second applied motor	0, 1, 9999	1	9999	114	
+-	495	Remote output selection	0, 1, 10, 11	1	0	148	
Output	496	Remote output data 1	0 to 4095	1	0	148	
Ō	497	Remote output data 2	0 to 4095	1	0	148	
munication error	500	Communication error execution waiting time	0 to 999.8s	0.1s	0	_	
Communic	501	Communication error occurrence count display	0	1	0	_	
_	502	Stop mode selection at communication error	0, 1, 2, 3	1	0	211, 228	
nance	503	Maintenance timer	0 (1 to 9998)	1	0	264	
Maintenance	504	Maintenance timer alarm output set time	0 to 9998, 9999	1	9999	264	
	541	Frequency command sign selection (CC-Link)	0, 1	1	0	_	
CC-Link	542	Communication station number (CC-Link)	1 to 64	1	1	_	
J	543 Baud rate selection (CC-Link)		0 to 4	1	0	_	
	544	CC-Link extended setting	0, 1, 12, 14, 18	1	0		
В	547	USB communication station number	0 to 31	1	0	241	
USB	548	USB communication check time interval	0 to 999.8s, 9999	0.1s	9999	241	
ion	549	Protocol selection	0, 1	1	0	228	
Communication	550	NET mode operation command source selection	0, 2, 9999	1	9999	201	
Comr	551	PU mode operation command source selection	2 to 4, 9999	1	9999	201	



Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba		Parameter		
1 didilictor	Remarks	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
338		26	A6	3	0	0	0	0	O *9	O *9
339		27	A7	3	0	0	0	0	O *9	O *9
340		28	A8	3	0	0	0	0	O *9	O *9
342		2A	AA	3	0	0	0	0	0	0
343		2B	AB	3	0	0	0	×	×	×
345	ND	2D	AD	3	0	0	0	0	O *9	O *9
346	ND	2E	AE	3	0	0	0	0	O *9	O *9
349	NC ND NL NP	31	B1	3	0	0	0	0	O *9	O *9
387	NL	57	D7	3	0	0	0	0	0	0
388	NL	58	D8	3	0	0	0	0	0	0
389	NL	59	D9	3	0	0	0	0	0	0
390	NL	5A	DA	3	0	0	0	0	0	0
391	NL	5B	DB	3	0	0	0	0	0	0
392	NL	5C	DC	3	0	0	0	0	0	0
450		32	В2	4	0	0	0	0	0	0
495		5F	DF	4	0	0	0	0	0	0
496		60	E0	4	0	0	0	×	×	×
497		61	E1	4	0	0	0	×	×	×
500	NC ND NL NP	00	80	5	0	0	0	0	0	0
501	NC ND NL NP	01	81	5	0	0	0	×	0	0
502		02	82	5	0	0	0	0	0	0
503		03	83	5	0	0	0	×	×	×
504		04	84	5	0	0	0	0	×	0
541	NC	29	A9	5	0	0	0	0	O *9	O *9
542	NC	2A	AA	5	0	0	0	0	O *9	O *9
543	NC	2B	AB	5	0	0	0	0	O *9	O *9
544	NC	2C	AC	5	0	0	0	0	O *9	O *9
547		2F	AF	5	0	0	0	0	O *9	O *9
548		30	В0	5	0	0	0	0	O *9	O *9
549		31	B1	5	0	0	0	0	O *9	O *9
550		32	B2	5	0	0	0	0	O *9	O *9
551		33	В3	5	0	0	0	0	O *9	O *9

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting		
age or	555	Current average time	0.1 to 1.0s	0.1s	1s	265			
Current average time monitor	556	Data output mask time	0 to 20s	0.1s	0s	265			
Curre	557	Current average value monitor signal output reference current	0 to 500A	0.01A	Rated inverter current	265			
_	563	Energization time carrying-over times	(0 to 65535)	1	0	150			
_	564	Operating time carrying-over times	(0 to 65535)	1	0	150			
_	571	Holding time at a start	0 to 10s, 9999	0.1s	9999	108			
_	611	Acceleration time at a restart	0 to 3600s, 9999	0.1s	9999	158			
_	645	AM 0V adjustment	970 to 1200	1	1000	156			
_	653	Speed smoothing control	0 to 200%	0.1%	0	171			
_	665	Regeneration avoidance frequency gain	0 to 200%	0.1%	100	257			
_	800	Control method selection	20, 30	1	20	80, 82, 85			
_	859	Torque current	0 to 500A (0 to ****) , 9999 *6	0.01A (1) *6	9999	116			
Protective functions	872 *11	Input phase loss protection selection	0, 1	1	1	168			
ance	882	Regeneration avoidance operation selection	0, 1, 2	1	0	257			
n avoid tion	883	Regeneration avoidance operation level	300 to 800V	0.1V	400VDC/ 780VDC *5	257			
Regeneration avoidance function	885	Regeneration avoidance compensation frequency limit value	0 to 10Hz, 9999	0.01Hz	6Hz	257			
Rege	886	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%	257			
Free parameter	888	Free parameter 1	0 to 9999	1	9999	267			
F	889	Free parameter 2	0 to 9999	1	9999	267			
	C0 (900) *8	FM terminal calibration	_	_	_	156			
	C1 (901) *8	AM terminal calibration Terminal 2 frequency setting bias	_	_	_	156			
	(902) *8	frequency	0 to 400Hz	0.01Hz	0Hz	175			
meters	(902) *8 125	Terminal 2 frequency setting bias Terminal 2 frequency setting gain	0 to 300%	0.1%	0%	175			
Calibration parameters	(903) *8	frequency	0 to 400Hz	0.01Hz	50Hz	175			
ibratio	(903) *8 C5	Terminal 2 frequency setting gain Terminal 4 frequency setting bias	0 to 300%	0.1%	100%	175			
Cal	(904) *8 C6	frequency	0 to 400Hz	0.01Hz	0Hz	175			
	(904) *8	Terminal 4 frequency setting bias Terminal 4 frequency setting gain	0 to 300%	0.1%	20%	175			
	(905) *8	frequency	0 to 400Hz	0.01Hz	50Hz	175			
	(905) *8 C22 to C25	Terminal 4 frequency setting gain	Terminal 4 frequency setting gain 0 to 300% 0.1% 100% 175						
_	(922 to 923)	Parameter for manufacturer setting. Do	not set.						

\
١

555 556 557	Remarks	Read 37	Write	Extended	> -V/F -√	spondence				1
556		37				AD MFVC	GP MFVC	Сору	Clear	All clear
			B7	5	0	0	0	0	0	0
557		38	В8	5	0	0	0	0	0	0
		39	В9	5	0	0	0	0	0	0
563		3F	BF	5	0	0	0	×	×	×
564		40	C0	5	0	0	0	×	×	×
571 611		47 0B	C7 8B	5 6	0	0	0 0	0	0	0
645		2D	AD	6	0	0	0	0	×	0
653		35	B5	6	0	0	0	0	0	0
665		41	C1	6	0	0	0	0	0	0
800		00	80	8	×	0	0	0	0	0
859		3B	BB	8	×	0	0	0	×	0
872		48	C8	8	0	0	0	0	0	0
882		52	D2	8	0	0	0	0	0	0
883		53	D3	8	0	0	0	0	0	0
885		55	D5	8	0	0	0	0	0	0
886		56	D6	8	0	0	0	0	0	0
888		58	D8	8	0	0	0	0	×	×
889		59	D9	8	0	0	0	0	×	×
C0 (900)	AY	5C	DC	1	0	0	0	0	×	0
C1 (901)		5D	DD	1	0	0	0	0	×	0
C2 (902)		5E	DE	1	0	0	0	0	×	0
C3 (902)		5E	DE	1	0	0	0	0	×	0
125 (903)		5F	DF	1	0	0	0	0	×	0
C4 (903)		5F	DF	1	0	0	0	0	×	0
C5 (904)		60	E0	1	0	0	0	0	×	0
C6 (904)		60	E0	1	0	0	0	0	×	0
126 (905)		61	E1	1	0	0	0	0	×	0
C7 (905)		61	E1	1	0	0	0	0	×	0
C22 to C25 (922 to 923)	Parameter for manufa	cturer sett	ting. Do no	ot set.						

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
PU	990	PU buzzer control	0, 1	1	1	272	
۵	991	PU contrast adjustment	0 to 63	1	58	272	
rs e list	Pr.CL	Parameter clear	0, 1	1	0	273	
parameters ue change	ALLC	All parameter clear	0, 1	1	0	273	
	Er.CL	Faults history clear	0, 1	1	0	275	
Clear Initial val	Pr.CH	Initial value change list	_			274	

*1 Differ according to capacities.

6%: FR-E740-026(SC) or less, FR-E720S-050(SC) or less

4%: FR-E740-040(SC) to 095(SC), FR-E720S-080(SC) and 110(SC)

3%: FR-E740-120(SC) and 170(SC)

2%: FR-E740-230(SC) and 300(SC)

*2 Differ according to capacities.

5s: FR-E740-095(SC) or less, FR-E720S-110(SC) or less

10s: FR-E740-120(SC) and 170(SC)

15s: FR-E740-230(SC) and 300(SC)

*3 Differ according to capacities.

6%: FR-E720S-008(SC) and 015(SC)

4%: FR-E740-016(SC) to 170(SC), FR-E720S-030(SC) to 110(SC)

2%: FR-E740-230(SC) and 300(SC)

- *4 Write is disabled in the communication mode (Network operation mode) from the PU connector.
- *5 The initial value differs according to the voltage class. (200V class/400V class)
- *6 The range differs according to the *Pr. 71* setting.
- *7 Theses parameters can be set only in the safety stop function model.
- *8 The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).
- *9 These parameters are communication parameters that are not cleared when parameter clear (all clear) is executed from RS-485 communication. (Refer to page 210 for RS-485 communication).
- *10 When a communication option is installed, parameter clear (lock release) during password lock (Pr. 297 ± 9999) can be performed only from the communication option.
- *11 Available only for the three-phase power input model.

Parameter	Remarks	Instruction Code		Control Mode-based Correspondence Table			Parameter			
i didiliotoi	Romanio	Read	Write	Extended	V/F	AD MFVC	GP MFVC	Сору	Clear	All clear
990		5A	DA	9	0	0	0	0	0	0
991		5B	DB	9	0	0	0	0	×	0
Pr.CL		_	FC	_	_	_	_	_	_	_
ALLC		_	FC	_	_	_	_	_	_	_
Er.CL		_	F4	_	_	_	_	_	_	_
Pr.CH		_	-	_	_	_	_	_	_	_

Parameters according to purposes

4.3	Control mode	79
4.3.1	Changing the control method (Pr. 80, Pr. 81, Pr. 800)	80
4.4	Adjustment of the output torque (current) of the motor	81
4.4.1	Manual torque boost (Pr. 0, Pr. 46)	81
4.4.2	Advanced magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr.89, Pr. 800)	82
4.4.3	General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)	85
4.4.4	Slip compensation (Pr. 245 to Pr. 247)	
4.4.5	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157, Pr. 277)	88
4.5 I	Limiting the output frequency	92
4.5.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	92
4.5.2	Avoiding mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	93
4.6	V/F pattern	94
4.6.1	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	94
4.6.2	Load pattern selection (Pr. 14)	96
4.7 I	Frequency setting by external terminals	98
4.7.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	98
4.7.2	Jog operation (Pr. 15, Pr. 16)	
4.7.3	Remote setting function (Pr. 59)	102
4.8	Setting of acceleration/deceleration time and acceleration/	
	deceleration pattern	105
4.8.1	Setting of the acceleration and deceleration time	
	(Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 147)	
4.8.2 4.8.3	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	
4.8.4	Acceleration/deceleration pattern (Pr. 29)	109
4.0.4	(Pr. 61 to Pr. 63, Pr. 292, Pr. 293)	110
4.9	Selection and protection of a motor	112
4.9.1	Motor overheat protection (Electronic thermal O/L relay) (Pr. 9, Pr. 51)	112
4.9.2	Applied motor (Pr. 71, Pr. 450)	
4.9.3	Exhibiting the best performance for the motor (offline auto tuning)	
	(Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859)	116
4.10 I	Motor brake and stop operation	124
4.10.1	DC injection brake (Pr. 10 to Pr. 12)	124
4.10.2	Selection of a regenerative brake (Pr. 30, Pr. 70)	126
4.10.3	. ,	
4.10.4		
4.10.5		
4.11	Function assignment of external terminal and control	135
4.11.1	Input terminal function selection (Pr. 178 to Pr. 184)	
4.11.2	Inverter output shutoff signal (MRS signal, Pr. 17)	
4.11.3	Condition selection of function validity by second function selection signal (RT)	138

4.11.4	Start signal operation selection (STF, STR, STOP signal, Pr. 250)	139
4.11.5	Output terminal function selection (Pr. 190 to Pr. 192)	141
4.11.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	145
4.11.7	Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153)	146
4.11.8	Remote output selection (REM signal, Pr. 495 to Pr. 497)	148
4.12	Monitor display and monitor output signal	149
4.12.1	Speed display and speed setting (Pr. 37)	149
4.12.2	• •	450
4 40 0	(Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)	
4.12.3 4.12.4		
	Operation selection at power failure and instantaneous power failure	158
4.13.1	Automatic restart after instantaneous power failure/flying start	
4.10.1	(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	158
4.13.2		
4.14	Operation setting at fault occurrence	166
4.14.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	166
4.14.2		
4.14.3		
	Energy saving operation	169
4.15.1	 	169
	Motor noise, EMI measures, mechanical resonance	170
	•	
4.16.1 4.16.2		
	, ,	
4.17	Frequency setting by analog input (terminal 2, 4)	1/2
4.17.1		
4.17.2	7	174
4.17.3	Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	175
4.18 I	Misoperation prevention and parameter setting restriction	180
4.18.1		180
4.18.1	,	
4.18.3	,	
4.18.4	· · · · · · · · · · · · · · · · · · ·	
4.18.5		
4.19	Selection of operation mode and operation location	190
4.19.1	Operation mode selection (Pr. 79)	190
4.19.2	•	
4.19.3		200
	operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)	201

4.20 C	communication operation and setting	207
4.20.1	Wiring and configuration of PU connector	207
4.20.2	Initial settings and specifications of RS-485 communication	
	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	
4.20.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	211
4.20.4	Communication EEPROM write selection (Pr. 342)	214
4.20.5	Mitsubishi inverter protocol (computer link communication)	215
4.20.6	Modbus-RTU communication specifications	
	(Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	
4.20.7	USB communication (Pr. 547, Pr. 548)	241
4.21 S	pecial operation and frequency control	242
4.21.1	PID control (Pr. 127 to Pr. 134)	242
4.21.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	249
4.21.3	Droop control (Pr. 286 to Pr. 287)	256
4.21.4	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	257
4.22 L	Iseful functions	259
4.22.1	Cooling fan operation selection (Pr. 244)	259
4.22.2	Display of the life of the inverter parts (Pr. 255 to Pr. 259)	260
4.22.3	Maintenance timer alarm (Pr. 503, Pr. 504)	
4.22.4	Current average value monitor signal (Pr. 555 to Pr. 557)	265
4.22.5	Free parameter (Pr. 888, Pr. 889)	267
4.23 S	etting from the parameter unit and operation panel	268
4.23.1	RUN key rotation direction selection (Pr. 40)	268
4.23.2	PU display language selection(Pr.145)	
4.23.3	Operation panel frequency setting/key lock operation selection (Pr. 161)	
4.23.4	Magnitude of frequency change setting (Pr. 295)	
4.23.5	Buzzer control (Pr. 990)	
4.23.6	PU contrast adjustment (Pr. 991)	
4.24 P	arameter clear/ All parameter clear	273
4.25 I	nitial value change list	274
4.26 C	check and clear of the faults history	275
	· · · · · · · · · · · · · · · · · ·	



V/F control (initial setting), Advanced magnetic flux vector control and General-purpose magnetic flux vector control are available with this inverter.

(1) V/F Control

•It controls frequency and voltage so that the ratio of frequency (F) to voltage (V) is constant when changing frequency.

(2) Advanced (General-purpose) magnetic flux vector control

- •This control divides the inverter output current into an excitation current and a torque current by vector calculation and makes voltage compensation to flow a motor current which meets the load torque.
- •General-purpose magnetic flux vector control is the same function as the FR-E500 series. For other cases, select Advanced magnetic flux vector control.



POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity.
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant-torque motor (SF-JRCA four-pole, SF-HRCA 0.2kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- Wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)



4.3.1 Changing the control method (Pr. 80, Pr. 81, Pr. 800)

Set when selecting the control method for Advanced magnetic flux vector control and General-purpose magnetic flux vector control. The initial value is V/F control.

•Select a control mode using Pr. 800 Control method selection.

Parameter Number	Name	Initial Value	Setting Range		Description	
80	Motor capacity	9999	0.1 to 15kW	Set the applied motor capacity.		
80	Motor Capacity	9999	9999	V/F Control		
81	Number of motor poles	9999	2, 4, 6, 8, 10	Set the nu	mber of motor poles.	
01	Number of motor poles	9999	9999	V/F Contro	ol	
000	Control method	20	20	V/F	Advanced magnetic flux vector control *	
800	selection	20	30	Control	General-purpose magnetic flux vector control *	

^{*} Set a value other than "9999" in Pr. 80 and Pr. 81.

(1) Setting of the motor capacity and the number of motor poles (Pr. 80, Pr. 81)

- •Motor specifications (motor capacity and number of motor poles) must be set to select Advanced magnetic flux vector control or General-purpose magnetic flux vector control.
- •Set the motor capacity (kW) in Pr. 80 Motor capacity and set the number of motor poles in Pr. 81 Number of motor poles.

(2) Selection of control method

 Select the inverter control method for V/F control, Advanced magnetic flux vector control, and General-purpose magnetic flux vector control.

Pr. 80, 81	Pr. 800 Setting	Control Method		
Other than 9999	20 (<i>Pr</i> : <i>800</i> initial value)	Advanced magnetic flux vector control		
	30	General-purpose magnetic flux vector control		
9999 (<i>Pr. 80, Pr. 81</i> initial value)	*	V/F control		

^{*} Control method is V/F control regardless of the setting value of Pr. 800 when "9999" is set in Pr. 80 Motor capacity or Pr. 81 Number of motor poles.

(3) Control method switching by external terminals (X18 signal)

- •Use the V/F switchover signal (X18) to change the control method (between V/F control and Advanced magnetic flux vector control (General-purpose magnetic flux vector control)) with external terminal.
- •Turn the X18 signal ON to change the currently selected control method (Advanced magnetic flux vector control or General-purpose magnetic flux vector control) to V/F control.

For the terminal used for X18 signal input, set "18" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



• REMARKS

Switch the control method using external terminal (X18 signal) during an inverter stop. If control method between V/F control and Advanced (General-purpose) magnetic flux vector control is switched during the operation, the actual switchover does not take place until the inverter stops. In addition, if control method is switched to V/F control during the operation, only second function becomes valid as V/F control and second function are selected simultaneously in V/F control.



NOTE

· Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Advanced magnetic flux vector control 👺 Refer to page 82

General-purpose magnetic flux vector control Refer to page 85

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

Pr. 450 Second applied motor Refer to page 114

Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time Refer to page 105

Pr. 46 Second torque boost Refer to page 81

Pr. 47 Second V/F (base frequency) Refer to page 94

Pr. 48 Second stall prevention operation current Refer to page 88

Pr. 51 Second electronic thermal O/L relay Refer to page 112



4.4 Adjustment of the output torque (current) of the motor

Purpose	Parameter that	Parameter that should be Set			
Set starting torque manually	Manual torque boost	Pr. 0, Pr. 46	81		
Automatically control output current according to load	Advanced magnetic flux vector control, General-purpose magnetic flux vector control	Pr. 71, Pr. 80, Pr. 81, Pr. 89, Pr. 90, Pr. 450, Pr. 800	82, 85		
Compensate for motor slip to secure low-speed torque	Slip compensation (V/F control and General-purpose magnetic flux vector control only)	Pr. 245 to Pr. 247	87		
Limit output current to prevent inverter trip	Stall prevention operation	Pr. 22, Pr. 23, Pr. 66, Pr. 156, Pr. 157	88		

4.4.1 Manual torque boost (Pr. 0, Pr. 46)

You can compensate for a voltage drop in the low-frequency range to improve motor torque reduction in the low-speed range.


- •Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- •Two kinds of start torque boosts can be changed by switching between terminals.

Parameter Number	Name	Initial Value		Setting Range	Description		
		FR-E740-016(SC) and 026(SC) FR-E720S-008(SC) to 050(SC)	6%				
0	Torque boost	FR-E740-040(SC) to 095(SC) FR-E720S-080(SC) and 110(SC)	4%	0 to 30%	Set the output voltage at 0Hz as %.		
		FR-E740-120(SC) and 170(SC)	3%				
		FR-E740-230(SC) and 300(SC)	2%				
	Second torque	9999		0 to 30%	Set the torque boost when the RT		
46 *	•			0 10 30%	signal is ON.		
	boost			9999	Without second torque boost		

^{*} The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Starting torque adjustment

- •On the assumption that *Pr. 19 Base frequency voltage* is 100%, set the output voltage at 0Hz in % to *Pr. 0 (Pr. 46)*.
- •Adjust the parameter little by little (about 0.5%), and check the motor status each time. If the setting is too large, the motor will overheat. The guideline is about 10% at the greatest.



(2) Set two kinds of torque boosts (RT signal, Pr. 46)

- •When you want to change torque boost according to applications, switch multiple motors with one inverter, etc., use *Second torque boost*.
- Pr. 46 Second torque boost is valid when the RT signal is ON.
- •For the terminal used for RT signal input, set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.



REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 138)



NOTE

- The amount of current flows in the motor may become large according to the conditions such as the motor characteristics, load, acceleration/deceleration time, wiring length, etc., resulting in an overcurrent trip (OL (overcurrent alarm) then E.OC1 (overcurrent trip during acceleration), overload trip (E.THM (motor overload trip), or E.THT (inverter overload trip).
- (When a fault occurs, release the start command, and decrease the Pr. 0 setting 1% by 1% to reset.) (Refer to page 278.)
- The Pr. 0, Pr. 46 settings are valid only when V/F control is selected.
- When using the inverter dedicated motor (constant-torque motor) with the FR-E740-120(SC) and 170(SC), set torque boost value to 2%.
- When $Pr. \theta =$ "3%" (initial value), if Pr. 71 value is changed to the setting for use with a constant-torque motor, the $Pr. \theta$ setting changes to 2%.
- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 3 Base frequency, Pr. 19 Base frequency voltage & Refer to page 94 Pr. 71 Applied motor & Refer to page 114

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

4.4.2 Advanced magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr.89, Pr. 800)

Advanced magnetic flux vector control can be selected by setting the capacity, poles and type of the motor used in *Pr.* 80 and *Pr.* 81.

• Advanced magnetic flux vector control?

The low speed torque can be improved by providing voltage compensation to flow a motor current which meets the load torque. Output frequency compensation (slip compensation) is made so that the motor actual speed approximates a speed command value. Effective when load fluctuates drastically, etc.

When the FR-E500 series used for General-purpose magnetic flux vector control was replaced, select General-purpose magnetic flux vector control only when the same operation characteristic is necessary. (*Refer to page 85*)

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0,1, 3 to 6, 13 to 16, 23, 24 40, 43, 44 50, 53, 54	By selecting a standard motor or constant-torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999	0.1 to 15kW	Set the applied motor capacity.
81	Number of motor poles	9999	9999 2, 4, 6, 8, 10 9999	V/F control Set the number of motor poles. V/F control
89	Speed control gain (Advanced magnetic flux		0 to 200%	Motor speed fluctuation due to load fluctuation is adjusted during Advanced magnetic flux vector control. 100% is a referenced value.
	vector)		9999	Gain matching with the motor set in <i>Pr.71</i> .
	Control method		20	Advanced magnetic flux vector control *
800	selection	20	30	General-purpose magnetic flux vector control * (Refer to page 85)

The above parameters can be set when Pr. 160 User group read selection = "0".(Refer to page 184)

^{*} Set a value other than "9999" in Pr. 80 and Pr. 81.



POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity.
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant-torque motor (SF-JRCA four-pole, SF-HRCA 0.2kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)
- Permissible wiring length between inverter and motor differs according to the inverter capacity and setting value of *Pr. 72 PWM frequency selection* (carrier frequency). *Refer to page 20* for the permissible wiring length.



<Selection method of Advanced magnetic flux vector control>

Perform secure wiring.

(Refer to page 14)



Set	the	motor.	(Pr	71	
OUL			(1 /.	/1,	ı

	Motor	Pr. 71 Setting *1	Remarks
Mitsubishi standard	SF-JR	0 (initial value)	
motor	SF-HR	40	
Mitsubishi high efficiency motor	Others	3	Offline auto tuning is necessary. *2
Mitsubishi constant-	SF-JRCA 4P	1	
torque motor	SF-HRCA	50	
torque motor	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2
Other manufacturer's standard motor	_	3	Offline auto tuning is necessary. *2
Other manufacturer's constant-torque motor	_	13	Offline auto tuning is necessary. *2

- Refer to page 114, for other settings of Pr. 71.
- Refer to page 116 for offline auto tuning.



Set the motor capacity and the number of motor poles.

(Pr. 80, Pr. 81) (Refer to page 82)



Set motor capacity (kW) in Pr. 80 Motor capacity and the number of motor poles (number of poles) in Pr. 81 Number of motor poles.

(V/F control is performed when the setting is "9999" (initial value).

Select the control method. (Pr. 800) (Refer to page 82)



Set "20" (initial value) in Pr. 800 to make Advanced magnetic flux vector control valid

Set the operation command. (Refer to page 190)

Select the start command and speed command.

(1)Start command

- 1)Operation panel: Setting by pressing (RUN) of the operation panel
- 2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)

(2)Speed command

- 1)Operation panel: Setting by pressing of the operation panel
- 2)External analog command (terminal 2 or 4):

Give a speed command using the analog signal input to terminal 2 (or terminal 4).

3)Multi-speed command:

The external signals (RH, RM, RL) may also be used to give speed command.

Test run

As required

• Perform offline auto tuning. (Pr. 96) (Refer to page 116)




NOTE

- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.
- When a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) is connected between the inverter and motor, output torque may decrease.)

(1) Adjust the motor speed fluctuation at load fluctuation (Pr. 89 Speed control gain (Advanced magnetic flux vector))

The motor speed fluctuation at load fluctuation can be adjusted using Pr. 89. (It is useful when the speed command does not match the motor speed after the FR-E500 series inverter is replaced with the FR-E700 series inverter, etc.)





Parameters referred to

Pr. 71, Pr. 450 Applied motor Refer to page 114 Pr. 800 Control method selection Refer to page 80



4.4.3 General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)

General-purpose magnetic flux vector control is the same function as the FR-E500 series. Select this control when the same operation characteristic is necessary. For other cases, select Advanced magnetic flux vector control. (*Refer to page 82*)

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0,1, 3 to 6, 13 to 16, 23, 24 40, 43, 44 50, 53, 54	By selecting a standard motor or constant-torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999	0.1 to 15kW	Applied motor capacity.
00	motor capacity	3333	9999	V/F control
81	Number of motor	9999	2, 4, 6, 8, 10	Number of motor poles.
01	poles	9999	9999	V/F control
800	Control method		20	Advanced magnetic flux vector control * (Refer to page 82)
800	selection	20	30	General-purpose magnetic flux vector control *

The above parameters can be set when Pr. 160 User group read selection = "0".(Refer to page 184)

^{*} Set a value other than "9999" in Pr. 80 and Pr. 81.



POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity.
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant-torque motor (SF-JRCA four-pole, SF-HRCA 0.2kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)
- Permissible wiring length between inverter and motor differs according to the inverter capacity and setting value of *Pr. 72 PWM frequency selection* (carrier frequency). *Refer to page 20* for the permissible wiring length.

<Selection method of General-purpose magnetic flux vector control>

Perform secure wiring. (Refer to page 14)

Set the motor.(Pr. 71)

	Motor	Pr. 71 Setting *1	Remarks
Mitsubishi standard	SF-JR	0 (initial value)	
motor	SF-HR	40	
Mitsubishi high efficiency motor	Others	3	Offline auto tuning is necessary. *2
Mitsubishi constant-	SF-JRCA 4P	1	
torque motor	SF-HRCA	50	
torque motor	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2
Other manufacturer's		3	Offline auto tuning is necessary. *2
standard motor	_	3	Offiline auto turning is necessary. *2
Other manufacturer's			
constant-torque	_	13	Offline auto tuning is necessary. *2
motor			

- *1 Refer to page 114, for other settings of Pr. 71.
- *2 Refer to page 116 for offline auto tuning.



Set the motor capacity and the number of motor poles.

(Pr. 80, Pr. 81) (Refer to page 85)



Set motor capacity (kW) in *Pr. 80 Motor capacity* and the number of motor poles (number of poles) in *Pr. 81 Number of motor poles*.

(V/F control is performed when the setting is "9999" (initial value).

Select the control method.(Pr. 800) (Refer to page 85)



Set "30" in *Pr. 800* to make General-purpose magnetic flux vector control valid.

Set the operation command. (Refer to page 190)

Select the start command and speed command.

(1)Start command

- 1)Operation panel: Setting by pressing (RUN) of the operation panel
- 2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)

(2)Speed command

- 1)Operation panel: Setting by pressing of the operation panel
- 2)External analog command (terminal 2 or 4):
 Give a speed command using the analog signal input to terminal 2 (or
- 3)Multi-speed command:

terminal 4).

The external signals (RH, RM, RL) may also be used to give speed command.

Test run

As required

- Perform offline auto tuning. (Pr. 96) (Refer to page 116)
- Set slip compensation. (Pr. 245, Pr. 246, Pr. 247) (Refer to page 87)



NOTE

- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.
- When a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) is connected between the inverter and motor, output torque may decrease.)



Parameters referred to

Pr.3 Base frequency, Pr.19 Base frequency voltage Refer to page 94

Pr.71 Applied motor Refer to page 114

Pr.77 Parameter write selection Refer to page 183



4.4.4 Slip compensation (Pr. 245 to Pr. 247) SP MEVC

When V/F control or General-purpose magnetic flux vector control is performed, the inverter output current may be used to assume motor slip to keep the motor speed constant.

Parameter Number	Name	Initial Value	Setting Range	Description
245	Rated slip	9999	0.01 to 50%	Rated motor slip.
245	Rated Slip	9999	0, 9999	No slip compensation
246	Slip compensation time constant	0.5s	0.01 to 10s	Slip compensation response time. When the value is made smaller, response will be faster. However, as load inertia is greater, a regenerative overvoltage fault (E.OV□) is more liable to occur.
247	Constant-power range slip compensation selection	9999	9999	Slip compensation is not made in the constant power range (frequency range above the frequency set in <i>Pr. 3</i>) Slip compensation is made in the constant power range.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

• Slip compensation is validated when the motor rated slip calculated by the following formula is set in Pr. 245. Slip compensation is not made when Pr. 245 = "0" or "9999".



• REMARKS

- When performing slip compensation, the output frequency may become greater than the set frequency. Set the Pr. 1 Maximum frequency value a little higher than the set frequency.
- Slip compensation is always valid when Advanced magnetic flux vector control is selected, the Pr. 245 to Pr. 247 settings are invalid.



Parameters referred to

Pr. 1 Maximum frequency Refer to page 92 Pr. 3 Base frequency Refer to page 94

4.4.5 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157, Pr. 277)

This function monitors the output current and automatically changes the output frequency to prevent the inverter from coming to trip due to overcurrent, overvoltage, etc. In addition, simple torque limit which limits the output torque to the predetermined value can be selected.

It can also limit stall prevention and fast-response current limit operation during acceleration/deceleration, driving or regeneration.

Stall prevention

If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically varied to reduce the output current.

● Fast-response current limit

If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.


Torque limit

The inverter output frequency is controlled so that the output torque (torque current) will not exceed the stall prevention operation level (motor rated torque is referenced).

Parameter Number	Name	Initial Value	Setting Range	Description
	Stall prevention operation		0	Stall prevention operation invalid
22*	level	150%	0.1 to 200%	Set the current value to start the stall
	levei		0.1 to 20070	prevention operation.
	Stall prevention			The stall operation level can be reduced
	operation level		0 to 200%	when operating at a high speed above the
23	compensation factor	9999		rated frequency.
	at double speed		9999	Constant according to Pr. 22.
	Second stall prevention		0	Stall prevention operation invalid
48	•	9999	0.1 to 200%	Second stall prevention operation level
	operation current		9999	Same level as Pr. 22.
	Stall prevention			Cot the free successor at which the estall
66	operation reduction	50Hz	0 to 400Hz	Set the frequency at which the stall
	starting frequency			operation level is started to reduce.
	Stall prevention operation			Select whether stall prevention operation
156	selection	0	0 to 31, 100, 101	and fast-response current limit operation
	Selection			will be performed or not.
			0 to 25s	Output start time of the OL signal output
157	OL signal output timer	0s	0 10 258	when stall prevention is activated.
			9999	Without the OL signal output
	Stall prevention operation		0	Output current is the limit level
277	current switchover	0	1	Output torque (torque current) is the limit
	Current Switchover		1	level


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Block diagram



^{*} This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

(2) Setting of stall prevention operation level (Pr. 22)



- •Set in Pr. 22 the percentage of the output current to the rated inverter current at which stall prevention operation will be performed. Normally set this parameter to 150% (initial value).
- •Stall prevention operation stops acceleration (makes deceleration) during acceleration, makes deceleration during constant speed, and stops deceleration (makes acceleration) during deceleration.
- •When stall prevention operation is performed, the OL signal is



• If an overload status lasts long, an inverter trip (e.g. electronic thermal O/L relay (E.THM)) may occur.

(3) A machine protection and load limit by torque limit (Pr. 277)

- •When Pr. 277 Stall prevention current switchover = "1", torque limit can be set.
- •When output torque (torque current) exceeds the stall prevention operation level, the output frequency is controlled to limit the output torque. For the stall prevention operation level at this time, the motor rated torque is defined as reference.




> REMARKS

- When driving multiple motors with one inverter, torque limit does not function properly.
- Since magnetic flux decreases in the constant output range (Pr. 3 Base frequency or more), the inverter operate with lower torque than the stall prevention operation level.
- · When torque limit is activated during regeneration, the output frequency is increased up to the maximum frequency.
- Torque limit does not function at 5Hz or less during deceleration.
- Note the following when using torque limit under V/F control.
 - (a) Capacity of the inverter and motor should be the same.
 - (b) Stall prevention operation level (torque limit level) is the rated torque reference of the motor whose capacity is equivalent to
 - When Pr. 0 Torque boost setting is large, torque limit is likely to occur in the low speed range.
- (d) Use the Advanced magnetic flux vector control when more appropriate torque limit is necessary.

(4) Stall prevention operation signal output and output timing adjustment (OL signal, Pr. 157)

- •When the output current exceeds the stall prevention operation level and stall prevention is activated, the stall prevention operation signal (OL signal) turns ON for longer than 100ms. When the output current falls to or below the stall prevention operation level, the output signal turns OFF.
- •Use Pr. 157 OL signal output timer to set whether the OL signal is output immediately or after a preset period of time.
- •This operation is also performed when the regeneration avoidance function or σ_{i} (overvoltage stall) is executed.
- •For the OL signal, set "3 (positive logic) or 103 (negative logic)" in Pr. 190 to Pr. 192 (output terminal function selection) and assign functions to the output terminal.


Pr. 157 Setting	Description
0 (initial value)	Output immediately.
0.1 to 25	Output after the set time (s) has elapsed.
9999	Not output.






- If the frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears to trip the
- Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.

(5) Setting of stall prevention operation in high frequency range (Pr. 22, Pr. 23, Pr. 66)





- •During high-speed operation above the rated motor frequency, acceleration may not be made because the motor current does not increase. If operation is performed in a high frequency range, the current at motor lockup becomes smaller than the rated output current of the inverter, and the protective function (OL) is not executed even if the motor is at a stop. To improve the operating characteristics of the motor in this case, the stall prevention level can be reduced in the high frequency range. This function is effective for performing operation up to the high-speed range on a centrifugal separator etc. Normally, set 50Hz in *Pr.* 66 and 100% in *Pr.* 23.
- •Formula for stall prevention operation level

Stall prevention operation level in high frequency range (%) = A + B
$$\times \left[\frac{Pr. 22 - A}{Pr. 22 - B}\right] \times \left[\frac{Pr. 23 - 100}{100}\right]$$

However, A =
$$\frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{\text{Output frequency (Hz)}}, B = \frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{400 \text{Hz}}$$

•By setting "9999" (initial value) in *Pr. 23 Stall prevention operation level compensation factor at double speed*, the stall prevention operation level is constant at the *Pr. 22* setting up to 400Hz.

(6) Set two types stall prevention operation levels (Pr. 48)

- •Turning RT signal ON makes Pr. 48 Second stall prevention operation current valid.
- •For the terminal used for RT signal input, set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.



NOTE

- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.
- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 138)



(7) Limit the stall prevention operation and fast-response current limit operation according to the operating status (Pr. 156)

•Refer to the following table and select whether stall prevention operation and fast-response current limit operation will be performed or not and the operation to be performed at OL signal output.

Pr. 156		Fast-Response Current Limit*4	st-Response		OL Signal Output O:Operation	Pr. 156	Fast-Response	Stall Prevention Operation Selection O: Activated •: Not activated			OL Signal Output O:Operation	
Sett		O: Activated ●: Not activated	Acceleration	Constant speed	Deceleration	continued •: Operation not continued *1	Setting	O: Activated •: Not activated	Acceleration	Constant	Deceleration	●: Operation not continued *1
0 (in valu		0	0	0	0	0	16	0	0	0	0	•
1	,	•	0	0	0	0	17	•	0	0	0	•
2		0	•	0	0	0	18	0	•	0	0	•
3		•	•	0	0	0	19	•	•	0	0	•
4		0	0	•	0	0	20	0	0	•	0	•
5		•	0	•	0	0	21	•	0	•	0	•
6		0	•	•	0	0	22	0	•	•	0	•
7		•	•	•	0	0	23	•	•	•	0	•
8		0	0	0	•	0	24	0	0	0	•	•
9		•	0	0	•	0	25	•	0	0	•	•
10		0	•	0	•	0	26	0	•	0	•	•
11		•	•	0	•	0	27	•	•	0	•	•
12		0	0	•	•	0	28	0	0	•	•	•
13		•	0	•	•	0	29	•	0	•	•	•
14		0	•	•	•	— *2	30	0	•	•	•	— *2
15	5	•	•	•	•	— *2	31	•	•	•	•	— *2
100	Power driving	0	0	0	0	0	Power driving	•	0	0	0	0
*3	Regeneration	•	•	•	•	- *2	*3 Regeneration	•	•	•	•	 *2


- When "Operation not continued for OL signal output" is selected, the 📙 🖟 fault (stopped by stall prevention) is displayed and operation stopped. *1
- *2
- Since stall prevention is not activated, OL signal and E.OLT are not output.

 The settings "100" and "101" allow operations to be performed in the driving and regeneration modes, respectively. The setting "101" disables the fast-*3 response current limit in the driving mode.
- OL signal is not output at fast-response current limit operation.



- When the load is heavy or the acceleration/deceleration time is short, stall prevention is activated and acceleration/ deceleration may not be made according to the preset acceleration/deceleration time. Set Pr. 156 and stall prevention operation level to the optimum values.
- In vertical lift applications, make setting so that the fast-response current limit is not activated. Torque may not be produced, causing a load drop due to gravity.







Test operation must be performed.

Stall prevention operation during acceleration may increase the acceleration time.

Stall prevention operation performed during constant speed may cause sudden speed changes.

Stall prevention operation during deceleration may increase the deceleration time, increasing the deceleration distance.



Parameters referred to

- Pr. 3 Base frequency Refer to page 94
 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135
 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

4.5 Limiting the output frequency

Purpose	Parameter	that should be Set	Refer to Page
Set upper limit and lower limit of output frequency	Maximum/minimum frequency	Pr. 1, Pr. 2, Pr. 18	92
Perform operation by avoiding mechanical resonance points	Frequency jump	Pr. 31 to Pr. 36	93


4.5.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)

Motor speed can be limited.

Clamp the upper and lower limits of the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
1	Maximum frequency	120Hz	0 to 120Hz	Upper limit of the output frequency.
2	Minimum frequency	0Hz	0 to 120Hz	Lower limit of the output frequency.
18 *	High speed maximum	120Hz	120 to 400Hz	Set when performing the operation at 120Hz
10 *	frequency	12002	120 10 40002	or more.

^{*} The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



(1) Set maximum frequency

- Use *Pr. 1 Maximum frequency* to set the maximum frequency. If the value of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
- When you want to perform operation above 120Hz, set the upper limit of the output frequency to Pr. 18 High speed maximum frequency. (When Pr. 18 is set, Pr. 1 automatically switches to the frequency of Pr. 18. Also, when Pr. 1 is set, Pr. 18 is automatically changed to the frequency set in Pr. 1.

• REMARKS

• When performing operation above 50Hz using the frequency setting analog signal, change *Pr. 125 (Pr. 126) (frequency setting gain)*.

(2) Set minimum frequency

- Use Pr. 2 Minimum frequency to set the minimum frequency.
- If the set frequency is less than Pr. 2, the output frequency is clamped at Pr. 2 (will not fall below Pr. 2).

> REMARKS

- When Pr. 15 Jog frequency is equal to or less than Pr. 2, the Pr. 15 setting has precedence over the Pr. 2 setting.
- When stall prevention is activated to decrease the output frequency, the output frequency may drop to Pr. 2 or below.



Note that when *Pr. 2* is set to any value equal to or more than *Pr. 13 Starting frequency*, simply turning ON the start signal will run the motor at the preset frequency according to the set acceleration time even if the command frequency is not input.



Parameters referred to

Pr. 13 Starting frequency Refer to page 108 Pr. 15 Jog frequency Refer to page 100

Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency 👺 Refer to page 175




4.5.2 Avoiding mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)

When avoiding resonance arisen from the natural frequency of a mechanical system, use these parameters to jump the resonant frequencies.

Parameter Number	Name	Initial Value	Setting Range	Description
31	Frequency jump 1A	9999	0 to 400Hz, 9999	
32	Frequency jump 1B	9999	0 to 400Hz, 9999	44.45.04.05.04.05.6
33	Frequency jump 2A	9999	0 to 400Hz, 9999	1A to 1B, 2A to 2B, 3A to 3B is frequency
34	Frequency jump 2B	9999	0 to 400Hz, 9999	9999: Function invalid
35	Frequency jump 3A	9999	0 to 400Hz, 9999	a constant and a constant
36	Frequency jump 3B	9999	0 to 400Hz, 9999	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



- Up to three areas can be set, with the jump frequencies set to either the top or bottom point of each area.
- The value set to 1A, 2A or 3A is a jump point and operation in the jump zone is performed at these frequencies.



To fix the frequency to 30Hz in the range 30Hz to 35Hz, set 35Hz in Pr.~34 and 30Hz in Pr.~33.

To jump the frequency to 35Hz in the range 30Hz to 35Hz, set 35Hz in Pr. 33 and 30Hz in Pr. 34.



NOTE

During acceleration/deceleration, the running frequency within the set area is valid.

4.6 V/F pattern


Purpose	Parameter	that should be Set	Refer to Page
Set motor ratings	Base frequency, Base frequency voltage	Pr. 3, Pr. 19, Pr. 47	94
Select a V/F pattern according to applications.	Load pattern selection	Pr. 14	96

4.6.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)

Used to adjust the inverter outputs (voltage, frequency) to the motor rating.

Parameter Number	Name	Initial Value	Setting Range	Description
3	Base frequency	50Hz	0 to 400Hz	Rated motor frequency. (50Hz/60Hz)
			0 to 1000V	Base voltage.
19 *	9 * Base frequency voltage	8888	8888	95% of power supply voltage
			9999	Same as power supply voltage
47 *	Second V/F (base	0000	0 to 400Hz	Base frequency when the RT signal is ON.
4/*	frequency)	9999	9999	Second V/F invalid

^{*} The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



(1) Base frequency setting (Pr. 3)

- When operating a standard motor, generally set the rated frequency of the motor to *Pr. 3 Base frequency*. When running the motor using commercial power supply-inverter switch-over operation, set *Pr. 3* to the same value as the power supply frequency.
- If the frequency given on the motor rating plate is "60Hz" only, always set to "60Hz". It may result in an inverter trip due to overload.

Special care must be taken when "1" (variable torque load) is set in $Pr.\ 14\ Load\ pattern\ selection$.


 When using the Mitsubishi constant-torque motor, set Pr. 3 to 60Hz.

(2) Set two kinds of base frequencies (Pr. 47)

- When you want to change the base frequency when switching two types of motors with one inverter, use the *Pr. 47 Second V/F* (base frequency).
- *Pr. 47 Second V/F (base frequency)* is valid when the RT signal is ON. Set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* and assign the RT signal.

• REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 138)



- •Use Pr. 19 Base frequency voltage to set the base voltage (e.g. rated motor voltage).
- •If the setting is less than the power supply voltage, the maximum output voltage of the inverter is as set in Pr. 19.
- •Pr. 19 can be utilized in the following cases.
 - (a) When regeneration is high (e.g. continuous regeneration) During regeneration, the output voltage becomes higher than the reference and may cause an overcurrent trip (E.OC□) due to an increased motor current.
 - (b) When power supply voltage variation is large When the power supply voltage exceeds the rated voltage of the motor, speed variation or motor overheat may be caused by excessive torque or increased motor current.

 When Advanced magnetic flux vector control or General-purpose magnetic flux vector control is selected, Pr. 3, Pr. 47 and Pr. 19 are invalid and Pr. 83 and Pr. 84 are valid.

Note that Pr. 3 or Pr. 47 value is made valid as inflection points of S-pattern when Pr. 29 Acceleration/deceleration pattern selection = "1" (S-pattern acceleration/deceleration A).

· Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to


Pr. 14 Load pattern selection Refer to page 96 Pr. 29 Acceleration/deceleration pattern selection Refer to page 109 Pr. 83 Rated motor voltage, Pr. 84 Rated motor frequency Refer to page 116 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135 General-purpose magnetic flux vector control Refer to page 85 Advanced magnetic flux vector control Refer to page 82

4.6.2 Load pattern selection (Pr. 14)

You can select the optimum output characteristic (V/F characteristic) for the application and load characteristics.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	For constant-torque load
		tion 0	1	For variable torque load
14	Load pattern selection		2	For constant-torque elevators
14	14 Load pattern selection			(at reverse rotation boost of 0%)
			2	For constant-torque elevators
			3	(at forward rotation boost of 0%)

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)




(1) Constant-torque load application (setting "0", initial value)

- At or less than the base frequency, the output voltage varies linearly with the output frequency.
- Set this value when driving the load whose load torque is constant even if the speed varies, e.g. conveyor, cart or roll drive.

POINT


If the load is a fan or pump, select for constant-torque load (setting "0") in any of the following cases.


- · When a blower of large inertia moment (J) is accelerated in a short time
- · For constant-torque load such as rotary pump or gear pump
- · When load torque increases at low speed, e.g. screw pump



(2) Variable-torque load application (setting "1")

- At or less than the base frequency, the output voltage varies with the output frequency in a square curve.
- Set this value when driving the load whose load torque varies in proportion to the square of the speed, e.g. fan or pump.





(3) Constant-torque load application (setting "2, 3")

- · Set "2" when a vertical lift load is fixed as power load at forward rotation driving regenerative load at reverse rotation.
- Pr. 0 Torque boost is valid during forward rotation and torque boost is automatically changed to "0%" during reverse rotation. Pr. 46 Second torque boost is valid when the RT signal turns ON.
- Set "3" for an elevated load that is in the driving mode during reverse rotation and in the regenerative load mode during forward rotation according to the load weight, e.g. counterweight system.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.

• REMARKS

- When torque is continuously regenerated as vertical lift load, it is effective to set the rated voltage in Pr. 19 Base frequency voltage to prevent trip due to current at regeneration.
- In addition, when the RT signal is ON, the other second functions are also valid.



- Load pattern selection does not function under Advanced magnetic flux vector control and General-purpose magnetic flux vector control.
- Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 0, Pr. 46 (Torque boost) Refer to page 81 Pr. 3 Base frequency Refer to page 94 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135 General-purpose magnetic flux vector control Refer to page 82 Advanced magnetic flux vector control Refer to page 82

4.7 Frequency setting by external terminals

Purpose	Parameter	that should be Set	Refer to Page
Make frequency setting by	Multi anad anavatian	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27,	98
combination of terminals	Multi-speed operation	Pr. 232 to Pr. 239	90
Perform jog operation	Jog operation	Pr. 15, Pr. 16	100
Infinitely variable speed setting by	Domete cetting function	Pr. 59	102
terminals	Remote setting function	Pr. 59	102

4.7.1 Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)


Can be used to change the preset speed in the parameter with the contact signals.

Any speed can be selected by merely turning ON/OFF the contact signals (RH, RM, RL, REX signals).

Parameter	Name	Initial Value	Setting Range	Description	
Number	Name	illitiai value	Setting Range	Description	
4	Multi-speed setting (high	50Hz	0 to 400Hz	Frequency when RH turns ON	
7	speed)	30112	0 10 400112	Frequency when Kir turns ON	
5	Multi-speed setting (middle	30Hz	0 to 400Hz	Frequency when RM turns ON	
3	speed)	30112	0 10 400112	Trequency when this on	
6	Multi-speed setting (low	10Hz	0 to 400Hz	Frequency when RL turns ON	
	speed)	10112	0 10 400112	Frequency when RL turns ON	
24 *	Multi-speed setting (speed 4)	9999	0 to 400Hz, 9999		
25 *	Multi-speed setting (speed 5)	9999	0 to 400Hz, 9999		
26 *	Multi-speed setting (speed 6)	9999	0 to 400Hz, 9999		
27 *	Multi-speed setting (speed 7)	9999	0 to 400Hz, 9999		
232 *	Multi-speed setting (speed 8)	9999	0 to 400Hz, 9999	Frequency from 4 speed to 15 speed can	
233 *	Multi-speed setting (speed 9)	9999	0 to 400Hz, 9999	be set according to the combination of	
234 *	Multi-speed setting (speed 10)	9999	0 to 400Hz, 9999	the RH, RM, RL and REX signals.	
235 *	Multi-speed setting (speed 11)	9999	0 to 400Hz, 9999	9999: not selected	
236 *	Multi-speed setting (speed 12)	9999	0 to 400Hz, 9999		
237 *	Multi-speed setting (speed 13)	9999	0 to 400Hz, 9999		
238 *	Multi-speed setting (speed 14)	9999	0 to 400Hz, 9999		
239 *	Multi-speed setting (speed 15)	9999	0 to 400Hz, 9999		

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

^{*} This parameter can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



(1) 3-speed setting (Pr. 4 to Pr. 6)

•The inverter operates at frequencies set in *Pr. 4* when RH signal is ON, *Pr. 5* when RM signal is ON and *Pr. 6* when RL signal is ON.


• REMARKS


- For multi-speed setting, if two or three speeds are simultaneously selected, priority is given to the set frequency of the lower signal.
 - For example, when the RH and RM signals turn ON, the RM signal (Pr. 5) has a higher priority.
- The RH, RM, RL signals are assigned to the terminal RH, RM, RL in the initial setting. By setting "0 (RL)", "1 (RM)", "2 (RH)" in any of *Pr. 178 to Pr. 184 (input terminal function selection)*, you can assign the signals to other terminals.



(2) Multi-speed setting for 4 or more speeds (Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)

- •Frequency from 4 speed to 15 speed can be set according to the combination of the RH, RM, RL and REX signals. Set the running frequencies in *Pr. 24 to Pr. 27, Pr. 232 to Pr. 239* (In the initial value setting, speed 4 to speed 15 are invalid).
- •For the terminal used for REX signal input, set "8" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.





Multi-speed operation connection example

*1 When "9999" is set in *Pr. 232 Multi-speed setting (speed 8)*, operation is performed at frequency set in *Pr. 6* when RH, RM and RL are turned OFF and REX is turned ON.



REMARKS

The priorities of the frequency commands by the external signals are "Jog operation > multi-speed operation > terminal 4 analog input > terminal 2 analog input".

(Refer to page 175 for the frequency command by analog input)

- Valid in the External operation mode or PU/External combined operation mode (Pr. 79 = "3" or "4").
- Multi-speed parameters can also be set in the PU or External operation mode.
- Pr. 24 to Pr. 27 and Pr. 232 to Pr. 239 settings have no priority between them.
- When Pr. 59 Remote function selection ≠ "0", multi-speed setting is invalid as RH, RM and RL signals are remote setting signals.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 15 Jog frequency 👺 Refer to page 100

Pr. 59 Remote function selection Refer to page 102

Pr. 79 Operation mode selection 👺 Refer to page 190

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

4.7.2 Jog operation (Pr. 15, Pr. 16)

You can set the frequency and acceleration/deceleration time for Jog operation. Jog operation can be performed in either of the External and the PU operation mode.

This operation can be used for conveyor positioning, test operation, etc.


Parameter Number	Name	Initial Value	Setting Range	Description
15	Jog frequency	5Hz	0 to 400Hz	Frequency for Jog operation.
16	Jog acceleration/ deceleration time	0.5s	0 to 3600/ 360s *	Acceleration/deceleration time for Jog operation. As the acceleration/deceleration time, set the time taken to reach the frequency (initial value is 50Hz) set in <i>Pr. 20 Acceleration/deceleration reference frequency</i> . Acceleration/deceleration time can not be set separately.


These parameters are displayed as simple mode parameter only when the parameter unit (FR-PU04/FR-PU07) is connected. When the parameter unit is not connected, the above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

* When the Pr. 21 Acceleration/deceleration time increments setting is "0" (initial value), the setting range is "0 to 3600s" and setting increments is "0.1s". When the setting is "1", the setting range is "0 to 360s" and the setting increments is "0.01s".

Jog operation from outside

- When the JOG signal is ON, a start and stop can be made by the start signal (STF, STR).
- •For the terminal used for Jog operation selection, set "5" in any of Pr.178 to Pr.184 (input terminal function selection) to assign the function.





Connection diagram for external Jog operation

Display -



Operation


- 1. Screen at powering ON
 - Confirm that the External operation mode is selected. ([EXT] lit)

If not displayed, press $\frac{PU}{FXT}$ to change to the External (EXT) operation mode. If the operation mode still does not change, set Pr. 79 to change to the External operation mode.

2. Turn ON the JOG switch.



- Turn the start switch (STF or STR) ON.
 - The motor runs while the start switch (STF or STR) is ON.
 - The motor runs at 5Hz. (initial value of Pr.
- 4. Turn the start switch (STF or STR) OFF.




(I) REMARKS

- When you want to change the running frequency, change Pr. 15 Jog frequency. (initial value "5Hz")
- When you want to change the acceleration/deceleration time, change Pr. 16 Jog acceleration/deceleration time. (initial value "0.5s") The acceleration time and deceleration time cannot be set separately for Jog operation.



(2) Jog operation from PU

•Selects Jog operation mode from the operation panel and PU (FR-PU04/FR-PU07). Operation is performed only while the start button is pressed.



Operation

Display

- 1. Confirmation of the RUN indication and operation mode indication
 - The monitor mode should have been selected.
 - The inverter should be at a stop.
- 2. Press (PU) to choose the PU Jog operation mode.
- 3. Press (RUN
 - While (RUN) is pressed, the motor rotates.
 - The motor runs at 5Hz. (Pr. 15 initial value)
- 4. Release (RUN)















[When changing the frequency of PU Jog operation]


5. Press (MODE) to choose the parameter setting mode.




PRM indication is lit.



(The parameter number read previously appears.)





8. Turn (to set the value to " / [[[] [] ". (10Hz)

9. Press (SET) to set.

















Flicker...Parameter setting complete!!

10.Perform the operations in steps 1 to 4.

The motor rotates at 10Hz.



NOTE

- When Pr. 29 Acceleration/deceleration pattern selection = "1" (S-pattern acceleration/deceleration A), the acceleration/deceleration time is the period of time required to reach Pr. 3 Base frequency.
- The Pr. 15 setting should be equal to or higher than the Pr. 13 Starting frequency. Starting frequency
- The JOG signal can be assigned to the input terminal using any of *Pr. 178 to Pr. 184 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Set parameters after confirming the function of each terminal.
- During Jog operation, the second acceleration/deceleration via the RT signal cannot be selected. (The other second functions are valid. (*Refer to page 227*))
- When *Pr. 79 Operation mode selection* = "4", pressing RUN of the operation panel and FWD | REV of the parameter unit (FR-PU04/FR-PU07) starts the inverter and pressing RESET stops the inverter.
- This function is invalid when Pr. 79 = "3".



Parameters referred to


- Pr. 13 Starting frequency Refer to page 108
- Pr. 29 Acceleration/deceleration pattern selection 📭 Refer to page 109
- Pr. 20 Acceleration/deceleration reference frequency, Pr. 21 Acceleration/deceleration time increments 👺 Refer to page 105
- Pr. 79 Operation mode selection Refer to page 190
- Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

4.7.3 Remote setting function (Pr. 59)

•Even if the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.

Parameter			Setting	Description		
Number	Name	Initial Value	Range	RH, RM, RL signal function	Frequency setting storage function	
		0	0	Multi-speed setting	_	
			1	Remote setting	With	
			2	Remote setting	Not used	
59	59 Remote function selection				Not used	
			3	Remote setting	(Turning STF/STR OFF	
			3	Remote setting	clears remotely-set	
					frequency.)	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 156)



* External running frequency (other than multi-speed) or PU running frequency



(1) Remote setting function

•Use *Pr. 59* to select whether the remote setting function is used or not and whether the frequency setting storage function in the remote setting mode is used or not.

When *Pr.* 59 is set to any of "1 to 3" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).

•When using the remote setting function, following frequencies can be compensated to the frequency set by RH and RM operation according to the operation mode.

During external operation (including Pr. 79 = "4") external frequency command other than multi-speed settings

(2) Frequency setting storage

•The frequency setting storage function stores the remotely-set frequency (frequency set by RH/RM operation) into the memory (EEPROM). When power is switched OFF once, then ON, operation is resumed with that output frequency value. (Pr. 59 = 1)

<Frequency setting storage conditions>


Remotely-set frequency is stored in the following timings.

- · When the start signal (STF or STR) turns OFF.
- Every minute after both the RH (acceleration) and RM (deceleration) signals turn OFF (ON). (The frequency is overwritten if the latest frequency is different from the previous frequency when comparing the two. The state of the RL signal does not affect writing.)



NOTE

 The range of frequency changeable by RH (acceleration) and RM (deceleration) is 0 to maximum frequency (Pr. 1 or Pr. 18 setting).
 Note that the maximum value of set frequency is (main speed + maximum frequency).



- When the acceleration or deceleration signal switches ON, acceleration/deceleration time is as set in *Pr. 44 Second acceleration/deceleration time* and *Pr. 45 Second deceleration time*. Note that when the time set in *Pr. 7* or *Pr. 8* is longer than the time set in *Pr. 44* or *Pr. 45*, the acceleration/deceleration time is as set in *Pr. 7* or *Pr. 8*. (when RT signal is OFF) When the RT signal is ON, acceleration/deceleration is made in the time set in *Pr. 44* and *Pr. 45*, regardless of the *Pr. 7* or *Pr. 8* setting.
 - Even if the start signal (STF or STR) is OFF, turning ON the acceleration (RH) or deceleration (RM) signal varies the preset frequency.
- When switching the start signal from ON to OFF, or changing frequency by the RH or RM signal frequently, set the frequency setting value storage function (write to EEPROM) invalid (Pr. 59 = "2, 3"). If set valid (Pr. 59 = "1"), frequency is written to EEPROM frequently, this will shorten the life of the EEPROM.
- The RH, RM, RL signals can be assigned to the input terminal using any *Pr. 178 to Pr. 184 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Set parameters after confirming the function of each terminal.
- · Also available for the Network operation mode.







> REMARKS

During Jog operation or PID control operation, the remote setting function is invalid.

Setting frequency is "0"

- Even when the remotely-set frequency is cleared by turning ON the RL (clear) signal after turn OFF (ON) of both the RH and RM signals, the inverter operates at the remotely-set frequency stored in the last operation if power is reapplied before one minute has elapsed since turn OFF (ON) of both the RH and RM signals
- When the remotely-set frequency is cleared by turning ON the RL (clear) signal after turn OFF (ON) of both the RH and RM signals, the inverter operates at the frequency in the remotely-set frequency cleared state if power is reapplied after one minute has elapsed since turn OFF (ON) of both the RH and RM signals.







🄨 When selecting this function, re-set the maximum frequency according to the machine.



Parameters referred to

Pr. 1 Maximum frequency, Pr. 18 High speed maximum frequency Refer to page 92

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time The Refer to page 105

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135



4.8 Setting of acceleration/deceleration time and acceleration/deceleration pattern

Purpose	Parameter t	hat should be Set	Refer to Page
Motor acceleration/deceleration	Acceleration/deceleration	Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44,	105
time setting	times	Pr. 45, Pr. 147	105
Starting frequency	Starting frequency and start-time hold	Pr. 13, Pr. 571	108
Set acceleration/deceleration pattern suitable for application	Acceleration/deceleration pattern	Pr. 29	109
Automatically set optimum acceleration/deceleration time.	Automatic acceleration/ deceleration	Pr. 61 to Pr. 63, Pr. 292	110

4.8.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 147)

Used to set motor acceleration/deceleration time.

Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease. For the acceleration time at automatic restart after instantaneous power failure, refer to *Pr. 611 Acceleration time at a restart (page 158)*.

Parameter Number	Name	Initial Value		Setting Range	Des	scription
7	Acceleration time	FR-E740-095(SC) or less FR-E720S-110(SC) or less	5s	0 to 3600/	/ Motor acceleration time.	
,	Acceleration time	FR-E740-120(SC) and 170(SC) FR-E740-230(SC) and 300(SC)	10s 15s	360s *2	Wotor acceleration	uiile.
8	Deceleration time	FR-E740-230(3C) and 300(3C) FR-E740-095(SC) or less FR-E720S-110(SC) or less	5s	0 to 3600/	Motor deceleration	timo
0	Deceleration time	FR-E740-120(SC) and 170(SC) FR-E740-230(SC) and 300(SC)	10s 15s	360s *2	Motor deceleration	ume.
	Acceleration/		•		Frequency that will	be the basis of
20 *1	deceleration	50Hz		1 to 400Hz	acceleration/deceleration time.	
	reference	331.12		1 10 100112		celeration time, set the
	frequency				frequency change time from stop to Pr. 20.	
	Acceleration/	_		0	Increments: 0.1s Range: 0 to 3600s	Increments and setting range of acceleration/
21 *1	deceleration time increments	0		1	Increments: 0.01s Range: 0 to 360s	deceleration time setting can be changed.
44 *1	Second acceleration/ deceleration time	FR-E740-095(SC) or less FR-E720S-110(SC) or less FR-E740-120(SC) and 170(SC) 10s FR-E740-230(SC) and 300(SC) 15s		0 to 3600/ 360s *2	Acceleration/decele	eration time when the RT
45 *1	Second deceleration time	9999		0 to 3600/ 360s *2 9999	Deceleration time when the RT signal is ON. Acceleration time = deceleration time	
147 *1	Acceleration/ deceleration time switching	9999		0 to 400Hz	Frequency when automatically switching the acceleration/deceleration time of <i>Pr. 4</i> and <i>Pr. 45</i> .	
*1 The above	frequency	en Pr 160 User group read selection = "0	U (D.C.	9999	No function	

^{*1} The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

^{*2} Depends on the Pr. 21 Acceleration/deceleration time increments setting. The initial value for the setting range is "0 to 3600s" and the setting increments is "0.1s".

Running frequency Time Acceleration time Pr. 7. Pr. 44 Pr. 8 Pr. 45

(1) Acceleration time setting (Pr. 7, Pr. 20)

- •Use *Pr. 7 Acceleration time* to set the acceleration time required to reach *Pr. 20 Acceleration/deceleration reference frequency* from 0Hz.
- •Set the acceleration time according to the following formula.

Acceleration time setting =
$$\frac{Pr. 20}{\text{Maximum operating frequency - }Pr. 13} \times \text{Acceleration time from a stop to the maximum operating frequency}$$

Example) How to find the setting value for Pr: 7 when increasing the output frequency to the maximum frequency of 40Hz in 10s with Pr: 20 = 50Hz (initial setting) and Pr: 13 = 0.5Hz.

$$Pr. 7 = \frac{50\text{Hz}}{40\text{Hz} - 0.5\text{Hz}} \times 10\text{s} = 12.7\text{s}$$

(2) Deceleration time setting (Pr. 8, Pr. 20)

- •Use *Pr. 8 Deceleration time* to set the deceleration time required to reach 0Hz from *Pr. 20 Acceleration/deceleration reference frequency*.
- •Set the deceleration time according to the following expression.

$$\frac{\text{Deceleration}}{\text{time setting}} = \frac{Pr. 20}{\text{Maximum operating frequency - } Pr. 10} \times \text{Deceleration time from the maximum operating frequency to a stop}$$

Example) How to find the setting value for Pr.~8 when decreasing the output frequency from the maximum frequency of 40Hz in 10s with Pr.~20 = 120Hz and Pr.~10 = 3Hz.

$$Pr. 8 = \frac{120 \text{Hz}}{40 \text{Hz} - 3 \text{Hz}} \times 10 \text{s} = 32.4 \text{s}$$

(3) Change the setting range and increments of the acceleration/deceleration time (Pr. 21)

•Use Pr. 21 to set the acceleration/deceleration time and minimum setting range.



NOTE

• Changing the *Pr. 21* setting changes the acceleration/deceleration time setting (*Pr. 7, Pr. 8, Pr. 16, Pr. 44, Pr. 45*). (It does not influence the setting of *Pr. 611 Acceleration time at a restart*.)

When $Pr.\ 7$ is set to "5.0s" at $Pr.\ 21$ setting of "0", and then $Pr.\ 21$ is changed to "1", the $Pr.\ 7$ setting automatically changes to "0.5s".




(4) Set two kinds of acceleration/deceleration times (RT signal, Pr. 44, Pr. 45, Pr. 147)

- Pr. 44 and Pr. 45 are valid when the RT signal is ON, or the output frequency reaches or exceeds the setting of Pr. 147.
- •When "9999" is set to Pr. 45, the deceleration time becomes equal to the acceleration time (Pr. 44).
- •For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.
- Acceleration/deceleration time changes when the RT signal turns ON or the output frequency reaches the Pr.147 setting or higher.

Pr. 147 Setting	Acceleration/Deceleration Time	Description	
9999 (initial value)	Pr. 7. Pr. 8	No automatic switching of the acceleration/deceleration	
9999 (IIIItiai vaide)	F1. /, F1. 0	time	
0.00Hz	Pr. 44, Pr. 45	Second acceleration/deceleration time from a start	
0.00 Hz $\leq Pr. 147 \leq$ Set frequency	Output frequency < Pr. 147: Pr. 7, Pr. 8	Acceleration/deceleration time automatic switching *	
0.00Hz ≤ <i>Pr. 147</i> ≤ Set frequency	Pr. 147 ≤ Output frequency: Pr. 44, Pr. 45	Acceleration/deceleration time automatic switching *	
Sat fraguaday & Pr. 147	Pr. 7. Pr. 8	No automatic switching, since output frequency will not	
Set frequency < Pr. 147	Pr. /, Pr. 0	reach the switching frequency	

When the RT signal turns on, the acceleration/deceleration time switches to the second acceleration/deceleration time even when the output frequency is not reached to Pr. 147 setting.





NOTE

- When the acceleration/deceleration pattern is S-pattern acceleration/deceleration A (refer to page 109), the acceleration/ deceleration time is the time required to reach ${\it Pr.\,3\,Base\,frequency}$.
- Acceleration/deceleration time formula when the set frequency is the base frequency or higher

$$t = \frac{4}{9} \times \frac{T}{(Pr. 3)^2} \times f^2 + \frac{5}{9} T$$

- T: Acceleration/ueceif: Set frequency (Hz) T: Acceleration/deceleration time setting (s)
- Guideline for acceleration/deceleration time at the Pr. 3 Base frequency of 50Hz (0Hz to set frequency)

Frequency setting (Hz) Acceleration/ deceleration time (s)	50	120	200	400
5	5	16	38	145
15	15	47	115	429

Changing terminal assignment may affect the other functions. Set parameters after confirming the function of each terminal.



• REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 138)
- If the Pr. 20 setting is changed, the Pr. 125 and Pr. 126 (frequency setting signal gain frequency) settings do not change. Set Pr. 125 and Pr. 126 to adjust the gains.
- When the Pr. 7, Pr. 8, Pr. 44 and Pr. 45 settings are 0.03s or less, the acceleration/deceleration time is 0.04s. At that time, set Pr 20 to "120Hz" or less.
- Any value can be set to the acceleration/deceleration time but the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mechanical system J (moment of inertia) and motor torque.



Parameters referred to


Pr. 3 Base frequency Refer to page 94 Pr. 10 DC injection brake operation frequency Refer to page 124 Pr. 29 Acceleration/deceleration pattern selection Refer to page 109 Pr. 125, Pr. 126 (frequency setting gain frequency) Refer to page 175 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

4.8.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571)

You can set the starting frequency and hold the set starting frequency for a certain period of time. Set these functions when you need the starting torque or want to smooth motor drive at a start.

Parameter Number	Name	Initial Value	Setting Range	Description
13	Starting frequency	0.5Hz	0 to 60Hz	Frequency at start can be set in the range 0 to 60Hz. Starting frequency at which the start signal is turned ON.
571	Holding time at a start	9999	0.0 to 10.0s 9999	Holding time of <i>Pr. 13 Starting frequency</i> . Holding function at a start is invalid

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)




(1) Starting frequency setting (Pr. 13)

- •Frequency at start can be set in the range 0 to 60Hz.
- You can set the starting frequency at which the start signal is turned ON.



NOTE

The inverter will not start if the frequency setting signal is less than the value set in Pr. 13. For example, when 5Hz is set in Pr. 13, the motor will not start running until the frequency setting signal reaches 5Hz.



(2) Start-time hold function (Pr. 571)

- •This function holds during the period set in *Pr. 571* and the output frequency set in *Pr. 13 Starting frequency*.
- •This function performs initial excitation to smooth the motor drive at a start.



REMARKS

When Pr. 13 = "OHz", the starting frequency is held at 0.01Hz.



NOTE

- . When the start signal was turned OFF during start-time hold, deceleration is started at that point.
- At switching between forward rotation and reverse rotation, the starting frequency is valid but the start-time hold function is invalid.



Note that when *Pr. 13* is set to any value equal to or lower than *Pr. 2 Minimum frequency*, simply turning ON the start signal will run the motor at the preset frequency even if the command frequency is not input.



Parameters referred to

Pr. 2 Minimum frequency Refer to page 92




4.8.3 Acceleration/deceleration pattern (Pr. 29)

You can set the acceleration/deceleration pattern suitable for application.


Parameter Number	Name	Initial Value	Setting Range	Description
	Acceleration/deceleration		0	Linear acceleration/ deceleration
29		0	1	S-pattern acceleration/deceleration A
	pattern selection		2	S-pattern acceleration/deceleration B

The above parameters can be set when Pr. 160 User group read selection ="0". (Refer to page 184)



(1) Linear acceleration/deceleration (Pr. 29 = "0", initial value)

•For the inverter operation, the output frequency is made to change linearly (linear acceleration/deceleration) to prevent the motor and inverter from excessive stress to reach the set frequency during acceleration, deceleration, etc. when frequency changes. Linear acceleration/deceleration has a uniform frequency/time slope.



(2) S-pattern acceleration/deceleration A (Pr. 29 = "1")

•For machine tool spindle applications, etc.


Used when acceleration/deceleration must be made in a short time to a highspeed range of not lower than the base frequency.

In this acceleration/deceleration pattern, *Pr. 3 Base frequency* (fb) is the inflection point of the S pattern and you can set the acceleration/deceleration time appropriate for motor torque reduction in a constant-power operation range of base frequency (fb) or higher.



NOTE

As the acceleration/deceleration time of S-pattern acceleration/deceleration A, set the time taken until Pr. 3 Base frequency is reached, not Pr. 20 Acceleration/deceleration reference frequency.



(3) S-pattern acceleration/deceleration B (Pr. 29 = "2")

•For prevention of load shifting in conveyor and other applications.

Since acceleration/deceleration is always made in an S shape from current frequency (f2) to target frequency (f1), this function eases shock produced at acceleration/deceleration and is effective for load collapse prevention, etc.



Parameters referred to

Pr. 3 Base frequency Refer to page 94

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 20 Acceleration/deceleration reference frequency Refer to page 105

4.8.4 Shortest acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)

The inverter operates in the same conditions as when appropriate values are set in each parameter even if acceleration/deceleration time and V/F pattern are not set. This function is useful when you just want to operate, etc. without fine parameter setting.

Parameter	Nama	Initial	Setting	De enigetie o
Number	Name	Value	Range	Description
			0 to 500A	Set the reference current during shortest
61	Reference current	9999	0 10 00071	acceleration/deceleration.
			9999	Rated inverter output current value is reference
62	Reference value at	9999	0 to 200%	Set the limit value during shortest acceleration.
02	acceleration	9999	9999	150% is a limit value
63	Reference value at	0000	0 to 200%	Set the limit value during shortest deceleration.
63	deceleration	9999	9999	150% is a limit value
	Automatic acceleration/ deceleration	0	0	Normal mode
			1	Shortest acceleration/deceleration (without brake)
292			11	Shortest acceleration/deceleration (with brake)
			7, 8	Brake sequence mode 1, 2
			., •	(Refer to page 131)
			0	Both acceleration and deceleration are made in the
				shortest acceleration/deceleration mode
293	Acceleration/deceleration	0	1	Only acceleration is made in the shortest
293	separate selection		<u>'</u>	acceleration/deceleration mode
			2	Only deceleration is made in the shortest
			2	acceleration/deceleration mode

The above parameters can be set when Pr. 160 User group read selection ="0". (Refer to page 184)

(1) Shortest acceleration/deceleration mode (Pr. 292 = "1, 11", Pr. 293)

- •Set when you want to accelerate/decelerate the motor for the shortest time. It is desired to make acceleration/deceleration in a shorter time for a machine tool etc. but the design values of machine constants are unknown.
- •Acceleration/deceleration speed is automatically adjusted at a start of acceleration/deceleration from the value of the setting value of *Pr. 7 Acceleration time* and *Pr. 8 Deceleration time* so that acceleration/deceleration is made with the maximum torque the inverter can output. (The setting values of *Pr. 7* and *Pr. 8* are not changed.)
- •Either acceleration or deceleration can be made in the shortest time using *Pr. 293 Acceleration/deceleration separate selection*. When the setting value is "0" (initial value), both acceleration and deceleration can be made in the shortest time.
- •Set "11" when an optional MRS type type brake resistor, high-duty brake resistor or brake unit is connected. Deceleration time can be further shortened.
- •When the shortest/acceleration mode is selected, the stall prevention operation level during acceleration/deceleration from the value of becomes 150% (adjustable using *Pr. 61* to *Pr. 63*). Setting of *Pr. 22 Stall prevention operation level* is used only during a constant speed operation.
- •It is inappropriate to use for the following applications.
 - a) Machine with a large inertia such as a fan (more than 10 times). Since stall prevention operation will be activated for a long time, this type of machine may be brought to an alarm stop due to motor overloading, etc.
 - b) To perform operation with a constant acceleration/deceleration time.

> REMARKS

- Even if automatic acceleration/deceleration mode has been selected, inputting the JOG signal (Jog operation) or RT signal (second function selection) during an inverter stop will switch to the normal operation and give priority to Jog operation or second function selection. Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation in automatic acceleration/deceleration mode.
- Since acceleration/deceleration is made with the stall prevention operation being activated, the acceleration/deceleration speed always varies according to the load conditions.
- Note that when proper values are set in Pr. 7 and Pr. 8, acceleration/deceleration time may be shorter than selecting shortest
 acceleration/deceleration mode.



(2) Adjustment of shortest acceleration/deceleration mode (Pr. 61 to Pr. 63)

•By setting the adjustment parameters Pr. 61 and Pr. 63, the application range can be made wider.

Parameter	Name	Setting Range	Description			
Number		oottiiig ittaligo	Becomption			
			For example, when the motor and inverter are different in capacity,			
	Reference current	0 to 500A	set the rated motor current value.			
61		0 10 500A	Set reference current (A) of the stall prevention operation level			
			during acceleration/deceleration.			
		9999 (initial value)	The rated inverter current is defined as reference.			
			Set when it is desired to change the reference level of acceleration			
62	Reference value at	0 to 200%	and deceleration.			
J 52	acceleration	0 10 200%	Set the stall prevention operation level (ratio to the current value of			
	Reference value at		Pr. 61) during acceleration/deceleration.			
63	deceleration	0000 (initial value)	Stall prevention operation level is 150% for the shortest acceleration/			
	4000.0.4011	9999 (initial value)	deceleration.			

• REMARKS

Since the Pr. 61 to Pr. 63 settings automatically return to the initial value (9999) if the Pr. 292 setting is changed, set Pr. 292 first when you need to set Pr. 61 to Pr. 63.



Parameters referred to

Pr. 0 Torque boost Refer to page 81
Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 105

Pr. 22 Stall prevention operation level Refer to page 88

4.9 Selection and protection of a motor

Purpose	Parameter that	should be Set	Refer to Page
Motor protection from overheat	Electronic thermal O/L relay	Pr. 9, Pr. 51	112
Use the constant-torque motor	Applied motor	Pr. 71	114
The motor performance can be maximized for operation in magnetic flux vector control method.	Offline auto tuning	Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859	116

4.9.1 Motor overheat protection (Electronic thermal O/L relay) (Pr. 9, Pr. 51)


Set the current of the electronic thermal relay function to protect the motor from overheat. This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

Parameter Number	Name	Initial Value	Setting Range	Description
9	Electronic thermal O/L relay	Inverter rated current *1	0 to 500A	Set the rated motor current.
51 *2	Second electronic thermal O/L relay *3	9999	0 to 500A	Valid when the RT signal is ON. Set the rated motor current.
			9999	Second electronic thermal O/L relay invalid

- *1 The initial value of the FR-E740-026(SC) or less, FR-E720S-050(SC) or less is set to 85% of the rated inverter current.
- *2 The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)
- *3 When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.

(1) Electronic thermal O/L relay (Pr. 9)

Electronic thermal O/L relay operation characteristic



This function detects the overload (overheat) of the motor and trips. (The operation characteristic is shown on the left)

- Set the rated current (A) of the motor in Pr. 9.
 (If the motor has both 50Hz and 60Hz rating and the Pr. 3 Base frequency is set to 60Hz, set the 1.1 times of the 60Hz rated motor current.)
- Set "0" in Pr. 9 when you do not want to operate the electronic thermal O/L relay, e.g. when using an external thermal relay with the motor. (Note that the output transistor protection of the inverter functions (E.THT).)
- When using a Mitsubishi constant-torque motor
 - 1) Set "1" or "13 to 16", "50", "53", "54" in any of *Pr.* 71. (This provides a 100% continuous torque characteristic in the low-speed range.
 - 2) Set the rated current of the motor in Pr. 9.
- *1 When 50% of the inverter rated output current (current value) is set to Pr. 9
- *2 The % value denotes the percentage to the inverter rated output current. It is not the percentage to the motor rated current.
- *3 When you set the electronic thermal O/L relay dedicated to the Mitsubishi constant-torque motor, this characteristic curve applies to operation at 6Hz or higher.

NOTE


- Fault by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-OFF.
- When multiple motors are operated by a single inverter, protection cannot be provided by the electronic thermal function. Install an external thermal relay to each motor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- · A special motor cannot be protected by the electronic thermal relay function.
- The operation time of the transistor protection thermal shortens when the Pr. 72 PWM frequency selection setting increases.
- · Electronic thermal relay may not function when 5% or less of inverter rated current is set to electronic thermal relay setting.



(2) Set two different electronic thermal O/L relays (Pr. 51)

Use this function when running two motors of different rated currents individually by a single inverter. (When running two motors together, use external thermal relays.)

- •Set the rated current of the second motor to Pr. 51.
- •When the RT signal is ON, thermal protection is provided based on the Pr. 51 setting.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



Pr. 450	Pr. 9	Pr.51	RT =	OFF	RT =	= ON
Second applied motor	Electronic thermal O/L relay	Second electronic thermal O/L relay	First motor	Second motor	First motor	Second motor
		9999	×	×	×	×
9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	×	0	×
9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0
		9999	×	×	×	×
Other than 9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	Δ	Δ	0
Other than 9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0


- O... Output current value is used to perform integration processing
- Δ... Output current is assumed as 0A to perform integration processing. (cooling processing)
- x... Electronic thermal relay function is not activated.



• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 138)

(3) Electronic thermal relay function prealarm (TH) and alarm signal (THP signal)

100%: Electronic thermal O/L relay alarm operation value




- The alarm signal (THP) is output and electronic thermal relay function prealarm (TH) is displayed when the electronic thermal O/L relay cumulative value reaches 85% of the level set in Pr. 9 or Pr. 51. If it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E.THM/E.THT) occurs.
- The inverter does not trip even when the alarm signal (THP) is output.
- For the terminal used for the THP signal output, assign the function by setting "8 (positive logic) or 108 (negative logic)" in any of *Pr. 190 to Pr. 192 (output terminal function selection)* .



NOTE

• Changing the terminal assignment using *Pr.190 to Pr.192 (output terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.

(4) External thermal relay input (OH signal)



- To protect the motor against overheat, use the OH signal when using an external thermal relay or the built-in thermal protector of the motor.
- When the thermal relay operates, the inverter trips and outputs the fault signal (E.OHT).
- For the terminal used for OH signal input, assign the function by setting "7" to any of *Pr. 178 to Pr.184 (input terminal function selection)*.



NOTE

• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 71 Applied motor Refer to page 114

Pr. 72 PWM frequency selection Refer to page 170

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

4.9.2 Applied motor (Pr. 71, Pr. 450)

Setting of the used motor selects the thermal characteristic appropriate for the motor.

Setting is required to use a constant-torque motor. Thermal characteristic of the electronic thermal relay function suitable for the motor is set.

When General-purpose magnetic flux vector or Advanced magnetic flux vector control is selected, the motor constants (SF-JR, SF-HR, SF-JRCA, SF-HRCA, etc.) necessary for control are selected as well.

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0, 1, 3 to 6, 13 to 16, 23, 24, 40, 43, 44, 50, 53, 54	Selecting the standard motor or constant-torque motor sets the corresponding motor thermal characteristic.
450	Second applied motor	9999	0, 1 9999	Set when using the second motor. Second motor is invalid (thermal characteristic of the first motor (<i>Pr. 71</i>))

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Set the motor to be used

Refer to the following list and set this parameter according to the motor used.

Pr. 71 (Pr. 450)					Motor (O: Used motor)			
Se	tting	Thermal Characteristic of the Electronic Thermal Relay Function						
Pr. 71	Pr. 450							
(<i>Pr. 71</i> in	0 nitial value)	Thermal characteristics of a standard motor			0			
	1	Thermal characteristics of the Mitsubishi con	stant-torque m	otor		0		
40	_	Thermal characteristic of Mitsubishi high effic	ciency motor (S	SF-HR)	O *1			
50	_	Thermal characteristic of Mitsubishi constant	-torque motor	(SF-HRCA)		O *2		
3	_	Standard motor			0			
13	_	Constant-torque motor				0		
23	_	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)	Select "Offline auto tuning setting"		0			
43	_	Mitsubishi high efficiency motor (SF-HR)			O *1			
53	_	Mitsubishi constant-torque motor (SF-HRCA)				O *2		
4	_	Standard motor			0			
14	_	Constant-torque motor				0		
24	_	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)		data can be read, ed, and set.	0			
44	_	Mitsubishi high efficiency motor (SF-HR)			0*1			
54	_	Mitsubishi constant-torque motor (SF-HRCA)				O *2		
5	_	Standard motor	Star	Direct input of	0			
15	_	Constant-torque motor	connection	motor constants		0		
6		Standard motor	Delta		0			
16	_	Constant-torque motor	connection	is enabled		0		
_	9999 (initial value)	Without second applied motor						

Motor constants of Mitsubishi high efficiency motor SF-HR.

• REMARKS

- When performing offline auto tuning, set any of "3, 13, 23, 43, 53" in Pr. 71. (Refer to page 116 for offline auto tuning.)
- For the FR-E740-120(SC) and 170(SC), the Pr. 0 Torque boost and Pr. 12 DC injection brake operation voltage settings are automatically changed according to the Pr. 71 setting as follows.

Automatic Change Parameter	Standard Motor Setting *1	Constant-torque Motor Setting *2
Pr. 0	3%	2%
Pr. 12	4%	2%

Pr. 71 setting: 0, 3 to 6, 23, 24,40, 43, 44

Pr. 71 setting: 1, 13 to 16, 50, 53, 54



NOTE

• Set the electronic thermal relay function to the thermal characteristic for the constant-torque motor when using a geared motor (GM-S, GM-D, GM-SY, GM-HY2 series) to perform Advanced magnetic flux vector control or Generalpurpose magnetic-flux vector control.

Motor constants of Mitsubishi constant-torque motor SF-HRCA.



(2) Use two motors (Pr. 450)

- Set Pr. 450 Second applied motor to use two different motors with one inverter.
- When "9999" (initial value) is set, no function is selected.
- When a value other than 9999 is set in Pr. 450, the second motor is valid when the RT signal turns ON.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



(I) REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 138)



ullet Changing the terminal assignment using $Pr.\ 178\ to\ Pr.\ 184\ (input\ terminal\ function\ selection)$ may affect other functions. Set parameters after confirming the function of each terminal.



Net this parameter correctly according to the motor used.

Incorrect setting may cause the motor to overheat and burn.



Parameters referred to

Pr. 0 Torque boost Refer to page 81

Pr. 12 DC injection brake operation voltage Refer to page 124

Pr. 80 Motor capacity, Pr. 81 Number of motor poles Refer to page 116

Pr. 82 to Pr. 84, Pr. 90 to Pr. 94 (motor constants), Pr. 96 Auto tuning setting/status Refer to page 116

Pr. 800 Control method selection Refer to page 80

4.9.3 Exhibiting the best performance for the motor (offline auto tuning) (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859)

The motor performance can be maximized with offline auto tuning.

•What is offline auto tuning?

When performing Advanced magnetic flux vector control or General-purpose magnetic flux vector control, the motor can be run with the optimum operating characteristics by automatically measuring the motor constants (offline auto tuning) even when each motor constants differs, other manufacturer's motor is used, or the wiring length is long.

Parameter Number	Name	Initial Value		Setting Range	Description
				0, 1, 3 to 6,	By selecting a standard motor or constant-
71	Applied motor	0		13 to 16, 23, 24, 40,	torque motor, thermal characteristic and motor
				43, 44, 50, 53, 54	constants of each motor are set.
80	Motor capacity	9999		0.1 to 15kW	Applied motor capacity.
	отог оприотој			9999	V/F control
81	Number of motor poles	9999		2, 4, 6, 8, 10	Number of motor poles.
_				9999	V/F control
					Tuning data
				0 to 500A	(The value measured by offline auto tuning is
82	Motor excitation current	9999			automatically set.)
				9999	Uses the Mitsubishi motor (SF-JR, SF-HR,
		200V class	200V		SF-JRCA, SF-HRCA) constants.
83	Rated motor voltage	400V class	400V	0 to 1000V	Rated motor voltage (V).
84	Rated motor frequency	50Hz	400 0	10 to 120Hz	Rated motor frequency (Hz).
90	Motor constant (R1)	9999		0 to 50Ω, 9999	Tuning data
91	Motor constant (R2)	9999		0 to 50Ω, 9999	(The value measured by offline auto tuning is
92	Motor constant (L1)	9999		0 to 1000mH, 9999	automatically set.)
93	Motor constant (L2)	9999		0 to 1000mH, 9999	9999: Uses the Mitsubishi motor (SF-JR, SF-
94	Motor constant (X)	9999		0 to 100%, 9999	HR, SF-JRCA, SF-HRCA) constants.
	()			0	Offline auto tuning is not performed
				1	For Advanced magnetic flux vector control Offline auto tuning is performed without motor running (all motor constants).
96	Auto tuning setting/ status			11	For General-purpose magnetic flux vector control Offline auto tuning is performed without motor running. (motor constant (R1) only)
				21	Offline auto tuning for V/F control (automatic restart after instantaneous power failure (with frequency search)) (Refer to page 161)
859	Torque current	9999		0 to 500A	Tuning data (The value measured by offline auto tuning is automatically set.)
				9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.

The above parameters can be set when Pr.~160~User~group~read~selection = "0".(Refer to page 184)



• The setting range and increments of *Pr. 82, Pr. 90* to *Pr. 94* and *Pr. 859* changes according to the setting value of *Pr. 71* and *Pr. 96*.

Applied Motor		Internal Stored Value *1		Direct Input Value *2		Auto Tuning Measured Value *3	
Parameter Number	Function Name	Setting Range	Setting Increments	Setting Range	Setting Increments	Setting Range	Setting Increments
82	Motor excitation current	0 to 500A, 9999	0.01A	0 to 500A, 9999	0.01A	0 to ****, 9999	1
90	Motor constant (R1)	0 to 50Ω, 9999	0.001Ω	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
91	Motor constant (R2)	0 to 50Ω, 9999	0.001Ω	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
92	Motor constant (L1)	0 to 1000mH, 9999	0.1mH	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
93	Motor constant (L2)	0 to 1000mH, 9999	0.1mH	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
94	Motor constant (X)	0 to 100%, 9999	0.1%	0 to 500Ω, 9999	0.01Ω	0 to ****, 9999	1
859	Torque current	0 to 500A, 9999	0.01A	0 to 500A, 9999	0.01A	0 to ****, 9999	1

- *1 When Pr. 71 = "0, 1, 40 or 50", or setting value of Pr. 96 read after performing offline auto tuning is not "3, 13, 23".
- *2 When Pr. 71 = "5, 6, 15, or 16"
- *3 When Pr. 71 = "3, 13, 23, 43 or 53" and setting value of Pr. 96 read after performing offline auto tuning is "3, 13, 23". Or when Pr. 71 = "4, 14, 24, 44 or 54".



POINT

- This function is valid only when a value other than "9999" is set in *Pr.* 80 and *Pr.* 81 and Advanced magnetic flux vector control or General-purpose magnetic flux vector control is selected.
- You can copy the offline auto tuning data (motor constants) to another inverter with the PU (FR-PU07).
- Even when motors (other manufacturer's motor, SF-JRC, etc.) other than Mitsubishi standard motor (SF-JR 0.2kW or more), high efficiency motor (SF-HR 0.2kW or more), and Mitsubishi constant-torque motor (SF-JRCA four-pole, SF-HRCA 0.2kW to 15kW) are used or the wiring length is long (30m or more as a reference), using the offline auto tuning function runs the motor with the optimum operating characteristics.
- Tuning is enabled even when a load is connected to the motor.
 As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if the motor runs slightly.
- · Reading/writing/copy of motor constants tuned by offline auto tuning are enabled.
- The offline auto tuning status can be monitored with the operation panel and PU (FR-PU04/FR-PU07).
- Do not connect a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) between the inverter and motor.

(1) Before performing offline auto tuning

Check the following before performing offline auto tuning.

- Make sure Advanced magnetic flux vector control or General-purpose magnetic flux vector control (*Pr.* 80, *Pr.* 81) is selected. (Tuning can be performed even under V/F control selected by turning ON X18.)
- A motor should be connected. Note that the motor should be at a stop at a tuning start.
- The motor capacity should be equal to or one rank lower than the inverter capacity.
- A high-slip motor, high-speed motor and special motor cannot be tuned. (The maximum frequency is 120Hz.)
- As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if the motor runs slightly.
- Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

(2) Setting

- 1) Select Advanced magnetic flux vector control (*Refer to page 82*) or General-purpose magnetic flux vector control (*Refer to page 85*).
- 2) Set "1" or "11" in Pr. 96 Auto tuning setting/status.
 - When the setting is "1" Tune all motor constants without running the motor.

When performing Advanced magnetic flux vector control, set "1" to perform tuning.

It takes approximately 25 to 75s* until tuning is completed.

(Excitation noise is produced during tuning.)

*Tuning time differs according to the inverter capacity and motor type.

• When the setting is "11"...... Tune motor constants (R1) only without running the motor.

When performing General-purpose magnetic flux vector control, set "11" to perform tuning.

It takes approximately 9s until tuning is completed.

- 3) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 112)
- 4) Set the rated voltage of motor (initial value is 200V/400V) in *Pr. 83 Rated motor voltage* and rated motor frequency (initial value is 50Hz) in *Pr. 84 Rated motor frequency*.

(For a Japanese standard motor, etc. which has both 50Hz and 60Hz rated values, use it with an initial value(400V/60Hz).

5) Set Pr. 71 Applied motor according to the motor used.

Motor	Pr. 71 Setting *1	
	SF-JR	3
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
	SF-JRCA 4P	13
Mitsubishi constant-torque motor	SF-HRCA	53
	Others (SF-JRC, etc.)	13
Other manufacturer's standard motor		3
Other manufacturer's constant-torque motor	_	13

^{*1} Refer to page 114, for other settings of Pr. 71.

(3) Execution of tuning



POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below) When the start command is turned ON under V/F control, the motor starts.

1) When performing tuning or PU operation, press (RUN) of the operation panel or FWD or REV of the parameter unit (FR-PU04/FR-PU07).

For external operation, turn ON the run command (STF signal or STR signal). Tuning starts.



- To force tuning to end, use the MRS or RES signal or press $\frac{\text{STOP}}{\text{RESET}}$ of the operation panel. (Turning the start signal (STF signal or STR signal) OFF also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
 - Input terminal <valid signal> MRS, RES, STF, STR
 - Output terminal RUN, AM, A, B, C

Note that the progress status of offline auto tuning is output in eight steps from AM when speed and output frequency are selected.

- Since the RUN signal turns ON when tuning is started, caution is required especially when a sequence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching on the main circuit power (R/L1, S/L2, T/ L3) of the inverter.
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not executed properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04/FR-PU07) Display		Operation Panel Indication	
Pr. 96 setting	1	11	1	11
(1) Setting	READ:List 1 STOP PU	READ:List 11 STOP PU	# MON — EXT	; ; SEX
(2)Tuning in progress	TUNE 2	TUNE 12		15 EXT
(3)Normal end	TUNE 3 COMPLETION STF STOP PU	TUNE 13 COMPETION STF STOP PU	Flickering	Flickering
(4)Error end (when inverter protective function operation is activated)	TUNE ERROR	9 OP PU	3 RUN MON EXT	



• REMARKS

Reference: Offline auto tuning time (when the initial value is set)

Offline Auto Tuning Setting	Time
Tune all motor constants (Pr. 96 = "1")	Approximately 25 to 75s
	(Tuning time differs according to the inverter capacity and motor type.)
Tune motor constants (R1) only ($Pr. 96 = "11"$)	Approximately 9s

• The set frequency monitor displayed during the offline auto tuning is 0Hz.



3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For external operation, turn OFF the start signal (STF signal or STR signal) once.

This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)



• REMARKS

- Do not change the Pr. 96 setting after completion of tuning (3 or 13). If the Pr. 96 setting is changed, tuning data is invalid. If the Pr. 96 setting is changed, tuning must be performed again.
- 4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error	Error Cause	Remedy	
Display	Error Gause	Kemedy	
8	Forced end	Set "1" or "11" in Pr. 96 and perform tuning again.	
9	Inverter protective function operation	Make setting again.	
91	Current limit (stall prevention) function was activated.	Set "1" in Pr. 156.	
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.	
93	Calculation error	Check the motor wiring and make setting again.	
93	A motor is not connected.	Set the rated current of the motor in Pr. 9.	

- 5) When tuning is ended forcibly by pressing (STOP) or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end properly. (The motor constants have not been set.) Perform an inverter reset and restart tuning.
- 6) When using the motor corresponding to the following specifications and conditions, reset Pr.9 Electronic thermal O/L relay as below after tuning is completed.
 - a) When the rated power specifications of the motor is 200/220V(400/440V) 60Hz, set 1.1 times rated motor current value in Pr.9.
 - b) When performing motor protection from overheat using a PTC thermistor or motor with temperature detector such as Klixon, set "0" (motor overheat protection by the inverter is invalid) in Pr.9.



- · The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is

♠ CAUTION

As the motor may run slightly during offline auto tuning, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs. Note that if the motor runs slightly, tuning performance is unaffected.



(4) Utilizing or changing offline auto tuning data for use

The data measured in the offline auto tuning can be read and utilized or changed.

<Operating procedure>

1) Set Pr. 71 according to the motor used.

Motor		Pr. 71 Setting *1
	SF-JR	4
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	24
Mitsubishi high efficiency motor	SF-HR	44
	Others	4
	SF-JRCA 4P	14
Mitsubishi constant-torque motor	SF-HRCA	54
	Others (SF-JRC, etc.)	14
Other manufacturer's		4
standard motor	-	4
Other manufacturer's		14
constant-torque motor	-	14

^{*1} For other settings of Pr.71, refer to page 114.

2) In the parameter setting mode, read the following parameters and set desired values.

Parameter	Name	Setting Range	Setting	Initial
Number	Name	Setting Range	Increments	Value
82	Motor excitation current	0 to ****, 9999	1	9999
90	Motor constant (R1)	0 to ****, 9999	1	9999
91	Motor constant (R2)	0 to ****, 9999	1	9999
92	Motor constant (L1)	0 to ****, 9999	1	9999
93	Motor constant (L2)	0 to ****, 9999	1	9999
94	Motor constant (X)	0 to ****, 9999	1	9999
859	Torque current	0 to ****, 9999	1	9999

• REMARKS

- When "9999" is set in Pr. 82, Pr. 90 to Pr. 94, Pr. 859, Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants are used.
- · As the motor constants measured in the offline auto tuning have been converted into internal data (****), refer to the following setting example when making setting:

Setting example To slightly increase Pr. 90 value (5%)

When Pr. 90 is displayed as "2516",

set 2642, i.e. 2516 x 1.05=2641.8, in Pr. 90.

(The value displayed has been converted into a value for internal use. Hence, simple addition of a given value to the displayed value has no significance.)

7/

(5) Method to set the motor constants without using the offline auto tuning data

The Pr. 90 to Pr. 94 motor constants may either be entered in $[\Omega]$ or in [mH]. Before starting operation, confirm which motor constant unit is used.

• To enter the Pr. 90 to Pr. 94 motor constants in $[\Omega]$

<Operating procedure>

1)Set Pr. 71 according to the motor used.

		Star Connection Motor	Delta Connection Motor
Setting	Standard motor	5	6
	Constant-torque motor	15	16

2)In the parameter setting mode, read the following parameters and set desired values.

Ig =torque current, I100 =rated current, I0 =no load current

$$Iq = \sqrt{1100^2 - 10^2}$$

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
82	Motor excitation current (no load current)	0 to 500A, 9999	0.01A	9999
90	Motor constant (r1)	0 to 50Ω, 9999	0.001Ω	9999
91	Motor constant (r2)	0 to 50Ω, 9999	0.001Ω	9999
92	Motor constant (x1)	0 to 50Ω, 9999	0.001Ω	9999
93	Motor constant (x2)	0 to 50Ω, 9999	0.001Ω	9999
94	Motor constant (xm)	0 to 500Ω, 9999	0.01Ω	9999
859	Torque current	0 to 500A, 9999	0.01A	9999

3)Refer to the following table and set Pr. 83 and Pr. 84.

Parameter Number	Name	Setting Range	Setting Increments	Initial Value	
83	Rated motor voltage	0 to 1000V	0.1V	400V class	400V
84	Rated motor frequency	10 to 120Hz	0.01Hz	50	Hz



> REMARKS

• When "9999" is set in Pr. 82, Pr. 90 to Pr. 94, Pr. 859, Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants are used.



NOTE

 If "star connection" is mistaken for "delta connection" or vice versa during setting of Pr. 71, Advanced magnetic flux vector control and General-purpose magnetic flux vector control cannot be exercised properly.



●To enter the Pr. 90 to Pr. 94 motor constants in [mH]

<Operating procedure>


1) Set Pr. 71 according to the motor used.

Motor	Pr.71 Setting *1	
Mitsubishi standard motor	SF-JR	0
Mitsubishi high efficiency motor	SF-HR	40
Mitsubishi constant-torque motor	SF-JRCA 4P	1
Witsubishi constant-torque motor	SF-HRCA	50

^{*1} For other settings of Pr. 71, refer to page 114.

2) In the parameter setting mode, read the following parameters and set desired values. Calculate the Pr. 94 value from the following formula.

$$Pr. 94 \text{ setting} = (1 - \frac{M^2}{L1 \times L2}) \times 100 \text{ (\%)}$$



R1: Primary resistance

R2: Secondary resistance

I1: Primary leakage inductance

I2: Secondary leakage inductanceM: Excitation inductance

S: Slip

L1 = I1 + M: Primary inductance L2 = I2 + M: Secondary inductance

Motor equivalent circuit diagram

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
82	Motor excitation current (no load current)	0 to 500A, 9999	0.01A	9999
90	Motor constant (R1)	0 to 50Ω, 9999	0.001Ω	9999
91	Motor constant (R2)	0 to 50Ω, 9999	0.001Ω	9999
92	Motor constant (L1)	0 to 1000mH, 9999	0.1mH	9999
93	Motor constant (L2)	0 to 1000mH, 9999	0.1mH	9999
94	Motor constant (X)	0 to 100%, 9999	0.1%	9999
859	Torque current	0 to 500A, 9999	0.01A	9999

3) Refer to the following table and set Pr. 83 and Pr. 84.

Parameter Number	Name	Setting Range	Setting Increments	Initial Value	
83	Rated motor voltage	0 to 1000V	0.1V	400V class	400V
84	Rated Motor Frequency	10 to 120Hz	0.01Hz	50	Hz

> REMARKS

• When "9999" is set in Pr. 82, Pr. 90 to Pr. 94, Pr. 859, Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants are used.

Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 105

Pr. 9 Electronic thermal O/L relay Refer to page 112

Pr. 71 Applied motor Refer to page 114

Pr. 80 Motor capacity, Pr. 81 Number of motor poles Refer to page 80

Pr. 156 Stall prevention operation selection Refer to page 88

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

Pr. 800 Control method selection Refer to page 80

4.10 Motor brake and stop operation


Purpose	Parameter th	Refer to Page	
Motor braking torque adjustment	DC Injection brake	Pr. 10 to Pr. 12	124
Improve the motor braking torque with	Selection of a	Dr. 20. Dr. 70	126
an option	regenerative brake	Pr. 30, Pr. 70	120
Coast the motor to a stop	Selection of motor	Pr. 250	128
Coast the motor to a stop	stopping method	F1. 230	120
Used to stop the motor with a		Dr. 6 Dr. 49 Dr. 270 Dr. 275	
mechanical brake	Stop-on-contact control	Pr. 6, Pr. 48, Pr. 270, Pr. 275,	129
(vibration restraint at stop-on-contact)		Pr. 276	
Used to stop the motor with a			
mechanical brake (operation timing of a	Brake sequence function	Pr. 278 to Pr. 283, Pr. 292	131
mechanical brake)			

4.10.1 DC injection brake (Pr. 10 to Pr. 12)

The DC injection brake can be operated at a motor stop to adjust the stop timing and braking torque. In DC injection brake operation, DC voltage is directly applied to the motor to prevent the motor shaft from rotating. The motor will not return to the original position if the motor shaft rotates due to external force.

Parameter Number	Name	Initial Value		Setting Range	Description
10	DC injection brake operation frequency	3Hz		0 to 120Hz	Operation frequency of the DC injection brake.
	DC injection brake			0	DC injection brake disabled
11	operation time	0.5s		0.1 to 10s	Operation time of the DC injection brake.
		FR-E720S-008(SC) and 015(SC)	6%		
12	DC injection brake	FR-E740-016(SC) to 170(SC)	4%	0 to	DC injection brake voltage (torque). When
12	operation voltage	FR-E720S-030(SC) to 110(SC)		30%	"0" is set, DC injection brake is disabled.
		FR-E740-230(SC) and 300(SC)	2%		

The above parameters can be set when Pr. 160 User group read selection ="0". (Refer to page 184)



(1) Operation frequency setting (Pr. 10)

• When the frequency at which the DC injection brake will be operated is set to *Pr. 10*, the DC voltage is applied to the motor upon reaching to the set frequency during deceleration.

(2) Operation time setting (Pr. 11)

- •In Pr. 11, set the time of the DC injection brake.
- •When the motor does not stop due to large load moment (J), increasing the setting produces an effect.
- •When *Pr. 11* = "0s", the DC injection brake is disabled. (At a stop, the motor coasts.)

(3) Operation voltage (torque) setting (Pr. 12)

- Use Pr. 12 to set the percentage to the power supply voltage.
- When Pr. 12 = "0%", the DC injection brake is disabled. (At a stop, the motor coasts.)
- When using the constant-torque motor (SF-JRCA) and energy saving motor (SF-HR, SF-HRCA), change the Pr. 12 setting as follows:

Motor	Pr.12 DC injection brake operation voltage Setting						
	FR-E740-095(SC) or less,	4%					
SF-JRCA	FR-E720S-110(SC) or less	4%					
	FR-E740-120(SC) or more	2%					
	FR-E740-095(SC) or less,	4%					
SF-HR, SF-HRCA	FR-E720S-110(SC) or less	470					
SF-FIR, SF-FIRCA	FR-E740-120(SC) and 170(SC)	3%					
	FR-E740-230(SC) and 300(SC)	2%					





REMARKS

- For the FR-E740-120(SC) and 170(SC), when the *Pr. 12* setting is the following, changing the *Pr. 71 Applied motor* setting automatically changes the *Pr. 12* setting. Therefore, it is not necessary to change the *Pr. 12* setting.
 - (a) When 4% (initial value) is set in Pr. 12
 - The *Pr. 12* setting is automatically changed to 2% if the *Pr. 71* value is changed from the value selecting the standard motor (0, 3 to 6, 23, 24, 40, 43, 44) to the value selecting the constant-torque motor (1, 13 to 16, 50, 53, 54).
 - (b) When 2% is set in Pr. 12
 - The *Pr. 12* setting is automatically changed to 4% (initial value) if the *Pr. 71* value is changed from the value selecting the constant-torque motor (1, 13 to 16, 50, 53, 54) to the value selecting the standard motor (0, 3 to 6, 23, 24, 40, 43, 44).
- Even if the Pr. 12 setting is increased, braking torque is limited so that the output current is within the rated inverter current.



⚠ As stop holding torque is not produced, install a mechanical brake.



Parameters referred to

Pr. 13 Starting frequency Refer to page 108
Pr. 71 Applied motor Refer to page 114

4.10.2 Selection of a regenerative brake (Pr. 30, Pr. 70)

- When making frequent starts/stops, use the optional brake resistor (MRS type),high-duty brake resistor (FR-ABR)
 and brake unit (FR-BU2) to increase the regenerative brake duty.
- Use a power regeneration common converter (FR-CV) for continuous operation in regeneration status.
 Use the high power factor converter (FR-HC) to reduce harmonics, improve the power factor, or continuously use the regenerative status.

Parameter	Name	Initial	Setting	Description	
Number	Name	Value	Range	Description	
				Inverter without regenerative function	
			0	Brake resistor (MRS type)Brake unit (FR-BU2)	
	Regenerative function		U	Power regeneration common converter (FR-CV)	
30	selection	0		High power factor converter (FR-HC)	
			1	High-duty brake resistor (FR-ABR)	
			2	High power factor converter (FR-HC) when automatic	
			2	restart after instantaneous power failure is selected	
	Special regenerative			Brake duty (6%) when using the brake resistor (MYS type),	
70	brake duty	0%	0 to 30%	Brake duty when using the high-duty brake resistor	
				(FR-ABR)(10%)	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) When using the brake resistor (MRS type),brake unit (FR-BU2), power regeneration common converter (FR-CV), and high power factor converter (FR-HC).

•Set Pr. 30 to "0" (initial value). The Pr. 70 setting is made invalid.

At this time, the regenerative brake duty is as follows.

Туре	Regenerative Brake Duty
FR-E720S-030(SC) or more	3%
FR-E740-016(SC) or more	2%

[•]Assign the inverter operation enable signal (X10) to the contact input terminal. To make protective coordination with the FR-HC and FR-CV, use the inverter operation enable signal to shut off the inverter output.

Input the RDY signal of the FR-HC (RDYB signal of the FR-CV).

(2) When using the high-duty brake resistor (FR-ABR) (FR-E740-016(SC) or more, FR-E720S-030(SC) or more)

- •Set "1" in Pr. 30.
- •Set Pr. 70 as follows.

(3) When a high power factor converter (FR-HC) is used and automatic restart after instantaneous power failure function is made valid.


- •When automatic restart after instantaneous power failure function of both the FR-HC and inverter is valid (when a value other than "9999" is set in *Pr. 57 Restart coasting time*), set "2" in *Pr. 30*.
- •Set Pr. 70 to "0%" (initial value).
- •When the FR-HC detects power failure during inverter operation, the RDY signal turns ON, resulting in the motor coasting. Turning the RDY signal OFF after power restoration, the inverter detects the motor speed (depends on the *Pr.162 Automatic restart after instantaneous power failure selection*) and restarts automatically after instantaneous power failure.

[•]For the terminal used for X10 signal input, assign its function by setting "10" (X10) to any of Pr. 178 to Pr. 184.



(4) Regenerative brake duty alarm output and alarm signal (RBP signal)

100%: regenerative overvoltage protection operation value



- •[RB] appears on the operation panel and an alarm signal (RBP) is output when 85% of the regenerative brake duty set in Pr. 70 is reached. If the regenerative brake duty reaches 100% of the Pr. 70 setting, a regenerative overvoltage (E.OV1 to E.OV3) occurs. Note that [RB] is not displayed when Pr. 30 = "0".
- •The inverter does not trip even when the alarm (RBP) signal is output.
- •For the terminal used for the RBP signal output, assign the function by setting "7 (positive logic) or 107 (negative logic)" in any of Pr. 190 to Pr. 192 (output terminal function selection).



(I) REMARKS

- The MRS signal can also be used instead of the X10 signal. (Refer to page 137)
- Refer to page 34 to 38 for connecting the brake resistor (MRS type), high-duty brake resistor (FR-ABR), brake unit (FR-BU2), high power factor converter (FR-HC), and power regeneration common converter (FR-CV).



NOTE

When terminal assignment is changed using Pr. 178 to Pr. 184 (input terminal function selection) and Pr. 190 to Pr. 192 (output terminal function selection), the other functions may be affected. Set parameters after confirming the function of each terminal. (Refer to page 135)





The value set in Pr. 70 must not exceed the setting of the brake resistor used. Otherwise, the resistor can overheat.



Parameters referred to


Pr. 57 Restart coasting time Refer to page 158 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141


4.10.3 Stop selection (Pr. 250)

Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns OFF. Used to stop the motor with a mechanical brake, etc. together with switching OFF of the start signal. You can also select the operations of the start signals (STF/STR). (Refer to page 139 for start signal selection)

Parameter		Initial		Description			
Number	Name		Setting Range	Start signal (STF/STR)	Stop operation		
Number		Value		(Refer to page 139)	Stop operation		
				STF signal: Forward rotation start	The motor is coasted to a stop		
		op selection 9999	0 to 100s	STR signal: Reverse rotation start	when the preset time elapses after		
				311 Signal. Neverse location start	the start signal is turned OFF.		
	Stop selection		1000s to 1100s	STF signal: Start signal	The motor is coasted to a stop (Pr.		
250				STR signal: Forward/reverse signal	250 - 1000)s after the start signal is		
230					turned OFF.		
			9999	STF signal: Forward rotation start			
				STR signal: Reverse rotation start	When the start signal is turned		
			8888	STF signal: Start signal	OFF, the motor decelerates to stop.		
			0000	STR signal: Forward/reverse signal			

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)





(1) Decelerate the motor to a stop

- •Set Pr. 250 to "9999" (initial value) or "8888".
- •The motor decelerates to a stop when the start signal (STF/STR) turns OFF.

(2) Coast the motor to a stop

- •Use Pr. 250 to set the time from when the start signal turns OFF until the output is shut off. When any of "1000 to 1100" is set, the output is shut off in (Pr. 250 - 1000)s.
- •The output is shut off when the time set in Pr. 250 has elapsed after the start signal had turned OFF. The motor coasts to a stop.
- •The RUN signal turns OFF when the output stops.

(I) REMARKS

- Stop selection is invalid when the following functions are activated.
 - Power failure stop function (Pr. 261)
 - PU stop (Pr. 75)
 - Deceleration stop because of communication error (Pr. 502)
 - Emergency stop by LonWorks communication
- When setting of Pr. 250 is not 9999 nor 8888, acceleration/deceleration is performed according to the frequency command, until start signal is OFF and output is shutoff.



NOTE

When the start signal is turned ON again during motor coasting, the motor starts at Pr. 13 Starting frequency.



Parameters referred to


Pr .7 Acceleration time, Pr. 8 Deceleration time Refer to page 105 Pr. 13 Starting frequency Refer to page 108



4.10.4 Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276)

AD MFVC GP MFVC


To ensure accurate positioning at the upper limit etc. of a lift, stop-on-contact control causes a mechanical brake to be closed while the motor is developing a holding torque to keep the load in contact with a mechanical stopper etc. This function suppresses vibration which is liable to occur when the load is stopped upon contact in vertical motion applications, ensuring steady precise positioning.



Parameter	Name	Initial	Setting	Description
Number	Name	Value	Range	Description
6	Multi-speed setting (low speed)	10Hz	0 to 400Hz	Sets the output frequency for stop-on-contact control.
48 *1	Second stall prevention operation current	9999	0 to 200%	Sets the stall prevention operation level for stall prevention operation level.
	operation current		9999	Pr. 22 setting
270 *1	Stop-on contact control	0	0	Normal operation
270 *1	selection	U	1	Stop-on-contact control
275 *1, *2	Stop-on contact excitation current low-speed multiplying	9999	0 to 300%	Set the force (holding torque) for stop-on-contact control. Normally set 130% to 180%.
	factor		9999	Without compensation
276 *1	PWM carrier frequency at stop-	9999	0 to 9	Sets a PWM carrier frequency for stop-on-contact control.
270 *1	on contact	5599	9999	As set in Pr. 72 PWM frequency selection.

- *1 This parameter can be set when Pr. 160 User group read selection = "0". (Refer to page 184)
- *2 This parameter allows its setting to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.

(1) Connection and operation example



- The input signal terminal used differs according to the Pr. 180 to Pr. 184 settings.
- \ast Goes into stop-on-contact control when both RL and RT switch ON. RL and RT may be switched on in any order with any time difference.
 - (a) Acceleration time (Pr. 7) (b) Deceleration time (Pr. 8)
 - (c) Second deceleration time (Pr. 44/Pr. 45)

(2) Set stop-on-contact control

- Make sure that the inverter is in External operation mode. (Refer to page 190)
- Select Advanced magnetic flux vector control or General-purpose magnetic flux vector control.
- Set "1" in *Pr. 270 Stop-on contact control selection*.
- Set output frequency during stop-on-contact control in *Pr.* 6 *Multi-speed setting (low speed)*.

 The frequency should be as low as possible (about 2Hz). If it is set to more than 30Hz, the operating frequency will be 30Hz.
- When both the RT and RL signals are switched ON, the inverter starts the stop-on-contact control, in which operation is performed at the frequency set in *Pr.* 6 independently of the preceding speed.
- For the terminal used for X18 signal input, set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* and "0" in *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.



NOTE

- By increasing the Pr. 275 setting, the low-speed (stop-on-contact) torque increases, but overcurrent fault (E.OCT) may
 occur or the machine may oscillate in a stop-on-contact state.
- The stop-on-contact function is different from servo-lock function, and if used to stop or hold a load for an extended period, this function can cause the motor to overheat.
 - After a stop, immediately change to a mechanical brake to hold the load.
- Under the following operating conditions, the stop-on-contact function is invalid: PU operation (*Pr. 79*), Jog operation (JOG signal), PU+External operation (*Pr. 79*), PID control function operation (*Pr. 128*), remote setting function operation (*Pr. 59*), automatic acceleration/deceleration operation (*Pr. 292*)

(3) Function switching of stop-on-contact control selection

Main Functions	Normal Operation	With stop-on-contact Control
Main Functions	(either RL or RT is OFF or both are OFF)	(both RL and RT are ON)
	Multi-speed	
Output frequency	0 to 5V, 0 to 10V	Pr. 6 setting
	4 to 20mA etc.	
Stall prevention operation	D.: 22 potting	Pr. 48 setting
level	Pr. 22 setting	(Pr. 22 when Pr. 48 = "9999")
Excitation current low		Only Pr. 275 (0 to 300%) is compensated
speed scaling factor	_	from normal operation
Carrier frequency	Pr. 72 setting	Pr. 276 setting when output frequency is 3Hz
ourner inequency	17. 72 Setting	or less (Pr. 72 when Pr. 276 = "9999")
Fast-response current	Valid	Invalid
limit	Valid	mirana .

(4) Set frequency when stop-on-contact control (Pr. 270 = 1) is selected

- The following table lists the frequencies set when the input terminals (RH, RM, RL, RT, JOG) are selected together. Bold frame indicates stop-on-contact control is valid.
- Stop-on-contact control is invalid when remote setting function is selected (*Pr. 59* = 1 to 3).

ln	put Si	gnal (O = 0	N)	Sat Fraguency
RH	RM	RL	RT	JOG	Set Frequency
0					Pr. 4 Multi-speed setting (high speed)
	0				Pr. 5 Multi-speed setting (middle speed)
		0			Pr. 6 Multi-speed setting (low speed)
			0		By 0 to 5V(0 to 10V), 4 to 20mA
					input
				0	Pr. 15 Jog frequency
0	0				Pr. 26 Multi-speed setting (speed 6)
0		0			Pr. 25Multi-speed setting (speed 5)
0			0		Pr. 4 Multi-speed setting (high speed)
0				0	Pr. 15 Jog frequency
	0	0			Pr. 24 Multi-speed setting (speed 4)
	0		0		Pr. 5 Multi-speed setting (middle speed)
	0			0	Pr. 15 Jog frequency
		0	0		Pr. 6 Multi-speed setting (low speed)
		0		0	Pr. 15 Jog frequency
			0	0	Pr. 15 Jog frequency
		0	0	0	Pr. 15 Jog frequency

In	put Si	gnal (O = 0	N)	Sat Fraguency
RH	RM	RL	RT	JOG	Set Frequency
	0		0	0	Pr. 15 Jog frequency
	0	0		0	Pr. 15 Jog frequency
	0	0	0		Pr. 6 Multi-speed setting (low speed)
0			0	0	Pr. 15 Jog frequency
0		0		0	Pr. 15 Jog frequency
0		0	0		Pr. 6 Multi-speed setting (low speed)
0	0			0	Pr. 15 Jog frequency
0	0		0		Pr. 26 Multi-speed setting (speed 6)
0	0	0			Pr. 27 Multi-speed setting (speed 7)
	0	0	0	0	Pr. 15 Jog frequency
0		0	0	0	Pr. 15 Jog frequency
0	0		0	0	Pr. 15 Jog frequency
0	0	0		0	Pr. 15 Jog frequency
0	0	0	0		Pr. 6 Multi-speed setting (low speed)
0	0	0	0	0	Pr. 15 Jog frequency
					By 0 to 5V(0 to 10V), 4 to 20mA input



NOTE

• Changing the terminal function using any of *Pr. 178 to Pr. 184* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 (multi-speed setting) Refer to page 98

Pr. 15 Jog frequency Refer to page 100

Pr. 48 Second stall prevention operation current Refer to page 88

Pr. 59 Remote function selection Refer to page 102

Pr. 72PWM frequency selection Refer to page 170

Pr. 79 Operation mode selection Refer to page 190

Pr. 128 PID action selection Refer to page 242

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

Pr. 292 Automatic acceleration/deceleration Refer to page 110



4.10.5 Brake sequence function (Pr. 278 to Pr. 283, Pr. 292) ADMEVIC GP. MEVIC


This function is used to output from the inverter the mechanical brake operation timing signal in vertical lift and other applications.

This function prevents the load from dropping with gravity at a start due to the operation timing error of the mechanical brake or an overcurrent alarm from occurring at a stop, ensuring secure operation.

Parameter	Name	Initial	Setting	Description.
Number	Name	Value	Range	Description
278	Brake opening frequency	3Hz	0 to 30Hz	Set to the rated slip frequency of the motor + about 1.0Hz. This parameter may be set only if $Pr. 278 \le Pr. 282$.
279	Brake opening current	130%	0 to 200%	Generally, set this parameter to about 50 to 90%. If the setting is too low, the load is liable to drop due to gravity at start. Suppose that the rated inverter current is 100%.
280	Brake opening current detection time	0.3s	0 to 2s	Generally, set this parameter to about 0.1 to 0.3s.
281	Brake operation time at start	0.3s	0 to 5s	When <i>Pr. 292</i> = "7", set the mechanical delay time until the brake is loosened. Set the mechanical delay time until the brake is loosened + about 0.1 to 0.2s when <i>Pr. 292</i> = "8".
282	Brake operation frequency	6Hz	0 to 30Hz	Set the frequency to activate the mechanical brake by turning OFF the brake opening request signal (BOF). Generally, set this parameter to the $Pr.\ 278$ setting + 3 to 4Hz. This parameter may be set only if $Pr.\ 278 \le Pr.\ 282$.
283	Brake operation time at stop	0.3s	0 to 5s	Set the mechanical delay time until the brake is closed + 0.1s when $Pr.\ 292 = 7$. Sets the mechanical delay time until the brake is closed + 0.2 to 0.3s when $Pr.\ 292 = 8$.
292	Automatic acceleration/ deceleration	0	0 1, 11 7	Normal operation mode Shortest acceleration/deceleration mode (Refer to page 110) Brake sequence mode 1
			8	Brake sequence mode 2

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

<Connection diagram>



- 1 The input signal terminal used differs according to the Pr. 178 to Pr. 184 settings.
- *2 The output signal terminal used differs according to the Pr. 190 to Pr. 192 settings.
- *3 The current should be within the permissible current of transistor in the inverter. (24V 0.1ADC)

· N

NOTE

- When brake sequence function is selected, automatic restart after instantaneous power failure is invalid.
- When using this function, set the acceleration time to 1s or longer.
 - Changing the terminal function using any of *Pr. 178 to Pr. 184* and *Pr. 190 to Pr. 192* may affect the other functions. Set parameters after confirming the function of each terminal.


(1) Set the brake sequence mode

- Select Advanced magnetic flux vector control or General-purpose magnetic flux vector control.
 The brake sequence function is valid only when the External operation mode, External/PU combined operation mode 1 or Network operation mode is selected.
- Set "7 or 8" (brake sequence mode) in *Pr. 292*.

 To ensure more complete sequence control, it is recommended to set "7" (brake opening completion signal input) in *Pr. 292*.
- Set "15" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* and assign the brake opening completion signal (BRI) to the input terminal.
- Set "20 (positive logic)" or "120 (negative logic)" in any of *Pr. 190 to Pr. 192 (output terminal function selection)* and assign the brake opening request signal (BOF) to the output terminal.

(2) With brake opening completion signal input (Pr. 292 = "7")


- When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr. 278* and the output current is not less than the value set in *Pr. 279*, the inverter outputs the brake opening request signal (BOF) after the time set in *Pr. 280* has elapsed.
 - When the time set in *Pr. 281* elapses after the brake opening completion signal (BRI) was activated, the inverter increases the output frequency to the set speed.
- When the inverter decelerates to the frequency set in Pr.282 during deceleration, the inverter turns OFF the BOF signal and decelerates further to the frequency set in Pr.278. After electromagnetic brake operation completes and inverter recognizes the turn OFF of BRI signal, the inverter holds the frequency set in Pr.278 for the time set in Pr.283. And after the time set in Pr.283 passes, the inverter decelerates again. The inverter finally stops when its frequency reaches to Pr.13 Starting frequency setting or 0.5Hz, whichever is lower.





(3) Without brake opening completion signal input (Pr.292 = "8")

- When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr. 278* and the output current is not less than the value set in *Pr. 279*, the inverter outputs the brake opening request signal (BOF) after the time set in *Pr. 280* has elapsed.
 - When the time set in Pr. 281 elapses after the BOF signal is output, the inverter increases the output frequency to the set speed.
- When the inverter decelerates to the frequency set in *Pr.282* during deceleration, the inverter turns OFF the BOF signal and decelerates further to the frequency set in *Pr.278*. After the turn OFF of BOF signal, the inverter holds the frequency set in *Pr.278* for the time set in *Pr.283*. And after the time set in *Pr.283* passes, the inverter decelerates again. The inverter finally stops when its frequency reaches to *Pr.13 Starting frequency* setting or 0.5Hz, whichever is lower.



REMARKS

If brake sequence function has been selected, inputting the JOG signal (Jog operation) or RT signal (second function selection)
during an inverter stop will make brake sequence function invalid and give priority to Jog operation or second function selection.
 Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation with brake sequence function.

$\overline{\gamma}$

(4) Protective functions


If any of the following occurs during the brake sequence operation, the inverter results in a fault, trips, and turns OFF the brake opening request signal (BOF).

Fault Display	Description
E.MB4	Although more than 2s have elapsed after the start command (forward or reverse rotation) is input, the brake opening request signal (BOF) does not turn ON.
E.MB5	Although more than 2s have elapsed after the brake opening request signal (BOF) turned on, the brake opening completion signal (BRI) does not turn ON.
E.MB6	Although the inverter had turned ON the brake opening request signal (BOF), the brake opening completion signal (BRI) turned OFF midway.
E.MB7	Although more than 2s have elapsed after the brake opening request signal (BOF) turned OFF at a stop, the brake opening completion signal (BRI) does not turn OFF.



NOTE

- During deceleration, inverter output is shut OFF when the frequency reaches *Pr.13 Starting frequency* or 0.5Hz, whichever is lower. For *Pr.278 Brake opening frequency*, set *Pr.13* or a frequency equal to or higher than 0.5Hz.
- Setting Pr. 278 Brake opening frequency too high activates stall prevention operation and may cause E.MB4.
- If the sum of the time between Pr. 13 Starting frequency and Pr. 278 Brake opening frequency + Pr. 280 Brake opening current detection time is more than 2s, E.MB4 occurs.





Parameters referred to

Pr. 80 Motor capacity, Pr. 81 Number of motor poles 👺 Refer to page 80

Pr. 180 to Pr. 184 (input terminal function selection) Refer to page 135

Pr. 190 to Pr. 192 (output terminal function selection) The Refer to page 141

Pr. 800 Control method selection The Refer to page 80



4.11 Function assignment of external terminal and control

Purpose	Parameter the	at should be Set	Refer to Page
Assign function to input terminal	Input terminal function selection	Pr. 178 to Pr. 184	135
Set MRS signal (output shutoff) to NC contact specification	MRS input selection	Pr. 17	137
Assign start signal and forward/ reverse command to other signals	Start signal (STF/STR) operation selection	Pr. 250	139
Assign function to output terminal	Output terminal function assignment	Pr. 190 to Pr. 192	141
Detect output frequency	Up-to-frequency sensitivity Output frequency detection	Pr. 41 to Pr. 43	145
Detect output current	Output current detection Zero current detection	Pr. 150 to Pr. 153	146
Remote output function	Remote output	Pr. 495 to Pr. 497	148

4.11.1 Input terminal function selection (Pr. 178 to Pr. 184)

Use these parameters to select/change the input terminal functions.

Parameter Number	Name	Initial Value	Initial Signal	Setting Range
178	STF terminal function selection	60	STF (forward rotation command)	
179	STR terminal function 61		STR (reverse rotation command)	
180	RL terminal function selection	0	RL (low-speed operation command)	
181	RM terminal function selection	1	RM (middle speed operation command)	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 60*1, 61*2, 62, 65 to 67, 9999
182	RH terminal function selection	2	RH (high-speed operation command)	
183 *3	MRS terminal function selection	24	MRS (output stop)	
184	RES terminal function selection	62	RES (inverter reset)	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

- *1 The setting value of "60" is available for Pr. 178 only.
- *2 The setting value of "61" is available for Pr. 179 only.
- *3 For the safety stop function model, this setting is active only during the communication operation. (Refer to page 207)

(1) Input terminal function assignment

- •Using *Pr. 178 to Pr. 184*, set the functions of the input terminals.
- •Refer to the following table and set the parameters:

Setting	Signal	Function		Related Parameters	Refer to Page
0 5		Pr. 59 = 0 (initial value)	Low-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 Pr.232 to Pr.239	98
0	RL	Pr. 59 = 1, 2 *1	Remote setting (setting clear)	Pr. 59	102
		Pr. 270 = 1 *2	Stop-on contact selection 0	Pr. 270, Pr. 275, Pr. 276	129
1	RM	Pr. 59 = 0 (initial value)	Middle-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	98
		<i>Pr. 59</i> = 1, 2 *1	Remote setting (deceleration)	Pr. 59	102
2	RH	Pr. 59 = 0 (initial value)	High-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	98
		<i>Pr.</i> 59 = 1, 2 *1	Remote setting (acceleration)	Pr. 59	102

Setting	Signal	Function		Related Parameters	Refer to Page
	DT	Second function selection		Pr. 44 to Pr. 51	138
3	RT	<i>Pr. 270</i> = 1 *2 Stop-o	n contact selection 1	Pr. 270, Pr. 275, Pr. 276	129
4	AU	Terminal 4 input selection		Pr. 267	172
5	JOG	Jog operation selection		Pr. 15, Pr. 16	100
7	ОН	External thermal relay input *3		Pr. 9	112
8	REX	15-speed selection (combination RH)	with three speeds RL, RM,	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	98
10	X10	Inverter run enable signal (FR-H	C, FR-CV connection)	Pr. 30, Pr. 70	126
12	X12	PU operation external interlock		Pr. 79	190
14	X14	PID control valid terminal		Pr. 127 to Pr. 134	242
15	BRI	Brake opening completion signal		Pr. 278 to Pr. 283	131
16	X16	PU-External operation switchover (turning ON X16 selects External operation)		Pr. 79, Pr. 340	197
18	X18	V/F switchover (V/F control is performed when X18 is ON)		Pr. 80, Pr. 81, Pr. 800	80, 82, 85, 116
24	MRS	Output stop		Pr. 17	137
25	STOP	Start self-holding selection		_	139
60	STF	Forward rotation command (assigned)	gned to STF terminal (Pr. 178)	_	139
61	STR	Reverse rotation command (assigned)	gned to STR terminal (Pr. 179)	_	139
62	RES	Inverter reset		_	_
65	X65	PU/NET operation switchover (turning ON X65 selects PU operation)		Pr. 79, Pr. 340	198
66	X66	External/NET operation switchov NET operation)	er (turning ON X66 selects	Pr. 79, Pr. 340	198
67	X67	Command source switchover (turand Pr. 339 commands valid)	rning ON X67 makes Pr. 338	Pr. 338, Pr. 339	201

- *1 When Pr. 59 Remote function selection = "1" or "2", the functions of the RL, RM and RH signals are changed as given in the table.
- *2 When Pr. 270 Stop-on contact control selection = "1", functions of RL and RT signals are changed as in the table.
- *3 The OH signal turns ON when the relay contact "opens".

No function



9999

NOTE

- Changing the terminal assignment using *Pr.178 to Pr.184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.
- · Same function can be assigned to two or more terminals. In this case, the logic of terminal input is OR.
- The priorities of the speed commands are in order of JOG > multi-speed setting (RH, RM, RL, REX) > PID (X14).
- When the X10 signal (FR-HC, FR-CV connection-inverter operation enable signal) is not set or when the PU operation external interlock (X12) signal is not assigned with *Pr.79 Operation mode selection* set to "7", the MRS signal shares this function.
- Same signal is used to assign multi-speed (7 speeds) and remote setting. They cannot be set individually.
 (Same signal is used since multi-speed (7 speeds) setting and remote setting are not used to set speed at the same time.)
- Switch the control method using external terminal (X18 signal) during an inverter stop. If control method between V/F
 control and Advanced (General-purpose magnetic) flux vector control is switched during the operation, the actual
 switchover does not take place until the inverter stops. In addition, if control method is switched to V/F control during
 the operation, only second function becomes valid as V/F control and second function are selected simultaneously in
 V/F control.
- Turning the AU signal ON makes terminal 2 (voltage input) invalid.

(2) Response time of each signal

• The response time of the X10 signal and MRS signal is within 2ms. The response time of other signals is within 20ms.





4.11.2 Inverter output shutoff signal (MRS signal, Pr. 17)

The inverter output can be shut off by the MRS signal. Also, logic for the MRS signal can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Normally open input
		0	2	Normally closed input
17	MRS input selection		2	(NC contact input specifications)
17				External terminal: Normally closed input
			4	(NC contact input specifications)
				Communication: Normally open input

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)





(1) Output shutoff signal (MRS signal)

- Turning ON the output shutoff signal (MRS) during inverter running shuts off the output immediately.
- •MRS signal may be used as described below.
- (a) When mechanical brake (e.g. electromagnetic brake) is used to stop motor

The inverter output is shut off when the mechanical brake operates.

- (b) To provide interlock to disable operation by the inverter With the MRS signal ON, the inverter cannot be operated if the start signal is entered into the inverter.
- (c) Coast the motor to a stop.
 When the start signal is turned OFF, the inverter decelerates the motor to a stop in the preset deceleration time, but when the MRS signal is turned ON, the motor coasts to a stop.

(2) MRS signal logic inversion (Pr. 17)

• When *Pr. 17* is set to "2", the MRS signal (output stop) can be changed to the normally closed (NC contact) input specification. When the MRS signal turns ON (opens), the inverter shuts off the output.

(3) Assign a different action for each MRS signal input from communication and external terminal (Pr. 17 = "4")

•When *Pr. 17* is set to "4", the MRS signal from external terminal (output stop) can be changed to the normally closed (NC contact) input, and the MRS signal from communication can be changed to the normally open (NO contact) input. This function is useful to perform operation by communication with MRS signal from external terminal remained ON.

External MRS	Communication MRS Pr. 17 Setting				
External wito	Communication wito	0	2	4	
OFF	OFF	Operation enabled	Output shutoff	Output shutoff	
OFF	ON	Output shutoff	Output shutoff	Output shutoff	
ON	OFF	Output shutoff	Output shutoff	Operation enabled	
ON	ON	Output shutoff	Operation enabled	Output shutoff	



> REMARKS

- For MRS signal, assign the function by setting "24" to any of *Pr.178 to Pr.184 (Input terminal function selection)*. (For the standard control circuit terminal model, the function is assigned to terminal MRS in the initial setting.)
- · When using an external terminal to input the MRS signal, the MRS signal shuts off the output in any of the operation modes.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to


Pr. 178 to Pr. 184 (input terminal function selection) TF Refer to page 135


4.11.3 Condition selection of function validity by second function selection signal (RT)

- You can select the second function using the RT signal.
- When the RT signal turns ON, the second function becomes valid.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.
- The second function has the following applications.
- (a) Switching between normal use and emergency use
- (b) Switching between heavy load and light load
- (c) Changing of acceleration/deceleration time by broken line acceleration/deceleration
- (d) Switching of characteristic between the main motor and sub motor

Second function connection diagram

Second acceleration/deceleration time





• When the RT signal is ON, the following second function is selected at the same time.

Function	First Function	Second Function	Refer to
Function	Parameter Number	Parameter Number	Page
Torque boost	Pr. 0	Pr. 46	81
Base frequency	Pr. 3	Pr. 47	94
Acceleration time	Pr. 7	Pr. 44	105
Deceleration time	Pr. 8	Pr. 44, Pr. 45	105
Electronic thermal O/L relay	Pr. 9	Pr. 51	112
Stall prevention	Pr. 22	Pr. 48	88
Applied motor	Pr. 71	Pr. 450	114



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135



4.11.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250)


You can select the operation of the start signal (STF/STR). Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns OFF. Used to stop the motor with a mechanical brake, etc. together with switching OFF of the start signal. (*Refer to page 128* for stop selection)

Paramotor	Parameter Initial			Description		
Number	Name	Value	Setting Range	Start signal	Stop operation	
Number		value		(STF/STR)	Refer to page 128	
250	Stop 9999 selection	0 to 100s	STF signal: Forward rotation start STR signal: Reverse rotation start STF signal: Start signal STR signal: Forward/reverse signal	The motor is coasted to a stop when the preset time elapses after the start signal is turned OFF. When the setting is any of 1000s to 1100s, the inverter coasts to a stop in (<i>Pr. 250</i> - 1000)s.		
		9999		STF signal: Forward rotation start STR signal: Reverse rotation start STF signal: Start signal STR signal: Forward/reverse signal	When the start signal is turned OFF, the motor decelerates to stop.	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Two-wire type connection (STF, STR signal)

- •The two-wire connection is shown below.
- In the default setting, the forward/reverse rotation signals (STF/STR) are used as start and stop signals. Turn ON either of the forward and reverse rotation signals to start the motor in the corresponding direction. Switch both OFF (or both ON) of the start signals during operation to decelerate the inverter to a stop.
- •The speed setting signal may either be given by entering 0 to 10VDC across the speed setting input terminal 2-5, by setting the required values in *Pr. 4 to Pr. 6 Multi-speed setting (high, middle, low speeds)*, etc. (For multi-speed operation, refer to *page 98*.)
- •When *Pr. 250* is set to any of "1000 to 1100, 8888", the STF signal becomes a start command and the STR signal a forward/reverse command.




REMARKS

- When Pr. 250 is set to any of "0 to 100, 1000 to 1100", turning OFF the start command coasts the inverter to a stop. (Refer to page 128)
- The STF and STR signals are assigned to the STF and STR terminals in the default setting. The STF signal can be assigned to *Pr. 178 STF terminal function selection*, and the STR signal to *Pr. 179 STR terminal function selection* only.

(2) Three-wire type (STF, STR, STOP signal)

- •The three-wire connection is shown below.
- •Turning the STOP signal ON makes start self-holding function valid. In this case, the forward/reverse rotation signal functions only as a start signal.
- If the start signal (STF or STR) is turned ON and then OFF, the start signal is held and makes a start. When changing the direction of rotation, turn STR (STF) ON once and then OFF.
- •To stop the inverter, turning off the STOP signal once decelerates it to a stop.
- When using the STOP signal, set "25" in Pr. 178 to Pr. 184 to assign function.



• REMARKS

- When the JOG signal is turned ON to enable Jog operation, the STOP signal becomes invalid.
- If the MRS signal is turned ON to stop the output, the self-holding function is not canceled.

(3) Start signal selection

STF	STR	Pr. 250 Setting	Inverter Status
317	SIK	0 to 100s, 9999	1000s to 1100s 8888
OFF	OFF	Stop	Stop
OFF	ON	Reverse rotation	Зюр
ON	OFF	Forward rotation	Forward rotation
ON	ON	Stop	Reverse rotation



Parameters referred to

Pr. 4 to Pr. 6 (multi-speed setting) Refer to page 98
Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135



4.11.5 Output terminal function selection (Pr. 190 to Pr. 192)

You can change the functions of the open collector output terminal and relay output terminal.

Parameter Number	Nar	me	Initial Value	Initial Signal	Setting Range
190	RUN terminal function selection	Open collector	0	RUN (inverter running)	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 80*1, 81*1, 90, 91,
191	FU terminal function selection	output terminal	4	FU (output frequency detection)	193*1, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164,
192	A,B,C terminal function selection	Relay output terminal	99	ALM (fault output)	180*1, 181*1, 190, 191, 193*1, 195, 196, 198, 199, 9999

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Output signal list

- •You can set the functions of the output terminals.
- •Refer to the following table and set the parameters: (0 to 99: positive logic, 100 to 199: negative logic)

Setting				Related	Refer	
Positive logic	Negative logic	Signal	Function	Operation	Parameter	to Page
0	100	RUN	Inverter running	Output during operation when the inverter output frequency rises to or above <i>Pr. 13 Starting frequency</i> .	_	143
1	101	SU	Up to frequency *1	Output when the output frequency is reached to the set frequency.	Pr. 41	145
3	103	OL	Overload alarm	Output while stall prevention function is activated.	Pr. 22, Pr. 23, Pr. 66	88
4	104	FU	Output frequency detection	Output when the output frequency reaches the frequency set in <i>Pr. 42</i> (<i>Pr. 43</i> for reverse rotation).	Pr. 42, Pr. 43	145
7	107	RBP	Regenerative brake pre-alarm	Output when 85% of the regenerative brake duty set in Pr : 70 is reached.	Pr. 70	126
8	108	THP	Electronic thermal O/L relay pre-alarm	Output when the electronic thermal value reaches 85% of the trip level. (Electronic thermal relay function protection (E.THT/E.THM) activates, when the value reached 100%.)	Pr. 9, Pr. 51	112
11	111	RY	Inverter operation ready	Output when reset process is completed (when the inverter can be started by switching the start signal ON or while it is running) after powering on inverter.	_	143
12	112	Y12	Output current detection	Output when the output current is higher than the $Pr. 150$ setting for longer than the time set in $Pr. 151$.	Pr. 150, Pr. 151	146
13	113	Y13	Zero current detection	Output when the output power is lower than the $Pr. 152$ setting for longer than the time set in $Pr. 153$.	Pr. 152, Pr. 153	146
14	114	FDN	PID lower limit	Output when the feedback value falls below the lower limit of PID control.		
15	115	FUP	PID upper limit	Output when the feedback value rises above the upper limit of PID control	Pr. 127 to Pr. 134	242
16	116	RL	PID forward/reverse rotation output	Output when forward rotation is performed in PID control.		
20	120	BOF	Brake opening request	Output to open the brake when the brake sequence function is selected.	Pr. 278 to Pr. 283, Pr. 292	131
25	125	FAN	Fan fault output	Output at the time of a fan fault.	Pr. 244	259
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection providing temperature.	_	286
46	146	Y46	During deceleration at occurrence of power failure	Output when the power failure-time deceleration function is executed. (retained until release)	Pr. 261	164
47	147	PID	During PID control activated	Output during PID control.	Pr. 127 to Pr. 134	242
64	164	Y64	During retry	Output during retry processing.	Pr. 65 to Pr. 69	166

^{*1 &}quot;80, 81, 180 and 181" are available only in the safety stop function model. "93" and "193" are available only in Pr. 190 and Pr. 191.

Set	ting				Related	Refer
Positive logic	Negative logic	Signal	Function	Operation	Parameter	to Page
80	180	SAFE	Safety monitor output *2	Output while safety stop function is activated.	_	30
81	181	SAFE2	Safety monitor output 2 *2	The signal is output when no internal safety circuit failure (E.SAF, E.6, E.7, E.CPU) exists.	_	30
90	190	Y90	Life alarm	Output when any of the control circuit capacitor, main circuit capacitor and inrush current limit circuit or the cooling fan approaches the end of its service life.	Pr. 255 to Pr. 259	260
91	191	Y91	Fault output 3 (power-off signal)	Output when a fault occurs due to the internal circuit failure of the inverter wiring mistake.	_	144
93	193	Y93	Current average value monitor signal	Average current value and maintenance timer value are output as pulses. The signal can not be set in <i>Pr. 192 A,B,C terminal function selection</i> .	Pr. 555 to Pr. 557	265
95	195	Y95	Maintenance timer signal	Output when Pr. 503 rises to or above the Pr. 504 setting.	Pr. 503, Pr. 504	264
96	196	REM	Remote output	Output to the terminal when a value is set to the parameter.	Pr. 495 to Pr. 497	148
98	198	LF	Alarm output	Output when an alarm (fan failure or communication error warning) occurs.	Pr. 121, Pr. 244	210, 259
99	199	ALM	Fault output	Output when the fault occurs. The signal output is stopped when the fault is reset.	_	144
99	199	_	No function		_	

Note that when the frequency setting is varied using an analog signal or of the operation panel, the output of the SU (up to frequency) signal may alternate ON and OFF depending on that varying speed and the timing of the varying speed due to acceleration/deceleration time setting. (The output will not alternate ON and OFF when the acceleration/deceleration time setting is "0s".)

These parameters can be set only in the safety stop function model.



• REMARKS


- The same function may be set to more than one terminal.
- When the function is executed, the terminal conducts at the setting of any of "0 to 99", and does not conduct at the setting of



- Changing the terminal assignment using Pr.190 to Pr.192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.
- Do not assign signals which repeat frequent ON/OFF to terminal A, B, C. Otherwise, the life of the relay contact decreases.

Function assignment of external terminal and control

(2) Inverter operation ready signal (RY signal) and inverter running signal (RUN signal)



- When the inverter is ready to operate, the output of the operation ready signal (RY) is ON. (It is also ON during inverter running.)
- When the output frequency of the inverter rises to or above *Pr. 13 Starting frequency*, the output of the inverter running signal (RUN) is turned ON. During an inverter stop or DC injection brake operation, the output is OFF.
- When using the RY and RUN signals, assign functions to *Pr.190 to Pr.192 (output terminal selection function)* referring to the table below.

Output	Pr. 190 to Pr. 192 Setting			
Signal	Positive logic	Negative logic		
RY	11	111		
RUN	0	100		

Inverter Status		Start Signal OFF	Start Signal	Start Signal ON	Under DC	Output	Automatic Restart after Instantaneous Power Failure		
							Coasting		
Output	Resetting	(during		(during	Brake	shutoff *2	Start	Start	Restarting
. \		stop)	(during stop)	operation)	Drake		signal	signal	Restaining
signal							ON	OFF	
RY	OFF	ON	ON	ON	ON	OFF	ON *1		ON
RUN	OFF	OFF	OFF	ON	OFF	OFF	OFF		ON


^{*1} This signal turns OFF during power failure or undervoltage.

• REMARKS

• The RUN signal (positive logic) is assigned to the terminal RUN in the initial setting.

Output is shutoff under conditions such as a fault occurrence, MRS signal ON, and the safety stop operation.

(3) Fault output signal (ALM signal)



• If the inverter comes to trip, the ALM signal is output.

• REMARKS

- The ALM signal is assigned to the terminal A, B, C in the default setting. By setting "99 (positive logic) or 199 (negative logic) in *Pr.190 to Pr.192 (output terminal function selection)*, the ALM signal can be assigned to the other terminal.
- Refer to page 280 for the inverter fault description.

(4) Fault output 3 (power-off signal) (Y91 signal)

- The Y91 signal is output at occurrence of a fault attributable to the failure of the inverter circuit or a fault caused by a wiring mistake.
- When using the Y91 signal, set "91 (positive logic)" or "191 (negative logic)" to any of *Pr.190 to Pr.192 (output terminal function selection)* to assign the function to the output terminal.
- The following table indicates the faults that will output the Y91 signal. (Refer to page 279 for the fault description.)

Operation Indicat		Name			
€. 6€	E. BE	Brake transistor alarm detection			
E. GF	E.GF	Output side earth (ground) fault overcurrent			
E. LF	E.LF	Output phase loss			
E. PE	E.PE	Parameter storage device fault			
E.P.E.2	E.PE2	Internal board fault			
E. 6/ E. 7, E.C.P.U	E. 6/ E. 7/ E.CPU	CPU fault			
EJ 0H	E.IOH	Inrush current limit circuit fault			

• REMARKS

 At occurrence of output side earth (ground) fault overcurrent (E.GF), overcurrent trip during acceleration(E.OC1) may be displayed. At this time, the Y91 signal is output.



Parameters referred to

Pr. 13 Starting frequency 👺 Refer to page 108





4.11.6 Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)

The inverter output frequency is detected and output at the output signals.

Parameter Number	Name	Initial Value	Setting Range	Description
41	Up-to-frequency sensitivity	10%	0 to 100%	Level where the SU signal turns ON.
42	Output frequency detection	6Hz	0 to 400Hz	Frequency where the FU signal turns ON.
43	Output frequency detection for reverse 99		0 to 400Hz	Frequency where the FU signal turns ON in reverse rotation.
	rotation		9999	Same as Pr. 42 setting

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)





(1) Up-to-frequency sensitivity (SU signal, Pr. 41)

- When the output frequency reaches the set frequency, the up-to-frequency signal (SU) is output.
- •The Pr.~41 value can be adjusted within the range 0% to $\pm 100\%$ on the assumption that the set frequency is 100%.
- •This parameter can be used to ensure that the running frequency has been reached to provide the operation start signal etc. for related equipment.
- •When using the SU signal, set "1 (positive logic) or 101 (negative logic)" in *Pr. 190 to Pr. 192 (output terminal function selection)* to assign function to the output terminal.

(2) Output frequency detection (FU signal, *Pr. 42*, *Pr. 43*)

- The output frequency detection signal (FU) is output when the output frequency reaches or exceeds the *Pr. 42* setting.
- •This function can be used for electromagnetic brake operation, open signal, etc.
- Frequency detection that is dedicated to reverse operation can be set by setting detection frequency to *Pr. 43*. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during vertical lift operation, etc.
- •When $Pr. 43 \neq$ "9999", the Pr. 42 setting is used for forward rotation and the Pr. 43 setting is used for reverse rotation.

• REMARKS

- The FU signal is assigned to the terminal FU in the initial setting. The FU signal can also be assigned to the other terminal by setting "4 (positive logic) or 104 (negative logic)" in any of *Pr. 190 to Pr. 192*.
- All signals are OFF during DC injection brake.
- The output frequency to be compared with the set frequency is the output frequency before slip compensation is performed.



NOTE

Changing the terminal assignment using Pr.190 to Pr.192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to


Pr. 190 to Pr. 192 (output terminal function selection) 🖫 (Refer to page 141)


4.11.7 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153)

The output current during inverter running can be detected and output to the output terminal.

Parameter Number	Name	Initial Value	Setting Range	Description
150	Output current detection level	150%	0 to 200%	100% is the rated inverter current.
151	Output current detection signal delay time	0s	0 to 10s	Output current detection period. The time from when the output current has risen above the setting until the output current detection signal (Y12) is output.
152	Zero current detection level	5%	0 to 200%	The rated inverter current is assumed to be 100%.
153	Zero current detection time	0.5s	0 to 1s	Period from when the output current drops below the <i>Pr. 152</i> value until the zero current detection signal (Y13) is output.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)





* The zero current detection signal (Y13) holds the signal for approximately 100ms once turned ON.

(1) Output current detection (Y12 signal, *Pr. 150*, *Pr. 151*)

- •The output current detection function can be used for excessive torque detection, etc.
- •If the output current remains higher than the *Pr.* 150 setting during inverter operation for longer than the time set in *Pr.* 151, the output current detection signal (Y12) is output from the inverter's open collector or relay output terminal.
- When the Y12 signal turns ON, the ON state is held for approximately 100ms.
- •For the Y12 signal, set "12 (positive logic) or 112 (negative logic)" in *Pr. 190 to Pr. 192 (output terminal function selection)* and assign functions to the output terminal.

(2) Zero current detection (Y13 signal, Pr. 152, Pr. 153)

- •If the output current remains lower than the *Pr.* 152 setting during inverter operation for longer than the time set in *Pr.* 153, the zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.
- •When the inverter's output current falls to "0", torque will not be generated. This may cause a drop due to gravity when the inverter is used in vertical lift application.
- To prevent this, the Y13 signal can be output from the inverter to close the mechanical brake when the output current has fallen to "zero".
- •For the Y13 signal, set "13 (positive logic) or 113 (negative logic)" in *Pr. 190 to Pr. 192 (output terminal function selection)* and assign functions to the output terminal.

• REMARKS

- This function is also valid during execution of the offline auto tuning.
- The response time of Y12 and Y13 signals is approximately 0.1s. Note that the response time changes according to the load condition.

When Pr. 152 = "0", detection is disabled.



NOTE

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



! CAUTION

The zero current detection level setting should not be too low, and the zero current detection time setting not too long. Otherwise, the detection signal may not be output when torque is not generated at a low output current.

To prevent the machine and equipment from resulting in hazardous conditions detection signal, install a safety backup such as an emergency brake even the zero current detection function is set valid.



Parameters referred to

Offline auto tuning Refer to page 116
Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

4.11.8 Remote output selection (REM signal, Pr. 495 to Pr. 497)

You can utilize the ON/OFF of the inverter's output signals instead of the remote output terminal of the programmable logic controller.

Parameter	Name	Initial	Setting	Description				
Number	Name	Value	Range	Description				
			0	Remote output data clear at powering OFF	Remote output data is			
			1	Remote output data retention at powering	cleared during an			
495	Remote output	0	'	OFF	inverter reset			
495	selection		10	Remote output data clear at powering OFF	Remote output data is			
			11	Remote output data retention at powering	retained during an			
			11	OFF	inverter reset			
496*	Remote output data 1	0	0 to 4095					
497*	Remote output data 2	0	0 to 4095	Refer to the following diagram.				

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

* This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

<Remote output data>


Pr. 496 b11 b0 ABC * E * Pr. 497 b11 b0 **Y2***2 **Y1***2 **Y0***2 **Y4***2 Y6*2 Y5*2 Y3*2 *

- *1 Any
- *2 Y0 to Y6 are available only when the extension output option (FR-A7AY E
- *3 RA1 to RA3 are available only when the relay output option (FR-A7AR E kit) is fitted


- The output terminal can be turned ON/OFF depending on the Pr. 496 or Pr. 497 setting. The remote output selection can be controlled ON/OFF by computer link communication from the PU connector or by communication from the communication option.
- Set "96 (positive logic) or 196 (negative logic)" to any of Pr. 190 to Pr. 192 (output terminal function selection), and assign the remote output (REM) signal to the terminal used for remote output,
- When you refer to the diagram on the left and set 1 to the terminal bit (terminal where the REM signal has been assigned) of *Pr. 496* or *Pr. 497*, the output terminal turns ON (OFF for negative logic). By setting 0, the output terminal turns OFF (ON for negative logic).

Example: When "96 (positive logic)" is set in *Pr. 190 RUN terminal function selection* and "1" (H01) is set in *Pr. 496*, the terminal RUN turns ON.

ON/OFF example for positive logic



Signal condition during a reset



- * When Pr. 495 = "1," the signal condition saved in EEPROM (condition of the last power OFF) is applied.
- When Pr. 495 = "0 (initial value), 10", performing a power ON reset (including a power failure) clears the REM signal output. (The ON/OFF status of the terminals are as set in Pr. 190 to Pr. 192.) The Pr. 496 and Pr. 497 settings are also "0". When Pr. 495 = "1, 11", the remote output data before power OFF is stored into the EEPROM, so the signal output at power recovery is the same as before power OFF. (See the chart on the left) However, it is not stored when the inverter is reset (terminal reset, reset request through communication).
- When Pr. 495 = "10 or 11," the signal before the reset is held even during an inverter reset.

REMARKS

• The output terminal where the REM signal is not assigned using any of *Pr. 190 to Pr. 192* does not turn ON/OFF if 0/1 is set to the terminal bit of *Pr. 496 or Pr. 497*. (It turns ON/OFF with the assigned function.)

Parameters referred to

Pr. 190 to Pr. 192 (output terminal function selection) T Refer to page 141



4.12 Monitor display and monitor output signal

Purpose	Parameter that	Refer to Page	
Display motor speed Set speed	Speed display and speed setting	Pr. 37	149
Change PU monitor display data	DU/PU main display data selection Cumulative monitor clear	Pr. 52, Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564	150
Change the monitor output from terminal AM	Terminal AM function selection	Pr. 158	150
Set the reference of the monitor output from terminal AM	Terminal AM standard setting	Pr. 55, Pr. 56	155
Adjust terminal AM outputs	Terminal AM calibration	Pr. 645, Pr. 901	156

4.12.1 Speed display and speed setting (Pr. 37)

The monitor display and frequency setting of the PU (FR-PU04/FR-PU07) can be changed to the machine speed.

Parameter Number	Name	Initial Value	Setting Range	Description
37	37 Speed display		0	Frequency display, setting
31	Speed display	U	0.01 to 9998*	Machine speed at 60Hz.

The above parameters can be set when Pr. 160User group read selection = "0". (Refer to page 184)

* The maximum value of the setting range differs according to the Pr. 1 Maximum frequency (Pr.18 High speed maximum frequency) and it can be calculated from the following formula.

Maximum setting value of $Pr. 37 < \frac{16777.215 \times 60 \text{ (Hz)}}{\text{Setting value of } Pr. 1 (Pr.18) \text{ (Hz)}}$

Note that the maximum setting value of Pr. 37 is 9998 if the result of the above formula exceeds 9998.

• To display the machine speed, set in *Pr. 37* the machine speed for 60Hz operation. For example, when *Pr. 37* = "1000", "1000" is displayed on the output frequency and set frequency monitor when the running frequency is 60Hz. When running frequency is 30Hz, "500" is displayed.

Pr. 37 Setting	Output Frequency Monitor	Set Frequency Monitor	Frequency Setting	Parameter Setting
0 (initial value)	Hz	Hz	Hz	Hz
0.01 to 9998	Machine speed *1	Machine speed *1	Machine speed *1	112

- *1 Machine speed conversion formulaPr. 37 × frequency/60Hz
- *2 Hz is displayed in 0.01Hz increments and machine speed is in 0.001.



NOTE

- Under V/F control, the output frequency of the inverter is displayed in terms of synchronous speed, and therefore, displayed value = actual speed + motor slip. The display changes to the actual speed (estimated value calculated based on the motor slip) when Advanced magnetic flux vector control was selected or slip compensation was valid.
- Refer to Pr. 52 when you want to change the PU main monitor (PU main display).
- Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- When the machine speed is displayed on the FR-PU04/FR-PU07, do not change the speed by using an up/down key in the state where the set speed exceeding 65535 is displayed. The set speed may become arbitrary value.
- While the machine speed is displayed on the monitor, values of other parameters related to speed (*Pr. 1*, etc.) are in frequency increments. Set other parameters (*Pr. 1*, etc) related to speed in increments of frequency.
- Due to the limitations on the resolution of the set frequency, the indication in the second decimal place may differ from the setting.
- When frequency or set frequency is monitored from network option card except for FR-A7NC E kit, frequency is displayed for monitor description regardless of *Pr. 37* setting.



Make sure that the running speed setting is correct.

Otherwise, the motor might run at extremely high speed, damaging the machine.



Parameters referred to

Pr. 1 Maximum frequency, Pr.18 High speed maximum frequency Refer to page 92 Pr. 52 DU/PU main display data selection Refer to page 150

Pr. 800 Control method selection Refer to page 80

4.12.2 Monitor display selection of DU/PU and terminal AM (Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)

The monitor to be displayed on the main screen of the control panel and parameter unit (FR-PU04/FR-PU07) can be selected.

In addition, signal to be output from the terminal AM (analog voltage output) can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
52 *	DU/PU main display data selection	0 (output frequency)	0, 5, 7 to 12, 14, 20, 23 to 25, 52 to 57, 61, 62, 100	Select the monitor to be displayed on the operation panel and parameter unit. Refer to the following table for monitor description.
158 *	AM terminal function selection	1 (output frequency)	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	Select the monitor output to terminal AM.
			0	Set "0" to clear the watt-hour meter monitor.
170	Watt-hour meter clear	9999	10	Sets the maximum value for the monitoring from communication to 9999kWh.
			9999	Sets the maximum value for the monitoring from communication to 65535kWh.
171	Operation hour meter clear	9999	0, 9999	Set "0" in the parameter to clear the operation time monitor. Setting 9999 does not clear.
	Monitor decimal digits		0	Displayed as integral value
268 *	selection	9999	1	Displayed in 0.1 increments.
	Selection		9999	No function
563	Energization time carrying- over times	0	0 to 65535 (reading only)	The numbers of cumulative energization time monitor exceeded 65535h is displayed. (Reading only)
564	Operating time carrying- over times	0	0 to 65535 (reading only)	The numbers of operation time monitor exceeded 65535h is displayed. (Reading only)

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Monitor description list (Pr. 52)


- •Set the monitor to be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) in *Pr. 52 DU/PU main display data selection* .
- ulletSet the monitor to be output to the terminal AM (analog voltage output) in Pr.~158~AM terminal function selection .
- ullet Refer to the following table and set the monitor to be displayed. (The monitor marked \times cannot be selected.)

		Pr. 52 S	Setting		Terminal AM Full Scale Value		
Types of Monitor	Unit	Operation panel LED	PU main monitor	Pr.158 (AM) Setting			Description
Output frequency	0.01Hz	0/1	100	1	Pr. 55		Displays the inverter output frequency.
Output current	0.01A	0/1	100	2	Pr 56		Displays the inverter output current effective value.
Output voltage	0.1V	0/1	100	3	200V class 400V		Displays the inverter output voltage.
Output voltage	0.17	0/1	100	3	400V class	800V	Displays the inverter output voltage.
Fault display		0/1	100	×	_		Displays 8 past faults individually.
Frequency setting value	0.01Hz	5	*1	5	Pr. 55		Displays the set frequency.
Motor torque	0.1%	7	*1	7	Rated torque applied moto		Displays the motor torque in % on the assumption that the rated motor torque is 100%. (Displays 0% during V/F control)
Converter output voltage	0.1V	8	*1	8	200V class 400V class	400V 800V	Displays the DC bus voltage value.

^{*} This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



		Pr. 52 Setting					
Towns of Maniton	11!4	Operation	PU	Pr.158 (AM)	Terminal AM	December 41 and	
Types of Monitor	Unit	panel LED	main monitor	Setting	Full Scale Value	Description	
Regenerative brake duty	0.1%	9	*1	9	Pr. 70	Brake duty set in Pr. 30, Pr. 70	
Electronic thermal relay function load factor	0.1%	10	*1	10	100%	Displays the thermal cumulative value on the assumption that the thermal operation level is 100% (Larger thermal between the motor thermal and transistor thermal).	
Output current peak value	0.01A	11	*1	11	Pr. 56	Holds and displays the peak value of the output power monitor. (Cleared at every start)	
Converter output voltage peak value	0.1V	12	*1	12	200V class 400V 400V class 800V	Holds and displays the peak value of the DC bus voltage value. (Cleared at every start)	
Output power	0.01kW	14	*1	14	Rated inverter power × 2	Displays the power on the inverter output side	
Input terminal status	_	_	*1	×	_	Displays the input terminal ON/OFF status on the PU. (<i>Refer to page 153</i> for DU display)	
Output terminal status	_	_	*1	×	_	Displays the output terminal ON/OFF status on the PU. (<i>Refer to page 153</i> for DU display)	
Cumulative energization time *2	1h	2	0	×	_	Adds up and displays the energization time after inverter shipment. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 563</i> .	
Reference voltage output	_	-	_	21	_	Terminal AM: Output 10V	
Actual operation time *2, *3	1h	2	3	×	_	Adds up and displays the inverter operation time. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 564</i> . Can be cleared by <i>Pr. 171. (Refer to page 154)</i>	
Motor load factor	0.1%	2	14	24	200%	Displays the output current value on the assumption that the inverter rated current value is 100%. Monitor value = output power monitor value/rated inverter current 100 [%]	
Cumulative power *5	0.01kWh *4	2	25	×	_	Adds up and displays the power amount based on the output power monitor. Can be cleared by <i>Pr. 170. (Refer to page 154)</i>	
PID set point	0.1%	5	52	52	100%	Displays the set point, measured value and	
PID measured value	0.1%		3	53	100%	deviation during PID control (Refer to page	
PID deviation	0.1%	5	4	×	_	246 for details)	
Inverter I/O terminal monitor	_	55	×	×	_	Displays the ON/OFF status of the inverter input terminal and output terminal on the operation panel (<i>Refer to page 153</i> for details)	
Option input terminal status	_	56	×	×	_	Displays the input terminal ON/OFF status of the digital input option (FR-A7AX E Kit) on the operation panel. (<i>Refer to page 153</i> for details)	
Option output terminal status	_	57	×	×	_	Displays the output terminal ON/OFF status of the digital output option (FR-A7AY E kit) or relay output option (FR-A7AR E Kit) on the operation panel (<i>Refer to page 153</i> for details).	
Motor thermal load factor	0.1%	6	1	61	Thermal relay operation level (100%)	Motor thermal heat cumulative value is displayed. (Motor overload trip (E.THM) at 100%)	




- Frequency setting to output terminal status on the PU main monitor are selected by "other monitor selection" of the parameter unit (FR-PU04/FR-PU07)
- *2 The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0. When the operation panel is used, the time is displayed up to 65.53 (65530h) in the indication of 1h = 0.001, and thereafter, it is added up from 0.
- Actual operation time is not accumulated when the cumulative operation time is less than 1h until turning OFF of the power supply.
- *4 When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.
- *5 Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- Larger thermal value between the motor thermal and transistor thermal is displayed.
 - A value other than 0% is displayed if the surrounding air temperature (heatsink temperature) is high even when the inverter is at a stop.

> REMARKS


- By setting "0" in Pr. 52, the monitoring of output speed to fault display can be selected in sequence by (SET)
- When the operation panel is used, the displayed units are Hz and A only and the others are not displayed.
- The monitor set in Pr. 52 is displayed in the third monitor position. However, change the output current monitor for the motor load factor.

Initial Value

*The monitor displayed at powering on is the first monitor. Display the monitor you want to display on the first monitor and hold down (SET) for 1s. (To return to the output frequency monitor, hold down (SET) for 1s after displaying the output frequency monitor.)



Example)When Pr. 52 is set to "20" (cumulative energization time), the monitor is displayed on the operation panel as described below.



(2) Display set frequency during stop (Pr. 52)

• When "100" is set in Pr. 52, the set frequency and output frequency are displayed during stop and operation respectively. (LED of Hz flickers during stop and is lit during operation.)

Pr. 52					
0	100				
During	During ston	During			
running/stop	During Stop	running			
Output	Set	Output			
frequency	frequency*	frequency			
	Output current				
Output voltage					
	Fault display				
	During running/stop Output	During running/stop Output Set frequency* Output current Output voltage			

The set frequency displayed indicates the frequency to be output when the start command is ON. Different from the frequency setting displayed when Pr. 52 = "5", the value based on maximum/minimum frequency and frequency jump is displayed.

> REMARKS

- During an error, the output frequency at error occurrence appears.
- During MRS signal is ON, the values displayed are the same as during a stop. During offline auto tuning, the tuning status monitor has priority.




(3) Operation panel I/O terminal monitor (Pr. 52)


- •When Pr. 52 is set to any of "55 to 57", the I/O terminal status can be monitored on the operation panel.
- •The I/O terminal monitor is displayed on the third monitor.
- •The LED is ON when the terminal is ON, and the LED is OFF when the terminal is OFF. The center line of LED is always ON.

Pr. 52 Setting	Monitor Description
55	Displays the I/O and output terminal ON/OFF status of the inverter unit.
56 *	Displays the input terminal ON/OFF status of the digital input option (FR-A7AX E kit).
57 *	Displays the output terminal ON/OFF status of the digital output option (FR-A7AY E kit) or relay output option (FR-A7AR E kit).


- * You can set "56" or "57" if the option is not fitted. When the option is not fitted, the monitor displays are all OFF.
 - •On the unit I/O terminal monitor (Pr. 52 = "55"), the upper LEDs denote the input terminal status and the lower the output terminal status.



- *Terminal MRS is available only in the standard control circuit terminal model.
- •On the input option terminal monitor (Pr. 52 = "56"), the decimal point LED of the first digit LED is ON.



•On the output option terminal monitor (Pr. 52 = "57"), the decimal point LED of the second digit LED is ON.



Cumulative power monitor and clear (Pr. 170)

- •On the cumulative power monitor (Pr. 52 = "25"), the output power monitor value is added up and is updated in 1h increments.
- •The operation panel, parameter unit (FR-PU04/FR-PU07) and communication (RS-485 communication, communication option) display increments and display ranges are as indicated below.

Operation Panel *1		Parameter Unit *2		Communication			
Range	Unit	Range	ae Unit		Range		
Range	Oilit	Kallye	Oilit	<i>Pr. 170</i> = 10	<i>Pr. 170</i> = 9999	Unit	
0 to 99.99kWh	0.01kWh	0 to 999.99kWh	0 to 999.99kWh 0.01kWh	0 to 65535kWh			
100.0 to 999.9kWh	0.1kWh	1000.0 to 9999.9kWh	0.1kWh	0 to 9999kWh	1	1kWh	
1000 to 9999kWh	1kWh	10000 to 99999kWh	1kWh	(initial value)			

- Power is measured in the range 0 to 9999.99kWh, and displayed in 4 digits.
 - When the monitor value exceeds "99.99", a carry occurs, e.g. "100.0", so the value is displayed in 0.1kWh increments.
- Power is measured in the range 0 to 99999.99kWh, and displayed in 5 digits.
 - When the monitor value exceeds "999.99", a carry occurs, e.g. "1000.0", so the value is displayed in 0.1kWh increments.
- •Writing "0" to Pr. 170 clears the cumulative power monitor.



REMARKS

• If "0" is written to Pr. 170 and Pr. 170 is read again, "9999" or "10" is displayed.

(5) Cumulative energization time and actual operation time monitor (Pr. 171, Pr. 563, Pr. 564)

- •Cumulative energization time monitor (Pr. 52 = "20") accumulates energization time from shipment of the inverter every one hour.
- •On the actual operation time monitor (Pr. 52 = "23"), the inverter running time is added up every hour. (Time is not added up during a stop.)
- •If the monitored value exceeds 65535, it is added up from 0. You can check the numbers of cumulative energization time monitor exceeded 65535h with Pr. 563 and the numbers of actual operation time monitor exceeded 65535h with Pr. 564.
- •Writing "0" to Pr. 171 clears the cumulative power monitor. (The cumulative time monitor can not be cleared.)



REMARKS

- The actual operation time is not added up unless the inverter is operated one or more hours continuously.
- If "0" is written to Pr. 171 and Pr. 171 is read again, "9999" is always displayed. Setting "9999" does not clear the actual operation

(6) You can select the decimal digits of the monitor (Pr. 268)

•As the operation panel display is 4 digits long, the decimal places may vary at analog input, etc. The decimal places can be hidden by selecting the decimal digits.

In such a case, the decimal digits can be selected by Pr. 268.

Pr. 268 Setting	Description
9999 (initial value)	No function
	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first
0	decimal place and smaller are rounded to display an integral value (1 increments). The monitor value smaller than
	0.99 is displayed as 0.
1	When 2 decimal places (0.01 increments) are monitored, the 0.01 decimal place is dropped and the monitor
'	displays the first decimal place (0.1 increments). The monitored digits in 1 increments are displayed as they are.



• REMARKS

The number of display digits on the cumulative energization time (Pr. 52 = "20"), actual operation time (Pr. 52 = "23"), and cumulative power (Pr. 52 = "25") does not change.



Parameters referred to

Pr. 30 Regenerative function selection, Pr. 70 Special regenerative brake duty 👺 Refer to page 126

Pr. 37 Speed display Refer to page 149

Pr. 55 Frequency monitoring reference, Pr. 56 Current monitoring reference Refer to page 155




4.12.3 Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)

Analog voltage output from the terminal AM is available. Set the reference of the signal output from terminal AM.

Parameter Number	Name	Initial Value	Setting Range	Description
55	Frequency monitoring reference	50Hz	0 to 400Hz	Full-scale value when frequency monitor value is output to terminal AM.
56	Current monitoring reference	Inverter rated current	0 to 500A	Full-scale value when current monitor value is output to terminal AM.


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184).

(1) Frequency monitoring reference (Pr. 55)



- Set the full scale value when outputting the frequency monitor from terminal AM.
- Set the frequency to be referenced when the frequency monitor (output frequency/set frequency) is selected for the terminal AM display.
- Set the frequency (output frequency/set frequency) when the voltage output at terminal AM is 10VDC.
- The analog voltage output and frequency at terminal AM are proportional. (The maximum output voltage is 10VDC.)

(2) Current monitoring reference (Pr. 56)



- Set the full scale value when outputting the current monitor from terminal AM.
- Set the current to be referenced when the current monitor (inverter output current, etc.) is selected for terminal AM display.
- Set the current value when the voltage output at terminal AM is 10VDC.
- The analog voltage output and current value at terminal AM are proportional. (The maximum output voltage is 10VDC.)

The above parameters allow their settings to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.


Terminal AM calibration (calibration parameter Pr. 645, C1 (Pr.901))

By using the operation panel or parameter unit, you can calibrate terminal AM to full scale deflection.

Parameter Number	Name	Initial Value	Setting Range	Description
645	AM 0V adjustment	1000	970 to 1200	Calibrates the scale of the meter when analog output is 0.
C1(901)	AM terminal calibration	_	_	Calibrates the scale of the meter connected to terminal AM.

- The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)
- *2 The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).
- The above parameters allow their settings to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write

Terminal AM bias calibration



- Use Pr. 645 AM 0V adjustment to calibrate the bias side output signal from terminal AM.
- If the meter needle does not point to 0 when the analog output from terminal AM is 0, add or decrease the Pr. 645 setting to adjust the meter needle points to 0.
- When changing ± 1 in Pr. 645, the analog output changes about ±5mV.

(Analog output will not become lower than about -100mV even when setting the Pr. 645 lower.)





NOTE

- Calibration bias and gain changes when changing the control circuit terminal block. Use Pr. 645 and C1(Pr. 901) to
- If bias calibration (Pr. 645) is performed, make sure to perform gain calibration (C1(Pr. 901)) too.

(2) Terminal AM gain calibration (C1 (Pr. 901))

Terminal AM is factory-set to provide a 10VDC output in the full-scale status of the corresponding monitor item. Calibration parameter C1 (Pr. 901) allows the output voltage ratios (gains) to be adjusted according to the meter scale. Note that the maximum output voltage is 10VDC.





- · Calibrate the terminal AM gain in the following procedure.
 - 1) Connect a 0-10VDC meter (frequency meter) to across inverter terminals AM-5. (Note the polarity. The terminal AM is positive.)
 - 2) Refer to the monitor description list (page 150) and set Pr. 158. When you selected the running frequency, inverter output current, etc. as monitor, preset in Pr. 55 or Pr. 56 the running frequency or current value at which the output signal will be 10V.
 - 3) When outputting the item that cannot achieve a 100% value easily by operation, e.g. output current, set "21" (reference voltage output) in Pr. 158 and perform the following operation. After that, set "2" (output current, for example) in Pr. 158.




• REMARKS

When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set Pr. 158 to "21" (reference voltage output) and make calibration. 10VDC is output from the terminal AM.



(3) How to calibrate the terminal AM when using the operation panel



Operation –

- operation mode indication
- 2. Press (MODE) to choose the parameter setting mode.
- 3. Turn until [. . . appears.
- 4. Press (SET) until [- appears.
- 5. Turn antil [Set to C1 AM terminal calibration.
- 6. Press (SET) to enable setting.
- 7. If the inverter is at a stop, press the (RUN) key to start the inverter. (Motor needs not be connected.)
- 8. Turn (to adjust the indicator needle to the desired position.
- 9. Press(SET) Setting is complete.



(When Pr. 158 = 1)



PRM indication is lit.



(The parameter number read previously appears.)

- C1 to C7 setting is enabled.

- The monitor set to Pr. 158 AM terminal function selection is displayed.
- Analog indicator

Flicker...Parameter setting complete!!

- to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.[].

• REMARKS

- · Calibration can also be made for external operation. Set the frequency in the External operation mode, and make calibration in
- Calibration can be made even during operation.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the parameter unit.



Parameters referred to

Pr. 55 Frequency monitoring reference Refer to page 155 Pr. 56 Current monitoring reference Refer to page 155 Pr. 158 AM terminal function selection Refer to page 150

4.13 Operation selection at power failure and instantaneous power failure

Purpose	Parameter ti	nat should be Set	Refer to Page
At instantaneous power failure	Automatic restart operation	Pr. 30, Pr. 57, Pr. 58, Pr. 96,	
occurrence, restart inverter without	after instantaneous power	Pr. 162, Pr. 165, Pr. 298, Pr. 299,	158
stopping motor	failure/flying start	Pr. 611	
When undervoltage or a power	Power failure-time		
failure occurs, the inverter can be	deceleration-to-stop	Pr. 261	164
decelerated to a stop.	function		

4.13.1 Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)

You can restart the inverter without stopping the motor in the following cases:


- When power comes back on after an instantaneous power failure
- When motor is coasting at start

Parameter	M	1.20.137.1	Setting	B d. G
Number	Name	Initial Value	Range	Description
30	Regenerative function	0, 1		The motor starts at the starting frequency when MRS (X10) turns ON then OFF
	selection		2	Restart operation is performed when MRS (X10) turns ON then OFF
57	Restart coasting time	9999	0	FR-E740-040(SC) or less, FR-E720S-080(SC) or less1s FR-E740-060(SC) to 170(SC), FR-E720S-110(SC)2s FR-E740-230(SC) and 300(SC)3s The above times are coasting time.
			0.1 to 5s	Waiting time for inverter-triggered restart after an instantaneous power failure.
58	Restart cushion time	1s	9999 0 to 60s	No restart
50	Restart cusinon time	15	0 10 605	Voltage starting time at restart. Offline auto tuning is not performed
			0	Advanced magnetic flux vector control
			1	Offline auto tuning is performed without motor running (all motor constants) (Refer to page 82)
96	Auto tuning setting/status	0	11	For General-purpose magnetic flux vector control Offline auto tuning is performed without motor running (motor constants (R1) only) (Refer to page 85)
			21	Offline auto tuning (tuning performed without motor running) for V/F control and automatic restart after instantaneous power failure (with frequency search)
	Automatic restart after		0	With frequency search
162	instantaneous power	1	1	Without frequency search (reduced voltage system)
102	failure selection	ı	10	Frequency search at every start
			11	Reduced voltage at every start
165	Stall prevention	150%	0 to 200%	Considers the rated inverter current as 100% and sets the stall
	operation level for restart			prevention operation level during restart operation.
298	298 Frequency search gain	9999	0 to 32767	When offline auto tuning is performed under V/F control, frequency search gain necessary for frequency search for automatic restart after instantaneous power failure is set as well as the motor constants (R1).
			9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants
			0	Without rotation direction detection
F	Rotation direction		1	With rotation direction detection
299	detection selection at restarting	0	9999	When $Pr. 78 = 0$, With rotation direction detection When $Pr. 78 = 1, 2$
				Without rotation direction detection
611	Acceleration time at a	9999	0 to 3600s	Acceleration time to reach <i>Pr. 20 Acceleration/deceleration reference frequency</i> at a restart.
	restart		9999	Acceleration time for restart is the normal acceleration time (e.g. <i>Pr.</i> 7)

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)




When Pr. 162 = 1, 11 (without frequency search)



^{*} The output shut off timing differs according to the load condition.

When Pr. 162 = 0, 10 (with frequency search)



(1) Automatic restart operation selection

(Pr. 30, Pr. 162, Pr. 299)

Without frequency search

When Pr. 162 = "1 (initial value)" or "11", automatic restartoperation is performed in a reduced voltage system, where the voltage is gradually risen with the output frequency unchanged from prior to an instantaneous power failure independently of the coasting speed of the

• REMARKS

This system stores the output frequency and rotation direction prior to an instantaneous power failure and restart using the stored value. Therefore, if the instantaneous power failure time exceeds 0.2s and the stored value cannot be retained, the inverter starts at Pr. 13 Starting frequency (initial value = 0.5Hz) in the starting direction upon power restoration.

With frequency search

When "0 or 10" is set in Pr. 162, the inverter smoothly starts after detecting the motor speed upon power restoration. (The motor capacity should be equal to or one rank lower than the inverter capacity)

When using the frequency search, perform offline auto tuning.

(Refer to page 116 for Advanced magnetic flux vector control, General-purpose magnetic flux vector control and page 161 for V/F control.)

- •During reverse rotation, the inverter can be restarted smoothly as the direction of rotation is detected.
- You can select whether to make rotation direction detection or not with Pr. 299 Rotation direction detection selection at restarting.

When capacities of the motor and inverter differ, set "0" (without rotation direction detection) in Pr. 299.

Pr. 299 Setting		Pr. 78 Setting	I
Fr. 299 Setting	0	1	2
9999	0	×	×
0 (initial value)	×	×	×
1	0	0	0

- O: the rotation direction is detected.
- x: the rotation direction is not detected.



• REMARKS

- Speed detection time (frequency search) changes according to the motor speed. (maximum 100ms)
- When the inverter capacity is two rank or more larger than the motor capacity, the inverter may not start due to overcurrent trip (E.OC \square).
- If two or more motors are connected to one inverter, the function does not operate properly. (The inverter does not start smoothly.)
- When reverse rotation is detected when Pr. 78 = "1" (reverse rotation disabled), the rotation direction is changed to forward rotation after decelerates in reverse rotation when the start command is forward rotation. The inverter will not start when the start command is reverse rotation.



NOTE

- · When automatic restart operation after instantaneous power failure is activated while the motor is running at a low speed (less than 10Hz), the motor restarts in the direction prior to instantaneous power failure without detecting the rotation direction (Pr. 299 Rotation direction detection selection at restarting = "1").
- If the frequency search result exceeds the set frequency, the output frequency is limited at the set frequency.
- When the wiring length exceeds 100m, select without frequency search (Pr. 162 = "1, 11").



Restart operation at every start

When Pr. 162 = "10 or 11", automatic restart operation is also performed every start, in addition to the automatic restart after instantaneous power failure. When Pr. 162 = "0", automatic restart operation is performed at the first start after power supply ON, but not performed at the second time or later.

• Automatic restart operation selection of MRS (X10) signal

Restart operation after turning MRS (X10) signal ON then OFF using Pr.~30 can be selected as in the table below. When automatic restart after instantaneous power failure is selected while using the high power factor converter (FR-HC), normally set "2" in Pr.~30.

Pr. 30 Setting	Operation after turning OFF, ON, then OFF the MRS and X10 Signals		
0, 1	Start at the Pr. 13 Starting frequency.		
2	Restart (starts at the coasting speed.)		



> REMARKS

• When output is shut off using terminal S1 and S2 in the safety stop function model, the inverter restarts in the same way as when output is shut off by MRS (X10) signal.

(2) Restart coasting time (Pr. 57)

- Coasting time is the time from when the motor speed is detected until automatic restart control is started.
- •Set Pr. 57 to "0" to perform automatic restart operation.


The coasting time is automatically set to the value below. Generally this setting will pose no problems.

FR-E740-040(SC) or less, FR-E720S-080(SC) or less	1s
FR-E740-060(SC) to 170(SC), FR-E720S-110(SC)	2s
FR-E740-230(SC) and 300(SC)	3s

•Operation may not be performed well depending on the magnitude of the moment of inertia (J) of the load or running frequency. Adjust the coasting time between 0.1s and 5s according to the load specifications.

(3) Restart cushion time (Pr. 58)

- Cushion time is the length of time taken to raise the voltage appropriate to detected motor speed (output frequency prior to instantaneous power failure when Pr. 162 = "1, 11") from 0V.
- •Normally the initial value need not be changed for operation, but adjust it according to the magnitude of the moment of inertia (J) of the load or torque.



(4) Automatic restart operation adjustment (Pr. 165, Pr. 611)

- •Using Pr. 165, you can set the stall prevention operation level at a restart.
- •Using *Pr. 611*, you can set the acceleration time until *Pr.20 Acceleration/deceleration reference frequency* is reached when automatic restart operation is performed besides the normal acceleration time.



> REMARKS

• If the Pr. 21 Acceleration/deceleration time increments is changed, the setting increments of Pr. 611 remain unchanged.



(5) Frequency search gain (Pr. 298), offline auto tuning (Pr. 96)

- •When automatic restart after instantaneous power failure operation (with frequency search) is valid at V/F control, perform offline auto tuning.
- •Perform offline auto tuning during V/F control in the following order to set Pr. 298 Frequency search gain automatically. (Refer to page 116 during Advanced magnetic flux vector control and General-purpose magnetic flux vector control.)

Before performing offline auto tuning

Check the following before performing offline auto tuning.

- The inverter is under V/F control
- •A motor should be connected. Note that the motor should be at a stop at a tuning start.
- •The motor capacity should be equal to or one rank lower than the inverter capacity.
- •A high-slip motor, high-speed motor and special motor cannot be tuned. (The maximum frequency is 120Hz.)
- •Even if tuning is performed without motor running (Pr. 96 Auto tuning setting/status = "21"), the motor may run slightly. Therefore, fix the motor securely with a mechanical brake, or before tuning, make sure that there will be no problem in safety if the motor runs (caution is required especially in vertical lift applications). Note that tuning performance is unaffected even if the motor runs slightly.
- Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASF-H, FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

Setting

1) Set "21" in Pr. 96 Auto tuning setting/status.

Tuning is performed without motor running.

It takes approximately 9s * until tuning is completed.

(Excitation noise is produced during tuning.)

- *Tuning time differs according to the inverter capacity and motor type.
- 2) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 112)
- 3) Set Pr. 71 Applied motor according to the motor used.

Motor	<i>Pr.71</i> Setting *1	
	SF-JR	
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
Mitauhiahi aanatant tarawa	SF-JRCA 4P	13
Mitsubishi constant-torque motor	SF-HRCA	53
motor	Others (SF-JRC, etc.)	13
Other manufacturer's standard motor	_	3
Other manufacturer's constant torque motor	_	13

^{*1}Refer to page 114, for other settings of Pr. 71.

Execution of tuning



POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below)

1) When performing PU operation, press (RUN) of the operation panel. For External operation, turn ON the start command (STF signal or STR signal). Tuning starts.





- To force tuning to end, use the MRS or RES signal or press $\frac{(STOP)}{(RESET)}$ of the operation panel. (Turning the start signal (STF signal or STR signal) OFF also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
- •Input terminal <Valid signal> MRS, RES, STF, STR
- Output terminal RUN, AM, A, B, C

Note that the progress status of offline auto tuning is output in eight steps from AM when speed and output frequency are selected.

- Since the RUN signal turns ON when tuning is started, caution is required especially when a sequerence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching ON the main circuit power (R/L1, S/L2, T/
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not executed properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04, FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04, FR-PU07)	Operation Panel Indication
Pr. 96 setting	21	21
(1) Setting	READ:List 21 STOP PU	2 1 = MCN
(2) Tuning in progress	TUNE 22 STF FWD PU	
(3) Normal end	TUNE 23 COMPLETION STF STOP PU	Flickering
(4) Error end (when inverter protective function operation is activated)		3 Ext 2

•Reference: Offline auto tuning time (when the initial value is set)

Offline Auto Tuning Setting	Time
Tune motor constants (R1) only	Approx. 9s (Tuning time differs according to the inverter capacity
(<i>Pr.</i> 96 = "21")	and motor type.)

3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For External operation, turn OFF the start signal (STF signal or STR signal) once.

This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)



REMARKS

Do not change the Pr. 96 setting after completion of tuning (23). If the Pr. 96 setting is changed, tuning data is invalid. If the Pr. 96 setting is changed, tuning must be performed again.



4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error Display	Error Cause	Remedy
8	Forced end	Set "21" in Pr. 96 and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Set "1" in <i>Pr. 156</i> .
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
93	Calculation error	Check the motor wiring and make setting again.
93	A motor is not connected.	Set the rated current of the motor in Pr. 9.

- 5) When tuning is ended forcibly by pressing (STOP) or turning OFF the start signal (STF or STR) during tuning, offline auto tuning does not end normally. (The motor constants have not been set.) Perform an inverter reset and restart tuning.
- 6) When using the motor corresponding to the following specifications and conditions, reset Pr.9 Electronic thermal O/L relay as below after tuning is completed.
 - a) When the rated power specifications of the motor is 200/220V(400/440V) 60Hz, set 1.1 times rated motor current
 - b) When performing motor protection from overheat using a PTC thermistor or motor with temperature detector such as Klixon, set "0" (motor overheat protection by the inverter is invalid) in Pr.9.



- The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is ON, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is ignored.
- The set frequency monitor displayed during the offline auto tuning is 0Hz.
- Changing the terminal assignment using Pr.178 to Pr.184 (input terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.
- The SU and FU signals are not output during a restart. They are output after the restart cushion time has elapsed.
- Automatic restart operation will also be performed after a reset or when a retry is made by the retry function.



Mhen automatic restart after instantaneous power failure has been selected, the motor and machine will start suddenly (after the reset time has elapsed) after occurrence of an instantaneous power failure. Stay away from the motor and machine.

When you have selected automatic restart after instantaneous power failure function, apply in easily visible places the CAUTION stickers supplied to the Installation guideline.

power failure, deceleration starts after Pr. 58 Restart cushion time has elapsed.



Mhen the start signal is turned OFF or (RESET) is pressed during the restart cushion time after instantaneous



Parameters referred to

Pr. 7 Acceleration time, Pr. 21 Acceleration/deceleration time increments ** Refer to page 105

Pr. 13 Starting frequency Refer to page 108

Pr. 65, Pr. 67 to Pr. 69 Retry function Refer to page 166

Pr. 71 Applied motor Refer to page 114

Pr. 78 Reverse rotation prevention selection Refer to page 184


Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

4.13.2 Power-failure deceleration stop function (Pr. 261)

When a power failure or undervoltage occurs, the inverter can be decelerated to a stop or can be decelerated and reaccelerated to the set frequency.

Parameter	Name	Initial	Setting	Description
Number	Name	Value	Range	Description
261	Power failure stop selection	0	0 1 2	Coasts to stop. When undervoltage or power failure occurs, the inverter output is shut off. When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. If power is restored during a power failure, the inverter accelerates again.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



(1) Parameter setting


•When *Pr. 261* is set to "1" or "2", the inverter decelerates to a stop if an undervoltage or power failure occurs.

(2) Operation outline of deceleration to stop at power failure

•When undervoltage or power failure has occurred, the output frequency is decreased and controlled so that the converter circuit (DC bus) voltage is constant and decreased to 0Hz to stop.

(3) Power failure stop function (Pr. 261 = "1")


•If power is restored during power failure deceleration, deceleration to a stop is continued and the inverter remains stopped. To restart, turn OFF the start signal once, then turn it ON again.



Turn OFF STF once to make acceleration again

• REMARKS


- When automatic restart after instantaneous power failure is selected (*Pr.* 57 ≠ "9999"), power failure stop function is invalid and automatic restart operation after instantaneous power failure is valid.
- When the power failure deceleration stop function is active (*Pr. 261* = "1"), the inverter will not start even if the power is turned ON with the start signal (STF/STR) ON. After switching ON the power, turn OFF the start signal once and then ON again to make a start.






(4) Operation continuation at instantaneous power failure function (Pr. 261 = "2")

- •When power is restored during deceleration after a power failure, acceleration is made again up to the set frequency.
- •When this function is used in combination with the automatic restart after instantaneous power failure function(Pr.57 ≠ "9999"), deceleration can be made at a power failure and acceleration can be made again after power restoration.







NOTE

When operation continuation at instantaneous power failure function is used, keep the starting signal (STF/STR) ON even during instantaneous power failure. If the starting signal turns OFF during instantaneous power failure, the inverter decelerates according to the deceleration time setting, causing the motor to coast if enough regenerative energy is not obtained.

(5) Power failure deceleration signal (Y46 signal)

- •The Y46 signal is ON during deceleration at an instantaneous power failure or during a stop after deceleration at an instantaneous power failure.
- •After a power failure stop, the inverter can not start even if power is restored the start command is given. In this case, check the power failure deceleration signal (Y46 signal). (at occurrence of input phase loss (E.ILF), etc.)
- •For the Y46 signal, set "46 (forward operation)" or "146 (reverse operation)" to any of Pr. 190 to Pr. 192 (output terminal function selection) to assign the function.



• REMARKS

During a stop or trip, the power failure stop selection is not performed.



Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Provided the power failure stop function is valid, some loads may cause the inverter to trip and the motor to

The motor will coast if enough regenerative energy is not given from the motor to the inverter.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 158 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

4.14 Operation setting at fault occurrence


Purpose	Parameter th	nat should be Set	Refer to Page
Recover by retry operation at fault	Retry operation	Pr. 65, Pr. 67 to Pr. 69	166
occurrence	itelly operation	11. 00, 11. 07 10 11. 03	100
Do not output input/output phase	Input/output phase failure Pr. 251, Pr. 872		170
failure alarm	protection selection	PI. 231, PI. 0/2	168
Detect an earth (ground) fault at	Earth (ground) fault		168
start	detection at start	F1. 249	108

4.14.1 Retry function (Pr. 65, Pr. 67 to Pr. 69)


If a fault occurs, the inverter resets itself automatically to restart. You can also select the fault for a retry. When you have selected automatic restart after instantaneous power failure ($Pr. 57 Restart coasting time \neq 9999$), restart operation is performed at the retry operation time which is the same of that of a power failure. (Refer to page 158 for the restart function.)

Parameter	Name	Initial	Setting	Description
Number	Name	Value Range		Description
65	Retry selection	0	0 to 5	A fault for retry can be selected. (Refer to the next page)
			0	No retry function
			1 to 10	Set the number of retries at fault occurrence.
67	Number of retries at fault	0		A fault output is not provided during retry operation.
67	occurrence	U		Set the number of retries at fault occurrence. (The setting
				value of minus 100 is the number of retries.)
				A fault output is provided during retry operation.
68	Potry waiting time	10	0.1 to 360s	Set the waiting time from when an inverter fault occurs
30	Retry waiting time	1s	0.1 (0.3608	until a retry is made.
69	Retry count display erase	0	0	Clear the number of restarts succeeded by retry.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



Retry failure example



- Retry operation automatically resets a fault and restarts the inverter at the starting frequency when the time set in Pr. 68 elapses after the inverter is tripped.
- Retry operation is performed by setting *Pr.* 67 to any value other than "0". Set the number of retries at fault occurrence in *Pr.* 67.
- When retries fail consecutively more than the number of times set in Pr. 67, a retry count excess fault (E.RET) occurs, resulting in inverter trip. (Refer to retry failure example)
- Use *Pr.* 68 to set the waiting time from when the inverter trips until a retry is made in the range 0.1 to 360s.
- Reading the *Pr. 69* value provides the cumulative number of successful restart times made by retry.

The cumulative count in *Pr.* 69 is increased by 1 when a retry is regarded as successful after normal operation continues without faults occurring for more than four times longer than the time set in *Pr.* 68 after a retry start.

(When retry is successful, cumulative number of retry failure is cleared.)

- Writing "0" to Pr. 69 clears the cumulative count.
- During a retry, the Y64 signal is ON. For the Y64 signal, assign the function by setting "64 (positive operation)" or "164 (negative operation)" to any of *Pr. 190 to Pr. 192 (output terminal function selection)*.



- Using *Pr.* 65, you can select the fault that will cause a retry to be executed. No retry will be made for the fault not indicated. (*Refer to page 280* for the fault description.)
 - indicates the faults selected for retry.

Fault for	Pr. 65 Setting					
Retry	0	1	2	3	4	5
E.OC1	•	•		•	•	•
E.OC2	•	•		•	•	
E.OC3	•	•		•	•	•
E.OV1	•		•	•	•	
E.OV2	•		•	•	•	
E.OV3	•		•	•	•	
E.THM	•					
E.THT	•					
E. BE	•				•	
E. GF	•				•	

Fault for	Pr. 65 Setting					
Retry	0	1	2	3	4	5
E.USB	•				•	
E.OHT	•					
E.OLT	•				•	
E.OPT	•				•	
E.OP1	•				•	
E. PE	•				•	
E.MB4	•				•	
E.MB5	•				•	
E.MB6	•				•	
E.MB7	•				•	
E.ILF	•				•	



NOTE

- When terminal assignment is changed using *Pr.190 to Pr.192*, the other functions may be affected. Set parameters after confirming the function of each terminal.
- . The data stored as the error reset for retry is only that of the fault which occurred the first time.
- When an inverter fault is reset by the retry function at the retry time, the accumulated data of the electronic thermal relay function, regeneration brake duty etc. are not cleared. (Different from the power-ON reset.)
- Retry is not performed if E.PE (Parameter storage device fault) occurred at power ON.
- If a fault that is not selected for a retry occurs during retry operation (retry waiting time), the retry operation stops while the fault indication is still displayed.



Mhen you have selected the retry function, stay away from the motor and machine when the inverter is tripped. They will start suddenly (after the reset time has elapsed) after the inverter trip.

When you have selected the retry function, apply in easily visible places the CAUTION stickers supplied.



Parameters referred to

Pr. 57 Restart coasting time (Refer to page 158)

4.14.2 Input/output phase loss protection selection (Pr. 251, Pr. 872)

You can choose whether to make Input/output phase loss protection valid or invalid.

- Output phase loss protection is a function to stop the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) is lost.
- Input phase loss protection is a function to stop the inverter output if one of the three phases (R/L1, S/L2, T/L3) on the inverter's input side is lost.

Parameter Number	Name	Initial Value	Setting Range	Description
254	Output phase loss	4	0	Without output phase loss protection
251	protection selection	1	1	With output phase loss protection
070	Input phase loss protection	1	0	Without input phase loss protection
872 *	selection		1	With input phase loss protection

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Output phase loss protection selection (Pr. 251)

- If phase loss occurs during inverter running (except for during DC brake operation, or output frequency is 1Hz or less), output phase loss protection (E.LF) activates, and inverter trips.
- When Pr. 251 is set to "0", output phase loss protection (E.LF) becomes invalid.

(2) Input phase loss protection selection (Pr. 872)

• When *Pr.* 872 is set to "1", input phase loss protection (E.ILF) is provided if a phase loss of one phase among the three phases is detected for 1s continuously.



NOTE

- If an input phase loss continues for a long time, the converter section and capacitor lives of the inverter will be shorter.
- If the load is light or during a stop, lost phase cannot be detected because detection is performed based on the fluctuation of bus voltage. Large unbalanced phase-to-phase voltage of the three-phase power supply may also cause input phase loss protection (E.ILF).
- Phase loss can not be detected during regeneration load operation.
- If parameter copy is performed from single-phase power input model to three-phase power input model, *Pr. 872* setting may be changed. Check *Pr. 872* setting after parameter copy.

4.14.3 Earth (ground) fault detection at start (Pr. 249)

You can choose whether to make earth (ground) fault detection at start valid or invalid. Earth (Ground) fault detection is executed only right after the start signal is input to the inverter.

Protective function will not activate if an earth (ground) fault occurs during operation.

Parameter Number	Name	Initial Value	Setting Range	Description
240	Earth (ground) fault	I 1 F	0	Without earth (ground) fault detection
249	detection at start		1	With earth (ground) fault detection

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



NOTE

- As detection is executed at start, output is delayed for approx. 20ms every start.
- If an earth (ground) fault is detected with "1" set in *Pr. 249*, output side earth (ground) fault overcurrent (E.GF) is detected and the inverter trips. (*Refer to page 287*)
- If the motor capacity is smaller than the inverter capacity of the FR-E740-120(SC) or more, earth (ground) fault detection may not be provided.

^{*} Available only for the three-phase power input model.



4.15 Energy saving operation

Purpose	Parameter th	Parameter that should be Set			
Energy saving operation	Optimum excitation control	Pr. 60	169		

Optimum excitation control (Pr. 60)

Without a fine parameter setting, the inverter automatically performs energy saving operation. This operation is optimum for fan and pump applications

Parameter Number	Name	Initial Value	Setting Range	Description
60	Energy saving control	•	0	Normal operation mode
60	selection *	U	9	Optimum excitation control mode

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

- * When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.
- When "9" is set in Pr. 60, the inverter operates in the Optimum excitation control mode.
- · The Optimum excitation control mode is a control system which controls excitation current to improve the motor efficiency to maximum and determines output voltage as an energy saving method.



(I) REMARKS

• When the motor capacity is too small as compared to the inverter capacity or two or more motors are connected to one inverter, the energy saving effect is not expected.



- When the Optimum excitation control mode is selected, deceleration time may be longer than the setting value. Since overvoltage alarm tends to occur as compared to the constant-torque load characteristics, set a longer deceleration
- Optimum excitation control functions only under V/F control. Optimum excitation control does not function under Advanced magnetic flux vector control and General-purpose magnetic flux vector control.
- Optimum excitation control will not be performed during an automatic restart after instantaneous power failure.
- · Since output voltage is controlled by Optimum excitation control, output current may slightly increase.



Parameters referred to

Advanced magnetic flux vector control Tel Refer to page 82 General-purpose magnetic flux vector control 👺 Refer to page 85 Pr. 57 Restart coasting time Refer to page 158

4.16 Motor noise, EMI measures, mechanical resonance

Purpose of Use	Parameter that	Refer to Page	
Reduction of the motor noise Measures against EMI and leakage currents	Carrier frequency and Soft-PWM selection	Pr. 72, Pr. 240	170
Reduce mechanical resonance	Speed smoothing control	Pr. 653	171

4.16.1 PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240)

You can change the motor sound.

Parameter Number	Name	Initial Value	Setting Range	Description
72	PWM frequency selection	1	0 to 15	You can change the PWM carrier frequency. The setting is in [kHz]. Note that 0 indicates 0.7kHz and 15 indicates 14.5kHz.
240	Soft-PWM operation	4	0	Soft-PWM is invalid
240	selection	'	1	When $Pr. 72 = "0 to 5"$, soft-PWM is valid.

The above parameters can be set when Pr.160 User group read selection = "0". (Refer to page 184)

(1) PWM carrier frequency changing (Pr. 72)

- •You can change the PWM carrier frequency of the inverter.
- •Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or motor or on EMI measures or on leakage current reduction caused by the PWM switching.

(2) Soft-PWM control (Pr. 240)

•Soft-PWM control is a control method that changes the motor noise from a metallic tone into an unoffending complex tone.



NOTE

- Decreasing the PWM carrier frequency effect on EMI measures and on leakage current reduction, but increases motor noise.
- When PWM carrier frequency is set to 1kHz or less ($Pr.72 \le 1$), fast response current limit may function prior to stall prevention operation due to increase in ripple currents, resulting in insufficient torque. In such case, set fast-response current limit operation invalid using Pr. 156 Stall prevention operation selection.
- When setting 2kHz or more in *Pr. 72* to perform operation in the place where the surrounding air temperature exceeding 40°C, caution should be taken as the rated inverter current should be reduced. (*Refer to page 314*)



Parameters referred to

Pr. 156 Stall prevention operation selection 👺 Refer to page 88

The above parameters allow their settings to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.




4.16.2 Speed smoothing control (Pr. 653)

Vibration due to mechanical resonance influences the inverter control, causing the output current (torque) unstable. In this case, the output current (torque) fluctuation can be reduced to ease vibration by changing the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
653	Speed smoothing control	0	0 to 200%	Increase or decrease the value using 100% as reference to check an effect.

The above parameters can be set when Pr. 160 User group read selection = "0".(Refer to page 184)

(1) Control block diagram



(2) Setting method

If vibration due to mechanical resonance occurs, set 100% in *Pr. 653*, run the inverter at the frequency which generates maximum vibration and check if the vibration will be reduced or not after several seconds.

If effect is not produced, gradually increase the Pr. 653 setting and check the effect repeatedly until the most effective value is set in Pr. 653.

If vibration becomes large by increasing the Pr. 653 setting, gradually decrease the Pr. 653 setting than 100% to check the effect in a similar manner.



NOTE

Depending on the machine, vibration may not be reduced enough or an effect may not be produced.

4.17 Frequency setting by analog input (terminal 2, 4)

Purpose	Parameter that	Refer to Page	
Selection of voltage/current input (terminal 2, 4) Perform forward/reverse rotation by analog input.	Analog input selection	Pr. 73, Pr. 267	172
Adjustment (calibration) of analog input frequency and voltage (current)	Bias and gain of frequency setting voltage (current)	Pr. 125, Pr. 126, Pr. 241, C2 to C7 (Pr. 902 to Pr. 905)	175

4.17.1 Analog input selection (Pr. 73, Pr. 267)

You can select the function that switches between forward rotation and reverse rotation according to the analog input terminal specifications and input signal.

Parameter	Name	Initial	Setting	Description				
Number	Name	Value	Range	Description				
			0	Terminal 2 input 0 to 10V	Terminal 2 input 0 to 10V			
73	Analog input	1	1	Terminal 2 input 0 to 5V		operation		
73	selection	'	10	Terminal 2 input 0 to 10V		With reversible		
			11	Terminal 2 input 0 to 5V		operation		
	Voltage/current input switch		nt input switch					
				Standard control	Safety stop function	Description		
				circuit terminal model	model			
267	Terminal 4 input selection	0	0	I v	VI	Terminal 4 input 4 to 20mA		
			1		VI	Terminal 4 input 0 to 5V		
			2	I V		Terminal 4 input 0 to 10V		


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Selection of analog input specifications

- •For the terminal 2 for analog voltage input, 0 to 5V (initial value) or 0 to 10V can be selected.
- Either voltage input (0 to 5V, 0 to 10V) or current input (4 to 20mA initial value) can be selected for terminal 4 used for analog input.

Change the input specifications to change Pr. 267 and voltage/current input switch.

- Rated specifications of terminal 4 change according to the voltage/current input switch setting.
- Voltage input: Input resistance $10k\Omega \pm 1k\Omega$, maximum permissible input voltage 20VDC
- Current input: Input resistance 233 $\!\Omega\pm5\Omega\!,$ maximum permissible input voltage 30mA







NOTE

Set *Pr. 267* and a voltage/current input switch correctly, then input an analog signal in accordance with the setting. Incorrect setting as in the table below could cause component damage. Incorrect settings other than below can cause abnormal operation.

Setting Causing Con	nponent Damage	Operation
Switch setting	Terminal input	Operation
I (current input)	Voltage input	This could cause component damage to the analog signal output circuit of signal output devices. (electrical load in the analog signal output circuit of signal output devices increases)
V (voltage input)	Current input	This could cause component damage of the inverter signal input circuit. (output power in the analog signal output circuit of signal output devices increases)

•Refer to the following table and set Pr. 73 and Pr. 267.

indicates main speed setting)

Pr. 73	Terminal 2	Termin	Reversible	
Setting	Input	AU signal		Operation
0	0 to 10V			
1 (initial value)	0 to 5V	OFF	_	Not function
10	0 to 10V			Yes
11	0 to 5V			
0 1 (initial value)		ON	According to the <i>Pr. 267</i> setting 0:4 to 20mA (initial value)	Not function
10 11			1:0 to 5V 2:0 to 10V	Yes


-: invalid

•The terminal used for the AU signal input, set "4" in Pr. 178 to Pr. 184 (input terminal function selection) to assign functions.




NOTE

- Turn the AU signal ON to make terminal 4 valid.
- Make sure that the parameter and switch settings are the same. Different setting may cause a fault, failure or malfunction.
- Use *Pr. 125 (Pr. 126) (frequency setting gain)* to change the maximum output frequency at input of the maximum output frequency command voltage (current). At this time, the command voltage (current) need not be input.
 - Also, the acceleration/deceleration time, which is a slope up/down to the acceleration/deceleration reference frequency, is not affected by the change in Pr. 73 setting.
- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Connection diagram using terminal 2 (0 to 5VDC)



Connection diagram using terminal 2 (0 to 10VDC)

(2) Perform operation by analog input selection.

- •The frequency setting signal inputs 0 to 5VDC (or 0 to 10VDC) to across the terminals 2-5. The 5V (10V) input is the maximum output.
- •The power supply 5V can be input by either using the internal power supply or preparing an external power supply. Prepare an external power supply to input the power supply 10V. For the built-in power supply, terminals 10-5 provide 5VDC output.


Terminal	Inverter Built-in	Frequency	Pr.73
	Power Supply	Setting	(terminal 2 input
	Voltage	Resolution	power)
10	5VDC	0.1Hz/50Hz	0 to 5VDC input

- •When inputting 10VDC to the terminal 2, set "0" or "10" in *Pr. 73*. (The initial value is 0 to 5V)
- •Setting "1 (0 to 5VDC)" or "2 (0 to 10VDC)" in *Pr. 267* and a voltage/current input switch in the OFF position changes the terminal 4 to the voltage input specification. When the AU signal turns ON, the terminal 4 input becomes valid.



REMARKS


The wiring length of the terminal 10, 2, 5 should be 30m maximum.



(3) Perform operation by analog input selection.

- •When the pressure or temperature is controlled constant by a fan, pump, etc., automatic operation can be performed by inputting the output signal 4 to 20mADC of the adjuster to across the terminals 4-5.
- •The AU signal must be turned ON to use the terminal 4.

Connection diagram using terminal 4 (4 to 20mADC)



Perform forward/reverse rotation by analog input (polarity reversible operation)

•Setting "10" or "11" in *Pr. 73* and adjusting *Pr. 125* (*Pr. 126*) *Terminal 2* frequency setting gain frequency (Terminal 4 frequency setting gain frequency) and *C2* (*Pr. 902*) *Terminal 2 frequency setting bias frequency* to *C7* (*Pr.905*) *Terminal 4 frequency setting gain* makes reverse operation by terminal 2 (terminal 4) valid.

Example)When performing reversible operation by terminal 2 (0 to 5V) input

- 1) Set "11" in *Pr. 73* to make reversible operation valid. Set frequency at maximum analog input in *Pr. 125 (Pr. 903)*
- 2) Set 1/2 of the value set in C4 (Pr. 903) in C3 (Pr. 902).
- 3) Reversible operation is performed when 0 to 2.5VDC is input and forward rotation when 2.5 to 5VDC.



NOTE

- When reversible operation is set, be aware of reverse rotation operation when analog input stops (only the start signal is input).
- When reversible operation is valid, reversible operation (0 to 4mA: reverse operation, 4mA to 20mA: forward operation) is performed by terminal 4 in the initial setting.



Parameters referred to

Pr. 125 Terminal 2 frequency setting gain frequency, Pr. 126 Terminal 4 frequency setting gain frequency frequency setting gain frequency freque

4.17.2 Response level of analog input and noise elimination (Pr. 74)

The time constant of the primary delay filter can be set for the external frequency command (analog input (terminal 2, 4) signal).

Parameter Number	Name	Initial Value	Setting Range	Description
74	Input filter time constant	1	0 to 8	Primary delay filter time constant for the analog input.
				A larger setting results in a larger filter.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

- Valid for eliminating noise of the frequency setting circuit.
- Increase the filter time constant if steady operation cannot be performed due to noise.
 A larger setting results in slower response. (The time constant can be set between approximately 5ms to 1s with the setting of 0 to 8.)



4.17.3 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))

You can set the magnitude (slope) of the output frequency as desired in relation to the frequency setting signal (0 to 5V, 0 to 10V or 4 to 20mADC).

Set *Pr. 267* and voltage/current input switch to switch between 0 to 5VDC, 0 to 10VDC, 0 to 20mADC using terminal 4. (*Refer to page 172*)


[Frequency setting bias/gain parameter]


Parameter	Name	Initial	Setting		Description
Number	Name	Value	Range	2000.iipao.ii	
125	Terminal 2 frequency setting	50Hz	0 to 400Hz	Frequency of terminal 2 input gain (maximum).	
123	gain frequency	30112	0 10 400112	r requericy or termina	a z input gain (maximum).
126	Terminal 4 frequency setting	50Hz	0 to 400Hz	Frequency of termina	al 4 input gain (maximum).
120	gain frequency	30112	0 10 400112	r requeries or termina	i + input gain (maximum).
244 +1 +2	Analog input display unit	0	0	Displayed in %	Unit for analog input display
241 *1, *3	switchover	0	1	Displayed in V/mA	Unit for analog input display.
C2 (902)	Terminal 2 frequency setting	0Hz	0 to 400Hz	Frequency on the bias side of terminal 2 input.	
*1, *2	bias frequency	0112	0 10 400112		
C3 (902)	Terminal 2 frequency setting	0%	0 to 300%	Converted % of the bias side voltage of terminal 2 input.	
*1, *2	bias	0 70	0 10 300 /0		
C4 (903)	Terminal 2 frequency setting	100%	0 to 300%	Converted % of the gain side voltage of terminal 2	
*1, *2	gain	100 /0	0 10 300 %	input.	
C5 (904)	Terminal 4 frequency setting	0Hz	0 to 400Hz	Frequency on the hi	iss side of terminal 4 input
*1, *2	bias frequency	0112	0 10 400112	Frequency on the bias side of terminal 4 input.	
C6 (904)	Terminal 4 frequency setting	20%	0 to 300%	Converted % of the bias side current (voltage) of	
*1, *2	bias	20 /0	0 10 300 /0	terminal 4 input.	
C7 (905)	Terminal 4 frequency setting	100%	0 to 300%	Converted % of the	gain side current (voltage) of
*1, *2	gain	100 /0	0 10 300 /6	terminal 4 input.	

^{*1} This parameter can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

^{*2} The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).

^{*3} This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.





(1) Change the frequency at maximum analog input (Pr. 125, Pr. 126)

•Set *Pr. 125 (Pr. 126)* when changing frequency setting (gain) of the maximum analog input voltage (current) only. (*C2 (Pr. 902)* to *C7 (Pr.905)* setting need not be changed)

(2) Analog input bias/gain calibration (C2 (Pr. 902) to C7 (Pr. 905))

- •The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter to set the output frequency, e.g. 0 to 5V, 0 to 10V or 4 to 20mADC, and the output frequency.
- •Set the bias frequency of the terminal 2 input using *C2 (Pr. 902)*.

(It is initially-set to the frequency at 0V)

- •Set the output frequency in *Pr. 125* for the frequency command voltage set with *Pr. 73 Analog input selection*
- •Set the bias frequency of the terminal 4 input using *C5* (*Pr.* 904).

(It is initially-set to the frequency at 4mA)

- •Using *Pr. 126*, set the output frequency relative to 20mA of the frequency command current (4 to 20mA).
- •There are three methods to adjust the frequency setting voltage (current) bias/gain.
 - a) Method to adjust any point by application of a voltage (current) to across terminals 2-5 (4-5)
 page 177
 - b) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5)

 ## page 178
 - c) Method to adjust frequency only without adjustment of voltage (current) * page 179



NOTE

• When voltage/current input signal for terminal 4 was switched using *Pr. 267* and voltage/current input switch, perform calibration without fail.

(3) Analog input display unit changing (Pr. 241)

- You can change the analog input display unit (%/V/mA) for analog input bias/gain calibration.
- Depending on the terminal input specification set to *Pr.* 73, *Pr.* 267, and voltage/current switch, the display units of *C3 (Pr. 902), C4 (Pr. 903), C6 (Pr. 904), C7 (Pr. 905)* change as shown below.

Analog Command (terminal 2, 4) (depending on <i>Pr. 73, Pr. 267</i> , and voltage/current input switch)	<i>Pr. 241</i> = 0 (initial value)	<i>Pr. 241</i> = 1
0 to 5V input	0 to 5V → 0 to 100% (0.1%) display	0 to 100% → 0 to 5V (0.01V) display
0 to 10V input	0 to 10V → 0 to 100% (0.1%) display	0 to 100% → 0 to 10V (0.01V) display
0 to 20mA input	0 to 20mA → 0 to 100%(0.1%) display	0 to 100% → 0 to 20mA (0.01mA) display

Display -



(4) Frequency setting signal (current) bias/gain adjustment method

(a) Method to adjust any point by application of a voltage (current) to across terminals 2 and 5 (4 and 5).

Operation -

- Confirm the RUN indication and operation mode indication
 - The inverter should be at a stop.
 - The inverter should be in the PU operation mode.

(Using $\frac{PU}{EXT}$)

2. Press (MODE) to choose the parameter setting mode.






(The parameter number read previously appears.)

- 3. Turn until [. . . appears.
- 4. Press (SET) until [- appears.
- 5. Turn until [4 ([7) appears.

Set to C4 Terminal 2 frequency setting gain.



 Apply a 5V (20mA) voltage (current).
 (Turn the external potentiometer connected across terminals 2-5 (across terminals 4-5) to maximum (any position).)




(MODE)



C1 to C7 setting is enabled.

Terminal 2 input is selected







 The value is nearly 100 (%) in the maximum position of the potentiometer.

7

NOTE

After performing operation in step 6, do not touch until completion of calibration.



Terminal 2 input is







Terminal 4 input is selected

Flicker...Parameter setting complete!!

- * The value is nearly 100 (%) in the maximum position of the potentiometer.
- •Turn to read another parameter.
- •Press (SET) to return to the [- indication (step 4).
- •Press (SET) twice to show the next parameter (Pr.LL).

> REMARKS

- If the frequency meter (display meter) connected across the terminals AM-5 does not indicate exactly 50Hz, set the *calibration* parameter C1 AM terminal calibration. (Refer to page 156)
- If the gain and bias of frequency setting voltage (current) are too close, an error (£ 3) may be displayed at setting.

Frequency setting by analog input (terminal 2, 4)

(b) Method to adjust any point without application of a voltage (current) to across terminals 2 and 5 (4 and 5) (To change from 4V (80%) to 5V (100%))

Operation — Display 1. Confirm the RUN indication and operation mode indication • The inverter should be at a stop. • The inverter should be in the PU operation mode. PRM indication is lit. 2. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) 3. Turn (until [. . . 4. Press (SET) until [- - - appears. C1 to C7 setting is enabled. 5. Turn until [4 ([?) appears. Set to C4 Terminal 2 frequency setting gain. Terminal 2 input is Terminal 4 input selected is selected Analog voltage (current) value (%) **6.** Press (SET) to display the analog voltage across terminals 2-5 (across (current) value (%). terminals 4-5) The gain frequency is reached 7. Turn to set gain voltage (%). when the analog voltage (current) 188 "0V(0mA) is 0%, 10V(5V, 20mA) is 100%" value across terminals 2-5 (across terminals 4-5) is 100%. **REMARKS** The current setting at the instant of turning You can not check after performing operation in step 7. Terminal 2 input Terminal 4 input 8. Press(SET) to set. is selected is selected

Flicker...Parameter setting complete!!

(Adjustment completed)

•Turn to read another parameter.

•Press (SET) to return to the [- - - indication (step 4).

•Press (SET) twice to show the next parameter (Pr.[].

• REMARKS

By pressing after step 6, you can confirm the current frequency setting bias/gain setting. You can not check after performing operation in step 7.



(c) Adjusting only the frequency without adjusting the gain voltage (current). (When changing the gain frequency from 50Hz to 40Hz)

Operation –

1. Turn until P. 125 (Pr. 125) or

P. 126 (Pr. 126) appears

- 2. Press (SET) to show the currently set value. (50.00Hz)
- 3. Turn (to change the set value to " \\ [] [] [] ". (40.00Hz)
- 4. Press (SET) to set.

Display -











Terminal 2 input is selected

Terminal 4 input is selected

Flicker...Parameter setting complete!!

5. Mode/monitor check

Press (MODE) twice to choose the monitor/ frequency monitor.

6. Apply a voltage across the inverter terminals 2-5 (across 4-5) and turn on the start command (STF, STR).

Operation starts at 40Hz.







REMARKS

- Changing C4 (Pr. 903) or C7 (Pr. 905) (gain adjustment) value will not change the Pr. 20 value.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the FR-PU04/FR-PU07.
- When setting the value to 120Hz or more, it is necessary to set Pr.~18~High~speed~maximum~frequency to 120Hz or more. (Refer to
- Make the bias frequency setting using the calibration parameter C2 (Pr. 902) or C5 (Pr. 904). (Refer to page 176)



! CAUTION

⚠ Be cautious when setting any value other than "0" as the bias frequency at 0V (0mA). Even if a speed command is not given, merely turning on the start signal will start the motor at the preset frequency.



Parameters referred to

Pr. 20 Acceleration/deceleration reference frequency Refer to page 105 Pr. 73 Analog input selection, Pr. 267 Terminal 4 input selection Refer to page 172
Pr. 79 Operation mode selection Refer to page 190

4.18 Misoperation prevention and parameter setting restriction

Purpose	Parameter that should	l be Set	Refer to Page
Limits reset function Trips when PU is disconnected Stops from PU	Reset selection/disconnected PU detection/PU stop selection	Pr. 75	180
Prevention of parameter rewrite	Parameter write disable selection	Pr. 77	183
Prevention of reverse rotation of the motor	Reverse rotation prevention selection	Pr. 78	184
Displays necessary parameters	Display of applied parameters and user group function	Pr. 160, Pr. 172 to Pr. 174	184
Parameter restriction using password	Password function	Pr. 296, Pr. 297	187
Control of parameter write by communication	EEPROM write selection	Pr. 342	214

4.18.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75)

You can select the reset input acceptance, disconnected PU (FR-PU04/FR-PU07) connector detection function and PU stop function.

Parameter Number	Name	Initial Value	Setting Range	Description
	Reset selection/			For the initial value, reset always enabled,
75	disconnected PU detection/	14	0 to 3, 14 to 17	without disconnected PU detection, and
	PU stop selection			with PU stop function are set.

[•] The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

[•] This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*. Also, if parameter (all) clear is executed, this setting will not return to the initial value.

Pr. 75 Setting	Reset Selection	Disconnected PU Detection	PU Stop Selection
0	Reset input normally enabled	If the PU is disconnected, operation	
1	Reset input is enabled only when the fault occurs.	will be continued.	Pressing (STOP) decelerates the motor
2	Reset input normally enabled	When the PU is disconnected, the	to a stop only in the PU operation
3	Reset input is enabled only when the fault occurs.	inverter trips.	mode.
14 (initial value)	Reset input normally enabled	If the PU is disconnected, operation	
15	Reset input is enabled only when the fault occurs.	will be continued.	Pressing (STOP) decelerates the motor
16	Reset input normally enabled	When the PU is disconnected, the	to a stop in any of the PU, External and Network operation modes.
17	Reset input is enabled only when the fault occurs.	inverter trips.	and Network operation modes.

(1) Reset selection

- •You can select the enable condition of reset function (RES signal, reset command through communication) input.
- •When Pr. 75 is set to any of "1, 3, 15, 17", a reset can be input only when the inverter is tripped.

NOTE

- When the reset signal (RES) is input during operation, the motor coasts since the inverter being reset shuts off the output.
- When reset is performed, cumulative values of electronic thermal O/L relay, regenerative brake duty are cleared.
- The reset key of the PU is only valid when the inverter is tripped, independently of the Pr. 75 setting.



(2) Disconnected PU detection

- •This function detects that the PU (FR-PU04/FR-PU07) has been disconnected from the inverter for longer than 1s and causes the inverter to provide a fault output (E.PUE) and come to trip.
- •When Pr. 75 is set to any of "0, 1, 14, 15", operation is continued if the PU is disconnected.

REMARKS

- When the PU has been disconnected since before power-ON, it is not judged as a fault.
- To make a restart, confirm that the PU is connected and then reset the inverter.
- The motor decelerates to a stop when the PU is disconnected during PU Jog operation with Pr. 75 set to any of "0, 1, 14, 15" (which selects operation is continued if the PU is disconnected).
- When RS-485 communication operation is performed through the PU connector, the reset selection/PU stop selection function is valid but the disconnected PU detection function is invalid.

(3) PU stop selection

- •In any of the PU operation, External operation and Network operation modes, the motor can be stopped by pressing STOP key of the operation panel or parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)).
- •When the inverter is stopped by the PU stop function, " 🗗 🚍 " (PS) is displayed. A fault output is not provided.
- •After the motor is stopped from the PU, it is necessary to perform PU stop (PS) reset to restart. PS reset can be made from the unit from which PU stop is made (operation panel, parameter unit (FR-PU04/PU07, operation panel for FR-E500 (PA02)).
- The motor can be restarted by making PS cancel using a power supply reset or RES signal.
- •When Pr. 75 is set to any of "0 to 3", PU stop (PS display) is invalid, deceleration to a stop by (STOP) is valid only in the PU operation mode.




(I) REMARKS

During operation in the PU operation mode through USB communication or RS-485 communication from the PU connector, the motor decelerates to stop (PU stop) when entered from the operation panel $\frac{(STOP)}{RESET}$

(PS) reset method)



(4) How to restart the motor stopped by (STOP) input from the PU in External operation mode (PU stop



a) Operation panel

- 1)After completion of deceleration to a stop, switch OFF the STF or STR signal.
- 2)Press (PU) to display PU(P 5 reset)
- 3)Press $\frac{PU}{EXT}$ to return to \boxed{EXT} .
- 4)Switch ON the STF or STR signal.

b) Parameter unit (FR-PU04/FR-PU07)

- 1)After completion of deceleration to a stop, switch OFF the STF or STR signal.
- 2)Press EXT(**P** 5 reset)
- 3)Switch ON the STF or STR signal.
- •The motor can be restarted by making a reset using a power supply reset or RES signal.

• REMARKS

If Pr. 250 Stop selection is set to other than "9999" to select coasting to a stop, the motor will not be coasted to a stop but decelerated to a stop by the PU stop function during external operation.

(5) Restart (PS reset) method when PU stop (PS display) is made during PU operation

•PU stop (PS display) is made when the motor is stopped from the unit where control command source is not selected (operation panel, parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)) in the PU operation mode. For example, when *Pr. 551 PU mode operation command source selection* = "9999" (initial value), the motor is stopped from

the PU (PS display) if entered from the operation panel (RESET) in PU operation mode with the parameter unit mounted.

When the motor is stopped from the PU when the parameter unit (FR-PU04/FR-PU07) is selected as control command source.

- 1) After the motor has decelerated to a stop, press (STOP) of the parameter unit (FR-PU04/FR-PU07).
- 2) Press $\frac{\text{PU}}{\text{EXT}}$ to display $\boxed{\text{EXI}}$.($\begin{subarray}{c} \begin{subarray}{c} \begin{sub$
- 3) Press PU of the parameter unit (FR-PU04/FR-PU07) to select the PU operation mode.
- 4) Press FWD or REV of the parameter unit (FR-PU04/FR-PU07).

(I) REMARKS

When Pr. 551 = "9999", the priorities of the PU command source is USB connector > parameter unit (FR-PU04/FR-PU07) > operation panel.

⚠ CAUTION

not reset the inverter while the start signal is being input.

Otherwise, the motor will start instantly after resetting, leading to potentially hazardous conditions.

Parameters referred to

Pr. 250 Stop selection Refer to page 128

Pr. 551 PU mode operation command source selection Refer to page 201



4.18.2 Parameter write disable selection (Pr. 77)

You can select whether write to various parameters can be performed or not. Use this function to prevent parameter values from being rewritten by misoperation.

Parameter Number	Name	Initial Value	Setting Range	Description
	Parameter write selection	0	0	Write is enabled only during a stop.
77			1	Parameter can not be written.
(Ver.UP)			2	Parameter write is enabled in any operation
				mode regardless of operation status.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

Pr. 77 can be always set independently of the operation mode and operation status.

(1) Write parameters only during stop (setting "0" initial value)

- •Parameters can be written only during a stop in the PU operation mode.
- •The shaded parameters in the parameter list (page 58) can always be written regardless of the operation mode and operating status. However, Pr. 72 PWM frequency selection, Pr. 240 Soft-PWM operation selection, and Pr. 275 Stop-on contact excitation current low-speed multiplying factor can be written when the inverter is running in the PU operation mode, but cannot be written in the External operation mode.

(2) Inhibit parameter write (setting "1")

- Parameter write is not enabled.(Read is enabled.)
- Parameter clear and all parameter clear cannot be performed, either.
- •The parameters given on the right can be written if Pr. 77 = "1".

	Parameter Number	Name
	Nullibei	
е	22	Stall prevention operation level
	75	Reset selection/disconnected PU detection/
=	73	PU stop selection
	77	Parameter write selection
	79	Operation mode selection
	160	User group read selection
	296	Password lock level
	297	Password lock/unlock

(3) Write parameters during operation (setting "2")

- •Parameters can always be written.
- •The following prameters cannot be written when the inverter is running if Pr. 77 = "2". Stop the inverter when changing their parameter settings.

Parameter	Name			
Number	Name			
23	Stall prevention operation level compensation			
25	factor at double speed			
40	RUN key rotation direction selection			
48	Second stall prevention operation current			
60	Energy saving control selection			
61	Reference current			
66	Stall prevention operation reduction starting			
00	frequency			
71	Applied motor			
79	Operation mode selection			
80	Motor capacity			
81	Number of motor poles			
82	Motor excitation current			
83	Rated motor voltage			
84 Rated motor frequency				
90 to 94	(Motor constants)			

Parameter	Name				
Number	Name				
96	Auto tuning setting/status				
178 to 184	(input terminal function selection)				
190 to 192	(output terminal function selection)				
277	Stall prevention operation current switchover				
292	Automatic acceleration/deceleration				
293	Acceleration/deceleration separate selection				
298	Frequency search gain				
329	Digital input unit selection				
329	(Parameter for the plug-in option FR-A7AX E kit)				
450	Second applied motor				
541	Frequency command sign selection (CC-Link)				
341	(Parameter for the plug-in option FR-A7NC E kit)				
800	Control method selection				
859	Torque current				



Parameters referred to

Pr. 79 Operation mode selection 🕼 Refer to page 190

4.18.3 Reverse rotation prevention selection (Pr. 78)

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Parameter Number	Name	Initial Value	Setting Range	Description
78	Reverse rotation prevention selection	0	0	Both forward and reverse rotations allowed
			1	Reverse rotation disabled
			2	Forward rotation disabled

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

- · Set this parameter when you want to limit the motor rotation to only one direction.
- This parameter is valid for all of the reverse rotation and forward rotation keys of the operation panel and parameter unit(FR-PU04/FR-PU07), the start signals (STF, STR signals) via external terminals, and the forward and reverse rotation commands through communication.

4.18.4 Extended parameter display and user group function (Pr. 160, Pr. 172 to Pr. 174)

Parameter which can be read from the operation panel and parameter unit can be restricted.

Parameter Number	Name	Initial Value	Setting Range	Description
			9999	Displays only the simple mode parameters
160 *3	User group read selection	0	0	Displays simple mode + extended parameters
100 *3			1	Displays the parameters registered in the user group.
172 *1	User group registered display/batch clear	0	(0 to 16)	Displays the number of cases registered as a user group (reading only)
			9999	Batch clear the user group registration
173 *1, *2	User group registration	9999	0 to 999, 9999	Sets the parameter numbers to be registered to the user group
174 *1, *2	User group clear	9999	0 to 999, 9999	Sets the parameter numbers to be cleared from the user group

- *1 The above parameters can be set when Pr. 160 User group read selection = "0".
- *2 The values read from Pr. 173 and Pr. 174 are always "9999".
- *3 This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

(1) Display of simple mode parameters and extended parameters (Pr. 160)

- •When Pr. 160 = "9999", only the simple mode parameters can be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). (Refer to the parameter list, page 58, for the simple mode parameters.)
- •In the initial setting (Pr. 160 = "0") status, simple mode parameters and extended parameters can be displayed.

• REMARKS

- · When a plug-in option is fitted to the inverter, the option parameters can also be read.
- When communication is used to read the parameters, all parameters can be read, regardless of the Pr. 160 setting
- When RS-485 communication is used to read the parameters, all parameters can be read, regardless of the Pr. 550 NET mode operation command source selection, Pr. 551 PU mode operation command source selection, regardless of Pr. 160 setting.

Pr. 551	Pr. 550	Pr. 160 Valid/Invalid	
2 (PU)	-	Valid	
	0 (OP)	Valid	
3 (USB)	2 (PU)	Invalid (all parameters	
9999	2 (FU)	can be read)	
(auto detect initial		With OP: valid	
value)	9999 (auto detect initial	Without OP: invalid	
	value)	(all parameters can be	
	,	read)	

^{*} OP indicates a communication option.

• Pr. 15 Jog frequency, Pr. 16 Jog acceleration/deceleration time, and Pr. 991 PU contrast adjustment are displayed as simple mode parameter when the parameter unit (FR-PU04/FR-PU07) is fitted.




(2) User group function (Pr. 160, Pr. 172 to Pr. 174)

- •The user group function is designed to display only the parameters necessary for setting.
- •From among all parameters, 16 parameters maximum can be registered in the user group. When Pr. 160 is set to "1", only the parameters registered to the user group can be accessed. (The parameters not registered in the user group can not be read.)
- •To set a parameter in the user group, set its parameter number in Pr. 173.
- •To delete a parameter from the user group, set its parameter number to Pr. 174. Set "9999" in Pr. 172 to batch delete parameters registered.

(3) Registration of parameter to user group (Pr. 173)

When registering Pr. 3 to user group



(4) Deletion of parameter from user group (Pr. 174)

When deleting Pr. 3 from user group

Operation -

- Display
- 1. Confirm the operation display and operation mode display.
 - The inverter should be at a stop.
 - The inverter should be in the PU operation mode.

 $(Press(\frac{PU}{FYT}))$ in the External operation mode.)

- 2. Press (MODE) to choose the parameter setting mode.
- 3. Turn until P 174 appears.
- **4.** Press (SET) to display " 9999"
- 5. Turn until Pr. 3 appears.
- To continue parameter clear, repeat steps 3 to











Flicker...Clear of *Pr. 3* to user group completed!!

(I) REMARKS

6. Press (SET) to set.

- Pr. 77, Pr. 160 and Pr. 991 can always be read, independently of the user group setting.
- Pr. 77, Pr. 160 and Pr. 172 to Pr. 174 cannot be registered to the user group.
- When *Pr. 174* is read, "9999" is always displayed. Although "9999" can be written, no function is available.
 When any value other than "9999" is set to *Pr. 172*, no function is available.

Parameters referred to

Pr. 550 NET mode operation command source selection Refer to page 201 Pr. 551 PU mode operation command source selection Refer to page 201



4.18.5 Password function (Pr. 296, Pr. 297)

Registering 4-digit password can restrict parameter reading/writing.

Parameter Number	Name	Initial Value	Setting Range	Description
296 *1	Password lock level	9999	0 to 6, 99, 100 to 106, 199	Select restriction level of parameter reading/ writing when a password is registered.
(Ver.UP)			9999	No password lock
	Password lock/unlock	9999	1000 to 9998	Register a 4-digit password
297 *2			(0 to 5) *3	Displays password unlock error count. (Reading only) (Valid when <i>Pr. 296</i> = "100" to "106")
			9999 *3	No password lock

The above parameters allow their settings to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

- *1 This parameter can be set when Pr. 160 User group read selection = "0."
- *2 If Pr. 296 = "9999" (no password lock), Pr. 297 can be set while Pr. 160 = "0." When the password lock is valid, Pr. 297 can be set regardless of the Pr. 160 setting.
- *3 Pr. 297 can be written as "0 or 9999," but the Pr. 297 setting does not change.

Ver. UPSpecifications differ according to the date assembled. Refer to page 324 to check the SERIAL number.

(1) Parameter reading/writing restriction level (Pr. 296)

•Level of reading/writing restriction by PU/NET mode operation command can be selected by Pr. 296.

	PU Mode Operation Command *3		NET Mode Operation Command *4				
Pr. 296 Setting			RS-485 communication		Communication option		
	Read *1	Write *2	Read	Write *2	Read	Write *2	
9999	0	0	0	0	0	0	
0, 100 *6	×	×	×	×	×	×	
1, 101	0	×	0	×	0	×	
2, 102	0	×	0	0	0	0	
3, 103	0	0	0	×	0	×	
4, 104	×	×	×	×	0	×	
5, 105	×	×	0	0	0	0	
6, 106	0	0	×	×	0	×	
99, 199	Only parameters registered in the user group can be read/written.*5 (For the parameters not registered in the user group, same restriction level as "4, 104" applies.)						

O: enabled, x: restricted

- *1 If the parameter reading is restricted by the Pr. 160 setting, those parameters are unavailable for reading even when "O" is indicated.
- *2 If the parameter writing is restricted by the *Pr.* 77 setting, those parameters are unavailable for writing even when "O" is indicated.
- *3 Parameter access from unit where parameter is written in PU operation mode (initially set to operation panel, parameter unit) is restricted. (Refer to page 201 for PU mode operation command source selection)
 - This restricts parameter access from the command source that can write a parameter under Network operation mode (initially RS-485 communication from PU connector or a communication option). (*Refer to page 201* for NET mode command source.)
 - Read/write is enabled only in the simple mode parameters registered in the user group when Pr.160 User group read selection = "9999". Pr.296 and Pr.297 are always read/write enabled whether registered to a user group or not.
- *6 If a communication option is installed, option fault (E.OPT) occurs, and inverter trips. (Refer to page 287.)

(2) Password lock/unlock (Pr.296, Pr.297)

<I ock>

1) Set parameter reading/writing restriction level.(*Pr. 296* ≠ 9999)

Pr.296 Setting Value	Restriction of Password Unlock Error	<i>Pr.297</i> Display	
0 to 6, 99	No restriction	Always 0	
100 to 106, 199	Restricted at fifth error	Displays error count (0 to 5)	

* During [Pr. 296 = any of "100 to 106, 199"], if password unlock error has occurred 5 times, correct password will not unlock the restriction. All parameter clear can unlock the restriction.

(In this case, parameter settings are cleared.)

2) Write a four-digit number (1000 to 9998) in Pr. 297 as a password.

(When Pr. 296 = "9999", Pr. 297 cannot be written.)

When password is registered, parameter reading/writing is restricted with the restriction level set in Pr. 296 until unlocking.

• REMARKS

- After registering a password, a read value of Pr. 297 is always one of "0" to "5".
- When a password restricted parameter is read/written, L [] [] is displayed.
- Even if a password is registered, parameters which the inverter itself writes, such as inverter parts life, are overwritten as
- Even if a password is registered, Pr. 991 PU contrast adjustment can be read/written when a parameter unit (FR-PU04/FR-PU07) is connected.

<Unlock>

There are two ways of unlocking the password.

- Enter a password in Pr. 297.
 - Unlocked when a password is correct. If a password is incorrect, an error occurs and not unlocked.

During [Pr. 296 = any of "100 to 106, 199"], if password unlock error has occurred 5 times, correct password will not unlock the restriction. (During password lock)

Perform all parameter clear.



NOTE

- If the password has been forgotten, perform all parameter clear to unlock the parameter restriction. In that case, other parameters are also cleared.
- Parameter all clear can not be performed during the operation.
- Do not use the FR Configurator when parameter read is restricted (Pr. 296 = any of "0, 4, 5, 99, 100, 104, 105, 199"). FR Configurator may not function properly.



(I) REMARKS

The password unlock method is different for operation panel/FR-PU07, RS-485 communication, and communication option.

	Operation panel/ FR-PU07	RS-485 communication	Communication option
All parameter clear (data format H9966, H55AA)	0	0	0
Parameter clear (data format H9696, H5A5A)	×	×	0

O:Password can be unlocked. x:Password cannot be unlocked.



(3) Parameter operation during password lock/unlock

Parameter operation		Unlo	cked	Password registered	Locked
		Pr. 296 = 9999 Pr. 297 = 9999	<i>Pr. 296</i> ≠ 9999 <i>Pr. 297</i> = 9999	<i>Pr. 296</i> ≠ 9999 <i>Pr. 297</i> = 0 to 4 (Read value)	Pr. 296 = 100 to 106, 199 Pr. 297 = 5 (Read value)
Pr. 296	Read	0 *1	0	0	0
F1. 290	Write	0 *1	0 *1	×	×
Pr. 297	Read	0 *1	0	0	0
F1. 29/	Write	×	0	0	O *3
Performing pa	arameter clear	0	0	× *4	× *4
Performing parameter all clear		0	0	O *2	O *2
Performing parameter copy		0	0	×	×

O: enabled, x: restricted

- Reading/writing is unavailable when there is restriction to reading by the Pr. 160 setting. (Reading is available in NET mode regardless of Pr. 160 setting.)
- *2 Unavailable during the operation.
- Correct password will not unlock the restriction.
- Parameter clear is available only from the communication option.



• REMARKS

- When Pr. 296 = any of "4, 5, 104, 105" (password lock), the setting screen for PU JOG frequency is not displayed in the parameter unit (FR-PU04/FR-PU07).
- During password lock, parameter copy of the parameter unit (FR-PU07) cannot be performed.



Parameters referred to

Pr. 77 Parameter write selection Refer to page 183

Pr. 160 Extended function display selection Refer to page 184

Pr. 550 NET mode operation command source selection Refer to page 201

Pr. 551 PU mode operation command source selection Refer to page 201

$\overline{\gamma}$

4.19 Selection of operation mode and operation location

Purpose	Parameter that should	Refer to Page	
Operation mode selection	Operation mode selection	Pr. 79	190
Started in Network operation mode	Operation mode at power-ON	Pr. 79, Pr. 340	200
	Operation command source and		
Salastian of aparetian lagation	speed command source during	Pr. 338, Pr. 339	201
Selection of operation location	communication operation, selection	Pr. 550, Pr. 551	201
	of operation location		

4.19.1 Operation mode selection (Pr. 79)

Used to select the operation mode of the inverter.

Mode can be changed as desired among operation using external command signals (External operation), operation from the operation panel and PU (FR-PU07/FR-PU04) (PU operation), combined operation of PU operation and External operation (External/PU combined operation), and Network operation (when RS-485 communication or a communication option is used).

Parameter		Initial	Setting			LED Indication
Number	Name	Value	Range	Descr	iption	:Off
Number		Value	ixalige			i :On
			0	Use External/PU switchover mod PU and External operation mode At power on, the inverter is in the		PU operation mode PU External operation mode EXT NET operation mode
			1	Fixed to PU operation mode		PU operation mode
			2	Fixed to External operation mode Operation can be performed by switching between the External and NET operation mode.		External operation mode EXT NET operation mode
			External/PU combined operation	mode 1		
79	Operation mode selection	0	3	Frequency command Operation panel and PU (FR-PU04/FR-PU07) setting or external signal input (multi-speed setting, across terminals 4-5 (valid when AU signal turns ON)).*	Start command External signal input (terminal STF, STR)	
			4	External/PU combined operation	PU EXT	
				Frequency command	Start command	
				External signal input (terminal 2, 4, JOG, multi-speed selection, etc.)	Enter from RUN of the operation panel and FWD and REV of the PU (FR-PU04/FR-PU07)	
				Switchover mode	,	
			6	Switchover between PU operation	on, External operation, and NET	PU operation mode
				operation is available while keep		PU
			7	External operation mode (PU operation Mode) X12 signal ON Operation mode can be switch (output stop during external operation Mode) X12 signal OFF	External operation mode EXT NET operation mode	
				-	ched to the PU operation mode.	


The above parameters can be changed during a stop in any operation mode.

^{*} The priorities of the frequency commands when *Pr.* 79 = "3" are "Multi-speed operation (RL/RM/RH/REX) > PID control (X14) > terminal 4 analog input (AU) > digital input from the operation panel".



(1) Operation mode basics

- The operation mode specifies the source of the start command and the frequency command for the inverter.
- · Basically, there are following operation modes.
 - External operation mode: For inputting start command and frequency command with an external potentiometer and switches which are connected to the control circuit terminal.
 - PU operation mode: For inputting start command and frequency command with the operation panel or parameter unit (FR-PU04 / FR-PU07).
 - Network operation mode (NET operation mode): For inputting start command and frequency command with RS-485 communication through PU connector or communication option.
- The operation mode can be selected from the operation panel or with the communication instruction code.




• REMARKS

- Either "3" or "4" may be set to select the PU/External combined mode. Refer to page 190 for details.
- The stop function (PU stop selection) activated by pressing (STOP) of the operation panel and parameter unit (FR-PU04/FR-PU07) is valid even in other than the PU operation mode in the initial setting.

 (Refer to Pr. 75 Reset selection/disconnected PU detection/PU stop selection (page 180))

(2) Operation mode switching method



• REMARKS

• Refer to the following for switching by the external terminal.

PU operation external interlock signal (X12) Refer to page 196

PU-external operation switch-over signal (X16) Refer to page 197


External-NET operation switchover signal (X65), NET-PU operation switchover signal (X66) Refer to page 198

Pr. 340 Communication startup mode selection Refer to page 200




(3) Operation mode selection flow

In the following flowchart, select the basic parameter setting and terminal connection related to the operation mode.



(4) External operation mode (setting "0" (initial value), "2")



- •Select the External operation mode when the start command and the frequency command are applied from a frequency setting potentiometer, start switch, etc. which are provided externally and connecting them to the control circuit terminals of the inverter.
- •Generally, parameter change cannot be performed from the operation panel in the External operation mode. (Some parameters can be changed. Refer to the detailed description of each parameter.)
- When "0" or "2" is selected for *Pr. 79*, the inverter enters the External operation mode at power-ON. (When using the Network operation mode, refer to *page 200*.)
- When parameter changing is seldom necessary, setting
 "2" fixes the operation mode to the External operation mode.

When frequent parameter changing is necessary, setting "0" (initial value) allows the operation mode to be changed easily to the PU operation mode by pressing

- PU operation mode, always return to the External operation mode.
- The STF and STR signal are used as a start command, and the voltage or current signal to terminal 2, 4, multispeed signal, JOG signal, etc. are used as a frequency command.

(5) PU operation mode (setting "1")




Operation panel




- •Select the PU operation mode when applying start and frequency command by only the key operation of the operation panel (FR-PU04/FR-PU07). Also select the PU operation mode when making communication using the PU connector.
- •When "1" is selected for *Pr. 79*, the inverter enters the PU operation mode at power ON. You cannot change to the other operation mode.
- •The setting dial of the operation panel can be used for setting like a potentiometer. (Refer to Pr. 161 Frequency setting/key lock operation selection (page 269))

(6) PU/External combined operation mode 1 (setting "3")



- •Select the PU/External combined operation mode 1 when applying frequency command from the operation panel or parameter unit (FR-PU04/FR-PU07) and inputting the start command with the external start switch.
- •Select "3" for *Pr. 79*. You cannot change to the other operation mode.
- •When a frequency is applied from the external signal by multi-speed setting, it has a higher priority than the frequency command from the PU. When AU is ON, the command signal to terminal 4 is used.

(7) PU/External combined operation mode 2 (setting "4")



- •Select the PU/External combined operation mode 2 when applying frequency command from the external potentiometer, multi-speed or JOG signal and inputting the start command by key operation of the operation panel or parameter unit (FR-PU04/FR-PU07).
- •Select "4" for *Pr. 79*. You cannot change to the other operation mode.

(8) Switch-over mode (setting "6")

•While continuing operation, you can switch between the PU operation, external operation and network operation (when RS-485 communication with the PU connector or communication option is used).

Operation Mode Switching	Switching Operation/Operating Status
External operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. •Rotation direction is the same as that of External operation. •The frequency set with the potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched OFF or the inverter is reset.)
External operation → NET operation	Send the mode change command to the Network operation mode through communication. •Rotation direction is the same as that of External operation. •The value set with the setting potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched OFF or the inverter is reset.)
PU operation → External operation	Press the external operation key of the operation panel or parameter unit. •The rotation direction is determined by the input signal of the External operation. •The set frequency is determined by the external frequency command signal.
PU operation → NET operation	Send the mode change command to the Network operation mode through communication. •Rotation direction and set frequency are the same as those of PU operation.
NET operation → External operation	Command to change to External mode is transmitted by communication. •Rotation direction is determined by the external operation input signal. •The set frequency is determined by the external frequency command signal.
NET operation → PU operation	Select the PU operation mode with the operation panel or parameter unit. •The rotation direction and frequency command in the Network operation mode are used unchanged.

(9) PU operation interlock (setting "7")

•The PU operation interlock function is designed to forcibly change the operation mode to the External operation mode when the PU operation interlock signal (X12) input turns OFF.

This function prevents the inverter from being inoperative by the external command if the mode is accidentally left unswitched from PU operation mode.

- •Set "7" (PU operation interlock) in Pr. 79.
- •For the terminal used for X12 signal (PU operation interlock signal) input, set "12" to any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function. (*Refer to page 135* for *Pr.178 to Pr.184*.)
- •When the X12 signal is not assigned, function of the MRS signal switches from MRS (output stop) to PU operation interlock signal.

X12 (MRS)	Functio	n/Operation		
Signal	Operation mode	Parameter write		
	Operation mode (External, PU, NET) switching	Parameter write enabled (depending on Pr. 77 Parameter		
ON	enabled	write selection and each parameter write conditions (Refe		
	Output stop during External operation	to page 58 for the parameter list))		
	Forcibly switched to External operation mode			
OFF	External operation allowed	December write disabled with expention of D. 70		
OFF	Switching between the PU and NET operation mode	Parameter write disabled with exception of <i>Pr. 79</i>		
	is enabled			

<Function/operation changed by switching ON-OFF the X12 (MRS) signal>

Operating (Condition		Operation		Switching to PU,
Operation	Status	X12 (MRS) Signal	Mode	Operating Status	NET Operation
mode	Status		Wode		Mode
	During	ON → OFF *1		If external operation frequency setting and	Disallowed
PU/NET	stop	ON 7 OIT *I	External *2	start signal are entered, operation is	Disallowed
	Running	ON → OFF *1		performed in that status.	Disallowed
	During	OFF → ON		During stop	Allowed
External	stop	ON → OFF	External *2	During stop	
External	Running	OFF → ON	External *2	During operation → output stop	Disallowed
	Tariffing	ON → OFF		Output stop → operation	Disallowed

^{*}I The operation mode switches to the External operation mode independently of whether the start signal (STF, STR) is ON or OFF. Therefore, the motor is run in External operation mode when the X12 (MRS) signal is turned OFF with either of STF and STR ON.

*2 At fault occurrence, pressing $(\frac{\text{STOP}}{\text{RESET}})$ of the operation panel resets the inverter.



NOTE

- If the X12 (MRS) signal is ON, the operation mode cannot be switched to the PU operation mode when the start signal (STF, STR) is ON.
- When the MRS signal is used as the PU interlock signal, the MRS signal serves as the normal MRS function (output stop) by turning ON the MRS signal and then changing the *Pr. 79* value to other than "7" in the PU operation mode. As soon as "7" is set to *Pr. 79*, the MRS signal acts as the PU interlock signal.
- When the MRS signal is used as the PU interlock signal, the logic of the signal is as set in Pr. 17. When Pr. 17 = "2", read ON as OFF and OFF as ON in the above explanation.
- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.

(10) Switching of operation mode by external signal (X16 signal)

- •When external operation and operation from the operation panel are used together, use of the PU-External operation switching signal (X16) allows switching between the PU operation mode and External operation mode during a stop (during a motor stop, start command OFF).
- •When Pr. 79 = any of "0, 6, 7", the operation mode can be switched between the PU operation mode and External operation mode. (Pr. 79 = "6" At Switchover mode, operation mode can be changed during operation)
- •For the terminal used for X16 signal input, set "16" to any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.

	Pr. 79	X16 Signal State Operation Mode		Remarks		
	Setting ON (external) OFF (PU)		OFF (PU)	Remarks		
0 (initial value)	External operation mode	PU operation mode	Can be switched to External, PU or NET operation mode		
	1	PU opera	tion mode	Fixed to PU operation mode		
	2	External operation mode		Fixed to External operation mode (can be switched to NET operation mode)		
	3, 4	External/PU combin	ned operation mode	External/PU combined mode fixed		
	6	External operation mode	PU operation mode	Switching among the External, PU, and NET operation mode is enabled while running.		
	X12 (MRS)	External operation	PU operation mode	Can be switched to External, PU or NET operation mode (output stop		
7	ON	mode	FO operation mode	in External operation mode)		
,	X12 (MRS) OFF	External operation mode		Fixed to External operation mode (forcibly switched to External operation mode)		



> REMARKS

- The operation mode status changes depending on the setting of *Pr. 340 Communication startup mode selection* and the ON/OFF status of the X65 and X66 signals. (For details, refer to *page 198*)
- The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > X12 > X66 > X65 > X16 > Pr. 340.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.

(11) Switching of operation mode by external signals (X65, X66 signals)

- When *Pr.* 79 = any of "0, 2, 6", the operation mode switching signals (X65, X66) can be used to change the PU or External operation mode to the Network operation mode during a stop (during a motor stop or start command OFF). (*Pr.* 79 = "6" Switch-over mode can be changed during operation)
- When switching between the Network operation mode and PU operation mode
 - 1)Set Pr. 79 to "0" (initial value) or "6".
 - 2)Set "10" in Pr. 340 Communication startup mode selection.
 - 3)Set "65" in any of Pr. 178 to Pr. 184 to assign the NET-PU operation switching signal (X65) to the terminal.
 - 4)The operation mode changes to the PU operation mode when the X65 signal turns ON, or to the Network operation mode when the X65 signal turns OFF.

Pr. 340	Pr. 79 Setting		X65 Sig	nal State	Remarks	
Setting			ON (PU)	OFF (NET)	Remarks	
	0.0	initial value)	PU operation mode *1	NET operation mode		
	,	initial value)	1 6 operation mode 1	*2		
		1	PU opera	ation mode	Fixed to PU operation mode	
	2		NET oper	ation mode	Fixed to NET operation mode	
		3, 4	External/PU combi	ned operation mode	External/PU combined mode fixed	
10		6	PU operation mode *1	NET operation mode	Operation mode can be switched with operation continued	
		O	To operation mode *1	*2	Operation mode can be switched with operation continued	
		X12 (MRS)	Switching among the External and		Output stan in External appration made	
	7	ON	PU operation me	ode is enabled *2	Output stop in External operation mode	
	/	X12 (MRS)	External on	aration made	Foreibly quitahed to External appration made	
		OFF	External ope	eration mode	Forcibly switched to External operation mode	

- *1 NET operation mode when the X66 signal is ON.
- *2 PU operation mode is selected when the X16 signal is OFF. PU operation mode also when *Pr. 550 NET mode operation command source selection=* "0" (communication option command source) and the communication option is not fitted.

 External operation mode when the X16 signal is ON.
 - •When switching between the Network operation mode and External operation mode
 - 1) Set *Pr.* 79 to "0 (initial value), 2, 6 or 7". (At the *Pr.* 79 setting of "7", the operation mode can be switched when the X12 (MRS) signal turns ON.)
 - 2) Set "0 (initial value) or 1" in Pr. 340 Communication startup mode selection.
 - 3) Set "66" in any of Pr. 178 to Pr. 184 to assign the NET-PU operation switching signal (X66) to the terminal.
 - 4) The operation mode changes to the Network operation mode when the X66 signal turns ON, or to the External operation mode when the X66 signal turns OFF.

Pr. 340		Pr. 79	X66 Sigr	nal State	Remarks
Setting	Setting		ON (NET) OFF (External)		Remarks
	0 ((initial value)	NET operation mode *1	External operation mode *2	
		1	PU operat	tion mode	Fixed to PU operation mode
		2	NET operation mode *1	External operation mode	Cannot be switched to PU operation mode
0 (initial	3, 4		External/PU combined operation mode		External/PU combined mode fixed
value), 1			1 6 1 .		External operation mode *2
	7	X12 (MRS) ON	NET operation mode *1	External operation mode *2	Output stop in External operation mode
	,	X12 (MRS) OFF	External ope	ration mode	Forcibly switched to External operation mode

^{*1} PU operation mode is selected when *Pr. 550 NET mode operation command source selection* = "0" (communication option command source) and the communication option is not fitted.

^{*2} PU operation mode is selected when the X16 signal is OFF. When the X65 signal has been assigned, the operation mode changes with the ON/OFF state of the X65 signal.





• The priorities of *Pr.* 79, *Pr.* 340 and signals are *Pr.* 79 > X12 > X66 > X65 > X16 > *Pr.* 340.



NOTE

• Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 15 Jog frequency Refer to page 100

Pr. 4 to 6, Pr. 24 to 27, Pr. 232 to Pr. 239 Multi-speed operation 👺 Refer to page 98

Pr. 75 Reset selection/disconnected PU detection/PU stop selection Refer to page 180

Pr. 161 Frequency setting/key lock operation selection Refer to page 269

Pr. 178 to Pr. 184 (input terminal function selection) TF Refer to page 135

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

Pr. 340 Communication startup mode selection Refer to page 200

Pr. 550 NET mode operation command source selection Refer to page 201

4.19.2 Operation mode at power-ON (Pr. 79, Pr. 340)

When power is switched ON or when power comes back on after instantaneous power failure, the inverter can be started up in the Network operation mode.

After the inverter has started up in the Network operation mode, parameter write and operation can be performed from a program.

Set this mode for communication operation using PU connector or communication option.

Parameter Number	Name	Initial Value	Setting Range	Description
79	Operation mode selection	0	0 to 4, 6, 7	Operation mode selection
/ *	Operation mode selection	Ü	0 10 4, 0, 7	(Refer to page 193)
	Communication startup mode selection		0	As set in <i>Pr. 79</i> .
		0	1	Network operation mode
340 *				Network operation mode
340 *			40	Operation mode can be changed between
			10	the PU operation mode and Network
				operation mode from the operation panel.

The above parameters can be changed during a stop in any operation mode.

(1) Specify operation mode at power-on (Pr. 340)

•Depending on the Pr. 79 and Pr. 340 settings, the operation mode at power-on (reset) changes as described below.

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power-on, Power Restoration, Reset	Operation Mode Switching		
	0 (initial value)	External operation mode	Switching among the External, PU and NET operation mode is enabled *1		
	1	PU operation mode	Fixed to PU operation mode		
0	2	External operation mode	Switching between the External and NET operation mode is enabled Switching to PU operation mode disabled		
(initial	3, 4	External/PU combined mode	Operation mode switching disabled		
value)	6	External operation mode	Switching among the External, PU, and NET operation mode is		
	0	External operation mode	enabled while running.		
		X12 (MRS) signal ON External operation mode	Switching among the External, PU and NET operation mode is		
	7	X12 (MR3) Signal ON External operation filode	enabled *1		
		X12 (MRS) signal OFF External operation mode	Fixed to External operation mode (Forcibly switched to External		
		12 (MR3) signal OFF External operation mode	operation mode.)		
	0	NET operation mode	Same as when <i>Pr. 340</i> = "0"		
	1	PU operation mode			
	2	NET operation mode			
1	3, 4	External/PU combined mode			
	6	NET operation mode			
	7	X12 (MRS) signal ON NET operation mode			
	•	X12(MRS) signal OFF External operation mode			
	0	NET operation mode	Switching between the PU and NET operation mode is enabled		
	_	·	*2		
	1	PU operation mode	Same as when <i>Pr. 340</i> = "0"		
10	2	NET operation mode	Fixed to NET operation mode		
	3, 4	External/PU combined mode	Same as when <i>Pr. 340</i> = "0"		
	6	NET operation mode	Switching between the PU and NET operation mode is enabled		
	_		while running *2		
	7	External operation mode	Same as when <i>Pr. 340</i> = "0"		

^{*1} Operation mode can not be directly changed between the PU operation mode and Network operation mode

^{*2} Operation mode can be changed between the PU operation mode and Network operation mode with $\frac{PU}{EXT}$ key of the operation panel and X65 signal.



Parameters referred to

Pr. 79 Operation mode selection 🕼 Refer to page 190

^{*} The above parameters can be set when *Pr. 160 User group read selection* = "0". However, the parameters can be set whenever the communication option is connected. (*Refer to page 184*)



4.19.3 Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)

When the RS-485 communication with the PU connector or communication option is used, the external start command and frequency command can be valid. Command source in the PU operation mode can be selected.

From the communication device, parameter unit, etc. which have command source, parameter write or start command can be executed. Parameter read or monitoring can be executed in any operation mode.

Parameter	Nome	Initial	Setting	Description
Number	Name	Value	Range	Description
220	Communication operation	0	0	Start command source communication
338	command source	0	1	Start command source external
			0	Frequency command source communication
	Communication speed		1	Frequency command source external
339	command source	0		Frequency command source external (Frequency command from
	command source		2	communication is valid, frequency command from terminal 2 is
				invalid)
			0	The communication option is the command source when NET
				operation mode.
	NET mode operation		2	PU connector is the command source when NET operation mode.
550 *	command source	9999		Automatic communication option recognition
	selection		9999	Normally, PU connector is the command source. When a
			9999	communication option is mounted, the communication option is the
				command source.
			2	PU connector is the command source when PU operation mode.
			3	USB connector is the command source when PU operation mode.
	PU mode operation		4	Operation panel is the command source when PU operation mode.
551 *	command source	9999		USB automatic recognition
331 *		9999		Normally, operation panel is the command source. When the
	selection		9999	parameter unit is connected to the PU connector, PU is the
				command source. When USB is connected, USB connector is the
				command source.

The above parameters can be set when *Pr. 160 User group read selection* = "0". However, the parameters can be set whenever the communication option is connected. (*Refer to page 184*)

(1) Select the command source of the Network operation mode (Pr. 550)

- •Either the RS-485 communication with the PU connector or communication option can be specified as the command source in the Network operation mode.
- •For example, set *Pr. 550* to "2" when executing parameter write, start command or frequency command from the unit RS-485 terminals in the Network operation mode independently of whether the communication option is connected or not.



NOTE

• Since *Pr.* 550 = "9999" (automatic communication option recognition) in the initial setting, parameter write, start command and frequency command cannot be executed by communication using the unit RS-485 terminals when the communication option is fitted.

^{*} This parameter can be changed during a stop in any operation mode.

\overline{Z}

(2) Selects the command source of the PU operation mode (Pr. 551)

- •Any of the operation panel, PU connector, or USB connector can be specified as the command source in the PU operation mode.
- •In the PU operation mode, set *Pr. 551* to "2" when executing parameter write, start command or frequency command during the RS-485 communication with PU communication.



NOTE

- When performing the RS-485 communication with the PU connector when *Pr. 551* = "9999", PU mode command source does not automatically change to the PU connector. Change to the Network operation mode to change the command source.
- When "2" (NET mode PU connector) is set in *Pr. 550* and "2" (PU mode PU connector) is set in *Pr. 551*, PU operation mode has priority. When the communication option is not fitted, therefore, the operation mode cannot be switched to the Network operation mode.
- Changed setting value is valid when powering ON or resetting the inverter.
- The Modbus-RTU protocol cannot be used in the PU operation mode. Select Network operation mode (NET mode command source).
- All of the operation mode indicator (PU_EXT NET) of the operation panel turns OFF when command source is not operation panel.

PU...PU operation mode, NET...network operation mode, —....without command source

				Command Sou	rce		
Pr. 550	Pr. 551	Operation	USB	PU co	nnector	Communication	Remarks
Setting	Setting	panel	connector	Parameter unit	RS-485 communication	option	Remarks
	2		1	PU	PU *1	NET *2	
	3		PU	_	_	NET *2	
0	4	PU	1	_	_	NET *2	
	9999 (initial value)	PU *3	PU *3	PU *3	_	NET *2	
	2	_	_	PU	PU *1	_	Switching to NET operation mode disabled
	3	_	PU	_	NET	_	
2	4	PU	_	_	NET	_	
	9999 (initial value)	PU *3	PU *3	PU *3	NET	_	
	2	_	_	PU	PU *1	NET *2	
	2	3 —	PU	_	_	NET *2	Communication option fitted
	3				NET	_	Communication option not fitted
9999 (initial	4	PU	_		_	NET *2	Communication option fitted
value)	4	PU		_	NET	_	Communication option not fitted
	9999	Dil »2	-	DII #2	_	NET *2	Communication option fitted
	(initial value)		FU*3	PU *3	NET	_	Communication option not fitted

¹ The Modbus-RTU protocol cannot be used in the PU operation mode. When using the Modbus-RTU protocol, set Pr. 550 to "2".

^{*2} When the communication option is not fitted, the operation mode cannot be switched to the Network operation mode.

^{*3} When Pr. 551 = "9999", the priorities of the PU command source is USB connector > parameter unit (FR-PU04/FR-PU07) > operation panel.



(3) Controllability through communication

- •Controllability through communication in each operation mode is shown below.
- •Monitoring and parameter read can be performed from any operation regardless of operation mode.

RS-485 communica tion from PU connector Other	2 connector) her than the above	Run command (start) Run command (stop) Running frequency setting Parameter write Inverter reset Run command (start) Run command (stop) Running frequency	O O O × × ×	× Δ*3 × ×*5	× Δ*3 Ο Ο*4	O		× × × × × × × × × × × × × × × × × × ×
RS-485 communica tion from PU connector Other	2 connector) her than the above	Running frequency setting Parameter write Inverter reset Run command (start) Run command (stop) Running frequency	O *4 O ×	× *5	O O*4	×		
RS-485 communica tion from PU connector Other	ner than the above	setting Parameter write Inverter reset Run command (start) Run command (stop) Running frequency	O*4 O ×	× *5	O*4			×
communica tion from PU connector Other	ner than the above	Inverter reset Run command (start) Run command (stop) Running frequency	O ×	0		O *4		
tion from PU connector Othe	ner than the above	Run command (start) Run command (stop) Running frequency	×		_	O4	>	· *5
PU connector Othe	ner than the above	Run command (stop) Running frequency			U	0		0
connector Othe	ner than the above	Running frequency	×	×	×	×	O *1	×
	above			×	×	×	O *1	×
	•	setting	×	×	×	×	O *1	×
		Parameter write	× *5	× *5	×*5	× *5	O *4	× *5
		Inverter reset	×	×	×	×	O *2	×
(LICD	3	Run command (start, stop)	0	×	×	0		×
	(USB connector) 9999 (automatic recognition)	Running frequency setting	0	×	0	×		×
Operation		Parameter write	O *4	× *5	× *5	× *5	>	· *5
from the rec		Inverter reset	0	0	0	0		0
USB connector		Run command (start, stop)	×	×	×	×		×
		Running frequency setting	×	×	×	×		×
	•	Parameter write	× *5	× *5	× *5	× *5	>	· *5
	•	Inverter reset	0	0	0	0	0	
Control by		Run command (start, stop)	×	×	×	×	×	O *1
tion from		Running frequency setting	×	×	×	×	×	O *1
communica		Parameter write	× *5	× *5	×*5	× *5	× *5	O *4
tion option		Inverter reset	×	×	×	×	×	O *2
Control		Inverter reset	0	0	0	0		0
circuit external	_	Run command (start, stop)	×	0	0	×	>	<*1
terminals		Frequency setting	×	0	×	0	>	· *1

O: Enabled, \times : Disabled, Δ : Some are enabled

- As set in Pr.338 Communication operation command source and Pr. 339 Communication speed command source (Refer to page 201)
- At occurrence of RS-485 communication error, the inverter cannot be reset from the computer.
- Enabled only when stopped by the PU. At a PU stop, PS is displayed on the operation panel. As set in Pr. 75 PU stop selection. (Refer to page 180)
- Some parameters may be write-disabled according to the Pr. 77 Parameter write selection setting and operating status. (Refer to page 183)
- Some parameters are write-enabled independently of the operation mode and command source presence/absence. When Pr. 77 = 2, write is enabled. (Refer to the parameter list on page 58) Parameter clear is disabled.
 - When Pr. 550 NET mode operation command source selection = "2" (PU connector valid) or Pr. 550 NET mode operation command source selection = "9999" and the communication option is not fitted.
- When Pr. 550 NET mode operation command source selection= "0" (communication option valid) or Pr. 550 NET mode operation command source selection= "9999" and the communication option is fitted.

7/

(4) Operation at error occurrence

Error Definition	Operation Mode Condition (Pr. 551 setting)	PU Operation	External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (Pr. 79 = 4)	NET Operation (when used with PU connector) *5	NET Operation (when used with communication option) *6
Inverter fault	_	Stop					
PU disconnection of the PU	2 (PU connector) 9999 (automatic recognition) Other than the	Stop/continued *	1, *4				
	above	Stop/continued*1			T	<u>, </u>	
RS-485 communication	2 (PU connector)	Stop/ continued*2	Continued		Stop/ continued*2	_	Continued
error of the PU connector	Other than the above	Continued				Stop/ continued*3	Continued
Communication error of USB	3 (USB connector) 9999 (automatic recognition)	Stop/ continued*2	Continued		Stop/ continued*2	Continued	
connector	Other than the above	Continued					
Communication error of communication option	_	Continued				Stop/ continued*3	Continued

- *1 Can be selected using Pr. 75 Reset selection/disconnected PU detection/PU stop selection.
- *2 Can be selected using Pr. 122 PU communication check time interval, Pr. 336 RS-485 communication check time interval, Pr. 548 USB communication check time interval.
- *3 As controlled by the communication option.
- *4 In the PU JOG operation mode, operation is always stopped when the PU is disconnected. Whether fault (E.PUE) occurrence is allowed or not is as set in Pr. 75 Reset selection/disconnected PU detection/PU stop selection.
- *5 When Pr. 550 NET mode operation command source selection = "2" (PU connector valid) or Pr. 550 NET mode operation command source selection = "9999" and the communication option is not fitted.
- *6 When Pr. 550 NET mode operation command source selection = "0" (communication option valid) or Pr. 550 NET mode operation command source selection = "9999" and the communication option is fitted.



(5) Selection of command source in Network operation mode (Pr. 338, Pr. 339)

- •There are two control sources: operation command source, which controls the signals related to the inverter start command and function selection, and speed command source, which controls signals related to frequency setting.
- •In Network operation mode, the commands from the external terminals and communication (PU connector or communication option) are as listed below.

_	pera		Pr	338 Communication operation command source		0: NET			1: Externa	al	Downselve
	ocat elect		Pr. 339 Communication speed command source		0: NET	1: External	2: External	0: NET	1: External	2: External	Remarks
Fix	ed		Runn	ing frequency from	NET		NET	NET		NET	
-	ctio			nunication	INLI		INCI	INLI		INE	
(tei	rmin	al-	Termi	inal 2	_	External	_	_	External	_	
	uival ictio		Termi	inal 4	_	Exte	ernal	_	Exte	ernal	
		0	RL	Low-speed operation command/remote setting clear/stop-on contact selection 0	NET	Exte	ernal	NET	NET External		Pr. 59 = "0" (multi-speed)
		1	RM	Middle-speed operation command/remote setting function	NET	Exte	ernal	NET	Exte	ernal	Pr. 59 = "1, 2" (remote) Pr. 270 = "1"
		2	RH	High-speed operation command/remote setting function	NET	Exte	ernal	NET	Exte	ernal	(stop-on-contact)
		3	RT	Second function selection/ stop-on contact selection 1	NET		External		<i>Pr. 270</i> = "1" (stop-on-contact)		
		4	AU	Terminal 4 input selection	— Combined		— Combined				
		5	JOG	Jog operation selection		— External					
		7	ОН	External thermal relay input			Exte	ernal			
	g	8	REX	15-speed selection	NET External		NET	Exte	ernal	<i>Pr</i> : 59 = "0" (multi-speed)	
on	葺	10	X10	Inverter run enable signal			Exte	ernal			
uncti	84 se	12	X12	PU operation external interlock			Exte	ernal			
ē	r. I	14	X14	PID control valid terminal	NET	Exte	ernal	NET	Exte	ernal	
Selective function	8 to F	15	BRI	Brake opening completion signal		NET			External		
Se	Pr. 178 to Pr. 184 setting	16	X16	PU/External operation switchover			Exte	ernal			
		18	X18	V/F switchover		NET			External		
				Output stop		Combined			External		Pr. 79 ≠ "7"
		24	MRS	PU operation interlock			Exte	ternal			Pr: 79 = "7" When the X12 signal is not assigned
		25	STOP	Start self-holding selection	— Exter		External				
		60	STF	Forward rotation command	NET Extern		External				
		61		Reverse rotation command	NET			External			
		62	RES	Inverter reset	External						
		65	X65	PU/NET operation switchover			Exte	ernal			
		66	X66	External/NET operation switchover			Exte	ernal			
		67	X67	Command source switchover			Exte	ernal			
[Ex	pla	natio	on of	table]	l						

External : Command is valid only from control terminal. NET : Command only from communication is valid

Combined: Command from both control terminal and communication is valid. : Command from either of control terminal and communication is invalid.

• REMARKS

- The command source of communication is as set in Pr. 550 and Pr. 551.
- The Pr. 338 and Pr. 339 settings can be changed while the inverter is running when Pr. 77 = "2". Note that the setting change is reflected after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.

Switching of command source by external signal (X67)

- •In the Network operation mode, the Command source switchover signal (X67) can be used to switch the start command source and speed command source.
- Set "67" to any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the X67 signal to the control terminal.
- •When the X67 signal is OFF, the start command source and speed command source are control terminal.

X67 Signal State	Start Command Source	Speed Command Source		
No signal assignment	According to Pr. 338	According to Pr. 339		
ON				
OFF	Command is valid only from control terminal.			



• REMARKS

- The ON/OFF state of the X67 signal is reflected only during a stop. It is reflected after a stop when the terminal is switched while the inverter is running.
- When the X67 signal is OFF, a reset via communication is disabled.



• Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 59 Remote function selection 👺 Refer to page 102 Pr. 79 Operation mode selection 🕦 Refer to page 190 Pr. 270 Stop-on contact control selection 🕼 Refer to page 129



4.20 Communication operation and setting


Purpose	Parameter that s	should be Set	Refer to Page	
	Initial setting of computer link	Pr. 117 to Pr. 124	210	
Communication operation from PU	communication (PU connector)	P1. 117 to P1. 124	210	
connector	Modbus-RTU communication Pr. 117, Pr. 118, Pr. 120, F		220	
	specifications	122, Pr. 343, Pr. 502, Pr. 549	228	
Restrictions on parameter write	Communication EEPROM write	Pr. 342	214	
through communication	selection	F1. 342	214	
Communication using USB (FR	USB communication	Dr. 547 Dr. 540	241	
Configurator)	USB communication	Pr. 547, Pr. 548	241	

4.20.1 Wiring and configuration of PU connector

Using the PU connector, you can perform communication operation from a personal computer etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

(1) PU connector pin-outs




Pin Number	Name	Description
1)	SG	Earth (ground)
1)	30	(connected to terminal 5)
2)	_	Parameter unit power supply
3)	RDA	Inverter receive+
4)	SDB	Inverter send-
5)	SDA	Inverter send+
6)	RDB	Inverter receive-
7)	SG	Earth (ground)
()	36	(connected to terminal 5)
8)	-	Parameter unit power supply

NOTE


- Pins No. 2 and 8 provide power to the parameter unit. Do not use these pins for RS-485 communication.
- When making RS-485 communication with a combination of the FR-E700 series, FR-E500 series and FR-S500 series, Incorrect connection of pins No.2 and No.8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure.
- When multiple inverters are connected using pins No.2 and No.8, power is provided from the inverter which is powered ON to the inverters which are powered OFF in case inverters which are powered ON and OFF are mixed. In such a case, a protective circuit of the inverter, which is ON, functions to stop communication.

When connecting multiple inverters for RS-485 communication, make sure to disconnect cables from No.2 and No.8 so that pins No.2 and No.8 are not connected between inverters.

< When pins No.2 and No.8 are connected>




When using the RS-485 converter which receives power from the inverter, make sure that power is provided from one inverter only. (*Refer to the figure below*.)




Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector.
 The product could be damaged due to differences in electrical specifications.

(2) PU connector communication system configuration

●Connection of a computer to the inverter (1:1 connection)



● Combination of a computer and multiple inverters (1:n connection)



* The inverters may be affected by reflection depending on the transmission speed or transmission distance. If this reflection hinders communication, provide a terminating resistor. If the PU connector is used to make a connection, use a distributor since a terminating resistor cannot be fitted. Connect the terminating resistor to only the inverter remotest from the computer. (Terminating resistor: 100Ω)

> REMARKS

Refer to the following when fabricating the cable on the user side.
 Examples of product available on the market (as of October 2008)


	Product	Туре	Maker
1) Communication cable	SGLPEV-T (Cat5e/300m)	Mitsubishi Cable Industries, Ltd.	
')	Communication cable	24AWG × 4P *1	iviliadolarii Cable iriduatires, Ltd.

*1 Do not use pins No. 2, 8 of the communication cable. (Refer to page 207)




(3) Connection with RS-485 computer

●Wiring of one RS-485 computer and one inverter



●Wiring of one RS-485 computer and "n" (multiple) inverters



- *1 Make connection in accordance with the instruction manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.
- *2 The inverters may be affected by reflection depending on the transmission speed or transmission distance. If this reflection hinders communication, provide a terminating resistor. If the PU connector is used to make a connection, use a distributor since a terminating resistor cannot be fitted. Connect the terminating resistor to only the inverter remotest from the computer. (Terminating resistor: 100Ω)




NOTE

- Do not use pins No. 2, 8 of the communication cable. (Refer to page 207)
- When making RS-485 communication among the FR-E700 series, FR-E500 series and FR-S500 series, incorrect connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure. (Refer to page 207)

(4) Two-wire type connection

If the computer is 2-wire type, a connection from the inverter can be changed to 2-wire type by passing wires across reception terminals and transmission terminals of the PU connector pin.



> REMARKS

- A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.
- The passed wiring length should be as short as possible.

4.20.2 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)

Used to perform required settings for RS-485 communication between the inverter and personal computer.

- Use PU connector of the inverter for communication.
- You can perform parameter setting, monitoring, etc. using Mitsubishi inverter protocol or Modbus-RTU protocol.
- To make communication between the personal computer and inverter, initialization of the communication specifications must be made to the inverter.

Data communication cannot be made if the initial settings are not made or there is any setting error.

Parameter Number	Name	Initial Value	Setting Range	Desc	cription	
447	PU communication	0	0 to 31 (0 to 247)	Inverter station number specification		
117	station number	0	*1	Set the inverter station numbers when two or more inverters are connected to one personal computer.		
				Communication speed	to one personal computer.	
					equals the communication	
118	PU communication speed	192	48, 96, 192, 384	speed.		
				Example)19200bps if 192	2	
				Stop bit length	Data length	
	PU communication stop		0	1bit	- 8bit	
119	bit length	1	1	2bit	ODIT	
	bit length		10	1bit	- 7bit	
			11	2bit	7 Dit	
	PU communication parity		0	Without parity check		
120	check	2	1	With odd parity check		
	CHECK		2	With even parity check		
	PU communication		0 to 150ms	Set the waiting time between data transmission to		
123	waiting time setting	9999	0 10 1001110	the inverter and response.		
	waiting time setting		9999	Set with communication	data.	
	PU communication CR/LF		0	Without CR/LF		
124	selection	1	1	With CR		
	00.00.00.1		2	With CR/LF		
549	Protocol selection	0	0	· '	outer link operation) protocol	
	Protocor selection	U	1	Modbus-RTU protocol		

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

^{*1} When "1" (Modbus-RTU protocol) is set in *Pr. 549*, the setting range within parenthesis is applied.



NOTE

 Always reset the inverter after making the initial settings of the parameters. After you have changed the communication-related parameters, communication cannot be made until the inverter is reset.



4.20.3 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)

You can select the inverter operation when a communication line error occurs during RS-485 communication from the PU connector.


Parameter	Name	Initial	Setting		Doco	rintion			
Number	Name	Value	Range	Description					
Number of PU 121 communication retries		1	0 to 10	consecutive erro	ors exceeds the p	error occurrence ermissible value, nputer link operat	the inverter trips		
	104100		9999	If a communication error occurs, the inverter will not come to trip.					
			0	fault (E.PUE) o	RS-485 communication can be made. Note that a communication fault (E.PUE) occurs as soon as the inverter is switched to the operation mode with command source.				
122	PU communication check time interval	0	0.1 to 999.8s	Communication check (signal loss detection) time interval If a no-communication state persists for longer than the permissible time, the inverter trips (depends on <i>Pr. 502</i>).					
			9999	No communication check (signal loss detection)					
				At fault occurrence	Indication	Fault output	At fault removal		
	Stop mode selection		0, 3	Coasts to stop	E.PUE	Output	Stop (E.PUE)		
502	at communication error	0	1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)		
			2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions		

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)


(1) Retry count setting (Pr.121)

- •Set the permissible number of retries at data receive error occurrence. (Refer to page 219 for data receive error for retry)
- •When data receive errors occur consecutively and exceed the permissible number of retries set, an inverter trips (E.PUE) and a motor stops (as set in *Pr. 502*).
- •When "9999" is set, an inverter fault is not provided even if data receive error occurs but an alarm signal (LF) is output. For the terminal used for the LF signal output, assign the function by setting "98 (positive logic) or 198 (negative logic)" in any of *Pr. 190 to Pr. 192 (output terminal function selection)*.

Example: PU connector communication, Pr. 121 = "1" (initial value)



Example: PU connector communication, *Pr. 121* = "9999"




• REMARKS

• *Pr. 121* is valid only when Mitsubishi inverter (computer link operation) protocol is selected. *Pr. 121* is not valid when Modbus-RTU communication protocol is selected.

(2) Signal loss detection (Pr.122)

- •If a signal loss (communication stop) is detected between the inverter and master as a result of a signal loss detection, a communication fault (E.PUE) occurs and the inverter trips. (as set in *Pr. 502*).
- •When the setting is "9999", communication check (signal loss detection) is not made.
- •When the setting value is "0" (initial value), RS-485 communication can be made. However, a communication fault (E.PUE) occurs as soon as the inverter is switched to the operation mode (Network operation mode in the initial setting) with the command source.
- •A signal loss detection is made when the setting is any of "0.1s to 999.8s". To make a signal loss detection, it is necessary to send data (refer to Mitsubishi inverter protocol control code (page 218), Modbus-RTU communication protocol (page 229)) from the computer within the communication check time interval. (The inverter makes communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master).
- •Communication check is made from the first communication in the operation mode with command source valid (Network operation mode in the initial setting).

Example: PU connector communication, Pr. 122 = "0.1 to 999.8s"



<u>A</u> CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter trips (E.PUE).

The inverter can be coasted to a stop by turning ON its RES signal or by switching power OFF.

If communication is broken due to signal cable breakage, computer fault, etc. the inverter does not detect such a fault. This should be fully noted.



(3) Stop operation selection at occurrence of communication fault (Pr. 502)

•Stop operation when retry count excess (Mitsubishi inverter protocol only) or signal loss detection error occurs can be selected.


Operation at fault occurrence


Pr. 502 Setting	Operation	Indication	Fault Output				
0 (initial value)	Coasts to stop.	E. PUE lit	Provided				
1	Decelerates to stop	E. PUE lit after stop	Provided after stop				
2	Decelerates to stop	L. I OL III alter stop	Not provided				
3	S	Same as the setting "0"					


Operation at fault removal

Pr.502 Setting	Operation	Indication	Fault Output		
0 (initial value)	Kept stopped	E. PUE	Kept provided		
1	Кері зіоррец	2.102	rept provided		
2	Automatic restart functions	Normal display	Not provided		
3	Same as the setting "0"				


● Pr. 502 setting "0 (initial value), 3"







● Pr. 502 setting "2"



• REMARKS

- The fault output indicates fault output signal (ALM signal) or alarm bit output.
- When the setting was made to provide a fault output, the fault description is stored into the faults history. (The fault description is written to the faults history when a fault output is provided.)

When no fault output is provided, the fault record overwrites the fault indication of the faults history temporarily, but is not stored.

After the fault is removed, the fault indication returns to the ordinary monitor, and the faults history returns to the preceding fault indication

- When the *Pr.* 502 setting is "1 or 2", the deceleration time is the ordinary deceleration time setting (e.g. *Pr.* 8, *Pr.* 44, *Pr.* 45). In addition, acceleration time for restart is the normal acceleration time (e.g. *Pr.* 7, *Pr.* 44).
- When "2" is set in Pr. 502, run command/speed command at restarting follows the command before an fault occurrence.
- When "2" is set in Pr. 502 at occurrence of a communication error and the error is removed during deceleration, the inverter accelerates again at that point.



Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 105 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

4.20.4 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from the inverter PU connector, USB communication, and communication option, parameters storage device can be changed from EEPROM + RAM to RAM only. Set when a frequent parameter change is necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM write selection	0	0	Parameter values written by communication are written to the EEPROM and RAM.
342		O	1	Parameter values written by communication are written to RAM.

The above parameters can be set when Pr. 160 User group read selection = "0". However, it can be set any time when the communication option is connected. (Refer to page 184)

• When changing the parameter values frequently, set "1" in Pr. 342 to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).



• REMARKS

• When "1" (write to RAM only) is set in Pr. 342, powering off the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched on again are the values stored in EEPROM previously.



4.20.5 Mitsubishi inverter protocol (computer link communication)


You can perform parameter setting, monitor, etc. from the PU connector of the inverter using the Mitsubishi inverter protocol (computer link communication).

(1) Communication

•The communication specifications are given below.

14	em	Description	Related
	em	Description	Parameter
Communication p	rotocol	Mitsubishi protocol (computer link)	Pr. 549
Conforming stand	dard	EIA-485 (RS-485)	_
Number of conne	ctable devices	1:N (maximum 32 units), setting is 0 to 31 stations	Pr. 117
Communication	PU connector	Selected among 4800/9600/19200/38400bps	Pr. 118
speed	PO Connector	Selected among 4600/9600/19200/36400bps	FI. 110
Control procedur	е	Asynchronous	_
Communication r	nethod	Half-duplex	_
	Character system	ASCII (7 bits or 8 bits can be selected)	Pr. 119
	Start bit	1bit	_
Communication	Stop bit length	1 bit or 2 bits can be selected	Pr. 119
Communication	Parity check	Check (with even or odd parity) or no check can be selected	Pr. 120
	Error check	Sum code check	_
	Terminator	CR/LF (presence/absence selectable)	Pr. 124
Waiting time setti	ng	Selectable between presence and absence	Pr. 123

(2) Communication procedure



- Data communication between the computer and inverter is made in the following procedure.
 - Request data is sent from the computer to the inverter. (The inverter will not send data unless requested.)
 - 2) After waiting for the waiting time
 - 3) The inverter sends reply data to the computer in response to the computer request.
 - 4) After waiting for the inverter data processing time
 - Answer from the computer in response to reply data 3) of the inverter is transmitted. (Even if 5) is not sent, subsequent communication is made properly.)
- *1 If a data error is detected and a retry must be made, execute retry operation with the user program. The inverter comes to trip if the number of consecutive retries exceeds the parameter setting.
 - 2 On receipt of a data error occurrence, the inverter returns retry data 3) to the computer again. The inverter comes to trip if the number of consecutive data errors reaches or exceeds the parameter setting.

(3) Communication operation presence/absence and data format types

- •Data communication between the computer and inverter is made in ASCII code (hexadecimal code).
- •Communication operation presence/absence and data format types are as follows:

No.	Operati	Run	Operation	Multi	Parameter	Inverter	Monitor	Parameter		
NO.	Operati	Command	Frequency	command	Write	Reset	WIOTITO	Read		
1)	Communication reque inverter in accordance program in the computer of the comp	A1	A, A2 *3	A3	A, A2 *3	А	В	В		
2)	Inverter data processir	ng time	Present	Present	Present	Present	Present	Present	Present	
3)	Reply data from the inverter (Data 1) is	No error *1 (Request accepted)	С	С	C1*4	С	C *2	E, E1, E2 *3	E, E2 *3	
3)	checked for error)	With error. (Request rejected)	D	D	D	D	D*2	D	D	
4)	Computer processing	delay time	10ms or more							
5)	Answer from computer in response to reply data 3).	No error *1 (No inverter processing) Absent		Absent	Absent (C)	Absent	Absent	Absent (C)	Absent (C)	
3)	(Data 3) is checked for error)	With error. (Inverter outputs 3) again.)	Absent	Absent	F	Absent	Absent	F	F	

- *1 In the communication request data from the computer to the inverter, 10ms or more is also required after "no data error (ACK)". (Refer to page 218)
- *2 Reply from the inverter to the inverter reset request can be selected. (Refer to page 222)
- *3 When any of "0.01 to 9998" is set in *Pr. 37* and "01" in instruction code HFF sets data format to A2 or E2. In addition, data format is always A2 and E2 for read or write of *Pr. 37*.
- *4 At mode error, and data range error, C1 data contains an error code. (Refer to page 227) Except for those errors, the error is returned with data format D.

Data writing format

Communication request data from the computer to the inverter 1)

Format	Number of Characters																		
Tormat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
A	ENQ *1	Inve stat numb		Instruction code		*3	Data				Sum *4								
A 1	ENQ *1	Inve stat numb	tion		uction de	*3	Data			Sum check				•					
A2	ENQ *1	Inve stat numb			uction de	*3	Data						ım eck	*4					
А3	ENQ *1	Inve stat numb	tion		uction de	*3	Send data type	Receive data type		Da	ta1		Data2				Su che		*4

Reply data from the inverter to the computer 3) (No data error detected)

	Format		Number of Characters																	
ľ	Officat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
	С	ACK Inverter station number *2		on er *2	*4															
	C1	STX station number *2		٠	Send data type			Error code 2		Da	ta1			Da	ta2		ETX *1	Su che		*4

Reply data from the inverter to the computer 3) (With data error)

-1. 7 .											
Format	Number of Characters										
Format	1	2	3	4	5						
D	NAK *1	Inve stat numb		Error code	*4						

- *1 Indicate a control code
- *2 Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal.
- When the *Pr. 123 PU communication waiting time setting* is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- *4 CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using *Pr. 124 PU communication CR/LF selection*.



Data reading format

Communication request data from the computer to the inverter 1)

	Format				Number	of Char	acters			
	1 Office	1	2	3	4	5	6	7	8	9
Ī	В	ENQ *1	Inve station no		Instructi	on code	*3	Su che	ım eck	*4

Reply data from the inverter to the computer 3) (No data error detected)

Format		Number of Characters											
Tomat	1	2	3	4	5	6	7	8	9	10	11	12	13
E	STX *1		erter umber *2		Read	d data	ETX *1			ım eck	*4		
E1	STX *1		erter umber *2	Read	data	ETX *1		um eck	*4				
E2	STX *1		erter umber *2			Read	data			ETX *1	Su che		*4

Format		Number of Characters										
Torritat	1	2	3	4 to 23	24	25	26	27				
E3	STX *1	Inve station no	erter umber *2	Read data (Inverter type information)	ETX *1	Su che		*4				

Reply data from the inverter to the computer 3) (With data error)

Format		Number of Characters							
Tormat	1	2 3		4	5				
n	NAK	Inverter station number *2		Error	*4				
	*1			code	*4				

Send data from the computer to the inverter 5)

Format	Number of Characters							
1 Office	1	4						
C (Without data error)	ACK *1	Inve		*4				
F (With data error)	NAK *1	Inve	erter umber *2	*4				

- Indicate a control code
- Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal. *2
- When the Pr. 123 PU communication waiting time setting is other than 9999, create the communication request data without "waiting time" in the data *3 format. (The number of characters decreases by 1.)
- CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using *Pr. 124 PU communication CR/LF selection*.

Data definitions

1) Control code

Signal	ASCII Code	Description		
STX	H02	Start of Text (Start of data)		
ETX	H03	End of Text (End of data)		
ENQ	H05	Enquiry (Communication request)		
ACK	H06	Acknowledge (No data error detected)		
LF	H0A	Line Feed		
CR H0D		Carriage Return		
NAK	H15	Negative Acknowledge (Data error detected)		

2) Inverter station number

Specify the station number of the inverter which communicates with the computer.


3) Instruction code

Specify the processing request, e.g. operation or monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code as appropriate. (Refer to page 58)

Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer to page 58)

5) Waiting time

Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer between 0 and 150ms in 10ms increments. (e.g. 1 = 10ms, 2 = 20ms).




• REMARKS


- When the Pr. 123, Pr. 337 (waiting time setting) setting is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time changes depending on the instruction code. (Refer to page 219)

6) Sum check code

The sum check code is 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



When the Pr. 123 Waiting time setting ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)






7) Error code


If any error is found in the data received by the inverter, its definition is sent back to the computer together with the NAK code.

Error Code	Error Item	Error Description	Inverter Operation
		The number of errors consecutively detected in communication request	
H0	Computer NAK error	data from the computer is greater than allowed number of retries.	
H1	Parity error	The parity check result does not match the specified parity	
	-	The sum check code in the computer does not match that of the data	Brought to trip (E. PUE)
H2	Sum check error	received by the inverter.	if error occurs
		The data received by the inverter has a grammatical mistake.	continuously more than
Н3	Protocol error	Alternatively, data receive is not completed within the predetermined	the allowable number of
		time. CR or LF is not as set in the parameter.	retry times.
H4	Framing error	The stop bit length differs from the initial setting.	
	0	New data has been sent by the computer before the inverter completes	
H5	Overrun error	receiving the preceding data.	
H6	_	_	_
			Does not accept
H7	Character error	The character received is invalid (other than 0 to 9, A to F, control code).	received data but is not
			brought to trip.
H8	_	-	_
H9	_	-	_
		Parameter write was attempted in other than the computer link operation	
HA	Mode error	mode, when operation command source is not selected or during inverter	
		operation.	Does not accept
НВ	Instruction code	The specified command does not exist.	received data but is not
TID	error	The specified command does not exist.	brought to trip.
НС	Data range error	Invalid data has been specified for parameter write, frequency setting,	
110	Data range cirol	etc.	
HD	_	-	_
HE	_	-	_
HF	_	1	_

(5) Response time



[Formula for data sending time]



Communication specifications

Name	Number of Bits			
Stop bit length		1 bits		
Stop bit length	Stop bit length			
Data langth		7 bits		
Data length		8 bits		
Parity check	Present	1 bit		
anty check	Absent	0		

●Data check time

Item	Check Time
Various monitors, operation command,	< 12ms
frequency setting (RAM)	< 1211IS
Parameter read/write, frequency setting	< 30ms
(EEPROM)	< 30IIIS
Parameter clear/all clear	< 5s
Reset command	No answer

(6) Instructions for the program


- 1) When data from the computer has any error, the inverter does not accept that data. Hence, in the user program, always insert a retry program for data error.
- 2) All data communication, e.g. run command or monitoring, are started when the computer gives a communication request. The inverter does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
- 3) Program example

To change the operation mode to computer link operation

Programming example of Microsoft® Visual C++® (Ver.6.0)

```
#include <stdio.h>
#include <windows.h>
void main(void){
     HANDLÉ
                       hCom:
                                        //Communication handle
     DCB
                      hDcb:
                                        //Structure for communication setting
     COMMTIMEOUTS
                               hTim:
                                        // Structure for time out setting
                                                 // Send buffer
     char
                       szTx[0x10];
     char
                       szRx[0x10]:
                                                 // Receive buffer
     char
                       szCommand[0x10];// Command
                                                 // For buffer size storing
     int
                       nTx,nRx;
     int
                       nSum;
                                                 // For sum code calculation
     BOOL
                       bRet:
     int
                       nRet;
     int
     //**** Opens COM1 port****
     hCom = CreateFile ("COM1", (GENERIC_READ | GENERIC_WRITE), 0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
     if (hCom != NULL) {
              //**** Makes a communication setting of COM1 port****
              GetCommState(hCom,&hDcb);
                                                                                    // Retrieves current communication information
              hDcb.DCBlength = sizeof(DCB);
                                                                                    // Structure size setting
              hDcb.BaudRate = 19200;
                                                                                    // Communication speed=19200bps
              hDcb.ByteSize = 8;
                                                                                    // Data length=8bit
              hDcb.Parity = 2;
                                                                                    // Even parity
              hDcb.StopBits = 2;
                                                                                    // Stop bit=2bit
              bRet = SetCommState(hCom,&hDcb);
                                                                                    // Sets the changed communication data
              if (bRet == TRUE) {
                       //**** Makes a time out setting of COM1 port****
                       Get CommTimeouts(hCom,&hTim);
                                                                                    // Obtains the current time out value
                       hTim.WriteTotalTimeoutConstant = 1000;
                                                                                    // Write time out 1s
                       hTim.ReadTotalTimeoutConstant = 1000;
                                                                                    // Read time out 1s
                       SetCommTimeouts(hCom,&hTim);
                                                                                    // Changed time out value setting
                       //**** Sets the command to switch the operation mode of the station 1 inverter to the network operation mode ****
                       sprintf(szCommand,"01FB10000");
                                                                                    // Send data (NET operation write)
                       nTx = strlen(szCommand):
                                                                                    //Send data size
                       //**** Generates sum code****
                                                                                    // Initialization of sum data
                       nSum = 0:
                       for (i = 0; i < nTx; i++) {
                               nSum += szCommand[i];
                                                                                    // Calculates sum code
                               nSum &= (0xff);
                                                                                    // Masks data
                      }
                       //**** Generates send data****
                                                                                    // Initialization of send buffer
                       memset(szTx,0,sizeof(szTx));
                       memset(szRx,0,sizeof(szRx)):
                                                                                    // Initialization of receive buffer
                       sprintf(szTx,"\5%s%02X",szCommand,nSum);// ENQ code+send data+sum code
                       nTx = 1 + nTx + 2;
                                                                                    // Number of ENQ code+number of send data+number of sum code
                       nRet = WriteFile(hCom,szTx,nTx,&nTx,NULL);
                       //**** Sending **
                       if(nRet != 0) {
                               nRet = ReadFile(hCom,szRx,sizeof(szRx),&nRx,NULL);
                       //**** Receiving ****
                               if(nRet != 0) {
                                         //**** Displays the receive data ****
                                         for(i = 0; i < nRx; i++) {
                                                 printf("%02X ",(BYTE)szRx[i]);// Consol output of receive data
                                                 // Displays ASCII coder in hexadecimal. Displays 30 when "0"
                                        printf("\n\r");
              CloseHandle(hCom);
                                                                                    // Close communication port
     }
```





! CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal loss etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will come to trip (E.PUE, E.SER).

The inverter can be coasted to a stop by switching ON its RES signal or by switching power OFF.

If communication is broken due to signal cable breakage, computer fault etc., the inverter does not detect such a fault. This should be fully noted.

(7) Setting items and set data

After completion of parameter settings, set the instruction codes and data then start communication from the computer to allow various types of operation control and monitoring.

No.		Item	Read/ Write	Instruction Code	Data Definition	Number of Data Digits (Format)	
1	Оре	eration mode	Read	Н7В	H0000: Network operation H0001: External operation	4 digits (B, E/D)	
			Write	HFB	H0002: PU operation	4 digits (A, C/D)	
		Output frequency /speed	Read	H6F	H0000 to HFFFF: Output frequency in 0.01Hz increments Speed increments 1/0.001 (when $Pr. 37 = 0.01$ to 9998) When "0.01 to 9998" is set in $Pr. 37$ and "01" in instruction code HFF, the increments change to 0.001 and the data format is E2. When "100" is set in $Pr. 52$, the monitor value is different depending on whether the inverter is at a stop or running. (Refer to page 150)	4 digits, 6 digits (B, E, E2/D)	
		Output current	Read	H70	H0000 to HFFFF: Output current (hexadecimal) in 0.01A increments	4 digits (B, E/D)	
		Output voltage	Read	H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments	4 digits (B, E/D)	
2	Monitor	Special monitor	Read H72 H0000 to HFFFF: Monitor data selected in instruction cod	H0000 to HFFFF: Monitor data selected in instruction code HF3	4 digits (B, E/D), 6 digits (B, E2/D)		
2	Mon	Special	Read	H73	H01 to H3F: Monitor selection data	2 digits (B, E1/D)	
		monitor Selection No.	Write	HF3	Refer to the special monitor No. table (page 224)	2 digits (A1, C/D)	
		Fault description	Read	H74 to H77	H0000 to HFFFF: Two latest fault records b15	4 digits (B, E/D)	
3				HF9	Control input commands such as the forward rotation signal (STF)	4 digits (A, C/D)	
	Run			and reverse rotation signal (STR). (For details, refer to page 226)	2 digits (A1, C/D)		
4	moni	rter status itor ansion)	Read	H79	Monitor the states of the output signals such as forward rotation, reverse rotation and inverter running (RUN). (For details, refer to	4 digits (B, E/D)	
	Invei moni	ter status tor	Read	Н7А	page 226)	2 digits (B, E1/D)	
	(RAI	Set frequency (RAM)		H6D	Read set frequency/speed from RAM or EEPROM. H0000 to HFFFF: Set frequency in 0.01Hz increments Speed increments 1/0.001 (when <i>Pr. 37</i> = 0.01 to 9998)	4 digits (B, E/D), 6 digits	
	Set frequency (EEPROM)			H6E	When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code HFF, the increments change to 0.001 and the data format is E2.	(B, E2/D)	
5	(RAI	requency (1)	-	HED	Write set frequency/speed to RAM or EEPROM. H0000 to H9C40 (0 to 400.00Hz): Frequency increments 0.01Hz Speed increments 1/0.001 (when <i>Pr. 37</i> = 0.01 to 9998)	4 digits	
	Set frequency (RAM, EEPROM)			Write	HEE	 When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code HFF, the increments change to 0.001 and the data format is A2. To change the set frequency consecutively, write data to the inverter RAM. (instruction code: HED) 	(A, C/D), 6 digits (A2, C/D)

Refer to page 216 for data format (A, A1, A2, A3, B, C, C1, D, E, E1, E2, E3, F)

(Ver.UP) Specifications differ according to the date assembled. Refer to page 324 to check the SERIAL number.



No.		Item	Read/ Write	Instruction Code			Data Definit	tion	Number of Data Digits (Format)	
6	Inver	ter reset	Write	HFD	·	19696: resets the invertible As the inverter is rest computer, the inverted computer. 19966: resets the invertible When data is sent no	4 digits (A, C/D) 4 digits			
7		ts history	Write	HF4	F	and then the inverter	(A, D) 4 digits (A, C/D)			
	Date	h clear			V s	arameters.	unication para ata. (O: Clear umeter clear, a	meters or not can be r, x: Not clear) Il clear, and communication	(A, C/D)	
						Clear Type	Data	Communication Pr.		
	Para	meter clear				Parameter clear	H9696	0		
8	All cl	ear	Write	HFC			H5A5A	×	4 digits	
	Ver.	UP)				All parameter clear	H9966	0	(A, C/D)	
					re re E	elated parameter settir esuming operation, se executing clear will clea	ngs also return t the paramete ar the instruction rd locked statu	on code HEC, HF3, and HFF is <i>(refer to page 187)</i> , only		
9	D			H00 to H63	re	Refer to the instruction code (Refer to page 58) and write and/or read parameter values as required. When setting $Pr.\ 100$ and later, link parameter extended setting			4 digits (B, E/D), 6 digits (B, E2/D)	
10	Para	meter	Write	H80 to HE3	n	vinen setting <i>Pr. 100 a</i> nust be set. Pata format of <i>Pr. 37</i> rea	4 digits (A, C/D), 6 digits (A2, C/D)			
11	Link	parameter	Read	H7F		arameter description etting.	is changed ac	ccording to the H00 to H09	2 digits (B, E1/D)	
- 11	exter	nded setting	Write	HFF		or details of the settin Refer to page 58).	gs, refer to the	e parameter instruction code	2 digits (A1, C/D)	
	Seco	ond parameter	Read	H6C	F	etting calibration para l00: Frequency *2 l01: Parameter-set and l02: Analog value inpu	alog value	ı	2 digits (B, E1/D)	
12	(instr	ruction code = 1, 9)	Write	HEC	*	Refer to the list of calibration parameter	calibration parans. an also be writte	ameters on the next page for $\frac{125}{125}$ (instruction code:	2 digits (A1, C/D)	
13		command	Write/ Read	HF0		vailable for writing 2 c	ommands, and	d monitoring 2 items for	10 digits (A3, C1/D)	
	Inverter type Read H7C Reading inverter type in ASCII of "H20" (blank code) is set for bla		n ASCII code. et for blank are	ea	20 digits (B, E3/D)					
14	Inverter type monitor	Capacity (Ver.UP)	Read	H7D	ir "I E 0	teading inverter capace that is read in increme the increments H20" (blank code) is set in the increment that is set in the incremen	nts of 0.1kW, a et for blank are (H20, H20, H2 (H20, H20, H	ea 0, H20, H20, H34)	6 digits (B, E2/D)	

Refer to page 216 for data format (A, A1, A2, A3, B, C, C1, D, E, E1, E2, E3, F)

Yer.UP Specifications differ according to the date assembled. *Refer to page 324* to check the SERIAL number.





• REMARKS

- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when an inverter reset or all

Example) When reading the C3 (Pr. 902) and C6 (Pr. 904) settings from the inverter of station 0

	Computer Send Data	Inverter Send Data	Description
1)	ENQ 00 FF 0 01 82	ACK 00	Set "H01" to the expansion link parameter.
2)	ENQ 00 EC 0 01 7E	ACK 00	Set "H01" to second parameter changing.
3)	ENQ 00 5E 0 0F	STX 00 0000 ETX 25	C3 (Pr. 902) is read. 0% is read.
4)	ENQ 00 60 0 FB	STX 00 0000 ETX 25	C6 (Pr. 904) is read. 0% is read.

To read/write C3 (Pr. 902) and C6 (Pr. 904) after inverter reset or parameter clear, execute from 1) again.

List of calibration parameters

B	None	Instruction Code				
Parameter	Name	Read	Write	Extended		
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1		
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1		
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1		
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1		
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1		
C6 (904)	Terminal 4 frequency setting bias	60	E0	1		
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1		
C7 (905)	Terminal 4 frequency setting gain	61	E1	1		

[Special monitor selection No.]

Refer to page 150 for details of the monitor description.

Description	Unit					
Output frequency/speed *1	0.01Hz/					
Output frequency/speed *1	0.001					
Output current	0.01A					
Output voltage	0.1V					
Fraguency actting/anoad actting *1	0.01Hz/					
Frequency setting/speed setting *1	0.001					
Motor torque	0.1%					
Converter output voltage	0.1V					
Regenerative brake duty	0.1%					
Electronic thermal relay function	0.1%					
load factor	0.176					
H0B Output current peak value						
Converter output voltage peak value	0.1V					
Output power	0.01kW					
	Output frequency/speed *1 Output current Output voltage Frequency setting/speed setting *1 Motor torque Converter output voltage Regenerative brake duty Electronic thermal relay function load factor Output current peak value Converter output voltage peak value					

Data	Description	Unit
H0F	Input terminal status *2	_
H10	Output terminal status *3	_
H14	Cumulative energization time	1h
H17	Actual operation time	1h
H18	Motor load factor	0.1%
H19	Cumulative power	1kWh
H34	PID set point	0.1%
H35	PID measured value	0.1%
H36	PID deviation	0.1%
H3A	Option input terminal status 1*4	_
H3B	Option input terminal status 2*5	_
H3C	Option output terminal status *6	_
H3D	Motor thermal load factor	0.1%
H3E	Inverter thermal load factor	0.1%
H3F	Cumulative power 2 Ver.UP	0.01kWh

Ver.UP Specifications differ according to the date assembled. Refer to page 324 to check the SERIAL number.

DY



- When "0.01 to 9998" is set in Pr. 37 and "01" in instruction code HFF, the data format is 6 digits (E2).
- Input terminal monitor details—MRS is OFF when using the safety stop function model.

	b15															b0
		_	_	_	_	RES	_	MRS	_	RH	RM	RL	_	_	STR	STF
*3	Output ter	rminal mo	nitor detai	ls												
	b15															b0
		_	_	_	_	_	_	_	_	_	ABC	FU	_	_	_	RUN
*4	Details of	option in	out termina	al monitor	1 (input te	erminal sta	atus of FF	R-A7AX E	kit)—all te	rminals a	re off whe	n an optio	n is not fit	tted.		
	b15															b0
	X15	X14	X13	X12	X11	X10	X9	X8	X7	X6	X5	X4	Х3	X2	X1	X0
*5	Details of	option in	out termina	al monitor	2 (input to	erminal sta	atus of FF	R-A7AX E	kit)—all te	rminals a	re off whe	n an optio	n is not fit	tted.		

Details of option output terminal monitor (output terminal status of FR-A7AY E kit/A7AR E kit/—all terminals are off when an option is not fitted.


b0 RA3 RA2 RA1 Y6 Y5 Y4 Y3 Y2 Y0

[Fault data]

Refer to page 279 for details of fault description

Data	Definition
H00	No fault
1100	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT
H31	E.THM
H40	E.FIN
H52	E.ILF

Data	Definition
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
HA0	E.OPT
HA1	E.OP1
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HB3	E.PE2
HC0	E.CPU
HC5	E.IOH



Fault record display example (instruction code H74) For read data H30A1 (Previous fault THT) (Latest fault...OP1) b8b7 001100001010100001 Previous fault Latest fault (H30)(HA1)

[Run command]

14	Instruction	Bit	December 1	Francis
Item	Code	Length	Description	Example
Run command	HFA	8bit	b0: AU (current input selection) *3 b1: forward rotation command b2: reverse rotation command b3: RL (low speed operation command) *1*3 b4: RM (middle speed operation command) *1*3 b5: RH (high speed operation command) *1*3 b6: RT (second function selection)*3 b7: MRS (output stop) *1*3	[Example 1] H02 Forward rotation b7
Run command (expansion)	HF9	16bit	b0: AU (current input selection) *3 b1: forward rotation command b2: reverse rotation command b3: RL (low speed operation command) *1*3 b4: RM (middle speed operation command) *1*3 b5: RH (high speed operation command) *1*3 b6: RT (second function selection)*3 b7: MRS (output stop) *1*3 b8: — b9: — b10: — b11: RES (reset) *2*3 b12: — b13: — b14: — b15: —	[Example 1] H0002 Forward rotation b15

^{*1} The signal within parentheses is the default setting. The description changes depending on the setting of Pr. 180 to Pr .184 (input terminal function selection) (page 135).

[Inverter status monitor]

	Instruction			
Item	Code	Length	Description	Example
Inverter status monitor	Н7А	8bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) * b7: ABC (fault) *	[Example 1] H02 During forward rotation b7 b0 0 0 0 0 0 0 1 0 [Example 2] H80 Stop at fault occurrence b7 b0 1 0 0 0 0 0 0 0 0
Inverter status monitor (expansion)	H79	16bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) * b7: ABC (fault) * b8: — b9: — b10: — b11: — b12: — b13: — b14: — b15: Fault occurrence	[Example 1] H0002 During forward rotation b15

^{*} The signal within parentheses is the default setting. Definitions change according to the *Pr.190 to Pr. 192 (output terminal function selection)*.

^{*2} The signal within parentheses is the default setting. Reset cannot be controlled by the network, bit 11 is invalid in the initial status. When using bit 11, change the signal with Pr. 184 RES terminal function selection (page135) (Reset can be executed with the instruction code HFD)

^{*3} When Pr. 551 = "2" (PU Mode command source is PU connector), only forward rotation and reverse rotation can be used.



[Multi command (HF0)]

Sending data format from computer to inverter

Format		Number of Characters																	
Tomat	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
А3	ENQ	Inve stat num	ion	Co	iction de =0)	Waiting time	data	Receive data type*2		Data	a1*3				ta2 •3		Su che		CR/LF

Reply data format from inverter to computer (No data error detected)

Format		Number of Characters																	
i Oillia	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C1	STX	Inve stat num	ion	data		code 1	Error code 2 *5		Data	a1*4				ita2 4		ETX	St che	um eck	CR/LF

- *1 Specify the data type of sending data (from computer to inverter).
- Specify the data type of reply data (from inverter to computer).
- *3 Combination of data 1 and data 2 for sending

Data Type	Data 1	Data 2	Remarks					
Run command		Set frequency	Run command (expansion) is same as instruction code HF9					
U	(expansion) (RAM)		(Refer to page 226)					
1	Run command		The unit of set frequency is always by four digits, even when "0.01					
ı	(expansion)	(RAM, EEPROM)	to 9998" is set in Pr. 37 and "01" is set in instruction code HFF.					

Combination of data 1 and data 2 for reply

Data Type	Data 1	Data 2	Remarks
0	Inverter status	Output frequency	Inverter status monitor (expansion) is same as instruction code
U	monitor (expansion)	(speed)	H79 (Refer to page 226)
1	Inverter status monitor (expansion)	Special monitor	The unit of speed monitor is always by four digits (rounds down after the decimal point), even when "0.01 to 9998" is set in <i>Pr. 37</i> and "01" is set in instruction code HFF. Replys the monitor item specified in instruction code HF3 for special monitor.(<i>Refer to page 224</i>)

Error code for sending data 1 is set in error code 1, and error code for sending data 2 is set in error code 2. Mode error (HA), instruction code error (HB), data range error (HC) or no error (HF) is replied.

4.20.6 Modbus-RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)

Using the Modbus-RTU communication protocol, communication operation or parameter setting can be performed from the PU connector of the inverter.

Parameter Number	Name	Initial Value	Setting Range		Desc	ription			
	PU communication		0	No reply to the master *					
117	station number	0			number specificat				
			1 to 247			vhen two or more	inverters are		
					e personal compu	uter.			
440	PU communication	00	48, 96, 192,	Communication	•				
118	speed	96	384	· ·	•	e communication	speed.		
	'			Example) 9600b					
			0	Without parity ch Stop bit length 2					
	PU communication			With odd parity of					
120	parity check	2	1	Stop bit length 1					
	parity check		2	With even parity check					
				Stop bit length 1bit					
				RS-485 communication can be made. Note that a communication					
		0	0	fault (E.PUE) occurs as soon as the inverter is switched to the					
	DIIiti			operation mode with command source.					
122	PU communication		0.1 to 999.8s	Communication check (signal loss detection) time interval					
	check time interval			If a no-communication state persists for longer than the permissible					
				time, the inverter trips (depends on Pr. 502).					
			9999	No communication check (signal loss detection)					
343	Communication error	0		Displays the nu	mber of commun	ication errors duri	ng Modbus-RTU		
343	count	O	_	communication ((reading only)				
				At Fault	Indication	Fault Output	At Fault		
				Occurrence	indication	l auit Output	Removal		
	Stop mode selection		0, 3	Coasts to stop.	E.PUE	Output	Stop		
502	at communication	0	0, 0	,			(E.PUE)		
	error		1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)		
			2	Decelerates to	After stop	Without output	Automatic		
			2	stop	E.PUE	Without output	restart functions		
549	Protocol selection	0	0	Mitsubishi inverter (computer link operation) protocol					
U+3	i iotocoi selectioni		1	Modbus-RTU pr	otocol				

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

Some functions are invalid for broadcast communication. (Refer to page 231)



• When "1" (Modbus-RTU protocol) is set in *Pr. 549* and "384" (38400bps) in *Pr. 118*, parameter unit (FR-PU04/FR-PU07) is disabled. When using the parameter unit (FR-PU04/FR-PU07), change parameter using the operation panel.



(I) REMARKS

- Set Pr. 549 Protocol selection to "1" to use the Modbus-RTU protocol.
- When PU connector is selected as NET mode command source (when Pr. 550 NET mode operation command source selection ="2" or "9999" (initial value) without communication option), Modbus-RTU communication operation can be performed. (Refer to page

^{*} When Modbus-RTU communication is performed from the master with address 0 (station number 0) set, broadcast communication is selected and the inverter does not send a response message. When response from the inverter is necessary, set a value other than "0" (initial value is 0) in Pr. 117 PU communication station number.



(1) Communication

•The communication specifications are given below.

Item		Description	Related Parameter
Communication protocol		Modbus-RTU protocol	Pr. 549
Conforming	standard	EIA-485(RS-485)	_
Number of o	connectable	1:N (maximum 32 units), setting is 0 to 247 stations	Pr. 117
Communica	ation speed	Selected among 4800/9600/19200/38400bps	Pr. 118
Control procedure		Asynchronous	_
Communication method		Half-duplex	_
	Character system	Binary (always 8 bits)	_
	Start bit	1bit	_
	Stop bit length	Select from the following three types	
Communi	Stop bit length	 No parity, stop bit length 2 bits 	Pr. 120
cation	Parity check	 No odd parity, stop bit length 1 bit 	P1. 120
	Parity Check	Even parity, stop bit length 1 bit	
	Error check	CRC code check	_
	Terminator	Not used	_
Waiting time	e setting	Not used	_

(2) Outline


The Modbus protocol is the communication protocol developed by Modicon for PLC.

The Modbus protocol performs serial communication between the master and slave using the dedicated message frame. The dedicated message frame has the functions that can perform data read and write. Using the functions, you can read and write the parameter values from the inverter, write the input command of the inverter, and check the operating status. In this product, the inverter data are classified in the holding register area (register addresses 40001 to 49999). By accessing the assigned holding register address, the master can communicate with the inverter which is a slave.



There are two different serial transmission modes: ASCII (American Standard Code for Information Interchange) mode and RTU (Remote Terminal Unit) mode. This product supports only the RTU mode in which 1-byte (8-bit) data is transmitted as-is. Only the communication protocol is defined by the Modbus protocol, and the physical layer is not stipulated.

Message format



Data check time

Item	Check Time	
Various monitors, operation command,	<20ms	
frequency setting (RAM)	~201115	
Parameter read/write, frequency setting	<50ms	
(EEPROM)	\ 501115	
Parameter clear/all clear	<5s	
Reset command	No answer	

1) Query

The master sends a message to the slave (= inverter) at the specified address.

2) Normal Response

After receiving the query from the master, the slave executes the requested function and returns the corresponding normal response to the master.

3) Error Response

If an invalid function code, address or data is received, the slave returns it to the master.

When a response description is returned, the error code indicating that the request from the master cannot be executed is

No response is returned for the hardware-detected error, frame error and CRC check error.

4) Broadcast

By specifying address 0, the master can send a message to all slaves. All slaves that received the message from the master execute the requested function. In this communication, the slaves do not return a response to the master.



• REMARKS

The inverter performs the function independently of the inverter station number setting (Pr. 117) during broadcast communication.



(4) Message frame (protocol)

Communication method

Basically, the master sends a query message (question) and the slave returns a response message (response). When communication is normal, Device Address and Function Code are copied as they are, and when communication is abnormal (function code or data code is illegal), bit 7 (= 80h) of Function Code is turned ON and the error code is set to Data Bytes.

Query message from Master





Device Address
Function Code
Eight-Bit Data Bytes
Error Check

Response message from slave

The message frame consists of the four message fields as shown above.

By adding the no-data time (T1: Start, End) of 3.5 characters to the beginning and end of the message data, the slave recognizes it as one message.

Protocol details

The four message fields will be explained below.

Start	1) ADDRESS 2) FUNCTION		3) DATA	4) CRC	CHECK	End
T1	8bit	8bit	n×8bit	L 8bit	H 8bit	T1

Message Field		Description							
	The address code is 1 byte long (8 bits) and any of 0 to 247 can be set. Set 0 to send a broadcast								
1) ADDRESS field	message (all-address instruction) or any of 1 to 247 to send a message to each slave.								
I) ADDRESS IIEIU	When the sl	When the slave responds, it returns the address set from the master.							
	The value s	et to Pr. 117 PU communication	station number is the slave address.						
	The function	n code is 1 byte long (8 bits) a	nd any of 1 to 255 can be set. The m	aster sets the function					
	that it wants	to request from the slave, and	d the slave performs the requested or	peration. The following					
	table gives t	the supported function codes.	An error response is returned if the	set function code is					
	other than th	hose in the following table.							
	When the sl	ave returns a normal respons	e, it returns the function code set by	the master. When the					
	slave return	s an error response, it returns	H80 + function code.						
	Code	Function Name	Outline	Broadcast					
	Code	Function Name	Outilile	Communication					
	H03	Read Holding Register	Reads the holding register data.	Disallowed					
2) FUNCTION	H06	Preset Single Register	Writes data to the holding	Allowed					
field	Tioo Treset Single Register		register.	Allowed					
	H08	Diagnostics	Function diagnosis	Disallowed					
	1	2149.1001100	(communication check only)	2.0001.00					
	H10	Preset Multiple Registers	Writes data to multiple	Allowed					
			consecutive holding registers.						
	1140	Read Holding Register	Reads the number of registers that succeeded in communication	Disallowed					
	H46	Access Log	last time.	Disallowed					
	Table 1:Function code list								
	The format (changes depending on the fur	action code (Refer to page 232). Data in	ocludes the hyte count					
3) DATA field			, , , ,	iolades the byte count,					
		number of bytes, description of access to the holding register, etc. The received message frame is checked for error. CRC check is performed, and 2 byte long data is							
	added to the end of the message. When CRC is added to the message, the low-order byte is added								
		ollowed by the high-order byte							
4) CRC CHECK		, ,	ng side that adds CRC to the messa	ge. The receiving side					
field			ing, and compares the result of that of						
			field. If these two values do not mate						
	as error.	1000.700 III tilo Orto OrteOrt	note: If these two values do not mate	, and result is defined					
	वर्ष था।								



(5) Message format types

The message formats corresponding to the function codes in Table 1 on page 231 will be explained.

●Read holding register data (H03 or 03)

Can read the description of **1)** system environment variables, **2)** real-time monitor, **3)** faults history, and **4)** inverter parameters assigned to the holding register area (refer to the register list (page 237))

Query message

1) Slave Address	2) Function	Starting Address		No. of	Points	CRC Check		
(8bit)	H03	Н	L	Η	L	L	Н	
(ODIL)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

1) Slave 2) Function		Byte Count		Data	CRC Check		
(8bit)	H03	(8bit)	Н	L		L	Н
(obit)	(8bit)	(ODIL)	(8bit)	(8bit)	(n × 16bit)	(8bit)	(8bit)

Query message setting

Message	Setting Description
1) Slave Address	Address to which the message will be sent
1) Slave Address	Broadcast communication cannot be made (0 is invalid).
2) Function	Set H03.
	Set the address at which holding register data read will be started.
2) Starting Address	Starting address = Starting register address (decimal)-40001
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holding
	register 40002.
4) No. of Points	Number of holding registers from which data will be read
4) No. of Points	The number of registers from which data can be read is a maximum of 125.

Description of normal response

Message	Setting Description				
5) Byte Count	The setting range is H02 to HFA (2 to 250).				
5) Byte Count	Twice greater than the No. of Point specified at 4) is set.				
	The number of data specified at 4) is set. Data are read in order of Hi byte and Lo				
6) Data: Read data	byte, and set in order of starting address data, starting address + 1 data, starting				
	address + 2 data,				

Example: To read the register values of 41004 (Pr. 4) to 41006 (Pr. 6) from the slave address 17 (H11)

Query message

Slave Address	Function	Starting Address		No. of F	Points	CRC Check		
H11	H03	H03	HEB	H00	H03	H77	H2B	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

Slave Address	Function	Byte Count		Data					CRC Check	
H11	H03	H06	H17	H70	H0B	HB8	H03	HE8	H2C	HE6
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Read value

Register 41004(*Pr. 4*): H1770 (60.00Hz) Register 41005(*Pr. 5*): H0BB8 (30.00Hz) Register 41006(*Pr. 6*): H03E8 (10.00Hz)



• Write holding register data (H06 or 06)

Can write the description of 1) system environment variables and 4) inverter parameters assigned to the holding register area (refer to the register list (page 237)).

Query message

1) Slave Address	2) Function	3) Registe	r Address	4) Pres	et Data	CRC Check		
(8bit)	H06	Н	L	Н	L	L	Н	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

1) Slave Address	2) Function	2) Function 3) Register		4) Pres	et Data	CRC Check	
(Ohit)	H06	Н	L	Н	L	L	Н
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Query message setting

Message	Setting Description
1) Slave Address	Address to which the message will be sent
1) Slave Address	Setting of address 0 enables broadcast communication
2) Function	Set H06.
	Address of the holding register to which data will be written
2) Decister Address	Register address = Holding register address (decimal)-40001
3) Register Address	For example, setting of register address 0001 writes data to the holding register
	address 40002.
4) Propet Date	Data that will be written to the holding register
4) Preset Data	The written data is always 2 bytes.

Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message. No response is made for broadcast communication.

Example: To write 60Hz (H1770) to 40014 (running frequency RAM) at slave address 5 (H05).

Query message

Slave Address	Function	Register A	Preset	Data	CRC Check		
H05	H06	H00	H0D	H17	H17 H70		H99
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Same data as the query message



NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.



•Function diagnosis (H08 or 08)

A communication check can be made since the query message sent is returned unchanged as a response message (function of sub function code H00).

Sub function code H00 (Return Query Data)

Query message

1) Slave Address 2) Function		3) Subf	unction	4) [)ate	CRC Check		
(8bit)	H08	H00	H00	Н	L	L	Н	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

1) Slave Address	2) Function	3) Subfunction		4) [Date	CRC Check		
(8bit)	H08	H00	H00	Н	L	L	Н	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Query message setting

Message	Setting Description				
1) Slave Address	Address to which the message will be sent				
1) Slave Address	Broadcast communication cannot be made (0 is invalid).				
2) Function	Set H08.				
3) Subfunction	Set H0000.				
4) Data	Any data can be set if it is 2 bytes long. The setting range is H0000 to HFFFF				

• Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.



NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.

• Write multiple holding register data (H10 or 16)

You can write data to multiple holding registers.

Query message

, -	Slave dress	2) Function		ting ress	_) . of sters	5) ByteCount		6) Data		CRC Check	
(8	Bbit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	(8bit)	H (8bit)	L (8bit)	 (n×2×8bit)	L (8bit)	H (8bit)

Normal response (Response message)

1)Slave Address	1)Slave Address 2)Function		Address	4)No. of I	Registers	CRC Check		
(8bit)	H10	H	L	H	L	L	H	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

· Query message setting

Message	Setting Description				
1) Clave Address	Address to which the message will be sent				
1) Slave Address	Setting of address 0 enables broadcast communication				
2) Function	Set H10.				
	Address where holding register data write will be started				
2) Starting Address	Starting address = Starting register address (decimal)-40001				
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holdi				
	register 40002.				
4) No. of Dointo	Number of holding registers where data will be written				
4) No. of Points	The number of registers where data can be written is a maximum of 125.				
E) Pyto Count	The setting range is H02 to HFA (2 to 250).				
5) Byte Count	Set a value twice greater than the value specified at 4).				
	Set the data specified by the number specified at 4). The written data are set in				
6) Data	order of Hi byte and Lo byte, and arranged in order of the starting address data,				
	starting address + 1 data, starting address + 2 data				



• Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.

Example: To write 0.5s (H05) to 41007 (Pr. 7) at the slave address 25 (H19) and 1s (H0A) to 41008 (Pr.8).

Query message

Slave Address	Function		ting ress	No. of Points		Byte Count		Data				CRC Check	
H19	H10	H03	HEE	H00	H02	H04	H00	H05	H00	H0A	H86	H3D	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

Slave Address	Function	Starting Address		No. of	Points	CRC Check		
H19	H10	H03	HEE	H00	H02	H22	H61	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

• Read holding register access log (H46 or 70)

A response can be made to a query made by the function code H03 or H10.

The starting address of the holding registers that succeeded in access during previous communication and the number of successful registers are returned.

In response to the query for other than the above function code, 0 is returned for the address and number of registers.

Query message

1) Slave Address	2) Function	CRC (Check
(8bit)	H46	L	Н
	(8bit)	(8bit)	(8bit)

Normal response (Response message)

1) Slave Address	2) Function	3) Starting	g Address	4) No. o	f Points	CRC (Check
(8bit)	H46	H	L	H	L	L	H
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Query message setting

Message	Setting Description
1) Slave Address	Address to which the message will be sent
1) Slave Address	Broadcast communication cannot be made (0 is invalid).
2) Function	Set H46.

· Description of normal response

Message	Setting Description	
	The starting address of the holding registers that succeeded in access is returned.	
3) Starting Address	Starting address = Starting register address (decimal)-40001	
	For example, when the starting address 0001 is returned, the address of the	
	holding register that succeeded in access is 40002.	
4) No. of Points	The number of holding registers that succeeded in access is returned.	

Example: To read the successful register starting address and successful count from the slave address 25 (H19).

Query message

Slave Address	s Function CRC Check		Check
H19	H46	H8B	HD2
(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Slave Address	Function	Starting	Address	No. of	Points	CRC	Check
H19	H10	H03	HEE	H00	H02	H22	H61
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Success of two registers at starting address 41007 (Pr. 7) is returned.



• Error response

An error response is returned if the query message received from the master has an illegal function, address or data. No response is returned for a parity, CRC, overrun, framing or busy error.



No response message is sent in the case of broadcast communication also.

Error response (Response message)

1) Slave Address	Slave Address 2) Function		CRC Check	
(8bit)	H80 + Function	(8bit)	L	Н
(ODIL)	(8bit)	(ODIL)	(8bit)	(8bit)

Message	Setting Description
1) Slave Address	Address received from the master
2) Function	Master-requested function code + H80
3) Exception Code	Code in the following table

Error code list

Code	Error Item	Error Description
01	ILLEGAL FUNCTION	The set function code in the query message from the master cannot be
01	ILLEGAL FUNCTION	handled by the slave.
		The set register address in the query message from the master cannot be
02	02 ILLEGAL DATA ADDRESS *1	handled by the inverter.
		(No parameter, parameter read disabled, parameter write disabled)
		The set data in the query message from the master cannot be handled by the
03	ILLEGAL DATA VALUE	inverter.
		(Out of parameter write range, mode specified, other error)

- An error will not occur in the following cases.
 - 1) Function code H03 (Read holding register data)
 - When the No. of Points is 1 or more and there is one or more holding registers from which data can be read
 - 2) Function code H10 (Write multiple holding register data)
 - When the No. of Points is 1 or more and there is 1 or more holding registers to which data can be written

Namely, when the function code H03 or H10 is used to access multiple holding registers, an error will not occur if a non-existing holding register or read disabled or write disabled holding register is accessed.



(I) REMARKS

An error will occur if all accessed holding registers do not exist.

Data read from a non-existing holding register is 0, and data written there is invalid.

· Message data mistake detection

To detect the mistakes of message data from the master, they are checked for the following errors. If an error is detected, a trip will not occur.

Error check item

Error Item	Error Description	Inverter Operation
Darity orror	The data received by the inverter differs from the	
Parity error	specified parity (Pr. 120 setting).	
Framing arrar	The data received by the inverter differs from the	
Framing error	specified stop bit length (Pr. 120).	
Overrun error	The following data was sent from the master before	1) Pr.343 is increased by 1 at error
Overruit error	the inverter completes data receiving.	occurrence.
	The message frame data length is checked, and the	2)The terminal LF is output at error
Message frame error	received data length of less than 4 bytes is regarded	occurrence.
	as an error.	
	A mismatch found by CRC check between the	
CRC check error	message frame data and calculation result is	
	regarded as an error.	



(6) Modbus registers

System environment variable

Register	Definition	Read/write	Remarks
40002	Inverter reset	Write	Any value can be written
40003	Parameter clear	Write	Set H965A as a written value.
40004	All Parameter clear	Write	Set H99AA as a written value.
40006	Parameter clear *1	Write	Set H5A96 as a written value.
40007	All parameter clear *1	Write	Set HAA99 as a written value.
40009	Inverter status/control input instruction*2	Read/write	See below.
40010	Operation mode/inverter setting *3	Read/write	See below.
40014	Running frequency (RAM value)	Read/write	According to the <i>Pr.37</i> settings, the frequency
	3 - 4		and selectable speed are in 1r/min
40015	Running frequency (EEPROM value)	Write	increments.

- The communication parameter values are not cleared.
- *2 For write, set the data as a control input instruction. For read, data is read as an inverter operating status.
- For write, set data as the operation mode setting.
- For read, data is read as the operation mode status.

<Inverter status/control input instruction>

Bit	Defir	ition
Dit	Control input instruction	Inverter status
0	Stop command	RUN (inverter running) *2
1	Forward rotation command	Forward rotation
2	Reverse rotation command	During reverse rotation
3	RH (high-speed operation	SU (up-to-frequency)
3	command)*1	30 (up-to-frequency)
4	RM (middle-speed operation	Ol (overload)
4	command)*1	OL (overload)
5	RL (low-speed operation	0
3	command)*1	O
6	0	FU (frequency detection) *2
7	RT (second function selection)	ABC (fault) *2
8	AU (current input selection)	0
9	0	0
10	MRS (output stop) *1	0
11	0	0
12	RES (reset) *1	0
13	0	0
14	0	0
15	0	Fault occurrence

<Operation mode/inverter setting>

Mode	Read Value	Written
Wiode	Reau value	Value
EXT	H0000	H0010
PU	H0001	_
EXT	H0002	
JOG	H0002	_
PU	H0003	
JOG	110003	_
NET	H0004	H0014
PU+EXT	H0005	

The restrictions depending on the operation mode changes according to the computer link specifications.

- *1 The signal within parentheses is the default setting. The description changes depending on the setting of Pr.180 to Pr.184 (input terminal function
 - Each assigned signal is valid or invalid depending on NET. (Refer to page 201)
- *2 The signal within parentheses is the default setting. Definitions change according to the Pr.190 to Pr.192 (output terminal function selection). (Refer to page 141)

●Real time monitor

Refer to page 150 for details of the monitor description.

Register	Description	Unit
40201	Output frequency/speed *1	0.01Hz/1
40202	Output current	0.01A
40203	Output voltage	0.1V
40205	Output frequency setting/speed	0.01Hz/1
40203	setting *1	0.01112/1
40207	Motor torque	0.1%
40208	Converter output voltage	0.1V
40209	Regenerative brake duty	0.1%
40210	Electronic thermal relay function	0.1%
40210	load factor	0.176
40211	Output current peak value	0.01A
40212	Converter output voltage peak value	0.1V
40214	Output power	0.01kW
40215	Input terminal status *2	_

Register	Description	Unit
40216	Output terminal status *3	_
40220	Cumulative energization time	1h
40223	Actual operation time	1h
40224	Motor load factor	0.1%
40225	Cumulative power	1kWh
40252	PID set point	0.1%
40253	PID measured value	0.1%
40254	PID deviation	0.1%
40258	Option input terminal status*4	_
40259	Option input terminal status 2*5	_
40260	Option output terminal status *6	_
40261	Motor thermal load factor	0.1%
40262	Inverter thermal load factor	0.1%
40263	Cumulative power 2 (Ver.UP)	0.01kWh

Ver.UP Specifications differ according to the date assembled. Refer to page 324 to check the SERIAL number.

Communication operation and setting

*1 *2	When Pr.3				•			stop funct	ion model							
*2	b15	iii iai iiioiii	toi details	— IVINO IS	OII WIIC	an using ti	ie salety s	stop funct	on model	•						b0
	_	_	_	_		RES	_	MRS	-	RH	RM	RL	_	_	STR	STF
*3	Output ter	rminal mo	nitor detai	ls												
	b15															b0
		_	_	_		_	_	_	_	_	ABC	FU	_	_	_	RUN
*4	Details of	option inp	out termina	al monitor	1 (input te	erminal sta	atus of FR	R-A7AX E	kit)—all te	rminals a	re off whe	n an optio	n is not fit	tted.		
	b15															b0
	X15	X14	X13	X12	X11	X10	X9	X8	X7	X6	X5	X4	Х3	X2	X1	X0
*5	Details of	option in	out termina	al monitor	2 (input te	erminal sta	atus of FR	R-A7AX E	kit)—all te	rminals a	re off whe	n an optic	n is not fit	tted.		
	b15				` '				,			•				b0
	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	DY
*6	6 Details of option output terminal monitor (output terminal status of FR-A7AY E kit/A7AR E kit)—all terminals are off when an option is not fitted.															
	b15		•		, ,					, -						b0
	_	_	_	_	_	_	RA3	RA2	RA1	Y6	Y5	Y4	Y3	Y2	Y1	Y0



Parameter

Parameter	Register	Parameter Name	Read/ Write	Remarks
0 to 999	41000 to 41999	Refer to the parameter list (page 58) for the parameter names.	Read/write	The parameter number + 41000 is the register number.
C2(902)	41902	Terminal 2 frequency setting bias frequency	Read/write	
C3(902)	42092	Terminal 2 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C3 (902) is read.
03(902)	43902	Terminal 2 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the voltage applied to the terminal 2 is read.
125(903)	41903	Terminal 2 frequency setting gain frequency	Read/write	
C4(002)	42093	Terminal 2 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C4 (903) is read.
C4(903)	43903	Terminal 2 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the voltage applied to the terminal 2 is read.
C5(904)	41904	Terminal 4 frequency setting bias frequency	Read/write	
C6(904)	42094	Terminal 4 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C6 (904) is read.
C0(904)	43904	Terminal 4 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.
126(905)	41905	Terminal 4 frequency setting gain frequency	Read/write	
C7(905)	42095	Terminal 4 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C7 (905) is read.
C7(905)	43905	Terminal 4 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.

• Faults history

Register	Definition	Read/write	Remarks
40501	Fault history 1	Read/write	
40502	Fault history 2	Read	Being 2 bytes in length, the data is stored as
40503	Fault history 3	Read	"H0000".
40504	Fault history 4	Read	Refer to the lowest 1 byte for the error code.
40505	Fault history 5	Read	Performing write using the register 40501 batch-
40506	Fault history 6	Read	clears the faults history.
40507	Fault history 7	Read	Set any value as data.
40508	Fault history 8	Read	7

Fault code list

Data	Definition
H00	No fault
1100	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT
H31	E.THM

Data	Definition
H40	E.FIN
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
HA0	E.OPT
HA1	E.OP1
HB0	E.PE

Data	Definition
HB1	E.PUE
HB2	E.RET
HB3	E.PE2
HC0	E.CPU
HC5	E.IOH
HC7	E.AIE
HC8	E.USB
HC9	E.SAF
HD8	E.MB4
HD9	E.MB5

Data	Definition
HDA	E.MB6
HDB	E.MB7
HF1	E.1
HF5	E.5
HF6	E.6
HF7	E.7
HFD	E.13

^{*} Refer to page 279 for details of fault description.

(7) Pr. 343 Communication error count

You can check the cumulative number of communication errors.

Parameter	Setting Range	Minimum	Initial Value	
Parameter	Setting Range	Setting Range	illitiai value	
343	(Reading only)	1	0	




NOTE

The number of communication errors is temporarily stored into the RAM. As it is not stored into the EEPROM performing a power supply reset or inverter reset clears the value to 0.

(8) Output terminal LF "alarm output (communication error warnings)"

During a communication error, the alarm signal (LF signal) is output by open collector output. Assign the used terminal using any of *Pr. 190 to Pr. 192 (output terminal function selection)*.





NOTE

The LF signal can be assigned to the output terminal using any of Pr.190 to Pr.192. Changing the terminal assignment may affect the other functions. Set parameters after confirming the function of each terminal.



4.20.7 USB communication (Pr. 547, Pr. 548)

Inverter setup can be easily performed using the FR Configurator by connecting the inverter and personal computer with a USB cable.


• A personal computer and inverter can be easily connected with one USB cable.

Parameter Number	Name	Initial Value	Setting Range	Description
547*	USB communication station number	0	0 to 31	Inverter station number specification
548*	USB communication check time interval		0	USB communication is possible Trips in the PU operation mode (E.USB)
		9999	0.1 to 999.8s	Sets the interval of communication check time. If a no-communication state persists for longer than the permissible time, the inverter trips (E.USB).
			9999	No communication check

^{*} Changed setting value is valid when powering on or resetting the inverter.

USB communication specifications

Interface	Conforms to USB1.1
Transmission	
Speed:	12Mbps
Wiring Length	Maximum 5m
Connector	USB mini B connector (receptacle mini B type)
Power supply	Self-power supply



· You can perform parameter setting and monitoring with the FR Configurator. Refer to the instruction manual of the FR Configurator for details.



• REMARKS

USB cable available on the market

Name	Model	Application/Specifications			
USB cable	MR-J3USBCBL3M Cable length 3m	Connector for amplifier mini-B connector (5 pin)	Connector for personal computer A connector		



Parameters referred to

Pr. 551 PU mode operation command source selection 👺 Refer to page 201

4.21 Special operation and frequency control

Purpose	Parameter t	Refer to Page	
Perform process control such as pump and air volume.	PID control	Pr. 127 to Pr. 134	242
Dancer control	PID control (dancer control setting)	Pr. 44, Pr. 45, Pr. 128 to Pr. 134	249
Frequency control appropriate for load torque	Droop control	Pr. 286, Pr. 287	256
Avoid overvoltage alarm due to regeneration by automatic adjustment of output frequency	Regeneration avoidance function	Pr. 882, Pr. 883, Pr. 885, Pr. 886	257

4.21.1 PID control (Pr. 127 to Pr. 134)

The inverter can be used to exercise process control, e.g. flow rate, air volume or pressure.

The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal used as a feedback value to constitute a feedback system for PID control.

Parameter	Nama	Initial	Setting	Description				
Number	Name	Value	Range		Descri	puon		
127	PID control automatic	9999	0 to 400Hz	Frequency at which	the control is aut	omatically changed to PID control.		
127	switchover frequency	9999	9999	Without PID automa	tic switchover function			
			0	PID action is not per	ID action is not performed			
			20	PID reverse action	Measured value (terminal 4)			
			21	PID forward action	Set value (termi	nal 2 or <i>Pr. 133</i>)		
			40	PID reverse action	Addition	For dancer control		
			41	PID forward action	method: fixed	set point (<i>Pr. 133</i>), - measured value (terminal 4)		
128	PID action selection	0	42	PID reverse action	Addition	main speed (frequency command		
			43	PID forward action	method: ratio	of the operation mode)		
			50	PID reverse action	Deviation value	signal input (LonWorks, CC-Link		
			51	PID forward action	communication)		
			60	PID reverse action	Measured value	e, set point input (LonWorks, CC-		
			61	PID forward action	Link communica	ation)		
				If the proportional ba	and is narrow (pa	rameter setting is small), the		
			0.1 to	manipulated variable varies greatly with a slight change of the				
129 *1	PID proportional band	100%	1000%	measured value. Hence, as the proportional band narrows, the				
125 *1	PID proportional band	100 /0	1000%	response sensitivity (gain) improves but the stability deteriorates, e.g.				
				hunting occurs. Gain Kp= 1/proportional band				
			9999	No proportional cont				
				When deviation step is input, time (Ti) is the time required for integral (
			0.1 to	action to provide the same manipulated variable as the proportional (F action. As the integral time decreases, the set point is reached earlier but hunting occurs more easily.				
130 *1	PID integral time	1s	3600s					
			9999	No integral control.				
				Maximum value				
			0 to	If the feedback value exceeds the setting, the FUP signal is output. The				
131	PID upper limit	9999	100%	. `	nA/5V/10V) of the	e measured value (terminal 4) is		
				equivalent to 100%.				
			9999	No function				
			0 4-	Minimum frequency	falla hala U	Atting against the EDN street to		
132	DID lower limit	0000	0 to			etting range, the FDN signal is		
132	PID lower limit	9999	100%	•		V/10V) of the measured value		
			9999	(terminal 4) is equiva	alent to 100%.			
			0 to 100%	No function W Used to set the set point for PID control.				
133 *1	PID action set point	9999	9999	Terminal 2 input is the		IOI.		
					•	equired for providing only the		
	PID differential time	9999	0.01 to	For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential				
134 *1			10.00s	· •		nade to a deviation change.		
			9999	No differential contro	•	iado to a deviation change.		
The above para	The above parameters can be set when $Pr = 160 \ User group read selection = "0" (Refer to page 184)$							


The above parameters can be set when Pr. 160 User group read selection ="0". (Refer to page 184)

^{*1} This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



(1) PID control basic configuration

•Pr. 128 = "20, 21" (measured value input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time


(2) PID action overview

1)PI action

A combination of proportional control action (P) and integral control action (I) for providing a manipulated variable in response to deviation and changes with time.

[Operation example for stepped changes of process value]

(Note) PI action is the sum of P and I actions.




2)PD action

A combination of proportional control action (P) and differential control action (D) for providing a manipulated variable in response to deviation speed to improve the transient characteristic.

[Operation example for proportional changes of process value]


(Note) PD action is the sum of P and D actions.



3)PID action

The PI action and PD action are combined to utilize the advantages of both actions for control.

(Note) PID action is the sum of P, I and D actions.




4)Reverse operation

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is positive, and decreases the manipulated variable if deviation is negative.



5)Forward action

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is negative, and decreases the manipulated variable if deviation is positive.



Relationships between deviation and manipulated variable (output frequency)

	Deviation				
	Positive Negative				
Reverse action	71	צ			
Forward action	K	7			

(3) Connection diagram

Source logic


•Pr. 128 = 20

•Pr. 182 = 14

•*Pr.* 190 = 15

•Pr. 191 = 14

•Pr. 192 = 16



- *1 The power supply must be selected in accordance with the power specifications of the detector used.
- *2 The used output signal terminal changes depending on the Pr. 190 to Pr. 192 (output terminal selection) setting.
- *3 The used input signal terminal changes depending on the Pr. 178 to Pr. 184 (input terminal selection) setting.
- *4 The AU signal need not be input.



(4) I/O signals and parameter setting

- •Set "20, 21, 50, 51, 60 or 61" in Pr. 128 to perform PID operation.
- Set "14" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal ON.

When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.

• Enter the set point using the inverter terminal 2 or Pr. 133 and enter the measured value to terminal 4.



• REMARKS

- When Pr. 128 = "0" or X14 signal is OFF, normal inverter operation is performed without PID action.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables

	Signal Terminal Used		Function	Description	Parameter Setting	
	X14	Depending on	PID control	Turn ON X14 signal to perform PID	Set 14 in any of <i>Pr. 178</i> to <i>Pr.</i>	
	X14	Pr. 178 to Pr. 184	selection	control. *1	184.	
				You can input the set point for PID	<i>Pr. 128</i> = 20, 21,	
	2	2	Set point input	control.	<i>Pr. 133</i> = 9999	
	2	2	Set point input	0 to 5V 0 to 100%	<i>Pr.</i> 73 = 1 *2, 11	
				0 to 10V 0 to 100%	<i>Pr.</i> 73 = 0, 10	
	PU		Set point input	Set the set point (Pr. 133) from the	<i>Pr. 128</i> = 20, 21	
	FU	_	Set point input	operation panel.	<i>Pr. 133</i> = 0 to 100%	
Input				Input the signal from the detector	<i>Pr. 128</i> = 20, 21	
lub			Measured value	(measured value signal).	17. 120 – 20, 21	
	4	4		4 to 20mA 0 to 100%	<i>Pr. 267</i> = 0 *2	
			input	0 to 5V 0 to 100%	<i>Pr. 267</i> = 1	
				0 to 10V 0 to 100%	Pr. 267 = 2	
			Deviation value	Inputs the deviation value from	D: 120 - FO F1	
	Communication		input	LONWORKS, CC-Link communication.	<i>Pr. 128</i> = 50, 51	
		*3	Set point, measured	Inputs the set point and deviation value		
	*3		value input	from LonWorks, CC-Link	<i>Pr. 128</i> = 60, 61	
			value iriput	communication.		
				Output to indicate that the process value	<i>Pr. 128</i> = 20, 21, 60, 61	
	FUP		Upper limit output	signal exceeded the maximum value (Pr.	<i>Pr. 131</i> ≠ 9999	
	1 01	-UP		131).	Set 15 or 115 in any of <i>Pr. 190</i>	
				131).	to Pr. 192 *4	
					<i>Pr. 128</i> = 20, 21, 60, 61	
	FDN		Lower limit output	Output when the process value signal	<i>Pr. 132</i> ≠ 9999	
	1511	Depending on	Lower mine output	falls below the minimum value (Pr. 132).	Set 14 or 114 in any of <i>Pr. 190</i>	
Ħ		Pr. 190 to Pr. 192			to Pr. 192. *4	
Output		17. 190 10 17. 192		"Hi" is output to indicate that the output		
0			Forward (reverse)	indication of the parameter unit is	Set 16 or 116 in any of Pr. 190	
	RL		rotation direction	forward rotation (FWD) or "Low" to	to Pr. 192. *4	
			output	indicate that it is reverse rotation (REV)	1017.192.**4	
				or stop (STOP).		
	PID		During PID control	Turns ON during PID control.	Set 47 or 147 in any of Pr. 190	
	110		activated	•	to Pr. 192. *4	
	SE	SE	Output terminal	Common terminal for open collector		
	NAME OF THE WAY STONE OF	<u> </u>	common	output terminal.		


- When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.
- The shaded area indicates the parameter initial value.
- Refer to the CC-Link communication option (FR-A7NC E kit) instruction manual for the setting method from CC-Link communication.
- Refer to the LonWorks communication option (FR-A7NL E kit) instruction manual for the setting method from LonWorks communication.
- When 100 or larger value is set in any of Pr.190 to Pr.192 (output terminal function selection), the terminal output has negative logic. (For details, Refer to page 141)



- Changing the terminal function using any of Pr. 178 to Pr. 184 and Pr. 190 to Pr. 192 may affect the other functions. Set parameters after confirming the function of each terminal.
- When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 172 for setting)

(5) PID automatic switchover control (Pr. 127)

- •The system can be started up without PID control only at a start.
- •When the frequency is set to *Pr. 127 PID control automatic switchover frequency* within the range 0 to 400Hz, the inverter starts up without PID control from a start until output frequency is reached to the set frequency of *Pr. 127*, and then it shifts to PID control. Once the system has entered PID control operation, it continues PID control if the output frequency falls to or below *Pr.127*.




(6) PID monitor function

- •The PID control set point, measured value and deviation value can be displayed on the operation panel and output from terminal AM.
- •Integral value indicating a negative % can be displayed on the deviation monitor. 0% is displayed as 1000. (The deviation monitor cannot be output from the terminal AM.)
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 158 AM terminal function selection.

Setting	Monitor Description	Minimum Increments	Terminal AM Full Scale	Remarks
52	PID set point	0.1%	100%	
53	PID measured value	0.1%	100%	_
54	PID deviation	0.1%	_	Value cannot be set to <i>Pr. 158</i> . Displays 1000 when the PID deviation is 0%.




(7) Adjustment procedure



(8) Calibration example

(A detector of 4mA at 0°C and 20mA at 50°C is used to adjust the room temperature to 25°C under PID control. The set point is given to across inverter terminals 2-5 (0 to 5V).)



*When calibration → Using calibration *Pr. 902* and *Pr. 903* (terminal 2) or *Pr. 904* and *Pr. 905* (terminal is required 4), calibrate the detector output and target setting input.

Make calibration in the PU mode during an inverter stop.

<Set point input calibration>

- 1. Apply the input voltage of 0% set point setting (e.g. 0V) across terminals 2-5.
- 2. Enter in C2 (Pr. 902) the frequency which should be output by the inverter at the deviation of 0% (e.g. 0Hz).
- 3. In C3 (Pr.902), set the voltage value at 0%.
- 4. Apply the voltage of 100% set point (e.g. 5V) to across terminals 2-5.
- 5. Enter in Pr.125 the frequency which should be output by the inverter at the deviation of 100% (e.g. 50Hz).
- 6. In C4 (Pr.903), set the voltage value at 100%.


<Measured value calibration>


- 1. Apply the input current of 0% measured value (e.g. 4mA) across terminals 4-5.
- 2. Make calibration using C6 (Pr. 904).
- 3. Apply the input current of 100% measured value (e.g. 20mA) across terminals 4-5.
- 4. Make calibration using C7 (Pr. 905).


(I) REMARKS

• The frequency set in C5 (Pr. 904) and Pr. 126 should be the same as set in C2 (Pr. 902) and Pr. 125.

The results of the above calibration are as shown below:









- If the RH, RM, RL signal (multi-speed) or JOG signal (Jog operation) is entered with the X14 signal ON, PID control is stopped and multi-speed or Jog operation started.
- If the setting is as follows, PID control becomes invalid.


Pr. 79 Operation mode selection ="6" (switchover mode)

When the inverter is at a stop with Pr. 261 Power failure stop selection selected.

- Changing the terminal function using any of Pr. 178 to Pr. 184, Pr. 190 to Pr. 192 may affect the other functions. Set parameters after confirming the function of each terminal.
- When PID control is selected, the minimum frequency is the frequency set in Pr. 902 and the maximum frequency is the frequency set in Pr. 903.

Pr. 1 Maximum frequency and Pr. 2 Minimum frequency settings are also valid.

- The remote operation function is invalid during PID operation.
- When the control is switched to PID control during normal operation, the frequency command value calculated by PID operation using 0Hz as standard is used without the frequency during the operation.



Operation when control is switched to PID control during normal operation



Parameters referred to

Pr. 59 Remote function selection Refer to page 102

Pr. 73 Analog input selection Refer to page 172

Pr. 79 Operation mode selection Refer to page 190

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141

Pr. 261 Power failure stop selection Refer to page 164

C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain 🖫 Refer to page 175



4.21.2 Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)

Performs PID control by feedbacking the position detection of the dancer roller, controlling the dancer roller is in the specified position.

Parameter Number	Name	Initial Value	Setting Range		Description		
44	Second acceleration/ deceleration time	FR-E740-095(SC) or less FR-E720S-110(SC) or less FR-E740-120(SC) and 170(SC) 10s FR-E740-230(SC) and 300(SC) 15s	0 to 3600/360s	the main spe	This parameter is the acceleration time of the main speed during dancer control. It want not function as second acceleration/ deceleration time.		
45	Second deceleration time	9999	0 to 3600/360s 9999	the main spe	This parameter is the deceleration time of the main speed during dancer control. It will be a speed to the control of the main speed during dancer control.		
			0		not function as second deceleration time. PID action is not performed		
			20	PID reverse action	reverse Measured value (terminal 4)		
			21	PID forward action	133)		
			40	PID reverse action	Addition method: fixed	For dancer control	
			41	PID forward action	Addition method: fixed	set point (Pr. 133), measured value	
128	PID action selection	0	42	PID reverse action	Addition method: ratio	(terminal 4) main speed (speed	
			43	PID forward action	Addition command of to operation moderatio		
			50	PID reverse action	Deviation value signal input (LonWorks, CC-Link communication) Set point and measured value input (LonWorks, CC-Link		
			51	PID forward action			
			60	PID reverse action			
			61	communication)			
				(parameter s	tional band is setting is smal variable varie		
129 *1	PID proportional	100%	0.1 to 1000%	slight change of the measured value.			
120 - 1	band	10070		Hence, as the proportional band narrows, the response sensitivity (gain) improves but			
				the stability deteriorates, e.g. hunting occurs. Gain Kp = 1/proportional band			
			9999	No proportio		ortional band	
			0000			ut, time (Ti) is the	
				time required	d for integral (I) action to	
400 - 1	DID into and times	_	0.1 to 3600s	-	•	ated variable as	
130 *1	PID integral time	1s				i. As the integral pint is reached	
					unting occurs		
			9999	No integral control.			
				Maximum va			
			0 t- 4000/			eeds the setting,	
131	PID upper limit	9999	0 to 100%	_	the FUP signal is output. The maximum		
				input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%.			
			9999	No function	· · · · · · · · · · · · · · · · · · ·		


Parameter Number	Name	Initial Value	Setting Range	Description
132	PID lower limit	9999	0 to 100%	Minimum value If the process value falls below the setting range, the FDN signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%.
			9999	No function
400 - 1	PID action set	9999	0 to 100%	Used to set the set point for PID control.
133 *1	point		9999	Always 50%
134 *1	PID differential time	9999	0.01 to 10.00s	For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential time increases, greater response is made to a deviation change.
			9999	No differential control.

The above parameters can be set when *Pr.160 User group read selection* ="0". (*Refer to page 184*)

*1 This parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

rol 🌾

(1) Dancer control block diagram



*1 The main speed can be selected from all operation mode such as external (analog voltage input, multi-speed), PU (digital frequency setting), communication (RS-485, CC-Link).

Set point and measured value of PID control

				Current/Voltage Input Switch		
	Input	Input Signal	Pr.267 Setting	Standard control circuit terminal model	Safety stop function model	
Set point	Pr. 133	0 to 100%	_	_	_	
Measured	When measured value is input as current (4 to 20mA)	4mA 0%, 20mA 100%	0	I V	VI	
value	When measured value is input as voltage	0V 0%, 5V 100%	1		VI	
	(0 to ± 5 V or 0 to ± 10 V)	0V 0%, 10V 100%	2			




NOTE

- Changing the terminal function using any of *Pr. 178 to Pr. 184* may affect the other functions. Set parameters after confirming the function of each terminal.
- When the *Pr. 267* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 172* for setting)

(2) Dancer control overview


Performs dancer control by setting 40 to 43 in *Pr. 128 PID action selection*. The main speed command is the speed command of each operation mode (External, PU, Network). Performs PID control by the position detection signal of the dancer roller, then the result is added to the main speed command. For acceleration/deceleration of the main speed, set the acceleration time in *Pr. 44 Second acceleration/deceleration time* in *Pr. 45 Second deceleration time*.

* Set 0s normally to Pr. 7 Acceleration time and Pr. 8 Deceleration time. When the Pr. 7 and Pr. 8 setting is large, response of dancer control during acceleration/deceleration is slow.



(3) Connection diagram

- Source logic
- Pr. 128 = 41
- •*Pr.* 182 = **14**
- •*Pr.* 190 = **15**
- •*Pr.* 191 = **14**
- •Pr. 192 = 16



- *1 The main speed command differs according to each operation mode (external, PU, communication)
- *2 The used output signal terminal changes depending on the Pr. 190 to Pr. 192 (output terminal selection) setting.
- *3 The used input signal terminal changes depending on the Pr. 178 to Pr. 184(input terminal selection) setting.
- *4 The AU signal need not be input.



(4) I/O signals and parameter setting

- •Set "40 to 43" in Pr. 128 to perform dancer control.
- •Set "14" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal ON.

When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.

- •Input the main speed command (External, PU, Network). The main speed command in any operation mode can be input. (Note that terminal 4 can not be used as the main speed command.)
- •Input the set point using Pr. 133, then input the measured value signal (dancer roller position detection signal) across terminal 4 and 5 of the inverter.



(I) REMARKS

- When Pr. 128 = "0" or X14 signal is OFF, normal inverter operation is performed without dancer control.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables

S	ignal	Terminal Used	Il Used Function Description		Parameter Setting
	X14	' '		Turn ON X14 signal to perform dancer	Set 14 in any of Pr. 178 to Pr. 184.
	<i>Pr. 178</i> to <i>Pr. 184</i> sel		selection	control. *1	Set 14 III ally 0117. 178 to 17. 184.
				Input the signal from the dancer roller	<i>Pr.128</i> = 40, 41, 42, 43
Input			Measured value	detector (measured value signal).	17.120 - 40, 41, 42, 40
<u>-</u>	4	4		4 to 20mA 0 to 100%	<i>Pr.267</i> = 0 *2
			input	0 to 5V 0 to 100%	<i>Pr.267</i> = 1
				0 to 10V 0 to 100%	<i>Pr.</i> 267 = 2
				Output to indicate that the measured	<i>Pr.128</i> = 40, 41, 42, 43
	FUP		Linnar limit autaut	value signal exceeded the maximum	<i>Pr.131</i> ≠ 9999
	FUP		Upper limit output	value	Set 15 or 115 in any of Pr. 190 to Pr. 192.
				(Pr. 131).	*3
			Lower limit output		<i>Pr.128</i> = 40, 41, 42, 43
	FDN			Output when the measured value signal	<i>Pr.132</i> ≠ 9999
	LDIN			falls below the minimum value (Pr. 132).	Set 14 or 114 in any of Pr. 190 to Pr. 192.
Output					*3
Out			Forward (reverse)	Output is "ON" when the output	
	RL		rotation direction	indication of the parameter unit is	Set 16 or 116 in any of Pr. 190 to Pr. 192.
	KL		output	forward rotation (FWD) and "OFF" when	*3
			output	reverse rotation (REV) or stop (STOP).	
	PID		During PID control	Turns ON during PID control.	Set 47 or 147 in any of Pr. 190 to Pr. 192.
	ני		activated	G	*3
	SE	SE	Output terminal	Common terminal for open collector	
)	01	common	output terminal.	


- When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.
- The shaded area indicates the parameter initial value.
- When 100 or larger value is set in any of Pr. 190 to Pr. 192 (output terminal function selection), the terminal output has negative logic. (For details, Refer to page 141)



- Changing the terminal function using any of Pr. 178 to Pr. 184 and Pr.190 to Pr.192 may affect the other functions. Set parameters after confirming the function of each terminal.
 - When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 172 for setting)

\overline{Z}

(5) Parameter details



•When ratio ($Pr.\ 128$ = "42, 43") is selected for addition method, PID control × (ratio of main speed) is added to the main speed. The ratio is determined by the $Pr.\ 125$ Terminal 2 frequency setting gain frequency and C2 ($Pr.\ 902$) Terminal 2 frequency setting bias frequency. The frequency setting signal is set to 0 to 50Hz in the range between 0 to 100% in the initial setting. The ratio is (×100%) when the main speed is 50Hz and (×50%) when 25Hz.



NOTE

- Even when C4 (Pr. 903) is set to other than 100%, the frequency setting signal is considered as 100%.
- Even when C3 (Pr. 903) is set to other than 0%, the frequency setting signal is considered as 0%.
- When C2 (Pr. 902) is set to other than 0Hz, the frequency setting signal is 0% when C2 (Pr. 902) is less than the set frequency
- •Turning X14 signal ON/OFF during operation by assigning X14 signal results in the following operation.

When X14 signal is ON: Uses output frequency unchanged as the main speed command and continues operation by dancer control.

When X14 signal is OFF: Ends dancer control and continues operation at the set frequency.

Pr. 128 Setting	PID Action	Addition Method	Set Point	Measured Value	Main Speed Command	
40 41	Reverse action Forward action	Fixed	Pr. 133	Terminal 4	Speed command for each	
42	Reverse action	Ratio	17.133	Terriniai 4	operation mode	
43	Forward action	Natio				

- •Action of *Pr. 129 PID proportional band, Pr. 130 PID integral time, Pr. 131 PID upper limit, Pr. 132 PID lower limit, Pr. 134 PID differential time* is the same as PID control. For the relationship of controlled variable (%) of PID control and frequency, 0% is equivalent to the set frequency of *Pr. 902* and 100% to *Pr. 903*.
- •For the *Pr. 133 PID action set point* setting, set frequency of *Pr. 902* is equivalent to 0% and *Pr. 903* to 100%. When *9999* is set in *Pr. 133*, 50% is the set point.



> REMARKS

Pr. 127 PID control automatic switchover frequency is invalid.

(6) Output signal

•Output terminal assignment during dancer control (PID control) operation

PID signal turns ON during dancer control (PID control) or at a stop by PID control (in the status PID operation being performed inside) (The signal is OFF during normal operation.)

For the terminal used for PID signal output, assign the function by setting "47 (positive logic) or 147 (negative logic)" in any of *Pr. 190* to *Pr. 192 (output terminal function selection)*.



NOTE

• Changing the terminal function using any of *Pr. 178* to *Pr. 184*, *Pr. 190* to *Pr. 192* may affect the other functions. Set parameters after confirming the function of each terminal.

(7) PID monitor function

- •The PID control set point and measured value can be output to the operation panel monitor display and terminal AM.
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 158 AM terminal function selection.

Setting	Monitor Description	Minimum	Terminal AM Full	Remarks	
Setting	Worldon Description	Increments	Scale	Remarks	
52	PID set point	0.1%	100%		
53	PID measured value	0.1%	100%	_	
54	PID deviation value	0.1%		Value cannot be set in Pr. 158.	
54			_	Displays 1000 when the PID deviation is 0%.	

(8) Priorities of main speed command


- •The priorities of the main speed speed command source when the speed command source is external are as follows. JOG signal > multi-speed setting signal (RL/RM/RH/REX) > 16 bit digital input (option) > terminal 2
- •The priorities of the main speed speed command source when "3" is set in *Pr. 79*. Multi-speed setting signal (RL/RM/RH/REX) > set frequency (digital setting by PU, operation panel)
- •Terminal 4 can not be selected as the main speed speed command even when AU terminal is turned ON.
- •Even when a remote operation function is selected by setting a value other than "0" in *Pr. 59*, compensation of the remote setting frequency to the main speed is ignored (changes to 0).



(9) Adjustment procedure

•Dancer roller position detection signal adjustment

When terminal 4 input is voltage input, 0V is minimum position and 5V(10V) is maximum position. When current is input, 4mA is minimum position and 20mA is maximum position. (initial value) When 0 to 7V is output from the potentiometer, it is necessary to calibrate *C7* (*Pr* .905) at 7V.



(Example) Control at a dancer center position using a 0 to 7V potentiometer

- 1) After changing the current/voltage input switch to "V", set "2" in Pr. 267 to change terminal 4 input to voltage input.
- 2) Input 0V to across terminal 4 and 5 to calibrate *C6* (*Pr. 904*). (% display displayed at analog calibration is irrelevant to % of the feed back value.)
- 3) By inputting 7V to across terminal 4 to 5, calibrate C7(Pr. 905) (% display displayed at analog calibration is irrelevant to % of the feed back value.)
- 4) Set 50% in Pr.133.



NOTE

When the *Pr. 267* setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 172* for setting)



> REMARKS

- PID control stops when RH, RM, RL, and REX signal (for multi-speed operation signal) or JOG signal is input during normal PID control. However, PID control continues when those signals are input during dancer control since these are treated as speed commands.
- During dancer control, *Second acceleration/deceleration time* of *Pr.44* and *Pr.45* are the parameters for acceleration/deceleration time setting to the main speed command source. They do not function as the second function.
- When switchover mode is set with "6" in Pr. 79, dancer control (PID control) is invalid.
- Speed command input to terminal 4 by AU signal is invalid when dancer control is selected.
- Acceleration/deceleration of the main speed command is the same operation as when frequency command is increased/ decreased by analog input.
 - Therefore, SU signal remains ON even if the starting signal is turned ON/OFF.(always in the constant speed state)
- The DC brake operation starting frequency when turning OFF the starting signal is not *Pr. 10* but a smaller value of either *Pr. 13* or 0.5Hz.
- The set frequency monitor is always variable as "main speed command+PID control".
- The main speed setting frequency accelerates for the acceleration/deceleration time set in *Pr. 44* and *Pr. 45* and the output frequency accelerates/decelerates for the acceleration/deceleration time set in *Pr. 7* and *Pr. 8*. Therefore, when the set time of *Pr. 7* and *Pr. 8* is longer than *Pr. 44* and *Pr. 45*, the output frequency accelerates/decelerates for the acceleration/deceleration time set in *Pr. 7* and *Pr. 8*.
- For the integral term limit, a smaller value of either the PID manipulated variable (%) value converted from the linear, interpolated *Pr. 1 Maximum frequency* with *Pr. 902* and *Pr. 903*, or 100% is used for limit.

 Although the output frequency is limited by the minimum frequency, operation limit of the integral term is not performed.



Parameters referred to


Pr. 59 Remote function selection Refer to page 102
Pr. 73 Analog input selection Refer to page 172
Pr. 79 Operation mode selection Refer to page 190
Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 135
Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141
C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain Refer to page 175

4.21.3 Droop control (Pr. 286 to Pr. 287) ADMEVC

This function is designed to balance the load in proportion to the load torque to provide the speed drooping characteristic under Advanced magnetic flux vector control.

This function is effective for balancing the load when using multiple inverters.

Parameter	Name	Initial	Setting	Description	
Number	Name	Value	Range	Description	
			0	Droop control is invalid (Normal operation)	
286	Droop gain	0%	0.1% to 100%	Droop control is valid Drooping amount at the rated torque as a percentage with respect to the rated motor frequency.	
287	Droop filter time constant	0.3s	0 to 1s	Time constant of the filter applied on the torque current.	



Droop compensation frequency = Torque current after filtering Rated value of torque current

(1) Droop control

- The output frequency is changed according to the magnitude of torque current under Advanced magnetic flux vector control.
 The drooping amount at the rated torque is set by the droop gain as a percentage using the rated frequency as a reference.
- The maximum droop compensation frequency is 120Hz.



> REMARKS

Set the droop gain to about the rated slip of the motor.

- Droop control is invalid during PID control operation.
- The maximum value of frequency after droop compensation is either 120Hz or Pr. 1 Maximum frequency, whichever is smaller.



Parameters referred to

Pr. 1 Maximum frequency Refer to page 92 PID control Refer to page 242



4.21.4 Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)

This function detects a regeneration status and increases the frequency to avoid the regenerative status.


 Possible to avoid regeneration by automatically increasing the frequency and continue operation if the fan happens to rotate faster than the set speed due to the effect of another fan in the same duct.


Parameter Number	Name	Initia	l Value	Setting Range	Description
	Regeneration			0	Regeneration avoidance function invalid
882	avoidance operation	0		1	Regeneration avoidance function is always valid
552	selection			2	Regeneration avoidance function is valid only during a constant speed operation
883	Regeneration avoidance operation level	200V class	400 VDC	300 to 800V	Bus voltage level at which regeneration avoidance operates. When the bus voltage level is set to low, overvoltage error will be less apt
		400V class	780 VDC		to occur. However, the actual deceleration time increases. The set value must be higher than the "power supply voltage $\times\sqrt{2}$
	Regeneration avoidance	6Hz		0 to 10Hz	Limit value of frequency which rises at activation of regeneration avoidance function.
885	compensation frequency limit value			9999	Frequency limit invalid
886	Regeneration avoidance voltage gain		00%	0 to 200%	Responsiveness at activation of regeneration avoidance. A larger setting will improve responsiveness to the bus voltage change. However, the output frequency could become unstable.
665	Regeneration avoidance frequency gain	100%		0 to 200%	When vibration is not suppressed by decreasing the $Pr.~886$ setting, set a smaller value in $Pr.~665$.


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) What is regeneration avoidance function? (Pr. 882, Pr. 883)

- •When the regeneration load is large, the DC bus voltage rises and an overvoltage fault (E. OV□) may occur. When this bus voltage rise is detected and the bus voltage level reaches or exceeds Pr. 883, increasing the frequency avoids the regeneration status.
- •The regeneration avoidance function is always ON when "1" is set in Pr. 882 and activated only during a constant speed when "2" is set in Pr. 882.












REMARKS

- The acceleration/deceleration ramp while the regeneration avoidance function is operating changes depending on the regeneration load.
- The DC bus voltage of the inverter is about √2 times as input voltage.
 When the input voltage is 220VAC, bus voltage is approximately 311VDC.
 When the input voltage is 440VAC, bus voltage is approximately 622VDC.
 However, it varies with the input power supply waveform.
- The *Pr. 883* setting should be kept higher than the DC bus voltage level. Otherwise, the regeneration avoidance function is always on even in the non-regeneration status and the frequency increases.
- While overvoltage stall (() is activated only during deceleration and stops the output frequency, the regeneration avoidance function is always on (*Pr.* 882 = 1) or activated only during a constant speed (*Pr.* 882 = 2) and increases the frequency according to the regeneration amount.



(2) Limit regeneration avoidance operation frequency (Pr. 885)

You can limit the output frequency compensated for (increased) by the regeneration avoidance function.

- •The frequency is limited to the output frequency (frequency prior to regeneration avoidance operation) + *Pr. 885 Regeneration avoidance compensation frequency limit value* during acceleration or constant speed. If the frequency increased by regeneration avoidance function exceeds the limit value during deceleration, the limit value is held until the output frequency falls to 1/2 of *Pr. 885*.
- •When the frequency increased by regeneration avoidance function has reached *Pr. 1 Maximum frequency*, it is limited to the maximum frequency.
- •When *Pr.* 885 is set to "9999", regeneration avoidance function operation frequency setting is invalid.

(3) Regeneration avoidance function adjustment (Pr. 665, Pr. 886)

•If the frequency becomes instable during regeneration avoidance operation, decrease the setting of *Pr. 886 Regeneration avoidance voltage gain*. Reversely, if sudden regeneration causes an overvoltage alarm, increase the setting.

When vibration is not suppressed by decreasing the *Pr. 886* setting, set a smaller value in *Pr. 665 Regeneration avoidance frequency gain*.



NOTE

- When regeneration avoidance operation is performed, $\Box \dot{L}$ (overvoltage stall) is displayed and the OL signal is output. Set the operation pattern at an OL signal output using Pr.156 Stall prevention operation selection. Set the output timing of the OL signal using Pr.157 OL signal output timer.
- · When regeneration avoidance operation is performed, stall prevention is also activated.
- The regeneration avoidance function cannot shorten the actual deceleration time taken to stop the motor. The actual
 deceleration time depends on the regeneration energy consumption capability. When shortening the deceleration
 time, consider using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (MRS type, FR-ABR etc.,) to
 consume regeneration energy at constant speed.
- When using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (MRS type, FR-ABR etc.,), set *Pr. 882* to "0 (initial value)" (regeneration avoidance function invalid). When using the regeneration unit, etc. to consume regeneration energy at deceleration, set *Pr. 882* to "2" (regeneration avoidance function valid only at a constant speed).



Parameters referred to

Pr. 1 Maximum frequency Refer to page 92
Pr. 8 Deceleration time Refer to page 105

Pr. 22 Stall prevention operation level Refer to page 88



Purpose	Parameter ti	Refer to Page	
Increase cooling fan life	Cooling fan operation selection	Pr. 244	259
	Inverter part life display	Pr. 255 to Pr. 259	260
To determine the maintenance time of parts.	Maintenance output function	Pr. 503, Pr. 504	264
or paris.	Current average value monitor signal	Pr. 555 to Pr. 557	265
Freely available parameter	Free parameter	Pr. 888, Pr. 889	267

4.22.1 Cooling fan operation selection (Pr. 244)

You can control the operation of the cooling fan (FR-E740-040(SC) or more, FR-E720S-050(SC) or more) built in the inverter.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Operates in power-ON status. Cooling fan ON/OFF control invalid (the cooling fan is always ON at power ON)
244	Cooling fan operation selection	1	1	Cooling fan ON/OFF control valid The fan is always ON while the inverter is running. During a stop, the inverter status is monitored and the fan switches ON-OFF according to the temperature.

The above parameters can be set when Pr.160 User group read selection = "0". (Refer to page 184)

- In either of the following cases, fan operation is regarded as faulty, [FN] is shown on the operation panel, and the fan fault (FAN) and alarm (LF) signals are output.
 - Pr. 244 = "0"

When the fan comes to a stop with power ON.

•Pr. 244 = "1"

When the inverter is running and the fan stops during fan ON command.

• For the terminal used for FAN signal output, set "25 (positive logic) or 125 (negative logic)" to any of *Pr. 190* to *Pr. 192 (output terminal function selection)*, and for the LF signal, set "98 (positive logic) or 198 (negative logic)".



NOTE

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr.190 to Pr.192 (output terminal function selection) 📭 Refer to page 141

4.22.2 Display of the life of the inverter parts (Pr. 255 to Pr. 259)

Degrees of deterioration of main circuit capacitor, control circuit capacitor, cooling fan and inrush current limit circuit can be diagnosed by monitor.

When any part has approached the end of its life, an alarm can be output by self diagnosis to prevent a fault.

(Use the life check of this function as a guideline since the life except the main circuit capacitor is calculated theoretically.)

For the life check of the main circuit capacitor, the alarm signal (Y90) will not be output if a measuring method of (4) is not performed.

Parameter	Name	Initial Value	Setting	Description	
Number	Name	iiiitiai vaiue	Range	Description	
				Displays whether the control circuit capacitor,	
255	Life alarm status display	0	(0 to 15)	main circuit capacitor, cooling fan, and each parts	
233	Life diaim status display	O	(0 to 13)	of the inrush current limit circuit has reached the	
				life alarm output level or not. (Reading only)	
	Inrush current limit circuit			Displays the deterioration degree of the inrush	
256	life display	100%	(0 to 100%)	current limit circuit.	
				(Reading only)	
	Control circuit capacitor life		(0 to 100%)	Displays the deterioration degree of the control	
257	display	100%		circuit capacitor.	
				(Reading only)	
				Displays the deterioration degree of the main	
258	Main circuit capacitor life	100%	(0 to 100%)	main circuit capacitor, cooling fan, and each parts of the inrush current limit circuit has reached the ife alarm output level or not. (Reading only) Displays the deterioration degree of the inrush current limit circuit. Reading only) Displays the deterioration degree of the control circuit capacitor. Reading only) Displays the deterioration degree of the main circuit capacitor. Reading only) The value measured by <i>Pr. 259</i> is displayed. Setting "1" and turning the power supply off starts the measurement of the main circuit capacitor life. When the <i>Pr. 259</i> value is "3" after powering on again, the measuring is completed.	
230	display	of the inrush current limit circuit has reache life alarm output level or not. (Reading only) Displays the deterioration degree of the inrucuit. (Reading only) Displays the deterioration degree of the corcircuit capacitor. (Reading only) Displays the deterioration degree of the corcircuit capacitor. (Reading only) Displays the deterioration degree of the macircuit capacitor. (Reading only) The value measured by Pr. 259 is displayed Setting "1" and turning the power supply off the measurement of the main circuit capacitic.	(Reading only)		
				The value measured by Pr. 259 is displayed.	
				Setting "1" and turning the power supply off starts	
	Main circuit capacitor life		0 1	the measurement of the main circuit capacitor life.	
259	•	0		When the Pr. 259 value is "3" after powering on	
	measuring		(2, 3, 6, 9)	main circuit capacitor, cooling fan, and each par of the inrush current limit circuit has reached the life alarm output level or not. (Reading only) Displays the deterioration degree of the inrush current limit circuit. (Reading only) Displays the deterioration degree of the control circuit capacitor. (Reading only) Displays the deterioration degree of the main circuit capacitor. (Reading only) The value measured by <i>Pr. 259</i> is displayed. Setting "1" and turning the power supply off star the measurement of the main circuit capacitor lift When the <i>Pr. 259</i> value is "3" after powering on again, the measuring is completed.	
				Writes deterioration degree in Pr. 258.	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)




(I) REMARKS

· Since repeated inrush currents at power ON will shorten the life of the converter circuit, frequent starts and stops of the magnetic contactor must be avoided.



(1) Life alarm display and signal output (Y90 signal, Pr. 255)

•Whether any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit has reached the life alarm output level or not can be checked by *Pr. 255 Life alarm status display* and life alarm signal (Y90).



Pr. 255 (decimal)	Bit (binary)	Inrush Current Suppression Circuit Life	Cooling Fan Life	Main Circuit Capacitor Life	Control Circuit Capacitor Life
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	×	×	×	×

O: With warnings, \times : Without warnings

- •The life alarm signal (Y90) turns ON when any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit reaches the life alarm output level.
- •For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) to any of *Pr. 190 to Pr. 192 (output terminal function selection)*.



NOTE

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Set parameters after confirming the function of each terminal.

(2) Inrush current limit circuit life display (Pr. 256)

- •The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in Pr. 256.
- •The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (0 times) every 1%/10,000 times.

As soon as 10% (900,000 times) is reached, Pr. 255 bit 3 is turned ON and also an alarm is output to the Y90 signal.

(3) Control circuit capacitor life display (Pr. 257)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 257 as a life.
- •In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%.

As soon as the control circuit capacitor life falls below 10%, *Pr. 255* bit 0 is turned ON and also an alarm is output to the Y90 signal.

Main circuit capacitor life display (Pr. 258, Pr. 259)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 258 as a life.
- •On the assumption that the main circuit capacitor capacitance at factory shipment is 100%, the capacitor life is displayed in Pr. 258 every time measurement is made.

When the measured value falls to or below 85%, Pr. 255 bit 1 is turned ON and also an alarm is output to the Y90 signal.

- ·Measure the capacitor capacity according to the following procedure and check the deterioration level of the capacitor capacity.
 - 1) Check that the motor is connected and at a stop.
 - 2) Set "1" (measuring start) in Pr. 259.
 - 3) Switch power OFF. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is
 - 4) After confirming that the LED of the operation panel is OFF, power ON again.
 - 5) Check that "3" (measuring completion) is set in Pr. 259, read Pr. 258, and check the deterioration degree of the main circuit capacitor.

Pr. 259	Description	Remarks	
0	No measurement	Initial value	
1	Measurement start	Measurement starts when the power supply	
'	Measurement start	is switched OFF.	
2	During measurement		
3	Measurement complete	Only displayed and cannot be set	
8	Forced end	Only displayed and calliot be set	
9	Measurement error		



> REMARKS

- When the main circuit capacitor life is measured under the following conditions, "forced end" (Pr. 259 = "8") or "measuring error" (Pr. 259 = "9") occurs or it remains in "measuring start" (Pr. 259 = "1"). Therefore, do not measure in such case.
 - In addition, even when "measurement completion" (Pr. 259 = "3") is confirmed under the following conditions, normal measurement can not be done.
 - (a) FR-HC, FR-CV is connected.
 - (b) DC power supply is connected to the terminal P/+ and N/-.
 - (c) The power supply switched ON during measurement.
 - (d) The motor is not connected to the inverter.
 - (e) The motor is running (coasting)
 - (f) The motor capacity is two rank smaller as compared to the inverter capacity.
 - (g) The inverter is tripped or a fault occurred when power is OFF.
 - (h) The inverter output is shut off with the MRS signal.
 - (i) The start command is given while measuring.
 - (j) The parameter unit (FR-PU04/FR-PU07) is connected.
 - (k) Use terminal PC as power supply.
 - (I) I/O terminal of the control terminal block and plug-in option is ON (continuity).
 - (m)Plug-in option is fitted. (only for the FR-E740-026(SC) or less, FR-E720S-050(SC) or less)
- Turning the power ON during measuring before LED of the operation panel turns OFF, it may remain in "measuring" (Pr. 259 = "2") status. In such case, carry out operation from step 2.



POINT

For accurate life measurement of the main circuit capacitor, wait 3 hours or longer after turning OFF. The temperature left in the main circuit capacitor affects measurement.





 $\cancel{\mathbb{A}}$ When measuring the main circuit capacitor capacity (Pr. 259 Main circuit capacitor life measuring = "1"), the DC voltage is applied to the motor for 1s at powering OFF. Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.



(5) Cooling fan life display

•The cooling fan speed of 50% or less is detected and "FN" is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). As an alarm display, Pr. 255 bit2 is turned on and also an alarm is output to the Y90 signal.



• REMARKS

• When the inverter is mounted with two or more cooling fans, "FN" is displayed with one or more fans with speed of 50% or less.



For replacement of each part, contact the nearest Mitsubishi FA center.


4.22.3 Maintenance timer alarm (Pr. 503, Pr. 504)

When the cumulative energization time of the inverter reaches the parameter set time, the maintenance timer output signal (Y95) is output. [17] (MT) is displayed on the operation panel.

This can be used as a guideline for the maintenance time of peripheral devices.

Parameter Number	Name	Initial Value	Setting Range	Description
503	Maintenance timer	0	0 (1 to 9998)	Displays the cumulative energization time of the inverter in 100h increments. (Reading only) Writing the setting of "0" clears the cumulative energization time.
504	Maintenance timer alarm output set time	9999	0 to 9998 9999	Time taken until when the maintenance timer alarm output signal (Y95) is output. No function

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



- The cumulative energization time of the inverter is stored into the EEPROM every hour and is displayed in Pr. 503 Maintenance timer in 100h increments. Pr. 503 is clamped at 9998 (999800h).
- When the Pr. 503 value reaches the time set to Pr. 504 Maintenance timer alarm output set time (100h increments), the maintenance timer alarm output signal (Y95) is output.
- For the terminal used for the Y95 signal output, assign the function by setting "95" (positive logic) or "195" (negative logic) to any of *Pr. 190 to Pr. 192 (output terminal function selection)*.



- The cumulative energization time is counted every hour. The energization time of less than 1h is not counted.
 Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141




4.22.4 Current average value monitor signal (Pr. 555 to Pr. 557)

The average value of the output current during constant speed operation and the maintenance timer value are output as a pulse to the current average value monitor signal (Y93).

The pulse width output to the I/O module of the programmable controller or the like can be used as a guideline due to abrasion of machines and elongation of belt and for aged deterioration of devices to know the maintenance time.


The current average value monitor signal (Y93) is output as pulse for 20s as 1 cycle and repeatedly output during constant speed operation.



Parameter Number	Name	Initial Value	Setting Range	Description
555	Current average time	1s	0.1 to 1.0s	Time taken to average the current during start pulse output (1s).
556	Data output mask time	0s	0.0 to 20.0s	Time for not obtaining (mask) transient state data.
557	Current average value monitor signal output reference current	Rated inverter current	0 to 500A	Reference (100%) for outputting the signal of the current average value.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



- The pulse output of the current average value monitor signal (Y93) is shown above.
- For the terminal used for the Y93 signal output, assign the function by setting "93" (positive logic) or "193" (negative logic) to *Pr. 190 and Pr. 191 (output terminal function selection)*. The function can not be assigned to *Pr. 192 A,B,C terminal function selection*.

1) Setting of Pr.556 Data output mask time

The output current is unstable (transient state) right after the operation is changed from the acceleration/deceleration state to the constant speed operation. Set the time for not obtaining (mask) transient state data in *Pr.* 556.

2) Setting of Pr. 555 Current average time

The average output current is calculated during Hi output of start pulse (1s). Set the time taken to average the current during start bit output in Pr. 555.

3) Setting of Pr. 557 Current average value monitor signal output reference current


Set the reference (100%) for outputting the signal of the current average value. Obtain the time to output the signal from the following calculation.

$\underline{ \text{Output current average value} } \times \text{5s (Output current average value 100\%/5s)}$

Note that the output time range is 0.5 to 9s and the output time is either of the following values when the output current average value is the corresponding percentage of the Pr. 557 setting.

Less than 10% ... 0.5s, more than 180% ... 9s

Example) when Pr. 557 = 10A and the average value of output current is 15A As 15A/10A x 5s=7.5, the current average value monitor signal is output as low pulse shape for 7.5s.




4) Setting of Pr. 503 Maintenance timer

After the output current average value is output as low pulse shape, the maintenance timer value is output as high pulse shape. The output time of the maintenance timer value is obtained from the following calculation.


$$\frac{Pr. 503 \times 100}{40000h} \times 5s \quad \text{(Maintenance timer value 100\%/5s)}$$

Note that the output time range is 2 to 9s, and it is 2s when the Pr. 503 setting is less than 16000h and 9s when exceeds 72000h.



• REMARKS

- Mask of data output and sampling of output current are not performed during acceleration/deceleration.
- When the speed is changed to acceleration/deceleration from constant speed during start pulse output, the data is judged as invalid, the start pulse is output as high pulse shape for 3.5s, and the end signal is output as low pulse shape for 16.5s. The signal is output for at least 1 cycle even when acceleration/deceleration state continues after the start pulse output is completed.



- When the output current value (inverter output current monitor) is 0A on completion of the 1 cycle signal output, the signal is not output until the speed becomes constant next time
- The current average value monitor signal (Y93) is output as low pulse shape for 20s (without data output) under the following condition.
- (a) When the motor is in the acceleration/deceleration state on completion of the 1 cycle signal output
- (b) When 1-cycle signal output was ended during restart operation with the setting of automatic restart after instantaneous power failure (*Pr. 57* ≠ "9999")
- When restart operation was being performed at the point of data output mask end with the setting of automatic restart after instantaneous power failure (Pr. 57 ≠ "9999")



NOTE

Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Set parameters after confirming the function of each terminal.



Parameters referred to

Pr. 57 Restart coasting time Refer to page 158 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 141 Pr. 503 Maintenance timer Refer to page 264



4.22.5 Free parameter (Pr. 888, Pr. 889)

You can input any number within the setting range 0 to 9999.

For example, the number can be used:

- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Parameter Number	Name	Initial Value	Setting Range	Description
888	Free parameter 1	9999	0 to 9999	Any values can be set. Data is held even
889	Free parameter 2	9999	0 to 9999	if the inverter power is turned OFF.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr.77 Parameter write selection.



Pr. 888 and Pr. 889 do not influence the inverter operation.

4.23 Setting from the parameter unit and operation panel

Purpose	Parameter	that should be Set	Refer to Page
Selection of rotation direction by (RUN) of the operation panel	RUN key rotation direction selection	Pr. 40	268
Switch the display language of the parameter unit	PU display language selection	Pr. 145	268
Use the setting dial of the operation panel like a potentiometer for frequency setting. Key lock of operation panel	Operation panel operation selection	Pr. 161	269
Change the magnitude of change of frequency setting by the setting dial of the operation panel	Magnitude of frequency change setting	Pr. 295	271
Control of the parameter unit buzzer	PU buzzer control	Pr. 990	272
Adjust LCD contrast of the parameter unit	PU contrast adjustment	Pr. 991	272

4.23.1 RUN key rotation direction selection (Pr. 40)

Used to choose the direction of rotation by operating (RUN) of the operation panel.

Parameter Number	Name	Initial Value	Setting Range	Description
40	RUN key rotation direction	0	0	Forward rotation
	selection	0	1	Reverse rotation

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

4.23.2 PU display language selection(Pr.145)

You can switch the display language of the parameter unit (FR-PU04/FR-PU07) to another.

Parameter Number	Name	Initial Value	Setting Range	Description	
			0	Japanese	
			1	English	
	PU display language selection	1	2	German	
145			1	3	French
145			4	Spanish	
			5	Italian	
			6	Swedish	
			7	Finnish	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)



4.23.3 Operation panel frequency setting/key lock operation selection (Pr. 161)


The setting dial of the operation panel can be used for setting like a potentiometer. The key operation of the operation panel can be disabled.

Parameter	Name	Initial Value	Setting	Description	
Number	Name	iiiidai value	Range		
			0	Setting dial frequency setting	Key lock invalid
161	Frequency setting/key lock operation selection	0	1	Setting dial potentiometer	Rey lock invalid
			10	Setting dial frequency setting	Koy look yolid
			11	Setting dial potentiometer	Key lock valid

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

(1) Using the setting dial like a potentiometer to set the frequency.

Operation example Changing the frequency from 0Hz to 50Hz during operation



REMARKS

- If the display changes from flickering "50.00" to "0.00", the setting of *Pr. 161 Frequency setting/key lock operation selection* may not be "4"
- · Independently of whether the inverter is running or at a stop, the frequency can be set by merely turning the dial.
- · When the frequency is changed, it will be stored in EEPROM as the set frequency after 10s.

(2) Disable the setting dial and key operation of the operation panel (Press [MODE] long (2s))

- Operation using the setting dial and key of the operation panel can be invalid to prevent parameter change, and unexpected start or frequency setting.
- •Set "10 or 11" in Pr. 161, then press (MODE) for 2s to make the setting dial and key operation invalid.
- •When the setting dial and key operation are invalid, **\\[\]** appears on the operation panel. If dial or key operation is attempted while dial and key operation are invalid, **Hill** appears. (When dial or key is not touched for 2s, monitor
- •To make the setting dial and key operation valid again, press (MODE) for 2s.



• REMARKS

• Even if the setting dial and key operation are disabled, the monitor display and (STOP) are valid.





- Release the operation lock to release the PU stop by key operation.
 When setting frequency by turning the setting dial, the frequency goes up to the set value of *Pr.1 Maximum frequency* (initial value: 120Hz). Adjust *Pr.1 Maximum frequency* setting according to the application.



4.23.4 Magnitude of frequency change setting (Pr. 295)

When setting the set frequency with the setting dial, frequency changes in 0.01Hz increments in the initial status. Setting this parameter increases the magnitude of frequency which changes according to the rotated amount of the setting dial, improving operability.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Function invalid
295	Magnitude of frequency change setting	0	0.01	The minimum varying width when the get
			0.10	The minimum varying width when the set frequency is changed by the setting dial can
			1.00	be set.
			10.00	be set.

The above parameter can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

The above parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

(1) Basic operation

When a value other than "0" is set in Pr. 295, the minimum varying width when the set frequency is changed by the setting dial can be set.

For example, when "1.00Hz" is set in Pr. 295, one click (one dial gauge) of the setting dial changes the frequency in increments of 1.00Hz→2.00Hz→3.00Hz.

When Pr. 295 = "1"



*One rotation of the setting dial equals to 24 clicks (24 dial gauges).



• REMARKS

- When machine speed display is selected with Pr. 37, the minimum increments of the magnitude of change is determined by Pr.295 as well. Note that the setting value may differ as speed setting changes the set machine speed and converts it to the speed display again.
- · When the set frequency (speed) is 100 or more, frequency is displayed in 0.1 increments. Therefore, the minimum varying width is 0.1 even when *Pr. 295* < 0.1.
- When the machine speed setting is 1000 or more, frequency is displayed in 1 increments. Therefore, the minimum varying width is 1 even when Pr. 295 < 1.



NOTE

- For Pr. 295, unit is not displayed.
 - This parameter is valid only in the set frequency mode. When other frequency-related parameters are set, it is not
- When 10 is set, frequency setting changes in 10Hz increments. Note the excess speed. (in potentiometer mode)

4.23.5 Buzzer control (Pr. 990)

You can make the buzzer "beep" when you press the key of the parameter unit (FR-PU04/FR-PU07).

Parameter Number	Name	Initial Value	Setting Range	Description
990	PU buzzer control	1 -	0	Without buzzer
990	PO buzzei control		1	With buzzer

The above parameter can be set when Pr. 160 User group read selection = "0". (Refer to page 184)

4.23.6 PU contrast adjustment (Pr. 991)

Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed. Decreasing the setting value makes contrast light.

Parameter Number	Name	Initial Value	Setting Range	Description
991	PU contrast adjustment	58	0 to 63	0: Light ↓ 63: Dark

The above parameter is displayed as simple mode parameter only when the parameter unit FR-PU04/FR-PU07 is connected.

The above parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

The above parameter allows its setting to be changed during operation in any operation mode even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.




4.24 Parameter clear/ All parameter clear



POINT

- Set "1" in Pr.CL Parameter clear, ALLC all parameter clear to initialize all parameters. (Parameters are not cleared when "1" is set in Pr. 77Parameter write selection.)
- Refer to the extended parameter list on page 58 for parameters cleared with this operation.



- Turn to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.

Setting	Description
0	Not executed.
	Set parameters back to the initial values. (Parameter clear sets back all parameters except
1	calibration parameters, terminal function selection parameters to the initial values.) Refer to the
	parameter list on page 58 for availability of parameter clear and all parameter clear.



> REMARKS

- if and E r if are displayed alternately ... Why?
 - The inverter is not in the PU operation mode.
 - PU connector or USB connector is used.
- 1. Press $\frac{PU}{EXT}$. [PU] is lit and the monitor (4 digit LED) displays "1". (When Pr: 79 = "0" (initial value))
- 2. Carry out operation from step 6 again.

4.25 Initial value change list

Displays and sets the parameters changed from the initial value.

Operation

- Screen at powering ON
 The monitor display appears.
- 2. Press $\frac{PU}{EXT}$ to choose the PU operation mode.
- 3. Press (MODE) to choose the parameter setting mode.
- 4. Turn until Pr.[H appears.
- 5. Pressing (SET) changes to the initial value change list screen.
- Turning displays the parameter number changed.
 - Press (SET) to read the currently set value.



(refer to step 6 and 7 on page 57)

- •Turn to read another parameter.
- •The display returns to P - after all parameters are displayed.
- 7. Pressing (SET) in P. - status returns to the parameter setting mode.
 - Turning sets other parameters.
 - Pressing (SET) displays the change list again.

Display



PU indication is lit.



PRM indication is lit.



(The parameter number read previously appears.)






It may take several seconds for creating the initial value change
 list. "P--- " flickers while creating the list.



















- Calibration parameters (C1 (Pr. 901) to C7 (Pr. 905)) are not displayed even they are changed from the initial settings.
- Only simple mode parameter is displayed when simple mode is set (Pr. 160 = 9999)
- Only user group is displayed when user group is set (Pr. 160 = "1").
- Pr. 160 is displayed independently of whether the setting value is changed or not.
- When parameter setting is changed after creating the initial value change list, the setting will be reflected to the initial value change list next time.




Parameters referred to

Pr. 160 User group read selection Refer to page 184
C1 (Pr. 901) AM terminal calibration Refer to page 156
C2(Pr. 902) to C7(Pr. 905) (Frequency setting bias/gain parameter) Refer to page 175

4.26 Check and clear of the faults history

(1) Check for the faults history



* The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0. When the operation panel is used, the time is displayed up to 65.53 (65530h) in the indication of 1h = 0.001, and thereafter, it is added up from 0.

Clearing procedure



POINT

Set "1" in Er.CL Fault history clear to clear the faults history.

 Operation — Display -1. Screen at powering ON The monitor display appears. PRM indication is lit. 2. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) 3. Turn until $\mathcal{E} r.\mathcal{L} \mathcal{L}$ (faults history clear) **4.** Press (SET) to read the currently set value. " \Box " (initial value) appears.

Flicker...Faults history clear complete!!

- to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.



6. Press (SET) to set.

Parameters referred to

Pr. 77 Parameter write selection 👺 Refer to page 183

5 / TROUBLESHOOTING

This chapter provides the "TROUBLESHOOTING" of this product.

Always read the instructions before using the equipment.

5.1	Reset method of protective function	278
5.2	List of fault or alarm indications	279
5.3	Causes and corrective actions	280
5.4	Correspondences between digital and actual characters	290
5.5	Check first when you have a trouble	291

Reset method of protective function

When a fault occurs in the inverter, the inverter trips and the PU display automatically changes to any of the following fault or alarm indications.

If the fault does not correspond to any of the following faults or if you have any other problem, please contact your sales representative.

- Retention of fault output signal.. When the magnetic contactor (MC) provided on the input side of the inverter is opened when a fault occurs, the inverter's control power will be lost and the fault output will not be held.
- Fault or alarm indicationWhen a fault or alarm occurs, the operation panel display automatically switches to the fault or alarm indication.
- Resetting methodWhen a fault occurs, the inverter output is kept stopped. Unless reset, therefore, the inverter cannot restart. (Refer to page 278)
- When any fault occurs, take the appropriate corrective action, then reset the inverter, and resume operation. Not doing so may lead to the inverter fault and damage.

Inverter fault or alarm indications are roughly categorized as below.

- (1) Error message
 - A message regarding operational fault and setting fault by the operation panel and parameter unit (FR-PU04 /FR-PU07) is displayed. The inverter does not trip.
- (2) Warning
 - The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
- (3) Alarm
 - The inverter does not trip. You can also output an alarm signal by making parameter setting.
- (4) Fault
 - When a fault occurs, the inverter trips and a fault signal is output.

5.1 Reset method of protective function

(1) Resetting the inverter

The inverter can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter. Inverter recovers about 1s after the reset is released.


Operation 1: Using the operation panel, press (STOP) to reset the inverter.

(This may only be performed when a fault occurs (Refer to page 284 for fault.))

Operation 2: Turn ON the reset signal (RES) for more than 0.1s. (If the RES signal is kept ON, "Err." appears (flickers) to indicate that the inverter is in a reset status.)

Operation 3: Switch power OFF once. After the indicator of the operation panel turns OFF, switch it ON again.









5.2 List of fault or alarm indications

	Operation P		Name	Refer to Page
	E	E	Faults history	275
			-	
ge	HOLA	HOLD	Operation panel lock	280
Error message	F004	LOCd Ver.UP	Password locked	280
Error	Er 1 to Er 4	Er1 to 4	Parameter write error	280
	Err.	Err.	Inverter reset	281
	OL.	OL	Stall prevention	281
			(overcurrent) Stall prevention	
	οĹ	oL	(overvoltage)	282
	rb	RB	Regenerative brake prealarm	282
g	ſH	тн	Electronic thermal relay function prealarm	282
Warning	<i>PS</i>	PS	PU stop	282
>	חר	МТ	Maintenance signal output	283
	Uu	UV	Undervoltage	283
	SA	SA *2	Safety stop	283
Alarm	٤٥	FN	Fan alarm	283
	E.D.C. 1	E.OC1	Overcurrent trip during acceleration	284
	E.002	E.OC2	Overcurrent trip during constant speed	284
	E.0 C 3	E.OC3	Overcurrent trip during deceleration or stop	284
	E.O 1	E.OV1	Regenerative overvoltage	285
	5.00.3	E.OV2	trip during acceleration Regenerative overvoltage	285
Fault	E.O u 3	E.OV3	trip during constant speed Regenerative overvoltage trip during deceleration or stop	285
	E.F.H.F	E.THT	Inverter overload trip (electronic thermal relay function)	285
	E.C.H.D.	E.THM	Motor overload trip (electronic thermal relay function)	286
	8.81 n	E.FIN	Heatsink overheat	286

	Operation P		Name	Refer to Page
	E.I.L.F	E.ILF *1	Input phase loss	286
	E.0 L F	E.OLT	Stall prevention stop	286
	Е. ЬЕ	E. BE	Brake transistor alarm detection	287
	E. GF	E.GF	Output side earth (ground) fault overcurrent at start	287
	E. LF	E.LF	Output phase loss	287
	E.0HF	E.OHT	External thermal relay operation	287
	E.0PT	E.OPT (Ver.UP)	Option fault	287
	E.DP 1	E.OP1	Communication option fault	288
	€. 1	E. 1	Option fault	288
	E. PE	E.PE	Parameter storage device fault	288
	<i>E.P.E.2</i>	E.PE2 *1	Internal board fault	288
Fault	E.PUE	E.PUE	PU disconnection	288
	E E.F	E.RET	Retry count excess	289
	E. 57 E. 67 E. 77 E.CPU	E. 5/ E. 6/ E. 7/ E.CPU	CPU fault	289
	E.I. OH	E.IOH *1	Inrush current limit circuit fault	289
	E.RT E	E.AIE *1	Analog input fault	289
	8.056	E. USB *1	USB communication fault	289
	E.NBY to E.NBN	E.MB4 to E.MB7	Brake sequence fault	289
	E.SRF	E.SAF *1*2	Safety circuit fault	290
	E. 13	E.13	Internal circuit fault	290

- If a fault occurs when using with the FR-PU04, "Fault 14" is displayed on the FR-PU04.
- *2 This is displayed only for the safety stop function model.

Ver.UP Specifications differ according to the date assembled.

*Refer to page 324 to check the SERIAL number.

5.3 Causes and corrective actions

(1) Error message

A message regarding operational troubles is displayed. Output is not shutoff.

Operation panel indication	HOLD HOLD				
Name	Operation par	Operation panel lock			
Description	Operation lock mode is set. Operation other than (STOP) is invalid. (Refer to page 270)				
Check point	-				
Corrective action	Press MODE for	Press (MODE) for 2s to release lock.			

Operation panel	LOCd	LOCA				
indication	Ver.UP	LULO				
Name	Password locked					
Description	Password function is active. Display and setting of parameter is restricted.					
Check point						
Corrective action	Enter the pass	word in Pr. 297 Password lock/unlock to unlock the password function before operating. (Refer to page 187).				

Ver. UP Specifications differ according to the date assembled. *Refer to page 324* to check the SERIAL number.

Operation panel	Er1	Ec. I					
indication	E11	בר ו					
Name	Write disable	Nrite disable error					
	• You attempted to make parameter setting when <i>Pr. 77 Parameter write selection</i> has been set to disable parameter write.						
Description	Frequency jump setting range overlapped.						
	The PU and inverter cannot make normal communication.						
Check the setting of Pr. 77 Parameter write selection. (Refer to page 183).							
Check point	• Check the settings of Pr. 31 to Pr. 36 (frequency jump). (Refer to page 93)						
	Check the contact the con	connection of the PU and inverter.					

Operation panel	Er2				
indication	EIZ	CCC			
Name	Write error du	ring operation			
Description	When parame	ter write was performed during operation with a value other than "2" (writing is enabled independently			
Description	of operation status in any operation mode) is set in Pr. 77 and the STF (STR) is ON.				
Check point	Check the Pr. 77 setting. (Refer to page 183).				
Check point	Check that the inverter is not operating.				
Corrective action	• Set "2" in <i>Pr. 77</i> .				
Corrective action	After stoppi	ng operation, make parameter setting.			

Operation panel indication	Er3	Er3		
Name	Calibration error			
Description	Analog input bias and gain calibration values are too close.			
Check point	Check the sett	Check the settings of C3, C4, C6 and C7 (calibration functions). (Refer to page 175).		



Operation panel indication	Er4	E-4						
Name	Mode designation error							
Description	Appears if a	 Appears if a parameter setting is attempted in the External or NET operation mode with Pr. 77 ≠ "2". 						
Description	Appears if a	parameter setting is attempted when the command source is not at the operation panel.						
	Check that	operation mode is PU operation mode.						
	• Check the Pr. 77 setting. (Refer to page 183).							
Check point	• Check if FR Configurator (USB connector) or a parameter unit (FR-PU04/FR-PU07) is connected when Pr. 551 =							
	"9999 (initial setting)."							
	Check the Pr.551 setting.							
	After setting	the operation mode to the "PU operation mode", make parameter setting. (Refer to page 190)						
	• After setting <i>Pr.</i> 77 = "2", make parameter setting.							
Corrective action	Disconnect FR Configurator (USB connector) or the parameter unit (FR-PU04/FR-PU07), and make parameter							
	setting.							
	After setting	Pr. 551 = "4", make parameter setting. (Refer to page 201)						

Operation panel	Err.	¢			
indication	EII.	Ċrr.			
Name	Inverter reset				
Description	Executing reset using RES signal, or reset command from communication or PU				
Description	Displays at powering OFF.				
Corrective action	Turn OFF the reset command				

(2) Warnings

When a warning occurs, the output is not shut off.

Operation panel			FR-PU04					
indication	OL	0L	FR-PU07	OL				
Name	Stall prevention	n (overcurrent)						
	During acceleration	inverter exceeds the function stops the infrom resulting in over	ne stall prever increase in fre vercurrent trip	torque when <i>Pr. 277 Stall prevention current switchover</i> = "1") of the tion operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this quency until the overload current decreases to prevent the inverter When the overload current has reduced below stall prevention eases the frequency again.				
Description	During constant- speed operation	inverter exceeds the function reduces from in overcurrent trip.	When the output current (output torque when <i>Pr. 277 Stall prevention current switchover</i> = "1") of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function reduces frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has reduced below stall prevention operation level, this function increases the frequency up to the set value.					
	During deceleration	When the output current (output torque when <i>Pr. 277 Stall prevention current switchover</i> = "1") of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function stops the decrease in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has decreased below stall prevention operation level, this function decreases the frequency again.						
Check point	 Check that the <i>Pr. 0 Torque boost</i> setting is not too large. Check that the <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i> settings are not too small. Check that the load is not too heavy. Are there any failure in peripheral devices? Check that the <i>Pr. 13 Starting frequency</i> is not too large. Check that the <i>Pr. 22 Stall prevention operation level</i> is appropriate 							
Corrective action	 Set a larger Reduce the Try Advance Change the Set stall pre-acceleration operation less 	Increase or decrease the <i>Pr. 0 Torque boost</i> setting 1% by 1% and check the motor status. (<i>Refer to page 81</i>) Set a larger value in <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i> . (<i>Refer to page 105</i>) Reduce the load weight. Try Advanced magnetic flux vector control and General-purpose magnetic flux vector control. Change the <i>Pr. 14 Load pattern selection</i> setting. Set stall prevention operation current in <i>Pr. 22 Stall prevention operation level</i> . (The initial value is 150%.) The acceleration/deceleration time may change. Increase the stall prevention operation level with <i>Pr. 22 Stall prevention operation level</i> , or disable stall prevention with <i>Pr. 156 Stall prevention operation selection</i> . (Operation at OL occurrence can be selected using <i>Pr. 156</i> .)						

Operation panel	-1	_ 1	FR-PU04	
indication	oL	OL	FR-PU07	oL
Name	Stall prevention	Stall prevention (overvoltage)		
Description	During deceleration	If the regenerative energy of the motor becomes excessive to exceed the regenerative energy consumption capability, this function stops the decrease in frequency to prevent overvoltage trip. As soon as the regenerative energy has reduced, deceleration resumes. If the regenerative energy of the motor becomes excessive when regeneration avoidance function is selected (<i>Pr.</i> 882 = 1), this function increases the speed to prevent overvoltage trip. (Refer to page 257).		
Check point		Check for sudden speed reduction. Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 257).		
Corrective action	The decelerat	ion time may change	e. Increase th	e deceleration time using Pr. 8 Deceleration time.

Operation panel indication	PS	25	FR-PU04 FR-PU07	PS
Name	PU stop			
Description	Stop with (STOP) of the PU is set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection</i> . (For <i>Pr. 75 refer to page 180</i> .)			
Check point	Check for a stop made by pressing (STOP) of the operation panel.			
Corrective action	Turn the start	signal OFF and re	elease with EXT).

Operation panel	RB		FR-PU04	RB		
indication	KB	-0	FR-PU07	KD		
Name	Regenerative	brake prealarm				
	Appears if the	regenerative brake	duty reaches	or exceeds 85% of the Pr. 70 Special regenerative brake duty value.		
	When the sett	ing of Pr. 70 Special r	egenerative bro	the duty is the initial value ($Pr. 70 = "0"$), this warning does not occur. If		
Description	the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs.					
Description	The RBP signal can be simultaneously output with the [RB] display. For the terminal used for the RBP signal output,					
	assign the function by setting "7 (positive logic) or 107 (negative logic)" in any of Pr. 190 to Pr. 192 (output terminal					
	function selection). (Refer to page 141).					
Check point	Check that	the brake resistor d	uty is not high			
Offeck point	Check that	the Pr. 30 Regenerati	ve function sele	ection and Pr. 70 Special regenerative brake duty settings are correct.		
Corrective action	Increase th	Increase the deceleration time.				
Corrective action	Check that	the Pr. 30 Regenerati	ve function sele	ection and Pr. 70 Special regenerative brake duty settings.		

Operation panel	TII	TH.	FR-PU04	TU	
indication	TH	1 171	FR-PU07	ТН	
Name	Electronic the	rmal relay function	prealarm		
	Appears if the cumulative value of the Pr. 9 Electronic thermal O/L relay reaches or exceeds 85% of the preset leve				
	it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E. THM) occurs.				
Description	The THP signal can be simultaneously output with the [TH] display. For the terminal used for THP signal output,				
	assign the function by setting "8 (positive logic) or 108 (negative logic)" in any of Pr. 190 to Pr. 192 (output terminal				
	function selection). (Refer to page 141).				
Chack point	Check for large load or sudden acceleration.				
Check point	• Is the <i>Pr. 9 Electronic thermal O/L relay</i> setting is appropriate? (<i>Refer to page 112</i>)				
Corrective action	Reduce the load and frequency of operation.				
Corrective action	 Set an appr 	opriate value in Pr.	9 Electronic the	ermal O/L relay. (Refer to page 112)	



Operation panel	MT		FR-PU04			
indication	MT	FR-PU07	MT			
Name	Maintenance s	signal output				
	Indicates that the cumulative energization time of the inverter has reached a given time.					
Description When the setting of <i>Pr. 504 Maintenance timer alarm output set time</i>			arm output set time is the initial value (Pr. 504 = "9999"), this warning			
	does not occur.					
The Pr. 503 Maintenance timer setting is larger than the Pr. 504 Main		an the Pr. 504 Maintenance timer alarm output set time setting. (Refer to				
Check point	page 264).					
Corrective action	Setting "0" in <i>Pr. 503 Maintenance timer</i> erases the signal.					

Operation panel	111/	11	FR-PU04		
indication	UV	<u>ו</u> וֹ וֵי	FR-PU07		
Name	Undervoltage				
Description	If the power supply voltage of the inverter decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases below about 115VAC (about 230VAC for 400V class), this function stops the inverter output and displays UU . An alarm is reset when the voltage returns to normal.				
Check point	Check that the power supply voltage is normal.				
Corrective action	Check the pov	ver supply system e	equipment suc	h as power supply.	

Operation panel	SA	58	FR-PU04			
indication	SA	_111	FR-PU07			
Name	Safety stop *					
Description	Appears when	safety stop function	n is activated	(during output shutoff).(Refer to page 30)		
Check point	If the indication	n appears when saf	ety stop functi	on is not used, check that shorting wires between S1 and PC, S2 and		
Check point	PC are connected.					
Corrective action	 When not using the safety stop function, short across terminals S1 and PC and across S2 and PC with shorting wire for the inverter to run. If 5 P is indicated when across S1 and PC and across S2 and PC are both shorted while using the safety stop function (drive enabled), internal failure might be the cause. Check the wiring of terminals S1, S2 and PC and contact your sales representative if the wiring has no fault. 					

^{*} This function is only available for the safety stop function model.

(3) Alarm

When an alarm occurs, the output is not shut off. You can also output an alarm signal by making parameter setting. (Set "98" in any of *Pr. 190 to Pr. 192 (output terminal function selection)*. *Refer to page 141*).

Operation panel	FN	En	FR-PU04	FN			
indication	111	, , ,	FR-PU07				
Name	Fan alarm	Fan alarm					
Description		For the inverter that contains a cooling fan, \digamma_{\Box} appears on the operation panel when the cooling fan stops due to an alarm or different operation from the setting of $Pr. 244 Cooling fan operation selection$.					
Check point	Check the cooling fan for an alarm.						
Corrective action	Check for fan	alarm. Please co	ntact your sales	representative.			

(4) Fault

When a fault occurs, the inverter trips and a fault signal is output.

Operation panel	E.OC1	E.O.C 1	FR-PU04	OC During Acc			
indication	E.001		FR-PU07	OC During Acc			
Name	Overcurrent tr	ip during accelera	ion				
Description		•		eds approximately 230% of the rated current during acceleration, the			
	•	uit is activated and					
	 Check for s 	udden acceleratio	١.				
	 Check that 	the downward acc	eleration time is	s not long for lifts.			
	 Check for o 	utput short-circuit/	ground fault.				
Check point	 Check if the 	e stall prevention o	peration level is	s set too high.			
	Check if the fast-response current limit operation is disabled.						
	 Check that 	Check that regeneration is not performed frequently. (Check that the output voltage becomes larger than the V/F					
	reference v	alue at regeneration	n and overcurr	ent occurs due to the high voltage.)			
	Increase the	Increase the acceleration time. (Shorten the downward acceleration time for lifts.					
	When "E.O.	C1" is always lit at	starting, discor	nnect the motor once and start the inverter.			
	If "E.OC1" i	s still lit, contact yo	our sales repres	sentative.			
Corrective action	Check the wiring to make sure that output short circuit/ground fault does not occur.						
Lower the setting of stall prevention operation level.							
	Activate the	fast-response cui	rent limit opera	tion. (Refer to page 88)			
	Set base vo	oltage (rated voltag	e of the motor,	etc.) in Pr. 19 Base frequency voltage. (Refer to page 94)			

Operation panel	F 000	5.002	FR-PU04	04- dia 0a di 00			
indication	E.OC2	C.U.L.C	FR-PU07	Stedy Spd OC			
Name	Overcurrent tri	ip during constant s	peed				
Description		When the inverter output current reaches or exceeds approximately 230% of the rated current during constant speed operation, the protective circuit is activated and the inverter trips.					
Check point	 Check for sudden load change. Check for output short-circuit/ground fault. Check if the stall prevention operation level is set too high. Check if the fast-response current limit operation is disabled. 						
Corrective action	 Keep load stable. Check the wiring to make sure that output short circuit/ground fault does not occur. Lower the setting of stall prevention operation level. Activate the fast-response current limit operation. (Refer to page 88) 						

Operation panel	E.OC3	E.0.C.3	FR-PU04	OC During Dec			
indication	1.0		FR-PU07	oc burning bec			
Name	Overcurrent tr	ip during decelerati	on or stop				
Description		When the inverter output current reaches or exceeds approximately 230% of the rated inverter current during deceleration (other than acceleration or constant speed), the protective circuit is activated and the inverter trips.					
Check point	 Check for sudden speed reduction. Check for output short-circuit/ground fault. Check for too fast operation of the motor's mechanical brake. Check if the stall prevention operation level is set too high. Check if the fast-response current limit operation is disabled. 						
Corrective action	 Increase the deceleration time. Check the wiring to make sure that output short circuit/ground fault does not occur. Check the mechanical brake operation. Lower the setting of stall prevention operation level. Activate the fast-response current limit operation. (<i>Refer to page 88</i>) 						



Operation panel	E.OV1	FOLL	,	FR-PU04	OV During Acc
indication	E.OVI	יייי	1	FR-PU07	OV During Acc
Name	Regenerative	overvoltage tr	ip duri	ng acceleration	on
	If regenerative	energy cause	es the	inverter's inte	rnal main circuit DC voltage to reach or exceed the specified value,
Description	the protective	the protective circuit is activated and the inverter trips. The circuit may also be activated by a surge voltage produced			
	in the power supply system.				
Check point	Check for too slow acceleration. (e.g. during downward acceleration in vertical lift load)				downward acceleration in vertical lift load)
Check point	• Check that the setting of Pr. 22 Stall prevention operation level is not too small.				
	Decrease the acceleration time.				
Corrective action	Corrective action • Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 257).				
	• Set the Pr.2.	2 Stall preventi	on ope	ration level COI	rectly.

Operation panel	E.OV2	8.002	FR-PU04	Stady Sad OV		
indication	E.OV2	C.U U C	FR-PU07	Stedy Spd OV		
Name	Regenerative	overvoltage trip dur	ing constant s	peed		
	If regenerative	energy causes the	inverter's inte	rnal main circuit DC voltage to reach or exceed the specified value,		
Description	the protective	the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage				
	produced in the power supply system.					
Check point	Check for sudden load change.					
Oneck point	Check that:	the setting of Pr. 22	Stall prevention	operation level is not too small.		
	Keep load stable.					
• Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to			Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 257).			
Corrective action	 Use the bra 	ke resistor, brake ui	nit or power re	generation common converter (FR-CV) as required.		
	• Set the Pr.2	2 Stall prevention ope	ration level co	rrectly.		

Operation panel	E.OV3	8.03	FR-PU04	OV During Dec		
indication	E.0V3	C.U.U.D	FR-PU07	OV During Dec		
Name	Regenerative	overvoltage trip dur	ing deceleration	on or stop		
	If regenerative	energy causes the	inverter's inte	rnal main circuit DC voltage to reach or exceed the specified value,		
Description	the protective	the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage				
	produced in the power supply system.					
Check point	Check for sud	Check for sudden speed reduction.				
	Increase the	Increase the deceleration time. (Set the deceleration time which matches the moment of inertia of the load)				
Corrective action	Longer the brake cycle.					
Corrective action	• Use regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). (Refer to page 257).					
	Use the bra	ke resistor, brake ui	nit or power re	generation common converter (FR-CV) as required.		

Operation panel indication	E.THT	E.F.H.F	FR-PU04 FR-PU07	Inv. Overload			
Name	Inverter overlo	Inverter overload trip (electronic thermal relay function)					
D	-			ent exceeds the protection level under the condition that a current not			
Description	less than the rated inverter current flows and overcurrent trip does not occur (230% or less), the electronic thermal relay activates to stop the inverter output. (Overload capacity 150% 60s, 200% 3s)						
	Check that acceleration/deceleration time is not too short. Observe that the same is not too short.						
Check point	 Check that torque boost setting is not too large (small). Check that load pattern selection setting is appropriate for the load pattern of the using machine. 						
	Check the r	notor for use under	overload.				
	 Check for to 	oo high surrounding	g air temperatu	re.			
	 Increase ac 	celeration/decelera	ition time.				
	 Adjust the to 	orque boost setting					
Corrective action	Set the load	Set the load pattern selection setting according to the load pattern of the using machine.					
	 Reduce the 	load weight.					
	Set the surr	ounding air temper	ature to within	the specifications.			

Operation panel	E.THM	E.C.H.C.	FR-PU04	Motor Ovrload	
indication	E. I FIN		FR-PU07	Motor Ovridad	
Name	Motor overloa	d trip (electronic the	ermal relay fun	ction) *1	
Description	The electronic thermal relay function in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation and pre-alarm (TH display) is output when the integrated value reaches 85% of the <i>Pr. 9 Electronic thermal O/L relay</i> setting and the protection circuit is activated to stop the inverter output when the integrated value reaches the specified value. When running a special motor such as a multi-pole motor or multiple motors, provide a thermal relay on the inverter output side since such motor(s) cannot be protected by the electronic thermal relay function.				
Check point	 Check the motor for use under overload. Check that the setting of <i>Pr. 71 Applied motor</i> for motor selection is correct. (<i>Refer to page 114</i>). Check that stall prevention operation setting is correct. 				
Corrective action		ant-torque motor, s		-torque motor in <i>Pr. 71 Applied motor</i> . s correct. <i>(Refer to page 88).</i>	

^{*1} Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.

Operation panel	E.FIN	EFI	_	FR-PU04	H/Sink O/Temp				
indication	E.FIN	<u></u>	171	FR-PU07	H/Silik O/Temp				
Name	Heatsink over	Heatsink overheat							
	If the heatsink	f the heatsink overheats, the temperature sensor is actuated and the inverter trips.							
Description	The FIN signal can be output when the temperature becomes approximately 85% of the heatsink overh								
Description	operation temperature. For the terminal used for the FIN signal output, assign the function by setting "26 (position logic) or 126 (negative logic)" in any of <i>Pr. 190 to Pr. 192 (output terminal function selection). (Refer to page 141).</i>								
	 Check for to 	oo high surro	ounding	air temperatu	re.				
Check point	Check for he	eatsink clogo	ging.						
	• Check that the cooling fan is not stopped (Check that \digamma_{n} is not displayed on the operation panel).								
	 Set the surr 	Set the surrounding air temperature to within the specifications.							
Corrective action • Clean the heatsink.									
	 Replace the 	cooling fan	•						

Operation panel	E.ILF	FIIF	FR-PU04	Fault 14						
indication	E.ILF		FR-PU07	Input phase loss						
Name	Input phase lo	Input phase loss *								
	Inverter trips w	nverter trips when function valid setting (=1) is selected in Pr. 872 Input phase loss protection selection and one phase of								
Description	the three phas	e power input is los	t. (Refer to pag	re 168).						
	It may be available if phase-to-phase voltage of the three-phase power input becomes largely unbalanced.									
Check point	 Check for a 	break in the cable f	or the three-p	hase power supply input.						
Check point	Check that	Check that phase-to-phase voltage of the three-phase power input is not largely unbalanced.								
	 Wire the cal 	oles properly.								
Corrective action	Repair a break portion in the cable.									
• Check the <i>Pr. 872 Input phase loss protection selection</i> setting.										
	• Set Pr. 872 =	= "0" (without input p	ohase loss pro	stection) when three-phase input voltage is largely unbalanced.						

^{*} Available only for three-phase power input model.

Operation panel indication	E.OLT	E.OLT	FR-PU04 FR-PU07	Stll Prev STP (OL shown during stall prevention operation)						
Name	Stall preventio	Stall prevention stop								
Description	trips the invert	If the output frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears and trips the inverter. OL appears while stall prevention is being activated. E.OLT may not occur if stall prevention (OL) is activated during output phase loss.								
Check point	Check the n	Check the motor for use under overload. (Refer to page 89).								
Corrective action	 Reduce the 	load weight. (Check	the Pr. 22 Sta	all prevention operation level setting.)						



Operation panel indication	E.BE	Ε.	<i>68</i>	FR-PU04 FR-PU07	Br. Cct. Fault			
Name	Brake transisto	or alarm	detection					
Description	transistor alarr	When a brake transistor alarm has occurred due to the large regenerative energy from the motor etc., the brake transistor alarm is detected and the inverter trips. In this case, the inverter must be powered OFF immediately.						
Check point	Reduce the load inertia.Check that the frequency of using the brake is proper.							
Corrective action	Replace the inverter.							

Operation panel	E.GF		GF	FR-PU04	Ground Fault				
indication	E.GF	<i>L</i> .		FR-PU07	Ground Fault				
Name	Output side ea	Output side earth (ground) fault overcurrent at start							
		The inverter trips if an earth (ground) fault overcurrent flows at start due to an earth (ground) fault that occurred on							
Description	the inverter's	output si	de (load sid	e). Whether the	nis protective function is used or not is set with Pr. 249 Earth (ground)				
	fault detection of	ault detection at start.							
Check point	Check for a gr	Check for a ground fault in the motor and connection cable.							
Corrective action	Remedy the g	Remedy the ground fault portion.							

Operation panel indication	E.LF	Ε.	LF	FR-PU04 FR-PU07	E.LF			
Name	Output phase	loss						
Description	during DC inje	If one of the three phases (U, V, W) on the inverter's output side (load side) is lost during inverter operation (except during DC injection brake operation and when output frequency is under 1Hz), inverter stops the output. Whether the protective function is used or not is set with <i>Pr. 251 Output phase loss protection selection</i> .						
Check point		 Check the wiring. (Check that the motor is normal.) Check that the capacity of the motor used is not smaller than that of the inverter. 						
Corrective action	Wire the calCheck the F		. ,	loss protection :	selection setting.			

Operation panel	E.OHT	FAHE	FR-PU04	OH Fault					
indication	E.OH1	<u> </u>	FR-PU07	On Fault					
Name	External therm	External thermal relay operation							
Description	If the external thermal relay provided for motor overheat protection or the internally mounted temperature relay in the motor, etc. switches on (contacts open), the inverter output is stopped. This function is available when "7" (OH signal) is set to any of <i>Pr. 178 to Pr. 184 (input terminal function selection)</i> . This protective function is not available in the initial status (OH signal is not assigned).								
Check point		 Check for motor overheating. Check that the value of 7 (OH signal) is set correctly in any of <i>Pr. 178 to Pr. 184 (input terminal function selection)</i>. 							
Corrective action		load and frequency relay contacts are re	•	cally, the inverter will not restart unless it is reset.					

Operation Panel Indication	E.OPT (Ver.UP)	E.0PF	FR-PU04 FR-PU07	Option Fault					
Name	Option fault	Option fault							
Description	Appears when	Appears when a communication option is connected while Pr. 296 = "0 or 100."							
Check point	Check if passw	Check if password lock is activated by setting Pr. 296 = "0, 100"							
Corrective action				communication option, set <i>Pr.296</i> ≠ "0,100".(<i>Refer to page 187</i>). ove measure, please contact your sales representative.					

Ver.UP Specifications differ according to the date assembled. *Refer to page 324* to check the SERIAL number.

Operation panel indication	E.OP1	E.0P	;	FR-PU04 FR-PU07	Option slot alarm 1				
Name	Communication	Communication option fault							
Description	Stops the inve	Stops the inverter output when a communication line fault occurs in the communication option.							
Check point	Check that Check for a	 Check for a wrong option function setting and operation. Check that the plug-in option unit is plugged into the connector securely. Check for a break in the communication cable. Check that the terminating resistor is fitted properly. 							
Corrective action	Connect the Check the connect the	 Check that the terminating resistor is fitted properly. Check the option function setting, etc. Connect the plug-in option securely. Check the connection of communication cable. Connect the terminating resistor correctly. 							

Operation panel	E. 1	Ľ	1	FR-PU04	Fault 1				
indication	E. 1	C.	1	FR-PU07	Fault I				
Name	Option fault	Option fault							
	Stops the inve	Stops the inverter output if a contact fault or the like of the connector between the inverter and communication option							
Description	occurs.	occurs.							
	Appears when	ppears when the switch for the manufacturer setting of the plug-in option is changed.							
	Check that	Check that the plug-in option unit is plugged into the connector securely.							
Check point	 Check for e 	Check for excess electrical noises around the inverter.							
	Check the s	Check the switch position for the manufacturer setting of the plug-in option.							
	Connect the	Connect the plug-in option securely.							
	Take measu	ıres against	noises i	f there are de	vices producing excess electrical noises around the inverter.				
Corrective action	If the proble	If the problem still persists after taking the above measure, please contact your sales representative.							
• Return the switch position for the manufacturer setting of the plug-in option to the initial status. (
	instruction m	anual of each	h option)						

Operation panel	E.PE		PE	FR-PU04	Courset Moment				
indication	E.PE	Ľ.	- <u>-</u>	FR-PU07	Corrupt Memry				
Name	Parameter sto	arameter storage device fault (control circuit board)							
Description	Stops the inve	Stops the inverter output if fault occurred in the parameter stored. (EEPROM fault)							
Check point	Check for too	Check for too many number of parameter write times.							
	Please contac	Please contact your sales representative.							
Corrective action	When perform	When performing parameter write frequently for communication purposes, set "1" in Pr. 342 to enable RAM write. Note							
	that powering OFF returns the inverter to the status before RAM write.								

Operation Panel	E.PE2	6060	FR-PU04	Fault 14					
Indication	E.PEZ	E.PE 2	FR-PU07	PR storage alarm					
Name	Internal board	fault							
Description	When a comb	When a combination of control board and main circuit board is wrong, the inverter is tripped.							
Check point	_	_							
Corrective action	Please contac	Please contact your sales representative.							
Corrective action	(For parts replacement, consult the nearest Mitsubishi FA Center.)								

Operation panel	E.PUE	<i>EPUE</i>	FR-PU04	PU Leave Out
indication			FR-PU07	1 o Edavo Out
Name	PU disconnection			
Description	 This function stops the inverter output if communication between the inverter and PU is suspended, e.g. the parameter unit is disconnected, when "2", "3", "16" or "17" was set in <i>Pr. 75 Reset selection/disconnected PU detection/ PU stop selection.</i> This function stops the inverter output when communication errors occurred consecutively for more than permissible number of retries when a value other than "9999" is set in <i>Pr. 121 Number of PU communication retries</i> during the RS-485 communication with the PU connector (use <i>Pr. 502 Stop mode selection at communication error</i> to change). This function also stops the inverter output if communication is broken within the period of time set in <i>Pr. 122 PU communication check time interval</i> during the RS-485 communication with the PU connector. 			
Check point	 Check that the parameter unit (FR-PU04/FR-PU07) is connected properly. Check the <i>Pr. 75</i> setting. 			
Corrective action	Connect the parameter unit (FR-PU04/FR-PU07) securely.			



Operation panel indication	E.RET	E E.T	FR-PU04 FR-PU07	Retry No Over		
Name	Retry count ex	Retry count excess				
Description	If operation cannot be resumed properly within the number of retries set, this function trips the inverter. This function is available only when $Pr. 67$ Number of retries at fault occurrence is set. When the initial value ($Pr. 67 = 0$) is set, this protective function is not available.					
Check point	Find the cause of fault occurrence.					
Corrective action	Eliminate the	Eliminate the cause of the error preceding this error indication.				

	E. 5	Ε.	5		Fault 5
Operation panel	E. 6	Ε.	5	FR-PU04	Fault 6
indication	E. 7	Ε.	7	FR-PU07	Fault 7
	E.CPU	E.C	PU		CPU Fault
Name	CPU fault				
Description	Stops the inve	Stops the inverter output if the communication fault of the built-in CPU occurs.			
Check point	Check for devices producing excess electrical noises around the inverter.				
Check point	 Check if the 	 Check if the terminal PC is shorted with the terminal SD. (E. 6/E. 7) 			
	Take measures against noises if there are devices producing excess electrical noises around the inverter.				
Corrective action	Check the contact the con	connection between the terminals PC and SD. (E. 6/E. 7)			
	Please conf	tact your s	ales repre	esentative.	

Operation panel indication	E.MB4 to 7 FR-PU04 FR-PU07 E.MB4 Fault to E.MB7 Fault				
Name	Brake sequence fault				
Description	• The inverter output is stopped when a sequence error occurs during use of the brake sequence function (<i>Pr. 278 to Pr. 283</i>) . This protective function is not available in the initial status. (<i>Refer to page 131</i>).				
Check point	Find the cause of alarm occurrence.				
Corrective action	Check the set parameters and perform wiring properly.				

Operation panel	E.IOH	E.I D		FR-PU04	
indication	E.IOH	בי ע	<i>¬</i>	FR-PU07	Inrush overheat
Name	Inrush current	Inrush current limit circuit fault			
Description	Stops the inve	rter output wh	nen the r	esistor of inru	ush current limit circuit overheated. The inrush current limit circuit fault
Check point	Check that frequent power ON/OFF is not repeated.				
Corrective action	Configure a ci	Configure a circuit where frequent power ON/OFF is not repeated.			
Corrective action	If the problem	still persists a	after tak	ing the above	e measure, please contact your sales representative.

Operation panel	E.AIE	E.R.I. E	FR-PU04	Fault 14		
indication	E.AIE	c.n, c	FR-PU07	Analog in error		
Name	Analog input fa	Analog input fault				
Description	Appears if voltage(current) is input		it to terminal 4	when the setting in Pr.267 Terminal 4 input selection and the setting of		
Description	voltage/curren	oltage/current input switch are dif				
Check point	Check the setting of Pr. 267 Terminal 4 input selection and voltage/current input switch. (Refer to page 172).					
Corrective action	Either give a f	Either give a frequency command by current input or set Pr. 267 Terminal 4 input selection, and voltage/current input				
Corrective action	switch to volta	ige input.				

Operation panel	E HOD (8.856	FR-PU04	Fault 14			
indication	E.USB	C.U D O	FR-PU07	USB comm error			
Name	USB commun	USB communication fault					
Description	When commu	When communication has broken during the time set in Pr. 548 USB communication check time interval, this function					
Description	stops the inverter output.						
Check point	Check the USB communication cable.						
	Check the Pr. 548 USB communication check time interval setting.						
Corrective action	Check the USB communication cable.						
Increase the Pr. 548 USB communication				time interval setting. Or, change the setting to 9999. (Refer to page 241).			

_
7/
//

Operation panel			FR-PU04	Fault 14			
'	E.SAF	FSBF	FR-PU07	Fault			
indication			FK-PUU1	E.SAF			
Name	Safety circuit f	Safety circuit fault *					
Description	Appears when	safety circuit is ma	Ifunctioning.				
Description	Appears when	one of the lines be	tween S1 and	PC, or between S2 and PC is opened.			
Check point	 If the indication appears when safety stop function is not used, check if shorting wires between S1 and PC, S2 and PC are connected. If the indication appears when safety stop function is used, check that the safety relay module or the connection has no fault. 						
Corrective action	 When not using the safety stop function, short across terminals S1 and PC and across S2 and PC with shorting wire. (Refer to page 30) When using the safety stop function, check that wiring of terminal S1, S2 and PC is correct and the safety stop input signal source such as safety relay module is operating properly. Refer to the Safety stop function instruction manual (BCN-211508-004) for causes and countermeasures. (Please contact your sales representative for the manual.) 						

^{*} This function is only available for the safety stop function model.

Operation panel indication	E.13	€.	13	FR-PU04 FR-PU07	Fault 13
Name	Internal circuit	nternal circuit fault			
Description	Stop the inverter output when an internal circuit fault occurred.				
Corrective action	Please contac	t your sal	es represe	ntative.	



NOTE

- If protective functions of E.ILF, E.AIE, E.USB, E.IOH, E.PE2 and, E.SAF are activated when using the FR-PU04, "Fault 14" is displayed.
- Also when the faults history is checked on the FR-PU04, the display is "E.14".
- If faults other than the above appear, contact your sales representative.

5.4 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel:

Actual	Digital
0	\Box
1	[/]
2	<u></u>
3	\exists
4	'- /
5	5
6	<u>E</u>
7	7
8	
9	9

A B	Actual	Digital
	A B C D W F G H -	



5.5 Check first when you have a trouble



POINT

• If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then set the required parameter values and check again.

5.5.1 Motor does not start

Check points	Possible Cause	Countermeasures	Refer to page
Main	Appropriate power supply voltage is not applied. (Operation panel display is not provided.)	Power ON a moulded case circuit breaker (MCCB), an earth leakage circuit breaker (ELB), or a magnetic contactor (MC). Check for the decreased input voltage, input phase loss, and wiring.	_
Circuit	Motor is not connected properly.	Check the wiring between the inverter and the motor.	16
	The jumper across P/+ and P1 is disconnected.	Securely fit a jumper across P/+ and P1. When using a DC reactor (FR-HEL), remove the jumper across P/+ and P1, and then connect the DC reactor.	38
	Start signal is not input.	Check the start command source, and input a start signal. PU operation mode: RUN External operation mode: STF/STR signal	193
	Both the forward and reverse rotation start signals (STF, STR) are input simultaneously.	Turn ON only one of the forward and reverse rotation start signals (STF or STR). If STF and STR signals are turned ON simultaneously in the initial setting, a stop command is given.	21
	Frequency command is zero. (RUN LED on the operation panel is flickering.)	Check the frequency command source and enter a frequency command.	193
	AU signal is not ON when terminal 4 is used for frequency setting. (RUN LED on the operation panel is flickering.)	Turn ON the AU signal. Turning ON the AU signal activates terminal 4 input.	172
Input Signal	Output stop signal (MRS) or reset signal (RES) is ON. (RUN LED on the operation panel flickers while MRS signal is ON.)	Turn MRS or RES signal OFF. Inverter starts the operation with a given start command and a frequency command after turning OFF MRS or RES signal. Before turning OFF, ensure the safety.	137, 278
	Jumper connector of sink - source is wrongly selected. (RUN LED on the operation panel is flickering.)	Check that the control logic switchover jumper connector is correctly installed. If it is not installed correctly, input signal is not recognized.	24
	Shorting wires between S1 and PC, S2 and PC are disconnected.	Short between S1 and PC, S2 and PC with shorting wires.	30
	Voltage/current input switch is not correctly set for analog input signal (0 to 5V/0 to 10V, 4 to 20mA). (RUN LED on the operation panel is flickering.)	Set <i>Pr. 73, Pr. 267</i> , and a voltage/current input switch correctly, then input an analog signal in accordance with the setting.	21
	(Operation panel indication is \$P\$ (PS).)	During the External operation mode, check the method of restarting from a (STOP) input stop from PU.	282
	Two-wire or three-wire type connection is wrong.	Check the connection. Connect STOP signal when three-wire type is used.	139

Check points	Possible Cause	Countermeasures	Refer to page
	Pr. 0 Torque boost setting is improper when V/F control is used.	Increase <i>Pr. 0</i> setting by 0.5% increments while observing the rotation of a motor. If that makes no difference, decrease the setting.	81
	Pr. 78 Reverse rotation prevention selection is set.	Check the <i>Pr.</i> 78 setting. Set <i>Pr.</i> 78 when you want to limit the motor rotation to only one direction.	184
	Pr. 79 Operation mode selection setting is wrong.	Select the operation mode which corresponds with input methods of start command and frequency command.	193
	Bias and gain <i>(calibration parameter C2 to C7)</i> settings are improper.	Check the bias and gain <i>(calibration parameter C2 to C7)</i> settings.	175
	<i>Pr. 13 Starting frequency</i> setting is greater than the running frequency.	Set running frequency higher than <i>Pr. 13</i> . The inverter does not start if the frequency setting signal is less than the value set in <i>Pr. 13</i> .	108
	Frequency settings of various running frequency (such as multi-speed operation) are zero. Especially, <i>Pr. 1 Maximum frequency</i> is zero.	Set the frequency command according to the application. Set $Pr.\ 1$ higher than the actual frequency used.	92
	<i>Pr. 15 Jog frequency</i> setting is lower than <i>Pr. 13 Starting frequency</i> .	Set Pr. 15 Jog frequency higher than Pr. 13 Starting frequency.	100
	Operation mode and a writing device do not match.	Check <i>Pr. 79, Pr. 338, Pr. 339, Pr. 550, Pr. 551</i> , and select an operation mode suitable for the purpose.	190, 201
Parameter Setting	Start signal operation selection is set by the <i>Pr. 250 Stop selection</i>	Check <i>Pr. 250</i> setting and connection of STF and STR signals.	139
	Inverter decelerated to a stop when power failure deceleration stop function is selected.	When power is restored, ensure the safety, and turn OFF the start signal once, then turn ON again to restart. Inverter restarts when <i>Pr. 261</i> ="2".	164
	Performing auto tuning.	When offline auto tuning ends, press (RESET) of the operation panel for the PU operation. For the External operation, turn OFF the start signal (STF or STR). This operation resets the offline auto tuning, and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)	116
	Automatic restart after instantaneous power failure function or power failure stop function is activated. (Performing overload operation with single-phase power input model may cause voltage insufficiency, and results in a detection of power failure.)	 Disable the automatic restart after instantaneous power failure function and power failure stop function. Reduce the load. Increase the acceleration time if the automatic restart after instantaneous power failure function or power failure stop function occurred during acceleration. 	158, 164
Load	Load is too heavy.	Reduce the load.	_
Others	Shaft is locked. Operation panel display shows an error (e.g. E.OC1).	Inspect the machine (motor). When any fault occurs, take an appropriate corrective action, then reset the inverter, and resume the operation.	279



5.5.2 Motor or machine is making abnormal acoustic noise

Check points	Possible Cause	Countermeasures	Refer to page
Input signal	Disturbance due to EMI when frequency command is	Take countermeasures against EMI.	42
Parameter Setting	given from analog input (terminal 2, 4).	Increase the <i>Pr. 74 Input filter time constant</i> if steady operation cannot be performed due to EMI.	174
	No carrier frequency noises (metallic noises) are generated.	In the initial setting, <i>Pr. 240 Soft-PWM operation selection</i> is enabled to change motor noise to an unoffending complex tone. Therefore, no carrier frequency noises (metallic noises) are generated. Set <i>Pr. 240</i> = "0" to disable this function.	170
	Resonance occurs. (output frequency)	Set <i>Pr. 31 to Pr. 36 (Frequency jump)</i> . When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.	93
Parameter Setting	Resonance occurs. (carrier frequency)	Change <i>Pr. 72 PWM frequency selection</i> setting. Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or a motor.	170
	Auto tuning is not performed under Advanced magnetic flux vector control or General-purpose magnetic flux vector control.	Perform offline auto tuning.	116
	Gain adjustment during PID control is insufficient.	To stabilize the measured value, change the proportional band (<i>Pr. 129</i>) to a larger value, the integral time (<i>Pr. 130</i>) to a slightly longer time, and the differential time (<i>Pr. 134</i>) to a slightly shorter time. Check the calibration of set point and measured value.	242
Others	Mechanical looseness	Adjust machine/equipment so that there is no mechanical looseness.	_
Motor	Operating with output phase loss	Check the motor wiring.	_
	Contact the motor manufacturer.		

5.5.3 Inverter generates abnormal noise

Check points	Possible Cause	Countermeasures	Refer to page
Fan	Fan cover was not correctly installed when a cooling fan was replaced.	Install a fan cover correctly.	305

5.5.4 Motor generates heat abnormally

Check points	Possible Cause	Countermeasures	Refer to page
	Motor fan is not working	Clean the motor fan.	
Motor	(Dust is accumulated.)	Improve the environment.	_
	Phase to phase insulation of the motor is insufficient.	Check the insulation of the motor.	_
Main	The inverter output veltage (LL V/ W) are unhalanced	Check the output voltage of the inverter.	301
Circuit	The inverter output voltage (U, V, W) are unbalanced.	Check the insulation of the motor.	301
Parameter	The Pu 71 Applied motor cetting in wrong	Check the Pr. 71 Applied meter setting	114
Setting	The Pr. 71 Applied motor setting is wrong.	Check the Pr. 71 Applied motor setting.	114
_	Motor current is large.	Refer to "5.5.11 Motor current is too large"	296

5.5.5 Motor rotates in the opposite direction

Check			Refer
points	Possible Cause	Countermeasures	to
points			page
Main	Phase sequence of output terminals U, V and W is	Connect phase sequence of the output cables (terminal	16
Circuit	incorrect.	U, V, W) to the motor correctly	10
	The start signals (forward rotation, reverse rotation) are	Check the wiring. (STF: forward rotation, STR: reverse	21
Input	connected improperly.	rotation)	
signal	Adjustment by the output frequency is improper during		
Signal	the reversible operation with Pr. 73 Analog input selection	Check the setting of Pr. 125, Pr. 126, C2 to C7.	175
	setting.		
Parameter	Pr. 40 RUN key rotation direction selection setting is	Check the Pr. 40 setting.	268
Setting	incorrect.	Officer the 17. 40 Setting.	200

5.5.6 Speed greatly differs from the setting

Check			Refer
points	Possible Cause	Countermeasures	to
points			page
Input	Frequency setting signal is incorrectly input.	Measure the input signal level.	_
signal	The input signal lines are affected by external EMI.	Take countermeasures against EMI such as using	42
Signal	The input signal lines are affected by external EMI.	shielded wires for input signal lines.	42
	Pr. 1, Pr. 2, Pr. 18, calibration parameter C2 to C7 settings	Check the settings of Pr. 1 Maximum frequency, Pr. 2	92
Parameter		Minimum frequency, Pr. 18 High speed maximum frequency.	
Setting	are improper.	Check the calibration parameter C2 to C7 settings.	175
	Pr. 31 to Pr. 36 (frequency jump) settings are improper.	Narrow down the range of frequency jump.	93
Load		Reduce the load weight.	_
Parameter	Ctall provention function is activated due to a begun	Set Pr. 22 Stall prevention operation level higher according	
	Stall prevention function is activated due to a heavy	to the load. (Setting Pr. 22 too large may result in	88
Setting	load.	frequent overcurrent trip (E.OC□).)	
Motor		Check the capacities of the inverter and the motor.	_

5.5.7 Acceleration/deceleration is not smooth

Check			Refer
points	Possible Cause	Countermeasures	to
points			page
		For V/F control, set Pr. 3 Base frequency and Pr. 47 Second	94
	The base frequency does not match the motor	V/F (base frequency).	94
	characteristics.	For Advanced magnetic flux vector control or General-	
	characteristics.	purpose magnetic flux vector control, set Pr. 84 Rated	116
		motor frequency.	
	Stall prevention function is activated due to a heavy load.	Reduce the load weight.	_
		Set Pr. 22 Stall prevention operation level higher according	
Parameter		to the load. (Setting Pr. 22 too large may result in	88
Setting		frequent overcurrent trip (E.OC□).)	
		Check the capacities of the inverter and the motor.	_
	Acceleration/deceleration time is too short.	Increase acceleration/deceleration time.	105
	Torque boost (Pr. 0, Pr. 46) setting is improper under V/F	Increase/decrease Pr. 0 Torque boost setting value by	81
	control, so the stall prevention function is activated.	0.5% increments to the setting.	01
		If the frequency becomes unstable during regeneration	
	Regeneration avoidance operation is performed	avoidance operation, decrease the setting of Pr. 886	257
		Regeneration avoidance voltage gain.	



5.5.8 Speed varies during operation

When Advanced magnetic flux vector control or the slip compensation is selected, the output frequency varies between 0 and 2Hz as load fluctuates. This is a normal operation and not a fault.

Check points	Possible Cause	Countermeasures	Refer to page
Input signal	Multi-speed command signal is chattering.	Take countermeasures to suppress chattering.	_
Load	Load varies during an operation.	Select Advanced magnetic flux vector control or General-purpose magnetic flux vector control.	82
	Frequency setting signal is varying.	Check the frequency setting signal.	_
1	The frequency setting signal is affected by EMI.	Set filter to the analog input terminal using <i>Pr. 74 Input filter time constant</i> .	174
Input signal		Take countermeasures against EMI, such as using shielded wires for input signal lines.	42
	Malfunction is occurring due to the undesirable current generated when the transistor output unit is connected.	Use terminal PC (terminal SD when source logic) as a common terminal to prevent a malfunction caused by undesirable current.	24
	Pr. 80 Motor capacity and Pr. 81 Number of motor poles setting is improper for the capacities of the inverter and the motor for Advanced magnetic flux vector control or General-purpose magnetic flux vector control.	Check the Pr. 80 Motor capacity and Pr. 81 Number of motor poles setting.	82
	Fluctuation of power supply voltage is too large.	Change the <i>Pr. 19 Base frequency voltage</i> setting (about 3%) under V/F control.	94
Parameter Setting	Hunting occurs by the generated vibration, for example, when structural rigidity at load side is insufficient.	Disable automatic control functions, such as energy saving operation, fast-response current limit function, regeneration avoidance function, Advanced magnetic flux vector control, General-purpose magnetic flux vector control, and stall prevention. During the PID control, set smaller values to <i>Pr.129 PID proportional band</i> and <i>Pr.130 PID integral time</i> . Lower the control gain, and adjust to increase the stability. Change <i>Pr. 72 PWM frequency selection</i> setting.	
	Wiring length exceeds 30m when Advanced magnetic flux vector control or General-purpose magnetic flux vector control is performed.	Perform offline auto tuning.	116
Others	Wiring length is too long for V/F control, and a voltage	Adjust <i>Pr. 0 Torque boost</i> by increasing with 0.5% increments for low-speed operation.	81
	drop occurs.	Change to Advanced magnetic flux vector control or General-purpose magnetic flux vector control.	82

5.5.9 Operation mode is not changed properly

Check			Refer
points	Possible Cause	Countermeasures	to
politis			page
Input		Check that the STF and STR signals are OFF.	
signal	Start signal (STF or STR) is ON.	When either is ON, the operation mode cannot be	190
Signai		changed.	
		When Pr. 79 Operation mode selection setting is "0" (initial	
		value), the inverter is placed in the External operation mode	
		at input power ON. To switch to the PU operation mode,	
Parameter	Pr. 79 setting is improper.	press $\frac{PU}{EXT}$ on the operation panel (press PU when the	190
Setting		parameter unit (FR-PU04/FR-PU07) is used). At other	
County		settings (1 to 4, 6, 7), the operation mode is limited	
		accordingly.	
	Operation mode and a writing device do not	Check Pr. 79, Pr. 338, Pr. 339, Pr. 550, Pr. 551, and select	190,
	correspond.	an operation mode suitable for the purpose.	201

5.5.10 Operation panel display is not operating

Check points	Possible Cause	Countermeasures	Refer to page
Main Circuit	Wiring or installation is improper.	Check for the wiring and the installation. Make sure that the connector is fitted securely across terminal P/+ and P1.	14
Main Circuit Control Circuit	Power is not input.	Input the power.	14
Parameter Setting	Command sources at the PU operation mode is not at the operation panel. (None of the operation mode displays (PU_EXT_NET)) is lit.)	Check the setting of $Pr. 551 \ PU \ mode \ operation \ command \ source \ selection.$ (If parameter unit (FR-PU04/FR-PU07) is connected while $Pr. 551 =$ "9999" (initial setting), all the operation mode displays (PU EXT NET) turn OFF.)	201

5.5.11 Motor current is too large

Check			Refer
points	Possible Cause	Countermeasures	to
	Torque boost (<i>Pr. 0, Pr. 46</i>) setting is improper under V/F control, so the stall prevention function is activated.	Increase/decrease <i>Pr. 0 Torque boost</i> setting value by 0.5% increments to the setting.	page 81
	V/F pattern is improper when V/F control is performed. (<i>Pr. 3, Pr. 14, Pr. 19</i>)	Set rated frequency of the motor to <i>Pr. 3 Base frequency</i> . Use <i>Pr. 19 Base frequency voltage</i> to set the base voltage (e.g. rated motor voltage).	94
Parameter		Change <i>Pr. 14 Load pattern selection</i> according to the load characteristic.	96
Setting	Stall prevention function is activated due to a heavy load.	Reduce the load weight.	_
Setting		Set $Pr. 22$ Stall prevention operation level higher according to the load. (Setting $Pr. 22$ too large may result in frequent overcurrent trip (E.OC \square).)	88
		Check the capacities of the inverter and the motor.	_
	Auto tuning is not performed under Advanced magnetic flux vector control or General-purpose magnetic flux vector control.	Perform offline auto tuning.	116



5.5.12 Speed does not accelerate

Check points	Possible Cause	Countermeasures	Refer to page	
	Start command and frequency command are chattering.	Check if the start command and the frequency command are correct.	_	
Input signal	The wiring length used for analog frequency command is too long, and it is causing a voltage (current) drop.	Perform analog input bias/gain calibration.	175	
	Input signal lines are affected by external EMI.	Take countermeasures against EMI, such as using shielded wires for input signal lines.	42	
	Pr. 1, Pr. 2, Pr. 18, calibration parameter C2 to C7 settings are improper.	Check the settings of <i>Pr. 1 Maximum frequency and Pr. 2 Minimum frequency</i> . If you want to run the motor at 120Hz or higher, set <i>Pr. 18 High speed maximum frequency</i> .	92 175	
	Torque boost (<i>Pr. 0, Pr. 46</i>) setting is improper under V/F control, so the stall prevention function is activated.	Check the <i>calibration parameter C2 to C7</i> settings. Increase/decrease <i>Pr. 0 Torque boost</i> setting value by 0.5% increments so that stall prevention does not occur.	81	
	V/F pattern is improper when V/F control is performed. (<i>Pr. 3, Pr. 14, Pr. 19</i>)	Set rated frequency of the motor to <i>Pr. 3 Base frequency</i> . Use <i>Pr. 19 Base frequency voltage</i> to set the base voltage (e.g. rated motor voltage).	94	
Parameter Setting	(-113, -111,	Change <i>Pr. 14 Load pattern selection</i> according to the load characteristic.	96	
		Reduce the load weight.	_	
	Stall prevention function is activated due to a heavy load.	Set <i>Pr. 22 Stall prevention operation level</i> higher according to the load. (Setting <i>Pr. 22</i> too large may result in frequent overcurrent trip (E.OC□).)	88	
		Check the capacities of the inverter and the motor.	_	
	Auto tuning is not performed under Advanced magnetic flux vector control or General-purpose magnetic flux vector control.	Perform offline auto tuning.	116	
	During PID control, output frequency is automatically cor	ntrolled to make measured value = set point.	242	
Main Circuit	The state of the s			

5.5.13 Unable to write parameter setting

Check			Refer
points	Possible Cause	Countermeasures	to
politis			page
Input	Operation is being performed (signal STF or STR is	Stop the operation.	
signal	ON).	When $Pr. 77 = "0"$ (initial value), write is enabled only	183
Signai	ON).	during a stop.	
	You are attempting to set the parameter in the External	Choose the PU operation mode.	
	operation mode.	Or, set Pr : 77 = "2" to enable parameter write regardless	183
	operation mode.	of the operation mode.	
Parameter	Parameter is disabled by the Pr. 77 Parameter write	Check Pr. 77 Parameter write selection setting.	183
Setting	selection setting.	Grieck 17. 77 1 arameter write selection setting.	103
Setting	Key lock is activated by the <i>Pr. 161 Frequency setting/key</i>	Check Pr. 161 Frequency setting/key lock operation selection	269
	lock operation selection setting.	setting.	209
	Operation mode and a writing device do not	Check Pr. 79, Pr. 338, Pr. 339, Pr. 550, Pr. 551, and select	190,
	correspond.	an operation mode suitable for the purpose.	201

MEMO

PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter provides the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" of this product.

Always read the instructions before using the equipment.

3.1	Inspection items	300
5.2	Measurement of main circuit voltages, currents and powers	307

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

Precautions for maintenance and inspection

For some short time after the power is switched OFF, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the inverter is not more than 30VDC using a tester, etc.

6.1 Inspection items

6.1.1 Daily inspection

Basically, check for the following faults during operation.

- (1) Motor operation fault
- (2) Improper installation environment
- (3) Cooling system fault
- (4) Abnormal vibration, abnormal noise
- (5) Abnormal overheat, discoloration

6.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

For a periodic inspection, contact your sales representative.

- (1) Check for cooling system fault......Clean the air filter, etc.
- (2) Tightening check and retightening.....The screws and bolts may become loose due to vibration, temperature changes, etc. Check and tighten them.

Tighten them according to the specified tightening torque (Refer to page 18, 26).

- (3) Check the conductors and insulating materials for corrosion and damage.
- (4) Measure insulation resistance.
- (5) Check and change the cooling fan and relay.

When using the safety stop function, periodic inspection is required to confirm that safety function of the safety system operates correctly.

For more details, refer to the Safety stop function instruction manual (BCN-A211508-004). (Please contact your sales representative for the manual.)

6.1.3 Daily and periodic inspection

Aross	Inspection Item			Inte	erval	Corrective Action of	Cuatamaria
Area of Inspection			Description	Daily	Periodic *2	Corrective Action at Alarm Occurrence	Customer's Check
		ounding ronment	Check the surrounding air temperature, humidity, dirt, corrosive gas, oil mist, etc.	0		Improve environment	
General	Ove	rall unit	Check for unusual vibration and noise.	0		Check alarm location and retighten	
	Pow	er supply voltage	Check that the main circuit voltages are normal.*1	0		Inspect the power supply	
			(1) Check with megger (across main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer	
	Gen	eral	(2) Check for loose screws and bolts.		0	Retighten	
			(3) Check for overheat traces on the parts.		0	Contact the manufacturer	
			(4) Check for stain		0	Clean	
			(1) Check conductors for distortion.		0	Contact the manufacturer	
	Con	ductors, cables	(2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.)		0	Contact the manufacturer	
Main circuit	Tern	ninal block	Check for damage.		0	Stop the device and contact the manufacturer.	
			(1) Check for liquid leakage.		0	Contact the manufacturer	
	Smoothing aluminum electrolytic capacitor		(2) Check for safety valve projection and bulge.		0	Contact the manufacturer	
			(3) Visual check and judge by the life check of the main circuit capacitor (<i>Refer to page 302</i>)		0		
	Relay		Check that the operation is normal and no chatter is heard.		0	Contact the manufacturer	
	Operation check		(1) Check that the output voltages across phases with the inverter operated alone is balanced		0	Contact the manufacturer	
Control			(2) Check that no fault is found in protective and display circuits in a sequence protective operation test.		0	Contact the manufacturer	
circuit, Protective		Overall	(1) Check for unusual odor and discoloration.		0	Stop the device and contact the manufacturer.	
circuit	arts check		(2) Check for serious rust development		0	Contact the manufacturer	
		Aluminum	(1) Check for liquid leakage in a capacitor and deformation trace		0	Contact the manufacturer	
	P	electrolytic capacitor	(2) Visual check and judge by the life check of the main circuit capacitor (<i>Refer to page 302</i>)		0		
			(1) Check for unusual vibration and noise.	0		Replace the fan	
Cooling	Cool	ing fan	(2) Check for loose screws and bolts		0	Fix with the fan cover fixing screws	
system			(3) Check for stain		0	Clean	
			(1) Check for clogging		0	Clean	
	Heat	sink	(2) Check for stain		0	Clean	
			(1) Check that display is normal.	0		Contact the manufacturer	
Dieploy	Indic	cation	(2) Check for stain	_	0	Clean	
Display	Mete	er	Check that reading is normal	0		Stop the device and contact the manufacturer.	
Load motor	Оре	ration check	Check for vibration and abnormal increase in operation noise	0		Stop the device and contact the manufacturer.	

^{*1} It is recommended to install a device to monitor voltage for checking the power supply voltage to the inverter.

^{*2} One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. For a periodic inspection, contact your sales representative.

6.1.4 Display of the life of the inverter parts

The self-diagnostic alarm is output when the life span of the control circuit capacitor, cooling fan and each parts of the inrush current limit circuit is near its end. It gives an indication of replacement time.

The life alarm output can be used as a guideline for life judgement.

Parts	Judgement Level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated remaining life 10%
Inrush current limit circuit	Estimated remaining life 10%
	(Power on: 100,000 times left)
Cooling fan	Less than 50% of the predetermined speed



POINT

Refer to page 260 to perform the life check of the inverter parts.



6.1.5 Checking the inverter and converter modules

<Preparation>

- (1) Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W).
- (2) Prepare a tester. (Use 100Ω range.)

<Checking method>

Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, P/+ and N/-, and check for electric continuity.




NOTE

- 1. Before measurement, check that the smoothing capacitor is discharged.
- 2. At the time of electric discontinuity, the measured value is almost ∞. When there is an instantaneous electric continuity, due to the smoothing capacitor, the tester may not indicate ∞. At the time of continuity, the measured value is several to several tens-of ohms depending on the module type, circuit tester type, etc. If all measured values are almost the same, the modules are without fault.

<Module device numbers and terminals to be checked>

		Tester Polarity		Measured		Tester I	Polarity	Measured
		(+)	$\overline{\bigcirc}$	Value		⊕	$\overline{\bigcirc}$	Value
	D1	R/L1	P/+	Discontinuity	D4	R/L1	N/-	Continuity
<u></u>	וט	P/+	R/L1	Continuity	D4	N/-	R/L1	Discontinuity
Converter	D2	S/L2	P/+	Discontinuity	D5	S/L2	N/-	Continuity
on Moc	DZ	P/+	S/L2	Continuity	D3	N/-	S/L2	Discontinuity
0 -	D3*	T/L3*	P/+	Discontinuity	D6*	T/L3*	N/-	Continuity
	D3*	P/+	T/L3*	Continuity	D0*	N/-	T/L3*	Discontinuity
	TR1	U	P/+	Discontinuity	TR4	U	N/-	Continuity
	IKI	P/+	U	Continuity	11114	N/-	U	Discontinuity
ter Je	TR3	V	P/+	Discontinuity	TR6	V	N/-	Continuity
Inverter module	1173	P/+	V	Continuity	INO	N/-	V	Discontinuity
= =		W	P/+	Discontinuity		W	N/-	Continuity
	TR5	P/+	W	Continuity	TR2	N/-	W	Discontinuity



(Assumes the use of an analog meter.)

6.1.6 Cleaning

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.



NOTE

Do not use solvent, such as acetone, benzene, toluene and alcohol, as they will cause the inverter surface paint to peel off. The display, etc. of the operation panel and parameter unit (FR-PU04/FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

^{*} T/L3, D3 and D6 are only for the three-phase power input models.

6.1.7 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically. Use the life check function as a guidance of parts replacement.

Part Name	Standard Replacement Interval *1	Description		
Cooling fan	10 years	Replace (as required)		
Main circuit smoothing capacitor	10 years *2	Replace (as required)		
On-board smoothing capacitor	10 years	Replace the board (as required)		
Relays	_	as required		

- *1 Replacement years for when the yearly average surrounding air temperature is 40°C (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)
- *2 Output current: 80% of the inverter rated current



NOTE

For parts replacement, consult the nearest Mitsubishi FA Center.

(1) Cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the surrounding air temperature. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be replaced immediately.

Removal

1) Push the hooks from above and remove the fan cover.


FR-E740-095(SC) or less FR-E720S-050(SC) to 110(SC)




- FR-E740-120(SC) or more

- 2) Disconnect the fan connectors.
- 3) Remove the fan.

FR-E740-095(SC) or less FR-E720S-050(SC) to 110(SC)




FR-E740-120(SC) or more



$\sqrt{}$


Reinstallation

 After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.




- 2) Reconnect the fan connectors.
- 3) When wiring, avoid the cables being caught by the fan.

FR-E740-095(SC) or less FR-E720S-050(SC) to 110(SC)




FR-E740-120(SC) or more




4) Reinstall the fan cover.

FR-E740-095(SC) or less FR-E720S-050(SC) to 110(SC)



Example for FR-E740-095

FR-E740-120(SC) or more



Example for FR-E740-120



NOTE

- Installing the fan in the opposite of air flow direction can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power OFF before replacing fans. Since the inverter circuits are charged with voltage even after power OFF, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.

(2) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc. The replacement intervals greatly vary with the surrounding air temperature and operating conditions. When the inverter is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

When a certain period of time has elapsed, the capacitors will deteriorate more rapidly. Check the capacitors at least every year (less than six months if the life will be expired soon).

The appearance criteria for inspection are as follows:

- 1) Case: Check the side and bottom faces for expansion
- 2) Sealing plate: Check for remarkable warp and extreme crack.
- 3) Check for external crack, discoloration, liquid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.



POINT

Refer to page 260 to perform the life check of the main circuit capacitor.

(3) Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).

6.1.8 Inverter replacement

The inverter can be replaced with the control circuit wiring kept connected. Before replacement, remove the wiring cover of the inverter.




NOTE


- Do not replace the control terminal of the standard control circuit terminal model with the control terminal of the safety stop function model, or vice versa. If replaced by mistake, the inverter does not operate properly.
- Before starting inverter replacement, switch power OFF, wait for at least 10 minutes, and then check the voltage with a tester and such to ensure safety.
- Calibration bias and gain changes when changing the control circuit terminal block. Use *Pr. 645* and *CI(Pr. 901)* to calibrate again in that case.

• Replacement procedure (Example of FR-E740-095)

(1) Remove the installation screw of the control circuit terminal block. Pull the control circuit terminal downward.



(2) Using care not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the installation screw.





6.2 Measurement of main circuit voltages, currents and powers


Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured.

When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.

• When installing meters etc. on the inverter output side

When the inverter-to-motor wiring length is large, especially in the 400V class, small-capacity models, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

To measure and display the output voltage and output current of the inverter, it is recommended to use the AM-5 terminal output function of the inverter.



Measuring Points and Instruments

Item	Measuring Point	Measuring Instrument	Remarks (Reference Measured	d Value)
Power supply voltage V1	R/L1 and S/L2 S/L2 and T/L3 T/L3 and R/L1 *4	Moving-iron type AC voltmeter *5	Commercial power supply Within permissible AC voltage fluctuati page 314)	on (Refer to
Power supply side current	R/L1, S/L2, T/L3 line current *4	Moving-iron type AC ammeter *5		
Power supply side power P1	R/L1, S/L2, T/L3 and R/L1 and S/L2, S/L2 and T/L3, T/L3 and R/L1, *4	Digital power meter (designed for inverter) or electrodynamic type single- phase wattmeter	P1=W11+W12+W13 (3-wattmeter meth	ood)
Power supply side power factor Pf1	Calculate after measuring possible supply side current and power [Three-phase power supply] $Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1} \times 100$	er supply side power.	[Single-phase power supply] $Pf_1 = \frac{P_1}{V_1 \times I_1} \times 100 \%$	
Output side voltage V2 Across U and V, V and W, W and U		Rectifier type AC voltage meter *1 *5 (moving-iron type cannot measure)	Difference between the phases is within maximum output voltage.	n 1% of the
Output side current I2	U, V and W line currents	Moving-iron type AC ammeter *2 *5	Difference between the phases is 10% the rated inverter current.	or lower of
Output side power P2	U, V, W and U and V, V and W	Digital power meter (designed for inverter) or electrodynamic type single- phase wattmeter	P2 = W21 + W22 2-wattmeter method (or 3-wattmeter m	ethod)
Output side power factor Pf2	Calculate in similar manner $Pf_2 = \frac{P_2}{\sqrt{3}V_2 \times I_2} \times 100$	to power supply side power factors.	or.	
Converter output	Across P/+ and N/-	Moving-coil type (such as tester)	Inverter LED display is lit. 1.35 × V1 760V maximum during regeneration fo	r 400V class
Frequency setting signal	Across 2(positive) and 5 Across 4(positive) and 5		0 to 10VDC, 4 to 20mADC	
Frequency setting power supply	Across 10(positive) and 5		5.2VDC	"5" is common.
Frequency meter signal	Across AM(positive) and 5	Moving-coil type (tester and such may be	Approx. 10VDC at maximum frequency (without frequency meter)	-
Start signal Select signal	Across PC(positive) and the following: STF, STR, RH, RM, or RL	used) (internal resistance $50k\Omega$ or more)	When open	"PC" is
Reset	Across RES and PC(positive)		20 to 30VDC ON voltage: 1V or less	
Output stop*6	Across MRS and PC(positive)			
Fault signal Across A and C Across B and C		Moving-coil type (such as tester)	Across A and C Discontinuity C	<fault> Continuity scontinuity</fault>

^{*1} Use an FFT to measure the output voltage accurately. An FA tester or general measuring instrument cannot measure accurately.

^{*2} When the carrier frequency exceeds 5kHz, do not use this instrument since using it may increase eddy-current losses produced in metal parts inside the instrument, leading to burnout. In this case, use an approximate-effective value type.

^{*3} When the setting of Pr. 192 A,B,C terminal function selection is positive logic

^{*4} T/L3 is only for the three-phase power input models.

^{*5} A digital power meter (designed for inverter) can also be used to measure.

^{*6} Terminal MRS is only available for the standard control circuit terminal model.



6.2.1 Measurement of powers


Use electro-dynamometer type meters (for inverter) for the both of inverter input and output side. Alternatively, measure using electrodynamic type single-phase wattmeters for the both of inverter input and output side in two-wattmeter or threewattmeter method. As the current is liable to be imbalanced especially in the input side, it is recommended to use the threewattmeter method.

Examples of process value differences produced by different measuring meters are shown below.

An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or threewattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

[Measurement conditions]


Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of **Measuring Inverter Input Power**

[Measurement conditions]

Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of **Measuring Inverter Output Power**

6.2.2 Measurement of voltages and use of PT

(1) Inverter input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

(2) Inverter output side

Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A needle type tester can not be used to measure the output side voltage as it indicates a value much greater than the actual value. A moving-iron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave. The value monitored on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values using the operation panel.

No PT can be used in the output side of the inverter. Use a direct-reading meter. (A PT can be used in the input side of the inverter.)

6.2.3 Measurement of currents

Use a moving-iron type meter on both the input and output sides of the inverter. However, if the carrier frequency exceeds 5kHz, do not use that meter since an overcurrent losses produced in the internal metal parts of the meter will increase and the meter may burn out. In this case, use an approximate-effective value type.


Since current on the inverter input side tends to be unbalanced, measurement of three phases is recommended. Correct value can not be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output side current should be within 10%.


When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the operation panel. Examples of process value differences produced by different measuring meters are shown below.

[Measurement conditions]

[Measurement conditions]

Value indicated by moving-iron type ammeter is 100%. Value indicated by moving-iron type ammeter is 100%.





Example of measuring inverter input current

Example of measuring inverter output current


6.2.4 Use of CT and transducer

A CT may be used in both the input and output sides of the inverter, but the one used should have the largest possible VA ability because an error will increase if the frequency gets lower.

When using a transducer, use the effective value calculation type which is immune to harmonics.

6.2.5 Measurement of inverter input power factor

Calculate using effective power and apparent power. A power-factor meter can not indicate an exact value.



6.2.6 Measurement of converter output voltage (across terminals P/+ and N/-)


The output voltage of the converter is developed across terminals P/+ and N/- and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 270VDC to 300VDC (540VDC to 600VDC for the 400V class) is output when no load is connected and voltage decreases during driving load operation.

When energy is regenerated from the motor during deceleration, for example, the converter output voltage rises to nearly 400VDC to 450VDC (800VDC to 900VDC for the 400V class) maximum.



6.2.7 Insulation resistance test using megger

• For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500VDC megger.)





NOTE

- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.
- For the electric continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.

6.2.8 Pressure test

Do not conduct a pressure test. Deterioration may occur.

MEMO

7 / SPECIFICATIONS

This chapter provides the "SPECIFICATIONS" of this product. Always read the instructions before using the equipment.

7.1	Rating	314
7.2	Common specifications	316
7.3	Outline dimension drawings	317

Ļ

7.1 Rating

7.1.1 Inverter rating

• Three-phase 400V power supply

	Model FR-E740-□(SC)∗8-EC	016	026	040	060	095	120	170	230	300
App	olicable motor capacity (kW)*1	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
	Rated capacity (kVA)*2	1.2	2.0	3.0	4.6	7.2	9.1	13.0	17.5	23.0
Output	Rated current (A)*7	1.6 (1.4)	2.6 (2.2)	4.0 (3.8)	6.0 (5.4)	9.5 (8.7)	12	17	23	30
Out	Overload current rating*3			150% 60	s, 200% 3	s (inverse-t	ime charac	teristics)		
	Voltage*4				Three-p	hase 380 t	to 480V			
	Regenerative braking torque *5	10	100% 50% 20%							
<u>></u>	Rated input voltage/frequency	Three-phase 380 to 480V 50Hz/60Hz								
supply	Permissible AC voltage fluctuation	325 to 528V 50Hz/60Hz								
	Permissible frequency fluctuation	±5%								
Power	Power supply capacity (kVA)*6	1.5	2.5	4.5	5.5	9.5	12	17	20	28
Pro	tective structure (JEM1030)	Enclosed type (IP20)								
Cod	Cooling system		ooling			For	ced air coo	ling		
App	proximate mass (kg)	1.4	1.4	1.9	1.9	1.9	3.2	3.2	6.0	6.0

- *1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- *2 The rated output capacity indicated assumes that the output voltage is 440V.
- *3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- *4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply.
- *5 The braking torque indicated is a short-duration average torque (which varies with motor loss) when the motor alone is decelerated from 60Hz in the shortest time and is not a continuous regenerative torque. When the motor is decelerated from the frequency higher than the base frequency, the average deceleration torque will reduce. Since the inverter does not contain a brake resistor, use the optional brake resistor when regenerative energy is large. A brake unit (FR-BU2) may also be used.
- *6 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
- *7 Setting 2kHz or more in *Pr. 72 PWM frequency selection* to perform low acoustic noise operation in the surrounding air temperature exceeding 40°C, the rated output current is the value in parenthesis.
- *8 The safety stop function model is indicated with SC.

Single-phase 200V power supply

	Model FR-E720S-□(SC)∗8-EC	800	015	030	050	080	110	
App	licable motor capacity (kW)*1	0.1	0.2	0.4	0.75	1.5	2.2	
	Rated capacity (kVA)*2	0.3	0.6	1.2	2.0	3.2	4.4	
put	Rated current (A)*7	0.8 (0.8)	1.5 (1.4)	3.0 (2.5)	5.0 (4.1)	8.0 (7.0)	11.0 (10.0)	
Output	Overload current rating*3	15	50% 60s, 20	00% 3s (inv	erse-time cl	haracteristic	cs)	
	Rated output voltage*4		Three-phase 200 to 240V					
	Regenerative braking torque *5	150% 10		0%	50%	20%		
Sly	Rated input AC voltage/frequency	Single-phase 200 to 240V 50Hz/60Hz						
supply	Permissible AC voltage fluctuation	170 to 264V 50Hz/60Hz						
S Je	Permissible frequency fluctuation	Within ±5%						
Power	Power supply capacity (kVA)*6	0.5	0.9	1.5	2.5	4.0	5.2	
Pro	tective structure (JEM1030)	Enclosed type (IP20)						
Cod	oling system	Self-cooling Forced air cooling			ling			
App	proximate mass (kg)	0.6	0.6	0.9	1.4	1.5	2.0	

- The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor. *1
- The rated output capacity indicated assumes that the output voltage is 230V.
- The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load. If the automatic restart after instantaneous power failure function (Pr. 57) or power failure stop function (Pr. 261) is set and power supply voltage is low while load becomes bigger, the bus voltage decreases to power failure detection level and load of 100% or more may not be available.
- The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply.
- The braking torque indicated is a short-duration average torque (which varies with motor loss) when the motor alone is decelerated from 60Hz in the shortest time and is not a continuous regenerative torque. When the motor is decelerated from the frequency higher than the base frequency, the average deceleration torque will reduce. Since the inverter does not contain a brake resistor, use the optional brake resistor when regenerative energy is large. A brake unit (FR-BU2) may also be used. (Option brake resisitor cannot be used for FR-E720S-008(SC) and 015(SC), FR-E710W-008 and 015.)
- The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
- Setting 2kHz or more in Pr. 72 PWM frequency selection to perform low acoustic noise operation with the surrounding air temperature exceeding 40°C, the rated output current is the value in parenthesis.
- The safety stop function model is indicated with SC.


7.2 Common specifications

				Soft-PWM control/high carrier frequency PWM control (V/F control, Advanced magnetic flux vector control,			
	Control method			General-purpose magnetic flux vector control, Optimum excitation control are available)			
specifications	Out	tput frequency ra	inge	0.2 to 400Hz			
	Frequency setting Analog input resolution			0.06Hz/60Hz (terminal2, 4: 0 to 10V/10bit) 0.12Hz/60Hz (terminal2, 4: 0 to 5V/9bit) 0.06Hz/60Hz (terminal4: 0 to 20mA/10bit)			
ati			Digital input	0.01Hz			
cific		quency	Analog input	Within $\pm 0.5\%$ of the max. output frequency (25°C ± 10 °C)			
be	acc	uracy	Digital input	Within 0.01% of the set output frequency			
	Volt	tage/frequency c	haracteristics	Base frequency can be set from 0 to 400Hz, Constant-torque/variable torque pattern can be selected			
Control		rting torque		200% or more (at 0.5Hz)when Advanced magnetic flux vector control is set (3.7K or less)			
ပိ	Tor	que boost		Manual torque boost			
	Acc	celeration/deceler	ration time setting	0.01 to 360s, 0.1 to 3600s (acceleration and deceleration can be set individually), linear or S-pattern acceleration deceleration modes are available.			
		injection brake		Operation frequency (0 to 120Hz), operation time (0 to 10s), operation voltage (0 to 30%) can be changed.			
	Stal	Il prevention ope	eration level	Operation current level can be set (0 to 200% adjustable), whether to use the function or not can be selected			
		quency setting	Analog input	Two terminals Terminal 2: 0 to 10V, 0 to 5V can be selected Terminal 4: 0 to 10V, 0 to 5V, 4 to 20mA can be selected			
	sigr		The signal is entered from the operation panel or parameter unit. Frequency setting increment can be set. 4 digit BCD or 16bit binary data (when the option FR-A7AX E kit is used)				
	Sta	rt signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.			
	Input signal (Standard control circuit terminal model:Seven terminals Safety stop function model: Six terminals)			The following signals can be assigned to <i>Pr. 178 to Pr.184 (input terminal function selection)</i> : multi-speed selection, remote setting, stop-on contact selection, second function selection, terminal 4 input selection, JOG operation selection, PID control valid terminal, brake opening completion signal, external thermal input, PU-External operation switchover, V/F switchover, output stop, start self-holding selection, forward rotation, reverse rotation command, inverter reset, PU-NET operation switchover, External-NET operation switchover, command source switchover, inverter operation enable signal, and PU operation external interlock			
on specifications	Operational functions		ns	Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection, automatic restart after instantaneous power failure operation, forward/reverse rotation prevention, remote setting, brake sequence, second function, multi-speed operation, stop-on contact control, droop control, regeneration avoidance, slip compensation, operation mode selection, offline auto tuning function, PID control, computer link operation (RS-485)			
Operation	Safety stop function *2		1 *2	Safety shutoff signal can be input from terminals S1 and S2. (compliant with EN ISO 13849-1 Category 3 / PLd EN62061 / IEC61508 SIL2)			
o	Output signal Open collector output (Two terminals) Relay output (One terminal) Operating status For meter Analog output (0 to 10VDC: one terminal)		terminal)	The following signals can be assigned to Pr.190 to Pr.192 (output terminal function selection): inverter operation, upto-frequency, overload alarm, output frequency detection, regenerative brake prealarm, electronic thermal relay function prealarm, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward/reverse rotation output, brake opening request, fan alarm*1, heatsink overheat prealarm, deceleration at an instantaneous power failure, PID control activated, safety monitor output*2, safety monitor output2*2, during retry, life alarm, current average value monitor, remote output, alarm output, fault output, fault output 3, and maintenance timer alarm			
			ne terminal)	The following signals can be assigned to Pr.158 AM terminal function selection: output frequency, motor current (steady), output voltage, frequency setting, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, reference voltage output, motor load factor, PID set point, PID measured value, output power 0 to 10VDC			
Indication		eration panel	Operating status	The following operating status can be displayed: output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.			
Indi		2-PU07)	Fault record	Fault record is displayed when a fault occurs. Past 8 fault records (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored			
			Interactive guidance	Function (help) for operation guide *3			
	Protective functions function		Protective/warning function Protective functions during acceleration, overvoltage during constant speed, overvoltage du		Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure*5, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault *4, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 *4, safety circuit fault *2		
				Fan alarm*1, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage, operation panel lock, password locked, inverter reset, safety stop *2			
nt	Sur	rounding air ten	perature	-10°C to +50°C (non-freezing) *6			
Environment	Am	bient humidity		90%RH or less (non-condensing)			
ron	Sto	rage temperatur	e *7	-20°C to +65°C			
nvii	Atm	nosphere		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)			
ū	Alti	tude/vibration		Maximum 1000m above sea level, 5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)			


- As the FR-E740-016(SC), 026(SC), FR-E720S-008(SC) to 030(SC) are not provided with the cooling fan, this alarm does not function. This function is only available for the safety stop function model. This operation guide is only available with option parameter unit (FR-PU07). This protective function is not available in the initial status. This protective function is available with the three-phase power input model only. When using the inverters at the surrounding air temperature of 40°C or less, the inverters can be installed closely attached (0cm clearance). Temperatures applicable for a short time, e.g. in transit.

7.3 **Outline dimension drawings**


●FR-E720S-008(SC) to 030(SC)




●FR-E720S-050(SC), 080(SC)




- ●FR-E740-016(SC) to 095(SC)
- ●FR-E720S-110(SC)




●FR-E740-120(SC), 170(SC)




●FR-E740-230(SC), 300(SC)



•Parameter unit (option) (FR-PU07)



●Enclosure surface operation panel (option) (FR-PA07)



APPENDIX

This chapter provides the "APPENDIX" of this product. Always read the instructions before using the equipment.

Appendix 1 For customers who are replacing the conventional model with this inverter

Appendix 1-1 Replacement of the FR-E500 series

(1) Instructions for installation

- 1) Removal procedure of the front cover was changed. (Refer to page 5)
- 2) The operation panel cannot be removed from the inverter.
- 3) Plug-in options of the FR-E500 series are not compatible.
- 4) Setup software (FR-SW0-SETUP, FR-SW1-SETUP, FR-SW2-SETUP) can not be used.

(2) Instructions for continuous use of the FR-PU04 (parameter unit)

- 1) For the FR-E700 series, many functions (parameters) have been added. User initial value list and user clear of the HELP function can not be used.
- 2) For the FR-E700 series, many protective functions have been added. These functions activate, but all faults are displayed as "Fault 14". When the faults history has been checked, "E.14" appears. Added faults display will not appear on the parameter unit.
- 3) User initial value setting can not be used.
- 4) User registration/clear (user group 2) can not be used.
- 5) Parameter copy/verification function can not be used.

(3) Parameter resetting

It is easy if you use setup software (FR Configurator SW3).

(4) Main differences and compatibilities with the FR-E500 Series

Item	FR-E500	FR-E700
Control method	V/F control General-purpose magnetic flux vector control	V/F control General-purpose magnetic flux vector control Advanced magnetic flux vector control Optimum excitation control
	Torque boost (Pr. 0) initial value FR-E540-1.5K to 3.7K: 6% FR-E540-5.5K, 7.5K: 4% FR-E520S-1.5K, 2.2K: 6%	FR-E740-040(SC) to 095(SC): 4% FR-E740-120(SC), 170(SC): 3% FR-E720S-080(SC), 110(SC): 4%
	DC injection brake operation voltage (<i>Pr. 12</i>) initial value 6%	4%
	Frequency at 5V (10V) input (<i>Pr. 38</i>) Frequency at 20mA input frequency (<i>Pr. 39</i>) Second electronic thermal O/L relay (<i>Pr. 48</i>) Shortest acceleration/deceleration mode (<i>Pr. 60</i>)	Parameter number change (Pr. 125 Terminal 2 frequency setting gain frequency) (Pr. 126 Terminal 4 frequency setting gain frequency) (Pr. 51 Second electronic thermal O/L relay) (Pr. 60 Energy saving control selection) (Pr. 292 Automatic acceleration/deceleration)
	Reverse rotation from the inverter operation panel Press REV.	After setting "1" in <i>Pr. 40 RUN key rotation direction</i> selection, press (RUN).
	AM terminal function selection (<i>Pr. 158</i>) setting 0: Output frequency (initial value), 1: Output current, 2: Output voltage	AM terminal function selection (<i>Pr. 158</i>) setting 1: Output frequency (initial value), 2: Output current, 3: Output voltage
	Second applied motor Pr. 71 = 100 to 123	Pr. 450 Second applied motor
Changed/cleared functions	Terminal 2 0 to 5V, 0 to 10V selection (<i>Pr. 73</i>) setting 0: 0 to 5V (initial value), 1: 0 to 10V	Pr. 73 Analog input selection 0: 0 to 10V 1: 0 to 5V (initial value)
	Operation mode selection (<i>Pr. 79</i>) Initial value 1: PU operation mode	Initial value 0: External operation mode is selected at power on
	Setting 8: Operation mode switching by external signal Setting General-purpose magnetic flux vector	Setting 8: deleted (X16 signal is used instead)
	Pr. 80 ≠ 9999 User group 1 (16), user group 2 (16)	$Pr. 80 \neq 9999, Pr. 81 \neq 9999, Pr. 800 = 30$ User group (16) only, setting methods were partially changed
	(<i>Pr.</i> 160, <i>Pr.</i> 173 to <i>Pr.</i> 175) Input terminal function selection (<i>Pr.</i> 180 to <i>Pr.</i> 183) setting 5: STOP signal (start self-holding selection) 6: MRS signal (output stop)	(Pr. 160, Pr. 172, Pr. 173) Pr. 178 to Pr. 184 Input terminal function selection setting 5: JOG signal (Jog operation selection) 6: None 24: MRS signal (output stop) 25: STOP signal (start self-holding selection)
	Cooling fan operation selection(<i>Pr. 244</i>) initial setting 0: Cooling fan operates in power-on status.	1: Cooling fan on/off control valid
	Stop selection (<i>Pr. 250</i>) setting increments 1s	0.1s
	RS-485 communication control source from the PU connector PU operation mode	Network operation mode (PU operation mode as FR- E500 when <i>Pr.</i> 551 = 2)
	Earth (ground) fault detection Detects always	Detects only at a start
Control terminal block	Fixed terminal block (can not be removed) Screw type terminal block (Phillips screw M2.5) Length of recommended blade terminal is 7mm.	Removable terminal block Standard control circuit terminal model: Screw type terminal block (Flathead screw M2 (M3 for terminal A, B, and C) Length of recommended blade terminal is 5mm (6mm
		for terminal A, B and C). Safety stop function model: Spring clamp terminal block (Fixes a wire with a pressure of inside spring) Length of recommended blade terminal is 10mm
Operation panel	Removable operation panel (PA02)	Integrated operation panel (can not be removed)
Parameter unit	FR-PU07 FR-PU04 (some functions, such as parameter copy, are invalid.)	
	Dedicated plug-in option (i FR-E5NC : CC-Link communication	installation is incompatible) FR-A7NC E kit : CC-Link communication
Plug-in option	FR-E5ND : DeviceNet communication FR-E5NL : LonWorks communication	FR-A7ND E kit : DeviceNet communication FR-A7NL E kit : LonWorks communication
Installation size	FR-E740-016(SC) to 170(SC), FR-E720S-110(SC) are co	ompatible in mounting dimensions

Appendix 2 Specification change

Appendix 2-1 SERIAL number check

Check the SERIAL number indicated on the inverter rating plate or package. (Refer to page 2)

Rating plate example

<u>□</u>	<u>O</u>	<u>○</u>	OOOOOO	SERIAL (Serial No.)
Symbol	Year	Month	Control number	
	TCOC	OOAOO	0 G 00	TC number

The SERIAL consists of 1 version symbol, 2 numeric characters or 1 numeric character and 1 alphabet letter indicating year and month, and 6 numeric characters indicating control number. Month is indicated as 1 to 9, X (October), Y (November), and Z (December).

Appendix 2-2 Changed Functions

- (1) •Writing to *Pr.19 Base frequency voltage* while inverter is running by setting *Pr.77 Parameter write selection*="2".
 - Pr.296 Password lock level, Pr. 297 Password lock/unlock, and output of Password locked error (LOCd).
 - Multi command of Mitsubishi inverter protocol (computer link communication), reading of connected inverter type and capacity, special monitor "Cumulative power 2," and reading of fault history "E.OPT".
 - Real time monitor of Modbus-RTU communication "Cumulative power 2," and reading of fault history "E.OPT".
 - Output of option fault (E.OPT)
 - Communication parameters for FR-A7ND (Pr.345 and Pr.346)

When parameter clear/all parameter clear is performed using DeviceNet communication or RS-485 communication, communication parameters (*Pr.345 and Pr.346*) are not cleared.

For single-phase 200V class, the changes apply to the February 2009 production or later.

For three-phase 400V class, the changes apply to the product with below SERIAL number or later.

Check the SERIAL number and TC number indicated on the inverter rating plate.

Туре	SERIAL number	10th and 11th Digits of TC Number
FR-E740-016 to 300-EC	□9200000	G5*

Changes do not apply to the products of which 10th and 11th digits of TC number are G6.

Appendix 3 Index

Numerics	(SU, FU signal, Pr. 41 to Pr. 43)
15-speed selection (combination with three speeds RL, RM,	Display of the life of the inverter parts
RH)(REX signal)	(Pr. 255 to Pr. 259)
/ (<u></u>	Droop control (Pr. 286 to Pr. 287)256
A	During PID control activated (PID signal)141, 242, 249
Acceleration time, deceleration time setting (Pr. 7, Pr. 8, Pr.	During retry (Y64 signal)
20, Pr. 21, Pr. 44, Pr. 45)	_
Acceleration/deceleration pattern (Pr. 29)109	E
Actual operation time	Earth (ground) fault detection at start (Pr. 249)168
Advanced magnetic flux control (Pr. 71, Pr. 80, Pr. 81, Pr. 89,	Easy operation mode setting (easy setting mode)56
Pr. 800)	Electronic thermal O/L relay pre-alarm (TH)112, 282
Alarm output (LF signal) 141, 211, 228, 259	Electronic thermal O/L relay pre-alarm (THP signal)112, 141
Analog input fault (E.AIE)	Electronic Thermal Relay Function Load Factor
Analog input selection(Pr. 73, Pr. 267)	Extended parameter display and user group function (Pr. 160, Pr. 172 to Pr. 174)
Applied motor (Pr. 71, Pr. 450)	External thermal relay input (OH signal)
Automatic restart after instantaneous power failure/flying start	External thermal relay input (OT signal)
(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	External/NET operation switchover (turning ON X66 selects
Avoid mechanical resonance points (frequency jumps) (Pr. 31	NET operation) (X66 signal)
to Pr. 36)	., , (3 . ,
(a)	F
В	Fan alarm (FN)259, 283
Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	Fan fault output (FAN signal)141, 259
Basic operation (factory setting)	Fault or alarm indication
Bias and gain of frequency setting voltage (current) (Pr. 125,	Fault output (ALM signal)141, 144
Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	Fault output 3 (power-OFF signal) (Y91 signal)141, 144
Brake opening completion signal (BRI signal) 131, 135	Faults history (E)
Brake opening request (BOF signal)131, 141	Fin overheat (E.FIN)
Brake sequence fault (E.MB4 to 7)	Forward rotation command (assigned to STF terminal (Pr.
Brake sequence function (Pr. 278 to Pr. 283, Pr. 292) 131	178) only) (STF signal)
Brake transistor alarm detection (E.BE)	Frequency setting value
Buzzer control (Pr. 990)	Front cover
С	Tront cover
Cables and wiring length	G
Change the control method (Pr. 80, Pr. 81, Pr. 800)	General-purpose magnetic flux vector control (Pr. 71, Pr. 80,
Change the parameter setting value	Pr. 81, Pr. 800)
Changing the control logic	,
Checking the inverter and converter modules	Н
Cleaning	Heatsink overheat pre-alarm (FIN signal)141, 286
Command source switchover (turning ON X67 makes Pr. 338	High speed operation command (RH signal)98, 135
and Pr. 339 commands valid) (X67 signal)	
Communication EEPROM write selection (Pr. 342) 214	I
Communication option fault (E.OP1)	Initial settings and specifications of RS-485 communication
Condition selection of function validity by second function	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)
selection signal (RT signal)	Input phase loss (E.ILF)
Connection of a DC reactor (FR-HEL)	Input terminal function selection(Pr. 178 to Pr. 189)
Connection of the brake unit (FR-BU2)	Input Terminal Status
Connection of the high power factor converter (FR-HC) 37	(Pr. 251, Pr. 872)
Connection of the power regeneration common converter	Inrush current limit circuit fault (E.IOH)
(FR-CV)	Insulation resistance test using megger
Connection to the PU connector	Internal board fault(E.PE2)
Control circuit terminal	Internal circuit fault (E.13)
Converter Output Voltage150	Inverter I/O Terminal Monitor
Converter output voltage peak value	Inverter installation environment8
Cooling fan operation selection (Pr. 244)	Inverter operation ready (RY signal)141, 143
Cooling system types for inverter panel	Inverter output shutoff signal (MRS signal, Pr. 17)137
CPU error (E.5, E.6, E. 7, E.CPU)	Inverter overload trip (electronic thermal relay function)
Cumulative energization time	(E.THT)
Cumulative power	Inverter placement
Current average value monitor signal (Pr. 555 to Pr. 557) 265 Current average value monitor signal (Y93 signal) 141, 265	Inverter replacement 306
Outfork average value monitor signal (193 Signal) 141, 203	Inverter reset (Err.) 278, 281
D	Inverter reset (RES signal)
Daily and periodic inspection	signal)
Daily inspection	Inverter running (RUN signal)
Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	Inverter thermal load factor
DC injection brake (Pr. 10 to Pr. 12)	Inverter-generated noises and their reduction techniques42
Detection of output frequency	J

J	Output voltage
Jog operation (Pr. 15, Pr. 16)100	Overcurrent trip during acceleration (E.OC1)
JOG operation selection (JOG signal)100, 135	Overcurrent trip during constant speed (E.OC2)28-
	Overcurrent trip during deceleration or stop (E.OC3) 28-
L	Overload alarm (OL signal)88, 14
Leakage currents and countermeasures40	р
Life alarm (Y90 signal)141, 260	•
Load pattern selection (Pr. 14)96	Parameter list
Low-speed operation command (RL signal)98, 135	Parameter storage device fault
	(control circuit board) (E.PE)
M	Parameter write disable selection (Pr. 77)
Magnitude of frequency change setting (Pr. 295)271	Parameter write error (Er1 to Er4)
Maintenance signal output (MT)264, 283	Password function (Pr. 296, Pr. 297)
Maintenance timer alarm (Pr. 503, Pr. 504)264	Periodic inspection
Maintenance timer signal (Y95 signal)141, 264	Peripheral devices.
Manual torque boost (Pr. 0, Pr. 46)	PID control (Pr. 127 to Pr. 134)
Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)92	PID control valid terminal (X14 signal)
Measurement of converter output voltage	PID Deviation
Measurement of currents	PID Forward/Reverse Rotation Output
Measurement of powers	(RL signal)141, 242, 249
Measurement of voltages and use of PT	PID lower limit (FDN signal)141, 242, 249
Middle-speed operation command (RM signal)98, 135	PID Measured Value
Mitsubishi inverter protocol	PID Set Point
(computer link communication)	PID upper limit (FUP signal)141, 242, 245
Modbus-RTU communication specifications (Pr. 117, Pr. 118,	Power failure deceleration signal (Y46 signal)141, 16-
Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	Power supply harmonics4
Monitor display selection of DU/PU and terminal AM (Pr. 52,	Power-failure deceleration stop function (Pr. 261)
Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)150	Pressure test
Motor Load Factor150	PU contrast adjustment (Pr. 991)
Motor overheat protection (Electronic thermal O/L relay) (Pr.	PU disconnection (E.PUE)
O. D., E4)	PU display language selection(Pr. 145)
9, Pr. 51)	LUL apparation systemal interlegic (V40 signal) 125 100
Motor overload trip (electronic thermal relay function)	PU operation external interlock (X12 signal)
Motor overload trip (electronic thermal relay function) (E.THM)112, 286	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) 112, 286 (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) 112, 286 Motor thermal load factor 150 Motor Torque 150 N Names and functions of the operation panel 54 O Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) 98 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) 201 Operation mode at power-ON (Pr. 79, Pr. 340) 200 Operation mode selection (Pr. 79) 190 Operation panel frequency setting/key lock operation selection (Pr. 161) 269 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502) 211 Optimum excitation control (Pr. 60) 169 Option fault (E.1) 288 Option input terminal status 150	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) 112, 286 Motor thermal load factor 150 Motor Torque 150 N Names and functions of the operation panel 54 O Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) 98 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) 201 Operation mode at power-ON (Pr. 79, Pr. 340) 200 Operation mode selection (Pr. 79) 190 Operation panel frequency setting/key lock operation selection (Pr. 161) 269 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502) 211 Optimum excitation control (Pr. 60) 169 Option fault (E.1) 288 Option input terminal status 150 Option output terminal status 150 Output current 150, 155	PU stop (PS)
Motor overload trip (electronic thermal relay function) 112, 286 Motor thermal load factor 150 Motor Torque 150 N Names and functions of the operation panel 54 O Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) 98 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) 201 Operation mode at power-ON (Pr. 79, Pr. 340) 200 Operation mode selection (Pr. 79) 190 Operation panel frequency setting/key lock operation selection (Pr. 161) 269 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502) 211 Optimum excitation control (Pr. 60) 169 Option fault (E.1) 288 Option input terminal status 150 Option output terminal status 150 Output current 150, 155 Output current detection (Y12 signal) 141, 141, 146	PU stop (PS)
Motor overload trip (electronic thermal relay function) 112, 286 Motor thermal load factor 150 Motor Torque 150 N Names and functions of the operation panel 54 O Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) 98 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) 201 Operation mode at power-ON (Pr. 79, Pr. 340) 200 Operation mode selection (Pr. 79) 190 Operation panel frequency setting/key lock operation selection (Pr. 161) 269 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502) 211 Optimum excitation control (Pr. 60) 169 Option fault (E.1) 288 Option input terminal status 150 Option output terminal status 150 Output current 150, 155 Output current detection function (Y12 signal) 141, 141, 146 Output current detection function (Y12 signal, Y13 signal, Pr.	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) 112, 286 Motor thermal load factor 150 Motor Torque 150 N Names and functions of the operation panel 54 O Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239) 98 Operation command source and speed command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551) 201 Operation mode at power-ON (Pr. 79, Pr. 340) 200 Operation mode selection (Pr. 79) 190 Operation panel frequency setting/key lock operation selection (Pr. 161) 269 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502) 211 Optimum excitation control (Pr. 60) 169 Option fault (E.1) 288 Option fault (E.OPT) 287 Option output terminal status 150 Option output terminal status 150 Option toutput current detection (Y12 signal) 141, 141, 146 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153) 146 Output frequency 150, 155 Output frequency 150, 155	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)
Motor overload trip (electronic thermal relay function) (E.THM)	PU stop (PS)

5		
Safety circuit fault (E.SAF)		
Safety stop (SA)		
Safety stop function (available only for the safety stop fu		
model)		
Safety stop function model Second function selection (RT signal)		
Selection of a regenerative brake (Pr. 30, Pr. 70)		
Setting dial push		
Shortest acceleration/deceleration (automatic acceleration)		
deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)		
Slip compensation (Pr. 245 to Pr. 247)		87
Specification of main circuit terminal		
Speed display and speed setting (Pr. 37)		
Speed smoothing control (Pr. 653)		
Stall prevention (E.OLT)		
Stall prevention (overcurrent) (OL)		
Stall prevention (overvoltage) (oL)		
Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 60		
156, Pr. 157, Pr. 277)	•••••	88
Standard control circuit terminal model		
Start self-holding selection (STOP signal)	SS, I	139 Or
250)		
Starting frequency and start-time hold function (Pr. 13,	1 Pr	139
571)		
Stop selection (Pr. 250)		
Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270)	. Pr.	
275, Pr. 276)		
Stop-on contact selection 0 (RL signal)		
Stop-on contact selection 1 (RT signal)	<i>29, 1</i>	135
_		
Т		
Terminal 4 input selection (AU signal) 1		
Terminal AM calibration (calibration parameter Pr. 645		
(Pr.901))		156
Terminal arrangement of the main circuit terminal, pow		
supply and the motor wiring		
Terminal connection diagram To exhibit the best performance of the motor performa		
(offline auto tuning) (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to		
Pr. 96, Pr. 859)		
U		
Undervoltage (UV)	2	283
Up-to-frequency signal (SU signal)		
USB communication (Pr. 547, Pr. 548)		
USB communication fault (E.USB)	41, 2	289
Use of CT and transducer		
V		
V/F switchover (V/F control is exercised when X18 is 0		
(X18 signal)	<i>80, 1</i>	135
•••		
W		
Wiring and configuration of PU connector		
Wiring cover		
Wiring of control circuit		
Wiring of control circuit	•••••	26
Z		
	11	116
Zero current detection (Y13 signal) 1	41, 1	140

Print Date	*Manual Number	Revision
Oct. 2007	IB(NA)-0600336ENG-A	First edition
Dec. 2007	IB(NA)-0600336ENG-B	Addition • FR-E740-230, 300
Oct. 2008	IB(NA)-0600336ENG-C	Addition • FR-E720S-008 to 110 Modification • 5.5 Check first when you have a trouble
Aug. 2010	IB(NA)-0600336ENG-D	Addition Pr. 296 Password lock level Pr. 297 Password lock/unlock Password locked (LOCd) Option fault (E.OPT) Safety stop function model FR-E740-016SC to 300SC FR-E720S-008SC to 110SC Setting values "80, 81, 180, 181" of Pr.190 to Pr.192 (Output terminal function selection) Safety stop (SA) Safety circuit fault (E.SAF)

1 For Maximum Safety

- Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to
 install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product
 are likely to cause a serious accident.
- Please do not use this product for loads other than three-phase induction motors.

