



INVERTER

FR-A7NC E kit-SC

INSTRUCTION MANUAL

CC-Link communication function

PRE-OPERATION INSTRUCTIONS	1
INSTALLATION	2
WIRING	3
INVERTER SETTING	4
FUNCTION OVERVIEW	5
I/O SIGNAL LIST	6
DETAILS OF INPUT AND OUTPUT SIGNALS	7
PROGRAMMING EXAMPLES	8
HOW TO CHECK FOR ERROR USING THE LEDS	9

Thank you for choosing this Mitsubishi Inverter plug-in option. This Instruction Manual gives handling information and precautions for use of this equipment. Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use the equipment to its optimum. Please forward this manual to the end user.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect this product until you have read through this Instruction Manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



WARNING

Incorrect handling may cause hazardous conditions, resulting in death or severe injury.



CAUTION

Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.



The **CAUTION** level may even lead to a serious consequence according to conditions. Both instruction levels must be followed because these are important to personal safety.

SAFETY INSTRUCTIONS

1. Electric Shock Prevention



WARNING

- While power is ON or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed high-voltage terminals and charging part and get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. You may accidentally touch the charged inverter circuits and get an electric shock.
- Before wiring or inspection, power must be switched OFF. To confirm that, LED indication of the operation panel must be checked. (It must be OFF.) Any person who is involved in wiring or inspection shall wait for at least 10 minutes after the power supply has been switched OFF and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.
- Any person who is involved in wiring or inspection of this equipment shall be fully competent to do the work.
- The plug-in option must be installed before wiring. Otherwise, you may get an electric shock or be injured.
- Do not touch the plug-in option or handle the cables with wet hands. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.

2. Injury Prevention

CAUTION

- The voltage applied to each terminal must be the ones specified in the Instruction Manual. Otherwise burst, damage, etc. may occur.
- The cables must be connected to the correct terminals. Otherwise burst, damage, etc. may occur.
- Polarity must be correct. Otherwise burst, damage, etc. may occur.
- While power is ON or for some time after power-OFF, do not touch the inverter as they will be extremely hot. Doing so can cause burns.

3. Additional Instructions

Also the following points must be noted to prevent an accidental failure, injury, electric shock, etc.

1) Transportation and mounting

CAUTION

- Do not install or operate the plug-in option if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the product.
- The mounting orientation must be correct.
- Foreign conductive objects must be prevented from entering the inverter. That includes screws and metal fragments or other flammable substances such as oil.

2) Trial run

CAUTION

- Before starting operation, each parameter must be confirmed and adjusted. A failure to do so may cause some machines to make unexpected motions.

3) Usage

WARNING

- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

CAUTION

- When parameter clear or all parameter clear is performed, the required parameters must be set again before starting operations because all parameters return to the initial value.
- For prevention of damage due to static electricity, nearby metal must be touched before touching this product to eliminate static electricity from your body.

4) Maintenance, inspection and parts replacement

CAUTION

- Do not test the equipment with a megger (measure insulation resistance).

5) Disposal

CAUTION

- This inverter plug-in option must be treated as industrial waste.

6) General instruction

Many of the diagrams and drawings in this Instruction Manual show the inverter without a cover or partially open for explanation. Never operate the inverter in this manner. The cover must be reinstalled and the instructions in the inverter manual must be followed when operating the inverter.

— CONTENTS —

1	PRE-OPERATION INSTRUCTIONS	1
1.1	Unpacking and product confirmation	1
1.1.1	Product confirmation	1
1.2	Parts	2
1.3	Inverter option specifications	4
1.4	CC-Link version	5
1.4.1	CC-Link ver. 1.10	5
1.4.2	CC-Link ver. 2	5
2	INSTALLATION	6
2.1	Pre-installation instructions	6
2.2	Installation procedure	6
3	WIRING	12
3.1	System configuration example	12
3.2	Connection of several inverters	13
3.3	Connection cable	16
3.4	Wiring	16
4	INVERTER SETTING	19

4.1	Parameter list	19
4.2	Operation Mode Setting	20
4.2.1	Operation mode indicator	20
4.2.2	Operation mode switching and communication startup mode (Pr. 79, Pr. 340)	21
4.3	Start and Speed Command Sources (Pr. 338, Pr. 339, Pr. 550)	24
4.3.1	Communication EEPROM write selection (Pr. 342)	28
4.4	Operation at Communication Error Occurrence	29
4.4.1	Operation selection at communication error occurrence (Pr. 500 to Pr. 502)	29
4.4.2	Fault and measures	33
4.5	Inverter Reset	34
4.6	CC-Link function setting	36
4.6.1	Station number setting (Pr. 542)	36
4.6.2	Baud rate setting (Pr. 543)	37
4.6.3	Frequency command with sign (Pr. 541)	38
5	FUNCTION OVERVIEW	39
<hr/> <hr/>		
5.1	Function block diagram	39
5.2	Output from the inverter to the network	40
5.3	Input to the inverter from the network	41
6	I/O SIGNAL LIST	42
<hr/> <hr/>		
6.1	CC-Link extended setting (Pr. 544)	42
6.2	I/O signal list	43

6.2.1	I/O signal when CC-Link ver.1 one station (FR-E500 series compatible) is occupied (Pr. 544 = 0)	43
6.2.2	I/O signal when CC-Link ver.1 one station is occupied (Pr. 544 = "1")	46
6.2.3	I/O signal when CC-Link ver.2 double setting is selected (Pr. 544 = "12")	47
6.2.4	I/O signal when CC-Link ver.2 quadruple setting is selected (Pr. 544 = "14")	48
6.2.5	I/O signal when CC-Link ver.2 octuple setting is selected (Pr. 544 = "18")	49

7 DETAILS OF INPUT AND OUTPUT SIGNALS 51

7.1	Details of remote input and output signals	51
7.1.1	Output signals (master module to inverter (FR-A7NC))	51
7.1.2	Input signals (inverter (FR-A7NC) to master module)	53
7.2	Details of remote register	55
7.2.1	Remote register (master module to inverter (FR-A7NC))	55
7.2.2	Remote register (inverter (FR-A7NC) to master module)	58
7.2.3	Instruction codes	61
7.2.4	Monitor codes	66

8 PROGRAMMING EXAMPLES 68

8.1	Program example for reading the inverter status	71
8.2	Program example for setting the operation mode	72
8.3	Program example for setting the operation commands	73
8.4	Program example for monitoring the output frequency	74
8.5	Program example for parameter reading	75
8.6	Program example for parameter writing	76
8.7	Program example for setting the running frequency	77

8.8	Program example for fault record reading	79
8.9	Program example for resetting the inverter at inverter error	80
8.10	Instructions	81
9	HOW TO CHECK FOR ERROR USING THE LEDS	83
9.1	When one inverter is connected.....	83
9.2	When two or more inverters are connected	85
9.3	Communication stops during operation.....	87

1 PRE-OPERATION INSTRUCTIONS



1.1 Unpacking and product confirmation

Take the plug-in option out of the package, check the product name, and confirm that the product is as you ordered and intact.

This product is a plug-in option dedicated for the FR-E700-SC series (Safety stop function model).

1.1.1 Product confirmation

Check the enclosed items.

<p>Plug-in option 1</p> 	<p>Junction connector.....1 (Refer to page 7, 9.)</p> 	<p>Spacer for plug-in option mounting.....1 (Refer to page 7, 9.)</p> 	<p>Terminal block..... 1 (Refer to page 16)</p> 
<p>Front cover for plug-in option 1 (Refer to page 7, 9.)</p> 	<p>M3 mounting screw (Long) (M3 × 20mm).....1 (Short) (M3 × 6mm).....1 (Refer to page 7, 9.)</p> 	<p>Hexagon spacer.....1 (Refer to page 7, 9.)</p> 	

CAUTION

- Install a provided front cover for plug-in option, in place of the inverter front cover .

1.2 Parts

Connector for communication


Mount the accessory terminal block to connect to the network.
(Refer to page 16.)

Mounting hole

Terminating resistor selection switch


Select the resistor value of the terminating resistor. *(Refer to page 13.)*

Front view



Mounting hole

Rear view




Mounting hole

Connector

Connect to the inverter option connector.

Terminal layout



Operation status indication LED

Lit/flicker of the LED indicate operation status. *(Refer to page 3.)*

● Operation status indication LED

LED	Description
L.RUN	Lit when refresh data is properly received. Turns OFF when a data transmission is stopped for a certain period of time.
L.ERR	<ul style="list-style-type: none">• Lit when a communication error occurs in the own station and flickers when settings of switch, etc. are changed while power is ON.• Flickers when the <i>Pr. 542</i> or <i>Pr. 543</i> setting is changed. Turn the power ON again or turn the RES signal ON. (Refer to page 36, 37.)
RUN	Lit during normal operation (5V is supplied in the board) (Lit even in the noncommunication status.) Flickers when the master station is CC-Link ver.1 and the FR-A7NC is CC-Link ver.2 compatible. (Refer to page 5.)
SD	Turns OFF when no data is transmitted.
RD	Lit when the received data carrier is detected.

REMARKS

- Set the station number using *Pr. 542 Communication station number (CC-Link)*. (Refer to page 36.)
- Set transmission baud rate using *Pr.543 Baud rate selection (CC-Link)*. (Refer to page 37.)

1.3 Inverter option specifications

Type	Inverter plug-in option type, terminal block connectable
Power supply	5VDC supplied from the inverter
Number of units connected	42 units max. (Refer to <i>page 42</i> for the number of stations occupied.) May be used with other equipment.
Cable size	0.3mm ² to 0.75mm ²
Station type	Remote device station
Number of stations occupied	CC-Link ver.1: occupies one station CC-Link ver.2: occupies one station (selectable from among double, quadruple and octuple)
Communication cable	CC-Link dedicated cable, CC-Link ver. 1.10 compatible CC-Link dedicated cable

1.4 CC-Link version

1.4.1 CC-Link ver. 1.10

The conventional CC-Link products, whose inter-station cable lengths have equally been changed to 20cm (7.87 inch) or more to improve the inter-station cable length restriction, are defined as CC-Link ver. 1.10. In comparison, the conventional products are defined as CC-Link ver. 1.00.

Refer to the CC-Link Master Module Manual for the maximum overall cable lengths and inter-station cable lengths of CC-Link ver. 1.00 and ver. 1.10.

CC-Link ver. 1.10 compatibility conditions

- 1) All modules that comprise a CC-Link system should be compatible with CC-Link ver. 1.10.
- 2) All data link cables should be CC-Link ver. 1.10 compatible, CC-Link dedicated cables.
(CC-Link ver. 1.10 compatible cables have a *CC-Link* logo or ver. 1.10 indication.)

CAUTION


- In a system that uses the CC-Link ver. 1.00 and ver. 1.10 modules and cables together, the maximum overall cable length and inter-station cable length are as specified for CC-Link ver. 1.00.

1.4.2 CC-Link ver. 2

The FR-A7NC is compatible with CC-Link ver.2.

When using the CC-Link ver.2 setting with the FR-A7NC, the master station needs to be compatible with the CC-Link ver.2.

For CC-Link ver.2, double, quadruple and octuple settings can be used to increase the remote register (RWr/w) points.



2 INSTALLATION

2.1 Pre-installation instructions

Make sure that the input power of the inverter is OFF.

CAUTION

-  With input power ON, do not install or remove the plug-in option. Otherwise, the inverter and plug-in option may be damaged.
-  For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

2.2 Installation procedure

CAUTION


- Always perform wiring to the main circuit terminals and control circuit terminals before installing the option. Wiring cannot be performed after installing the option.
- When mounting the plug-in option, do not let wires get caught in the plug-in option or the spacer for option mounting. If a wire gets caught, the inverter and the plug-in option may be damaged.
- When the inverter cannot recognize that the option unit is mounted due to improper installation, etc., "E. I" (option fault) is displayed.
- When mounting/removing an option, hold the sides of the circuit board. Do not press on the parts on the circuit board. Stress applied to the parts by pressing, etc. may cause a failure.
- Take caution not to drop mounting screws during the mounting and removal of the option.
- Pull the option straight out when removing. Pressure applied to the connector and to the circuit board may break the option.

REMARKS

- Because the voltage class, model name and serial number (only voltage class is labeled for FR-E720-5.5KSC (FR-E720-240SC), FR-E740-5.5KSC (FR-E740-120SC) or higher) are written on the PU cover, replace the PU cover of the plug-in option with the removed PU cover of the inverter.

● Inverter with one front cover


- (1) Remove the front cover from the inverter. (For removing the front cover, refer to the FR-E700 instruction manual.)
- (2) Remove the PU cover from the front cover. Open the PU cover with a driver, etc. and remove it in the direction of arrow as shown below.



- (3) Mount the spacer for plug-in option mounting, the hexagon spacer, and the junction connector. Fit the junction connector to the guide of the connector at the inverter side, and insert the junction connector as far as it goes.
- (4) Fit the connector of the plug-in option to the guide of the junction connector, and insert the plug-in option as far as it goes.
- (5) Fix the plug-in option securely by using the supplied mounting screw (short) to the upper screw hole and the other supplied mounting screw (long) to the lower screw hole of the plug-in option. If the screw holes do not line up, the connector may not have been plugged properly. Check for loose plugging. Tightening torque: 0.33 to 0.4N·m


7 INSTALLATION

- (6) Remove the PU cover provided on the front cover for plug-in option and install the other PU cover, which was removed in (2).
- (7) Mount the already wired terminal block to the plug-in option. (Refer to *Chapter 3* for wiring.)
- (8) Install the front cover for plug-in option to the inverter.




● Inverter with front covers 1 and 2

- (1) Remove the front covers 1 and 2 from the inverter. (For removing the front cover, refer to the FR-E700 instruction manual.)
- (2) Remove the PU cover from the front cover 2. For removing the PU cover, refer to *page 7*.




- (3) Install the front cover 1 to the inverter.
- (4) Mount the spacer for plug-in option mounting, the hexagon spacer, and the junction connector. Fit the junction connector to the guide of the connector at the inverter side, and insert the junction connector as far as it goes.
- (5) Fit the connector of the plug-in option to the guide of the junction connector, and insert the plug-in option as far as it goes.
- (6) Fix the plug-in option securely by using the supplied mounting screw (short) to the upper screw hole and the other supplied mounting screw (long) to the lower screw hole of the plug-in option. If the screw holes do not line up, the connector may not have been plugged properly. Check for loose plugging.
Tightening torque: 0.33 to 0.4N·m
- (7) Remove the PU cover provided on the front cover for plug in option and install the other PU cover, which was removed in (2).
- (8) Mount the already wired terminal block to the plug-in option. (Refer to *Chapter 3* for wiring.)
Pass the CC-Link cable over the front cover 1 of the inverter. (Refer to the finished installation figure in the next page.) If a CC-Link cable is passed through underneath the front cover 1, the bending radius of the cable shortens, stressing the cable.
- (9) Install the front cover for plug-in option to the inverter.



3 WIRING

3.1 System configuration example

- (1) Programmable controller side
Mount the "QJ61BT11N", "AJ61QBT11", "A1SJ61QBT11", "AJ61BT11", "A1SJ61BT11" or "LJ61BT11" "CC-Link system master/local module" on the main or extension base unit having the programmable controller CPU used as the master station.
- (2) Inverter side
Mount the option (FR-A7NC) on the inverter.
- (3) Connect the programmable controller CC-Link module master station and the terminal block supplied with the FR-A7NC with the CC-Link dedicated cable. After connecting the terminal block to the FR-A7NC, fit the front cover.



REMARKS


- When the CPU has automatic refresh function (example: QnA series CPU)
When the END instruction is executed by the programmable controller CPU, the buffer memory is automatically refreshed to enable communication with a remote device.
- When the CPU does not have automatic refresh function (example: AnA series CPU)
Sequence ladder logic is configured to perform direct communication with the buffer memory of the master station and to enable communication with a remote device.

3.2 Connection of several inverters

An inverter can join the link system as a CC-Link remote device station, and such device stations can be controlled and monitored with a user program of a programmable controller. These devices can be useful components of an automated factory.

For the shield cable of the CC-Link dedicated cable, connect it to "SLD" of each unit and always earth (ground) it via "FG".

Terminals SLD and FG are connected inside the unit.



- *1 Use the terminating resistors supplied with the programmable controller.
- *2 For the unit in the middle, set 1 and 2 of SW2 to OFF (without terminating resistor).
- *3 Perform setting of the terminating resistor selection switch (SW2).

(Refer to page 2 for the position of the switch.)

When connecting a terminating resistor separately, do not use a built-in terminating resistor. (SW2 1-OFF, 2-OFF)

	1	2	Description
	OFF	OFF	Without terminating resistor
	ON	OFF	Do not use.
	OFF	ON	130Ω
	ON	ON	110Ω

130Ω is a resistance value for the CC-Link ver.1.00 dedicated high performance cable.

REMARKS

When performing online exchange


The built-in terminating resistor cannot be exchanged online since the terminating resistor is on the FR-A7NC board and disconnected when the terminal block is removed from the FR-A7NC connector for communication. When changing the FR-A7NC online, connect a terminating resistor supplied with a programmable controller master module to the FR-A7NC after modifying it and do not use the internal terminating resistor (SW2 1-OFF, 2-OFF).

● Connection with the terminating resistor

Connect the terminating resistor between terminals DA-DB of the FR-A7NC at the end.

Modify the terminating resistors supplied with the programmable controller to use.

When a resistor is not supplied with the master module, use a resistor with 110Ω 1/2W available on the market.



- (1) Maximum number of units connected to one master station (CC-Link ver.1.10)
42 units (when connections are inverters only)

If any other units are included, the number of stations occupied depends on the unit and therefore the following conditions must be satisfied:

$$\{(1 \times a) + (2 \times b) + (3 \times c) + (4 \times d)\} \leq 64$$

a: Number of units occupying 1 station c: Number of units occupying 3 stations

b: Number of units occupying 2 stations d: Number of units occupying 4 stations

$$\{(16 \times A) + (54 \times B) + (88 \times C)\} \leq 2304$$

A: Number of remote I/O ≤ 64

B: Number of remote device stations ≤ 42

C: Number of local, standby master and intelligent device stations ≤ 26

- (2) Maximum number of units connected to one master station (CC-Link ver.2.00)
42 units (when connections are inverter only)

If any other units are included, the number of stations occupied depends on the unit and therefore the following conditions must be satisfied:

- $\{(a + a2 + a4 + a8) + (b + b2 + b4 + b8) \times 2 + (c + c2 + c4 + c8) \times 3 + (d + d2 + d4 + d8) \times 4\} \leq 64$
- $\{(a \times 32 + a2 \times 32 + a4 \times 64 + a8 \times 128) + (b \times 64 + b2 \times 96 + b4 \times 192 + b8 \times 384) + (c \times 96 + c2 \times 160 + c4 \times 320 + c8 \times 640) + (d \times 128 + d2 \times 224 + d4 \times 448 + d8 \times 896)\} \leq 8192$
- $\{(a \times 4 + a2 \times 8 + a4 \times 16 + a8 \times 32) + (b \times 8 + b2 \times 16 + b4 \times 32 + b8 \times 64) + (c \times 12 + c2 \times 24 + c4 \times 48 + c8 \times 96) + (d \times 16 + d2 \times 32 + d4 \times 64 + d8 \times 128)\} \leq 2048$

a: Number of single setting devices occupying one station

b: Number of single setting devices occupying two stations

c: Number of single setting devices occupying three stations

d: Number of single setting devices occupying four stations

a2: Number of double setting devices occupying one station

b2: Number of double setting devices occupying two stations

c2: Number of double setting devices occupying three stations

d2: Number of double setting devices occupying four stations

a4: Number of quadruple setting devices occupying one station

b4: Number of quadruple setting devices occupying two stations

c4: Number of quadruple setting devices occupying three stations

d4: Number of quadruple setting devices occupying four stations

a8: Number of octuple setting devices occupying one station

b8: Number of octuple setting devices occupying two stations

c8: Number of octuple setting devices occupying three stations

d8: Number of octuple setting devices occupying four stations

- $16 \times A + 54 \times B + 88 \times C \leq 2304$

A: Numbers of remote I/O ≤ 64

B: Number of remote device stations ≤ 42

C: Number of local and intelligent device stations ≤ 26

3.3 Connection cable

In the CC-Link system, use CC-Link dedicated cables.

If the cable used is other than the CC-Link dedicated cable, the performance of the CC-Link system is not guaranteed.

For the specifications of the CC-Link dedicated cable, refer to the website of the CC-Link Partner Association.

· Website of the CC-Link Partner Association <http://www.cc-link.org/>


3.4 Wiring

- (1) Strip off the sheath of the CC-Link dedicated cable and twist wires to use. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.

Use recommended cables. (*Refer to page 16.*) Recommended tightening torque : 0.22N·m to 0.25N·m

Wire the stripped cable after twisting it to prevent it from becoming loose. (Do not solder it.)

Cable stripping length



Use a blade type terminal as required.

Recommended blade terminal

For wiring of the CC-link communication signal, two CC-Link dedicated cables need to be twisted to wire to one terminal block.


It is recommended to use the following blade terminal and tool.

Recommended products (as of February 2012):
Phoenix Contact Co.,Ltd.

- Blade terminal model: AI-TWIN2 × 0,5-8WH
- Blade terminal crimping tool: CRIMPFOX 6




Note the crimping method.
Hold the long side in a longitudinal direction and insert it into the terminal block.




Connection of the shielding wires of the CC-Link dedicated cable


Twist the shielding wires and wire to the terminal SLD. Use a compression tube and junction terminal block.



Use of a compression tube



Use of a junction terminal block




- (2) Loosen the terminal screw and insert the cable into the terminal.

Screw Size	Tightening Torque	Cable Size	Screwdriver
M2	0.22N·m to 0.25N·m	0.3mm ² to 0.75mm ²	Small ⊖ flat-blade screwdriver (Tip thickness: 0.4mm /tip width: 2.5mm)

CAUTION

- Undertightening can cause cable disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.

- (3) Connect the terminal block to the connector for communication of the communication option.



REMARKS

- If the terminal block of the FR-A7NC is removed, the built-in terminating resistor cannot be used. (Refer to page 13.)

⚠ CAUTION

- ⚠ When wiring, take care not to subject the cable to stress.
- ⚠ After wiring, wire offcuts must not be left in the inverter. They may cause a fault, failure or malfunction.

4 INVERTER SETTING

4.1 Parameter list

The following parameters are used for the plug-in option (FR-A7NC).
Set the values according to need.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page
79	Operation mode selection	0 to 4, 6, 7	1	0	21
313 *1	DO0 output selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 80, 81, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 180, 181, 190, 191, 193, 195, 196, 198, 199, 9999	1	9999	53
314 *1	DO1 output selection				
315 *1	DO2 output selection				
338	Communication operation command source	0, 1	1	0	24
339	Communication speed command source	0, 1, 2	1	0	24
340	Communication startup mode selection	0, 1, 10	1	0	21
342	Communication EEPROM write selection	0, 1	1	0	28
349 *1	Communication reset selection	0, 1	1	0	34
500 *1	Communication error execution waiting time	0 to 999.8s	0.1s	0s	29
501 *1	Communication error occurrence count display	0	1	0	30
502 *2	Stop mode selection at communication error	0 to 3	1	0	31
541 *1	Frequency command sign selection (CC-Link)	0, 1	1	0	38
542 *1, *2, *3	Communication station number (CC-Link)	1 to 64	1	1	36
543 *1, *2, *3	Baud rate selection (CC-Link)	0 to 4	1	0	37
544 *1, *2	CC-Link extended setting	0, 1, 12, 14, 18	1	0	42
550 *2	NET mode operation command source selection	0, 2, 9999	1	9999	24

*1 Parameters which can be displayed when the plug-in option (FR-A7NC) is mounted.

*2 The setting is applied after inverter reset or at the next power-ON.

*3 "L.ERR" LED flickers if the setting is changed. If the inverter is reset, the setting is applied and the LED turns OFF.

4.2 Operation Mode Setting

The inverter mounted with a communication option has three operation modes.

- (1) PU operation [PU]..... Controls the inverter from the keys of the operation panel on the inverter or parameter unit (FR-PU07/FR-PA07).
- (2) External operation [EXT] ... Controls the inverter by switching ON/OFF external signals connected to the control circuit terminals of the inverter.
(The inverter is factory-set to this mode.)
- (3) Network operation [NET] ... Controls the inverter with instructions from the network via the communication option.
(The operation signal and running frequency can be entered from the control circuit terminals depending on the *Pr. 338 Communication operation command source* and *Pr. 339 Communication speed command source* settings.
Refer to page 25.)

4.2.1 Operation mode indicator

Operation panel



Operation mode indicators
(The inverter operates according to the LED lit mode.)
PU: PU operation mode
EXT: External operation mode
NET: Network operation mode

4.2.2 Operation mode switching and communication startup mode (Pr. 79, Pr. 340)

(1) Operation mode switching conditions

Before switching the operation mode, check that:

- 1) The inverter is at a stop;
- 2) Both the STF and STR signals are OFF; and
- 3) The *Pr. 79 Operation mode selection* setting is correct.

(Set using the operation panel of the inverter or parameter unit (FR-PU07/FR-PA07).)

Refer to *the Inverter Manual* for details of *Pr. 79*.

(2) Operation mode selection at power ON and at restoration from instantaneous power failure

The operation mode at power ON and at restoration from instantaneous power failure can be selected.

Set a value other than "0" in *Pr. 340* to select the Network operation mode.

After started in Network operation mode, parameter write from the network is enabled. (Refer to *page 76* for a program example for parameter write.)

REMARKS

- Change of the *Pr. 340* setting is applied valid power ON or an inverter reset.
- *Pr. 340* can be changed with the operation panel in any operation mode.


7 INVERTER SETTING

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power ON or Power Restoration	Operation Mode Switchover
0 (initial value)	0 (initial value)	External operation mode	Switching among the External, PU, and NET operation mode is enabled *1
	1	PU operation mode	PU operation mode fixed
	2	External operation mode	Switching between the external and NET operation mode is enabled Switching to the PU operation mode is disallowed
	3, 4	External/PU combined operation mode	Operation mode switching is disallowed
	6	External operation mode	Switching among the External, PU, and NET operation mode is enabled while running.
	7	X12 (MRS) signal ON External operation mode X12 (MRS) signal OFF ... External operation mode	Switching among the External, PU, and NET operation mode is enabled *1 External operation mode fixed (Forcibly switched to External operation mode.)
1	0	NET operation mode	Same as when Pr: 340 = "0"
	1	PU operation mode	
	2	NET operation mode	
	3, 4	External/PU combined operation mode	
	6	NET operation mode	
	7	X12 (MRS) signal ON NET operation mode X12 (MRS) signal OFF ... External operation mode	
10	0	NET operation mode	Switching between the PU and NET operation mode is enabled *2
	1	PU operation mode	Same as when Pr: 340 = "0"
	2	NET operation mode	NET operation mode fixed
	3, 4	External/PU combined operation mode	Same as when Pr: 340 = "0"
	6	NET operation mode	Switching between the PU and NET operation mode is enabled while running *2
	7	External operation mode	Same as when Pr: 340 = "0"

*1 Operation mode cannot be directly changed between the PU operation mode and Network operation mode.

*2 Operation mode can be changed between the PU operation mode and Network operation mode with  of the operation panel and X65 signal.

(3) Operation mode switching method



For the switching method with the external terminal, refer to *the Inverter Manual*.
 Refer to *page 61* for the switching method through the network.

CAUTION

- When starting the inverter in Network operation mode at power ON or an inverter reset, set a value other than "0" in Pr. 340. (Refer to page 21)
- When setting a value other than "0" in Pr. 340, make sure that the initial settings of the inverter are correct.

4.3 Start and Speed Command Sources (Pr. 338, Pr. 339, Pr. 550)

(1) Select command source for the Network operation mode (Pr. 550)

A control location for the Network operation mode can be selected from either the RS-485 communication with the PU connector or a communication option.

When using a communication option, set "0 or 9999 (initial value)" in Pr. 550.

Parameter Number	Name	Initial Value	Setting Range	Description
550	NET mode operation command source selection	9999	0	The communication option is the command source when NET operation mode.
			2	PU connector is the command source when NET operation mode.
			9999	Automatic communication option recognition Normally, PU connector is the command source. When a communication option is mounted, the communication option is the command source.

Refer to *the inverter manual* for details.

(2) Selection of control source for the Network operation mode (Pr. 338, Pr. 339)

- There are two command types: the start command, which controls the signals related to the inverter start command and function selection, and the speed command, which controls signals related to frequency setting.
- In Network operation mode, the commands from the external terminals and communication (PU connector or communication option) are as listed below.

Operation Location Selection		Pr. 338 Communication operation command source		0: NET			1: External			Remarks	
		Pr. 339 Communication speed command source		0: NET	1: External	2: External	0: NET	1: External	2: External		
Fixed function (terminal-equivalent function)	Running frequency from communication		NET	—	NET	NET	—	NET			
	Terminal 2		—	External	—	—	External	—			
	Terminal 4		—	External		—	External				
Selective function	Pr. 178 to Pr. 184 setting	0	RL	Low-speed operation command/remote setting clear/stop-on contact selection 0	NET	External		NET	External		Pr. 59 = "0" (multi-speed) Pr. 59 = "1, 2" (remote) Pr. 270 = "1" (stop-on-contact)
		1	RM	Middle-speed operation command/remote setting function	NET	External		NET	External		
		2	RH	High-speed operation command/remote setting function	NET	External		NET	External		
		3	RT	Second function selection/stop-on contact selection 1	NET			External			
		4	AU	Terminal 4 input selection	—	Combined		—	Combined		
		5	JOG	Jog operation selection	—			External			

7 INVERTER SETTING

Operation Location Selection		Pr. 338 Communication operation command source		0: NET			1: External			Remarks		
		Pr. 339 Communication speed command source		0: NET	1: External	2: External	0: NET	1: External	2: External			
Selective function	Pr. 178 to Pr. 184 setting	7	OH	External thermal relay input		External						
		8	REX	15-speed selection		NET	External		NET	External		Pr. 59 = "0" (multi-speed)
		10	X10	Inverter run enable signal		External						
		12	X12	PU operation external interlock		External						
		14	X14	PID control valid terminal		NET	External		NET	External		
		15	BRI	Brake opening completion signal		NET			External			
		16	X16	PU-External operation switchover		External						
		18	X18	V/F switchover		NET			External			
		24	MRS	Output stop		Combined			External			Pr. 79 ≠ "7"
				PU operation interlock		External					Pr. 79 = "7" When the X12 signal is not assigned	
25	STOP	Start self-holding selection		—			External					
60	STF	Forward rotation command		NET			External					

Operation Location Selection		Pr. 338 Communication operation command source		0: NET			1: External			Remarks	
		Pr. 339 Communication speed command source		0: NET	1: External	2: External	0: NET	1: External	2: External		
Selective function	Pr. 178 to Pr. 184 setting	61	STR	Reverse rotation command		NET			External		
		62	RES	Inverter reset		External					
		65	X65	PU/NET operation switchover		External					
		66	X66	External/NET operation switchover		External					
		67	X67	Command source switchover		External					

[Explanation of table]

External : Command is valid only from control terminal.

NET : Command only from communication is valid.

Combined : Command from both control terminal and communication is valid.

— : Command from either of control terminal and communication is invalid.

REMARKS

- The command source of communication is as set in Pr. 550 and Pr. 551.
- The Pr. 338 and Pr. 339 settings can be changed while the inverter is running when Pr. 77 = "2". Note that the setting change is applied after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.

4.3.1 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from the communication option, write to RAM is enabled. Set when frequent parameter changes are necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM write selection	0	0	Parameter values written by communication are written to the EEPROM and RAM.
			1	Parameter values written by communication are written to the RAM.

- When changing the parameter values frequently, set "1" in *Pr. 342* to write them to the RAM. Performing frequent parameter write with "0 (initial value)" (EEPROM write) set will shorten the life of the EEPROM.

REMARKS

- When "1" (write to RAM only) is set in *Pr. 342*, powering OFF the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched ON again are the values stored in EEPROM previously.

4.4 Operation at Communication Error Occurrence


4.4.1 Operation selection at communication error occurrence (Pr. 500 to Pr. 502)

You can select operations at communication error occurrences by setting *Pr. 500* to *Pr. 502* under network operation.

(1) Waiting time for the communication option fault output after a communication error

Waiting time for the communication option fault output after a communication line error occurrence can be set.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
500	Communication error execution waiting time	0 to 999.8s	0.1s	0s



When a communication line error occurs and lasts longer than the time set in *Pr. 500*, it is recognized as a communication option fault.


If the communication returns to normal within the time, it is not recognized as a communication option fault, and the operation continues.

(2) Displaying and clearing the communication error count

The cumulative count of communication error occurrences can be displayed.

Write "0" to clear this cumulative count.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
501	Communication error occurrence count display	0	1	0



At the point of communication line error occurrence, *Pr. 501 Communication error occurrence count display* is incremented by 1.

CAUTION

- Communication error count is temporarily stored in the RAM. The error count is stored in EEPROM only once per hour. If power reset or inverter reset is performed, *Pr. 501* setting will be the one that is last stored to EEPROM depending on the reset timing.

(3) Inverter operation at a communication error occurrence

How the inverter operates at a communication line error or an option unit fault can be set.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
502	Stop mode selection at communication error	0, 1, 2, 3	1	0

About setting

● Operation at an error occurrence

Error Definition	Pr. 502 Setting	Operation	Indication	Fault Output
Communication line	0	Continued *	Normal indication *	Not provided *
	1			
	2			
	3			
Communication option itself	0, 3	Coast to stop	E. 1 lit	Provided
	1, 2	Decelerated to stop	E. 1 lit after stop	Provided after stop

* When the communication returns to normal within the time period set in Pr. 500, the communication option fault (E.OP1) does not occur.

● Operation at error recognition after elapse of Pr. 500 time

Error Definition	Pr. 502 Setting	Operation	Indication	Fault Output
Communication line	0	Coast to stop	E.OP1 lit	Provided
	1	Decelerated to stop	E.OP1 lit after stop	Provided after stop
	2			
	3	Continued	Normal indication	Not provided
Communication option itself	0, 3	Coast to stop	E. 1 lit	Provided
	1, 2	Decelerated to stop	E. 1 lit after stop	Provided after stop

● Operation at error removal

Error Definition	Pr. 502 Setting	Operation	Indication	Fault Output
Communication line	0	Kept stopped	E.OP1 kept lit	Kept provided
	1			
	2	Restart	Normal indication	Not provided
	3	Continued		
Communication option itself	0, 3	Kept stopped	E. 1 kept lit	Kept provided
	1, 2			

CAUTION

- Communication line error [E.OP1 (fault data: HA1)] is an error that occurs on the communication line. Communication option itself error [E. 1 (fault data: HF1)] is an error that occurs in the communication circuit inside the option.
- Fault output indicates the fault signal (ALM signal) output and fault bit output.
- When the fault output setting is active, fault records are stored in the faults history. When the fault output setting is not active, fault record is overwritten to the faults history temporarily but not stored. After the fault is removed, the fault indication is reset, changing the display back to normal, and the last fault is displayed in the faults history.
- When the Pr. 502 setting is "1" or "2", the deceleration time is the normal deceleration time setting (e.g. Pr. 8, Pr. 44, Pr. 45).
- The acceleration time at a restart is the normal acceleration time setting (e.g. Pr. 7, Pr. 44).
- When the Pr. 502 setting is "2", the operation/speed command at a restart is the one given before the fault occurrence.
- When a communication line error occurs at the Pr. 502 setting of "2", removing the error during deceleration causes acceleration to restart at that point. (Acceleration is not restarted if the error is that of the option unit itself.)

4.4.2 Fault and measures

(1) The inverter operates as follows at error occurrences.

Error Location	Status		Operation Mode		
			Network Operation	External Operation	PU Operation
Inverter	Inverter operation		Inverter trip	Inverter trip	Inverter trip
	Data communication		Continued	Continued	Continued
Communication line	Inverter operation		Inverter trip *	Continued	Continued
	Data communication		Stop	Stop	Stop
Communication option	Poor contact	Inverter operation	Inverter trip *	Inverter trip *	Inverter trip *
		Data communication	Continued	Continued	Continued
	Error of communication option itself	Inverter operation	Inverter trip *	Continued	Continued
		Data communication	Stop	Stop	Stop

* Depends on the *Pr. 502* setting.

(2) Measures at fault occurrences

Fault Indication	Fault Definition	Measures
E.OP1	Communication option fault	Check the LED status of the option unit and remove the cause of the fault. (Refer to <i>page 83</i> for LED indication status) Inspect the master.
E.1	Option fault	Check the connection between the inverter and option unit for poor contact, etc. and remove the cause of the fault.

When faults other than the above are displayed, refer to *the inverter manual* and remove the cause of the fault.

4.5 Inverter Reset

(Refer to *page 80* for an inverter reset program example.)

(1) Operation conditions of inverter reset

Which resetting method is allowed or not allowed in each operation mode is described below.

Resetting Method			Operation Mode		
			Network Operation	External Operation	PU Operation
Reset via network	Inverter reset (<i>Refer to page 64</i>) *1		Enabled	Disabled	Disabled
	Error reset (RY1A) at inverter fault (<i>Refer to page 52</i>) *2	<i>Pr.349 = 0</i>	Enabled	Enabled	Enabled
		<i>Pr.349 = 1</i>		Disabled	Disabled
Turn ON the inverter RES signal (terminal RES)			Enabled	Enabled	Enabled
Switch OFF inverter power			Enabled	Enabled	Enabled
Reset from the PU/operation panel	Inverter reset		Enabled	Enabled	Enabled
	Reset at inverter fault		Enabled	Enabled	Enabled

*1 Inverter reset can be made any time.

*2 Reset can be made only when the protective function of the inverter is activated.

CAUTION

- When a communication line error has occurred, reset cannot be made from the network.
- The inverter is set to the External operation mode if it has been reset in Network operation mode in the initial status.
To resume the network operation, the inverter must be switched to the Network operation mode again.
Set a value other than "0" in *Pr. 340* to start in Network operation mode. (*Refer to page 21.*)
- Communication continues during inverter reset. (The inverter cannot be controlled for about 1s after release of a reset command.)

(2) Fault reset operation selection at inverter fault

When used with the communication option, a fault reset command* via network can be invalid in the External operation mode or PU operation mode.

Parameter Number	Name	Initial Value	Setting Range	Function
349	Communication reset selection	0	0	Fault reset* is enabled independently of operation mode
			1	Fault reset* is enabled only in the Network operation mode

* RY1A (Refer to page 52)

4.6 CC-Link function setting

4.6.1 Station number setting (Pr. 542)


Use Pr. 542 Communication station number (CC-Link) to set station number of the inverter. Set this parameter within the range of 1 to 64.

Parameter Number	Name	Initial Value	Setting Range
542	Communication station number (CC-Link)	1	1 to 64

CAUTION

- Use different station numbers for different devices. (If different devices have the same station number, the communication cannot be performed properly.)

Connection example



REMARKS

- Set consecutive numbers for the station numbers. (Do not skip a number in sequence like "station number 1 - station number 2 - station number 4".)
- The station number does not have to match with the physical connection sequence. (There is no problem with having the physical connection sequence like "station number 1 - station number 3 - station number 4 - station number 2".)
- One inverter occupies one station. (One remote device station)
- "L.ERR" LED flickers if the setting is changed. When power is switched ON again or the RES signal is turned ON, the setting value is applied and the LED turns OFF.

4.6.2 Baud rate setting (Pr. 543)

Set the transmission speed. (Refer to the manual for the CC-Link master module for details of transmission speed.)

Parameter Number	Name	Initial Value	Setting Range	Transmission Speed
543	Baud rate selection (CC-Link)	0	0	156kbps
			1	625kbps
			2	2.5Mbps
			3	5Mbps
			4	10Mbps

REMARKS

- "L.ERR" LED flickers if the setting is changed. When power is switched ON again or the RES signal is turned ON, the setting value is applied and the LED turns OFF.

4.6.3 Frequency command with sign (Pr. 541)

By frequency command with sign, the start command (forward rotation/reverse rotation) can do inverted operation.

Make a selection of the sign for the frequency command from RWw1.

Parameter Numbers	Name	Initial Value	Setting Range
541	Frequency command sign selection (CC-Link)	0	0, 1

Pr.541 Setting	Sign	Setting Range	Actual Frequency Command
0	Not used	0 to 40000	0 to 400.00Hz
1	With	-32768 to 32767 (two's complement)	-327.68 to 327.67Hz

Relationship between the start command and sign (Pr.541 = "1")

Start Command	Sign of the Frequency Command	Actual Run Command
Forward rotation	+	Forward rotation
	-	Reverse rotation
Reverse rotation	+	Reverse rotation
	-	Forward rotation

REMARKS


- When Pr.541 = 1(with sign)
 - When EEPROM write is specified with the RYE, write mode error (error code H01) will occur.
 - When concurrent execution of both RYD and RYE is enabled (when a value other than 0 is set in Pr.544) and both RYD and RYE are turned ON, RYD has precedence.
 - When power is turned ON (inverter reset), the initial setting status of the sign bit is "positive" and the set frequency is "0Hz". (The motor does not run at the frequency set before turning OFF the power (inverter reset).)
 - When set frequency is written with the instruction code of HED and HEE, the sign of the frequency command is not changed.

5 FUNCTION OVERVIEW

5.1 Function block diagram

Using function blocks, this section explains I/O data transfer to/from an inverter in CC-Link:

- Link refresh is continuously executed between the master station and inverter in the CC-Link system at intervals of 1.1ms to 141ms (per station).



- 1) These are I/O signals assigned to the CC-Link system master/local module. These signals are used for communication between the programmable controller CPU and CC-Link system master/local module. Refer to *page 51* for details of the signal.
- 2) Reading of data input to the inverter, writing of inverter output data, and reading of a faulty CC-Link station are available. Automatic refresh function enables reading from/writing to buffer memory. (Use FROM/TO command of the sequence program to synchronize without using the automatic refresh function.) Refer to CC-Link system master/local module manual for the buffer memory details.
- 3) CC-Link communication start command is given from the sequence program. After the CC-Link communication starts, link refresh is always performed asynchronously (or synchronously) with execution of sequence program.
For details, refer to the CC-Link system master/local module manual.

5.2 Output from the inverter to the network

Main items which can be output from the inverter to the master and their descriptions are explained below.

Item	Description	Refer to Page
Inverter status monitor	The output terminal status of the inverter can be monitored.	53
Output frequency monitor	The output frequency can be monitored.	58, 61
Output current monitor	The output current can be monitored.	61
Output voltage monitor	The output voltage can be monitored.	61
Special monitor	The monitor data selected can be checked.	61
Faults history	Fault records can be checked.	59, 62
Data at fault occurrence	The inverter status at fault occurrence can be checked.	59
Operation mode	The current operation mode can be checked.	61
Parameter read	Parameter settings can be read.	63
Read of set frequency	The current set frequency can be read.	62

REMARKS

- Refer to the inverter manual for functions controllable from the network in each operation mode.



5.3 Input to the inverter from the network

Main items which can be commanded from the master to the inverter and their descriptions are explained below.

Item	Description	Refer to Page
Forward rotation command	Give the forward rotation command.	51
Reverse rotation command	Give the reverse rotation command.	51
Input terminal function command	Execute functions assigned to the inverter input terminals.	51
Inverter output stop command	Stop the inverter output.	51
Error reset	Reset the inverter only when an inverter fault occurs.	52
Frequency setting	Set the frequency.	55, 62
Monitor command	Specify the description monitored.	55, 61
Operation mode specification	Set the operation mode.	61
Faults history clear	Erase past eight fault records.	63
All parameter clear	Return the parameter descriptions to the initial value.	63
Inverter reset	Reset the inverter.	64
Parameter write	Write parameter settings.	63
PID control	PID set point, PID measured value and PID deviation can be input from the network.	57

REMARKS

- Refer to the inverter manual for functions controllable from the network in each operation mode.

6 I/O SIGNAL LIST

6.1 CC-Link extended setting (Pr. 544)

Remote register function can be extended.

Parameter Number	Name	Initial Value	Setting Range	CC-Link Ver.	Description	Refer to page
544	CC-Link extended setting	0	0	1	Occupies one station (FR-E500 series compatible) *1	43
			1		Occupies one station	46
			12 *2	2	Occupies one station double	47
			14 *2		Occupies one station quadruple	48
			18 *2		Occupies one station octuple	49

- *1 The program used for conventional series inverter (FR-E500 series) can be used.
When RYD, RYE, and RYF turn ON simultaneously, only one of them is executed.
The upper 8 bits of RWw2 are not link parameter extended setting.
- *2 When using double, quadruple and octuple settings of the CC-Link ver.2, station data of the master station must be set to double, quadruple and octuple also.
(If the master station is CC-Link ver.1 compatible station, the above setting cannot be made.)

REMARKS

- The setting change is reflected after an inverter reset. (Refer to *page 34* for inverter reset.)

6.2 I/O signal list

6.2.1 I/O signal when CC-Link ver.1 one station (FR-E500 series compatible) is occupied (Pr. 544 = 0)

(1) Remote I/O (32 points)

Device No.	Signal	Refer to Page	Device No.	Signal	Refer to Page
RYn0	Forward rotation command	51	RXn0	Forward running	53
RYn1	Reverse rotation command	51	RXn1	Reverse running	53
RYn2	High-speed operation command (terminal RH function) *1	51	RXn2	Running (terminal RUN function) *3	53
RYn3	Middle-speed operation command (terminal RM function) *1	51	RXn3	Up to frequency (SU signal)	53
RYn4	Low-speed operation command (terminal RL function) *1	51	RXn4	Overload alarm (OL signal)	53
RYn5	Not used	—	RXn5	Not used	—
RYn6	Second function selection (RT signal) *2	51	RXn6	Frequency detection (terminal FU function) *3	53
RYn7	Terminal 4 input selection (AU signal) *2	51	RXn7	Error (terminal ABC function) *3	53
RYn8	Not used	—	RXn8	Not used	—
RYn9	Output stop (MRS signal) *1	51	RXn9	Pr. 313 assignment function (DO0) *4	53
RYnA	Not used	—	RXnA	Pr. 314 assignment function (DO1) *4	53
RYnB	Reset (terminal RES function) *1	51	RXnB	Pr. 315 assignment function (DO2) *4	53
RYnC	Monitor command	52	RXnC	Monitoring	53
RYnD	Frequency setting command (RAM)	52	RXnD	Frequency setting completion (RAM)	54
RYnE	Frequency setting command (RAM, EEPROM)	52	RXnE	Frequency setting completion (RAM, EEPROM)	54
RYnF	Instruction code execution request	52	RXnF	Instruction code execution completion	54

Device No.	Signal	Refer to Page	Device No.	Signal	Refer to Page
RY(n+1)0 to RY(n+1)7	Reserved	—	RX(n+1)0 to RX(n+1)7	Reserved	—
RY(n+1)8	Not used (initial data process completion flag)	—	RX(n+1)8	Not used (initial data process request flag)	—
RY(n+1)9	Not used (initial data process request flag)	—	RX(n+1)9	Not used (initial data process completion flag)	—
RY(n+1)A	Error reset request flag	52	RX(n+1)A	Error status flag	54
RY(n+1)B to RY(n+1)F	Reserved	—	RX(n+1)B	Remote station ready	54
			RX(n+1)C to RX(n+1)F	Reserved	—

("n" indicates a value determined according to the station number setting.)

- *1 These signals are set in the initial status. Using *Pr. 180 to Pr. 184*, you can change input signal functions. Signals of the RYn0 and RYn1 cannot be changed. Even when changed using *Pr. 178 and Pr. 179*, the settings are invalid.
Refer to *the inverter manual* for details of *Pr. 178 to Pr. 184*.
- *2 Signals of the RY6 and RY7 cannot be changed.
- *3 These signals are set in the initial status. Using *Pr. 190 to Pr. 192*, you can change output signal functions. Refer to *the inverter manual* for signals which can be assigned.
- *4 Output signal can be assigned using *Pr. 313 to Pr. 315*.
Refer to *the inverter manual* for signals which can be assigned.

(2) Remote register

Address	Description		Refer to Page	Address	Description	Refer to Page
	Upper 8 Bits	Lower 8 Bits				
RWwn	Monitor code 2	Monitor code 1	55	RWrn	First monitor value	58
RWwn+1	Set frequency (0.01Hz increments) *2		55	RWrn+1	Second monitor value	58
RWwn+2	H00 (arbitrary) *1	Instruction code	56	RWrn+2	Reply code	58
RWwn+3	Write data		56	RWrn+3	Read data	58

("n" indicates a value determined according to the station number setting.)

*1 The above 8 bit is always H00 even if a value other than H00 is set.

*2 When *Pr: 37* is not equal to "0", this will be machine speed display (1 increments).

6.2.2 I/O signal when CC-Link ver.1 one station is occupied (Pr. 544 = "1")

(1) Remote I/O (32 points)

Same as when Pr. 544 = "0" (Refer to page 43)

(2) Remote register

Address	Description		Refer to Page	Address	Description		Refer to Page
	Upper 8 Bits	Lower 8 Bits			Upper 8 Bits	Lower 8 Bits	
RWwn	Monitor code 2	Monitor code 1	55	RWrn	First monitor value		58
RWwn+1	Set frequency (0.01Hz increments) *		55	RWrn+1	Second monitor value		58
RWwn+2	Link parameter extended setting	Instruction code	56	RWrn+2	Reply code 2	Reply code 1	58
RWwn+3	Write data		56	RWrn+3	Read data		58

("n" indicates a value determined according to the station number setting.)

* When Pr. 37 is not equal to "0", this will be machine speed display (1 increments).

6.2.3 I/O signal when CC-Link ver.2 double setting is selected (Pr. 544 = "12")

(1) Remote I/O (32 points)

Same as when Pr. 544 = "0" (Refer to page 43)

(2) Remote register

Address	Description		Refer to Page	Address	Description		Refer to Page
	Upper 8 Bits	Lower 8 Bits			Upper 8 Bits	Lower 8 Bits	
RWwn	Monitor code 2	Monitor code 1	55	RWrn	First monitor value		58
RWwn+1	Set frequency (0.01Hz increments) *		55	RWrn+1	Second monitor value		58
RWwn+2	Link parameter extended setting	Instruction code	56	RWrn+2	Reply code 2	Reply code 1	58
RWwn+3	Write data		56	RWrn+3	Read data		58
RWwn+4	Monitor code 3		56	RWrn+4	Third monitor value		59
RWwn+5	Monitor code 4		56	RWrn+5	Fourth monitor value		59
RWwn+6	Monitor code 5		56	RWrn+6	Fifth monitor value		59
RWwn+7	Monitor code 6		56	RWrn+7	Sixth monitor value		59

("n" indicates a value determined according to the station number setting.)

* When Pr. 37 is not equal to "0", this will be machine speed display (1 increments).

6.2.4 I/O signal when CC-Link ver.2 quadruple setting is selected (Pr. 544 = "14")

(1) Remote I/O (32 points)

Same as when Pr. 544 = "0" (Refer to page 43)

(2) Remote register

Address	Description		Refer to Page	Address	Description		Refer to Page
	Upper 8 Bits	Lower 8 Bits			Upper 8 Bits	Lower 8 Bits	
RWwn	Monitor code 2	Monitor code 1	55	RWrn	First monitor value		58
RWwn+1	Set frequency (0.01Hz increments)*2		55	RWrn+1	Second monitor value		58
RWwn+2	Link parameter extended setting	Instruction code	56	RWrn+2	Reply code 2	Reply code 1	58
RWwn+3	Write data		56	RWrn+3	Read data		58
RWwn+4	Monitor code 3		56	RWrn+4	Third monitor value		59
RWwn+5	Monitor code 4		56	RWrn+5	Fourth monitor value		59
RWwn+6	Monitor code 5		56	RWrn+6	Fifth monitor value		59
RWwn+7	Monitor code 6		56	RWrn+7	Sixth monitor value		59
RWwn+8	Faults history No.	H00	56	RWrn+8	Faults history No.	Fault data	59
RWwn+9	PID set point (0.01% increments) *1		57	RWrn+9	Fault record (output frequency)		59
RWwn+A	PID measured value (0.01% increments) *1		57	RWrn+A	Fault record (output current)		59
RWwn+B	PID deviation (0.01% increments) *1		57	RWrn+B	Fault record (output voltage)		59
RWwn+C	H00 (Free)		—	RWrn+C	Fault record (energization time)		59
RWwn+D				RWrn+D	H00 (Free)		—
RWwn+E				RWrn+E			
RWwn+F				RWrn+F			

("n" indicates a value determined according to the station number setting.)

*1 When Pr. 128 = "50, 51, 60, 61", they are valid.

*2 When Pr. 37 is not equal to "0", this will be machine speed display (1 increments).

6.2.5 I/O signal when CC-Link ver.2 octuple setting is selected (Pr. 544 = "18")

(1) Remote I/O (32 points)

Same as when Pr. 544 = "0" (Refer to page 43)

(2) Remote register

Address	Description		Refer to Page	Address	Description		Refer to Page
	Upper 8 Bits	Lower 8 Bits			Upper 8 Bits	Lower 8 Bits	
RWwn	Monitor code 2	Monitor code 1	55	RWrn	First monitor value		58
RWwn+1	Set frequency (0.01Hz increments) *1		55	RWrn+1	Second monitor value		58
RWwn+2	Link parameter extended setting	Instruction code	56	RWrn+2	Reply code 2	Reply code 1	58
RWwn+3	Write data		56	RWrn+3	Read data		58
RWwn+4	Monitor code 3		56	RWrn+4	Third monitor value		59
RWwn+5	Monitor code 4		56	RWrn+5	Fourth monitor value		59
RWwn+6	Monitor code 5		56	RWrn+6	Fifth monitor value		59
RWwn+7	Monitor code 6		56	RWrn+7	Sixth monitor value		59
RWwn+8	Faults history No.	H00	56	RWrn+8	Faults history No.	Fault data	59
RWwn+9	PID set point (0.01% increments) *1		57	RWrn+9	Fault record (output frequency)		59
RWwn+A	PID measured value (0.01% increments) *1		57	RWrn+A	Fault record (output current)		59
RWwn+B	PID deviation (0.01% increments) *1		57	RWrn+B	Fault record (output voltage)		59
RWwn+C	H00 (Free)		—	RWrn+C	Fault record (energization time)		59
RWwn+D				H00 (Free)		—	
RWwn+E							
RWwn+F							
RWwn+10				Link parameter extended setting	Instruction code	57	RWrn+10

*1 When Pr. 128 = "50, 51, 60, 61", they are valid.

*2 When Pr. 37 is not equal to "0", this will be machine speed display (1 increments).

Address	Description		Refer to Page	Address	Description		Refer to Page
	Upper 8 Bits	Lower 8 Bits			Upper 8 Bits	Lower 8 Bits	
RWwn+11	Write data		57	RWrn+11	Read data		59
RWwn+12	Link parameter extended setting	Instruction code	57	RWrn+12	Reply code		59
RWwn+13	Write data		57	RWrn+13	Read data		59
RWwn+14	Link parameter extended setting	Instruction code	57	RWrn+14	Reply code		59
RWwn+15	Write data		57	RWrn+15	Read data		59
RWwn+16	Link parameter extended setting	Instruction code	57	RWrn+16	Reply code		59
RWwn+17	Write data		57	RWrn+17	Read data		59
RWwn+18	Link parameter extended setting	Instruction code	57	RWrn+18	Reply code		59
RWwn+19	Write data		57	RWrn+19	Read data		59
RWwn+1A	H00 (Free)		—	RWrn+1A	H00 (Free)		—
RWwn+1B							
RWwn+1C							
RWwn+1D							
RWwn+1E							
RWwn+1F							

("n" indicates a value determined according to the station number setting.)

7 DETAILS OF INPUT AND OUTPUT SIGNALS

The following device No. are those for station 1.

For stations 2 and later, the device No. are different. (Refer to the master module manual for correspondence between the device No. and station number)

7.1 Details of remote input and output signals

7.1.1 Output signals (master module to inverter (FR-A7NC))

The output signals from the master module are indicated. (Input signals to inverter)

Device No.	Signal	Description	
RY0	Forward rotation command *2	0 : Stop command 1 : Forward rotation start	When "1" is set, a start command is input to the inverter.
RY1	Reverse rotation command *2	0 : Stop command 1 : Reverse rotation start	When "1" is set in RY0 and RY1, a stop command is input.
RY2	High-speed operation command (terminal RH function) *1	Functions assigned to terminals RH, RM and RL are activated.	
RY3	Middle-speed operation command (terminal RM function) *1		
RY4	Low-speed operation command (terminal RL function) *1		
RY6	Second function selection (RT signal) *3	1 : Second function is selected	
RY7	Terminal 4 input selection (AU signal) *3	1 : Terminal 4 input is the main speed setting	
RY9	Output stop (MRS signal)*1	Function assigned to <i>Pr.183</i> is activated.	
RYB	Reset (terminal RES function) *1	Function assigned to terminal RES is activated.	

*1 Signal names are initial values. Using *Pr. 180* to *Pr. 184*, you can change input signal functions. Note that some of signals do not accept a command from the network according to the *Pr. 338* and *Pr. 339* settings. For example, reset (terminal RES function) of RYB cannot be controlled by the network. (Refer to page 24.)

Refer to *the inverter manual* for details of *Pr. 180* to *Pr.184*.

*2 Signals of the RY0 and RY1 cannot be changed. Even when changed using *Pr. 178* and *Pr. 179* the settings are invalid. Refer to *the inverter manual* for details of *Pr. 178* and *Pr.179*.

*3 Signals of the RY6 and RY7 cannot be changed.

7 DETAILS OF INPUT AND OUTPUT SIGNALS

Device No.	Signal	Description
RYC	Monitor command	When "1" is set in the monitor command (RYC), the monitored value is set in the remote register RWr0, 1, 4 to 7, and "1" is set in the monitoring (RXC). While "1" is set in the monitor command (RYC), the monitored data is always updated.
RYD *5	Frequency setting command (RAM)	When "1" is set in the frequency setting command (RYD), the set frequency (RWw1) is written to RAM of the inverter. *4 After the writing completes, "1" is set in the frequency setting completion (RXD).
RYE *5	Frequency setting command (RAM, EEPROM)	When "1" is set in the frequency setting command (RYE), the set frequency (RWw1) is written to RAM and EEPROM of the inverter. After the writing completes, "1" is set in the frequency setting completion (RXE). To change the frequency consecutively, be sure to write data to the inverter RAM.
RYF *5	Instruction code execution request	When "1" is set in the instruction code execution request (RYF), processes corresponding to the instruction codes set to RWw2, 10, 12, 14, 16 and 18 are executed. "1" is set in the instruction code execution request (RXF) after completion of instruction codes. When an instruction code execution error occurs, a value other than "0" is set in the reply code (RWr2, 10, 12, 14, 16, 18).
RY1A	Error reset request flag	When "1" is set in the error reset request flag (RY1A) at an inverter fault, the inverter is reset, then "0" is set in the error status flag (RX1A). *6

*4 While "1" is set in the frequency setting command (RYD), the set frequency (RWw1) is always applied.

*5 If "1" is set in these registers at the same time while Pr. 544 = "0," only one of these is executed.

*6 Refer to *page 34* for operation conditions of inverter reset.



7.1.2 Input signals (inverter (FR-A7NC) to master module)

The input signals to the master module are indicated. (Output signals from inverter)

Device No.	Signal	Description
RX0	Forward running	0 : Other than forward running (during stop or reverse rotation) 1 : Forward running
RX1	Reverse running	0 : Other than reverse running (during stop or forward rotation) 1 : Reverse running
RX2	Running (terminal RUN function) *1	Functions assigned to terminals RUN are activated. Refer to <i>the inverter manual</i> for signals which can be assigned.
RX3	Up to frequency (SU signal) *2	1 : Output frequency has reached the set frequency
RX4	Overload alarm (OL signal) *2	1 : Overload alarm occurrence
RX6	Frequency detection (terminal FU function) *1	Functions assigned to terminals FU and ABC activate. Refer to <i>the inverter manual</i> for signals which can be assigned.
RX7	Fault (terminal ABC function) *1	
RX9	— (DO0 function) *3	
RXA	— (DO1 function) *3	Functions assigned to Pr. 313 to Pr. 315 are activated. Refer to <i>the inverter manual</i> for signals which can be assigned.
RXB	— (DO2 function) *3	
RXC	Monitoring	After "1" is set in the monitor command (RYC), and the monitored value is set in the remote register Rwr0, 1, 4 to 7, "1" is set in this signal. When "0" is set in the monitor command (RYC), "0" is set in this signal.

*1 Signal names are initial values. Using Pr. 190 to Pr. 192, you can change output signal functions.

Refer to *the inverter manual* for details of Pr. 190 to Pr. 192.

*2 Signals of the RX3 and RX4 cannot be changed.

*3 Signals are not assigned in the initial setting.

Refer to Pr. 190 to Pr. 192 of *the inverter manual* for details of signals.

7 DETAILS OF INPUT AND OUTPUT SIGNALS

Device No.	Signal	Description
RXD	Frequency setting completion (RAM)	After "1" is set in the frequency setting command/torque command (RYD) and the frequency setting command/torque command is written to the inverter RAM, "1" is set in this signal. When "0" is set in the frequency setting command/torque command (RYD), "0" is set in this signal.
RXE	Frequency setting completion (RAM, EEPROM)	After "1" is set in the frequency setting command/torque command (RYE) and the frequency setting command/torque command is written to the inverter RAM and EEPROM, "1" is set in this signal. When "0" is set in the frequency setting command/torque command (RYE), "0" is set in this signal.
RXF	Instruction code execution completion	After "1" is set in the instruction code execution request (RYF) and the processes corresponding to the instruction codes (RWw2, 10, 12, 14, 16 and 18) are executed, "1" is set in this signal. When "0" is set in the instruction code execution request (RYF), "0" is set in this signal.
RX1A	Error status flag	When an inverter error occurs (protective function is activated), "1" is set in this signal.
RX1B	Remote station ready	When the inverter goes into the ready status upon completion of initial setting after power-ON or hardware reset, "1" is set in this signal. When an inverter error occurs (protective function is activated), "0" is set in this signal. The signal is used as an interlock signal during the write to/read from the master module.



7.2 Details of remote register

7.2.1 Remote register (master module to inverter (FR-A7NC))

●Remote register definition

Device No.	Signal	Description
RWw0	Monitor code1/ Monitor code2	Set the monitor code to be monitored. By setting "1" in RYC after setting, the specified monitored data is stored in RWr0/RWr1. Refer to <i>page 66</i> for monitor code details.
RWw1	Set frequency *1, *2	<ul style="list-style-type: none"> · Specify the set frequency or machine speed. At this time, whether to write to RAM or EEPROM is decided with the RYD and RYE settings. After setting the set frequency in this register, set "1" in RYD or RYE to write the frequency. After writing of frequency is completed, "1" is set in RXD or RXE in response to the input command. · The setting range is 0 to 400.00Hz (0.01Hz increments). Write "40000" when setting 400.00Hz.

*1 When *Pr. 37* is not equal to "0", this will be machine speed display (1 increments).

*2 When *Pr.541 Frequency command sign selection (CC-Link)* = "1", the setting value has either + or -. When the setting value is negative, the command is inversed from starting command.

Setting range: -327.68Hz to 327.67Hz (-327.68 to 327.67) 0.01Hz increments.

For details refer to *page 38*.

7 DETAILS OF INPUT AND OUTPUT SIGNALS

Device No.	Signal	Description
RWw2	Link parameter extended setting/ Instruction code	Set the instruction code for execution of operation mode rewrite, parameter read/write, error reference, error clear, etc. (Refer to page 61) Set "1" in RYF to execute the corresponding instruction after completing the register setting. "1" is set in RXF after completing the execution of the instruction. When a value other than "0" is set in <i>Pr. 544 CC-Link extended setting</i> , upper eight bits are link parameter extended setting. Example) When reading <i>Pr. 160</i> , instruction code is H0200.
RWw3	Write data	Set the data specified by the RWw2 instruction code. (When required) Set "1" in RYF after setting RWw2 and this register. Set zero when the write code is not required.
RWw4	Monitor code 3 *3	Set the monitor code to be monitored. By setting "1" in RYC after setting, the specified monitored data is stored in RWr□. (□ indicates a register number. (RWr4 to 7)) Refer to <i>page 66</i> for monitor code details.
RWw5	Monitor code 4 *3	
RWw6	Monitor code 5 *3	
RWw7	Monitor code 6 *3	
RWw8	Faults history No.	Set how many fault records in the past to be read. Up to eight past fault records can be read. Upper digits: H00 (the latest fault) to H07 (8th oldest fault) / lower digits: H00 When any of H08 to HFF is set to the upper digits, the fault record becomes an undetermined value.

*3 Write data is hexadecimal and only lower two digits are valid. (Upper 2 digits are ignored.)



Device No.	Signal	Description	
RWw9	PID set point *4	Set the PID set point Setting range : "0 to 100.00%"	· Input a value 100 times greater than the value to be set For example, input "10000" when setting 100.00%. · Refer to <i>the inverter manual</i> for details of PID control.
RWwA	PID measured value *4	Set the PID measured value Setting range : "0 to 100.00%"	
RWwB	PID deviation *4	Set the PID deviation. Setting range : "-100.00% to 100.00%"	
RWw10, RWw12, RWw14, RWw16, RWw18	Link parameter extended setting/ Instruction code	Set the instruction code (<i>refer to page 61</i>) for execution of operation mode rewrite, parameter read/write, error reference, error clear, etc. The instructions are executed in the following order by setting "1" in RYF after completing the register setting: RWw2, 10, 12, 14, 16, then 18. After completing the execution up to RWw18, "1" is set in RXF. Set HFFFF to disable an instruction by RWw10 to 18. (RWw2 is always executed.) The first 8 bits are link parameter extended setting. Example) When reading <i>Pr. 160</i> , instruction code is H0200.	
RWw11, RWw13, RWw15, RWw17, RWw19	Write data	Set the data specified by the instruction code of RWw10, 12, 14, 16, and 18. (when required) RWw10 and 11, 12 and 13, 14 and 15, 16 and 17, and 18 and 19 correspond each other. Set "1" in RYF after setting the instruction codes (RWw10, 12, 14, 16, and 18) and the corresponding register. Set "0" when the write code is not required.	

*4 When *Pr. 128* = "50, 51, 60, 61", they are valid. If the data outside the range is set, the previous setting is retained. Refer to *the inverter manual* for details of *Pr.128*.

7.2.2 Remote register (inverter (FR-A7NC) to master module)

(1) Remote register definition

Device No.	Signal	Description
RWr0	First monitor value	When "1" is set in RYC, the specified monitored data is set to the lower 8 bits of the monitor code (RWW0). When Pr. 37 Speed display \neq 0 and output frequency or set frequency monitor is set for monitor code (RWW0), machine speed setting (1 unit) is monitored.
RWr1	Second monitor value (Output frequency)	When "0" is set to the upper 8 bits of the monitor code (RWW0), the current output frequency is always set. When a value other than "0" is set to the upper 8 bits of the monitor code (RWW0) while "1" is set in RYC, the monitor data specified by the upper 8 bits of the monitor code (RWW0) is set. When Pr. 37 Speed display \neq 0 and output frequency or set frequency monitor is set for monitor code (RWW0), machine speed setting (1 unit) is monitored.
RWr2	Reply code (when Pr. 544 = 0)	When "1" is set in RYD or RYE, the reply code for the frequency setting command is set. When "1" is set in RYF, the reply code corresponding to the instruction code RWW2 is set. The value "0" is set for a normal reply and any digit other than "0" is set for data fault, mode error, etc. (reply code  refer to page 60)
	Reply code 1 (when Pr. 544 \neq 0)	Lower 8 bits of RWr2 When "1" is set in RYD or RYE, the reply code for the frequency setting command is set. (reply code 1  refer to page 60)
	Reply code 2 (when Pr. 544 \neq 0)	Upper 8 bits of RWr2 When "1" is set in RYF, the reply code corresponding to the instruction code RWW2 is set. (reply code 2  refer to page 60)
RWr3	Read data	For a normal reply, the reply data to the instruction specified by the instruction code is set.



Device No.	Signal	Description
RWr4	Third monitor value	When "1" is set in RYC, the monitored data specified by the monitor code (RWw□) is saved. (□ indicates a register number (RWw4 to 7)) When <i>Pr. 37 Speed display</i> ≠ 0 and output frequency or set frequency monitor is set for monitor code (RWw0), machine speed setting (1 unit) is monitored.
RWr5	Fourth monitor value	
RWr6	Fifth monitor value	
RWr7	Sixth monitor value	
RWr8	Fault record (fault data)	The fault data of faults history No. specified by RWw8 is stored in the lower 8 bits. Upper 8 bits of RWw8 will be reverted back to the upper 8 bits.
RWr9	Fault record (output frequency)	Output frequency of the faults history No. specified in RWw8 is stored.
RWrA	Fault record (output current)	Output current of the faults history No. specified in RWw8 is stored.
RWrB	Fault record (output voltage)	Output voltage of the faults history No. specified in RWw8 is stored.
RWrC	Fault record (energization time)	Energization time of the faults history No. specified in RWw8 is stored.
RWr10 to RWr19	Reply code	When "1" is set in RYF, the reply codes corresponding to the instruction code RWw10, 12, 14, 16, and 18 are set. The value "0" is set for a normal reply and other than "0" is set for data fault, mode error, etc. <i>(reply code ☞ refer to page 60)</i>
	Read data	For a normal reply, the reply data to the instruction specified by the instruction code is set.

(2) Reply code definition

The reply to the instruction execution is set to RWr2, 10, 12, 14, 16, 18.

When executing the frequency setting (RYD, RYE) or instruction code execution (RYF), check the reply code (RWr2) in the remote register after execution.

	Data	Item	Alarm Definition	Remarks
Reply code	H0000	Normal	No error (normal completion of instruction code execution)	<ul style="list-style-type: none"> · Reply code to Rwr2 when Pr. 544 = "0" · Reply code to RWwr10, 12, 14, 16, and 18 when Pr. 544 = "18"
	H0001	Write mode error	Parameter write was attempted during operation other than a stop in the Network operation mode.	
	H0002	Parameter selection error	Unregistered code number was set.	
	H0003	Setting range error	Set data is outside the permissible data range.	
Reply code 1	H00	Normal	No error (normal completion of instruction code execution)	Reply code to RWwr2 when Pr. 544 ≠ "0"
	H01	Write mode error	Parameter write was attempted during operation other than a stop in the Network operation mode.	
	H03	Frequency command setting range error	Frequency outside the range is set	
Reply code 2	H00	Normal	No error (normal completion of instruction code execution)	
	H01	Write mode error	Parameter write was attempted during operation other than a stop in the Network operation mode.	
	H02	Parameter selection error	Unregistered code number was set.	
	H03	Setting range error	Set data is outside the permissible data range.	



7.2.3 Instruction codes

(1) Instruction code definition

Set the instruction code using a remote register (RWw) (Refer to page 55.)


The definition read by the instruction code is stored in the remote register (RWr). (Refer to page 58.)

Item		Read/ Write	Code Number	Description
Operation mode		Read	H007B	H0000: Network operation mode H0001: External operation mode, External JOG operation mode H0002: PU operation mode, External/PU combined operation mode 1 and 2, PUJOG operation mode
		Write	H00FB	H0000: Network operation mode H0001: External operation mode H0002: PU operation mode (Pr. 79 = "6")
Monitor	Output frequency *1	Read	H006F	H0000 to HFFFF: Running frequency0.01Hz increments Machine speed..... 1 increments (When Pr. 37 ≠ "0")
	Output current	Read	H0070	H0000 to HFFFF: Output current (hexadecimal) Increments 0.01A
	Output voltage	Read	H0071	H0000 to HFFFF: Output voltage (hexadecimal) Increments 0.1V
	Special monitor	Read	H0072	H0000 to HFFFF: Check the data of the monitor selected by the instruction code H00F3.
	Special monitor selection No.	Read	H0073	H01 to H3F: Monitor selection data
Write		H00F3 *2	Refer to monitor code. (Refer to page 66.)	

*1 When "100" is set in Pr. 52 DU/PU main display data selection, set frequency is monitored during a stop and output frequency is monitored during running.

*2 Write data is hexadecimal and only lower two digits are valid. (Upper 2 digits are ignored.)

7 DETAILS OF INPUT AND OUTPUT SIGNALS

Item		Read/Write	Code Number	Description
Monitor	Faults history	Read	H0074 to H0077	H0000 to HFFFF: Last two fault records 
Set frequency (RAM)		Read	H006D	Read set frequency or machine speed from RAM or EEPROM. · H0000 to HFFFF: Set frequency...0.01Hz increments Machine speed .. 1 increments (When Pr. 37 ≠ "0")
Set frequency (EEPROM)			H006E	
Set frequency (RAM) *3		Write	H00ED	Write set frequency or machine speed to RAM or EEPROM. · H0000 to H9C40 (0 to 400.00Hz) : Frequency.....0.01Hz increments · H0000 to H270E (0 to 9998) : " Machine speed .. 1 increments (When Pr. 37 ≠ "0") · To change the set frequency consecutively, write data to the inverter RAM. (Instruction code: HED)
Set frequency (RAM and EEPROM) *3		Write	H00EE	

*3 Setting from remote registers can be made.

Item	Read/ Write	Code Number	Description													
Parameter	Read	H0000 to H0063	<ul style="list-style-type: none"> · Refer to the instruction code in the parameter list in the inverter manual to read and write as required. Write to <i>Pr. 77</i> and <i>Pr. 79</i> is disabled. When setting <i>Pr.100</i> and later, set link parameter extended setting. Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999". · When changing the parameter values frequently, set "1" in <i>Pr. 342</i> to write them to the RAM. (<i>Refer to page 28.</i>) 													
	Write	H0080 to H00E3														
Faults history batch clear	Write	H00F4	H9696: Clears the faults history in batch.													
All parameter clear	Write	H00FC	<p>All parameters return to the initial values. Whether to clear communication parameters or not can be selected according to data. (○: Clear, ×: Not clear) <i>Refer to the inverter manual</i> for parameter clear, all clear, and communication parameters.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Clear Type</th> <th style="text-align: center;">Data</th> <th style="text-align: center;">Communication Pr.</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">Parameter clear</td> <td style="text-align: center;">H9696</td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">H5A5A</td> <td style="text-align: center;">× *4</td> </tr> <tr> <td rowspan="2" style="text-align: center;">All parameter clear</td> <td style="text-align: center;">H9966</td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">H55AA</td> <td style="text-align: center;">× *4</td> </tr> </tbody> </table> <p>When clear is executed for H9696 or H9966, communication-related parameter settings also return to the initial values. When resuming operation, set the parameters again. Executing clear will clear the instruction code H00EC, H00F3, and H00FF settings.</p>	Clear Type	Data	Communication Pr.	Parameter clear	H9696	○	H5A5A	× *4	All parameter clear	H9966	○	H55AA	× *4
			Clear Type	Data	Communication Pr.											
Parameter clear	H9696	○														
	H5A5A	× *4														
All parameter clear	H9966	○														
	H55AA	× *4														

*4 Turning OFF the power supply while clearing parameters with H5A5A or H55AA also clears the communication parameter settings back to the initial settings.

7 DETAILS OF INPUT AND OUTPUT SIGNALS

Item	Read/ Write	Code Number	Description
Inverter reset	Write	H00FD	H9696: Resets the inverter.
Link parameter extended setting *5	Read	H007F	H0000 to H0009: Parameter description is changed according to the instruction code (extended) setting. Refer to <i>the inverter manual</i> for instruction code (extended) settings.
	Write	H00FF	
Second parameter changing *6	Read	H006C	When setting the bias/gain (instruction codes H5E to H61, HDE to HE1) parameters H00: Frequency *7 H01: Analog value set in parameters H02: Analog value input from the terminal
	Write	H00EC	

*5 Setting is valid only when *Pr. 544* = "0". When *Pr. 544* ≠ "0", set using *RWw2* or *RWw10, 12, 14, 16, or 18*. (Refer to page 56)

*6 Setting can be made when the link parameter extended setting = "1, 9".

*7 Gain frequencies can be written using *Pr. 125* (instruction code H99) and *Pr. 126* (instruction code H9A) also.



(2) Fault data


Refer to the inverter manual for details of fault definitions.

Data	Definition
H00	No fault
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT
H31	E.THM
H40	E.FIN
H52	E.ILF
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
HA0	E.OPT
HA1	E.OP1

Data	Definition
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HB3	E.PE2
HC0	E.CPU
HC5	E.IOH
HC7	E.AIE
HC8	E.USB
HC9	E.SAF
HD8	E.MB4
HD9	E.MB5
HDA	E.MB6
HDB	E.MB7
HF1	E.1
HF5	E.5
HF6	E.6
HF7	E.7
HFD	E.13

Fault record display example
(instruction code H74)

For read data H30A1



Last fault E.THT
 Current fault E.OP1

7.2.4 Monitor codes

Monitored items can be selected with the special monitor selection No. of the instruction code and the remote registers, RWw0 and RWw4 to 7.

Divide the monitor code (RWw0) into half to select the first monitor description (RWr0) from the lower 8 bits and the second monitor description (RWr1) from the upper 8 bits.

REMARKS

- When Pr. 544 = "12, 14, 18" descriptions of monitor code 3 (RWw4) to 6 (RWw7) can be selected.

(Example) When output current is selected for the first monitor and output voltage is selected for the second monitor → monitor code is H0302


Code Number	Second Monitor Description (the first 8 bits)	First, Third to Sixth Monitor Description (the last 8 bits)	Increments
H00	Output frequency/machine speed *1, *4	No monitoring (monitor value is 0)	0.01Hz/1
H01	Output frequency/machine speed *1, *4		0.01Hz/1
H02	Output current *4		0.01A
H03	Output voltage *4		0.1V
H05	Frequency setting value/machine speed setting *1		0.01Hz/1
H07	Motor torque		0.1%
H08	Converter output voltage		0.1V
H09	Regenerative brake duty		0.1%
H0A	Electronic thermal relay function load factor		0.1%
H0B	Output current peak value		0.01A
H0C	Converter output voltage peak value		0.1V
H0E	Output power		0.01kW
H0F	Input terminal status *2		—




Code Number	Second Monitor Description (the first 8 bits)	First, Third to Sixth Monitor Description (the last 8 bits)	Increments
H10		Output terminal status *3	—
H14		Cumulative energization time	1h
H17		Actual operation time	1h
H18		Motor load factor	0.1%
H19		Cumulative power	1kWh
H34		PID set point	0.1%
H35		PID measured value	0.1%
H36		PID deviation	0.1%
H3D		Motor thermal load factor	0.1%
H3E		Inverter thermal load factor	0.1%
H3F		Cumulative power 2	0.01kWh

*1 When Pr. 37 is not equal to "0", this will be machine speed display (1 increments).

*2 Input terminal monitor details (ON: 1, OFF: 0, — : undetermined value)



*3 Output terminal monitor details (ON: 1, OFF: 0, — : undetermined value)



*4 The monitored values are retained even if an inverter fault occurs. Resetting will clear the retained values.


8 PROGRAMMING EXAMPLES

This chapter provides programming examples which control the inverter with sequence programs.

Item	Program Example	Refer to Page
Reading the inverter status	Reading the inverter status from the buffer memory of the master station	71
Setting the operation mode	Selecting the Network operation mode	72
Setting the operation commands	Commanding the forward rotation and middle speed signals	73
Setting the monitoring function	Monitoring the output frequency	74
Reading a parameter value	Reading the value of <i>Pr. 7 Acceleration time</i>	75
Writing a parameter value	Setting "3.0 s" in <i>Pr. 7 Acceleration time</i>	76
Setting the running frequency (running speed)	Setting to 50.00Hz	77
Reading the fault records	Reading the inverter faults	79
Inverter reset	Perform inverter reset at a fault occurrence.	80

(1) System configuration for programming example

Programmable controller




- (2) Network parameter setting of the master station
 Network parameters are set as below.


Item		Setting Conditions
Start I/O No.		0000
Operation settings	Data link alarm station setting	Input clear
	Setting at CPU stop	Refresh
Type		Master
Mode		Remote net ver.1 mode
All connect count		2
Remote input (RX)		X1000
Remote output (RY)		Y1000
Remote register (RWr)		W0

Item		Setting Conditions
Remote register (RWw)		W100
Special relay (SB)		SB0
Special register (SW)		SW0
Retry count		3
Automatic reconnection station count		1
CPU down select		Stop
Scan mode settings		Asynchronous
Station information	Station type	Remote device station

- (3) The relation between the device of the programmable controller CPU and remote I/O (RX, RY) of the remote device station is as follows:
The devices used actually are indicated in shaded regions.





- (4) The relation between the device of the programmable controller CPU and remote register (RWw, RWr) of the remote device station is as follows:
The devices used actually are indicated in shaded regions.



8.1 Program example for reading the inverter status

The following program turns ON Y00 of the output unit when station 1 inverter is running




8.2 Program example for setting the operation mode

The following explains a program to write various data to the inverter.


The following explains a program to change the operation mode of station 1 inverter to network operation.

- Operation mode writing code number: HFB (hexadecimal)
- Network operation set data: H0000 (hexadecimal) (*Refer to page 61*)
- The reply code at the time of instruction code execution is set to D2. (*Refer to page 60*)



8.3 Program example for setting the operation commands

The following program gives a forward command and middle speed command to station 1 inverter



Y100F	b15	b7	b0	Y1000									
	0	0	0	0	0	0	0	0	0	1	0	0	1
	[Run command]												
											1 : ON		
											0 : OFF		

Run command	b6 : Second function selection (RT signal)
b0 : Forward rotation command	b7 : Terminal 4 input selection (AU signal)
b1 : Reverse rotation command	b8 : —
b2 : High-speed operation command (terminal RH function) *1	b9 : Output stop (MRS signal) *1
b3 : Middle-speed operation command (terminal RM function) *1	b10 : —
b4 : Low-speed operation command (terminal RL function) *1	b11 : Inverter reset (terminal RES function) *1
b5 : —	

*1 These signals are initial values. You can change input signals using Pr. 180 to Pr. 184 (input terminal function selection).
Note that some of the signals do not receive a command from the programmable controller depending on the setting. (Refer to page 24.)

8.4 Program example for monitoring the output frequency


The following explains a program to read monitor functions of the inverter.

The following program reads the output frequency of station 1 inverter to D1.

Output frequency reading code number: H0001 (hexadecimal)

Refer to *page 66* for the monitor code numbers.


(Example) The output frequency of 60Hz is indicated as H1770 (6000).



8.5 Program example for parameter reading

The following program reads *Pr. 7 Acceleration time* of station 1 inverter to D1.

- *Pr. 7 Acceleration time* reading code number: H07 (hexadecimal)
- Refer to the inverter manual for details of the parameter codes .
- The reply code at the time of instruction code execution is set to D2. (*Refer to page 60*)



REMARKS

- For parameters having numbers 100 and later, change their link parameter extended settings (set them to other than H0000). Refer to *the inverter manual* for details.


8.6 Program example for parameter writing

The following program changes the setting of *Pr.7 Acceleration time* of station 1 inverter to 3.0s.

- Acceleration time writing code number: H87 (hexadecimal)
- Acceleration time set data: K30 (decimal)

For the parameter code numbers, refer to the inverter manual.

The reply code at the time of instruction code execution is set to D2. (*Refer to page 60*)




REMARKS

- For parameters having numbers 100 and later, change their link parameter extended settings (set them to other than H0000). Refer to the parameter list of *the inverter manual* for settings.
- For other functions, refer to the instruction codes (*page 61*).

8.7 Program example for setting the running frequency

- 1) The following program example changes the running frequency of station 1 inverter to 50.00Hz
 Set frequency: K5000 decimal
 The reply code at the time of instruction code execution is set to D2. (Refer to page 60)



2) To continuously change the running frequency from the programmable controller

When the frequency (speed) setting completion (example: X100D) switches ON, make sure that the reply code in the remote register is 0000H and change the set data (example: W101) continuously.


3) Program example for writing data to EEPROM

Modify the program on *page 77* as follows:


Frequency setting command Y100D → Y100E

Frequency setting completion X100D → X100E

<Timing chart when writing to RAM>



<Timing chart when writing to EEPROM>



Reflect to the inverter when Y100E turns ON

*1 For EEPROM, write is made only once when Y100E is switched ON.

*2 If the set data is changed with Y100E ON, it is not applied on the inverter.


8.8 Program example for fault record reading

The following program reads fault records of station 1 inverter to D1.

· Faults history No. 1, No. 2 reading code number: H74 (hexadecimal)


For the error code numbers, refer to *page 65*.

The reply code at the time of instruction code execution is set to D2. (*Refer to page 60*)



8.9 Program example for resetting the inverter at inverter error

The following is a program example for resetting station 1 inverter at inverter error.



REMARKS

- The above inverter reset using RY1A is available only when an inverter error occurs.
When *Pr. 349 Communication reset selection* = "0", inverter reset is available independently of the operation mode.
- When using the instruction code execution request (RYF) with the instruction code (HFD) and data (H9696) to reset the inverter, set a value other than "0" in *Pr. 340 Communication startup mode selection* (refer to page 21) or change the operation mode to the Network operation mode. (For the program example, refer to page 72)
- Refer to *page 34* for operation conditions of inverter reset.

8.10 Instructions


(1) Programming instructions

1) Since the buffer memory data of the master station is kept transferred (refreshed) to/from the inverters, the TO instruction need not be executed every scan in response to data write or read requests.

The execution of the TO instruction every scan does not pose any problem.

2) If the FROM/TO instruction is executed frequently, data may not be written reliably.

When transferring data between the inverter and sequence program via the buffer memory, perform the handshake to confirm that data has been written without error.



(2) Operating and handling instructions

1) Command only from the programmable controller can be accepted during operation from CC-Link communication.

The run command from external and parameter unit is ignored.

2) If the station number set to different inverters is not the same, normal communication cannot be made.

3) The inverter is brought to a fault "E.OP1" if data communication stops for more than the time set in *Pr. 500 Communication error execution waiting time* due to a programmable controller fault, an open CC-Link dedicated cable etc. during CC-Link operation.

4) If the programmable controller (master station) is reset during CC-Link operation or if the programmable controller is powered off, data communication stops and the inverter is brought to a fault "E.OP1".

To reset the programmable controller (master station), switch the operation mode to the External operation once, then reset the programmable controller.

5) When *Pr. 340* = "0 (initial value)", any inverter whose main power is restored is reset to return to the External operation mode. To resume the network operation, therefore, set the operation mode to the network operation using the programmable controller program.

Set a value other than "0" in *Pr. 340* to start in the Network operation mode after inverter reset.

(Refer to page 21)

(3) Troubleshooting

1) Operation mode does not switch to the Network operation mode

- Check that the option unit (FR-A7NC) and CC-Link dedicated cables are fitted properly. (Check for contact fault, break in the cable, etc.)
- Check that *Pr. 542 Communication station number (CC-Link)* setting switches are set to the correct positions. (Check that the station number matches the program, the station numbers are not repeated, and the station number is not outside the range.)
- Check that the inverter is in the External operation mode.
- Check that the operation mode switching program is running.
- Check that the operation mode switching program has been written correctly.


2) Inverter does not start in the Network operation mode

- Check that the inverter starting program has been written correctly.
- Check that the inverter starting program is running.
- Check that *Pr.338 Communication operation command source* is not set to external. *(Refer to page 24)*


9 HOW TO CHECK FOR ERROR USING THE LEDS

9.1 When one inverter is connected

The following diagram shows the system configuration with one inverter. The diagram indicates how the cause of the fault can be checked with the LED status of the inverter communication option (FR-A7NC). (In this example, assume SW, M/S, and PRM LEDs of the master module are OFF (master module is in normal operation).)



Operation status indication LED




7 HOW TO CHECK FOR ERROR USING THE LEDS

LED Status					Cause
RUN	L.RUN	SD	RD	L.ERR	
●	●	◎	◎	◎	Normal communication is made but CRC error has occurred due to noise.
●	●	◎	◎	○	Normal communication
●	●	◎	○	◎	Hardware fault
●	●	◎	○	○	Hardware fault
●	●	○	◎	◎	Cannot answer due to CRC error of receive data.
●	●	○	◎	○	Data sent to the host station does not reach destination.
●	●	○	○	◎	Hardware fault
●	●	○	○	○	Hardware fault
●	○	◎	◎	◎	Polling response is made but refresh receive is in CRC error.
●	○	◎	◎	○	Hardware fault
●	○	◎	○	◎	Hardware fault
●	○	◎	○	○	Hardware fault
●	○	○	◎	◎	Data sent to the host station is in CRC error.
●	○	○	◎	○	There is no data sent to the host station, or data sent to the host station cannot be received due to noise.
●	○	○	○	◎	Hardware fault
●	○	○	○	○	Cannot receive data due to break in the cable, etc.
●	○	○	◎○	●	Invalid baud rate or station number setting
●	●	◎	◎	◎	Baud rate or station number changed during operation.
○	○	○	○	○	Baud rate or station number changed during operation.
◎	—	—	—	—	Master station is connected to CC-Link ver. 1 and FR-A7NC is connected to CC-Link ver. 2.

●: ON, ○: OFF, ◎: Flicker

9.2 When two or more inverters are connected

The following system configuration shows how the cause of a fault can be checked with the LED status of the inverter communication option (FR-A7NC) and countermeasures for the fault.
 (In this example, assume SW, M/S, and PRM LEDs of the master module are OFF (master module is in normal operation).)



LED Status				Cause	Corrective Action
Master Module	Inverters (FR-A7NC)				
	Station 1	Station 2	Station 3		
TIME LINE or TIME LINE	RUN ●	RUN ●	RUN ●	Normal	—
	L.RUN ●	L.RUN ●	L.RUN ●		
○	SD ●	SD ●	SD ●	Poor contact of the FR-A7NC with the inverter	Plug the FR-A7NC securely. Check the connector.
	RD ●	RD ●	RD ●		
●	L.ERR ○	L.ERR ○	L.ERR ○		
	RUN ○	RUN ●	RUN ●		
○	L.RUN ○	L.RUN ●	L.RUN ●		
	SD ○	SD ●	SD ●		
	RD ○	RD ●	RD ●		
	L.ERR ○	L.ERR ○	L.ERR ○		

●: ON, ○: OFF, ◎: Flicker, *: Any of ON, flicker or OFF

7 HOW TO CHECK FOR ERROR USING THE LEDS

LED Status				Cause	Corrective Action
Master Module	Inverters (FR-A7NC)				
	Station 1	Station 2	Station 3		
	RUN ● L.RUN ● SD ● RD ● L.ERR ○	RUN ● L.RUN ○ SD * RD * L.ERR ○	RUN ● L.RUN ○ SD * RD * L.ERR ○	Since the L.RUN LEDs of the FR-A7NC on station 2 and later are OFF, the transmission cable between the remote I/O units A and B is open or disconnected from the terminal block.	Referring to the LED "ON" condition, search for an open point and repair.
TIME ○ LINE ○ or TIME ● LINE ○	RUN ● L.RUN ○ SD * RD * L.ERR ○	RUN ● L.RUN ○ SD * RD * L.ERR ○	RUN ● L.RUN ○ SD * RD * L.ERR ○	The transmission cable is shorted.	Among the three wires of the transmission cable, search for the shorted wire and repair.
	RUN ● L.RUN ○ SD * RD * L.ERR *	RUN ● L.RUN ○ SD * RD * L.ERR *	RUN ● L.RUN ○ SD * RD * L.ERR *	The transmission cable is wired improperly.	Check the wiring on the inverter terminal block and correct the improper wiring point.

●: ON, ○: OFF, ◎: Flicker, *: Any of ON, flicker or OFF

9.3 Communication stops during operation

- Check that the option unit (FR-A7NC) and CC-Link dedicated cables are fitted properly. (Check for contact fault, break in the cable, etc.)
- Check that the programmable controller program is executed properly.
- Check that data communication has not stopped due to an instantaneous power failure, etc.

LED States				Cause	Corrective Action	
Master Module	Inverters (FR-A7NC)					
	Station 1	Station 2	Station 3			
TIME LINE or TIME LINE	○	●	●	●	Since the L.RUN LEDs of the FR-A7NC on station 1 and the FR-A7NC on station 3 are OFF, the station numbers of the inverters set as stations 1 and 3 are the same.	After correcting the repeated station numbers of the inverters using <i>Pr. 542 Communication station number (CC-Link)</i> , switch power ON again.
	○	○	○	○		
	●	○	○	○		
○	○	○	○	○	Since the L.RUN and SD LEDs of the FR-A7NC on station 2 are OFF, the transmission speed setting of the FR-A7NC on station 2 is wrong within the setting range (0 to 4).	After correcting the transmission speed setting using <i>Pr. 543 Baud rate selection (CC-Link)</i> , switch power on again.
○	○	○	○	○	Since the L.ERR LED of the FR-A7NC on station 3 flickers, the setting switch of the FR-A7NC on station 3 was moved during normal operation.	After returning the setting switch of the FR-A7NC to the original position using <i>Pr. 542 Communication station number (CC-Link)</i> or <i>Pr. 543 Baud rate selection (CC-Link)</i> power ON the inverter again.

●: ON, ○: OFF, ◎: Flicker, *: Any of ON, flicker or OFF

7 HOW TO CHECK FOR ERROR USING THE LEDS

LED States				Cause	Corrective Action
Master Module	Inverters (FR-A7NC)				
	Station 1	Station 2	Station 3		
	RUN ● L.RUN ● SD ● RD ● L.ERR ○	RUN ● L.RUN ● SD ● RD ● L.ERR ●	RUN ● L.RUN ● SD ● RD ● L.ERR ○	Since the L.ERR LED of the FR-A7NC on station 2 is ON, the FR-A7NC itself on station 2 is affected by noise. (L.RUN may go OFF.)	Securely connect FG of each inverter and master module to ground.
TIME LINE or TIME LINE	● ● ○ ●	● ● ● ●	● ● ● ●	Since the L.ERR LEDs of the FR-A7NC on station 2 and later are ON, the transmission cable between the inverters of stations 2 and 3 is affected by noise. (L.RUN may go OFF.)	Check that the transmission cable is connected to SLD. Also run it as far away as possible from the power lines. (100mm or more)
	RUN ● L.RUN ● SD ● RD ● L.ERR ○	RUN ● L.RUN ● SD ● RD ● L.ERR ○	RUN ● L.RUN ● SD ● RD ● L.ERR ●	Terminating resistor is not selected. (L.RUN may go OFF.)	Check that the setting of the terminating resistor selection switch is correct. (refer to page 13)

●: ON, ○: OFF, ◎: Flicker, *: Any of ON, flicker or OFF

MEMO

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision	
Aug. 2011	IB(NA)-0600469ENG-A	First edition	
Aug. 2012	IB(NA)-0600469ENG-B	<table border="1"><tr><td>Modification</td></tr></table> <ul style="list-style-type: none">•Remote register RWw8, RWr8	Modification
Modification			

INVERTER

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

IB(NA)-0600469ENG-B(1208) MEE

Printed in Japan

Specifications subject to change without notice.