






6.4.2 出力信号  
DO1A ~ DO3A, DO1B ~ DO3BおよびDO4NAをソース出力、DO4PBをシンク出力として使用することができます。



注 1. すべての外部配線は、CN10A、CN10Bの二系統に分離してください。I/O電源 (DC 24 V、0 V共通) の結線についても、CN10A、CN10Bの形で通り結線を行わず、別な結線を行ってください。  
2. 各出力デバイスは、次の表で示した組合せのコネクタピンに割り付けられています。各デバイスについては、第7章を参照してください。

出力用コネクタピンの組合せ
DO1A (CN10A-8)/DO1B (CN10B-8)
DO2A (CN10A-17)/DO2B (CN10B-17)
DO3A (CN10A-9)/DO3B (CN10B-9)
DO4NA (CN10A-18)/DO4PB (CN10B-18)

3. インタフェース用にDC 24 V ± 10%の電源を外部から供給してください。全入出力点数を使用した場合、合計0.8 Aの電流容量が必要です。入出力点数を減らすことにより電流容量を下げることができます。7.2節記載のインタフェースに必要な電流を参照してください。便宜上、入出力番号と出力信号用のDC 24 V電源を分けて記載していますが、1線で使用します。  
4. DO4PA (CN10A-16)、DO4NA (CN10A-18)、DO4PB (CN10B-16)、DO4NB (CN10B-18) は、2014年9月前生産のMR-D30では使用できません。これらのピンには何も接続しないでください。

第7章 信号

7.1 コネクタおよびピンサイン  
(1) 入力デバイス  
DI1 ~ DI6に [Pr. PSD02] 入力デバイス選択DI1] ~ [Pr. PSD07 入力デバイス選択DI6] でデバイスを割り付けてください。ネットワークによる安全監視機能制御の場合、ネットワーク経由で入力することができます。

デバイス	略称	コネクタピン番号	機能	機能が有効になる入力ピンの状態
STO指令	STOC	CN10A-4	STO指令によりSTO機能が作動します。	閉接
SS1指令	SS1C	CN10A-5	SS1指令によりSS1機能が作動します。	閉接
SS2指令	SS2C	CN10A-6	SS2指令によりSS2/SOS機能が作動します。	閉接
SLS1指令	SLS1C	CN10A-13 CN10A-14 CN10A-15	SLS1指令により、SLS機能1が作動します。パラメータとして、[Pr. PSA07 SLS減速監視時間1] および [Pr. PSA11 SLS速度1] を使用します。	閉接
SLS2指令	SLS2C	CN10B-4 CN10B-5 CN10B-6	SLS2指令により、SLS機能2が作動します。パラメータとして、[Pr. PSA08 SLS減速監視時間2] および [Pr. PSA12 SLS速度2] を使用します。	閉接
SLS3指令	SLS3C	CN10B-13 CN10B-14 CN10B-15	SLS3指令により、SLS機能3が作動します。パラメータとして、[Pr. PSA09 SLS減速監視時間3] および [Pr. PSA13 SLS速度3] を使用します。	閉接
SLS4指令	SLS4C	CN10B-16	SLS4指令により、SLS機能4が作動します。パラメータとして、[Pr. PSA10 SLS減速監視時間4] および [Pr. PSA14 SLS速度4] を使用します。	閉接
テストハルス出力A	PLSA	CN10A-12	外部配線診断用のテストハルスを出します。	
テストハルス出力B	PLSB	CN10B-12	外部配線診断用のテストハルスを出します。	

(2) 出力デバイス  
安全監視機能の状態モニタ (SM) はDO1 ~ DO4で出力します。DO1 ~ DO4に [Pr. PSD08 出力デバイス選択DO1] ~ [Pr. PSD11 出力デバイス選択DO4] で出力デバイスを割り付けることができます。ネットワークによる安全監視機能制御の場合、ネットワーク経由で出力することもできます。その場合、DO1 ~ DO4も同時に使用することができます。

デバイス	略称	コネクタピン番号	機能	作動時の出力ピンの状態
SSM出力	SSMS	CN10A-8 CN10A-9	SLS機能による速度監視が作動中、サーボモータ速度がSLS速度以下であることを示します。	導通
SBC出力	SBCS	CN10A-17	電圧ブレーキの報知信号を出力します。	閉接
STO出力	STOS	CN10A-18	STO機能が作動していることを示すモニタ出力信号です。	閉接
SOS出力	SOSs	CN10B-8	SS2/SOS機能が作動していることを示すモニタ出力信号です。	閉接
SS1出力	SS1s	CN10B-9 CN10B-17	SS1機能が作動していることを示すモニタ出力信号です。	閉接
SS2出力	SS2s	CN10B-16	SS2/SOS機能によりサーボモータが停止状態であることが監視されていることを示すモニタ出力信号です。	閉接
SLS1出力	SLS1s	CN10B-13	SLS機能1が作動していることを示すモニタ出力信号です。	閉接
SLS2出力	SLS2s	CN10B-14	SLS機能2が作動していることを示すモニタ出力信号です。	閉接
SLS3出力	SLS3s	CN10B-15	SLS機能3が作動していることを示すモニタ出力信号です。	閉接
SLS4出力	SLS4s	CN10B-16	SLS機能4が作動していることを示すモニタ出力信号です。	閉接


(3) 電源

名称	略称	コネクタピン番号	機能と用途
デジタル入力/出力用コモンA	DICOMA	CN10A-2 CN10A-11	入力信号用のコモン端子です。入出力インタフェース用DC 24 V (DC 24 V ± 10% 0.8 A) を入力してください。電流容量は使用する入出力インタフェースの点数により変わります。
デジタル出力/出力用コモンA	DO24VA	CN10A-1 CN10A-10	外部配線診断用のテストハルスを出するための電源を入力してください。DC 24 V外部電源の+を接続してください。
デジタル出力/出力用コモンB	DO24VB	CN10A-7	出力信号用のコモン端子です。
デジタル出力/出力用DO4A電圧	DO4PA	CN10A-16	DO4A出力信号の電源端子です。DC 24 V 外部電源の+を接続してください。
デジタル入力/出力用コモンB	DICOMB	CN10B-2 CN10B-11	入力信号用のコモン端子です。入出力インタフェース用DC 24 V (DC 24 V ± 10% 0.8 A) を入力してください。電流容量は使用する入出力インタフェースの点数により変わります。
テストハルス用電圧入力B	DC24VB	CN10B-1 CN10B-10	外部配線診断用のテストハルスを出するための電源を入力してください。DC 24 V外部電源の+を接続してください。
デジタル出力/出力用コモンB	DO24VB	CN10B-7	出力信号用のコモン端子です。
デジタル出力/出力用DO4B電圧	DO4NB	CN10B-18	DO4B出力信号の電源端子です。DC 24 V 外部電源の+を接続してください。


7.2 インタフェース (ソース入出力の場合)  
MR-D30では、入出力インタフェースにソースタイプおよびシンクタイプを使用することができます。例として、ソースインタフェースについて示します。シンクインタフェースについては、「MR-D30技術資料集」を参照してください。

(1) 入力インタフェース  
フォトプラのアンロード側が入力端子になっている入力回路です。ソース (オープンコレクタ) タイプのトランジスタ出力、リレースイッチなどから信号を与えてください。

(a) 外部機器の接続  
外部機器の出力信号を、DI<sub>n</sub>に接続してください。



(2) 出力インタフェース  
出力トランジスタがオンになったときに出力端子から負荷に電流が流れるタイプです。ランプ、リレーまたはフォトプラをドライブできます。誘導負荷の場合にはダイオード (D) を、ランプ負荷には突入電流抑制用抵抗 (R) を設置してください。(定格電流: 5 mA ~ 40 mA, 最大電流: 50 mA, 突入電流: 100 mA以下) MR-D30内部で2.4 Vの電圧降下があります。



7.3 CN10AおよびCN10B用コネクタの配線方法  
結線時の工具の取扱いは注意してください。

(1) ワイヤストリップ  
(a) 適合電線サイズAWG 24 ~ 16 (推奨電線UL 1007) の電線を使用し、電線のストリップ長は10 mm ± 0.5 mmに加工してください。使用に際しては必ずゲージなどでストリップ長を確認したあとに使用してください。  
(b) ストリップした電線に曲がり、バラケ、断り太りがある場合は軽く直り直すなどの修正を行い、ストリップ長を確認したあとに使用してください。また、過度の変形がある場合は使用しないでください。  
(c) 電線切断面および絶縁体のストリップ面は平滑に加工してください。

(2) 電線の結線方法  
結線作業を行う際は、必ずヘッドコネクタから、リセアセンブリを引き抜いた状態で作業してください。コネクタ嵌合状態で作業した場合、コネクタや基板を破損する危険があります。  
先端幅2.0 mm、厚さ2.5 mmのマイナスドライバで開放ボタンを押し状態で電線を奥まで挿入し、ドライバを外してください。結線方法については、「MR-D30技術資料集」を参照してください。

(3) コネクタの装着  
コネクタは最後まで挿入されるとパチンといった音や感覚 (クリック感) がありますので、必ず最後までまっすぐに挿入してください。装着後、マイナスドライバでコネクタ付属のねじを締め付けてください。引抜きに際しては、ねじを緩めてから引き抜いてください。

第8章 表示部  
MR-D30には、4個のLED表示が実装されています。次の表に表示内容を示します。

LED	点灯状態	内容
POWER	点灯	電源が供給されている。
RUN	点灯	電源が供給されていない。
RUN	点灯	安全監視機能が作動している。STO機能、SS1機能、SS2/SOS機能、SLS機能のいずれかが作動し、正常に運転または停止が行われている。
RUN	消灯	安全監視機能が作動していない。安全監視機能の作動指令が入力されていないか、内部診断異常などにより安全監視機能が作動していない。
STO	点灯	STO機能が作動している。サーボモータへのエネルギー供給が遮断されている。
STO	消灯	STO機能が作動していない。サーボモータへのエネルギー供給は遮断されていない。
ERROR	点灯	MR-D30で何らかの異常を検知している。[注]
ERROR	点滅	MR-D30で何らかの異常を検知している。
ERROR	消灯	MR-D30で異常は検知されていない。

注 MR-D30に対応していないサーボポンプにMR-D30を取り付ける。"ERROR" が点灯します。ソフトウェアバージョンB3以降のMR-J4、B-RJサーボポンプまたはソフトウェアバージョンB5以降のMR-J4-RJサーボポンプに装着していることを確認してください。(2.3.4項 (3) (a) 参照)

各状態における表示例を次の表に示します。

POWER	RUN	STO	ERROR	サーボポンプ表示	状態	内容
●	●	●	●	通常表示	電源オフ	電源が供給されていない状態です。
○	●	○	●	95_またはAb	診断中	入力デバイスによる安全監視機能制御の場合、起動時間着断を実施してください。ネットワークによる安全監視機能制御の場合、ネットワークを接続してください。
○	○	●	●	通常表示	安全監視機能停止中	安全監視機能が作動していない状態です。
○	○	○	●	95_	安全監視機能作動中 (遮断中)	STO機能、SS1機能が作動している状態です。
○	○	○	●	通常表示	安全監視機能作動中 (監視中)	SLS機能、SS2/SOS機能が作動している状態です。
○	●/○	○	◎/○	アラーム番号	異常発生	異常を検知した状態です。第8章を参照して異常の内容を確認してください。[注]
○	○	○	○	アラーム番号	異常発生 (ウォッチドグ)	CPUなどの部品の異常によりウォッチドグになっている状態です。


(○: 点灯 ●: 点滅 ◎: 消灯)  
注 MR-D30に対応していないサーボポンプにMR-D30を取り付けると "ERROR" が点灯します。MR-D30に対応しているサーボポンプのソフトウェアバージョンについては、2.3.4項 (3) (a) を参照してください。

第9章 設定方法  
MR Configurator2を使用して設定してください。詳細については「MR-D30技術資料集」を参照してください。  
[Pr. PSA01 安全監視機能有効化設定] は、[Pr. PSA\_]、[Pr. PSC\_] および [Pr. PSD\_] の内容を確認したうえで "1" に設定してください。このパラメータを設定するまで [AL. 7A パラメータ設定異常 (安全監視機能)] が発生し、STOを解除することができません。

第10章 トラブルシューティング  
電源が入らない、またはERROR LEDが点灯した場合、次の表に従って処置してください。

事象	内容	発生要因	処置
電源が入らない。	電源を投入しても、電源LEDが点灯しない。	1. サーボポンプが接続している。 2. MR-D30とサーボポンプが正しく接続されていない。 3. MR-D30が故障している。	サーボポンプを交換してください。 接続を確認してください。
ERROR LEDが点滅した。	ERROR LEDが点滅し、サーボポンプにアラーム番号表示された。	MR-D30またはサーボポンプで異常が発生している。[注]	MR-D30を交換してください。 アラーム番号を確認のうえ、「MR-J4 サーボポンプ技術資料集 (トラブルシューティング編)」に従って問題を解消してください。
ERROR LEDが点灯した。	ERROR LEDが点灯したまま消灯しない。	MR-D30が故障している。	MR-D30を交換してください。

第11章 外形寸法図




CN10A				CN10B			
番号	略称	略称	番号	番号	略称	略称	番号
10	DC24VA	DC24VA	1	10	DC24VB	DC24VB	1
11	DICOMA	DICOMA	2	11	DICOMB	DICOMB	2
12	PLSA		3	12	PLSB		3
13	DI2A	DI1A	4	13	DI2B	DI1B	4
14	DI4A	DI3A	5	14	DI4B	DI3B	5
15	DI6A	DI5A	6	15	DI6B	DI5B	6
16	DO4PA	DO24VA	7	16	DO4PB	DO24VB	7
17	DO2A	DO1A	8	17	DO2B	DO1B	8
18	DO4NA	DO3A	9	18	DO4NB	DO3B	9


質量: 0.15 [kg]

第12章 据付け

取付け方向と間隔



第13章 コネクタ



第14章 ユーザドキュメンテーションのためのチェックリスト例

MITSUBISHI ELECTRIC  
製造者/設置者のためのMR-D30設置用チェックリスト  
最初の試運転までに少なくとも次の項目を満たしてください。項目中の規格は、要件に対して製造者/設置者が確認責任を持ちます。  
このチェックリストを機械の関連文書と共に維持および保管し、定期点検の際に参考資料として使用できるようにしてください。

1. 機械に適用される指令規格に基づいているか。	はい	いいえ
2. 指令規格は適合宣言 (DoC) に含まれているか。	はい	いいえ
3. 保護装置は要求されたカテゴリに一致しているか。	はい	いいえ
4. 感電保護対策 (保護クラス) は有効であるか。	はい	いいえ
5. 安全監視機能 (すべてのネットワーク接続のテスト) を確認しているか。	はい	いいえ

チェックリストの実施を、専門の技術者による最初の試運転および定期点検に代えることはできません。

[品質保証内容]  
1. 無償保証期間と無償保証範囲  
無償保証期間中に、製品に当社側の責任による故障や理由 (以下併せて「故障」と呼びます) が発生した場合、当社はお買い上げいただきました販売店または当社サービス会社を通じて、無償で製品を修理させていただきます。ただし、国内および海外における出張修理が必要な場合は、技術者派遣に要する旅費を申し受けます。また、故障ユニットの取替えに伴う現地再搬送・試運転は当社業務外とさせていただきます。

[無償保証期間]  
製品の無償保証期間は、お客様にご購入またはご指定場所へ納入後12ヶ月とさせていただきます。ただし、当社製品出荷後の流通期間を最長6ヶ月として、製造から18ヶ月を無償保証期間の上限とさせていただきます。また、修理品の無償保証期間は、修理前の無償保証期間を超えて長くありません。

[無償保証範囲]  
(1) 一次故障診断は、原則として弊社にて実施をお願い致します。ただし、弊社要請により当社、または当社サービス網がこの業務を有償にて代行することができます。この場合、故障原因が当社側にある場合は無償と致します。  
(2) 修理内容、使用状況、および修理履歴などの記録、取扱説明書、ユーザーマニュアル、製造者/注意ラベルなどに記載された条件・注意事項などにしたがった正常な状態で使用されている場合に限定させていただきます。  
(3) 無償保証期間内であっても、以下の場合には有償修理とさせていただきます。  
(i) お客様における不適切な保管や取扱い、不注意、過失などにより生じた故障およびお客様のハードウェアまたはソフトウェア設計内容に起因した故障。  
(ii) お客様にて当社の了解なく製品に改造などの手を加えたことによる故障。  
(iii) 当社製品がお客様の機器に組み込まれて使用された場合、お客様の機器が受けている法的規制による安全装置または業界の通念に準拠されていないときと判断される機能・構造などを載せていない状態であったと認められる故障。  
(iv) 取扱説明書などに指定された消耗部品が正常に保守・交換されなければ防げたと思われる故障。  
(v) 消耗部品 (バッテリー、ファン、平滑コンデンサなど) の交換。  
(vi) 火災、異常電圧などの不可抗力による外部要因および地震、雷、風水害などの天災地災による故障。  
(vii) 当社技術者の専任技術者の水準では見てできなかった事象による故障。  
(viii) その他、当社の責任外の場合またはお客様が当社責任外と認めた故障。

2. 生産中止後の有償修理期間  
(1) 当社が有償にて製品修理を受け付けることができる期間は、その製品の生産中止後7年間です。生産中止に類しましては、当社セールスとサービスなどにて報告させていただきます。  
(2) 生産中止後の製品供給 (補用品を含む) はできません。  
3. 海外でのサービス  
海外においては、当社の各地域FAセンターで修理受付をさせていただきます。ただし、各FAセンターでの修理条件などが異なる場合がありますのでご了承ください。

4. 機会損失、二次損失などへの保証責任の除外  
無償保証期間の内外を問わず、以下については当社業務外とさせていただきます。  
(1) 当社の責に帰することができない事象から生じた障害。  
(2) 当社製品の故障に起因するお客様の機会損失、機会利益。  
(3) 当社の予見の有無を問わず特別の事情から生じた損害、二次損害、事故補償、当社製品以外への損害。  
(4) お客様による交換作業、現地機械設備の再調整、立上げ試運転その他の業務に対する補償。  
5. 製品仕様の変更  
カタログ、マニュアルもしくは技術資料などに記載の仕様は、お断りなしに変更させていただく場合がありますので、あらかじめご承知ください。

6. 製品の適用について  
(1) 当社汎用ACサーボをご使用いただくにあたりましては、万一汎用ACサーボに故障・不具合などが発生した場合でも重大な事故にいたらない用途であること、および故障・不具合発生時にはバックアップやフェールセーフ機能が機器外部でシステム的に実装されていることをご使用の条件とさせていただきます。  
(2) 当社汎用ACサーボは、一般工場などへの用途を対象とした汎用品として設計・製作されています。したがって、各電力会社との原子力発電所およびその他の発電所向けなどの公共への影響が大きき用途や、鉄道各社および官公庁向けの用途など、特別品質保証体制をご要求になる用途には、汎用ACサーボの適用を除外させていただきます。また、航空、医療、鉄道、鍛冶、材料装置、有人送達装置、橋梁機械、安全機械など人命や財産に大きな影響が予測される用途への使用についても、当社汎用ACサーボの適用を除外させていただきます。  
ただし、これらの用途であっても、使途を限定して特別な品質をご要求されないことをお客様にご了承いただく場合には、適用可否について検討致しますので当社窓口へご相談ください。



Country/Region	Sales office	Tel/Fax
USA	Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.	Tel : +1-847-478-2100 Fax : +1-847-478-2253
Germany	Mitsubishi Electric Europe B.V. German Branch Mitsubishi-Electric-Platz 1, 40862 Ratingen, Germany	Tel : +49-2102-486-0 Fax : +49-2102-486-1120
China	Mitsubishi Electric Automation (China) Ltd. Mitsubishi Electric Automation Center, No.1366 Hongqiao Road, Shanghai, China	Tel : +86-21-2322-3030 Fax : +86-21-2322-3030
Korea	Mitsubishi Electric Automation Korea Co. Ltd. 7F-9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea	Tel : +82-2-3660-9510 Fax : +82-2-3664-8372/8335
Japan	Mitsubishi Electric Corporation Tokyo Building, 2-7-3, Marunouchi, Chiyoda-ku, Tokyo 100-8310, Japan	Tel : +81-3-3218-2111

## 2. About safety

This chapter explains safety of users and machine operators. Please read the chapter carefully before mounting the equipment. In this installation guide, the specific warnings and cautions levels are classified as follows.

**WARNING** Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

**CAUTION** Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight injury to personnel or may cause physical damage.

### 2.1 Professional engineer

Only professional engineers should mount this to MR-J4 servo amplifiers. Here, professional engineers should meet all the conditions below.

- Persons who took a proper training of related work of electrical equipment or persons who can avoid risk based on past experience.
- Persons who have read and familiarized himself/herself with this installation guide and operating manuals for the protective devices (e.g. light curtain) connected to the safety control system.

### 2.2 Applications of the devices

MR-D30 has a control system whose configuration is possible to be for safety. This product complies with the following standards. (Declaration of conformity No. BCN-B61008-076)

- EN ISO 13849-1 Category 3 PL d and Category 4 PL e
- IEC 61508 SIL 2 and SIL 3
- EN 62061 SIL CL 2 and SIL CL 3
- EN 61800-5-2
- IEC/EN/KN 61800-3/GB 12668.3



An achieved safety level depends on external circuit, wiring conditions, parameter settings, sensor selections, and mounting position on the machine. A photoelectric and contact sensor such as light curtain, laser scanner, safety switch, sensor, and push button for emergency stop can be used with programs. The power of an actuator mounted on the machine or system can be shut off safely using switching output of the safety control system.

### 2.3 Correct use

**WARNING** If you need to get close to the moving parts of the machine for inspection or others, ensure safety by confirming the power off, etc. Otherwise, it may cause an accident.

**CAUTION** MR-D30 complies with basic specifications concerning radiation electromagnetic immunity and fulfills requirements of industrial uses. Therefore, MR-D30 is only for use in industrial environment, not for general use.

MR-D30 can be used only within specifications. (Refer to section 6.2 and section 6.3.) Only professional engineer can use the control system in which MR-D30 is integrated. Additionally, only when a professional engineer installed, performed test operations, and adjusted a machine following "MR-D30 Instruction Manual", an operator can use the machine.

#### 2.3.1 EU compliance

The EC directives were issued to standardize the regulations of the EU countries and ensure smooth distribution of safety-guaranteed products. The CE marking proves the compliance of the manufacturer with the EC directives, and this marking also applies to machines and equipment incorporating servos.

- EMC compliance
  - The combination of MR-J4 servo amplifier and MR-D30 complies with category C3 in accordance with EN 61800-3. As for I/O wires (max. length 10 m) and encoder cables (max. length 50 m), use shielded wires and ground the shields.
  - Install an EMC filter and surge protector on the primary side. The following shows recommended products.
    - EMC filter: Soshin Electric HF3000A-UN series
    - Surge protector: Okaya Electric Industries RSPD-250-U4 series
  - MR-J4 Series are not intended to be used on a low-voltage public network which supplies domestic premises; radio frequency interference is expected if used on such a network.
  - The installer shall provide a guide for installation and use, including recommended mitigation devices. To avoid the risk of crosstalk to signal cables, the installation instructions shall either recommend that the power interface cable be segregated from signal cables.
- For Declaration of Conformity (DoC)
  - Hereby, MITSUBISHI ELECTRIC EUROPE B.V. declares that the servo amplifier with MR-D30 is in compliance with EC directives (Machinery directive (2006/42/EC), EMC directive (2014/30/EU), Low voltage directive (2014/35/EU) and RoHS directive (2011/65/EU)). For the copy of Declaration of Conformity, contact your local sales office.

#### 2.3.2 USA/Canada compliance

The servo amplifiers on which MR-D30 is mounted are designed in compliance with UL 508C and CSA C22.2 No. 14.

- Installation
  - The minimum cabinet size is 150% of each MR-J4 servo amplifier's volume including MR-D30. Also, design the cabinet so that the ambient temperature in the cabinet is 55 °C or less. The servo amplifiers on which MR-D30 is mounted must be installed in a metal cabinet. For environment, the units should be used in open type (UL 50) and overvoltage category III or lower. MR-D30 and servo amplifier needs to be installed at or below pollution degree 2. For connection, use only copper wires.
- Short-circuit current rating (SCCR)
  - Each servo amplifier on which MR-D30 is mounted has checked with a short-circuit test.
- Overload protection characteristics
  - The servo amplifier on which MR-D30 is mounted has servo motor overload protective function. (It is set on the basis (full load current) of 120% rated current of the servo amplifier.)
- Over-temperature protection for motor
  - Motor Over temperature sensing is not provided by the drive.
  - Integral thermal protection is necessary for motor and refer to chapter 4 for the proper connection.
- Capacitor discharge
  - It takes 15 minutes for capacitor discharging of the servo amplifier on which MR-D30 is mounted. Do not touch the unit and terminals immediately after power off.
- Branch circuit protection
  - For installation in United States, branch circuit protection must be provided, in accordance with the National Electrical Code and any applicable local codes. For installation in Canada, branch circuit protection must be provided, in accordance with the Canada Electrical Code and any applicable provincial codes.

#### 2.3.3 South Korea compliance

This product complies with the Radio Wave Law (KC mark). Please note the following to use the product. 이 기기는 업무용 (A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다. (The product is for business use (Class A) and meets the electromagnetic compatibility requirements. The seller and the user must note the above point, and use the product in a place except for home.)

### 2.4 Safety observation function compatible unit

The safety observation function is executed by writing a parameter to MR-D30 in a system using an MR-J4 servo amplifier, motion CPU and safety programmable controller in the following table. Set the parameters of MR-D30 correctly for a proper operation of the safety observation function. Protective functions such as the safety observation function may not work due to an incorrect setting. Refer to "MR-D30 Instruction Manual" for the parameter setting details.

Product name	Model
Servo amplifier	MR-J4_GF-RJ/MR-J4_GF-RJ MR-J4_B-RJ/MR-J4_B-RJ MR-J4_A-RJ/MR-J4_A-RJ MR-J4-DU_A-RJ/MR-J4-DU_A4-RJ
Programmable controller (Note 1)	R_SFCPU
Motion CPU module (Note 2)	Q173DSCPU/Q172DSCPU

Note 1. For using the safety observation function through CC-Link IE Field  
 2. For using the safety observation function through SSCNET II/H

#### (2) List of safety observation function compatible unit

MR-D30 software version	Servo amplifier software version	Safety observation function	Servo motor with functional safety	Servo amplifier
A1 or later	A3 or later	STO/SS1/SBC/SLS/SSM/SOS/SS2/SM	HG-KR_WOC HG-SR_WOC HG-JR_WOC	MR-J4_GF_RJ

MR-D30 software version	Servo amplifier software version	Safety observation function	Servo motor with functional safety	Servo amplifier
A2 or later	A3 or later	STO/SS1/SBC/SLS/SSM/SOS/SS2/SM	HG-KR_WOC HG-SR_WOC HG-JR_WOC	MR-J4_GF_RJ

### 2) MR-J4-(DU)B\_-RJ/MR-J4-(DU)A\_-RJ

MR-D30 software version	Servo amplifier software version	Safety observation function	Servo motor with functional safety	Servo amplifier
A0	B3 or later	STO/SS1/SBC/SLS/SSM/SM	Not compatible	MR-J4_B_RJ
A1 or later	B3/B4	STO/SS1/SBC/SLS/SSM/SM	Not compatible	MR-J4_B_RJ
	B5 or later	STO/SS1/SBC/SLS/SSM/SOS/SS2/SM	HG-KR_WOC HG-SR_WOC HG-JR_WOC	MR-J4_A_RJ (Note) MR-J4-DU_B_RJ MR-J4-DU_A_RJ (Note)

Note: The servo amplifiers manufactured in November, 2014 or later is supported.

### (b) Programmable controller

Model	Software version
R_SFCPU	07 or later

### (c) Motion controller

Model	OS	Software version
Q173DSCPU	SW8DNC-SV22Q/ISW8DNC-SV13QJ	05 or later
Q172DSCPU	SW8DNC-SV22QL/ISW8DNC-SV13QL	

## 2.5 General cautions for safety protection and protective measures

**POINT**

- Observe the cautions for safety protection and protective measures.
- Observe the items in this section for proper use of MR-D30.

- When mounting, installing, and using the MR-D30, always observe standards and directives applicable in the country.
- When using an MR-D30 in an EU member state, comply with the following directives.
  - Machinery directive 2006/42/EC
  - EMC directive 2014/30/EU
  - Low-voltage directive 2014/35/EU
  - RoHS directive 2011/65/EU
  - Other laws/regulations of labor safety
- The manufacturer and owner of machines on which an MR-D30 is used should be familiarized with all the applicable laws and regulations and should be responsible to observe them. For Declaration of Conformity (DoC), our company declares that the servo amplifiers are in compliance with the necessary requirements and standards (2006/42/EC, 2014/30/EU, 2014/35/EU and 2011/65/EU). You can obtain the copy of Declaration of Conformity from our website.
- The contents of "MR-D30 Instruction Manual" must be observed.
- Tests should be performed by professional engineers, especially qualified and responsible personnel, and should be recorded/documentated for a third party to rebuild and confirm the tests.
- An external power supply of equipment should have resistance to instantaneous power failure for 20 ms according to the specifications of IEC/EN 60204-1.

2.6 Disposal  
 Disposal of unusable or irreparable devices should always occur in accordance with the applicable country-specific waste disposal regulations. (Example: European Waste 16 02 14)

### 2.7 Risk assessment

To ensure safety, users should decide all the risk assessments and residual risks in the entire machine equipment. A company and/or individual who constructed the safety related system must take full responsibility for installation and commissioning of the system. Additionally, when complying with a European machinery directive, the system must acquire safety standards certification as a whole. Perform all risk assessments and safe level certification to the machine or the system as a whole. It is recommended that a Certification Body final safety certification of the system be used. The following shows residual risks concerning the safety observation function of this product.

#### 2.7.1 Common residual risks in each function

- At the shipment to end-users, check the settings of safety related components with programming tools and monitored/displayed contents on display and record and save the setting data concerning the safety observation function and the programming tools you used. Perform them using a check sheet, etc.
  - The safety will not be ensured such as in assembling machine until installing, wiring, and adjustment are completed properly. Install, wire, and adjust your system referring to installation guide for each unit.
- Only qualified personnel are authorized to install, start-up, repair or adjust the machines in which these components are installed. Only trained engineers should install and operate the equipment. (ISO 13849-1 Table F.1 No. 5)
- Separate the wiring for safety observation function from other signal wirings. (ISO 13849-1 Table F.1 No. 1)
- Protect the cables with appropriate ways (routing them in a cabinet, using a cable guard, etc.).
- We recommend using a switch, relay, sensor, etc. which comply with safety standards. When using a switch, relay, sensor, etc. which do not comply with safety standards, perform a safety confirmation.
- Keep the required clearance/creepage distance depending on voltage you use.
- The time to a safety observation error depends on parameter settings.

#### 2.7.2 Residual risks in each function


- Speed monitoring (SLS)
  - Speed monitoring function guarantees the servo motor speed), but it does not guarantee the actual machine safety speed. Set parameters so that the safe speed of the machine is the same as the safety speed of the specified motor.
  - Check if the speed of the monitored servo axis is the same as the actual speed by using a tachometer, etc. considering the speed includes an error caused by the command and encoder resolution.
  - The defect of the mechanical section such as slid of shaft and wanting of a timing belt, etc. is not covered. Be sure to eliminate the risk of mechanical section before operation.
  - Speed monitoring error detection time is set to 1 ms. Error in shorter than this time are not detected.
  - After speed is over the limit, safety observation error (shut-off signal off) does not occur during the speed error detection time set by the parameter. Make sure that safety can be ensured during this period.
- Safe speed monitor (SSM)
  - When SSM is used as a restart trigger, perform it according to IEC/EN 60204-1.
- Safe brake control (SBC)
  - This function guarantees only that power to mechanic break is properly supplied and abrasion of the brake cannot be detected. Check this function regularly that the mechanic brake can operate.

### 3. Conditions of use for the product

- MR-D30 complies with a safety standard, but this fact does not guarantee that MR-D30 will be free from any malfunction or failure. The user of this product shall comply with any and all applicable safety standard, regulation or law and take appropriate safety measures for the system in which the product is installed or used and shall take the second or third safety measures other than the product. Our company is not liable for damages that could have been prevented by compliance with any applicable safety standard, regulation or law.
- Our company prohibits the use of Products with or in any application involving, and we shall not be liable for a default, a liability for defect warranty, a quality assurance, negligence or other tort and a product liability in these applications.
  - Power plants
  - Trains, railway systems, airplanes, airline operations, and other transportation systems
  - Hospitals, medical care, dialysis and life support facilities or equipment
  - Amusement equipment
  - Incineration and fuel devices
  - Handling of nuclear or hazardous materials or chemicals
  - Mining and drilling
  - Other applications where the level of risk to human life, health or property are elevated.

## 4. Block diagram and timing chart

- Function block diagram (for using input signal)  
 This is an example of a combination with MR-J4\_B\_-RJ.



Note 1. Safety switch, safety relay, etc.  
 2. Please use a thermal sensor, etc. for thermal protection of the servo motor.  
 3. The HG-KR\_WOC, HG-SR\_WOC, or HG-JR\_WOC servo motor is required to use the SS2/SOS functions.

- How to use the functions  
 To use the safety observation functions, combine MR-D30 with MR-J4. For how to use the functions, refer to "MR-D30 Instruction Manual".

### 5. Maintenance and disposal

MR-D30 safety logic unit is equipped with LED displays to check errors for maintenance. Please dispose this unit according to your local laws and regulations. Mounting the functional safety unit to the servo amplifier enables you to use the safety observation functions such as STO/SS1/SS2/SOS/SLS/SSM/SBC without depending on a controller. Changing the combination of MR-D30 and MR-J4 servo amplifier will trigger [AL 7A.4 Functional safety unit combination error (safety observation function)] and the safety observation function you set will not operate.

## 6. Functions and configuration

### 6.1 Summary

- Safety observation functions are available with your servo amplifier. Disposal of unusable or irreparable devices should always occur in accordance with the applicable country-specific waste disposal regulations. (Example: European Waste 16 02 14)
- Drive safety compatible integrated motion controller  
 Safety communication with motion controllers is available by using MR-D30 with MR-J4\_B\_-RJ. With this, the wiring which was required can be reduced for the STO signal and encoder signal for safety observation.
- Drive safety integrated programmable controller  
 Safety communication with safety programmable controller is available by using MR-D30 with MR-J4\_GF\_-RJ. With this, the wiring which was required can be reduced for the STO signal and encoder signal for safety observation.

### 6.2 Transportation and storage

**CAUTION**

- Transport the products correctly according to their mass.
- Stacking in excess of the limited number of product packages is not allowed.
- Install the equipment in a load-bearing place in accordance with "MR-D30 Instruction Manual".
- Do not put excessive load on the machine.

When you keep or use it, please fulfill the following environment.

Item	Environment	
Ambient temperature	Operation [°C]	0 to 55 Class 3K3 (IEC/EN 60721-3-3)
	Transportation (Note) [°C]	-20 to 65 Class 2K4 (IEC/EN 60721-3-2)
	Storage (Note) [°C]	-20 to 65 Class 1K4 (IEC/EN 60721-3-1)
Ambient humidity	Operation, transportation, storage	5 %RH to 90 %RH
	Test condition	10 Hz to 57 Hz with amplitude of 0.075 mm 57 Hz to 150 Hz with constant acceleration of 9.8 m/s <sup>2</sup> to IEC/EN 61800-5-1 (Test Fc of IEC 60508-2-4)
Vibration resistance	Operation (Note)	5.9 m/s <sup>2</sup>
	Transportation (Note)	Class 2M3 (IEC/EN 60721-3-2)
	Storage	Class 1M2 (IEC/EN 60721-3-2)
Pollution degree	2	
IP rating	Mounted on a servo amplifier: IP20 (IEC/EN 60529)	
	MR-D30 (single): IP00 (IEC/EN 60529)	
Altitude	Operation, storage	2000 m or less above sea level
	Transportation	10000 m or less above sea level


Note: In regular transport packaging

### 6.3 Specifications

Model	MR-D30	
Output	Rated voltage	24 V DC
	Rated current [A]	0.3
Interface power supply	Voltage	24 V DC ± 10%
	Power supply capacity [A]	0.8 (Note 1)
Safety performance	Standards certified by CB	EN ISO 13849-1 Category 4, PL e and Category 3, PL d IEC 61508 SIL 2 and SIL 3 EN 62061 SIL CL 2 and SIL CL 3 EN 61800-5-2
	Mean time to dangerous failure	MTTFd ≥ 100 [years] (313a)
	Effectiveness of fault monitoring of a system or subsystem	DC = High, 97.6 [%]
	Average probability of dangerous failures per hour	PFH = 6.57 × 10 <sup>-4</sup> [1/h]
	Mission time	TM = 20 [years]
Safety observation function (IEC/EN 61800-5-2)	Response performance (Note 2)	Using input device: 15 ms or less Using a drive safety integrated motion controller: 60 ms or less Using drive safety integrated programmable controller: 65 ms or less
	Speed observation resolution	Depends on a command resolution (22 bit position command: 0.1 r/min or less)
	Position observation resolution	1/32 rev
	Safety position data resolution	32 pulses/rev (5 bits)
	Input device	6 points × 2 systems (source/sink)
	Output device	Source: 3 points × 2 systems and 1 point × 1 system Sink: 1 point × 1 system
	Safe torque off (STO)	Category 4, PL e, SIL 3 (Note 3)/Category 3, PL d, SIL 2
Safety observation function (IEC/EN 61800-5-2)	Safe stop 1 (SS1)	Category 4, PL e, SIL 3 (Note 3)/Category 3, PL d, SIL 2
	Safely-limited speed (SLS) (Note 7)	Category 4, PL e, SIL 3 (Note 3, 4)/Category 3, PL d, SIL 2
	Safe speed monitor (SSM) (Note 7)	Category 4, PL e, SIL 3 (Note 3, 4)/Category 3, PL d, SIL 2
	Safe brake control (SBC)	Category 4, PL e, SIL 3 (Note 3)/Category 3, PL d, SIL 2
	Safe operating stop (SOS)	Category 4, PL e, SIL 3 (Note 3)/Category 3, PL d, SIL 2
	Safe stop 2 (SS2) (Note 5, 7)	Category 4, PL e, SIL 3 (Note 3)/Category 3, PL d, SIL 2
	Status monitor (STO/SOS)	Category 4, PL e, SIL 3/Category 3, PL d, SIL 2 (Note 6)
Compliance to global standards	CE marking	EMC: EN 61800-3 MD: EN ISO 13849-1, EN 61800-5-2, EN 62061
	Structure (IP rating)	Natural cooling, open (mounted on a servo amplifier: IP20, MR-D30 (single): IP00)
Mass [g]	150	

Note 1. This is the value applicable when all I/O signals are used. The current capacity can be decreased by reducing the number of I/O points.  
 2. Time from STO input off to energy shut off.  
 3. To meet Category 4, PL e, SIL 3 for input signals, a diagnosis using test pulses is required.  
 4. To meet Category 4, PL e, SIL 3, using with an HG-KR\_WOC, HG-SR\_WOC, or HG-JR\_WOC servo motor is required.  
 5. To enable SS2 and SOS, using with an HG-KR\_WOC, HG-SR\_WOC, or HG-JR\_WOC servo motor is required.  
 6. For the achievable safety level, refer to the section of "Safety observation function (IEC/EN 61800-5-2)".  
 7. Linear servo system, direct drive servo system, and fully closed loop system are not compatible with SLS, SSM, SS2, and SOS.

6.4 When using MR-D30 for an MR-J4 series servo amplifier  
6.4.1 Input signal




1. Separate all the external wires by two types, CN10A and CN10B.
2. Assign each input device to the following combinations of connector and pin. Refer to chapter 7 for each device.

Combination of connector and pin for input	
D1A (CN10A-4)/D1B (CN10B-4)	
D2A (CN10A-13)/D2B (CN10B-13)	
D3A (CN10A-5)/D3B (CN10B-5)	
D4A (CN10A-14)/D4B (CN10B-14)	
D5A (CN10A-6)/D5B (CN10B-6)	
D6A (CN10A-15)/D6B (CN10B-15)	

3. Supply 24 V DC ± 10% to interfaces from outside. When all the I/O points are used, the required current capacity is 0.8 A in total. The current capacity can be decreased by reducing the number of I/O points. Refer to section 7.2 that gives the current value necessary for the interface. The illustration of the 24 V DC power supply is divided between input signal and output signal for convenience. However, they can be configured by one.

6.4.2 Output signal

DO1A to DO3A, DO1B to DO3B, and DO4NA can be used as source outputs, and DO4PB can be used as a sink output.



1. Separate all the external wires by two types, CN10A and CN10B. Be sure to wire them separately by the two types for power supply for IO (24 V DC, 0 V common). Do not mix them when wiring.
2. Assign each output device to the following combinations of connector and pin. Refer to chapter 7 for each device.

Combination of connector and pin for output	
DO1A (CN10A-8)/DO1B (CN10B-8)	
DO2A (CN10A-17)/DO2B (CN10B-17)	
DO3A (CN10A-9)/DO3B (CN10B-9)	
DO4NA (CN10A-18)/DO4PB (CN10B-18)	

3. Supply 24 V DC ± 10% to interfaces from outside. When all the I/O points are used, the required current capacity is 0.8 A in total. The current capacity can be decreased by reducing the number of I/O points. Refer to section 7.2 that gives the current value necessary for the interface. The illustration of the 24 V DC power supply is divided between input signal and output signal for convenience. However, they can be configured by one.
4. DO4PA (CN10A-16), DO4NA (CN10A-18), DO4PB (CN10B-16) and DO4NB (CN10B-18) will not be available with MR-D30 manufactured in September 2014 or before. Do not connect anything to these pins.

7. Signals

7.1 Connector and pin assignment

- (1) Input device  
Assign the devices to D1\_1 to D6\_6 with [Pr. PSD02] input device selection D11 to [Pr. PSD07] input device selection D16. For the safety observation function control by network, you can input through network.

Device	Symbol	Connector and pin No.	Function	Input pin status which the function turns to be enabled
STO command	STOC	CN10A-4 CN10A-5	The STO function operates by the STO command.	Opened
SS1 command	SS1C	CN10A-6 CN10A-13	The SS1 function operates by the SS1 command.	Opened
SS2 command	SS2C	CN10A-14 CN10A-15	The SS2/SOS functions operate by the SS2/SOS command.	Opened
SLS1 command	SLS1C	CN10B-4 CN10B-5 CN10B-6	The SLS function 1 operates by the SLS1 command. [Pr. PSA07] SLS deceleration monitoring time 1] and [Pr. PSA11] SLS speed 1] are used as parameters.	Opened
SLS2 command	SLS2C	CN10B-13 CN10B-14 CN10B-15	The SLS function 2 operates by the SLS2 command. [Pr. PSA08] SLS deceleration monitoring time 2] and [Pr. PSA12] SLS speed 2] are used as parameters.	Opened
SLS3 command	SLS3C	CN10B-4 CN10B-5 CN10B-6	The SLS function 3 operates by the SLS3 command. [Pr. PSA09] SLS deceleration monitoring time 3] and [Pr. PSA13] SLS speed 3] are used as parameters.	Opened
SLS4 command	SLS4C	CN10B-13 CN10B-14 CN10B-15	The SLS function 4 operates by the SLS4 command. [Pr. PSA10] SLS deceleration monitoring time 4] and [Pr. PSA14] SLS speed 4] are used as parameters.	Opened
Test pulse output A	PLSA	CN10A-12	Outputs test pulses for external wiring diagnosis.	
Test pulse output B	PLSB	CN10B-12	Outputs test pulses for external wiring diagnosis.	

(2) Output device

The status monitor (SM) of the safety observation function is output from DO1\_1 to DO4\_4. The devices can be assigned to DO1\_1 to DO4\_4 with [Pr. PSD08] output device selection DO11 to [Pr. PSD11] output device selection DO31. For the safety observation function control by network, you can output through network. Then, DO1\_1 to DO4\_4 can be used simultaneously.

Device	Symbol	Connector and pin No.	Function	Output pin status during operation
SSM output	SSMS	CN10A-8 CN10A-9	Indicates that the servo motor speed is at SLS speed or less while speed observation is operating by SLS function.	Closed
SBC output	SBCS	CN10A-17	Outputs a control signal of the electromagnetic brake.	Opened
STO output	STGS	CN10A-18	This is a monitor output signal meaning that the STO function is operating.	Opened
SOS output	SOSS	CN10B-8 CN10B-9	This is a monitor output signal meaning that the SS2/SOS function is operating.	Opened
SS1 output	SS1S	CN10B-17 CN10B-18	This is a monitor output signal meaning that the SS1 function is operating.	Opened
SS2 output	SS2S	CN10B-16	This is a monitor output signal meaning that the SS2/SOS function monitors the servo motor is in the stop state.	Opened
SLS1 output	SLS1S	CN10B-4	This is a monitor output signal meaning that the SLS function 1 is operating.	Opened
SLS2 output	SLS2S	CN10B-13	This is a monitor output signal meaning that the SLS function 2 is operating.	Opened
SLS3 output	SLS3S	CN10B-4	This is a monitor output signal meaning that the SLS function 3 is operating.	Opened
SLS4 output	SLS4S	CN10B-13	This is a monitor output signal meaning that the SLS function 4 is operating.	Opened

(3) Power supply

Name	Symbol	Connector and pin No.	Function and application
Digital input I/F common A	DICOMA	CN10A-2 CN10A-11	This is a common terminal for input signal. Input 24 V DC (24 V DC ± 10% 0.8 A) for I/O interface. The power supply capacity changes depending on the number of I/O interface points to be used. For sink interface, connect + of 24 V DC external power supply. For source interface, connect - of 24 V DC external power supply.
Test pulse power supply input A	DC24VA	CN10A-1 CN10A-10	Input a power supply to output test pulses for external wiring diagnosis. Connect the positive terminal of the 24 V DC external power supply.
Digital output I/F common A	DO24VA	CN10A-7	This is a common terminal for output signal. For source interface, connect + of 24 V DC external power supply.
DO4A power supply for digital output I/F	DO4PA	CN10A-16	This is the power terminal for the DO4A output signal. Connect the positive terminal of the 24 V DC external power supply.
Digital input I/F common B	DICOMB	CN10B-2 CN10B-11	This is a common terminal for input signal. Input 24 V DC (24 V DC ± 10% 0.8 A) for I/O interface. The power supply capacity changes depending on the number of I/O interface points to be used. For sink interface, connect + of 24 V DC external power supply. For source interface, connect - of 24 V DC external power supply.
Test pulse power supply input B	DC24VB	CN10B-1 CN10B-10	Input a power supply to output test pulses for external wiring diagnosis. Connect the positive terminal of the 24 V DC external power supply.
Digital output I/F common B	DO24VB	CN10B-7	This is a common terminal for output signal. For source interface, connect + of 24 V DC external power supply.
DO4B power supply for digital output I/F	DO4NB	CN10B-18	This is the power terminal for the DO4B output signal. Connect the negative terminal of the 24 V DC external power supply.

7.2 Interface (source I/O)


For MR-D30, source type I/O interfaces can be used. The following shows an example of source interface.

(1) Input interface

For MR-D30, source type and sink type I/O interfaces can be used. Transmit signals from source (open-collector) type transistor output, relay switch, etc. For sink interface, refer to "MR-D30 Instruction Manual".


(a) External device connection

Connect the output signal to DI\_1.



(2) Output interface

When the output transistor is turned on, the current flows from the output terminal to a load. A lamp, relay or photocoupler can be driven. Install a diode (D) for an inductive load, or install an inrush current suppressing resistor (R) for a lamp load. (Rated current: 5 mA to 40 mA, maximum current: 50 mA, inrush current: 100 mA or less)  
A 2.4 V voltage drop occurs in MR-D30.



7.3 Wiring method of CN10A and CN10B connectors

Handle with the tool with care when connecting wires.

(1) Wire strip

- Use wires with size of AWG 24 to 16 (recommended electric wire: UL 1007) and strip the wires to make the stripped length 10 mm ± 0.5 mm. Confirm the stripped length with gauge, etc. before using the wires.
- If the stripped wires are bent, loose or too thick due to twisting too much, fix the wires by twisting lightly, etc. Then, confirm the stripped length before using the wires. Do not use excessively deformed wires.
- Smooth out the wire surface and stripped insulator surface.

(2) Connecting wires

Before connecting wires, be sure to pull out the receptacle assembly from the header connector. If wires are connected with inserted connector, the connector and the printed board may malfunction.  
With pressing the release button with a flat-blade screwdriver with the blade edge width of 2.0 mm to 2.5 mm, insert a wire all the way in and remove the screwdriver. Refer to "MR-D30 Instruction Manual" for wiring.

(3) Connectors

Be sure to insert the connector all the way straight until you hear or feel clicking. After connection, tighten the screw came with the connector using a flat-blade screwdriver. Loosen the screw before disconnection.

8. Display

MR-D30 has four LED indications. They indicate the followings.

LED	Lighting status	Description
POWER	Lit	Power is being supplied.
	Extinguished	Power is not supplied.
RUN	Lit	The safety observation function is performing. STO, SS1, SS2/SOS, or SLS function is being executed normally, performing shutdown or observation.
	Extinguished	The safety observation function is not performing. Because the operation commands are not inputted or an internal diagnosis error has occurred.
STO	Lit	STO function is performing. The power to the motors is shut off.
	Extinguished	STO function is not performing. The power to the motors is not shut off.
ERROR	Lit	Some errors have been detected for MR-D30. (Note)
	Blinking	Some errors have been detected for MR-D30.
	Extinguished	An error is not being detected in MR-D30.

Note. When a servo amplifier which is not compatible with MR-D30 is connected to MR-D30, "ERROR" will light. Check if MR-D30 is connected to the MR-J4\_ B\_ RJ servo amplifier with the software version B5 or later, or the MR-J4\_ A\_ RJ servo amplifier with the software version B5 or later. (Refer to (3) (a) of section 2.3.4.)



The following shows indication example of each state.

POWER	RUN	STO	ERROR	Servo amplifier display	Status	Description
●	●	●	●	Normal	Power off	Power is not supplied.
○	●	○	●	95_ or Ab	During diagnosis	For the safety observation function control by input device, execute a fixing diagnosis at start-up. For the safety observation function control by network, connect networks.
○	●	●	●	Normal	Safety observation function is not performing.	The safety observation function is not performing.
○	○	○	●	95_	Safety observation function is performing (shutting power off).	STO or SS1 function is performing.
○	○	●	●	Normal	Safety observation function is performing (monitoring).	SLS or SS2/SOS function is performing.
○	●/○	○	◎/○	Alarm No.	Error has occurred.	An error has been detected. Refer to chapter 8 for error details. (Note)
○	○	○	○	Alarm No.	Error has occurred (watchdog).	Watchdog is occurring due to parts error, such as the CPU.

Note. When a servo amplifier which is not compatible with MR-D30 is connected to MR-D30, "ERROR" will light. Refer to section 2.3.4 (3) (a) for the software version of a servo amplifier that is compatible with MR-D30.

9. Setting method


Use MR Configurator2 for the settings. Refer to "MR-D30 Instruction Manual" for details.  
Check the contents of [Pr. PSA\_ ], [Pr. PSC\_ ], and [Pr. PSD\_ ] and set [Pr. PSA01] Safety observation function activation setting to "1". Until setting this parameter, STO cannot be canceled due to [AL\_ ] FA Parameter setting error (safety observation function) occurrence.

10. Troubleshooting

When power is not supplied or ERROR LED turns on, refer the following table and take the appropriate action.

Event	Description	Cause	Action
Power is not supplied.	Power LED does not turn on although power is supplied.	1. The servo amplifier is malfunctioning. 2. MR-D30 is not connected to the servo amplifier properly. 3. MR-D30 is malfunctioning.	Replace the servo amplifier. Check the connection. Replace the MR-D30.
ERROR LED is blinking.	ERROR LED is blinking and an alarm No. is displayed on the servo amplifier.	An error has occurred in MR-D30 or servo amplifier.	Check the alarm No. and remove the problem referring to "MELSERVO-J4 Servo Amplifier Instruction Manual Trouble Shooting".
ERROR LED is on.	ERROR LED has been on.	MR-D30 is malfunctioning.	Replace the MR-D30.



11. Dimensions



CN10A				CN10B			
No.	Symbol	Symbol	No.	No.	Symbol	Symbol	No.
10	DC24VA	DC24VA	1	10	DC24VB	DC24VB	1
11	DICOMA	DICOMA	2	11	DICOMB	DICOMB	2
12	PLSA	PLSA	3	12	PLSB	PLSB	3
13	DI2A	DI1A	4	13	DI2B	DI1B	4
14	DI4A	DI3A	5	14	DI4B	DI3B	5
15	DI6A	DI5A	6	15	DI6B	DI5B	6
16	DO4PA	DO24VA	7	16	DO4PB	DO24VB	7
17	DO2A	DO1A	8	17	DO2B	DO1B	8
18	DO4NA	DO3A	9	18	DO4NB	DO3B	9


12. Installation

Installation direction and clearances



1. For 11 kW to 22 kW servo amplifiers, the clearance between the bottom and ground will be 120 mm or more.
2. For MR-J4-500\_ RJ, the clearance on the left side will be 25 mm or more.

13. Connector



14. Check list for user documentation

**MITSUBISHI ELECTRIC**  
MR-D30 installation checklist for manufacturer/installer

The following items must be satisfied by the initial test operation at least. The manufacturer/installer must be responsible for checking the standards in the items.  
Maintain and keep this checklist with related documents of machines to use this for periodic inspection.

1. Is it based on directive/standard applied to the machine?	Yes	No
2. Is directive/standard contained in Declaration of Conformity (DoC)?	Yes	No
3. Does the protection instrument conform to the category required?	Yes	No
4. Are electric shock protective measures (protective class) effective?	Yes	No
5. Is the safety observation function checked (test of all the shut-off wiring)?	Yes	No

Checking the items will not be instead of the first test operation or periodic inspection by professional engineers.

[Warranty]

1. Warranty period and coverage  
We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

The term of warranty for Product is twelve (12) months after your purchase or delivery of the Product to a place designated by you or eighteen (18) months from the date of manufacture whichever comes first ("Warranty Period"). Warranty period for repaired Product cannot exceed beyond the original warranty period before any repair work.

[Limitations]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule. It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases.
  - i) a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
  - ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
  - iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
  - iv) a failure which may be regarded as avoidable if consumable parts participated in the instruction manual, etc. are duly maintained and replaced
  - v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
  - vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
  - vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
  - viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA center for details.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

- Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:
- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
  - (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
  - (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
  - (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our General-Purpose AC Servo, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in General-Purpose AC Servo, and a backup or fail-safe function should operate on an external system to General-Purpose AC Servo when any failure or malfunction occurs.
- (2) Our General-Purpose AC Servo is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.  
In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used.  
We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.