

Personal Computer Embedded Type
Servo System Controller

Simple Motion Board
User's Manual (Advanced Synchronous Control)

-MR-EM340GF

SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only.

In this manual, the safety precautions are classified into two levels: "⚠️ WARNING" and "⚠️ CAUTION".

 WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
 CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠️ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Design Precautions]

WARNING

- Configure safety circuits externally to ensure that the entire system operates safely even when a fault occurs in the personal computer. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Configure external safety circuits, such as an emergency stop circuit, protection circuit, and protective interlock circuit for forward/reverse operation or upper/lower limit positioning.
 - (2) If an incorrect home position return direction is set, motion control may continue without deceleration. To prevent machine damage caused by this, configure an interlock circuit external to the Simple Motion board.
 - (3) When the Simple Motion board detects an error, the motion slows down and stops or the motion rapidly stops, depending on the stop group setting in parameter. Set the parameter to meet the specifications of a positioning control system. In addition, set the home position return parameter and positioning data within the specified setting range.
 - For the operating status of each station after a communication failure, refer to manuals relevant to the network. Incorrect output or malfunction due to a communication failure may result in an accident.
 - When modifying data of a running Simple Motion board, configure an interlock in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running Simple Motion board, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents. Determine corrective actions to be taken in case of a communication failure.
 - Especially, when a remote Simple Motion board is controlled, immediate action cannot be taken if a problem occurs in the Simple Motion board due to a communication failure. To prevent this, configure an interlock in the program, and determine corrective actions to be taken in case of a communication failure.
 - Do not write any data to the "system area" and "write-protect area" of the buffer memory in the Simple Motion board. Doing so may cause malfunction of the Simple Motion board. For the "system area", and "write-protect area", refer to the user's manual for the Simple Motion board.
-

[Design Precautions]

WARNING

- If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock in the program to ensure that the entire system will always operate safely even if communications fail. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - To maintain the safety of the Simple Motion board against unauthorized access from external devices via the network, take appropriate measures. To maintain the safety against unauthorized access via the Internet, take measures such as installing a firewall.
 - If safety standards (ex., robot safety rules, etc.,) apply to the system using the Simple Motion board, servo amplifier and servomotor, make sure that the safety standards are satisfied.
 - Construct a safety circuit externally of the Simple Motion board or servo amplifier if the abnormal operation of the Simple Motion board or servo amplifier differs from the safety directive operation in the system.
-

[Design Precautions]

CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100 mm or more between them. Failure to do so may result in malfunction due to noise.
 - After the personal computer is powered on or rebooted, the time taken for the Simple Motion board to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
 - Do not power off or reboot the personal computer during the setting registration. Doing so will make the data in the flash ROM undefined. The data need to be set in the buffer memory and to be written to the flash ROM again. Doing so may cause malfunction or failure of the Simple Motion board.
-

[Installation Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before mounting or removing the Simple Motion board to or from the personal computer. Failure to do so may result in electric shock or cause the Simple Motion board to fail or malfunction.
 - Do not touch any connectors while power is on. Doing so may cause electric shock or malfunction.
-

[Installation Precautions]

CAUTION

- Use the Simple Motion board in an environment that meets the general specifications in the Simple Motion Board User's Manual. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
 - Fix the Simple Motion board securely with the board-fixing screw. Tighten the screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or Simple Motion board, resulting in drop, short circuit, or malfunction. For the tightening torque of the board-fixing screws, refer to the manual supplied with the personal computer.
 - Do not directly touch any conductive parts and electronic components of the Simple Motion board. Hold the front panel or edge of the print board. Not holding by the front panel or edges may cause malfunction or failure of the Simple Motion board.
 - Do not disassemble or modify the Simple Motion board. Doing so may cause failure, malfunction, injury, or a fire.
 - Before handling the Simple Motion board, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the Simple Motion board to fail or malfunction.
 - Install the Simple Motion board to a personal computer which is compliant with PCI Express® standard. Failure to do so may cause a failure or malfunction.
 - Securely insert the Simple Motion board into the slot following the board installation instruction of the personal computer. Incorrect insertion of the Simple Motion board may cause malfunction, failure, or drop of the board.
 - When installing the Simple Motion board, take care not to contact with other boards.
 - When installing the Simple Motion board, take care not to get injured by an implemented component or a surrounding member.
 - Handle the Simple Motion board in a place where static electricity will not be generated. Failure to do so may cause a failure or malfunction.
 - The Simple Motion board is included in an antistatic envelope. When storing or transporting it, be sure to put it in the antistatic envelope. Failure to do so may cause a failure or malfunction.
 - Do not drop or apply a strong impact to the Simple Motion board. Doing so may cause a failure or malfunction.
-

[Wiring Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or damage to the Simple Motion board.
 - After installation and wiring, attach the cover of the equipment the Simple Motion board is installed to before turning it on for operation. Failure to do so may result in electric shock.
-

[Wiring Precautions]

CAUTION

- Ground the controllers, servo amplifiers and servo motors embedded with a Simple Motion board with a ground resistance of 100 ohm or less. Do not use a common grounding with other equipment.
 - Check the rated voltage and signal layout before wiring to the Simple Motion board, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
 - Connectors must be correctly connected. Incomplete connections may cause short circuit, fire, or malfunction.
 - Securely connect the connector to the Simple Motion board. Poor contact may cause malfunction.
 - Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100 mm or more between them. Failure to do so may result in malfunction due to noise.
 - Place the cables in a duct or clamp them. If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the Simple Motion board or cables or malfunction due to poor contact.
 - Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the Simple Motion board and external device.
 - When disconnecting the cable from the Simple Motion board, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. Pulling the cable connected to the Simple Motion board may result in malfunction or damage to the Simple Motion board or cable.
 - Prevent foreign matter such as dust or wire chips from entering the personal computer. Such foreign matter can cause a fire, failure, or malfunction.
 - For Ethernet cables to be used in the system, select the ones that meet the specifications in the user's manual of the Simple Motion board. If not, normal data transmission is not guaranteed.
-

[Startup and Maintenance Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before cleaning or retightening the board-fixing screws. Failure to do so may result in electric shock or malfunction.
 - Turn off the external power supply for the system in all phases before installing the Simple Motion board to or removing it from the personal computer. Failure to do so may result in electric shock or cause the Simple Motion board to fail or malfunction.
 - Do not connect or disconnect any communication cable while power is on. Doing so may result in a malfunction.
-

[Startup and Maintenance Precautions]

CAUTION

- When modifying data of a running Simple Motion board, configure an interlock in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running Simple Motion board, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents. Determine corrective actions to be taken in case of a communication failure.
 - Especially, when a remote Simple Motion board is controlled, immediate action cannot be taken if a problem occurs in the Simple Motion board due to a communication failure. To prevent this, configure an interlock in the program, and determine corrective actions to be taken in case of a communication failure.
 - Do not disassemble or modify the Simple Motion board. Doing so may cause failure, malfunction, injury, or a fire.
 - Use any radio communication device such as a cellular phone or PHS (Personal Handyphone System) more than 25 cm away in all directions from the Simple Motion board. Failure to do so may cause malfunction.
 - Shut off the external power supply (all phases) used in the system before mounting or removing the Simple Motion board. Failure to do so may cause the Simple Motion board to fail or malfunction.
 - Tighten the board-fixing screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or Simple Motion board, resulting in drop, short circuit, or malfunction. For the tightening torque of the board-fixing screws, refer to the manual supplied with the personal computer.
 - After the first use of the product, do not mount/remove the Simple Motion board to/from the personal computer more than 50 times. Exceeding the limit of 50 times may cause malfunction.
 - Maintenance must be performed by qualified maintenance personnel with knowledge.
 - Before handling the Simple Motion board, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the Simple Motion board to fail or malfunction.
 - The Simple Motion board is included in an antistatic envelope. When storing or transporting it, be sure to put it in the antistatic envelope. Failure to do so may cause a failure or malfunction.
 - The microprocessor built in the Simple Motion board will reach a high temperature during operation. Do not touch it directly when replacing the Simple Motion board. Doing so may result in a burn.
 - Before testing the operation, set a low speed value for the speed limit parameter so that the operation can be stopped immediately upon occurrence of a hazardous condition.
 - Confirm and adjust the program and each parameter before operation. Unpredictable movements may occur depending on the machine.
 - When using the absolute position system function, on starting up, and when the Simple Motion board or absolute position motor has been replaced, always perform a home position return.
 - Before starting the operation, confirm the brake function.
 - Do not perform a megger test (insulation resistance measurement) during inspection.
 - After maintenance and inspections are completed, confirm that the position detection of the absolute position detection function is correct.
 - Extreme adjustments and changes may lead to unstable operation, so never make them.
-

[Startup and Maintenance Precautions]

CAUTION

- Do not place the Simple Motion board or servo amplifier on metal that may cause a power leakage or wood, plastic or vinyl that may cause static electricity buildup. Doing so can cause malfunction or failure of the Simple Motion board.
-

[Operating Precautions]

CAUTION

- When changing data and operating status, and modifying program of the running Simple Motion board, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
 - Do not power off or reboot the personal computer while the setting values in the buffer memory are being written to the flash ROM in the Simple Motion board. Doing so will make the data in the flash ROM undefined. The values need to be set in the buffer memory and written to the flash ROM again. Doing so also can cause malfunction or failure of the Simple Motion board.
 - Note that when the reference axis speed is specified for interpolation operation, the speed of the partner axis (2nd, 3rd, or 4th axis) may exceed the speed limit value.
 - Do not go near the machine during test operations or during operations such as teaching. Doing so may lead to injuries.
-

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.
-

[Transportation Precautions]

CAUTION

- The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.
 - The Simple Motion board is a precision machine, so do not drop or apply strong impacts on it.
-

CONDITIONS OF USE FOR THE PRODUCT

- (1) Mitsubishi Simple Motion board ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries. MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi representative in your region.

INTRODUCTION

Thank you for purchasing the personal computer embedded type servo system controllers.

This manual describes the functions and programming of the relevant products listed below.

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the personal computer embedded type servo system controller to handle the product correctly. When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Please make sure that the end users read this manual.

Relevant products

MR-EM340GF

Point

Symbols used in this manual are shown below.

A serial No. is inserted in the "****" mark.

- [Pr.**]: Symbols indicating positioning parameter or home position return parameter items
 - [Da.**]: Symbols indicating positioning data or block start data items
 - [Md.**]: Symbols indicating monitor data items
 - [Cd.**]: Symbols indicating control data items
-

COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

Method of ensuring compliance

To ensure that this product maintains EMC and Low Voltage Directives, please refer to the following manual.

 Simple Motion Board User's Manual (Startup)

CONTENTS

SAFETY PRECAUTIONS	1
CONDITIONS OF USE FOR THE PRODUCT	7
INTRODUCTION	7
COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES	8
RELEVANT MANUALS	11
TERMS	12
CHAPTER 1 OUTLINE OF ADVANCED SYNCHRONOUS CONTROL	13
1.1 Outline of Synchronous Control	13
1.2 Performance Specifications	16
1.3 Operation Method of Synchronous Control	19
Synchronous control execution procedure	19
Starting/ending for synchronous control	20
Stop operation of output axis	22
CHAPTER 2 INPUT AXIS MODULE	24
2.1 Servo Input Axis	24
Overview of servo input axis	24
Servo input axis parameters	26
Servo input axis monitor data	29
2.2 Synchronous Encoder Axis	31
Overview of synchronous encoder axis	31
Setting method for synchronous encoder	34
Synchronous encoder axis parameters	39
Synchronous encoder axis parameters via link device	44
Synchronous encoder axis control data	47
Synchronous encoder axis monitor data	50
CHAPTER 3 CAM FUNCTION	53
3.1 Control Details for Cam Function	53
3.2 Create Cam Data	60
Memory configuration of cam data	60
Cam data operation function	63
Cam auto-generation function	67
CHAPTER 4 ADVANCED SYNCHRONOUS CONTROL	77
4.1 Main Shaft Module	77
Overview of main shaft module	77
Main shaft parameters	78
Main shaft clutch parameters	80
Main shaft clutch control data	85
4.2 Auxiliary Shaft Module	86
Overview of auxiliary shaft module	86
Auxiliary shaft parameters	86
Auxiliary shaft clutch parameters	88
Auxiliary shaft clutch control data	93
4.3 Clutch	94
Overview of clutch	94

Control method for clutch	94
Smoothing method for clutch	101
Use example of clutch	106
4.4 Speed Change Gear Module	107
Overview of speed change gear module	107
Speed change gear parameters	108
4.5 Output Axis Module	109
Overview of output axis module	109
Output axis parameters	111
4.6 Synchronous Control Change Function	115
Overview of synchronous control change function	115
Synchronous control change control data	115
4.7 Synchronous Control Monitor Data	119
4.8 Phase Compensation Function	123
4.9 Output Axis Sub Functions	124
CHAPTER 5 ADVANCED SYNCHRONOUS CONTROL INITIAL POSITION	125
<hr/>	
5.1 Synchronous Control Initial Position	125
5.2 Synchronous Control Initial Position Parameters	129
5.3 Cam Axis Position Restoration Method	132
Cam axis current value per cycle restoration	132
Cam reference position restoration	137
Cam axis feed current value restoration	139
5.4 Synchronous Control Analysis Mode	141
5.5 Cam Position Calculation Function	143
Cam position calculation control data	143
Cam position calculation monitor data	145
5.6 Method to Restart Synchronous Control	150
APPENDICES	151
<hr/>	
Appendix 1 List of Buffer Memory Addresses (for Synchronous Control)	151
Appendix 2 Sample Program of Synchronous Control	162
INDEX	166
<hr/>	
REVISIONS	168
WARRANTY	169
INFORMATION AND SERVICES	170
TRADEMARKS	170

RELEVANT MANUALS

Manual name [manual number]	Description	Available form
Simple Motion Board User's Manual (Advanced Synchronous Control) [IB-0300326] (This manual)	Functions and programming for the synchronous control of the Simple Motion board	Print book e-Manual PDF
Simple Motion Board User's Manual (Startup) [IB-0300322]	Specifications, procedures before operation, system configuration, wiring, and operation examples of the Simple Motion board	Print book e-Manual PDF
Simple Motion Board User's Manual (Application) [IB-0300324]	Functions, input/output signals, buffer memory, parameter settings, programming, and troubleshooting of the Simple Motion board	Print book e-Manual PDF
Simple Motion Board User's Manual (Network) [IB-0300328]	Functions, parameter settings, troubleshooting and buffer memory of CC-Link IE Field Network	Print book e-Manual PDF
Simple Motion Board User's Manual (API Library) [IB-0300330]	API library and others that the host personal computer uses to control the Simple Motion board	Print book e-Manual PDF



e-Manual refers to the Mitsubishi FA electronic book manuals that can be browsed using a dedicated tool.

e-Manual has the following features:

- Required information can be cross-searched in multiple manuals.
- Other manuals can be accessed from the links in the manual.
- The hardware specifications of each part can be found from the product figures.
- Pages that users often browse can be bookmarked.

TERMS

Unless otherwise specified, this manual uses the following terms.

Term	Description
API library	A general name for the library that creates the application on the host personal computer controlling the Simple Motion board
Axis	Another term for a servo amplifier
Buffer memory	A memory in the Simple Motion board, where data (such as setting values and monitoring values) are stored
CC-Link IE Field Network	A high-speed and large-capacity open field network that is based on Ethernet (1000BASE-T)
Device	A device (X, Y, RX, RY, or others) in the Simple Motion board
EM Configurator	A product name for start-up and examination tool for Simple Motion board
Host personal computer	A general name for a personal computer which operates user programs
Label	A label that represents one of memory areas (I/O signals and buffer memory areas) specific to the Simple Motion board in a given character string
Link device	A device (RX, RY, RWr, or RWw) in a module on CC-Link IE Field Network
Link scan (Link scan time)	Time required for all the stations on the network to transmit data. The link scan time depends on data volume and the number of transient transmission requests.
MR-EM340GF	Another term for the Simple Motion board compatible with CC-Link IE Field Network
MR-J4-GF	MR-J4-_GF_(-RJ) Servo amplifier series
MR-J4-GF-RJ	MR-J4-_GF_-RJ Servo amplifier series
Operation cycle	A motion operation cycle that is set in the inter-module synchronization cycle setting of the Simple Motion board
Remote input (RX)	Bit data input from a slave station to the master station (For some areas in a local station, data are output in the opposite direction.)
Remote output (RY)	Bit data output from the master station to a slave station (For some areas in a local station, data are output in the opposite direction.)
Remote register (RWr)	Word data input from a slave station to the master station (For some areas in a local station, data are output in the opposite direction.)
Remote register (RWw)	Word data output from the master station to a slave station (For some areas in a local station, data are output in the opposite direction.)
Servo amplifier	A generic term for a drive unit Unless specified in particular, indicates the motor driver unit of the sequential command method which is controlled by the Simple Motion board (belonging to own station).
Simple Motion board	The abbreviation for the personal computer embedded type servo system controller Simple Motion board
User program	A general name for applications using the API library

1 OUTLINE OF ADVANCED SYNCHRONOUS CONTROL


The outline, specifications and the operation method of synchronous control using the Simple Motion board are explained in this chapter.

This chapter helps to understand what can be done using the positioning system and which procedure to use for a specific purpose.

1.1 Outline of Synchronous Control

"Synchronous control" can be achieved using software instead of controlling mechanically with gear, shaft, speed change gear or cam, etc.

"Synchronous control" synchronizes movement with the input axis (servo input axis or synchronous encoder axis), by setting "the advanced synchronous control parameters" and starting synchronous control on each output axis.



It is possible to control without amplifier by setting the virtual servo amplifier.

*1 It is possible to drive the servo input axis except for the positioning control (home position return, manual control, speed-torque control, synchronous control).


For details on the positioning control, the home position return, the manual control and the speed-torque control, refer to the following.

📖 Simple Motion Board User's Manual (Application)

*2 Speed change gear can be arranged on one of "Main shaft side", "Auxiliary shaft side" or "After composite auxiliary shaft gear".

List of synchronous control module

The module is used in synchronous control as follows.



Point

- Input axis module can be set to one of servo input axis or synchronous encoder axis.
- Speed change gear can be arranged on one of main shaft side, auxiliary shaft side or after composite auxiliary shaft gear.
- Set the movement amount of input axis module as large as possible to prevent the speed fluctuation of output axis module in the synchronous control. If the movement amount of input axis module is small, the speed fluctuation of output axis module may occur depending on the setting for advanced synchronous parameter.
- The following items can be monitored in the "Synchronous Control Image" window using the EM Configurator; each synchronous control monitor data and the rotation direction of main shaft main input axis, main shaft sub input axis, auxiliary shaft axis, and output axis (cam axis feed current value)

Input axis

Classification	Name	Parts	Function description	Maximum number of usable		Reference
				Number per board	Number per axis	
Input axis module	Servo input axis	—	• Used to drive the input axis with the position of the servomotor controlled by the Simple Motion board.	16	—	☞ Page 24 Servo Input Axis
	Synchronous encoder axis	—	• Used to drive the input axis with input pulse from the synchronous encoder.	16	—	☞ Page 31 Synchronous Encoder Axis

■Output axis

Classification	Name	Parts	Function description	Maximum number of usable		Reference
				Number per board	Number per axis	
Main shaft module	Main shaft main input axis		<ul style="list-style-type: none"> The input axis on the main side of the main shaft module. The reference position on the main shaft. 	16	1	☞ Page 77 Main Shaft Module
	Main shaft sub input axis		<ul style="list-style-type: none"> The input axis on the sub side of the main shaft module. It is used to input the compensation amount for the position of the main shaft main input axis. 	16	1	☞ Page 77 Main Shaft Module
	Composite main shaft gear		<ul style="list-style-type: none"> The composite movement amount of the main shaft main input axis and the main shaft sub input axis are transmitted to the main shaft gear. 	16	1	☞ Page 77 Main Shaft Module
	Main shaft gear		<ul style="list-style-type: none"> The converting movement amount after composite main shaft gear is transmitted by the setting gear ratio. 	16	1	☞ Page 77 Main Shaft Module
	Main shaft clutch		<ul style="list-style-type: none"> The movement amount of the main shaft is transmitted by the clutch ON/OFF. 	16	1	☞ Page 77 Main Shaft Module ☞ Page 94 Clutch
Auxiliary shaft module	Auxiliary shaft axis		<ul style="list-style-type: none"> The input axis of the auxiliary shaft module. 	16	1	☞ Page 86 Auxiliary Shaft Module
	Auxiliary shaft gear		<ul style="list-style-type: none"> The converting movement amount of the auxiliary shaft is transmitted by the setting gear ratio. 	16	1	☞ Page 86 Auxiliary Shaft Module
	Auxiliary shaft clutch		<ul style="list-style-type: none"> The movement amount of the auxiliary shaft is transmitted by the clutch ON/OFF. 	16	1	☞ Page 86 Auxiliary Shaft Module ☞ Page 94 Clutch
	Composite auxiliary shaft gear		<ul style="list-style-type: none"> The composite movement amount of the main shaft and the auxiliary shaft are transmitted. 	16	1	☞ Page 86 Auxiliary Shaft Module
Speed change gear module	Speed change gear		<ul style="list-style-type: none"> It is used to change the speed by setting speed change ratio during the operation. 	16	1	☞ Page 107 Speed Change Gear Module
Output axis module	Output axis		<ul style="list-style-type: none"> The cam conversion is processed based on the input movement amount and the setting cam data. The feed current value is output as the command to the servo amplifier. 	16	1	☞ Page 109 Output Axis Module

■Cam data

Classification	Name	Function description	Maximum number of usable	Reference
			Number per board	
Cam data	Cam data	<ul style="list-style-type: none"> It controls the operation pattern of the output axis (two-way operation and feed operation), which is corresponding to the input movement amount of the output axis module. 	Up to 1024	☞ Page 53 CAM FUNCTION

1.2 Performance Specifications

Performance specifications

Item		Number of settable axes
Input axis	Servo input axis	16 axes/board
	Synchronous encoder axis	16 axes/board
Composite main shaft gear		1/output axis
Main shaft main input axis		1 axis/output axis
Main shaft sub input axis		1 axis/output axis
Main shaft gear		1/output axis
Main shaft clutch		1/output axis
Auxiliary shaft		1 axis/output axis
Auxiliary shaft gear		1/output axis
Auxiliary shaft clutch		1/output axis
Composite auxiliary shaft gear		1/output axis
Speed change gear		1/output axis
Output axis (Cam axis)		16 axes/board

Cam specifications

Item		Specification	
Memory capacity*1	Cam storage area	3M bytes	
	Cam open area	16M bytes	
Number of cam registration*2		Up to 1024 (Dependent on memory capacity, cam resolution and coordinate number)	
Comment		Up to 32 characters per cam data	
Cam data	Stroke ratio data format	Cam resolution	256/512/1024/2048/4096/8192/16384/32768
		Stroke ratio	-214.7483648 to 214.7483647 [%]
	Coordinate data format	Coordinate number	2 to 65535
		Coordinate data	Input value: 0 to 2147483647 Output value: -2147483648 to 2147483647

*1 Cam data capacity can be calculated using EM Configurator.

*2 The maximum number of cam registration by the cam resolution is shown below. (In case it created by the same cam resolution.)

■Stroke ratio data format

Cam resolution	Maximum number of cam registration	
	Cam storage area	Cam open area
256	1024	
512	1024	
1024	1024	
2048	1024	
4096	1024	
8192	512	
16384	256	
32768	128	

■Coordinate data format

Coordinate number	Maximum number of cam registration	
	Cam storage area	Cam open area
128	1024	
256	1024	
512	1024	
1024	1024	
2048	1024	
4096	512	
8192	256	
16384	128	
32768	64	
65535	32	

Cam operation specifications

Item	Specification
Operation method of cam data	(1) EM Configurator Write/read/verify to cam storage area (2) Via buffer memory (Cam data operation function) Write/read to cam storage area and cam open area
Cam auto-generation function	Automatically generate the following cams. <ul style="list-style-type: none"> • Cam for rotary cutter (central reference) • Easy stroke ratio cam • Advanced stroke ratio cam
Cam position calculation function	Calculate the cam position by the user program. Used to calculate the cam position for the synchronous control initial position before starting synchronous control.


Synchronous encoder axis specifications

Item	Specification	
Number of control axes	16	
Synchronous encoder axis type	Synchronous encoder via servo amplifier/ Synchronous encoder via buffer memory/ Synchronous encoder via link device	
Control unit	mm, inch, degree, pulse (Possible to select the decimal places of position unit and speed unit)	
Unit conversion	Numerator	-2147483648 to 2147483647 [Synchronous encoder axis position unit]
	Denominator	1 to 2147483647 [pulse]
Length per cycle setting range	1 to 2147483647 [Synchronous encoder axis position unit]	
Current value range	Current value	-2147483648 to 2147483647 [Synchronous encoder axis position unit]
	Current value per cycle	0 to (Length per cycle - 1) [Synchronous encoder axis position unit]
Control method	Control instruction	Current value change, Counter disable, Counter enable
	Current value setting address	Address setting range: -2147483648 to 2147483647 [Synchronous encoder axis position unit]

1.3 Operation Method of Synchronous Control

Synchronous control execution procedure

The synchronous control is executed using the following procedure.



*1 Page 24 INPUT AXIS MODULE
 *2 Page 53 CAM FUNCTION
 *3 Page 77 ADVANCED SYNCHRONOUS CONTROL, Page 129 Synchronous Control Initial Position Parameters
 *4 Page 162 Sample Program of Synchronous Control


Precautions

- Mechanical elements such as limit switches are considered as already installed.
- Parameter settings for positioning control apply for all axes with the Simple Motion board.
- Be sure to execute the home position return when the home position return request flag is ON.

Starting/ending for synchronous control

Set the advanced synchronous control parameters for each output axis to start synchronous control.

The status changes to synchronous control after the advanced synchronous control parameters are analyzed at the start of synchronous control, and the output axes synchronize with input axis operations.



Synchronous control system control data

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.380] Synchronous control start	<ul style="list-style-type: none"> • Synchronous control begins if the target axis bit is turned ON. • Synchronous control ends if the bit is turned OFF during synchronous control. Fetch cycle: Operation cycle	■Set the target axis in 16 bits. (bit0: axis 1 to bit15: axis 16) OFF : Synchronous control end ON : Synchronous control start	0	36320

For labels, refer to the following.

📖 Page 156 Synchronous control system control data

Starting method for synchronous control

Synchronous control can be started by turning the target axis bit from OFF to ON in "[Cd.380] Synchronous control start" after setting the advanced synchronous control parameters.

"5: Analyzing" is set in "[Md.26] Axis operation status" at the synchronous control start, and the advanced synchronous control parameters are analyzed. The BUSY signal turns ON after completion of analysis, and "15: Synchronous control" is set in "[Md.26] Axis operation status".

Start the input axis operation after confirming that "15: Synchronous control" is set in "[Md.26] Axis operation status".

Point

[API library]

To start the synchronous control, use the MMC_Axis::StartSync method.

Ending method for synchronous control

Synchronous control can be ended by turning the target axis bit from ON to OFF in "[Cd.380] Synchronous control start" after the input axis operation is stopped.

The BUSY signal turns OFF at the synchronous control end, and "0: Standby" is set in "[Md.26] Axis operation status" at the output axis stop.

Synchronous control can also be ended by turning the target axis bit from ON to OFF in "[Cd.380] Synchronous control start" during the input axis operation. However, it is recommended to end after stopping the input axis operation since the output axis stops immediately.

Refer to the following for the stop operation of output axis at the synchronous control end.

 Page 22 Stop operation of output axis

Point

[API library]

To complete the synchronous control, use the MMC_Axis::StopSync method.

Starting history

The starting history is updated when starting synchronous control. "9020: Synchronous control operation" is stored in "[Md.4] Start No.".

Status when starting synchronous control

The following bits in "[Md.31] Status" are turned OFF when starting synchronous control in the same way as for the positioning control start.

Bit	Details
b0	In speed control flag
b1	Speed-position switching latch flag
b2	Command in-position flag
b4	Home position return complete flag
b5	Position-speed switching latch flag
b10	Speed change 0 flag

Restriction

- If bit for multiple axes are turned ON simultaneously in "[Cd.380] Synchronous control start", control is not started simultaneously since the analysis is processed for each axis in numerical order. When the multiple axes must be started simultaneously, start the input axis operation after confirming that all axes are configured for the synchronous control.
- If the input axis operates during the analysis at the synchronous control start, the movement amount of the input axis is reflected immediately after the synchronous control start. The output axis might rapidly accelerate depending on the movement amount of the input axis. Start the input axis operation after confirming that are configured for synchronous control.
- The analysis process for synchronous control start might take time depending on the setting of the advanced synchronous control parameters. (When "0: Cam axis current value per cycle restoration" is set in "[Pr.462] Cam axis position restoration object" and the cam (cam resolution: 32768) is searched: 26 ms, When "0: Cam axis current value per cycle restoration" is set in "[Pr.462] Cam axis position restoration object" and the cam (cam resolution: 256) is searched: 0.4 ms) Set "1: Cam reference position restoration" or "2: Cam axis feed current value restoration" in "[Pr.462] Cam axis position restoration object" to start synchronous control at high speed.
- When the advanced synchronous control parameters are set to the value outside the setting range, the synchronous control does not start, and the input axis error No. is stored in the monitor data.

Stop operation of output axis

If the following causes occur in stopping the output axis during synchronous control, synchronous control is completed after stops processing for the output axis (BUSY signal is OFF, axis operation status is standby).

Synchronous alignment must be executed for the output axis to restart the synchronous control. (Page 109 Output Axis Module)


Stop cause	Stop process
The target axis bit of "[Cd.380] Synchronous control start" is turned from ON to OFF.	Immediate stop
Software stroke limit error occurrence	
Emergency stop	
Forced stop	
Stop group1 to 3*1 (Stop with hardware stroke limit or stop command)	Deceleration stop

*1 Refer to the following for details.

Simple Motion Board User's Manual (Application)

Immediate stop

The operation stops without decelerate. The Simple Motion board immediately stops the command, but the operation will coast for the droop pulses accumulated in the deviation counter of the servo amplifier.




Deceleration stop

The output axis stops with deceleration according to the setting in "[Pr.37] Stop group 1 rapid stop selection" to "[Pr.39] Stop group 3 rapid stop selection". The deceleration time is set in "[Pr.446] Synchronous control deceleration time" for deceleration stop, and in "[Pr.36] Rapid stop deceleration time" for rapid stop. The slope of deceleration is as follows.

$$\text{Slope of deceleration} = \frac{\text{"[Pr.8] Speed limit value"} / \text{Deceleration time}}{\text{(Rapid stop deceleration time)}}$$

The cam axis current value per cycle is not updated, and only the feed current value is updated, since the deceleration stop begins. Therefore, the path of the feed current value is drawn regardless the cam operation with deceleration stop.

The input axis must be stopped when the output axis is stop synchronizing with the input axis.



2 INPUT AXIS MODULE

The settings for the parameter and monitor data for the input axis module that used with synchronous control are explained in this chapter.

Refer to the following for details on the connection and control for the servo amplifier and the synchronous encoder that are used for input axis module.

📖 Simple Motion Board User's Manual (Application)


2.1 Servo Input Axis

Overview of servo input axis

The servo input axis is used to drive the input axis based on the position of the servomotor that is being controlled by the Simple Motion board.

The status of a servo input axis can also be monitored even before the synchronous control start since the setting of a servo input axis is valid after the system's power supply ON.

The following shows the relationship between the position of the servomotor and the servo input axis.



Control method for servo input axis

All controls (including synchronous control) can be executed for a servo input axis.

Refer to the following for the controls other than the synchronous control.

📖 Simple Motion Board User's Manual (Application)

Point

If the virtual servo amplifier function is set in the servo input axis, synchronous control can be executed by the input value as virtual.

Refer to the following for details on virtual servo amplifier function.

📖 Simple Motion Board User's Manual (Application)

If "1: Feed current value" or "2: Real current value" is set in "[Pr.300] Servo input axis type", set "1: Update feed current value" in "[Pr.21] Feed current value during speed control" to start the speed position change control. If "0: Do not update feed current value" or "2: Clear feed current value to zero" is set in [Pr.21], the error "Speed-position switching control start in servo input axis not possible" (error code: 1BA7H) will occur and the control will not start.

Units for the servo input axis

The position units and speed units for the servo input axis are shown below for the setting "[Pr.300] Servo input axis type" and "[Pr.1] Unit setting".

■ Servo input axis position units

Setting value of "[Pr.300] Servo input axis type"	Setting value of "[Pr.1] Unit setting"	Servo input axis position unit	Range
1: Feed current value 2: Real current value	0: mm	$\times 10^{-4}$ mm (10^{-1} μ m)	-214748.3648 to 214748.3647 [mm] (-214748364.8 to 214748364.7 [μ m])
	1: inch	$\times 10^{-5}$ inch	-21474.83648 to 21474.83647 [inch]
	2: degree	$\times 10^{-5}$ degree	-21474.83648 to 21474.83647 [degree]
	3: pulse	pulse	-2147483648 to 2147483647 [pulse]
3: Servo command value 4: Feedback value	—	pulse	-2147483648 to 2147483647 [pulse]

■ Servo input axis speed units

Setting value of "[Pr.300] Servo input axis type"	Setting value of "[Pr.1] Unit setting"	Servo input axis speed unit	Range
1: Feed current value 2: Real current value	0: mm	$\times 10^{-2}$ mm/min	-21474836.48 to 21474836.47 [mm/min]
	1: inch	$\times 10^{-3}$ inch/min	-2147483.648 to 2147483.647 [inch/min]
	2: degree	$\times 10^{-3}$ degree/min ^{*1}	-2147483.648 to 2147483.647 [degree/min] ^{*1}
	3: pulse	pulse/s	-2147483648 to 2147483647 [pulse/s]
3: Servo command value 4: Feedback value	—	pulse/s	-2147483648 to 2147483647 [pulse/s]

*1 When "[Pr.83] Speed control 10 x multiplier setting for degree axis" is valid, this will be the speed unit " $\times 10^{-2}$ degree/min" (Range: - 21474836.48 to 21474836.47 [degree/min]).

Point

- When "1: Feed current value" or "3: Servo command value" is set in "[Pr.300] Servo input axis type", and the servo input axis becomes servo OFF by the servo alarm or forced stop, the amount of value change may be large. This can be prevented by setting "2: Real current value" or "4: Feedback value" in "[Pr.300] Servo input axis type".
- When a home position return for the axis where "1: Feed current value" or "2: Real current value" is set in "[Pr.300] Servo input axis type" is performed, if the servo input axis operation during home position return is used as the input value, the input is stopped in the midway of home position return. When the servo input axis operation during home position return is used as the input value, set "3: Servo command value" or "4: Feedback value" in "[Pr.300] Servo input axis type".

Servo input axis parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.300] Servo input axis type	<ul style="list-style-type: none"> Set the current value type to be generated of the input value for the servo input axis. Fetch cycle: <u>At power supply ON</u>	■Set in decimal. 0: Invalid 1: Feed current value 2: Real current value 3: Servo command value 4: Feedback value	0	32800+10n
[Pr.301] Servo input axis smoothing time constant	<ul style="list-style-type: none"> Set to smooth the input value. Fetch cycle: <u>At power supply ON</u>	■Set in decimal. 0 to 5000 [ms]	0	32801+10n
[Pr.302] Servo input axis phase compensation advance time	<ul style="list-style-type: none"> Set the time to advance or delay the phase. Fetch cycle: <u>Operation cycle</u>	■Set in decimal. -2147483648 to 2147483647 [μ s]	0	32802+10n 32803+10n
[Pr.303] Servo input axis phase compensation time constant	<ul style="list-style-type: none"> Set the time constant to affect the phase compensation. Fetch cycle: <u>At power supply ON</u>	■Set in decimal. 0 to 65535 [ms] ^{*1}	10	32804+10n
[Pr.304] Servo input axis rotation direction restriction	<ul style="list-style-type: none"> Set this parameter to restrict the input movement amount to one direction. Fetch cycle: <u>At power supply ON</u>	■Set in decimal. 0: Without rotation direction restriction 1: Enable only for current value increase direction 2: Enable only for current value decrease direction	0	32805+10n

*1 Set the value as follows in a user program.
 0 to 32767: Set as a decimal.
 32768 to 65535: Convert into a hexadecimal and set.

For labels, refer to the following.


☞ Page 151 Servo input axis parameters

[Pr.300] Servo input axis type

Set the current value type to be generated of the input value for the servo input axis.


Setting value	Details
0: Invalid	Servo input axis is invalid.
1: Feed current value	Generate the input value based on "[Md.20] Feed current value".
2: Real current value	Generate the input value based on the real current value, which is converted into units of the encoder feedback pulses from the servo amplifier.
3: Servo command value	Generate the input value based on the command pulse for the servo amplifier (a value that the feed current value is converted into encoder pulse units).
4: Feedback value	Generate the input value based on the encoder feedback pulse from the servo amplifier.

Simple Motion board



[Pr.301] Servo input axis smoothing time constant

Set the averaging time to execute a smoothing process for the input movement amount from the servo input axis. The smoothing process can moderate speed fluctuation, when the "Real current value" or "Feedback value" is used as input values. The input response is delayed depending on the time corresponding to the setting by smoothing process setting.



[Pr.302] Servo input axis phase compensation advance time

Set the time to advance or delay the phase (input response) of the servo input axis. Refer to the following for the delay time inherent to the system using the servo input axis.


☞ Page 123 Phase Compensation Function

Setting value	Details
1 to 2147483647 [μ s]	Advance the phase (input response) according to the setting time.
0 [μ s]	Do not execute phase compensation.
-2147483648 to -1 [μ s]	Delay the phase (input response) according to the setting time.

If the setting time is too long, the system experiences overshoot or undershoot at acceleration/deceleration of the input speed. In this case, set longer time to affect the phase compensation amount in "[Pr.303] Servo input axis phase compensation time constant".

[Pr.303] Servo input axis phase compensation time constant

Set the time constant to affect the phase compensation amount for the first order delay. 63 [%] of the phase compensation amount are reflected in the time constant setting.



[Pr.304] Servo input axis rotation direction restriction

Set this parameter to restrict the input movement amount for the servo input axis to one direction.

This helps to avoid reverse operation caused by such as machine vibration when "Real current value" or "Feedback value" is used as input values.


Setting value	Details
0: Without rotation direction restriction	Rotation direction restriction is not executed.
1: Enable only for current value increase direction	Enable only the input movement amount in the increasing direction of the servo input axis current value.
2: Enable only for current value decrease direction	Enable only the input movement amount in the decreasing direction of the servo input axis current value.

The input movement amount in the reverse direction of the enabled direction accumulates as a rotation direction restricted amount, and will be reflected when the input movement amount moves in the enabled direction again. Therefore, the current value of servo input does not deviate when the reverse operation is repeated.

The rotation direction restricted amount is set to 0 when the following operations are executed for the servo input axis.

- A servo amplifier is connected
- The home position return is executed
- The current value is changed

For "1: Enable only for current value increase direction" is set in "[Pr.304] Servo input axis rotation direction restriction".



Servo input axis monitor data

n: Axis No. - 1

Monitor item	Storage details	Monitor value	Buffer memory address
[Md.300] Servo input axis current value	<ul style="list-style-type: none"> The current value for the servo input axis is stored. Refresh cycle: Operation cycle	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Servo input axis position units ^{*1}]	33120+10n 33121+10n
[Md.301] Servo input axis speed	<ul style="list-style-type: none"> The speed for the servo input axis is stored. Refresh cycle: Operation cycle	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Servo input axis speed units ^{*2}]	33122+10n 33123+10n
[Md.302] Servo input axis phase compensation amount	<ul style="list-style-type: none"> The current phase compensation amount is stored. Refresh cycle: Operation cycle	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Servo input axis position units ^{*1}]	33124+10n 33125+10n
[Md.303] Servo input axis rotation direction restriction amount	<ul style="list-style-type: none"> While the rotation direction is restricted, the accumulation for the input movement amount in the opposite direction of the enabled direction is stored. Refresh cycle: Operation cycle	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Servo input axis position units ^{*1}]	33126+10n 33127+10n

*1 Servo input axis position units ( Page 25 Servo input axis position units)

*2 Servo input axis speed units ( Page 25 Servo input axis speed units)

For labels, refer to the following.

 Page 155 Servo input axis monitor data

[Md.300] Servo input axis current value

The current value for the servo input axis is stored in servo input axis position units ( Page 25 Servo input axis position units) as follows.

The current value for the servo input axis is the value after processing the smoothing, the phase compensation and the rotation direction restriction.

Setting value of "[Pr.300] Servo input axis type"	Storage details
1: Feed current value 2: Real current value	<ul style="list-style-type: none"> The accumulative current value started with "[Md.20] Feed current value"/"[Md.101] Real current value" for the connection to the servo amplifier is stored. It is also stored in the range from -21474.83648 to 21474.83647 [degree] for degree units. When the "[Md.20] Feed current value"/"[Md.101] Real current value" is changed by the home position return or the current value change, the value is changed to the new current value.
3: Servo command value 4: Feedback value	<ul style="list-style-type: none"> When of the absolute position detection system setting is invalid, the accumulative current value that starts from 0 for the connected servo amplifier is stored. When of the absolute position detection system setting is valid, the accumulative current value that starts from the absolute position command/encoder feedback pulse for the connected servo amplifier is stored. The servo input axis current value will not change, even if the home position return or the current value is changed.

[Md.301] Servo input axis speed

The speed for the servo input axis is stored in servo input axis speed units ( Page 25 Servo input axis speed units).

The speed for the servo input axis is the value after processing smoothing, phase compensation, and rotation direction restriction.

[Md.302] Servo input axis phase compensation amount

The phase compensation amount for a servo input axis is stored in servo input axis position units ( Page 25 Servo input axis position units).

The phase compensation amount for a servo input axis is the value after processing smoothing and phase compensation.

[Md.303] Servo input axis rotation direction restriction amount

While the rotation direction is restricted for a servo input axis, the accumulation for input movement amount in the opposite direction of the enabled direction is stored in servo input axis position units ( Page 25 Servo input axis position units) as follows.

Setting value of "[Pr.304] Servo input axis rotation direction restriction"	Storage details
1: Enable only for current value increase direction	A negative accumulation is stored during rotation direction restriction. 0 is stored if there is no restriction.
2: Enable only for current value decrease direction	A positive accumulation is stored during rotation direction restriction. 0 is stored if there is no restriction.


Rotation direction restriction is processed after phase compensation processing. Therefore, if undershoot occurs from phase compensation during deceleration stop, the rotation direction restriction amount might remain.

2.2 Synchronous Encoder Axis

Overview of synchronous encoder axis

The synchronous encoder is used to drive the input axis based on input pulse from a synchronous encoder that is connected externally.

The status of a synchronous encoder axis can also be monitored after the system's power supply turns ON.



Synchronous encoder axis type

The following 3 types of synchronous encoders can be used for the synchronous encoder axis.

Refer to the following for the setting method for each synchronous encoder axis.

☞ Page 34 Setting method for synchronous encoder

Synchronous encoder axis type	Details
Synchronous encoder via servo amplifier	Used to use a synchronous encoder connected to the servo amplifier which supports the scale measurement mode as a synchronous encoder axis.
Synchronous encoder via buffer memory	Used to operate an encoder that is connected to such as another brand input board of the host personal computer as a synchronous encoder axis.
Synchronous encoder via link device	Used to use an incremental synchronous encoder, etc. connected to the high-speed counter module on the CC-Link IE Field Network as a synchronous encoder axis.

Control method for synchronous encoder axis

The following controls can be executed for the synchronous encoder axis by using "[Cd.320] Synchronous encoder axis control start" and "[Cd.321] Synchronous encoder axis control method".

Setting value of "[Cd.321] Synchronous encoder axis control method"	Control details
0: Current value change	"[Md.320] Synchronous encoder axis current value" and "[Md.321] Synchronous encoder axis current value per cycle" are changed based on the setting of "[Cd.322] Synchronous encoder axis current value setting address".
1: Counter disable	Input from the synchronous encoder is disabled.
2: Counter enable	Input from the synchronous encoder is enabled.

Units for the synchronous encoder axis

The position units and speed units for the synchronous encoder axis are shown below for the setting of "[Pr.321] Synchronous encoder axis unit setting".

■ Synchronous encoder axis position units

Setting value of "[Pr.321] Synchronous encoder axis unit setting"		Synchronous encoder axis position unit	Range
Control unit	Number of decimal places for position		
0: mm	0	mm	-2147483648 to 2147483647 [mm]
	∴	∴	∴
	9	$\times 10^{-9}$ mm	-2.147483648 to 2.147483647 [mm]
1: inch	0	inch	-2147483648 to 2147483647 [inch]
	∴	∴	∴
	9	$\times 10^{-9}$ inch	-2.147483648 to 2.147483647 [inch]
2: degree	0	degree	-2147483648 to 2147483647 [degree]
	∴	∴	∴
	9	$\times 10^{-9}$ degree	-2.147483648 to 2.147483647 [degree]
3: pulse	0	pulse	-2147483648 to 2147483647 [pulse]
	∴	∴	∴
	9	$\times 10^{-9}$ pulse	-2.147483648 to 2.147483647 [pulse]

■ Synchronous encoder axis speed units

Setting value of "[Pr.321] Synchronous encoder axis unit setting"			Synchronous encoder axis speed unit	Range
Control unit	Speed time unit	Number of decimal places for speed		
0: mm	0: second [s]	0	mm/s	-2147483648 to 2147483647 [mm/s]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ mm/s	-2.147483648 to 2.147483647 [mm/s]
	1: minute [min]	0	mm/min	-2147483648 to 2147483647 [mm/min]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ mm/min	-2.147483648 to 2.147483647 [mm/min]
1: inch	0: second [s]	0	inch/s	-2147483648 to 2147483647 [inch/s]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ inch/s	-2.147483648 to 2.147483647 [inch/s]
	1: minute [min]	0	inch/min	-2147483648 to 2147483647 [inch/min]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ inch/min	-2.147483648 to 2.147483647 [inch/min]
2: degree	0: second [s]	0	degree/s	-2147483648 to 2147483647 [degree/s]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ degree/s	-2.147483648 to 2.147483647 [degree/s]
	1: minute [min]	0	degree/min	-2147483648 to 2147483647 [degree/min]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ degree/min	-2.147483648 to 2.147483647 [degree/min]
3: pulse	0: second [s]	0	pulse/s	-2147483648 to 2147483647 [pulse/s]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ pulse/s	-2.147483648 to 2.147483647 [pulse/s]
	1: minute [min]	0	pulse/min	-2147483648 to 2147483647 [pulse/min]
		⋮	⋮	⋮
		9	$\times 10^{-9}$ pulse/min	-2.147483648 to 2.147483647 [pulse/min]

Setting method for synchronous encoder

Synchronous encoder via servo amplifier

There are restrictions in the function and the encoder that can be used by the version of the servo amplifier.

■Setting method

Used to use a synchronous encoder connected to the servo amplifier which supports the scale measurement mode as a synchronous encoder axis.

The following servo amplifiers can be used. The servo amplifier must support the scale measurement function.

- MR-J4-GF-RJ

Only a rotary encoder can be connected. Refer to the following servo amplifier instruction manuals for the version of the servo amplifier which supports the scale measurement function and the rotary encoder which can be used.

📖MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)

A synchronous encoder connected to the specified servo amplifier axis can be used by the following settings.

Setting item	Setting method
Synchronous encoder axis setting	Set "101 to 116: Synchronous encoder via servo amplifier (Connectable servo amplifier: axis 1 to axis 16)" in "[Pr.320] Synchronous encoder axis type". [Setting method of EM Configurator] Set the synchronous encoder axis parameter according to the setting below. <ul style="list-style-type: none">• "[Pr.320] Type" 101: Synchronous encoder via servo amplifier <ul style="list-style-type: none">• "[Pr.320] Axis No. of connected servo amplifier" Axis No. of servo amplifier to connect
Encoder type setting (Absolute/Incremental)	Set the servo parameter "Scale measurement mode selection (PA22)" according to the setting below. 0___H: Disabled 1___H: Used in absolute position detection system 2___H: Used in incremental system

When "1___H" is set in the servo parameter "Scale measurement mode selection (PA22)", the synchronous encoder axis current value and the synchronous encoder axis current value per cycle are restored after the servo amplifier axis is connected. Therefore, connection becomes valid, and will be on the counter enabling status. (The current value setting by current value change is required beforehand.)

When "2___H" is set in the servo parameter "Scale measurement mode selection (PA22)", "0" is set to the initial value of the synchronous encoder axis current value and the synchronous encoder axis current value per cycle after the servo amplifier axis is connected. Therefore, connection becomes valid, and will be on the counter enabling status.

If the corresponding servo amplifier axis is not connected, the connection of the synchronous encoder axis will be invalid.

Point

When "1___H" is set in the servo parameter "Scale measurement mode selection (PA22)" and the synchronous encoder movement amount (encoder pulse units) on disconnection or during the power supply OFF exceeds "2147483647" or "-2147483648", the synchronous encoder axis current value is restored with its opposite sign.

Point of the setting method

- When the servo parameter "Scale measurement mode selection (PA22)" is changed, it is required to switch the power of servo amplifier off once after the parameter is transferred to the servo amplifier, and then switch it on again.
- If the servo amplifier set by the servo parameter "Scale measurement mode selection (PA22)" does not support the "Scale measurement mode", "AL.37" (parameter error) will occur in the servo amplifier. Refer to the servo amplifier instruction manual for details of the servo parameter "Scale measurement mode selection (PA22)".
- The following information of the synchronous encoder via servo amplifier can be output with servo cyclic transmission function and servo transient transmission function. For the detail of CiA402 objects to be set, refer to the manual of the slave device.

Information of synchronous encoder


Load side encoder information 1

Load side encoder information 2

- A serial absolute synchronous encoder Q171ENC-W8 can be used in an incremental system by setting "2__H" in the servo parameter "Scale measurement mode selection (PA22)" even if the battery of the servo amplifier is dismantled.

Setting example

The following shows an example for setting a serial absolute synchronous encoder Q171ENC-W8 using MR-J4-GF-RJ as synchronous encoder axis 1 of the Simple Motion board.



Set the parameters as below.

- Set "101: Synchronous encoder via servo amplifier (servo amplifier axis 3)" in "[Pr.320] Synchronous encoder axis type" of synchronous encoder axis 1.
- Set "MR-J4 series" in "[Pr.100] Connected device" of the axis to connect Q171ENC-W8.
- Set "1__H" in the servo parameter "Function selection C-8 (PC26)".

Restrictions

- The servo amplifier axis selected as "Synchronous encoder via servo amplifier" in "[Pr.320] Synchronous encoder axis type" does not operate in the fully closed control mode even though "__1_H" is set in the servo parameter "Operation mode selection (PA01)".
- When the servo alarms about the serial absolute synchronous encoder connection occur in the servo amplifier axis selected as "Synchronous encoder via servo amplifier" in "[Pr.320] Synchronous encoder axis type", the status becomes servo OFF. "AL.25" (Absolute position erased), "AL.70" (Load-side encoder initial communication error 1), or "AL.71" (Load-side encoder normal communication error 1) occurs in the servo amplifier.
- The error "Synchronous encoder via servo amplifier invalid error" (error code: 1BAAH) occurs in the following cases.
 - The "[Pr.100] Connected device" of the axis No. selected as "Synchronous encoder via servo amplifier" in "[Pr.320] Synchronous encoder axis type" is not set or the servo axis, which scale measurement mode is not enabled, is set to the servo amplifier axis No. to connect to "Synchronous encoder via servo amplifier".
 - A linear scale is connected.

Synchronous encoder via buffer memory (Synchronous encoder via host personal computer)

■Setting method

Used to operate an encoder that is connected to such as another brand input board of the host personal computer as a synchronous encoder axis.

By setting "201: Synchronous encoder via buffer memory" in "[Pr.320] Synchronous encoder axis type", the synchronous encoder is controlled by the encoder value which is the input value of "[Cd.325] Input value for synchronous encoder via buffer memory".

The encoder value can be used as a cycle counter within the range from 0 to (Resolution of synchronous encoder via buffer memory - 1).


Connection is invalid just after the system's power supply is ON. When "1" is set in "[Cd.324] Connection command of synchronous encoder via buffer memory", the synchronous encoder axis current value and the synchronous encoder axis current value per cycle are restored based on "[Cd.325] Input value for synchronous encoder via buffer memory". Therefore, connection becomes valid, and will be on the counter enabling status.

The synchronous encoder axis is controlled based on the amount of change of "[Cd.325] Input value for synchronous encoder via buffer memory" while it is connecting.

■Setting example

The following shows an example for setting a synchronous encoder via buffer memory as synchronous encoder axis 4 of the Simple Motion board.

(Resolution of the encoder: 4096 pulses/rev)



Set "201: Synchronous encoder via buffer memory" in "[Pr.320] Synchronous encoder axis type" of synchronous encoder axis 4.

Set "4096" in "[Pr.329] Resolution of synchronous encoder via buffer memory" of synchronous encoder axis 4.

Read the encoder value of the encoder with a user program, and update "[Cd.325] Input value for synchronous encoder via buffer memory" of the synchronous encoder axis 4 at every time.

Restrictions

- "[Cd.325] Input value for synchronous encoder via buffer memory" is taken every operation cycle, but it is asynchronous with the process cycle of the user program. Therefore, speed fluctuation of the synchronous encoder axis becomes larger if the refresh cycle of "[Cd.325] Input value for synchronous encoder via buffer memory" becomes long. Update "[Cd.325] Input value for synchronous encoder via buffer memory" at the timing of the operation cycle interrupt or in a cycle less than the operation cycle, or use smooth speed fluctuation with the smoothing function.
- The synchronous encoder current value that is restored for the synchronous encoder connection gets restored into a converted value from the following range based on the synchronous encoder movement amount on disconnection.

Setting value of "[Pr.329] Resolution of synchronous encoder via buffer memory"	Range of restored synchronous encoder current value
1 or more	$-(\text{Resolution of synchronous encoder via buffer memory} / 2) \text{ to } (\text{Resolution of synchronous encoder via buffer memory} / 2 - 1) \text{ [pulse]}^{*1}$
0 or less	-2147483648 to 2147483647 [pulse]

*1 If the resolution of a synchronous encoder via buffer memory is an odd number, round down a negative value after the decimal point, round up a positive value after decimal point.

Synchronous encoder via link device

Setting method

Used to operate an incremental synchronous encoder that is connected to the high-speed counter module on the CC-Link IE Field Network as a synchronous encoder axis.

By setting "301: Synchronous encoder via link device" in "[Pr.320] Synchronous encoder axis type", the link device assigned to the synchronous encoder input axis can be used by the link device external signal assignment function.


The status is set to the counter disable just after a link is established. The synchronous encoder axis current value and the synchronous encoder axis current value per cycle are restored based on the link device value assigned to the synchronous encoder input axis. Therefore, connection becomes valid.

The synchronous encoder axis is controlled based on the amount of change of the link device value assigned to the synchronous encoder input axis while it is connecting.

Setting example

The following shows an example for setting a synchronous encoder via link device as synchronous encoder axis 4 of the Simple Motion board.

- Assign the link device to the synchronous encoder input using the link device external signal assignment function.
- Set "301: Synchronous encoder via link device" in "[Pr.320] Synchronous encoder axis type" of synchronous encoder axis 4.



The following shows an example for operating CH1 of the high-speed counter module (NZ2GFCF-D62PD2) as the ring counter to use as synchronous encoder input. For the specification and usage methods of the high-speed counter module, refer to the following manual.

 CC-Link IE Field Network High-Speed Counter Module User's Manual

Setting item	Setting value	Setting details
[Pr.710] Synchronous encoder axis: Link device type	0033H	Specify the remote register RWr10 (2 words) which stores the "current value" of the counter module.
[Pr.711] Synchronous encoder axis: Link device start No.	0010H	
[Pr.712] Synchronous encoder axis: Link device count direction setting	0	The encoder current value moves toward the positive direction by the count-up pulse.
[Pr.713] Synchronous encoder axis: Ring counter maximum value	360000	Set the upper limit of the ring counter to 360000. (Set the value to match with the setting value of RWw12 to RWw13.)
[Pr.714] Synchronous encoder axis: Ring counter minimum value	0	Set the lower limit of the ring counter to 0. (Set the value to match with the setting value of RWw10 to RWw11.)

■ Restrictions

- When using the link device, the fetch timing of the signal disperses in one link scan cycle.
- Set the movement amount per link scan so that the following formula is satisfied. If not, the actual movement amount of the synchronous encoder and the movement amount counted by the Simple Motion board might not be matched.

$$\text{Movement amount per link scan} < \frac{|(\text{Ring counter maximum value}) - (\text{Ring counter minimum value}) + 1|}{2}$$


Ex.

When using the high-speed counter module shown the setting example above, set the movement amount per link scan to 180000 or less.

$$\text{Movement amount per link scan} < \frac{|360000 - 0 + 1|}{2} = 180000.5$$

Synchronous encoder axis parameters

j: Synchronous encoder axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.320] Synchronous encoder axis type	<ul style="list-style-type: none"> Set the synchronous encoder axis type to be used. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 0: Invalid 101 to 116: Synchronous encoder via servo amplifier (Connectable servo amplifier: Axis 1 to axis 16) 201: Synchronous encoder via buffer memory 301: Synchronous encoder via link device 	0	34720+20j
[Pr.321] Synchronous encoder axis unit setting	<ul style="list-style-type: none"> Set the unit of the synchronous encoder axis. Set the position unit within the range from $\times 1$ to 10^{-9} [control unit]. Set the speed unit within the range from $\times 1$ to 10^{-9} [control unit/s or control unit/min]. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in hexadecimal. 	0003H	34721+20j
[Pr.322] Synchronous encoder axis unit conversion: Numerator	<ul style="list-style-type: none"> Set the numerator to convert the unit from the encoder pulse of the synchronous encoder axis into the synchronous encoder axis unit. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. -2147483648 to 2147483647 [Synchronous encoder axis position units^{*1}] 	1	34722+20j 34723+20j
[Pr.323] Synchronous encoder axis unit conversion: Denominator	<ul style="list-style-type: none"> Set the denominator to convert the unit from the encoder pulse of the synchronous encoder axis into the synchronous encoder axis unit. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 1 to 2147483647 [pulse] 	1	34724+20j 34725+20j
[Pr.324] Synchronous encoder axis length per cycle	<ul style="list-style-type: none"> Set the length per cycle of the synchronous encoder axis. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 1 to 2147483647 [Synchronous encoder axis position units^{*1}] 	4000	34726+20j 34727+20j
[Pr.325] Synchronous encoder axis smoothing time constant	<ul style="list-style-type: none"> Set the time to smooth for the input value. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 0 to 5000 [ms] 	0	34728+20j
[Pr.326] Synchronous encoder axis phase compensation advance time	<ul style="list-style-type: none"> Set the time to advance or delay the phase. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. -2147483648 to 2147483647 [μs] 	0	34730+20j 34731+20j
[Pr.327] Synchronous encoder axis phase compensation time constant	<ul style="list-style-type: none"> Set the time constant to affect the phase compensation. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 0 to 65535 [ms]^{*2} 	10	34732+20j
[Pr.328] Synchronous encoder axis rotation direction restriction	<ul style="list-style-type: none"> Set this parameter to restrict the input movement amount to one direction. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 0: Without rotation direction restriction 1: Enable only for current value increase direction 2: Enable only for current value decrease direction 	0	34733+20j
[Pr.329] Resolution of synchronous encoder via buffer memory	<ul style="list-style-type: none"> Set the resolution of the synchronous encoder when the synchronous encoder axis type is set to synchronous encoder via buffer memory. If 0 or less is set, the input value of synchronous encoder via buffer memory is processed as 32-bit counter. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. -2147483648 to 2147483647 [pulse] 	0	34734+20j 34735+20j

*1 Synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units)

*2 Set the value as follows in a user program.

0 to 32767: Set as a decimal

32768 to 65535: Convert into a hexadecimal and set

For labels, refer to the following.

 Page 151 Synchronous encoder axis parameters

[Pr.320] Synchronous encoder axis type

Set the synchronous encoder type to be generated of the input value for the synchronous encoder axis.

Setting value	Details
0: Invalid	Synchronous encoder axis is invalid.
101 to 116: Synchronous encoder via servo amplifier (Connectable servo amplifier: Axis 1 to axis 16)	Generate the input value based on the synchronous encoder input via servo amplifier connected to the specified servo amplifier (axis 1 to axis 16).
201: Synchronous encoder via buffer memory	Generate the input value with the value set in the buffer memory by the host personal computer as the encoder value.
301: Synchronous encoder via link device	Use an arbitrary value of link device as synchronous encoder input.

[Pr.321] Synchronous encoder axis unit setting

Set the position and speed unit of the synchronous encoder axis. Refer to the following for details.

 Page 32 Units for the synchronous encoder axis

[Pr.322] Synchronous encoder axis unit conversion: Numerator

The input movement amount of synchronous encoder is configured in encoder pulse units.

The units can be arbitrarily converted through unit conversation with setting [Pr.322] and [Pr.323].

Set [Pr.322] and [Pr.323] according to the controlled machine.

$$\begin{array}{l} \text{Synchronous encoder axis} \\ \text{movement amount (Movement} \\ \text{amount after unit conversion)} \end{array} = \begin{array}{l} \text{Synchronous encoder input} \\ \text{movement amount} \\ \text{(Encoder pulse units)} \end{array} \times \frac{\text{"[Pr.322] Synchronous encoder axis unit conversion: Numerator"}}{\text{"[Pr.323] Synchronous encoder axis unit conversion: Denominator"}}$$

The movement amount corresponding to "[Pr.323] Synchronous encoder axis unit conversion: Denominator" is set in "[Pr.322] Synchronous encoder axis unit conversion: Numerator" in synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units). The input movement amount can be reversed by the setting negative values. Set "[Pr.323] Synchronous encoder axis unit conversion: Denominator" based on encoder pulse units from the synchronous encoder. Set a value within the range from 1 to 2147483647.

[Pr.323] Synchronous encoder axis unit conversion: Denominator

The input movement amount of synchronous encoder is configured in encoder pulse units.

The units can be arbitrarily converted through unit conversation with setting [Pr.322] and [Pr.323].

Set [Pr.322] and [Pr.323] according to the controlled machine.

$$\begin{array}{l} \text{Synchronous encoder axis} \\ \text{movement amount (Movement} \\ \text{amount after unit conversion)} \end{array} = \begin{array}{l} \text{Synchronous encoder input} \\ \text{movement amount} \\ \text{(Encoder pulse units)} \end{array} \times \frac{\text{"[Pr.322] Synchronous encoder axis unit conversion: Numerator"}}{\text{"[Pr.323] Synchronous encoder axis unit conversion: Denominator"}}$$

The movement amount corresponding to "[Pr.323] Synchronous encoder axis unit conversion: Denominator" is set in "[Pr.322] Synchronous encoder axis unit conversion: Numerator" in synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units). The input movement amount can be reversed by the setting negative values. Set "[Pr.323] Synchronous encoder axis unit conversion: Denominator" based on encoder pulse units from the synchronous encoder. Set a value within the range from 1 to 2147483647.

[Pr.324] Synchronous encoder axis length per cycle

Set the length per cycle for the synchronous encoder axis current value per cycle.

The current value of synchronous encoder axis is stored in "[Md.321] Synchronous encoder axis current value per cycle" at ring counter based on the setting value.

The unit settings are in synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units).


Set a value within the range from 1 to 2147483647.

Setting example of the unit conversion and the length per cycle.

The following shows an example a rotary encoder is connected which resolution is 4000 [pulse/rev] to the motor axis side on the rotation table that drives by 1/5 pulley system, and the control unit is degree.

- Position unit: 0.1 [degree]
- Speed unit: 0.001 [degree/min]
- Length per cycle: 360.0 [degree] (1 cycle of the rotation table)

Setting item	Setting details	Setting value	
[Pr.321] Synchronous encoder axis unit setting	Control unit	2: degree	3112H
	Number of decimal places for position	1	
	Speed time unit	1: minute [min]	
	Number of decimal places for speed	3	
[Pr.322] Synchronous encoder axis unit conversion: Numerator	360.0 [degree] × 1	3600 [× 0.1 degree]	
[Pr.323] Synchronous encoder axis unit conversion: Denominator	4000 [pulse] × 5	20000 [pulse]	
[Pr.324] Synchronous encoder axis length per cycle	360.0 [degree]	3600 [× 0.1 degree]	




[Pr.325] Synchronous encoder axis smoothing time constant

Set the averaging time to execute a smoothing process for the input movement amount from synchronous encoder.

The smoothing process can moderate speed fluctuation of the synchronous encoder input.

The input response is delayed depending on the time corresponding to the setting by smoothing process setting.



[Pr.326] Synchronous encoder axis phase compensation advance time

Set the time to advance or delay the phase (input response) of the synchronous encoder axis.

Refer to the following for the delay time inherent to the system using the synchronous encoder axis.

☞ Page 123 Phase Compensation Function


Setting value	Details
1 to 2147483647 [μ s]	Advance the phase (input response) according to the setting time.
0 [μ s]	Do not execute phase compensation.
-2147483648 to -1 [μ s]	Delay the phase (input response) according to the setting time.

If the setting time is too long, the system experiences overshoot or undershoot at acceleration/deceleration of the input speed. In this case, set a longer time to affect the phase compensation amount in "[Pr.327] Synchronous encoder axis phase compensation time constant".

[Pr.327] Synchronous encoder axis phase compensation time constant

Set the time constant to affect the phase compensation amount for the first order delay.

63 [%] of the phase compensation amount are reflected in the time constant setting.



[Pr.328] Synchronous encoder axis rotation direction restriction


Set this parameter to restrict the input movement amount for the synchronous encoder axis to one direction. This helps to avoid reverse operation caused by such as machine vibration of the synchronous encoder input.

Setting value	Details
0: Without rotation direction restriction	Rotation direction restriction is not executed.
1: Enable only for current value increase direction	Enable only the input movement amount in the increasing direction of the synchronous encoder axis current value.
2: Enable only for current value decrease direction	Enable only the input movement amount in the decreasing direction of the synchronous encoder axis current value.

The input movement amount in the reverse direction of the enabled direction accumulates as a rotation direction restricted amount, and it will be reflected when the input movement amount moves in the enabled direction again. Therefore, the current value of synchronous encoder axis does not deviate when the reverse operation is repeated.

The rotation direction restricted amount is set to 0 at the synchronous encoder axis connection and current value change.

For "1: Enable only for current value increase direction" is set in "[Pr.328] Synchronous encoder axis rotation direction restriction".



[Pr.329] Resolution of synchronous encoder via buffer memory

Set the resolution of connected synchronous encoder when "201: Synchronous encoder via buffer memory" is set in "[Pr.320] Synchronous encoder axis type".

If 1 or more is set, "[Cd.325] Input value for synchronous encoder via buffer memory" is processed as the cycle counter within the range from 0 to (resolution of synchronous encoder via buffer memory - 1).

If 0 or less is set, "[Cd.325] Input value for synchronous encoder via buffer memory" is processed as 32 bit counter within the range from -2147483648 to 2147483647.

Point

If 1 or more is set in "[Pr.329] Resolution of synchronous encoder via buffer memory", set the cycle counter within the range from 0 to (resolution of synchronous encoder via buffer memory - 1) as the input value in "[Cd.325] Input value for synchronous encoder via buffer memory".

Synchronous encoder axis parameters via link device

j: Synchronous encoder axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.710] Synchronous encoder axis: Link device type	<ul style="list-style-type: none"> Set link device type for use. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in hexadecimal. Other than below: Invalid 21H: RX (1 word) 22H: RY (1 word) 23H: RWr (1 word) 24H: RWw (1 word) 31H: RX (2 words) 32H: RY (2 words) 33H: RWr (2 words) 34H: RWw (2 words) 	0000H	35520+20j
[Pr.711] Synchronous encoder axis: Link device start No.	<ul style="list-style-type: none"> Set link device No. for use. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in hexadecimal. 0 to 1FFFFH 	1000H	35521+20j
[Pr.712] Synchronous encoder axis: Link device count direction setting	<ul style="list-style-type: none"> Set the relationship between link device count direction and assignment signal count direction. (Valid for only 0th bit) <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 0: Plus count (The signal will also be plus counted while the link device is plus count.) 1: Minus count (The signal will be minus counted while the link device is plus count.) 	0	34526+20j
[Pr.713] Synchronous encoder axis: Ring counter maximum value	<ul style="list-style-type: none"> Set the maximum and minimum value when the link device value is ring counter. When the ring counter maximum value is equal to the ring counter minimum value, the setting depends on the link device type setting. When the link device type is a 1-word device and a value outside the range of 1 word is set, the setting is ignored. (-32768 to 32767) 	<ul style="list-style-type: none"> Set in decimal. 1 word: -32768 to 32767 2 words: -2147483648 to 2147483647 	0	35522+20j 35523+20j
[Pr.714] Synchronous encoder axis: Ring counter minimum value	<ul style="list-style-type: none"> When the ring counter maximum value is smaller than the ring counter minimum value, the error "Outside the link device maximum/minimum value specification range" (error code: 1CC2H) occurs. <u>Fetch cycle: At power supply ON</u>			35524+20j 35525+20j
[Pr.1010] Synchronous encoder axis start request: Link device type	<ul style="list-style-type: none"> Set link device type for use. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in hexadecimal. Other than below: Invalid 11H: RX (1 bit) 12H: RY (1 bit) 13H: RWr (1 bit) 14H: RWw (1 bit) 	0000H	35530+20j
[Pr.1011] Synchronous encoder axis start request: Link device start No.	<ul style="list-style-type: none"> Set link device No. for use. <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in hexadecimal. 0 to 1FFFFH 	0000H	35531+20j
[Pr.1012] Synchronous encoder axis start request: Link device bit specification	<ul style="list-style-type: none"> Set the bit No. that used in occasion when "13H: RWr (1 bit)" and "14H: RWw (1 bit)" had been set to "[Pr.1010] Link device type". <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in hexadecimal. 00H to 0FH 	0000H	35532+20j
[Pr.1013] Synchronous encoder axis start request: Link device logic setting	<ul style="list-style-type: none"> Set the logic for assignment signal. (Valid for only 0th bit) <u>Fetch cycle: At power supply ON</u>	<ul style="list-style-type: none"> Set in decimal. 0: Negative logic 1: Positive logic 	0	35533+20j

For labels, refer to the following.

 Page 152 Synchronous encoder axis parameters via link device

- Set [Pr.710] to [Pr.714] when an arbitrary value of link device is used as synchronous encoder input.
- Set [Pr.1010] to [Pr.1013] when an arbitrary value of link device is used as synchronous encoder axis start request.

[Pr.710] Synchronous encoder axis: Link device type

Set link device type for use.

Other than below: Invalid

21H: RX (1 word)

22H: RY (1 word)

23H: RWr (1 word)

24H: RWw (1 word)

31H: RX (2 words)

32H: RY (2 words)

33H: RWr (2 words)

34H: RWw (2 words)

[Pr.711] Synchronous encoder axis: Link device start No.

Set link device No. for use.

If the link device No. out of the range is set, the error "Outside link device start No. range" (error code: 1CC0H) occurs and the synchronous encoder input via link device cannot be used.

[Pr.712] Synchronous encoder axis: Link device count direction setting

Set the relationship between link device count direction and assignment signal count direction.

(Valid for only 0th bit)

0: Plus count (The signal will also be plus counted while the link device is plus count.)

1: Minus count (The signal will be minus counted while the link device is plus count.)

[Pr.713] Synchronous encoder axis: Ring counter maximum value

Set the maximum value when the link device value is ring counter.

[When the link device type is set to 1 word]

The maximum value: 32767

[When the link device type is set to 2 words]

The maximum value: 2147483647

- When the ring counter maximum value is equal to the ring counter minimum value, the setting depends on the link device type setting.
- When the link device type is a 1-word device and a value outside the range of 1 word is set, the setting is ignored.
- When the ring counter maximum value is smaller than the ring counter minimum value, the error "Outside the link device maximum/minimum value specification range" (error code: 1CC2H) occurs.

[Pr.714] Synchronous encoder axis: Ring counter minimum value

Set the minimum value when the link device value is ring counter.

[When the link device type is set to 1 word]

The minimum value: -32768

[When the link device type is set to 2 words]

The minimum value: -2147483648

- When the ring counter maximum value is equal to the ring counter minimum value, the setting depends on the link device type setting.
- When the link device type is a 1-word device and a value outside the range of 1 word is set, the setting is ignored.
- When the ring counter maximum value is smaller than the ring counter minimum value, the error "Outside the link device maximum/minimum value specification range" (error code: 1CC2H) occurs.

[Pr.1010] Synchronous encoder axis start request: Link device type

Set link device type for use.

Other than below: Invalid

11H: RX (1 bit)

12H: RY (1 bit)

13H: RWr (1 bit)

14H: RWw (1 bit)

[Pr.1011] Synchronous encoder axis start request: Link device start No.

Set link device No. for use.

If the link device No. out of the range is set, the error "Outside link device start No. range" (error code: 1CC0H) occurs and the synchronous encoder axis start via link device cannot be used.

[Pr.1012] Synchronous encoder axis start request: Link device bit specification

Set the bit No. that used in occasion when "13H: RWr (1 bit)" and "14H: RWw (1 bit)" had been set to "[Pr.1010] Link device type".

Setting range: 00H to 0FH

If the value out of the range is set, the error "Outside the link device bit specification range" (error code: 1CC1H) occurs and the synchronous encoder axis start via link device cannot be used.

[Pr.1013] Synchronous encoder axis start request: Link device logic setting

Set the logic for assignment signal.

(Valid for only 0th bit)

0: Negative logic

1: Positive logic

Synchronous encoder axis control data

j: Synchronous encoder axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.320] Synchronous encoder axis control start	<ul style="list-style-type: none"> If set to "1", the synchronous encoder axis control is started. If set to "201", the synchronous encoder axis control starts based on the synchronous encoder axis control request. The Simple Motion board resets the value to "0" automatically after completion of the synchronous encoder axis control. Fetch cycle: <u>Operation cycle</u>	■Set in decimal. 1: Start for synchronous encoder axis control 201: Start request for synchronous encoder axis control (link device)	0	35040+10j
[Cd.321] Synchronous encoder axis control method	<ul style="list-style-type: none"> Set the control method for the synchronous encoder axis. Fetch cycle: <u>At synchronous encoder axis control start</u>	■Set in decimal. 0: Current value change 1: Counter disable 2: Counter enable	0	35041+10j
[Cd.322] Synchronous encoder axis current value setting address	<ul style="list-style-type: none"> Set a new current value for changing the current value. Fetch cycle: <u>At synchronous encoder axis control start</u>	■Set in decimal. -2147483648 to 2147483647 [Synchronous encoder axis position units ^{*2}]	0	35042+10j 35043+10j
[Cd.323] Synchronous encoder axis error reset	<ul style="list-style-type: none"> If set to "1" for resetting error and warning for the synchronous encoder axis, the error No. and warning No. are set to 0, and the error detection and warning detection bits status are turned OFF. The Simple Motion board resets the value to "0" automatically after completion of the error reset. In the case of the synchronous encoder axis parameter error, even if the error is reset, the setting valid flag of the synchronous encoder axis status has been OFF. Fetch cycle: <u>Main cycle</u> ^{*1}	■Set in decimal. 1: Error reset request	0	35044+10j
[Cd.324] Connection command of synchronous encoder via buffer memory	<ul style="list-style-type: none"> If set to "1", the synchronous encoder via buffer memory is connected. If set to "0", the synchronous encoder via buffer memory is disconnected. Fetch cycle: <u>Main cycle</u> ^{*1}	■Set in decimal. 1: Connect synchronous encoder via buffer memory 0: Disconnect synchronous encoder via buffer memory	0	35045+10j
[Cd.325] Input value for synchronous encoder via buffer memory	<ul style="list-style-type: none"> Set a value to be used every time as the input value for the synchronous encoder for the synchronous encoder via buffer memory. Fetch cycle: <u>Operation cycle</u>	■Set in decimal. -2147483648 to 2147483647 [pulse]	0	35046+10j 35047+10j

*1 With the exception of positioning control, main cycle processing is executed during the next available time. It changes by status of axis start.


*2 Synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units)

For labels, refer to the following.

 Page 156 Synchronous encoder axis control data

[Cd.320] Synchronous encoder axis control start


If set to "1", the synchronous encoder axis control is started.



If set to "201", the synchronous encoder axis control starts based on the link device input assigned to the synchronous encoder axis start request by the link device external signal assignment function.

Set the control method for the synchronous encoder axis in "[Cd.321] Synchronous encoder axis control method".

The Simple Motion board resets the value to "0" automatically after completion of the synchronous encoder axis control.



Point

[API library]

- To change the synchronous encoder axis current value and the synchronous encoder axis current value per cycle, use the `MMC_SyncEncoder::ChangeSyncEncoderPosition` method.
- To disable the input from the synchronous encoder axis, use the `MMC_SyncEncoder::DisableSyncEncoder` method.
- To enable the input from the synchronous encoder axis, use the `MMC_SyncEncoder::EnableSyncEncoder` method.

[Cd.321] Synchronous encoder axis control method

Set the control method for the synchronous encoder axis.

Setting value	Details	
0: Current value change	The synchronous encoder axis current value and the synchronous encoder axis current value per cycle are changed as follows. Set the new current value in "[Cd.322] Synchronous encoder axis current value setting address".	
	[Md.320] Synchronous encoder axis current value	"[Cd.322] Synchronous encoder axis current value setting address"
	[Md.321] Synchronous encoder axis current value per cycle	A value that is converted "[Cd.322] Synchronous encoder axis current value setting address" into the range from 0 to "[Pr.324] Synchronous encoder axis length per cycle - 1".
1: Counter disable	Input from the synchronous encoder is invalid. Smoothing processing, phase compensation processing and rotation direction restriction processing are continued. While these processes are valid, the input axis speed may not stop immediately when the counter disable is selected.	
2: Counter enable	Input from the synchronous encoder is valid.	

[Cd.322] Synchronous encoder axis current value setting address

Set a new current value in synchronous encoder axis position units to apply to the current value change for the synchronous encoder axis ( Page 32 Synchronous encoder axis position units).

[Cd.323] Synchronous encoder axis error reset

If set to "1", "[Md.326] Synchronous encoder axis error No." and "[Md.327] Synchronous encoder axis warning No." are set to 0 and then "b4: Error detection flag" and "b5: Warning detection flag" of "[Md.325] Synchronous encoder axis status" are turned OFF. A synchronous encoder connection becomes valid if there is no error.

The Simple Motion board resets the value to "0" automatically after completion of the error reset.

However, the setting of the synchronous encoder axis will not be valid even if the error is reset for the setting error of the synchronous encoder axis parameter. Reconfigure the parameter, and turn the power supply of the Simple Motion board ON again or execute the remote RESET.

Point

[API library]

To execute the error reset of the synchronous encoder axis, use the MMC_SyncEncoder::ResetSyncEncoderError method.

[Cd.324] Connection command of synchronous encoder via buffer memory

Use this data when "201: Synchronous encoder via buffer memory" is set in "[Pr.320] Synchronous encoder axis type".

If set to "1", the synchronous encoder axis is connected. Once connected, the synchronous encoder current value is restored based on the "[Cd.325] Input value for synchronous encoder via buffer memory".

If set to "0", the synchronous encoder axis is disconnected.

[Cd.325] Input value for synchronous encoder via buffer memory


Use this data when "201: Synchronous encoder via buffer memory" is set in "[Pr.320] Synchronous encoder axis type".

Set a value to be used every time as the input value for the synchronous encoder in encoder pulse units.

If 1 or more is set in "[Pr.329] Resolution of synchronous encoder via buffer memory", it is processed as a cycle counter within the range from 0 to (resolution of synchronous encoder via buffer memory - 1).

Synchronous encoder axis monitor data

j: Synchronous encoder axis No. - 1

Monitor item	Storage details	Monitor value	Buffer memory address																			
[Md.320] Synchronous encoder axis current value	<ul style="list-style-type: none"> The current value for the synchronous encoder axis is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Synchronous encoder axis position units ^{*1}]	35200+20j 35201+20j																			
[Md.321] Synchronous encoder axis current value per cycle	<ul style="list-style-type: none"> The current value per cycle for a synchronous encoder axis is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in decimal. 0 to (Synchronous encoder axis length per cycle - 1) [Synchronous encoder axis position units ^{*1}]	35202+20j 35203+20j																			
[Md.322] Synchronous encoder axis speed	<ul style="list-style-type: none"> The speed for a synchronous encoder axis is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Synchronous encoder axis speed units ^{*2}]	35204+20j 35205+20j																			
[Md.323] Synchronous encoder axis phase compensation amount	<ul style="list-style-type: none"> The phase compensation amount is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Synchronous encoder axis position units ^{*1}]	35206+20j 35207+20j																			
[Md.324] Synchronous encoder axis rotation direction restriction amount	<ul style="list-style-type: none"> While the rotation direction is restricted, the accumulation for the input movement amount in the opposite direction of the enabled direction is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in decimal. -2147483648 to 2147483647 [Synchronous encoder axis position units ^{*1}]	35208+20j 35209+20j																			
[Md.325] Synchronous encoder axis status	<ul style="list-style-type: none"> The status for a synchronous encoder axis is monitored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in hexadecimal. Buffer memory b15 b12 b8 b4 b0  <table border="1"> <thead> <tr> <th></th> <th>Stored items</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>b0</td> <td>Setting valid flag</td> <td rowspan="6">0: OFF 1: ON</td> </tr> <tr> <td>b1</td> <td>Connecting valid flag</td> </tr> <tr> <td>b2</td> <td>Counter enable flag</td> </tr> <tr> <td>b3</td> <td>Current value setting request flag</td> </tr> <tr> <td>b4</td> <td>Error detection flag</td> </tr> <tr> <td>b5</td> <td>Warning detection flag</td> </tr> <tr> <td>b6</td> <td>Start request flag</td> <td></td> </tr> </tbody> </table>		Stored items	Meaning	b0	Setting valid flag	0: OFF 1: ON	b1	Connecting valid flag	b2	Counter enable flag	b3	Current value setting request flag	b4	Error detection flag	b5	Warning detection flag	b6	Start request flag		35210+20j
	Stored items	Meaning																				
b0	Setting valid flag	0: OFF 1: ON																				
b1	Connecting valid flag																					
b2	Counter enable flag																					
b3	Current value setting request flag																					
b4	Error detection flag																					
b5	Warning detection flag																					
b6	Start request flag																					
[Md.326] Synchronous encoder axis error No.	<ul style="list-style-type: none"> The error code for the synchronous encoder axis is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in hexadecimal. (☞ Simple Motion Board User's Manual (Application))	35211+20j																			
[Md.327] Synchronous encoder axis warning No.	<ul style="list-style-type: none"> The warning code for the synchronous encoder axis is stored. Refresh cycle: <u>Operation cycle</u>	■Monitoring is carried out in hexadecimal. (☞ Simple Motion Board User's Manual (Application))	35212+20j																			

*1 Synchronous encoder axis position units (☞ Page 32 Synchronous encoder axis position units)

*2 Synchronous encoder axis speed units (☞ Page 33 Synchronous encoder axis speed units)

For labels, refer to the following.

☞ Page 155 Synchronous encoder axis monitor data

[Md.320] Synchronous encoder axis current value

The current value for the synchronous encoder axis is stored in synchronous encoder axis position units (☞ Page 32 Synchronous encoder axis position units).

[Md.321] Synchronous encoder axis current value per cycle

The current value per cycle for a synchronous encoder axis is stored in the range from 0 to ("[Pr.324] Synchronous encoder axis length per cycle" - 1).

The unit is synchronous encoder axis position units (☞ Page 32 Synchronous encoder axis position units).

[Md.322] Synchronous encoder axis speed

The speed for a synchronous encoder axis is stored in synchronous encoder axis speed units ( Page 33 Synchronous encoder axis speed units).

If the speed for a synchronous encoder axis exceeds the monitor range ( Page 31 Overview of synchronous encoder axis), the warning "Input axis speed display over" (warning code: 0BD2H) will occur. In this case, use a smaller number of decimal places for the speed in "[Pr.321] Synchronous encoder axis unit setting" or set the speed time units to "0: second [s]".

[Md.323] Synchronous encoder axis phase compensation amount

The phase compensation amount for a synchronous encoder axis is stored in the synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units).

The phase compensation amount for a synchronous encoder axis is the value after smoothing processing and phase compensation processing.

[Md.324] Synchronous encoder axis rotation direction restriction amount

While the rotation direction is restricted for a synchronous encoder axis, the accumulation for input movement amount in the opposite direction of the enabled direction is stored in synchronous encoder axis position units ( Page 32 Synchronous encoder axis position units) as follows.

Setting value of "[Pr.328] Synchronous encoder axis rotation direction restriction"	Storage details
1: Enable only for current value increase direction	A negative accumulation is stored during rotation direction restriction. 0 is stored if there is no restriction.
2: Enable only for current value decrease direction	A positive accumulation is stored during rotation direction restriction. 0 is stored if there is no restriction.

Rotation direction restriction is processed after phase compensation processing. Therefore, if undershoot occurs from phase compensation during deceleration stop, the rotation direction restriction amount might remain.

[Md.325] Synchronous encoder axis status

The each status for a synchronous encoder axis is monitored with the following each bits.

Bit	Storage item	Storage details
b0	Setting valid flag	At power supply ON, this flag turns ON when the synchronous encoder axis parameter ([Pr.320] to [Pr.329]) is normal and the setting of the synchronous encoder axis is valid. It is turned OFF when the setting is invalid or an error occurs.
b1	Connecting valid flag	When the synchronous encoder axis setting is valid, the synchronous encoder connection also becomes valid and this flag turns ON. This flag turns OFF when the connection is invalid.
b2	Counter enable flag	This flag turns ON when input from the synchronous encoder is enabled. If the counter disable control ^{*1} is executed, it is turned OFF, and input from the synchronous encoder becomes invalid. If the counter enable control ^{*1} is executed, it is turned ON, and input from the synchronous encoder becomes valid. When the synchronous encoder is valid to connect, the initial status is ON (enable) status.
b3	Current value setting request flag	This flag turns ON, when a synchronous encoder axis current value change is never executed. If the current value setting request flag is ON for the synchronous encoder connection, the synchronous encoder axis current value starts counting with 0. This flag turns OFF when a synchronous encoder axis current value change is executed.
b4	Error detection flag	This flag turns ON when an error occurs for the synchronous encoder axis. The error No. is stored in "[Md.326] Synchronous encoder axis error No." Reset the error in "[Cd.323] Synchronous encoder axis error reset".
b5	Warning detection flag	This flag turns ON when a warning occurs for the synchronous encoder axis. The warning No. is stored in "[Md.327] Synchronous encoder axis warning No." Reset the warning in "[Cd.323] Synchronous encoder axis error reset".
b6	Start request flag	This flag turns ON when the link device is assigned to the synchronous encoder axis start request signal and the start is requested.
b7 to b15	Not used	Always OFF

*1 Set the control method for synchronous encoder in "[Cd.321] Synchronous encoder axis control method". ( Page 47 Synchronous encoder axis control data)

[Md.326] Synchronous encoder axis error No.

When an error for a synchronous encoder axis is detected, the error code corresponding to the error details is stored.
If set to "1" in "[Cd.323]Synchronous encoder axis error reset", the value is set to "0".

[Md.327] Synchronous encoder axis warning No.

When a warning for a synchronous encoder axis is detected, the warning code corresponding to the warning details is stored.
If set to "1" in "[Cd.323] Synchronous encoder axis error reset", the value is set to "0".

3 CAM FUNCTION

The details on cam data and operation for cam function in output axis (cam axis) are explained in this chapter.

The cam function controls output axis by creating cam data that corresponds to the operation.

The functions to operate cam data include "Cam data operation function", "Cam auto-generation function", and "Cam position calculation function".

Refer to the following for the setting of the output axis.

☞ Page 77 ADVANCED SYNCHRONOUS CONTROL

Refer to the following for the cam position calculation function.

☞ Page 143 Cam Position Calculation Function


3.1 Control Details for Cam Function

The output axis for synchronous control is operated with a cam.

The following operations can be performed with cam functions.

- Two-way operation: Reciprocating operation with a constant cam strokes range.
- Feed operation: Cam reference position is updated every cycle.
- Linear operation: Linear operation (cam No.0) in the cycle as the stroke ratio is 100%.

The output axis is controlled by a value (feed current value), which is converted from the input value (cam axis current value per cycle) by cam data.



Cam data


The cam data used in the cam function includes "storage data" which is used for reading/writing with EM Configurator and "open data" which is transmitted to the internal memory at cam control.

Storage data		Open data
— (Reading and writing not possible)		Linear cam
Stroke ratio data format		Stroke ratio data format
Auto-generation data format	Cam for rotary cutter (central reference)	
	Easy/Advanced stroke ratio cam	
Coordinate data format		Coordinate data format

Storage data and open data are same for cams using the stroke ratio data format and the coordinate data format. A cam using the auto-generation data format (storage data) operates after being changed (transmitted) to the stroke ratio data format.

Linear cam control

When "0" is set for "[Pr.440] Cam No.", the cam data operates as a straight line with a 100% stroke ratio at the last point. The linear cam does not consume the cam open area. Also, it cannot be read/written as storage data.



Stroke ratio data format

The stroke ratio data format is defined in equal divisions for one cam cycle based on the cam resolution, and configured with stroke ratio data from points within the cam resolution.

Refer to the following for setting methods for cam data.


☞ Page 60 Create Cam Data

Setting item	Setting details	Setting range	Default value (EM Configurator)	Cam data operation function
Cam No.	Set the cam No.	0: Linear cam 1 to 1024: User created cam	1	[Cd.601] Operation cam No.
Cam data format	Set "1". (Setting with EM Configurator is not required.)	1: Stroke ratio data format	1	[Cd.604] Cam data format
Cam resolution	Set the number of divisions for one cam cycle.	256/512/1024/2048/ 4096/8192/16384/ 32768	256	[Cd.605] Cam resolution/ coordinate number
Cam data starting point	Set the cam data point corresponding to "Cam axis current value per cycle = 0".	0 to (Cam resolution - 1)	0	[Cd.606] Cam data starting point
Stroke ratio data	Set the stroke ratio from the 1st to the last point. (The 0th point setting is not required. It is always 0%.)	-2147483648 to 2147483647 [× 10 ⁻⁷ %] ^{*1} (-214.7483648 to 214.7483647%)	0	[Cd.607] Cam data value

*1 To display the stroke ratio out of range ±100%, select "Display advanced cam graph stroke" of the "Cam data" and click the [OK] button on the "Options" window displayed by the menu bar of EM Configurator [Tools] ⇒ [Options].

Ex.

Cam resolution: 512



3

Coordinate data format

The coordinate data format is defined in coordinates of more than 2 points for one cam cycle. The coordinate data is represented as "(Input value, Output value)".

Input value: Cam axis current value per cycle


Output value: Stroke position from cam reference position

With this format, "[Pr.441] Cam stroke amount" of output axis parameter is ignored and output value of the coordinate data becomes cam stroke position.


Refer to the following for setting methods for cam data.

☞ Page 60 Create Cam Data

Setting item	Setting details	Setting range	Default value (EM Configurator)	Cam data operation function
Cam No.	Set the cam No.	0: Linear cam 1 to 1024: User created cam	1	[Cd.601] Operation cam No.
Cam data format	Set "2". (Setting with EM Configurator is not required.)	2: Coordinate data format	2	[Cd.604] Cam data format
Coordinate number	Set the number of coordinate points in one cam cycle. The coordinates are included at the 0th point.	2 to 65535	2	[Cd.605] Cam resolution/ coordinate number
Cam data starting point	Setting is not required with coordinate data format.	—	—	[Cd.606] Cam data starting point
Coordinate data	Set all coordinate data (input value: X_n , output value: Y_n). Required to set the coordinate data (X_0 , Y_0) from the 0th point. The input value should be larger than the previous coordinate data ($X_n < X_{n+1}$).	Input value: 0 to 2147483647 [Cam axis cycle units] Output value: -2147483648 to 2147483647 [Output axis position units]	0	[Cd.607] Cam data value



When an input value that is 0 or the cam axis length per cycle does not exist in the coordinate data, the coordinate is calculated from the line segment between the nearest two coordinates.



■Auto-generation data format

A cam pattern is created based on the specified parameter (data for auto-generation). Control cam data is created in the stroke ratio data format in the cam open area. Therefore, the operation specification during the control conforms to the cam operation in the stroke ratio data format.

The types of cam patterns for auto-generation data format are as follows.

Auto-generation type	Features
Cam for rotary cutter (central reference)	The cam pattern for a rotary cutter can be created easily. An adjustment based on the center of the sheet is carried out easily.
Easy stroke ratio cam	Create the cam data such as the stroke ratio cam data created with EM Configurator. Sections, stroke amounts and cam curve types can be specified.
Advanced stroke ratio cam	Create the cam data equal to the stroke ratio cam data created with EM Configurator. Sections, stroke amounts, cam curve types and cam curve detailed parameters can be specified.

⚠ CAUTION

- If the cam data is set incorrectly, similarly to the incorrect setting of a target value and command speed in the positioning control, the position and speed command to the servo amplifier increases, and may cause machine interface and servo alarms such as "Overspeed" and "Command frequency error". When creating and changing cam data, execute a trial operation and provide the appropriate adjustments. Refer to the following for precautions on test operations and adjustments. (Page 1 SAFETY PRECAUTIONS)

Feed current value of cam axis

The feed current value is calculated as shown below.


■Stroke ratio data format

Feed current value = Cam reference position + (Cam stroke amount × Stroke ratio corresponding to cam axis current value per cycle)

■Coordinate data format

Feed current value = Cam reference position + Output value corresponding to cam axis current value per cycle

When the cam axis current value per cycle is in the middle of the defined cam data (Stroke ratio data/Coordinate data), the middle value is calculated from the nearest cam data.



Cam reference position


The cam reference position is calculated as shown below.

■Stroke ratio data format

Cam reference position = The preceding cam reference position + (Cam stroke amount × Stroke ratio at the last point)

■Coordinate data format

Cam reference position = The preceding cam reference position + Output value corresponding to "Input value = Cam axis length per cycle" - Output value corresponding to "Input value = 0"




Create cam data for two-way cam operation as shown below.

■Stroke ratio data format

Create cam data so that the stroke ratio is 0% at the last point.

■Coordinate data format

Create cam data with the same output value for the point where the input value is 0 and the input value is equal to the cam axis length per cycle.



Cam data starting point


This setting is only valid for cam data using the stroke ratio data format.

The cam data point corresponding to "Cam axis current value per cycle = 0" can be set as the cam data starting point.

The default value of the cam data starting point is 0. (The cam axis is controlled with cam data starting from the 0th point (stroke ratio 0%).)

When a value other than 0 is set for the cam data starting point, cam control is started from the point where the stroke ratio is not 0%.

The cam data starting point is set for each cam data. The setting range is from 0 to (cam resolution - 1).



Timing of applying cam control data

■Stroke ratio data format

If "[Pr.439] Cam axis length per cycle", "[Pr.440] Cam No." or "[Pr.441] Cam stroke amount" is changed during synchronous control, the new value is accepted and applied when the cam axis current value per cycle passes through the 0th point of cam data, or is on the 0th point.

The cam reference position is updated when the cam axis current value per cycle passes through the 0th point of cam data.

■Coordinate data format

If "[Pr.439] Cam axis length per cycle" or "[Pr.440] Cam No." is changed during synchronous control, the new value is accepted and applied when the cam axis current value per cycle passes through 0, or is on 0.

The cam reference position is updated when the cam axis current value per cycle passes through 0.

3.2 Create Cam Data

Memory configuration of cam data

Cam data is arranged in the following 2 areas.

Memory configuration	Storage item	Details	Remark
Cam storage area	Cam data	Data is written by the following operations. <ul style="list-style-type: none">• Write with EM Configurator• When executing "write (Cam storage area)" with the cam data operation function.	Data is preserved even when turning the power supply OFF.
	Cam auto-generation data	Data is written when the cam auto-generation request is executed. (Cam auto-generation function)	
Cam open area	Cam data	Cam data is transmitted from the cam storage area by the following operations. <ul style="list-style-type: none">• Power supply turn ON• Write to the cam storage area• When specifying the cam open area with the cam data operation function• When executing the cam auto-generation function	<ul style="list-style-type: none">• Data is lost when turning the power supply OFF.• The cam data that is used in cam control is stored.

Previously written cam data can be used after turning the power supply OFF by writing data in the cam storage area.


Cam data should be written in the cam storage area for normal use.

Point

There is the upper limit of writing numbers to the cam storage area (flash ROM). If the writing numbers to the flash ROM exceed the upper limit, the writing to the flash ROM may be disabled and the error "Flash ROM write error" (error code: 1931H) will occur.

It is recommended that data which is not necessary to be held at the power supply OFF is not written in the cam storage area with the cam data operation function and the cam auto-generation function.

It is possible to write directly to the cam open area via buffer memory when registering cam data that exceeds the memory capacity in the cam storage area, etc. ( Page 63 Cam data operation function) However, writing must be executed to the cam open area every time due to clearing the data at the power supply OFF.



*1 The operation from EM Configurator is executed toward cam storage area.

*2 Writing to cam open area is transmitted in the following timing.
 - Power supply turn ON
 - When "5: Transfer" is set in "[Cd.600] Cam data operation request"

*3 Data in the cam storage area is cleared when the power supply is turned ON again or the remote RESET.

Cam data operation with EM Configurator

Cam data can be modified while viewing the waveform with EM Configurator.

The cam data is written/read/verified to the cam storage area with EM Configurator, however it cannot be executed to the cam open area.

The waveform generated by the cam auto-generation function can be confirmed by the "Cam graph" on the "Cam Data" window from the Navigation window ⇒ "Cam Data" through reading with EM Configurator.

Cam data operation with buffer memory

It is possible to specify the area where cam data is written. The cam data is read from the cam open area. (☞ Page 63 Cam data operation function)

With the cam auto-generation function, auto-generation data is saved in the cam storage area, and the cam data is generated into the cam open area.

Cam data capacity

The size of the created cam data is shown below for the cam open area.

Operation method	Data method/Auto-generation type	Cam open area (16M bytes)
Create with EM Configurator	Auto-generation data format	Cam resolution × 4 bytes
	Coordinate data format	Coordinate number × 8 bytes
Create with cam data operation function	Stroke ratio data format	Cam resolution × 4 bytes
	Coordinate data format	Coordinate number × 8 bytes
Create with cam auto-generation	Auto-generation data format	Cam for rotary cutter (central reference)
		Easy stroke ratio cam
		Advanced stroke ratio cam

Delete method of cam data

The data of cam storage area/cam open area can be deleted (initialize) by the parameter initialization function with a parameter setting and positioning data. The parameter initialization function is executed by setting "1" in "[Cd.2] Parameter initialization request".

Write the empty data in the cam storage area with EM Configurator to delete only cam data.

Cam data operation function

This function is used to write/read cam data via buffer memory with the cam operation control data. To operate the points more than the amount of data for each operation (as follows), the operation should be executed separately.

Cam data format	Amount of data for each operation
Stroke ratio data format	32768
Coordinate data format	65535

Cam operation control data

Setting item	Setting details	Setting value (Read operation: Stored value)	Default value	Buffer memory address
[Cd.600] Cam data operation request	<ul style="list-style-type: none"> Set the command for operating cam data. The Simple Motion board resets the value to "0" automatically after completion of cam data operation. Fetch cycle: <u>Main cycle</u> ^{*1}	■Set in decimal. 1: Read (Cam open area) 2: Write (Cam storage area) 3: Write (Cam open area) 4: Read (Cam storage area) 5: Transfer -1: Zero clear	0	600000
[Cd.601] Operation cam No.	<ul style="list-style-type: none"> Set the operating cam No. Fetch cycle: <u>At requesting cam data operation</u>	■Set in decimal. 0: All cams (At transfer request only) 1 to 1024	0	600001
[Cd.602] Cam data first position	<ul style="list-style-type: none"> Set the first position for the operating cam data. Fetch cycle: <u>At requesting cam data operation</u>	■Set in decimal. <ul style="list-style-type: none"> Stroke ratio data format: 1 to cam resolution Coordinate data format: 0 to (Coordinate number - 1) 	0	600002
[Cd.603] Number of cam data operation points	<ul style="list-style-type: none"> Set the number of operating cam data points. Fetch cycle: <u>At requesting cam data operation</u>	■Set in decimal. <ul style="list-style-type: none"> Stroke ratio data format: 1 to 32768 Coordinate data format: 1 to 65535 	0	600003
[Cd.604] Cam data format	<ul style="list-style-type: none"> Write operation: Set cam data format. Read operation: The cam data format is stored Fetch cycle: <u>At requesting cam data operation</u> Refresh cycle: <u>At completing cam data operation</u>	■Set in decimal. 1: Stroke ratio data format 2: Coordinate data format 102: Cam auto-generation data format for rotary cutter cam (Central reference) 103: Cam auto-generation data format for easy stroke ratio cam 104: Cam auto-generation data format for advanced stroke ratio cam	0	600004
[Cd.605] Cam resolution/coordinate number	<ul style="list-style-type: none"> Write operation: Set the cam resolution/the coordinate number. Read operation: The cam resolution/the coordinate number is stored. Fetch cycle: <u>At requesting cam data operation</u> Refresh cycle: <u>At completing cam data operation</u>	■Set in decimal. <ul style="list-style-type: none"> Stroke ratio data format 256/512/1024/2048/4096/8192/16384/32768 Coordinate data format: 2 to 65535 	0	600005
[Cd.606] Cam data starting point	<ul style="list-style-type: none"> Write operation: Set the cam data starting point. Read operation: The cam data starting point is stored. Fetch cycle: <u>At requesting cam data operation</u> Refresh cycle: <u>At completing cam data operation</u> • Setting is not required with coordinate data format.	■Set in decimal. <ul style="list-style-type: none"> Stroke ratio data format: 0 to (Cam resolution - 1) Coordinate data format: Setting not required 	0	600006
[Cd.607] Cam data value	<ul style="list-style-type: none"> Write operation: Set the cam data corresponding to the cam data format. Read operation: The cam data is stored. Fetch cycle: <u>At requesting cam data operation</u> Refresh cycle: <u>At completing cam data operation</u>	■Set in decimal. <ul style="list-style-type: none"> Stroke ratio data format -2147483648 to 2147483647 [$\times 10^{-7}\%$] Coordinate data format Input value: 0 to 2147483647 [Cam axis cycle units^{*2}] Output value: -2147483648 to 2147483647 [Output axis position units^{*3}] 	0	600008 to 862147

*1 With the exception of positioning control, main cycle processing is executed during the next available time. It changes by status of axis start.

*2 Cam axis cycle units ( Page 110 Units for the output axis)

*3 Output axis position units ( Page 110 Units for the output axis)

For labels, refer to the following.

☞ Page 157 Cam operation control data: Cam data operation

[Cd.600] Cam data operation request

Set the following commands to write/read cam data.

Setting value	Details
1: Read	The cam data is read from the cam open area and stored to the buffer memory.
2: Write (Cam storage area)	The cam data is written to the cam storage area and the cam open area from the buffer memory.
3: Write (Cam open area)	The cam data is written to the cam open area from the buffer memory.
4: Read (Cam storage area)	The data is read from the cam storage area and stored to the buffer memory.
5: Transfer	The data is written to the cam open area from the cam storage area.
-1: Zero clear	All the buffer memories of "[Cd.607] Cam data value" are cleared to 0.

The setting value is reset to "0" automatically after completion of cam data operation.

If a warning occurs when requesting cam data operation, the warning No. is stored in "[Md.24] Axis warning No." of axis 1, and the setting value is reset to "0" automatically.

When another request command is set, the operation does not get executed and the setting value is reset to "0" automatically.

[Cd.601] Operation cam No.

Set the cam No. to write/read.

[Cd.602] Cam data first position

Set the first position of the cam data to write/read.

Set the cam data first position within the range from 1 to the cam resolution in cam resolution units using the stroke ratio data format. The stroke ratio of the 0th cam data is 0% fixed, and this data cannot be written/read.

Set a value within the range from 0 to (Coordinate number - 1) with the coordinate data format.

[Cd.603] Number of cam data operation points

Set the number of operation points to write/read starting from the first position of cam data.

- Stroke ratio data format

The following shows the operation details when the value of "Cam data first position + Cam data operation points - 1" is larger than the cam resolution in the stroke ratio data format.

Operation	Details
Reading	The cam data from the first position to the cam resolution is read in the buffer memory.
Writing	The warning "Outside number of cam data operation points range" (warning code: 0C43H) occurs, and writing is not executed.

- Coordinate data format

The following shows the operation details when the value of "Cam data first position + Cam data operation points" is larger than the coordinate number with the coordinate data format.

Operation	Details
Reading	The cam data from the first position to the last coordinate is read in the buffer memory.
Writing	The warning "Outside number of cam data operation points range" (warning code: 0C43H) occurs, and writing is not executed.

[Cd.604] Cam data format

Set one of the following cam data formats.

Setting value	Details
Reading (Cam open area)	1: Stroke ratio data format 2: Coordinate data format
Reading (Cam storage area)	1: Stroke ratio data format 2: Coordinate data format 102: Cam auto-generation data format for rotary cutter cam (Central reference) 103: Cam auto-generation data format for easy stroke ratio cam 104: Cam auto-generation data format for advanced stroke ratio cam
Writing	1: Stroke ratio data format 2: Coordinate data format

[Cd.605] Cam resolution/coordinate number

Set/load the cam resolution/the coordinate number.

Operation	Details
Reading	The cam resolution/the coordinate number of the set cam data is read.
Writing	Set the cam resolution with the following values when using the stroke ratio data format. 256/512/1024/2048/4096/8192/16384/32768 Set the coordinate number within the following range when using the coordinate data format. 2 to 65535

[Cd.606] Cam data starting point

Set/load the cam data starting point. This is used with the stroke ratio data format.

Operation	Details
Reading	The cam starting point of the set cam data is read.
Writing	Set the cam data starting point within the range from 0 to (Cam resolution - 1).

[Cd.607] Cam data value

Set/load the cam data operation points according to one of the following formats.

■Stroke ratio data format

Buffer memory address	Item	Setting value
600008 600009	Stroke ratio at first point	-2147483648 to 2147483647 [$\times 10^{-7}\%$] (-214.7483648 to 214.7483647 [%])
600010 600011	Stroke ratio at second point	
⋮	⋮	
862146 862147	Stroke ratio at 32768th point.	


For labels, refer to the following.

☞ Page 157 Cam operation control data: Cam data operation

■Coordinate data format

Buffer memory address	Item	Setting value
600008 600009	At first point	Input value 0 to 2147483647 [Cam axis cycle unit]
600010 600011		Output value -2147483648 to 2147483647 [Output axis position unit]
600012 600013	At second point	Input value 0 to 2147483647 [Cam axis cycle unit]
600014 600015		Output value -2147483648 to 2147483647 [Output axis position unit]
⋮	⋮	⋮
862144 862145	At 65535th point	Input value 0 to 2147483647 [Cam axis cycle unit]
862146 862147		Output value -2147483648 to 2147483647 [Output axis position unit]

[Cd.601] to [Cd.607] Cam data 

[Cd.600] Cam data operation request 

For labels, refer to the following.

☞ Page 157 Cam operation control data: Cam data operation

■Auto-generation data format

When the reading (cam storage area) is executed to the cam data created with the cam auto-generation or the cam data created with the cam curve by EM Configurator, the data is read as auto-generation data format.

- Cam for rotary cutter (central reference) data
- Easy stroke ratio cam data
- Advanced stroke ratio cam data

For the buffer memory assignment at reading, refer to the following.

☞ Page 68 [Cd.611] Cam auto-generation data

However, cam data created by a free-form curve cannot be read.

Cam auto-generation function

The cam auto-generation function is used to generate cam data automatically for specific purposes based on parameter settings.

With this function, cam data is generated in the cam open area.

It is possible to generate up to 16 Mbyte including the regular cam data. (Example: 1024 cam data (with the stroke ratio format, resolution is 4096) can be automatically generated.)

The processing time of cam auto-generation takes longer if the data point is larger. Also, the real processing time changes by status of axis start etc.

Cam operation control data

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.608] Cam auto-generation request	<ul style="list-style-type: none"> Set the request for cam auto-generation. The Simple Motion board resets the value to "0" automatically after completion of the cam auto-generation. Fetch cycle: Main cycle* ¹	■Set in decimal. 1: Cam auto-generation request 2: Cam auto-generation request (without writing to storage area)	0	862200
[Cd.609] Cam auto-generation cam No.	<ul style="list-style-type: none"> Set the cam No. to be generated automatically. Fetch cycle: At requesting cam auto-generation	■Set in decimal. 1 to 1024	0	862201
[Cd.610] Cam auto-generation type	<ul style="list-style-type: none"> Set the type of cam auto-generation. Fetch cycle: At requesting cam auto-generation	■Set in decimal. 2: Cam for rotary cutter (Central reference) 3: Easy stroke ratio cam 4: Advanced stroke ratio cam	0	862202
[Cd.611] Cam auto-generation data	<ul style="list-style-type: none"> Set the parameters for each type of cam auto-generation. Fetch cycle: At requesting cam auto-generation	(☞ Page 68 [Cd.611] Cam auto-generation data)	0	862204 to 866295

*1 With the exception of positioning control, main cycle processing is executed during the next available time. It changes by status of axis start.

For labels, refer to the following.

☞ Page 159 Cam operation control data: Cam auto-generation

[Cd.608] Cam auto-generation request

Set "1: Cam auto-generation request" or "2: Cam auto-generation request (without writing to storage area)" to execute cam auto-generation.

Cam data is generated in the cam open area of the specified cam No. based on the cam auto-generation data.

The setting value is reset to "0" automatically after completing the process.

When "1: Cam auto-generation request" is set, the cam auto-generation data is saved in the cam storage area (flash ROM).

The cam auto-generation is executed automatically again when the next power supply turns ON or "5: Transfer" is set in "[Cd.600] Cam data operation request".

If a warning occurs when requesting cam auto-generation, the warning No. is stored in "[Md.24] Axis warning No." of axis 1, and the setting value is reset to "0" automatically.

When another request command is set, this function does not get executed and the setting value is reset to "0" automatically.

[Cd.609] Cam auto-generation cam No.

Set the cam No. to be generated automatically.

[Cd.610] Cam auto-generation type

Set the type of cam auto-generation.

[Cd.611] Cam auto-generation data

Set the cam auto-generation data corresponding to "[Cd.610] Cam auto-generation type".


■Cam auto-generation data for rotary cutter (central reference)

When the synchronous position adjustment is set to 0, the cam pattern of which the sheet center is in the synchronous section is created.

Buffer memory address	Item	Setting value	Details
862204 862205	Cam resolution	256/512/1024/2048/4096/8192/16384/32768	Set the cam resolution for generating the cam.
862206	Auto-generation option	<ul style="list-style-type: none"> • Bit 0: Acceleration/deceleration system 0: Trapezoidal acceleration/deceleration 1: S-curve acceleration/deceleration • Bit1: Synchronous axis length setting 0: Diameter 1: Cycle length 	<ul style="list-style-type: none"> • Select the trapezoidal acceleration/deceleration system or the S-curve acceleration/deceleration system with bit 0. • Select the diameter or the cycle length for the synchronous axis length setting with bit 1. • Set "0" for bit 2 to 15.
862207	Synchronous section acceleration ratio	-5000 to 5000 [0.01%]	Set when the synchronous speed in the synchronous section needs to be adjusted. The speed is "Synchronous speed × (100% + Acceleration ratio)" in the synchronous section.
862208 862209	Sheet length	1 to 2147483647 [(Optional) Same units]	Set the sheet length.
862210 862211	Sheet synchronization width	1 to 2147483647 [(Optional) Same units]	<ul style="list-style-type: none"> • Set the sheet synchronization width (seal width). • When the synchronous speed section for retracting operation is required in front of and behind the sheet synchronization width, add the retracting width.
862212 862213	Synchronous axis length	<ul style="list-style-type: none"> • For diameter setting 1 to 680000000 • For cycle length setting 1 to 2147483647 [(Optional) Same units] 	<ul style="list-style-type: none"> • Set the rotary cutter axis length. • When the auto-generation option is set to the diameter, it is calculated as "Cycle length = setting value × π". • When the auto-generation option is set to the cycle length, it is calculated as "Cycle length = setting value".
862214 862215	Synchronous position adjustment	-1073741823 to 1073741823 [(Optional) Same units]	<ul style="list-style-type: none"> • Set the position adjustment of the synchronous section. Negative value: The synchronous section is adjusted to the sheet start side. 0: The center of the sheet is in the synchronous section. Positive value: The synchronous section is adjusted to the sheet end side. • Set the value within one-half of the sheet length.
862216 862217	Acceleration/ deceleration width	0 to 2147483647 [(Optional) Same units]	<ul style="list-style-type: none"> • Set the sheet width (one side) of the acceleration/ deceleration area. • When a negative value is set, the acceleration/deceleration width is calculated to be the maximum.
862218	Number of cutter	1 to 256	Set the number of cutter.
862219	Asynchronous speed result	0 to 65535 [0.01 times]	When the cam auto-generation is successfully performed, the asynchronous speed is stored as the ratio of the synchronous speed.

For labels, refer to the following.

 Page 159 Cam operation control data: Cam auto-generation



Ex.

Cam pattern created at the following settings:

Acceleration/deceleration system = Trapezoidal, Synchronous axis length setting = Diameter

Synchronous section acceleration ratio = 3.00%

Sheet length = 200.0 mm


Sheet synchronization width = 30.0 mm (Seal section) + 20.0 mm (Retracting operation)

Synchronous axis length = 100.0 mm (Diameter)

Synchronous position adjustment = 20.0 mm

Acceleration/deceleration width = 55.0 mm

Number of cutter = 1




[API library]

To automatically generate the cam for rotary cutter (central reference), use the MMC_Controller::MakeRotaryCutterCam method.

Easy stroke ratio cam/Advanced stroke ratio cam

Cam data can be automatically generated without using the cam data setting of EM Configurator by setting the stroke amount and sections. In easy stroke ratio cam, detailed coefficients of the cam curve are omitted and the curves and number of sections that can be used are limited.

With the current value per cycle "0" as starting point, automatically generates cam data from the stroke and cam curve type of each section until the specified end point (cam axis current value per cycle).



• Easy stroke ratio cam data for auto-generation

Buffer memory address	Item	Setting value	Details
862204 862205	Cam resolution	256/512/1024/2048/4096/8192/16384/ 32768	Set the cam resolution for generating the cam.
862206 862207	Cam axis length per cycle*1	1 to 2147483647 [[Optional] Same units (0.1 mm, etc.)]	Set the required input amount with the cam per cycle.
862208 862209	Cam data starting point	0 to (Resolution - 1)	Set the starting point as the point corresponding to "cycle length = 0" of cam data.
862210	Number of sections	1 to 32	Set the number of sections of cam data. Set data for the number of sections specified.
862212	Section 1 Cam curve type*2	0: Constant speed 1: Constant acceleration 2: Distorted trapezoid 3: Distorted sine 4: Distorted constant speed 5: Cycloid 6: 5th curve	Set the cam curve.
862214 862215	End point	1 to Cam axis length per cycle [Cam axis length per cycle units]*3	Set the point for cam axis length per cycle (cam axis current value per cycle). It is necessary to set a value larger than the end point immediately before (Xn < Xn + 1). Also, for the final end point, set as the cam axis length per cycle.
862216 862217	Stroke	-2147483648 to 2147483647 [× 0.0000001%]	Set the stroke position from the cam reference position of when at the end point specified by cam axis current value per cycle. When set at "1000000000", it becomes the position set in "[Pr.441] Cam stroke amount".
862218	Section 2 Cam curve type*2	0: Constant speed 1: Constant acceleration 2: Distorted trapezoid 3: Distorted sine 4: Distorted constant speed 5: Cycloid 6: 5th curve	The data specified by "number of sections" becomes valid. It is not necessary to set the data after the specified number of sections.
862220 862221	End point	1 to Cam axis length per cycle [Cam axis length per cycle units]*3	
862222 862223	Stroke	-2147483648 to 2147483647 [× 0.0000001%]	
⋮	⋮	⋮	
862398	Section 32 Cam curve type*2	0: Constant speed 1: Constant acceleration 2: Distorted trapezoid 3: Distorted sine 4: Distorted constant speed 5: Cycloid 6: 5th curve	
862400 862401	End point	1 to Cam axis length per cycle [Cam axis length per cycle units]*3	
862402 862403	Stroke	-2147483648 to 2147483647 [× 0.0000001%]	

*1 The set value is only used for cam data generation. Control is performed by the output axis parameter "[Pr.439] Cam axis length per cycle".

*2 Refer to the following for the shapes of each cam type. Use P1 = 0, P2 = 1.00, and default values for L1 and L2.

☞ Page 75 [Cam curve list]

*3 If setting is outside range, the cam axis length per cycle will be set as the final end point of the section settings.

For labels, refer to the following.

☞ Page 159 Cam operation control data: Cam auto-generation

• Advanced stroke ratio cam data for auto-generation

Buffer memory address	Item	Setting value	Details	
862204 862205	Cam resolution	256/512/1024/2048/4096/8192/16384/ 32768	Set the cam resolution for generating the cam.	
862206 862207	Cam axis length per cycle ^{*3}	1 to 2147483647 [Cam axis length per cycle units]	Set the required input amount with the cam per cycle.	
862208 862209	Cam stroke amount ^{*3}	1 to 2147483647 [Cam stroke amount units]	Set the reference value for the stroke amount specified by stroke (Yn). When the cam stroke amount units are "%", this is ignored.	
862210	Unit setting	<p>H</p> <p>→ Cam axis length per cycle units (Display) 0: mm 1: inch 2: degree 3: pulse → Number of decimal places 0 to 9</p> <p>→ Cam stroke amount 0: mm 1: inch 2: degree 3: pulse 9: % → Number of decimal places 0 to 9</p> <p>When a value outside the range is set, cam data is generated from the default value (H7952).</p>	Set the display unit of the cam axis length per cycle, and the unit for cam stroke amount in hexadecimal.	
862212 862213	Cam data starting point	0 to (Resolution - 1)	Set the starting point as the point corresponding to "cycle length = 0" of cam data.	
862214	Number of sections	1 to 360	Set the number of sections of cam data. Set data for the number of sections specified.	
862216	Section 1	Cam curve type ^{*2}	0: Constant speed 1: Constant acceleration 2: Distorted trapezoid 3: Distorted sine 4: Distorted constant speed 5: Cycloid 6: 5th curve 7: Trapezoid 8: Reverse trapezoid 9: Double hypotenuse 10: Reverse double hypotenuse 11: Single hypotenuse	Set the cam curve.
862218 862219		End point (X1)	1 to Cam axis length per cycle [Cam axis length per cycle units] ^{*1}	Set the point for cam axis length per cycle (cam axis current value per cycle). It is necessary to set a value larger than the end point immediately before (Xn < Xn + 1). Also, for the final end point, set as the cam axis length per cycle.
862220 862221		Stroke (Y1) ^{*4}	-2147483648 to 2147483647 [Cam stroke units]	Set the stroke position from the cam reference position of when at the end point specified by cam axis current value per cycle.
862222		Curve applicable range (P1)	0 to 100 [× 0.01]	Set the curve applicable range (start point: P1, end point: P2) for the cam curve. Set so that "P1 < P2". When "P1 = P2 = 0", "P1 = 0" and "P2 = 100" are applied.
862223		Curve applicable range (P2)		
862224		Acceleration/ deceleration range compensation (Range L1) ^{*2}	1 to 9999 [× 0.0001]	Set the acceleration/deceleration range (L1, L2) for the cam curve. The range that can be set differs depending on the cam curve. When "L1 = L2 = 0", the default value for each curve is applied.
862225		Acceleration/ deceleration range compensation (Range L2) ^{*2}		

Buffer memory address	Item	Setting value	Details
862226	Section 2	Cam curve type* ² 0: Constant speed 1: Constant acceleration 2: Distorted trapezoid 3: Distorted sine 4: Distorted constant speed 5: Cycloid 6: 5th curve 7: Trapecloid 8: Reverse trapeclloid 9: Double hypotenuse 10: Reverse double hypotenuse 11: Single hypotenuse	The data specified by "number of sections" becomes valid. It is not necessary to set the data after the specified number of sections.
862228 862229	End point (X2)	1 to Cam axis length per cycle [Cam axis length per cycle units] ^{*1}	
862230 862231	Stroke (Y2)* ⁴	-2147483648 to 2147483647 [Cam stroke units]	
862232	Curve applicable range (P1)	0 to 100 [× 0.01]	
862233	Curve applicable range (P2)		
862234	Acceleration/ deceleration range compensation (Range L1)* ²	1 to 9999 [× 0.0001]	
862235	Acceleration/ deceleration range compensation (Range L2)* ²		
⋮	⋮	⋮	
865806	Section 360	Cam curve type* ² 0: Constant speed 1: Constant acceleration 2: Distorted trapezoid 3: Distorted sine 4: Distorted constant speed 5: Cycloid 6: 5th curve 7: Trapecloid 8: Reverse trapeclloid 9: Double hypotenuse 10: Reverse double hypotenuse 11: Single hypotenuse	
865808 865809	End point (X32)	1 to Cam axis length per cycle [Cam axis length per cycle units]	
865810 865811	Stroke (Y32)* ⁴	-2147483648 to 2147483647 [Cam stroke units] ^{*1}	
865812	Curve applicable range (P1)	0 to 100 [× 0.01]	
865813	Curve applicable range (P2)		
865814	Acceleration/ deceleration range compensation (Range L1)* ²	1 to 9999 [× 0.0001]	
865815	Acceleration/ deceleration range compensation (Range L2)* ²		

- *1 If setting is outside range, the cam axis length per cycle will be set as the final end point of the section settings.
- *2 Refer to the following for the shapes of each cam type and ranges/default value for L1 and L2. Set "0" for the types of cam curves that do not use L1 and L2.
 Page 75 [Cam curve list]
- *3 The set value is only used for cam data generation. Control is performed by the output axis parameter "[Pr.439] Cam axis length per cycle" and "[Pr.441] Cam stroke amount".
- *4 When the cam stroke amount units is a unit other than "%", set the stroke amount so that "Stroke (Yn) / cam stroke amount" is inside the range of "-2.147483648 to 2.147483647".

For labels, refer to the following.








 Page 159 Cam operation control data: Cam auto-generation






Point

- Set data for the number of sections specified. It is not necessary to set the data after the number of sections specified.
- Set the end point data in ascending order.
- Various cam patterns are created by the setting of the stroke and cam data of each section. If the amount of change in stroke is large, it may cause a servo error in the servo amplifier including overspeed, command frequency error etc. When creating cam, confirm the cam operation in amplifier-less operation.
- Cam data will end at the section where the end point is exceeds the cam axis length per cycle set by the auto-generation data.

[Cam curve list]

- - - - : Stroke ratio ——— : Acceleration ■ : Range L1 ▨ : Range L2

Cam curve type			Acceleration curve shape	Curve applicable range (P1 to P2)	Acceleration/deceleration range compensation (): Default value	
Setting value	Cam curve name				Range L1	Range L2
0	Constant speed	Discontinuous		0.00 to 1.00	—	—
1	Constant acceleration			0.00 to 1.00	—	—
2	Distorted trapezoid	Two-dwelling symmetrical		0.00 to 1.00	0.0001 to 0.2499 (0.1250)	—
3	Distorted sine			0.00 to 1.00	0.0001 to 0.4999 (0.1250)	—
4	Distorted constant speed			0.00 to 1.00	0.0001 to 0.1249 (0.0625)	0.0001 to 0.4999 (0.2500)
5	Cycloid			0.00 to 1.00	—	—
6	5th curve			0.00 to 1.00	—	—

Cam curve type		Acceleration curve shape	Curve applicable range (P1 to P2)	Acceleration/deceleration range compensation (): Default value		
Setting value	Cam curve name			Range L1	Range L2	
7	Trapezoid	Two-dwelling asymmetrical		0.00 to 1.00	0.0001 to 0.2499 (0.1250)	—
8	Reverse trapezoid			0.00 to 1.00	0.0001 to 0.2499 (0.1250)	—
9	Double hypotenuse	One-dwelling		0.00 to 1.00	—	—
10	Reverse double hypotenuse			0.00 to 1.00	—	—
11	Single hypotenuse	Non-dwelling curve		0.00 to 1.00	—	—

Point

[API library]

- To automatically generate the easy stroke ratio cam, use the MMC_Controller::MakeEasyStrokeRatioCam method.
- To automatically generate the advanced stroke ratio cam, use the MMC_Controller::MakeAdvancedStrokeRatioCam method.

4 ADVANCED SYNCHRONOUS CONTROL

The parameters and monitor data for synchronous control such as "Main shaft module", "Speed change gear module", and "Output axis module" are explained in this chapter.

Configure the required settings according to the control and application requirements for each module.


4.1 Main Shaft Module

Overview of main shaft module

For the main shaft module, the input value is generated as a composite value from two input axes (the main and sub input axis) through the composite main shaft gear. The composite input value can be converted by the main shaft gear that provides the deceleration ratio and the rotation direction for the machine system, etc.

Refer to the followings for details on setting for the main shaft module.

☞ Page 78 Main shaft parameters, ☞ Page 80 Main shaft clutch parameters



*1 ☞ Page 94 Clutch

Main shaft parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.400] Main input axis No.	<ul style="list-style-type: none"> Set the input axis No. on the main input side for the main shaft. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Invalid 1 to 16: Servo input axis 801 to 816: Synchronous encoder axis 	0	36400+200n
[Pr.401] Sub input axis No.	<ul style="list-style-type: none"> Set the input axis No. on the sub input side for the main shaft. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Invalid 1 to 16: Servo input axis 801 to 816: Synchronous encoder axis 	0	36401+200n
[Pr.402] Composite main shaft gear	<ul style="list-style-type: none"> Select the composite method for input values from the main input axis and sub input axis. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in hexadecimal. 	0001H	36402+200n
[Pr.403] Main shaft gear: Numerator	<ul style="list-style-type: none"> Set the numerator for the main shaft gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. -2147483648 to 2147483647 	1	36404+200n 36405+200n
[Pr.404] Main shaft gear: Denominator	<ul style="list-style-type: none"> Set the denominator for the main shaft gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 1 to 2147483647 	1	36406+200n 36407+200n

For labels, refer to the following.

☞ Page 152 Synchronous parameters: Main shaft

[Pr.400] Main input axis No., [Pr.401] Sub input axis No.

Set the main input axis No. and the sub input axis No. for the main shaft.

Setting value	Details
0: Invalid	The input value is always 0.
1 to 16: Servo input axis	Set the servo input axis (axis 1 to axis 16). When the servo input axis is not set in the system setting, the input value is always 0. If the No. is set to the same value as the output axis, the following errors occur and synchronous control cannot be started. <ul style="list-style-type: none"> Outside main input axis No. range (error code: 1BE0H) Outside sub input axis No. range (error code: 1BE1H)
801 to 816: Synchronous encoder axis	Set the synchronous encoder axis (axis 1 to axis 16). When the synchronous encoder axis is invalid, the input value is always 0.

[Pr.402] Composite main shaft gear

Set the composite method for input values from the main and sub input axes. The setting values for each axis are shown as follows.

Setting value	Details
0: No input	The input value from the input axis is calculated as 0.
1: Input+	The input value from the input axis is calculated as it is.
2: Input-	The input value from the input axis is calculated with its opposite sign.

Operation assumes "0: No input" if the value is set out of the range from 0 to 2.

Point

The composite method for the composite main shaft gear can be changed during synchronous control. It is used as a clutch to switch input values between the main and the sub input axes.

4

[Pr.403] Main shaft gear: Numerator, [Pr.404] Main shaft gear: Denominator

Set the numerator and the denominator for the main shaft gear to convert the input value. The input value is converted as follows.

$$\text{Input value after conversion} = \text{Input value before conversion} \times \frac{[\text{Pr.403}] \text{ Main shaft gear: Numerator}}{[\text{Pr.404}] \text{ Main shaft gear: Denominator}}$$

The input value direction can be reversed by setting a negative value in the numerator of the main shaft gear.

Set the denominator of the main shaft gear to a value within the range from 1 to 2147483647.

Ex.

Convert the cam axis per cycle to be controlled in intervals of 0.1 mm (0.00394 inch). The cam axis synchronizes with a conveyer that moves 100 mm (3.937 inch) for every (360.00000 degree) of the main shaft.

"[Pr.403] Main shaft gear: Numerator": 1000 [× 0.1 mm]

"[Pr.404] Main shaft gear: Denominator": 36000000 [× 10⁻⁵ degree]

Main shaft clutch parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.405] Main shaft clutch control setting	<ul style="list-style-type: none"> Set the control method for the clutch. <p><u>Fetch cycle: Operation cycle</u></p>	<p>■Set in hexadecimal.</p>  <p>ON control mode 0: No clutch 1: Clutch command ON/OFF 2: Clutch command leading edge 3: Clutch command trailing edge 4: Address mode 6: Main shaft clutch control request ON/OFF 7: Main shaft clutch control request leading edge 8: Main shaft clutch control request trailing edge</p> <p>OFF control mode 0: OFF control invalid 1: One-shot OFF 2: Clutch command leading edge 3: Clutch command trailing edge 4: Address mode 7: Main shaft clutch control request leading edge 8: Main shaft clutch control request trailing edge</p>	0000H	36408+200n
[Pr.406] Main shaft clutch reference address setting	<ul style="list-style-type: none"> Set the reference address for the clutch. <p><u>Fetch cycle: At start of synchronous control</u></p>	<p>■Set in decimal.</p> <p>0: Current value after composite main shaft gear 1: Current value per cycle after main shaft gear</p>	0	36409+200n
[Pr.407] Main shaft clutch ON address	<ul style="list-style-type: none"> Set the clutch ON address for address mode. (This setting is invalid except during address mode.) If the address is out of the range from 0 to (Cam axis length per cycle - 1), the address is converted to a value within range. <p><u>Fetch cycle: Operation cycle</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647 [Main input axis position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36410+200n 36411+200n
[Pr.408] Movement amount before main shaft clutch ON	<ul style="list-style-type: none"> Set the movement amount between the clutch ON condition completing and the clutch closing. Set a positive value when the reference address is increasing, and a negative value when it is decreasing. <p><u>Fetch cycle: At completing clutch ON condition</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647 [Main input axis position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36412+200n 36413+200n
[Pr.409] Main shaft clutch OFF address	<ul style="list-style-type: none"> Set the clutch OFF address for the address mode. (This setting is invalid except during address mode.) If the address is out of the range from 0 to (Cam axis length per cycle - 1), the address is converted to a value within range. <p><u>Fetch cycle: Operation cycle</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647 [Main input axis position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36414+200n 36415+200n
[Pr.410] Movement amount before main shaft clutch OFF	<ul style="list-style-type: none"> Set the movement amount between the clutch OFF condition completing and the clutch opening. Set a positive value when the reference address is increasing, and a negative value when it is decreasing. <p><u>Fetch cycle: At completing clutch OFF condition</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647 [Main input axis position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36416+200n 36417+200n
[Pr.411] Main shaft clutch smoothing method	<ul style="list-style-type: none"> Set the clutch smoothing method. <p><u>Fetch cycle: At start of synchronous control</u></p>	<p>■Set in decimal.</p> <p>0: Direct 1: Time constant method (Exponent) 2: Time constant method (Linear) 3: Slippage method (Exponent) 4: Slippage method (Linear) 5: Slippage method (Linear: Input value follow up)</p>	0	36418+200n

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.412] Main shaft clutch smoothing time constant	<ul style="list-style-type: none"> For smoothing with a time constant method, set the smoothing time constant. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0 to 5000 [ms] 	0	36419+200n
[Pr.413] Slippage amount at main shaft clutch ON	<ul style="list-style-type: none"> For smoothing with a slippage method, set the slippage amount at clutch ON. <u>Fetch cycle: At turning clutch ON.</u>	<ul style="list-style-type: none"> Set in decimal. 0 to 2147483647 [Main input axis position units^{*1}, or cam axis cycle units^{*2}] 	0	36420+200n 36421+200n
[Pr.414] Slippage amount at main shaft clutch OFF	<ul style="list-style-type: none"> For smoothing with a slippage method, set the slippage amount at clutch OFF. <u>Fetch cycle: At turning clutch OFF.</u>	<ul style="list-style-type: none"> Set in decimal. 0 to 2147483647 [Main input axis position units^{*1}, or cam axis cycle units^{*2}] 	0	36422+200n 36423+200n

*1 Main input axis position units (☞ Page 24 INPUT AXIS MODULE)

*2 Cam axis cycle units (☞ Page 110 Units for the output axis)

For labels, refer to the following.

☞ Page 152 Synchronous parameters: Main shaft

[Pr.405] Main shaft clutch control setting

Set the ON and OFF control methods separately for the main shaft clutch.

The clutch control setting can be changed during synchronous control, however, the setting "No clutch" (Direct coupled operation) cannot be selected during synchronous control after already selecting another setting.

Refer to the following for operation details on the clutch control.

☞ Page 94 Control method for clutch

■ON control mode

Setting value	Details
0: No clutch (Direct coupled operation)	Execute direct coupled operation without clutch control.
1: Clutch command ON/OFF	The clutch is turned ON/OFF by the operation of "[Cd.400] Main shaft clutch command" ON/OFF. (Setting in the OFF control mode are not applicable in this mode.)
2: Clutch command leading edge	The clutch is turned ON when "[Cd.400] Main shaft clutch command" passes the leading edge (from OFF to ON).
3: Clutch command trailing edge	The clutch is turned ON when "[Cd.400] Main shaft clutch command" passes the trailing edge (from ON to OFF).
4: Address mode	The clutch is turned ON when the reference address (the current value after composite main shaft gear or the current value per cycle after main shaft gear) reaches "[Pr.407] Main shaft clutch ON address". The movement amount after passing through the ON address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
6: Main shaft clutch control request ON/OFF	The clutch is turned ON/OFF by ON/OFF operation of the link device assigned to the main shaft clutch control request by the link device external signal assignment function. (Setting in the OFF control mode are not applicable in this mode.)
7: Main shaft clutch control request leading edge	The clutch is turned ON when the link device assigned to the main shaft clutch control request by the link device external signal assignment function passes the leading edge (from OFF to ON).
8: Main shaft clutch control request trailing edge	The clutch is turned ON when the link device assigned to the main shaft clutch control request by the link device external signal assignment function passes the trailing edge (from ON to OFF).

Point

Other clutch parameters are not applicable during direct coupled operation by setting "0: No clutch". "[Cd.402] Main shaft clutch forced OFF command" and the change of the clutch control setting are ignored during direct coupled operation.

■OFF control mode

Setting value	Details
0: OFF control invalid	Clutch OFF control is not used. This setting is applicable only for execution with clutch ON control.
1: One-shot OFF	The clutch is turned OFF after moving the distance "[Pr.410] Movement amount before main shaft clutch OFF" (One-shot operation) after the clutch command turns ON. If "[Pr.410] Movement amount before main shaft clutch OFF" is 0, "[Md.420] Main shaft clutch ON/OFF status" does not turn ON in order to turn back OFF immediately.
2: Clutch command leading edge	The clutch is turned OFF when "[Cd.400] Main shaft clutch command" passes the leading edge (from OFF to ON).
3: Clutch command trailing edge	The clutch is turned OFF when "[Cd.400] Main shaft clutch command" passes the trailing edge (from ON to OFF).
4: Address mode	The clutch is turned OFF when the reference address (the current value after composite main shaft gear or the current value per cycle after main shaft gear) reaches "[Pr.409] Main shaft clutch OFF address". The movement amount before passing through the OFF address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
7: Main shaft clutch control request leading edge	The clutch is turned OFF when the link device assigned to the main shaft clutch control request by the link device external signal assignment function passes the leading edge (from OFF to ON).
8: Main shaft clutch control request trailing edge	The clutch is turned OFF when the link device assigned to the main shaft clutch control request by the link device external signal assignment function passes the trailing edge (from ON to OFF).

[Pr.406] Main shaft clutch reference address setting

Select the address type to be used as the reference address for clutch control. Note that the processing order of the main shaft gear and the main shaft clutch will change depending on the reference address setting.

Setting value	Details
0: Current value after composite main shaft gear	The clutch is controlled by using the current value after composite main shaft gear as a reference. Output after the clutch is a converted movement amount through the main shaft gear.
1: Current value per cycle after main shaft gear	The clutch is controlled by using the current value per cycle after main shaft gear. Output after the clutch is a movement amount without conversion.

The setting values for the following parameters are in units based on the reference address setting.

- "[Pr.407] Main shaft clutch ON address"
- "[Pr.409] Main shaft clutch OFF address"
- "[Pr.408] Movement amount before main shaft clutch ON", "[Pr.410] Movement amount before main shaft clutch OFF"
- "[Pr.413] Slippage amount at main shaft clutch ON", "[Pr.414] Slippage amount at main shaft clutch OFF"

[Pr.407] Main shaft clutch ON address

Set the clutch ON address when address mode is configured for the ON control mode of the main shaft clutch.

When the reference address is the current value per cycle after main shaft gear, the setting address is converted for control within the range from 0 to (Cam axis length per cycle - 1).

Ex.


Cam axis length per cycle: 20000 pulses

The ON address is controlled as 19000 pulses when the setting value is "-1000".

[Pr.408] Movement amount before main shaft clutch ON

Set the movement amount of the reference address with a signed value between the clutch ON condition completing and the clutch closing.

Setting value	Details
1 to 2147483647 (Positive value)	Used when the reference address is increasing in direction.
0	No movement amount (The clutch is immediately turned ON with the clutch ON condition completing.)
-2147483648 to -1 (Negative value)	Used when the reference address is decreasing in direction.



[Pr.409] Main shaft clutch OFF address

Set the clutch OFF address when address mode is configured for the OFF control mode of the main shaft clutch. When the reference address is the current value per cycle after main shaft gear, the setting address is converted for control within the range from 0 to (Cam axis length per cycle - 1).

Ex.


Cam axis length per cycle: 20000 pulses

The OFF address is controlled as 60 pulses when the setting value is "40060".

[Pr.410] Movement amount before main shaft clutch OFF

Set the movement amount of the reference address with a signed value between the clutch OFF condition completing and the clutch opening.

Setting value	Details
1 to 2147483647 (Positive value)	Used when the reference address is increasing in direction.
0	No movement amount (The clutch is immediately turned OFF with the clutch OFF condition completing.)
-2147483648 to -1 (Negative value)	Used when the reference address is decreasing in direction.



[Pr.411] Main shaft clutch smoothing method

Set the smoothing method for clutch ON/OFF.

Refer to the following.

 Page 101 Smoothing method for clutch

Setting value	Details
0: Direct	No smoothing
1: Time constant method (Exponent)	Smoothing with an exponential curve based on the time constant setting.
2: Time constant method (Linear)	Smoothing with linear acceleration/deceleration based on the time constant setting.
3: Slippage method (Exponent)	Smoothing with an exponential curve based on the slippage amount setting.
4: Slippage method (Linear)	Smoothing with linear acceleration/deceleration based on the slippage amount setting.
5: Slippage method (Linear: Input value follow up)	Smoothing with linear acceleration/deceleration based on the slippage amount setting (input value follow up).

[Pr.412] Main shaft clutch smoothing time constant

Set a time constant when the time constant method is set in "[Pr.411] Main shaft clutch smoothing method".

The time constant setting applies for clutch ON/OFF.

[Pr.413] Slippage amount at main shaft clutch ON

Set the slippage amount at clutch ON when the slippage method is set in "[Pr.411] Main shaft clutch smoothing method".

The slippage amount is set in units based on the current value selected in "[Pr.406] Main shaft clutch reference address setting".

If the set amount is negative, slippage amount at clutch ON is controlled as 0 (direct).

[Pr.414] Slippage amount at main shaft clutch OFF

Set the slippage amount at clutch OFF when the slippage method is set in "[Pr.411] Main shaft clutch smoothing method".

The slippage amount is set in units based on the current value selected in "[Pr.406] Main shaft clutch reference address setting".

If the set amount is negative, slippage amount at clutch OFF is controlled as 0 (direct).

Main shaft clutch control data

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.400] Main shaft clutch command	<ul style="list-style-type: none"> Set the clutch command ON/OFF. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 0: Main shaft clutch command OFF 1: Main shaft clutch command ON 	0	44080+20n
[Cd.401] Main shaft clutch control invalid command	<ul style="list-style-type: none"> Set "1" to disable the clutch control temporarily. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 0: Main shaft clutch control valid 1: Main shaft clutch control invalid 	0	44081+20n
[Cd.402] Main shaft clutch forced OFF command	<ul style="list-style-type: none"> Set "1" to force the clutch OFF. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 0: Main shaft clutch normal control 1: Main shaft clutch forced OFF 	0	44082+20n

For labels, refer to the following.

 Page 157 Control data for synchronous control

[Cd.400] Main shaft clutch command

Set ON/OFF for the main shaft clutch command. This command is used when the clutch ON control mode is "1: Clutch command ON/OFF", "2: Clutch command leading edge" or "3: Clutch command trailing edge" and the clutch OFF control mode is "2: Clutch command leading edge" or "3: Clutch command trailing edge".

Status is considered as clutch command OFF just before starting synchronous control. If synchronous control is started while the clutch command is ON, the condition is established just after starting synchronous control, by setting "2: Clutch command leading edge". The condition is not established just after starting, by setting "3: Clutch command trailing edge".

[Cd.401] Main shaft clutch control invalid command

The main shaft clutch control is invalid if "1" is set. The previous clutch ON/OFF status remains before clutch control becomes invalid.

Clutch control will not become invalid during the movement before clutch ON and clutch OFF. Instead, clutch control will become invalid after movement is completed.

[Cd.402] Main shaft clutch forced OFF command

Set "1" to force the clutch OFF. The output value from the clutch becomes 0 immediately, even during clutch smoothing. The slippage (accumulative) amount is set to 0 if smoothing with a slippage method.

Reset to "0" to restart the clutch control from the clutch OFF status after using the clutch forced OFF command.


4.2 Auxiliary Shaft Module

Overview of auxiliary shaft module

For the auxiliary shaft module, the input value is generated from the auxiliary shaft. The input value can be converted by the auxiliary shaft gear that provides the deceleration ratio and the rotation direction for the machine system, etc.

Refer to the followings for details on setting for the auxiliary shaft module.

☞ Page 86 Auxiliary shaft parameters, ☞ Page 88 Auxiliary shaft clutch parameters



*1 ☞ Page 94 Clutch

Auxiliary shaft parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.418] Auxiliary shaft axis No.	<ul style="list-style-type: none"> Set the input axis No. for the auxiliary shaft. Fetch cycle: <u>At start of synchronous control</u>	■Set in decimal. 0: Invalid 1 to 16: Servo input axis 801 to 816: Synchronous encoder axis	0	36430+200n
[Pr.419] Composite auxiliary shaft gear	<ul style="list-style-type: none"> Select the composite method for input values from the main shaft and the auxiliary shaft. Fetch cycle: <u>Operation cycle</u>	■Set in hexadecimal. H <ul style="list-style-type: none"> Main shaft input method <ul style="list-style-type: none"> 0: No input 1: Input + 2: Input - Auxiliary shaft input method <ul style="list-style-type: none"> 0: No input 1: Input + 2: Input - 	0001H	36431+200n
[Pr.420] Auxiliary shaft gear: Numerator	<ul style="list-style-type: none"> Set the numerator for the auxiliary shaft gear. Fetch cycle: <u>At start of synchronous control</u>	■Set in decimal. -2147483648 to 2147483647	1	36432+200n 36433+200n
[Pr.421] Auxiliary shaft gear: Denominator	<ul style="list-style-type: none"> Set the denominator for the auxiliary shaft gear. Fetch cycle: <u>At start of synchronous control</u>	■Set in decimal. 1 to 2147483647	1	36434+200n 36435+200n

For labels, refer to the following.

☞ Page 153 Synchronous parameters: Auxiliary shaft

[Pr.418] Auxiliary shaft axis No.

Set the input axis No. for the auxiliary shaft.

Setting value	Details
0: Invalid	The input value is always 0.
1 to 16: Servo input axis	Set the servo input axis (axis 1 to axis 16). When the servo input axis is not set in the system setting, the input value is always 0. If the No. is set to the same value as the output axis, the error "Outside auxiliary shaft No. range" (error code: 1BF0H) occurs and synchronous control cannot be started.
801 to 816: Synchronous encoder axis	Set the synchronous encoder axis (axis 1 to axis 16). When the synchronous encoder axis is invalid, the input value is always 0.

[Pr.419] Composite auxiliary shaft gear

Set the composite method for input values from the main and auxiliary shafts. The setting values for each axis are shown as follows.

Setting value	Details
0: No input	The input value from the input axis is calculated as 0.
1: Input+	The input value from the input axis is calculated as it is.
2: Input-	The input value from the input axis is calculated with its opposite sign.

Operation assumes "0: No input" if the value is set out of the range from 0 to 2.

Point

The composite method for the composite auxiliary shaft gear can be changed during synchronous control. It is used as a clutch to switch input values between the main and the auxiliary shafts.

[Pr.420] Auxiliary shaft gear: Numerator, [Pr.421] Auxiliary shaft gear: Denominator

Set the numerator and the denominator for auxiliary shaft gear to convert the input value. The input value is converted as follows.

$$\text{Input value after conversion} = \text{Input value before conversion} \times \frac{[\text{Pr.420}] \text{ Auxiliary shaft gear: Numerator}}{[\text{Pr.421}] \text{ Auxiliary shaft gear: Denominator}}$$

The input value direction can be reversed by setting a negative value in the numerator of the auxiliary shaft gear.

Set the denominator of the auxiliary shaft gear to a value within the range from 1 to 2147483647.

Auxiliary shaft clutch parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.422] Auxiliary shaft clutch control setting	<ul style="list-style-type: none"> Set the control method for the clutch. <p><u>Fetch cycle: Operation cycle</u></p>	<p>■Set in hexadecimal.</p> <p>H</p> <ul style="list-style-type: none"> ON control mode <ul style="list-style-type: none"> 0: No clutch 1: Clutch command ON/OFF 2: Clutch command leading edge 3: Clutch command trailing edge 4: Address mode 6: Auxiliary shaft clutch control request ON/OFF 7: Auxiliary shaft clutch control request leading edge 8: Auxiliary shaft clutch control request trailing edge OFF control mode <ul style="list-style-type: none"> 0: OFF control invalid 1: One-shot OFF 2: Clutch command leading edge 3: Clutch command trailing edge 4: Address mode 7: Auxiliary shaft clutch control request leading edge 8: Auxiliary shaft clutch control request trailing edge 	0000H	36436+200n
[Pr.423] Auxiliary shaft clutch reference address setting	<ul style="list-style-type: none"> Set the reference address for the clutch. <p><u>Fetch cycle: At start of synchronous control</u></p>	<p>■Set in decimal.</p> <ul style="list-style-type: none"> 0: Auxiliary shaft current value 1: Current value per cycle after auxiliary shaft gear 	0	36437+200n
[Pr.424] Auxiliary shaft clutch ON address	<ul style="list-style-type: none"> Set the clutch ON address for address mode. (This setting is invalid except during address mode.) If the address is out of the range from 0 to (Cam axis length per cycle - 1), the address is converted to a value within range. <p><u>Fetch cycle: Operation cycle</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647</p> <p>[Auxiliary shaft position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36438+200n 36439+200n
[Pr.425] Movement amount before auxiliary shaft clutch ON	<ul style="list-style-type: none"> Set the movement amount between the clutch ON condition completing and the clutch closing. Set a positive value when the reference address is increasing, and a negative value when it is decreasing. <p><u>Fetch cycle: At completing clutch ON condition</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647</p> <p>[Auxiliary shaft position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36440+200n 36441+200n
[Pr.426] Auxiliary shaft clutch OFF address	<ul style="list-style-type: none"> Set the clutch OFF address for the address mode. (This setting is invalid except during address mode.) If the address is out of the range from 0 to (Cam axis length per cycle - 1), the setting address is converted to a value within range. <p><u>Fetch cycle: Operation cycle</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647</p> <p>[Auxiliary shaft position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36442+200n 36443+200n
[Pr.427] Movement amount before auxiliary shaft clutch OFF	<ul style="list-style-type: none"> Set the movement amount between the clutch OFF condition completing and the clutch opening. Set a positive value when the reference address is increasing, and a negative value when it is decreasing. <p><u>Fetch cycle: At completing clutch OFF condition</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647</p> <p>[Auxiliary shaft position units^{*1}, or cam axis cycle units^{*2}]</p>	0	36444+200n 36445+200n
[Pr.428] Auxiliary shaft clutch smoothing method	<ul style="list-style-type: none"> Set the clutch smoothing method. <p><u>Fetch cycle: At start of synchronous control</u></p>	<p>■Set in decimal.</p> <ul style="list-style-type: none"> 0: Direct 1: Time constant method (Exponent) 2: Time constant method (Linear) 3: Slippage method (Exponent) 4: Slippage method (Linear) 5: Slippage method (Linear: Input value follow up) 	0	36446+200n

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.429] Auxiliary shaft clutch smoothing time constant	<ul style="list-style-type: none"> For smoothing with a time constant method, set the smoothing time constant. <u>Fetch cycle: At start of synchronous control</u>	■Set in decimal. 0 to 5000 [ms]	0	36447+200n
[Pr.430] Slippage amount at auxiliary shaft clutch ON	<ul style="list-style-type: none"> For smoothing with a slippage method, set the slippage amount at clutch ON. <u>Fetch cycle: At turning clutch ON.</u>	■Set in decimal. 0 to 2147483647 [Auxiliary shaft position units* ¹ , or cam axis cycle units* ²]	0	36448+200n 36449+200n
[Pr.431] Slippage amount at auxiliary shaft clutch OFF	<ul style="list-style-type: none"> For smoothing with a slippage method, set the slippage amount at clutch OFF. <u>Fetch cycle: At turning clutch OFF.</u>	■Set in decimal. 0 to 2147483647 [Auxiliary shaft position units* ¹ , or cam axis cycle units* ²]	0	36450+200n 36451+200n

*1 Auxiliary shaft position units ( Page 24 INPUT AXIS MODULE)

*2 Cam axis cycle units ( Page 110 Units for the output axis)

For labels, refer to the following.

 Page 153 Synchronous parameters: Auxiliary shaft

[Pr.422] Auxiliary shaft clutch control setting

Set the ON and OFF control methods separately for the auxiliary shaft.

The clutch control setting can be changed during synchronous control, however the setting to "No clutch" (Direct coupled operation) cannot be selected during synchronous control after already selecting another setting.

Refer to the following for operation details on the clutch control.

 Page 94 Control method for clutch

■ON control mode

Setting value	Details
0: No clutch (Direct coupled operation)	Execute direct coupled operation without clutch control.
1: Clutch command ON/OFF	The clutch is turned ON/OFF by the operation of "[Cd.403] Auxiliary shaft clutch command" ON/OFF. (Setting in the OFF control mode are not applicable in this mode.)
2: Clutch command leading edge	The clutch is turned ON when "[Cd.403] Auxiliary shaft clutch command" passes the leading edge (from OFF to ON).
3: Clutch command trailing edge	The clutch is turned ON when "[Cd.403] Auxiliary shaft clutch command" passes the trailing edge (from ON to OFF).
4: Address mode	The clutch is turned ON when the reference address (the auxiliary shaft current value or the current value per cycle after auxiliary shaft gear) reaches "[Pr.424] Auxiliary shaft clutch ON address". The movement amount after passing through the ON address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
6: Auxiliary shaft clutch control request ON/OFF	The clutch is turned ON/OFF by ON/OFF operation of the link device assigned to the auxiliary shaft clutch control request by the link device external signal assignment function. (Setting in the OFF control mode are not applicable in this mode.)
7: Auxiliary shaft clutch control request leading edge	The clutch is turned ON when the link device assigned to the auxiliary shaft clutch control request by the link device external signal assignment function passes the leading edge (from OFF to ON).
8: Auxiliary shaft clutch control request trailing edge	The clutch is turned ON when the link device assigned to the auxiliary shaft clutch control request by the link device external signal assignment function passes the trailing edge (from ON to OFF).

Point

Other clutch parameters are not applicable during direct coupled operation by setting "0: No clutch". "[Cd.405] Auxiliary shaft clutch forced OFF command" and the change of the clutch control setting are ignored during direct coupled operation.

■OFF control mode

Setting value	Details
0: OFF control invalid	Clutch OFF control is not used. This setting is applicable only for execution with clutch ON control.
1: One-shot OFF	The clutch is turned OFF after moving the distance "[Pr.427] Movement amount before auxiliary shaft clutch OFF" (One-shot operation) after the clutch command turns ON. If "[Pr.427] Movement amount before auxiliary shaft clutch OFF" is 0, "[Md.423] Auxiliary shaft clutch ON/OFF status" does not turn ON in order to turn back OFF immediately.
2: Clutch command leading edge	The clutch is turned OFF when "[Cd.403] Auxiliary shaft clutch command" passes the leading edge (from OFF to ON).
3: Clutch command trailing edge	The clutch is turned OFF when "[Cd.403] Auxiliary shaft clutch command" passes the trailing edge (from ON to OFF)
4: Address mode	The clutch is turned OFF when the reference address (the auxiliary shaft current value or the current value per cycle after auxiliary shaft gear) reaches "[Pr.426] Auxiliary shaft clutch OFF address". The movement amount before passing through the OFF address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.
7: Auxiliary shaft clutch control request leading edge	The clutch is turned OFF when the link device assigned to the auxiliary shaft clutch control request by the link device external signal assignment function passes the leading edge (from OFF to ON).
8: Auxiliary shaft clutch control request trailing edge	The clutch is turned OFF when the link device assigned to the auxiliary shaft clutch control request by the link device external signal assignment function passes the trailing edge (from ON to OFF).

[Pr.423] Auxiliary shaft clutch reference address setting

Select the address type to be used as the reference address for clutch control. Note that the processing order of the auxiliary shaft gear and the auxiliary shaft clutch will change depending on the reference address setting.

Setting value	Details
0: Auxiliary shaft current value	The clutch is controlled by using the current value for the servo input axis/synchronous encoder axis that is set for the auxiliary shaft. Output after the clutch is a converted movement amount through the auxiliary shaft gear.
1: Current value per cycle after auxiliary shaft gear	The clutch is controlled by using the current value per cycle after auxiliary shaft gear. Output after the clutch is a movement amount without conversion.

The setting values for the following parameters are in units based on the reference address setting.

- "[Pr.424] Auxiliary shaft clutch ON address"
- "[Pr.426] Auxiliary shaft clutch OFF address"
- "[Pr.425] Movement amount before auxiliary shaft clutch ON", "[Pr.427] Movement amount before auxiliary shaft clutch OFF"
- "[Pr.430] Slippage amount at auxiliary shaft clutch ON", "[Pr.431] Slippage amount at auxiliary shaft clutch OFF"

[Pr.424] Auxiliary shaft clutch ON address

Set the clutch ON address when address mode is configured for the ON control mode of the auxiliary shaft clutch.

When the reference address is the current value per cycle after auxiliary shaft gear, the setting address is converted for control within the range from 0 to (Cam axis length per cycle - 1).

Ex.


Cam axis length per cycle: 20000 pulses

The ON address is controlled as 19000 pulses when the setting value is "-1000".

[Pr.425] Movement amount before auxiliary shaft clutch ON

Set the movement amount of the reference address with a signed value between the clutch ON condition completing and the clutch closing.

Setting value	Details
1 to 2147483647 (Positive value)	Used when the reference address is increasing in direction.
0	No movement amount (The clutch is immediately turned ON with the clutch ON condition completing.)
-2147483648 to -1 (Negative value)	Used when the reference address is decreasing in direction.



[Pr.426] Auxiliary shaft clutch OFF address

Set the clutch OFF address when address mode is configured for the OFF control mode of the auxiliary shaft clutch. When the reference address is the current value per cycle after auxiliary shaft gear, the setting address is converted for control within the range from 0 to (Cam axis length per cycle - 1).

Ex.


Cam axis length per cycle: 20000 pulses

The OFF address is controlled as 60 pulses when the setting value is "40060".

[Pr.427] Movement amount before auxiliary shaft clutch OFF

Set the movement amount of the reference address with a signed value between the clutch OFF condition completing and the clutch opening.

Setting value	Details
1 to 2147483647 (Positive value)	Used when the reference address is increasing in direction.
0	No movement amount (The clutch is immediately turned OFF with the clutch OFF condition completing.)
-2147483648 to -1 (Negative value)	Used when the reference address is decreasing in direction.



[Pr.428] Auxiliary shaft clutch smoothing method

Set the smoothing method for clutch ON/OFF.

Refer to the following.

☞ Page 101 Smoothing method for clutch

Setting value	Details
0: Direct	No smoothing.
1: Time constant method (Exponent)	Smoothing with an exponential curve based on the time constant setting.
2: Time constant method (Linear)	Smoothing with linear acceleration/deceleration based on the time constant setting.
3: Slippage method (Exponent)	Smoothing with an exponential curve based on the slippage amount setting.
4: Slippage method (Linear)	Smoothing with linear acceleration/deceleration based on the slippage amount setting.
5: Slippage method (Linear: Input value follow up)	Smoothing with linear acceleration/deceleration based on the slippage amount setting (input value follow up).

[Pr.429] Auxiliary shaft clutch smoothing time constant

Set a time constant when the time constant method is set in "[Pr.428] Auxiliary shaft clutch smoothing method".

The time constant setting applies for clutch ON/OFF.

[Pr.430] Slippage amount at auxiliary shaft clutch ON

Set the slippage amount at clutch ON when the slippage method is set in "[Pr.428] Auxiliary shaft clutch smoothing method".

The slippage amount is set in units based on the current value selected in "[Pr.423] Auxiliary shaft clutch reference address setting".

If the set amount is negative, the slippage amount at clutch ON is controlled as 0 (direct).

[Pr.431] Slippage amount at auxiliary shaft clutch OFF

Set the slippage amount at clutch OFF when the slippage method is set in "[Pr.428] Auxiliary shaft clutch smoothing method".

The slippage amount is set in units based on the current value selected in "[Pr.423] Auxiliary shaft clutch reference address setting".

If the set amount is negative, the slippage amount at clutch OFF is controlled as 0 (direct).

Auxiliary shaft clutch control data

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.403] Auxiliary shaft clutch command	<ul style="list-style-type: none"> Set the clutch command ON/OFF. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 0: Auxiliary shaft clutch command OFF 1: Auxiliary shaft clutch command ON 	0	44083+20n
[Cd.404] Auxiliary shaft clutch control invalid command	<ul style="list-style-type: none"> Set "1" to disable the clutch control temporarily. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 0: Auxiliary shaft clutch control valid 1: Auxiliary shaft clutch control invalid 	0	44084+20n
[Cd.405] Auxiliary shaft clutch forced OFF command	<ul style="list-style-type: none"> Set "1" to force the clutch OFF. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 0: Auxiliary shaft clutch normal control 1: Auxiliary shaft clutch forced OFF 	0	44085+20n

For labels, refer to the following.

 Page 157 Control data for synchronous control

[Cd.403] Auxiliary shaft clutch command

Set ON/OFF for the auxiliary shaft clutch command. This command is used when the clutch ON control mode is "1: Clutch command ON/OFF", "2: Clutch command leading edge" or "3: Clutch command trailing edge" and the clutch OFF control mode is "2: Clutch command leading edge" or "3: Clutch command trailing edge".

Status is considered as clutch command OFF just before starting synchronous control. If synchronous control is started while the clutch command is ON, the condition is established just after starting synchronous control, by setting "2: Clutch command leading edge". The condition is not established after starting, by setting "3: Clutch command trailing edge."

[Cd.404] Auxiliary shaft clutch control invalid command

The auxiliary shaft clutch control is invalid if "1" is set. The previous clutch ON/OFF status remains before clutch control becomes invalid.

Clutch control will not become invalid during the movement before clutch ON and clutch OFF. Instead, clutch control will become invalid after the movement is completed.

[Cd.405] Auxiliary shaft clutch forced OFF command

Set "1" to force the clutch OFF. The output value from the clutch becomes 0 immediately, even during clutch smoothing. The slippage (accumulative) amount is set to 0 if smoothing with a slippage method.

Reset to "0" to restart the clutch control from the clutch OFF status after using the clutch forced OFF command.

4.3 Clutch

Overview of clutch

The clutch is used to transmit/disengage command pulses from the main/auxiliary shaft input side to the output axis module through turning the clutch ON/OFF, which controls the operation/stop of the servomotor.

A clutch can be configured for the main and auxiliary shafts.

Control method for clutch

Set the ON and OFF control methods separately in "[Pr.405] Main shaft clutch control setting" and "[Pr.422] Auxiliary shaft clutch control setting".

The clutch control setting can be changed during synchronous control, however, the setting "No clutch" (Direct coupled operation) cannot be selected during synchronous control after already selecting another setting.

Item	Setting item		Setting details/Setting value
	Main shaft clutch	Auxiliary shaft clutch	
Clutch control setting	[Pr.405] Main shaft clutch control setting	[Pr.422] Auxiliary shaft clutch control setting	<ul style="list-style-type: none"> • Set the clutch control method. ■ Set in hexadecimal. <div style="margin-left: 20px;"> <p>H</p> <ul style="list-style-type: none"> → ON control mode <ul style="list-style-type: none"> 0: No clutch 1: Clutch command ON/OFF 2: Clutch command leading edge 3: Clutch command trailing edge 4: Address mode 6: Main/auxiliary shaft clutch control request ON/OFF 7: Main/auxiliary shaft clutch control request leading edge 8: Main/auxiliary shaft clutch control request trailing edge → OFF control mode <ul style="list-style-type: none"> 0: OFF control invalid 1: One-shot OFF 2: Clutch command leading edge 3: Clutch command trailing edge 4: Address mode 7: Main/auxiliary shaft clutch control request leading edge 8: Main/auxiliary shaft clutch control request trailing edge </div>

When the clutch ON condition and the clutch OFF condition are completed simultaneously within one operation cycle, both clutch ON and OFF processing are executed within one operation cycle. Therefore, the clutch is from OFF to ON and again to OFF at the clutch OFF status, and it is from ON to OFF and again to ON at the clutch ON status.

The following shows the operations for the clutch ON/OFF by the setting of the ON control mode and the OFF control mode.

ON control mode

■No clutch (Direct coupled operation)

Execute direct coupled operation without clutch control.


Point

Other clutch parameters are not applicable during direct coupled operation by setting "0: No clutch". "Clutch forced OFF command" and the change of the clutch control setting are ignored during direct coupled operation.

■Clutch command ON/OFF

The clutch is turned ON/OFF by the operation of clutch command ON/OFF.


(Setting in the OFF control mode are not applicable in this mode.)



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch command	[Cd.400] Main shaft clutch command	[Cd.403] Auxiliary shaft clutch command
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status


■Clutch command leading edge

The clutch is turned ON when the clutch command passes the leading edge (from OFF to ON).



■Clutch command trailing edge


The clutch is turned ON when the clutch command passes the trailing edge (from ON to OFF).



■Address mode

The clutch is turned ON when the reference address reaches "Clutch ON address".

The movement amount after passing through the ON address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.



Item	Main shaft clutch	Auxiliary shaft clutch
Reference address	The current value specified in "[Pr.406] Main shaft clutch reference address setting" ("[Md.400] Current value after composite main shaft gear" or "[Md.401] Current value per cycle after main shaft gear")	The current value specified in "[Pr.423] Auxiliary shaft clutch reference address setting" (Auxiliary shaft current value (servo input axis current value/synchronous encoder axis current value) or "[Md.402] Current value per cycle after auxiliary shaft gear")
Clutch ON address	[Pr.407] Main shaft clutch ON address	[Pr.424] Auxiliary shaft clutch ON address
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status

■Main shaft clutch control request ON/OFF


The clutch is turned ON/OFF by ON/OFF operation of the link device assigned to the "Main shaft clutch control request". (Setting in the OFF control mode are not applicable in this mode.)

The clutch is turned OFF when a communication error occurs in the station of the assigned link device.

The following actions are required when using the main shaft clutch control request.

- Assign the link device to the main shaft clutch control request with the link device external signal assignment function.
- Set "1: Validates an external command" in "[Cd.8] External command valid".

Item	Main shaft clutch	Auxiliary shaft clutch
Clutch command	Link device assigned to the main shaft clutch control request with the link device external signal assignment function	Link device assigned to the auxiliary shaft clutch control request with the link device external signal assignment function
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status




■Main shaft clutch control request leading edge

The clutch is turned ON when the link device assigned to the "Main shaft clutch control request" passes the leading edge (from OFF to ON).

The clutch is turned OFF when a communication error occurs in the station of the assigned link device.

The following actions are required when using the main shaft clutch control request.

- Assign the link device to the main shaft clutch control request with the link device external signal assignment function.
- Set "1: Validates an external command" in "[Cd.8] External command valid".




■Main shaft clutch control request trailing edge

The clutch is turned ON when the link device assigned to the "Main shaft clutch control request" passes the trailing edge (from ON to OFF).

The clutch is turned OFF when a communication error occurs in the station of the assigned link device.

The following actions are required when using the main shaft clutch control request.

- Assign the link device to the main shaft clutch control request with the link device external signal assignment function.
- Set "1: Validates an external command" in "[Cd.8] External command valid".



OFF control mode


■OFF control invalid

Clutch OFF control is not used. This setting is applicable only for execution with clutch ON control.

■One-shot OFF

The clutch is turned OFF after moving the distance "Movement amount before clutch OFF" (One-shot operation) after the clutch command turn ON.


If "Movement amount before clutch OFF" is 0, "Clutch ON/OFF status" does not turn ON in order to turn back OFF immediately.



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch command	[Cd.400] Main shaft clutch command	[Cd.403] Auxiliary shaft clutch command
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status
Movement amount before clutch OFF	[Pr.410] Movement amount before main shaft clutch OFF	[Pr.427] Movement amount before auxiliary shaft clutch OFF


■Clutch command leading edge

The clutch is turned OFF when the clutch command passes the leading edge (from OFF to ON).



■Clutch command trailing edge


The clutch is turned OFF when the clutch command passes the trailing edge (from ON to OFF).



■Address mode

The clutch is turned OFF when the reference address reaches "Clutch OFF address".

The movement amount before passing through the OFF address is calculated as the output movement amount of the clutch based on the reference address passing through, thereby controlling the clutch with an accurate movement amount.



Item	Main shaft clutch	Auxiliary shaft clutch
Reference address	The current value specified in "[Pr.406] Main shaft clutch reference address setting" ("[Md.400] Current value after composite main shaft gear" or "[Md.401] Current value per cycle after main shaft gear")	The current value specified in "[Pr.423] Auxiliary shaft clutch reference address setting" (Auxiliary shaft current value (servo input axis current value/synchronous encoder axis current value) or "[Md.402] Current value per cycle after auxiliary shaft gear")
Clutch OFF address	[Pr.409] Main shaft clutch OFF address	[Pr.426] Auxiliary shaft clutch OFF address
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status


■Auxiliary shaft clutch control request leading edge

The clutch is turned ON when the link device assigned to the "Auxiliary shaft clutch control request" passes the leading edge (from OFF to ON).

The clutch is turned OFF when a communication error occurs in the station of the assigned link device.

The following actions are required when using the auxiliary shaft clutch control request.

- Assign the link device to the auxiliary shaft clutch control request with the link device external signal assignment function.
- Set "1: Validates an external command" in "[Cd.8] External command valid".




■Auxiliary shaft clutch control request trailing edge

The clutch is turned ON when the link device assigned to the "Auxiliary shaft clutch control request" passes the trailing edge (from ON to OFF).

The clutch is turned OFF when a communication error occurs in the station of the assigned link device.

The following actions are required when using the auxiliary shaft clutch control request.

- Assign the link device to the auxiliary shaft clutch control request with the link device external signal assignment function.
- Set "1: Validates an external command" in "[Cd.8] External command valid".



Smoothing method for clutch

Set the clutch smoothing method in "[Pr.411] Main shaft clutch smoothing method" and "[Pr.428] Auxiliary shaft clutch smoothing method".

The 2 types of clutch smoothing include the following.

- Time constant method smoothing
- Slippage method smoothing

When not using clutch smoothing, set "0: Direct" in the clutch smoothing method.

Item	Setting item		Setting details/Setting value
	Main shaft clutch	Auxiliary shaft clutch	
Clutch smoothing method	[Pr.411] Main shaft clutch smoothing method	[Pr.428] Auxiliary shaft clutch smoothing method	<ul style="list-style-type: none"> • Set the clutch smoothing method. ■Set in decimal. 0: Direct 1: Time constant method (Exponent) 2: Time constant method (Linear) 3: Slippage method (Exponent) 4: Slippage method (Linear) 5: Slippage method (Linear: Input value follow up)

The operation of each smoothing method is shown below.

Time constant method smoothing

Smoothing is processed with the time constant setting value in the smoothing time constant at clutch ON/OFF. After clutch ON smoothing is complete, smoothing is processed with the time constant setting value when the speed of the input values changes.


The movement amount between the clutch turning ON and OFF is not changed with smoothing.

Movement amount after clutch smoothing = Movement amount before clutch smoothing

Item	Setting item		Setting details	Setting value
	Main shaft clutch	Auxiliary shaft clutch		
Clutch smoothing time constant	[Pr.412] Main shaft clutch smoothing time constant	[Pr.429] Auxiliary shaft clutch smoothing time constant	<ul style="list-style-type: none"> • For smoothing with a time constant method, set the smoothing time constant. 	<ul style="list-style-type: none"> ■Set in decimal. 0 to 5000 [ms]

■Time constant method exponential curve smoothing


Set "1: Time constant method (Exponential)" in the clutch smoothing method.



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status
Clutch smoothing status	[Md.421] Main shaft clutch smoothing status	[Md.424] Auxiliary shaft clutch smoothing status

Time constant method linear acceleration/deceleration smoothing

Set "2: Time constant method (Linear)" in the clutch smoothing method.



Slippage method smoothing

Smoothing is processed with the value in slippage at clutch ON when the clutch turns ON, and with slippage at clutch OFF when the clutch turns OFF.

Smoothing is also processed with the slippage amount setting when the input speed to the clutch changes, therefore, positioning control at clutch ON/OFF is not affected by speed changes.

Processing proceeds with direct operation after completing clutch ON smoothing.

The movement amount between the clutch turning ON and OFF is as follows after clutch smoothing.

Movement amount after clutch smoothing = Movement amount before clutch smoothing + (Slippage amount at OFF - Slippage amount at ON)

Item	Setting item		Setting details	Setting value
	Main shaft clutch	Auxiliary shaft clutch		
Slippage amount at clutch ON	[Pr.413] Slippage amount at main shaft clutch ON	[Pr.430] Slippage amount at auxiliary shaft clutch ON	For smoothing with a slippage method, set the slippage amount at clutch ON.	<ul style="list-style-type: none"> Set in decimal. 0 to 2147483647 [Main input axis position units^{*1}/ auxiliary shaft position units^{*2} or cam axis cycle units^{*3}]
Slippage amount at clutch OFF	[Pr.414] Slippage amount at main shaft clutch OFF	[Pr.431] Slippage amount at auxiliary shaft clutch OFF	For smoothing with a slippage method, set the slippage amount at clutch OFF.	


*1 Main input axis position units (Page 24 INPUT AXIS MODULE)

*2 Auxiliary shaft position units (Page 24 INPUT AXIS MODULE)

*3 Cam axis cycle units (Page 110 Units for the output axis)

Slippage method exponential curve smoothing

Set "3: Slippage (Exponential)" in the clutch smoothing method.



Item	Main shaft clutch	Auxiliary shaft clutch
Clutch ON/OFF status	[Md.420] Main shaft clutch ON/OFF status	[Md.423] Auxiliary shaft clutch ON/OFF status
Clutch smoothing status	[Md.421] Main shaft clutch smoothing status	[Md.424] Auxiliary shaft clutch smoothing status


Slippage method linear acceleration/deceleration smoothing

Set "4: Slippage method (Linear)" or "5: Slippage method (Linear: Input value follow up)" in the clutch smoothing method. The differences between "4: Slippage method (Linear)" and "5: Slippage method (Linear: Input value follow up)" are shown below.

Input speed during smoothing	Smoothing method	
	4: Slippage method (Linear)	5: Slippage method (Linear: Input value follow up)
When the speed is fixed	No differences	
When the speed is changed continuously and slightly	Smoothing section is changed.	Smoothing section is fixed.
When the speed is changed largely	The output speed is changed slightly. (The average speed might be faster than the speed before starting smoothing.)	The output speed is changed depending on the input speed. (When the input speed is decelerated and accelerated again, the speed might be accelerated rapidly.)

- When the input speed to the clutch is fixed

The operations of "4: Slippage method (Linear)" and "5: Slippage method (Linear: Input value follow up)" are same.




- When the input speed to the clutch is changed continuously and slightly


["4: Slippage method (Linear)" is set.]

The clutch smoothing status ON section is changed.

When the clutch smoothing status ON section is extended




When the clutch smoothing status ON section is shortened



["5: Slippage method (Linear: Input value follow up)" is set.]

The clutch smoothing status ON section is fixed.




- When the input speed is changed largely during smoothing

["4: Slippage method (Linear)" is set.]

The output speed is changed slightly compared to the change of the input speed.


(The average speed might be faster than the speed before starting smoothing.)



["5: Slippage method (Linear: Input value follow up)" is set.]

The output speed is changed depending on the input speed.

(When the input speed is decelerated and accelerated again, the speed might be accelerated rapidly.)




■Operation at input speed deceleration during slippage method smoothing

When the speed before clutch processing decreases, the speed after clutch smoothing is controlled without exceeding the speed before clutch processing.


If slippage amount remains when the speed before clutch processing becomes 0, the smoothing process will be continued.

Then, the clutch smoothing process will be executed with the remaining slippage amount when the speed before clutch processing gets faster than the speed after clutch smoothing.




Use example of clutch

The following machine shows an example using clutch control for a flying shear cutting system that synchronizes off a start signal from a sensor input.



Main shaft clutch setting item	Setting value
[Pr.405] Main shaft clutch control setting	ON control mode: 7: Mainshaft clutch control request leading edge OFF control mode: 1: One-shot OFF
[Pr.406] Main shaft clutch reference address setting	0: Current value after composite main shaft gear
[Pr.408] Movement amount before main shaft clutch ON	0 mm
[Pr.410] Movement amount before main shaft clutch OFF	380 mm (14.96 inch)
[Pr.411] Main shaft clutch smoothing method	4: Slippage method (Linear)
[Pr.413] Slippage amount at main shaft clutch ON	100 mm (3.94 inch) (Distance between the sensor and the waiting position)
[Pr.414] Slippage amount at main shaft clutch OFF	20 mm (0.79 inch)





4.4 Speed Change Gear Module

Overview of speed change gear module

A speed change gear module is used to change the input speed from the main shaft/auxiliary shaft/composite auxiliary shaft gear during operation. When not using a speed change gear module, set "0: No speed change gear" in "[Pr.434] Speed change gear".

With speed change from a speed change gear module, operation is executed with linear acceleration/deceleration based on the setting for the speed change gear smoothing time constant.



Speed change gear parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.434] Speed change gear	<ul style="list-style-type: none"> Set the arrangement for the speed change gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: No speed change gear 1: Main shaft side 2: Auxiliary shaft side 3: After composite auxiliary shaft gear 	0	36460+200n
[Pr.435] Speed change gear smoothing time constant	<ul style="list-style-type: none"> Set the smoothing time constant for the speed change gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0 to 5000 [ms] 	0	36461+200n
[Pr.436] Speed change ratio: Numerator	<ul style="list-style-type: none"> Set the numerator for the speed change ratio. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. -2147483648 to 2147483647 	1	36462+200n 36463+200n
[Pr.437] Speed change ratio: Denominator	<ul style="list-style-type: none"> Set the denominator for the speed change ratio. <u>Fetch cycle: Operation cycle</u>	<ul style="list-style-type: none"> Set in decimal. 1 to 2147483647 	1	36464+200n 36465+200n

For labels, refer to the following.

☞ Page 153 Synchronous parameters: Speed change gear

[Pr.434] Speed change gear

Set the arrangement for the speed change gear.

Setting value	Details
0: No speed change gear	Speed change is not processed, and the input value is transmitted as is.
1: Main shaft side	Speed change is processed for input value after main shaft clutch based on the speed change ratio settings.
2: Auxiliary shaft side	Speed change is processed for input value after auxiliary shaft clutch based on the speed change ratio settings.
3: After composite auxiliary shaft gear	Speed change is processed for input value after composite auxiliary shaft gear based on the speed change ratio settings.

[Pr.435] Speed change gear smoothing time constant

Set the averaging time to execute a smoothing process for the speed change for the speed change gear.

The input response is delayed depending on the time set in the speed change gear smoothing time constant.

Speed is changed directly when "0" is set.

[Pr.436] Speed change ratio: Numerator, [Pr.437] Speed change ratio: Denominator

Set the numerator and the denominator for the speed change ratio.

"[Pr.436] Speed change ratio: Numerator" and "[Pr.437] Speed change ratio: Denominator" can be changed during synchronous control.

Input values for speed change are processed as follows.

$$\text{Input value after change} = \text{Input value before change} \times \frac{[\text{Pr.436}] \text{ Speed change ratio: Numerator}}{[\text{Pr.437}] \text{ Speed change ratio: Denominator}}$$


The input speed can be reversed by setting a negative value in "[Pr.436] Speed change ratio: Numerator".

"[Pr.437] Speed change ratio: Denominator" is set within the range from 1 to 2147483647.

4.5 Output Axis Module

Overview of output axis module

For the output axis module, the cam axis current value per cycle is calculated based on the input value (the output value from a speed change gear), and is converted based on the set cam data. The feed current value which is a command is output to the servo amplifier.



Units for the output axis

The position units for the output axis are shown below based on the setting "[Pr.1] Unit setting".

Setting value of "[Pr.1] Unit setting"	Output axis position unit	Range
0: mm	$\times 10^{-4}$ mm ($\times 10^{-1}$ μm)	-214748.3648 to 214748.3647 [mm] (-214748364.8 to 214748364.7 [μm])
1: inch	$\times 10^{-5}$ inch	-21474.83648 to 21474.83647 [inch]
2: degree	$\times 10^{-5}$ degree	-21474.83648 to 21474.83647 [degree]
3: pulse	pulse	-2147483648 to 2147483647 [pulse]

Cam axis cycle units are shown below based on the setting "[Pr.438] Cam axis cycle unit setting".

Setting value of "[Pr.438] Cam axis cycle unit setting"			Cam axis cycle unit	Range
Unit setting selection	Control unit	Number of decimal places		
0: Use units of main input axis	—	—	Servo input axis position unit (☞ Page 25 Servo input axis position units) Synchronous encoder axis position unit (☞ Page 32 Synchronous encoder axis position units)	
1: Use units of this setting	0: mm	0	mm	-2147483648 to 2147483647 [mm]
		∴	∴	∴
		9	$\times 10^{-9}$ mm	-2.147483648 to 2.147483647 [mm]
	1: inch	0	inch	-2147483648 to 2147483647 [inch]
		∴	∴	∴
		9	$\times 10^{-9}$ inch	-2.147483648 to 2.147483647 [inch]
	2: degree	0	degree	-2147483648 to 2147483647 [degree]
		∴	∴	∴
		9	$\times 10^{-9}$ degree	-2.147483648 to 2.147483647 [degree]
	3: pulse	0	pulse	-2147483648 to 2147483647 [pulse]
		∴	∴	∴
		9	$\times 10^{-9}$ pulse	-2.147483648 to 2.147483647 [pulse]

Output axis parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.438] Cam axis cycle unit setting	<ul style="list-style-type: none"> Set the units for the cam axis length per cycle. There is no influence on the control for the parameter for monitor display. <p>Fetch cycle: <u>At start of synchronous control</u></p>	<p>■Set in hexadecimal.</p> <p>H</p> <ul style="list-style-type: none"> Control unit 0: mm, 1: inch, 2: degree, 3: pulse Number of decimal places 0 to 9 Unit setting selection 0: Use units of main input axis 1: Use units of this setting 	0000H	36470+200n
[Pr.439] Cam axis length per cycle	<ul style="list-style-type: none"> Set the required input amount with the cam per cycle. <p>Fetch cycle: <u>At start of synchronous control, At passing through the 0th point of cam data</u></p>	<p>■Set in decimal.</p> <p>1 to 2147483647 [Cam axis cycle units*¹]</p>	4194304	36472+200n 36473+200n
[Pr.440] Cam No.	<ul style="list-style-type: none"> Set the cam No. <p>Fetch cycle: <u>At start of synchronous control, At passing through the 0th point of cam data</u></p>	<p>■Set in decimal.</p> <p>0: Linear cam (Preset) 1 to 1024: User created cam</p>	0	36474+200n
[Pr.441] Cam stroke amount	<ul style="list-style-type: none"> Set the cam stroke amount corresponding to the stroke ratio 100% for cam with stroke ratio data format. This is ignored for cams using the coordinate data format. <p>Fetch cycle: <u>At start of synchronous control, At passing through the 0th point of cam data</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647 [Output axis position units*²]</p>	4194304	36476+200n 36477+200n
[Pr.442] Cam axis length per cycle change setting	<ul style="list-style-type: none"> Set to change the "[Pr.439] Cam axis length per cycle" during synchronous control. <p>Fetch cycle: <u>At start of synchronous control</u></p>	<p>■Set in decimal.</p> <p>0: Invalid 1: Valid</p>	0	36471+200n
[Pr.444] Cam axis phase compensation advance time	<ul style="list-style-type: none"> Set the time to advance or delay the phase of the cam axis. <p>Fetch cycle: <u>Operation cycle</u></p>	<p>■Set in decimal.</p> <p>-2147483648 to 2147483647 [μs]</p>	0	36482+200n 36483+200n
[Pr.445] Cam axis phase compensation time constant	<ul style="list-style-type: none"> Set the time constant to affect the phase compensation of the cam axis. <p>Fetch cycle: <u>At start of synchronous control</u></p>	<p>■Set in decimal.</p> <p>0 to 65535 [ms]^{*3}</p>	10	36484+200n
[Pr.446] Synchronous control deceleration time	<ul style="list-style-type: none"> Set the deceleration time for the synchronous control. <p>Fetch cycle: <u>At start of synchronous control</u></p>	<p>■Set in decimal.</p> <p>0 to 65535 [ms]^{*3}</p>	0	36485+200n
[Pr.447] Output axis smoothing time constant	<ul style="list-style-type: none"> Set to smooth the output axis. <p>Fetch cycle: <u>At start of synchronous control</u></p>	<p>■Set in decimal.</p> <p>0 to 5000 [ms]</p>	0	36486+200n

*1 Cam axis cycle units ( Page 110 Units for the output axis)

*2 Output axis position units ( Page 110 Units for the output axis)

*3 Set the value as follows in a user program.

0 to 32767: Set as a decimal

32768 to 65535: Convert into a hexadecimal and set

For labels, refer to the following.

 Page 154 Synchronous parameters: Output axis

[Pr.438] Cam axis cycle unit setting

Set the command units for the cam axis input per cycle to be used for cam control.

These units are used for setting the cam axis length per cycle and the cam axis current value per cycle.

There is no influence on the control for the parameter for monitor display.

Refer to the following.

☞ Page 109 Overview of output axis module

[Pr.439] Cam axis length per cycle

Set the length per cycle of the cam axis to generate the cam axis current value per cycle.

The unit settings are in the cam axis cycle units (☞ Page 110 Units for the output axis).

Set a value within the range from 1 to 2147483647.

The cam axis length per cycle can be changed during synchronous control by setting "1: Valid" in "[Pr.442] Cam axis length per cycle change setting". The value set in "[Pr.439] Cam axis length per cycle" is valid when the cam axis current value per cycle passes through the 0th point of cam data, or is on the 0th point.


For cam data using the coordinate data format, if the input value of the last coordinate is less than "[Pr.439] Cam axis length per cycle", the coordinate is calculated from the line segment between the nearest two coordinates from the last coordinate.

The following shows an example in the case that "[Pr.439] Cam axis length per cycle" is changed to exceed the input value of the last coordinate of cam data using the coordinate data format during synchronous control.

[Coordinate data format]

- Cam axis length per cycle: 4194304 [pulse]
- Cam stroke amount: ± 4194304 [pulse]
- Coordinate data

Point	Input value	Output value
1	0	0
2	2097152	4194304
3	4194304	0



*1 The coordinate which is "an input value = a cam axis length per cycle" does not exist, so that the coordinate is calculated from the line segment between the nearest two coordinates from the last coordinate.

[Pr.440] Cam No.

Set the cam No. for cam control.

Cam No.0 operates as a linear cam for 100% of its stroke ratio along the cam axis length per cycle.

The cam No. can be changed during synchronous control.

The value set in "[Pr.440] Cam No." is valid when the cam axis current value per cycle passes through the 0th point of cam data, or is on the 0th point.

[Pr.441] Cam stroke amount

Set the cam stroke amount corresponding to a 100% stroke ratio in output axis position units ( Page 110 Units for the output axis) for cam control using the stroke ratio data format.

The cam stroke amount can be changed during synchronous control.

The value set in "[Pr.441] Cam stroke amount" is valid when the cam axis current value per cycle passes through the 0th point of cam data, or is on the 0th point.

The setting value is ignored for a cam using the coordinate data format.

[Pr.442] Cam axis length per cycle change setting

Set to change the cam axis length per cycle during synchronous control.

It can be changed for cam control using the cam No.0 (linear cam), the stroke ratio data format, and the coordinate data format. However, it cannot be changed when the cam data whose starting point is other than 0 is used for the stroke ratio data format.

Setting value	Details
0: Invalid	The cam axis length per cycle cannot be changed during synchronous control.
0: Valid	The value set in "[Pr.439] Cam axis length per cycle" is valid when the cam axis current value per cycle passes through the 0th point of cam data, or is on the 0th point.

[Pr.444] Cam axis phase compensation advance time

Set the time to advance or delay the phase of the cam axis current value per cycle in the cam control.


Setting value	Details
1 to 2147483647 [μ s]	Advance the phase according to the setting time.
0 [μ s]	Do not execute phase compensation.
-2147483648 to -1 [μ s]	Delay the phase according to the setting time.

If the setting time is too long, the system experiences overshoot or undershoot at acceleration/deceleration of the input speed. In this case, set a longer time to affect the phase compensation amount in "[Pr.445] Cam axis phase compensation time constant".

[Pr.445] Cam axis phase compensation time constant

Set the time constant to affect the phase compensation amount for the first order delay.

63 [%] of the phase compensation amount is reflected in the time constant setting.



[Pr.446] Synchronous control deceleration time

Set the time to decelerate to a stop when deceleration stop occurs during synchronous control.

Set the time from "[Pr.8] Speed limit value" until the speed becomes 0 in units of ms.


Operation assumes an immediate stop when "0" is set.

[Pr.447] Output axis smoothing time constant

Set the averaging time to execute a smoothing process for the movement amount of the output axis after cam data conversion.

The smoothing process can moderate rapid speed fluctuation for cams using the coordinate data format, etc.

The input response is delayed depending on the time corresponding to the setting by smoothing process setting.



4.6 Synchronous Control Change Function

Overview of synchronous control change function

This function can change the cam reference position, the cam axis current value per cycle and the current value per cycle after the main/auxiliary shaft gear during the synchronous control.

The following 5 methods exist for the synchronous control change function. Refer to the following on each change command.

☞ Page 115 Synchronous control change control data

Synchronous control change command	Application	Output axis operation
Cam reference position movement	Adjust the cam reference position by the movement amount.	Operated
Change cam axis current value per cycle	Change the cam axis current value per cycle.	None
Change current value per cycle after main shaft gear	Change the current value per cycle after main shaft gear.	None
Change current value per cycle after auxiliary shaft gear	Change the current value per cycle after auxiliary shaft gear.	None
Cam axis current value per cycle movement	Adjust the phase of the cam axis by the movement amount.	Operated

Synchronous control change control data

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.406] Synchronous control change request	<ul style="list-style-type: none"> Set "1" to initiate a synchronous control change command request. The value is reset to "0" automatically after completion of the synchronous control change. Fetch cycle: Operation cycle	■Set in decimal. 1: Synchronous control change request	0	44086+20n
[Cd.407] Synchronous control change command	<ul style="list-style-type: none"> Set the synchronous control change command. Fetch cycle: At requesting synchronous control change	■Set in decimal. 0: Cam reference position movement 1: Change cam axis current value per cycle 2: Change current value per cycle after main shaft gear 3: Change current value per cycle after auxiliary shaft gear 4: Cam axis current value per cycle movement	0	44087+20n
[Cd.408] Synchronous control change value	<ul style="list-style-type: none"> Set the change value for synchronous control change processing. Fetch cycle: At requesting synchronous control change	■Set in decimal. -2147483648 to 2147483647 (Refer to the detailed explanation for units.)	0	44088+20n 44089+20n
[Cd.409] Synchronous control reflection time	<ul style="list-style-type: none"> Set the reflection time for synchronous control change processing. Fetch cycle: At requesting synchronous control change	■Set in decimal. 0~65535 [ms] ^{*1}	0	44090+20n

*1 Set the value as follows in a user program.
 0 to 32767: Set as a decimal.
 32768 to 65535: Convert into a hexadecimal and set.

For labels, refer to the following.

☞ Page 157 Control data for synchronous control

[Cd.406] Synchronous control change request

Set "1" to initiate "[Cd.407] Synchronous control change command". The Simple Motion board resets the value to "0" automatically after completion of the synchronous control change.

The setting is initialized to "0" when starting synchronous control.


[Cd.407] Synchronous control change command

Set the synchronous control change command.

Setting value	Details	Reference
0	Cam reference position movement	Page 116 Cam reference position movement
1	Change cam axis current value per cycle	Page 116 Change cam axis current value per cycle
2	Change current value per cycle after main shaft gear	Page 117 Change current value per cycle after main shaft gear
3	Change current value per cycle after auxiliary shaft gear	Page 117 Change current value per cycle after auxiliary shaft gear
4	Cam axis current value per cycle movement	Page 117 Cam axis current value per cycle movement

■Cam reference position movement

This command is executed to move the cam reference position through adding the setting movement amount of "[Cd.408] Synchronous control change value". The movement amount to be added is averaged in "[Cd.409] Synchronous control reflection time" for its output. Set a long reflection time when a large movement amount is used since the cam axis feed current value moves with the movement amount.




When "[Cd.406] Synchronous control change request" is reset to "0" while executing the cam reference position movement instruction, operation is stopped midway. If the cam reference position movement instruction is executed again, the remainder movement amount is not reflected, and the operation starts with "[Cd.408] Synchronous control change value" to be used again.

If synchronous control is stopped while the cam reference position movement instruction is being executed, operation also stops midway. If synchronous control is restarted, the remainder movement amount is not reflected.

■Change cam axis current value per cycle

The cam axis current value per cycle is changed to "[Cd.408] Synchronous control change value". The cam reference position will be also changed to correspond to the changed cam axis current value per cycle.

This operation is completed within one operation cycle.



■Change current value per cycle after main shaft gear

The current value per cycle after main shaft gear is changed to the value set in "[Cd.408] Synchronous control change value". This operation is completed within one operation cycle.

Clutch control is not executed if the current value per cycle after main shaft gear (the value before being changed and after being changed) has already passed through the ON/OFF address in address mode.

■Change current value per cycle after auxiliary shaft gear

The current value per cycle after auxiliary shaft gear is changed to the value set in "[Cd.408] Synchronous control change value".


This operation is completed within one operation cycle.

Clutch control is not executed if the current value per cycle after the auxiliary shaft gear (the value before being changed and after being changed) has already passed through the ON/OFF address in address mode.

■Cam axis current value per cycle movement

This command is executed to move the cam axis current value per cycle through adding the setting movement amount of "[Cd.408] Synchronous control change value". The movement amount to be added is averaged in "[Cd.409] Synchronous control reflection time" for its output.

Set a long reflection time when a large movement amount is used since the cam axis feed current value moves with the movement amount.



Point

[API library]

- To change the current value of cam axis current value per cycle, current value per cycle after main shaft gear, or current value per cycle after auxiliary shaft gear during synchronous control, use the MMC_Axis::ChangeSyncPosition method.
- To move the cam axis current value per cycle or the cam reference position during synchronous control, use the MMC_Axis::MoveCamPosition method.

[Cd.408] Synchronous control change value

Set the change value for synchronous control change processing as follows.

[Cd.407] Synchronous control change command	[Cd.408] Synchronous control change value		
	Setting range	Unit	Setting details
0: Cam reference position movement	-2147483648 to 2147483647	Output axis position unit	<ul style="list-style-type: none"> • Set the movement amount of the cam reference position. • It moves within the range from -2147483648 to 2147483647.
1: Change cam axis current value per cycle		Cam axis cycle unit	<ul style="list-style-type: none"> • Set the change current value per cycle. • The setting value is converted within the range from 0 to (Cam axis length per cycle - 1).
2: Change current value per cycle after main shaft gear			
3: Change current value per cycle after auxiliary shaft gear			
4: Cam axis current value per cycle movement			<ul style="list-style-type: none"> • Set the movement amount of the cam axis current value per cycle. • It moves within the range from -2147483648 to 2147483647.

[Cd.409] Synchronous control reflection time

Set the reflection time for synchronous control change processing as follows.

[Cd.407] Synchronous control change command	Setting details for "[Cd.409] Synchronous control reflection time
0: Cam reference position movement	The time to reflect the movement amount to the cam reference position.
1: Change cam axis current value per cycle	Setting not required.
2: Change current value per cycle after main shaft gear	
3: Change current value per cycle after auxiliary shaft gear	
4: Cam axis current value per cycle movement	The time to reflect the movement amount to the cam axis current value per cycle.

4.7 Synchronous Control Monitor Data

Synchronous control monitor data is updated only during synchronous control.

The monitor values ([Md.400], [Md.401], [Md.402], [Md.407], [Md.408], and [Md.409]) from the last synchronous control session are restored the next time the system's power supply turns ON. Restarting operation status from the last synchronous control session is possible through returning to the last position via positioning control ( Page 125 ADVANCED SYNCHRONOUS CONTROL INITIAL POSITION).

"The last synchronous control session" indicates status just before the last synchronous control session was stopped as follows. These are listed with the last synchronization status.

- Just before " Cd.380 Synchronous control start" turns from ON to OFF.
- Just before deceleration stop by a stop command or an error, etc.
- Just before the system's power supply turned OFF to the Simple Motion board.

n: Axis No. - 1

Monitor item	Storage details	Monitor value	Buffer memory address
[Md.400] Current value after composite main shaft gear	<ul style="list-style-type: none"> • The current value after combining the main input and sub input values from the main shaft is stored. • Value is stored even after system's power supply OFF. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Main input axis position units^{*1}] 	42800+40n 42801+40n
[Md.401] Current value per cycle after main shaft gear	<ul style="list-style-type: none"> • The current value per cycle after the main shaft gear is stored. • One cycle is considered the cam axis length per cycle. • Value is stored even after system's power supply OFF. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*2}] 	42802+40n 42803+40n
[Md.402] Current value per cycle after auxiliary shaft gear	<ul style="list-style-type: none"> • The current value per cycle after the auxiliary shaft gear is stored. • One cycle is considered the cam axis length per cycle. • Value is stored even after system's power supply OFF. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*2}] 	42804+40n 42805+40n
[Md.406] Cam axis phase compensation amount	<ul style="list-style-type: none"> • The current phase compensation amount is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Cam axis cycle units^{*2}] 	42810+40n 42811+40n
[Md.407] Cam axis current value per cycle	<ul style="list-style-type: none"> • The current value per cycle is stored, which is calculated from the input movement amount to the cam axis. (The value after phase compensation) • Value is stored even after system's power supply OFF. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*2}] 	42812+40n 42813+40n
[Md.408] Cam reference position	<ul style="list-style-type: none"> • The feed current value as the cam reference position is stored. • Value is stored even after system's power supply OFF. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Output axis position units^{*3}] 	42814+40n 42815+40n
[Md.409] Cam axis feed current value	<ul style="list-style-type: none"> • The feed current value while controlling the cam axis is stored. • Value is stored even after system's power supply OFF. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Output axis position units^{*3}] 	42816+40n 42817+40n
[Md.410] Execute cam No.	<ul style="list-style-type: none"> • The executing cam No. is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. 0 to 1024 	42818+40n
[Md.411] Execute cam stroke amount	<ul style="list-style-type: none"> • The executing cam stroke amount is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Output axis position units^{*3}] 	42820+40n 42821+40n
[Md.412] Execute cam axis length per cycle	<ul style="list-style-type: none"> • The executing cam axis length per cycle is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> ■Monitoring is carried out in decimal display. 1 to 2147483647 [Cam axis cycle units^{*2}] 	42822+40n 42823+40n

Monitor item	Storage details	Monitor value	Buffer memory address
[Md.420] Main shaft clutch ON/OFF status	<ul style="list-style-type: none"> The ON/OFF status of main shaft clutch is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> Monitoring is carried out in decimal display. 0: Clutch OFF status 1: Clutch ON status 	42828+40n
[Md.421] Main shaft clutch smoothing status	<ul style="list-style-type: none"> The smoothing status of main shaft clutch is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> Monitoring is carried out in decimal display. 0: Not on clutch smoothing 1: On clutch smoothing 	42829+40n
[Md.422] Main shaft clutch slippage (accumulative)	<ul style="list-style-type: none"> The accumulative slippage of the main shaft clutch smoothing with slippage method is stored as a signed value. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Main input axis position units^{*1} or Cam axis cycle units^{*2}] 	42830+40n 42831+40n
[Md.423] Auxiliary shaft clutch ON/OFF status	<ul style="list-style-type: none"> The ON/OFF status of the auxiliary shaft clutch is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> Monitoring is carried out in decimal display. 0: Clutch OFF status 1: Clutch ON status 	42832+40n
[Md.424] Auxiliary shaft clutch smoothing status	<ul style="list-style-type: none"> The smoothing status of the auxiliary shaft clutch is stored. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> Monitoring is carried out in decimal display. 0: Not on clutch smoothing 1: On clutch smoothing 	42833+40n
[Md.425] Auxiliary shaft clutch slippage (accumulative)	<ul style="list-style-type: none"> The accumulative slippage on the auxiliary shaft clutch smoothing with slippage method is stored as a signed value. <u>Refresh cycle: Operation cycle (During synchronous control only)</u>	<ul style="list-style-type: none"> Monitoring is carried out in decimal display. -2147483648 to 2147483647 [Auxiliary shaft position units^{*4} or Cam axis cycle units^{*2}] 	42834+40n 42835+40n

*1 Main input axis position units (☞ Page 24 INPUT AXIS MODULE)

*2 Cam axis cycle units (☞ Page 110 Units for the output axis)

*3 Output axis position units (☞ Page 110 Units for the output axis)

*4 Auxiliary shaft position units (☞ Page 24 INPUT AXIS MODULE)

For labels, refer to the following.

☞ Page 155 Synchronous control monitor data

[Md.400] Current value after composite main shaft gear

The current value after combining the main input and the sub input values going into the composite main shaft gear is stored as an accumulative value.

Units are in position units of the main input axis (☞ Page 24 INPUT AXIS MODULE). The unit is pulse if the main input axis is invalid.

The current value after composite main shaft gear will be changed when the following operations are executed in the main input axis during synchronous control.

Operations of main input axis (Synchronous control)	Servo input axis		Synchronous encoder axis
	Absolute position detection system: valid	Absolute position detection system: invalid	
Home position return	Change method 1)		—
Current value change	Change method 1)		Change method 1)
Speed control ^{*1}	Change method 1)		—
Fixed-pitch feed control	Change method 1)		—
Speed-position switching control ^{*1}	Change method 1)		—
Position-speed switching control ^{*1}	Change method 1)		—
Connection to servo amplifier	Change method 2)	Change method 1)	—
Connection to synchronous encoder	—		Change method 1)

*1 When "2: Clear feed current value to zero" is set in "[Pr.21] Feed current value during speed control" only.

Change method 1): The new current value after composite main shaft gear is calculated based on the current value of the main input axis.

Current value after composite main shaft gear = Main input direction of composite main shaft gear × Main input axis current value

Change method 2): The movement amount of the main input axis from the last synchronous control session is reflected to the current value after composite main shaft gear.

Current value after composite main shaft gear = Current value after composite main shaft gear × Movement amount of main input axis from the last synchronous control session

[Md.401] Current value per cycle after main shaft gear

The input movement amount after the main shaft gear is stored within the range from 0 to (Cam axis length per cycle - 1). The unit is in cam axis cycle units ( Page 110 Units for the output axis).

The value is restored according to "[Pr.460] Setting method of current value per cycle after main shaft gear" when starting synchronous control. ( Page 125 Synchronous Control Initial Position)

[Md.402] Current value per cycle after auxiliary shaft gear

The input movement amount after the auxiliary shaft gear is stored within the range from 0 to (Cam axis length per cycle - 1). The unit is in cam axis cycle units ( Page 110 Units for the output axis).

The value is restored according to "[Pr.461] Setting method of current value per cycle after auxiliary shaft gear" when starting synchronous control. ( Page 125 Synchronous Control Initial Position)

[Md.406] Cam axis phase compensation amount

The phase compensation amount for the cam axis is stored with cam axis cycle units ( Page 110 Units for the output axis). The phase compensation amount after smoothing processing with "[Pr.445] Cam axis phase compensation time constant" is stored.

[Md.407] Cam axis current value per cycle

The cam axis current value per cycle is stored within the range from 0 to (Cam axis length per cycle - 1).

The current value after cam axis phase compensation processing can be monitored. The unit is in cam axis cycle units ( Page 110 Units for the output axis).

The value is restored according to "[Pr.462] Cam axis position restoration object" when starting synchronous control. ( Page 125 Synchronous Control Initial Position)

[Md.408] Cam reference position

The feed current value is stored as the cam reference position. The unit is in output axis position units ( Page 110 Units for the output axis). When the unit is in degrees, a range from 0 to 35999999 is used.

The value is restored according to "[Pr.462] Cam axis position restoration object" when starting synchronous control. ( Page 125 Synchronous Control Initial Position)

[Md.409] Cam axis feed current value

The feed current value of the cam axis is stored. The value is the same as "[Md.20] Feed current value" during synchronous control.

[Md.410] Execute cam No.

The executing cam No. is stored.

When "[Pr.440] Cam No." is changed during synchronous control, this is updated when the controlling cam No. switches.

[Md.411] Execute cam stroke amount

The executing cam stroke amount is stored.

When "[Pr.441] Cam stroke amount" is changed during synchronous control, this is updated when the controlling cam stroke amount switches.

[Md.412] Execute cam axis length per cycle

The executing cam axis length per cycle is stored.

When "[Pr.439] Cam axis length per cycle" is changed during synchronous control, this is updated when the controlling cam axis length per cycle switches.

[Md.420] Main shaft clutch ON/OFF status

The clutch ON/OFF status is stored.

[Md.421] Main shaft clutch smoothing status

The smoothing status of the clutch is stored. The status is updated by the clutch smoothing method as follows.

Method	Details
Time constant method	The status is always "1: On clutch smoothing" during the clutch ON status. The status will be "0: Not on clutch smoothing" when the clutch is turned OFF and smoothing is completed.
Slippage method	The status is "1: On clutch smoothing" till the clutch accumulative slippage amount reaches the slippage at clutch ON when the clutch is turned ON. The status will change to "0: Not on clutch smoothing" when the clutch accumulative slippage amount reaches the slippage at clutch ON. The status is "1: On clutch smoothing" till the clutch accumulative slippage amount reaches 0 when the clutch is turned OFF. The status will change to "0: Not on clutch smoothing" when the clutch accumulative slippage amount reaches 0.

[Md.422] Main shaft clutch slippage (accumulative)

The accumulative slippage amount with the slippage method is stored as a signed value.

The absolute value of the accumulative slippage increases to reach the slippage at clutch ON during clutch ON.

The absolute value of the accumulative slippage decreases to reach 0 during clutch OFF.

Monitoring of the accumulative slippage is used to check the smoothing progress with the slippage method.

[Md.423] Auxiliary shaft clutch ON/OFF status

The clutch ON/OFF status is stored.

[Md.424] Auxiliary shaft clutch smoothing status

The smoothing status of the clutch is stored. The status is updated by the clutch smoothing method as follows.

Method	Details
Time constant method	The status is always "1: On clutch smoothing" during the clutch ON status. The status will be "0: Not on clutch smoothing" when the clutch is turned OFF and smoothing is completed.
Slippage method	The status is "1: On clutch smoothing" till the clutch accumulative slippage amount reaches the slippage at clutch ON when the clutch is turned ON. The status will change to "0: Not on clutch smoothing" when the clutch accumulative slippage amount reaches the slippage at clutch ON. The status is "1: On clutch smoothing" till the clutch accumulative slippage amount reaches 0 when the clutch is turned OFF. The status will change to "0: Not on clutch smoothing" when the clutch accumulative slippage amount reaches 0.

[Md.425] Auxiliary shaft clutch slippage (accumulative)

The accumulative slippage amount with the slippage method is stored as a signed value.

The absolute value of the accumulative slippage increases to reach the slippage at clutch ON during clutch ON.

The absolute value of the accumulative slippage decreases to reach 0 during clutch OFF.

Monitoring of the accumulative slippage is used to check the smoothing progress with the slippage method.

4.8 Phase Compensation Function

In synchronous control, delays in progresses, etc. cause the phase to deviate at the output axis motor shaft end with respect to the input axis (servo input axis or synchronous encoder axis). The phase compensation function compensates in this case so that the phase does not deviate.

Phase compensation can be set for the input and the output axis. It is possible to compensate using the delay time inherent to the system based on the servo input axis or the synchronous encoder axis on the input axis side. It is also possible to use a compensation delay time equivalent to the position deviation for each servo amplifier on the output axis side.

Phase compensation of delay time of the input axis

Set delay time inherent to the system in the phase compensation advance time of the input axis ("[Pr.302] Servo input axis phase compensation advance time", "[Pr.326] Synchronous encoder axis phase compensation advance time").

The delay time inherent to the system is shown below.

■ Delay time inherent to the system for a servo input axis

Operation cycle [ms]	[Pr.300] Servo input axis type			
	Feed current value	Real current value	Command to servo amplifier	Feedback value
0.50	0 [μs]	1804 [μs]	0 [μs]	2805 [μs]
1.00	0 [μs]	2777 [μs]	0 [μs]	4777 [μs]
2.00	0 [μs]	4722 [μs]	0 [μs]	8722 [μs]
4.00	0 [μs]	8722 [μs]	0 [μs]	16722 [μs]

■ Delay time inherent to the system for a synchronous encoder axis

Operation cycle [ms]	[Pr.320] Synchronous encoder axis type		
	Synchronous encoder via servo amplifier	Synchronous encoder via buffer memory	Synchronous encoder via link device
0.50	2849 [μs]	2314 [μs]	2314 [μs]
1.00	4822 [μs]	3790 [μs]	3790 [μs]
2.00	8767 [μs]	6743 [μs]	6743 [μs]
4.00	16767 [μs]	12754 [μs]	12754 [μs]

Phase compensation of delay time of the output axis

Set delay time equivalent to the position deviation on the servo amplifier in "[Pr.444] Cam axis phase compensation advance time" for the output axis. The delay time equivalent to position deviation of the servo amplifier is calculated using the following formula. (When using MR-J4-GF)

Delay time [μs] = 1000000 / Servo parameter "Model loop gain (PB07)"

When the feed forward gain is set, the delay time is set to a smaller value than the value listed above.

The model loop gain will change when the gain adjustment method is auto tuning mode 1 or 2. The model loop gain must not be changed on the axis executing phase compensation through preventing change with the manual mode or interpolation mode setting.

Setting example

When axis 1 is synchronized with a synchronous encoder axis via servo amplifier, the phase compensation advance time is set as follows.

(If the operation cycle is as 2.00 [ms] and model loop gain of axis 1 is as 80.)

Setting item	Setting value
[Pr.326] Synchronous encoder axis phase compensation advance time	8767 [μs] (Reference: Delay time inherent to system for a synchronous encoder axis)
[Pr.444] Cam axis phase compensation advance time	1000000 / 80 = 12500 [μs]

When overshoot or undershoot occurs during acceleration/deceleration, set a longer time for the phase compensation time constant.

4.9 Output Axis Sub Functions

The following shows which sub functions apply for the output axis in synchronous control.

○: Valid, —: Invalid

Sub function	Output axis	Details
Backlash compensation function	○	The same control as other methods.
Electronic gear function	○	
Speed limit function	—	Setting is ignored. ("[Pr.8] Speed limit value" must be set to use "[Pr.446] Synchronous control deceleration time".)
Torque limit function	○	Controlled with "[Pr.17] Torque limit setting value" or "[Cd.101] Torque output setting value" similar to other methods.
Software stroke limit function	○	The axis stops immediately when exceeding the software stroke limit range. To disable the software stroke limit, set the setting value so that "Upper limit value = Lower limit value".
Hardware stroke limit function	○	Controlled the same as positioning control.
Forced stop function	○	Same control as other methods.
Speed change function	—	Setting is ignored.
Override function	—	
Acceleration/deceleration time change function	—	
Torque change function	○	
Absolute system	○	Same control as other methods.
Step function	—	
Skip function	—	
M code output function	—	M code is not able to output.
Teaching function	—	Setting is ignored.
Target position change function	—	
Command in-position function	—	
Acceleration/deceleration processing function	○	Valid at deceleration stop only. Deceleration time is set in "[Pr.446] Synchronous control deceleration time".
Pre-reading start function	—	Setting is ignored.
Deceleration start flag function	—	
Stop command processing for deceleration stop function	—	
Speed control 10 x multiplier setting for degree axis function	○	Reflected on monitor data.
Operation setting for incompleteness of home position return function	○	Controlled the same as positioning control. For a system that needs alignment, start synchronous control after establishing an a home position.
Controller in-position function	○	Controlled the same as positioning control.
Servo ON/OFF	○	Servo OFF request is ignored during synchronous control similar to positioning control.

Point

Sub functions for an input axis in synchronous control conform to the specification of each control (Home position return control, Positioning control, Manual control, Speed torque control). Refer to the following for details.

 Simple Motion Board User's Manual (Application)

5 ADVANCED SYNCHRONOUS CONTROL INITIAL POSITION

The initial position for synchronous control is explained in this chapter.


Configure these settings for situations that require initial position alignment for synchronous control.

5.1 Synchronous Control Initial Position

The following synchronous control monitor data can be aligned to a set position when starting synchronous control, as the initial position for synchronous control.

The alignment to a synchronous control initial position is useful for restoring a system based on the last control status along with restarting synchronous control after canceling midway.

Synchronous control monitor data	The position when starting synchronous control
[Md.400] Current value after composite main shaft gear	Restored to a position based on the main input axis of the main shaft.
[Md.401] Current value per cycle after main shaft gear	Restored according to "[Pr.460] Setting method of current value per cycle after main shaft gear".
[Md.402] Current value per cycle after auxiliary shaft gear	Restored according to "[Pr.461] Setting method of current value per cycle after auxiliary shaft gear".
[Md.407] Cam axis current value per cycle	Restored according to "[Pr.462] Cam axis position restoration object".
[Md.408] Cam reference position	
[Md.409] Cam axis feed current value	



Current value after composite main shaft gear at synchronous control start

The current value after composite main shaft gear is restored as follows according to the main input axis operation executed before starting synchronous control.

Operation of main input axis (Before synchronous control start)	Servo input axis		Synchronous encoder axis
	Absolute position detection system valid	Absolute position detection system invalid	
Home position return	Restoration method 1)		—
Current value change	Restoration method 1)		Restoration method 1)
Speed control*1	Restoration method 1)		—
Fixed-pitch feed control	Restoration method 1)		—
Speed-position switching control*1	Restoration method 1)		—
Position-speed switching control*1	Restoration method 1)		—
Connection to servo amplifier	Restoration method 2)	Restoration method 1)	—
Connection to synchronous encoder	—		Restoration method 1)
Others	Restoration method 2)		Restoration method 2)

*1 When "[Pr.300] Servo input axis type" is either "1: Feed current value" or "2: Real current value", and when "[Pr.21] Feed current value during speed control" is "2: Clear feed current value to zero" only.

Restoration method 1): The new current value after composite main shaft gear is calculated based on the current value of the main input axis.

Current value after composite main shaft gear =

Main input direction of composite main shaft gear × Main input axis current value

Restoration method 2): The movement amount of the main input axis from the last synchronous control session is reflected to the current value after composite main shaft gear.

Current value after composite main shaft gear =

Current value after composite main shaft gear at the last synchronous control session + Main input direction of composite main shaft gear × Amount of change of main input axis current value from the last synchronous control session

The current value after composite main shaft gear at the last synchronous control session is restored when "0: Invalid" is set in "[Pr.400] Main input axis No.", or when a servo input axis or a synchronous encoder axis as the main input axis is not connected.

Point

"The last synchronous control session" indicates status just before the last synchronous control session was stopped as follows. These are listed with the last synchronization status.

- Just before "[Cd.380] Synchronous control start" turns from ON to OFF.
- Just before deceleration stop by a stop command or an error, etc.
- Just before the power supply of the Simple Motion board turns OFF.

Current value per cycle after main/auxiliary shaft gear at synchronous control start

The current value per cycle after main shaft gear/current value per cycle after auxiliary shaft gear is restored as follows according to the main input axis/auxiliary shaft operation executed before starting synchronous control.

Operation of main input axis / auxiliary shaft (Before synchronous control start)	Servo input axis		Synchronous encoder axis
	Absolute position detection system valid	Absolute position detection system invalid	
Home position return	Restoration method 1)		—
Current value change	Restoration method 1)		Restoration method 1)
Speed control*1	Restoration method 1)		—
Fixed-pitch feed control	Restoration method 1)		—
Speed-position switching control*1	Restoration method 1)		—
Position-speed switching control*1	Restoration method 1)		—
Connection to servo amplifier	Restoration method 2)	Restoration method 1)	—
Connection to synchronous encoder	—		Restoration method 1)
Others	Restoration method 2)		Restoration method 2)

*1 When "[Pr.300] Servo input axis type" is either "1: Feed current value" or "2: Real current value", and when "[Pr.21] Feed current value during speed control" is "2: Clear feed current value to zero" only.

Restoration method 1): The new value of the current value per cycle after main shaft gear/current value per cycle after auxiliary shaft gear is calculated based on the current value after composite main shaft gear/auxiliary shaft current value.

[Main shaft]

Current value per cycle after main shaft gear = Main shaft gear ratio × Current value after composite main shaft gear

[Auxiliary shaft]

Current value per cycle after auxiliary shaft gear = Auxiliary shaft gear ratio × Auxiliary shaft current value

Restoration method 2): The movement amount from the last synchronous control session is reflected to the current value per cycle after main shaft gear/current value per cycle after auxiliary shaft gear.

[Main shaft]

Current value per cycle after main shaft gear =

Current value per cycle after main shaft gear at the last synchronous control session + Main shaft gear ratio × Amount of change of current value after composite main shaft gear from the last synchronous control session

[Auxiliary shaft]


Current value per cycle after auxiliary shaft gear =

Current value per cycle after auxiliary shaft gear at the last synchronous control session + Auxiliary shaft gear ratio × Amount of change of auxiliary shaft current value from the last synchronous control session

The current value per cycle after main shaft gear/current value per cycle after auxiliary shaft gear at the last synchronous control session is restored when "0: Invalid" is set in "[Pr.400] Main input axis No."/[Pr.418] Auxiliary shaft axis No.", or when a servo input axis or a synchronous encoder axis as the main input axis/auxiliary shaft is not connected.

Cam axis position at synchronous control start

The cam axis position is composed of the relationship of 3 positions "Cam axis current value per cycle", "Cam reference position" and "Cam axis feed current value". One of positions can be restored by defining 2 positions when starting synchronous control.



Select from 3 objects as follows in "[Pr.462] Cam axis position restoration object" which position is to be restored. (Refer to [Page 132](#) Cam Axis Position Restoration Method for details on the restoration method.)

- Cam axis current value per cycle restoration
- Cam reference position restoration
- Cam axis feed current value restoration

Various parameters need to be set for the cam axis position restoration as shown below. (Refer to [Page 129](#) Synchronous Control Initial Position Parameters for the setting details.)

○: Required, △:Required for initial setting value, —: Not required

[Pr.462] Cam axis position restoration object	[Pr.463] Setting method of cam reference position	[Pr.467] Cam reference position (Initial setting)	[Pr.464] Setting method of cam axis current value per cycle	[Pr.468] Cam axis current value per cycle (Initial setting)	Restoration processing details
0: Cam axis current value per cycle restoration	○	△	—	○ (Used as search starting point)	Restore "Cam axis current value per cycle" based on "Cam reference position" and "Cam axis feed current value".
1: Cam reference position restoration	—	—	○	△	Restore "Cam reference position" based on "Cam axis current value per cycle" and "Cam axis feed current value".
2: Cam axis feed current value restoration	○	△	○	△	Restore "Cam axis feed current value" based on "Cam axis current value per cycle" and "Cam reference position".

5.2 Synchronous Control Initial Position Parameters

n: Axis No. - 1

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Pr.460] Setting method of current value per cycle after main shaft gear	<ul style="list-style-type: none"> Select the setting method for the current value per cycle after main shaft gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Previous value 1: Initial setting value of current value per cycle after main shaft gear ([Pr.465]) 2: Calculate from input axis 	0	36500+200n
[Pr.461] Setting method of current value per cycle after auxiliary shaft gear	<ul style="list-style-type: none"> Select the setting method for the current value per cycle after auxiliary shaft gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Previous value 1: Initial setting value of current value per cycle after auxiliary shaft gear ([Pr.466]) 2: Calculate from input axis 	0	36501+200n
[Pr.462] Cam axis position restoration object	<ul style="list-style-type: none"> Select the object to restore the cam axis position. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Cam axis current value per cycle restoration 1: Cam reference position restoration 2: Cam axis feed current value restoration 	0	36502+200n
[Pr.463] Setting method of cam reference position	<ul style="list-style-type: none"> Select the setting method for the cam reference position. Set for the cam axis current value per cycle restoration or the cam axis feed current value restoration. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Previous value 1: Initial setting value of cam reference position 2: Feed current value 	2	36503+200n
[Pr.464] Setting method of cam axis current value per cycle	<ul style="list-style-type: none"> Select the setting method for the cam axis current value per cycle. Set for the cam reference position restoration or the cam axis feed current value restoration. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0: Previous value 1: Initial setting value of cam axis current value per cycle 2: Current value per cycle after main shaft gear 3: Current value per cycle after auxiliary shaft gear 	0	36504+200n
[Pr.465] Current value per cycle after main shaft gear (Initial setting)	<ul style="list-style-type: none"> Set the initial value of the current value per cycle after main shaft gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*1}] 	0	36506+200n 36507+200n
[Pr.466] Current value per cycle after auxiliary shaft gear (Initial setting)	<ul style="list-style-type: none"> Set the initial value of the current value per cycle after auxiliary shaft gear. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*1}] 	0	36508+200n 36509+200n
[Pr.467] Cam reference position (Initial setting)	<ul style="list-style-type: none"> Set the initial value of the cam reference position. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. -2147483648 to 2147483647 [Output axis position units^{*2}] 	0	36510+200n 36511+200n
[Pr.468] Cam axis current value per cycle (Initial setting)	<ul style="list-style-type: none"> Set the initial value for the cam axis current value per cycle. The restoration value for the cam axis current value per cycle is searched from the setting value with the cam axis current value per cycle restoration. <u>Fetch cycle: At start of synchronous control</u>	<ul style="list-style-type: none"> Set in decimal. 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*1}] 	0	36512+200n 36513+200n

*1 Cam axis cycle units (☞ Page 110 Units for the output axis)

*2 Output axis position units (☞ Page 110 Units for the output axis)

For labels, refer to the following.

☞ Page 154 Synchronous parameters: Synchronous control initial position

[Pr.460] Setting method of current value per cycle after main shaft gear

Select the setting method of "[Md.401] Current value per cycle after main shaft gear" when starting synchronous control.

Setting value	Details
0: Previous value	The current value per cycle after main shaft gear from the last synchronous control session is stored.
1: Initial setting value of current value per cycle after main shaft gear	The value set in "[Pr.465] Current value per cycle after main shaft gear (Initial setting)" is stored.
2: Calculate from input axis	The value calculated based on the current value after composite main shaft gear is stored.

[Pr.461] Setting method of current value per cycle after auxiliary shaft gear

Select the setting method of "[Md.402] Current value per cycle after auxiliary shaft gear" when starting synchronous control.

Setting value	Details
0: Previous value	The current value per cycle after auxiliary shaft gear from the last synchronous control session is stored.
1: Initial setting value of current value per cycle after auxiliary shaft gear	The value set in "[Pr.466] Current value per cycle after auxiliary shaft gear (Initial setting)" is stored.
2: Calculate from input axis	The value calculated based on the auxiliary shaft current value is stored.

[Pr.462] Cam axis position restoration object

Select the object to be restored from "Cam axis current value per cycle", "Cam reference position" or "Cam axis feed current value" when starting synchronous control.

Setting value	Details
0: Cam axis current value per cycle restoration	Restore the cam axis current value per cycle from "Cam reference position" and "Cam axis feed current value".
1: Cam reference position restoration	Restore the cam reference position from "Cam axis current value per cycle" and "Cam axis feed current value".
2: Cam axis feed current value restoration	Restore the cam axis feed current value from "Cam axis current value per cycle" and "Cam reference position".

[Pr.463] Setting method of cam reference position

Select the method for the cam reference position to be restored when "[Pr.462] Cam axis position restoration object" is set to "0: Cam axis current value per cycle restoration" or "2: Cam axis feed current value restoration".

Setting value	Details
0: Previous value	The cam reference position from the last synchronous control session is stored. The feed current value is stored when the cam reference position from the last synchronous control session is not saved.
1: Initial setting value of cam reference position	The value set in "[Pr.467] Cam reference position (Initial setting)" is stored.
2: Feed current value	The value set in "[Md.20] Feed current value" is stored.

[Pr.464] Setting method of cam axis current value per cycle

Select the method for the cam axis current value per cycle to be restored when "[Pr.462] Cam axis position restoration object" is set to "1: Cam reference position restoration" or "2: Cam axis feed current value restoration".

Setting value	Details
0: Previous value	The cam axis current value per cycle from the last synchronous control session is stored as is.
1: Initial setting value of cam axis current value per cycle	The value set in "[Pr.468] Cam axis current value per cycle (Initial setting)" is stored.
2: Current value per cycle after main shaft gear	The current value per cycle after main shaft gear is stored.
3: Current value per cycle after auxiliary shaft gear	The current value per cycle after auxiliary shaft gear is stored.

[Pr.465] Current value per cycle after main shaft gear (Initial setting)

Set the initial setting value of the current value per cycle after main shaft gear when "[Pr.460] Setting method of current value per cycle after main shaft gear" is set to "1: Current value per cycle after main shaft gear (Initial setting)".

The unit settings are in cam axis cycle units ( Page 110 Units for the output axis). Set within the range from 0 to (Cam axis length per cycle - 1).

[Pr.466] Current value per cycle after auxiliary shaft gear (Initial setting)

Set the initial setting value of the current value per cycle after auxiliary shaft gear when "[Pr.461] Setting method of current value per cycle after auxiliary shaft gear" is set to "1: Current value per cycle after auxiliary shaft gear (Initial setting)".

The unit settings are in cam axis cycle units ( Page 110 Units for the output axis). Set within the range from 0 to (Cam axis length per cycle - 1).

[Pr.467] Cam reference position (Initial setting)

Set the initial setting value of the cam reference position in output axis position units ( Page 110 Units for the output axis) when "[Pr.463] Setting method of cam reference position" is set to "1: Cam reference position (Initial setting)".

[Pr.468] Cam axis current value per cycle (Initial setting)

Set a value according to the setting for "[Pr.462] Cam axis position restoration object".

The unit settings are in cam axis cycle units ( Page 110 Units for the output axis). Set within the range from 0 to (Cam axis length per cycle - 1).

[Pr.462] Cam axis position restoration object	Setting value
0: Cam axis current value per cycle restoration	Set the starting point for search processing to restore the cam axis current value per cycle. Set to restore the position on the return path in two-way cam pattern operation. Refer to the following for details on search processing.  Page 132 Cam axis current value per cycle restoration
1: Cam reference position restoration	Set the initial setting value for the cam axis current value per cycle when "[Pr.464] Setting method of cam axis current value per cycle" is set to "1: Cam axis current value per cycle (Initial setting)".
2: Cam axis feed current value restoration	



5.3 Cam Axis Position Restoration Method

Cam axis current value per cycle restoration

If "[Pr.462] Cam axis position restoration object" is set to "0: Cam axis current value per cycle restoration" when starting synchronous control, the cam axis current value per cycle is restored based on the cam reference position and the cam axis feed current value.

Select the method for the cam reference position to be restored. The feed current value when starting synchronous control is used as the cam axis feed current value.

The cam axis current value per cycle is restored by searching for the corresponding value from the beginning to the end of the cam pattern. Set the starting point from where to search the cam pattern in "[Pr.468] Cam axis current value per cycle (Initial setting)". (It is also possible to search the return path in a two-way cam pattern operation.)




Restriction

- With two-way cam pattern operation, if the corresponding cam axis current value per cycle is not found, the error "Cam axis current value per cycle restoration disable" (error code: 1C28H) will occur and synchronous control will not be started.
- When starting synchronous control, the feed current value may change slightly from its original position at starting synchronous control. This is due to the readjustment of the position based on the restored cam axis current value per cycle. This does not result in the position mismatch.
- With a feed operation cam pattern, if the corresponding cam axis current value per cycle is not found on the first cycle, the cam reference position is changed automatically and the pattern is searched again.
- If the cam resolution is large, search processing may take a long time when starting synchronous control. (Cam resolution 256: Up to 0.4 ms, Cam resolution 32768: Up to 26 ms)


Cam axis current value per cycle restoration operation

■With a two-way cam pattern operation


- Search from "Cam axis current value per cycle = 0". (Cam data starting point = 0)




- Search from a value in the middle of the cam axis current value per cycle. (Cam data starting point $\neq 0$)



- Search from a value in the middle of the cam axis current value per cycle. (Cam data starting point $\neq 0$)




- The search fails.




■With a feed operation cam pattern


- Search from "Cam axis current value per cycle = 0". (Cam data starting point = 0)




- Search from a value in the middle of the cam axis current value per cycle. (Cam data starting point = 0)



- Search from a value in the middle of the cam axis current value per cycle. (Cam data starting point ≠ 0)



- The first search is fails and a search begins for the second time.



Point

If the first search fails, a second search may not be processed on the next cycle for a cam pattern with a feed stroke that is smaller than 100% of the stroke as above.

The intended cam axis current value per cycle can be found in the first search, by setting or positioning the cam reference position in advance.


Example

The following shows an example of restarting the cam (a cam similar to a cam with a linear feed where two identical positioning points do not exist on the cam) from the feed current value after a forced stop, when the forced stop has stopped operation.


If the following settings are used in a two-way cam or a cam where identical positioning points exist on the same cam, similar to the cam axis current value per cycle restoration operation ( Page 133 Cam axis current value per cycle restoration operation), the first matching feed current value (outward route) is restored, therefore restoration may start from an unintended cam pattern position. To avoid restoring the first matching feed current value, use cam axis current feed value restoration ( Page 139 Cam axis feed current value restoration).

Setting item	Setting value
[Pr.439] Cam axis length per cycle	1000 [pulse]
[Pr.441] Cam stroke amount	200 [pulse]
[Pr.462] Cam axis position restoration object	0: Cam axis current value per cycle restoration
[Pr.463] Setting method of cam reference position	1: Initial setting value of cam reference position
[Pr.464] Setting method of cam axis current value per cycle	0: Previous value
[Pr.467] Cam reference position (Initial setting)	0 [pulse]
[Pr.468] Cam axis current value per cycle (Initial setting)	0 [pulse]


- Advanced synchronous control operation



- Restore operation at restart of advanced synchronous control



- Cam operation





Cam reference position restoration

If "[Pr.462] Cam axis position restoration object" is set to "1: cam reference position restoration" when starting synchronous control, the cam reference position is restored based on the cam axis current value per cycle and the cam axis feed current value.

Select the method for the cam axis current value per cycle to be restored. The feed current value when starting synchronous control is used as the cam axis feed current value.

[Pr.464] Setting method of cam axis current value per cycle

- 0: Previous value
- 1: Initial setting value of cam axis current value per cycle
- 2: Current value per cycle after main shaft gear
- 3: Current value per cycle after auxiliary shaft gear




Example


The following shows an example of starting operation from a position of "cam axis current value per cycle=0" by restoring the cam reference position when starting from "feed current value=0[pulse]", in the cam when the cam data starting point is not 0.

Setting item	Setting value
[Pr.439] Cam axis length per cycle	1000 [pulse]
[Pr.441] Cam stroke amount	200 [pulse]
[Pr.462] Cam axis position restoration object	1: Cam reference position restoration
[Pr.463] Setting method of cam reference position	None
[Pr.464] Setting method of cam axis current value per cycle	1: Initial setting value of cam axis current value per cycle
[Pr.467] Cam reference position (Initial setting)	None
[Pr.468] Cam axis current value per cycle (Initial setting)	0 [pulse]


- Operation before starting advanced synchronous control



- Restore operation at start of advanced synchronous control



- Cam operation




Cam axis feed current value restoration


If "[Pr.462] Cam axis position restoration object" is set to "2: Cam axis feed current value restoration" when starting synchronous control, the cam axis feed current value is restored based on the cam axis current value per cycle and the cam reference position.

Select the method for the cam axis current value per cycle and the method for the cam reference position to be restored.

[Pr.464] Setting method of cam axis current value per cycle




[Pr.463] Setting method of cam reference position



The cam axis feed current value is restored based on the cam axis current value per cycle and the cam reference position.

[Md.409] Cam axis feed current value



Restriction

The cam axis feed current value moves to its restored value just after starting synchronous control when the cam axis feed current value to be restored is different from the feed current value at synchronous control start. If the difference is larger than "1600 [pulse]" in pulse command units, the error "Cam axis feed current value restoration disable" (error code: 1C29H) will occur and synchronous control cannot be started.

Point


With cam axis feed current value restoration, calculate the cam axis feed current value with the cam position calculation function (Page 143 Cam Position Calculation Function) or with synchronous control analysis mode (Page 141 Synchronous Control Analysis Mode) before starting synchronous control. Then start synchronous control after positioning to the correct cam axis feed current value.

Example


The following shows an example of starting a cam pattern from the zero point of the cam axis current value per cycle with the current feed current value position as the origin when returning to a specified point, or home position return is completed after a forced stop.

Setting item	Setting value
[Pr.439] Cam axis length per cycle	1000 [pulse]
[Pr.441] Cam stroke amount	200 [pulse]
[Pr.462] Cam axis position restoration object	2: Cam axis feed current value restoration
[Pr.463] Setting method of cam reference position	2: Feed current value
[Pr.464] Setting method of cam axis current value per cycle	1: Initial setting value of cam axis current value per cycle
[Pr.467] Cam reference position (Initial setting)	None
[Pr.468] Cam axis current value per cycle (Initial setting)	0 [pulse]


- Move to advanced synchronous control starting point



- Restore operation



- Cam operation



5.4 Synchronous Control Analysis Mode

With synchronous control analysis mode, advanced synchronous control parameters are only analyzed when there is a command to start synchronous control. This mode is used to confirm the synchronous positions of the output axes in order to align axes with position control before starting synchronous control.


If the target axis bit is ON in "[Cd.381] Synchronous control analysis mode" when starting synchronous control (turning the target axis bit from OFF to ON for "[Cd.380] Synchronous control start"), operation enters synchronous control analysis mode.

When the synchronization position analysis is completed, the synchronous control monitor data ([Md.400] to [Md.425]) is updated, and the target axis bit in "[Cd.380] Synchronous control start" turns OFF.

The busy signal is not turned ON during synchronous control analysis mode.

When starting synchronous control with synchronous control analysis mode, the following error does not occur.

- Cam axis feed current value restoration disable (error code: 1C29H)



Synchronous control system control data

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.380] Synchronous control start	<ul style="list-style-type: none"> • Synchronous control begins if the target axis bit is turned ON. • Synchronous control ends if the bit is turned OFF during synchronous control. Fetch cycle: Operation cycle	■Set the target axis in 16 bits. (bit0: axis 1 to bit15: axis 16) OFF: Synchronous control end ON: Synchronous control start	0	36320
[Cd.381] Synchronous control analysis mode	<ul style="list-style-type: none"> • If the target axis bit is turned ON and synchronous control is started, the analysis is only executed and the control does not start. Fetch cycle: At start of the synchronous control	■Set the target axis in 16 bits. (bit0: axis 1 to bit15: axis 16) OFF: Synchronous control analysis mode OFF ON: Synchronous control analysis mode ON	0	36322

For labels, refer to the following.

📖 Page 156 Synchronous control system control data

Example

The following shows a procedure of aligning the synchronous position of an output axis that references the input axis.

1. Set the following values in the synchronous control initial position parameters.

Setting item	Setting value
[Pr.460] Setting method of current value per cycle after main shaft gear	2: Calculate from input axis
[Pr.462] Cam axis position restoration object	2: Cam axis feed current value restoration
[Pr.463] Setting method of cam reference position	0: Previous value
[Pr.464] Setting method of cam axis current value per cycle	2: Current value per cycle after main shaft gear

2. Turn ON the target axis bit of "[Cd.381] Synchronous control analysis mode", and then turn the target axis bit from OFF to ON in "[Cd.380] Synchronous control start" to start the synchronous control analysis mode.
3. Verify the target axis bit is OFF for "[Cd.380] Synchronous control start", and execute positioning for the output axis to be updated to "[Md.409] Cam axis feed current value".
4. Turn OFF the target axis bit of "[Cd.381] Synchronous control analysis mode", and then turn the target axis bit from OFF to ON in "[Cd.380] Synchronous control start" to start synchronous control.

5.5 Cam Position Calculation Function

The cam position is calculated by the user program with this function. This function can be used to calculate the cam position for the synchronous control initial position before starting synchronous control.

Example

The following shows the procedure for synchronous position alignment, in a synchronous system where cam axes 2 and 3 are synchronized with the cam axis current value per cycle of axis 1.

1. Calculate the cam axis current value per cycle using this function based on the feed current value and the cam reference position of axis 1.
2. Calculate the cam axis feed current value of axis 2 with this function based on the cam axis current value per cycle that was calculated in 1).
3. Calculate the cam axis feed current value of axis 3 with this function based on the cam axis current value per cycle that was calculated in 1).
4. Execute positioning on axis 2 to the cam axis feed current value which was calculated in 2), and also on axis 3 to the cam axis feed current value which was calculated in 3).
5. Start synchronous control on axis 1, 2 and 3 with the feed current value restoration mode. Use the cam axis current value per cycle that was calculated in 1) for the cam axis current value per cycle (Initial setting).

Point

[API library]

- To calculate the cam axis feed current value, use the MMC_Controller::CalcCamCommandPosition method.
- To calculate the cam axis current value per cycle, use the MMC_Controller::CalcCamCommandPositionPerCycle method.

Cam position calculation control data

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.612] Cam position calculation request	<ul style="list-style-type: none"> • Set the cam position calculation request. • The Simple Motion board resets the value to "0" automatically after completion of the cam position calculation. Fetch cycle: Main cycle ^{*1}	■Set in decimal. 1: Cam axis feed current value calculation request 2: Cam axis current value per cycle calculation request	0	53780
[Cd.613] Cam position calculation: Cam No.	<ul style="list-style-type: none"> • Set the cam No. for the cam position calculation. Fetch cycle: At requesting cam position calculation	■Set in decimal. 0 to 1024	0	53781
[Cd.614] Cam position calculation: Stroke amount	<ul style="list-style-type: none"> • Set the cam stroke amount for the cam position calculation. Fetch cycle: At requesting cam position calculation	■Set in decimal. -2147483648 to 2147483647 [Output axis position units ^{*2}]	0	53782 53783
[Cd.615] Cam position calculation: Cam axis length per cycle	<ul style="list-style-type: none"> • Set the cam axis length per cycle for the cam position calculation. Fetch cycle: At requesting cam position calculation	■Set in decimal. 1 to 2147483647 [Cam axis cycle units ^{*3}]	0	53784 53785
[Cd.616] Cam position calculation: Cam reference position	<ul style="list-style-type: none"> • Set the cam reference position for the cam position calculation. Fetch cycle: At requesting cam position calculation	■Set in decimal. -2147483648 to 2147483647 [Output axis position units ^{*2}]	0	53786 53787
[Cd.617] Cam position calculation: Cam axis current value per cycle	<ul style="list-style-type: none"> • Set the cam axis current value per cycle for the cam position calculation. Fetch cycle: At requesting cam position calculation	■Set in decimal. 0 to (Cam axis length per cycle) [Cam axis cycle units ^{*3}]	0	53788 53789

Setting item	Setting details	Setting value	Default value	Buffer memory address
[Cd.618] Cam position calculation: Cam axis feed current value	<ul style="list-style-type: none"> Set the cam axis feed current value for the cam position calculation. (Set when calculating the cam axis current value per cycle.) Fetch cycle: At requesting cam position calculation	■Set in decimal. -2147483648 to 2147483647 [Output axis position units*2]	0	53790 53791

*1 With the exception of positioning control, main cycle processing is executed during the next available time. It changes by status of axis start.

*2 Output axis position units ( Page 110 Units for the output axis)

*3 Cam axis cycle units ( Page 110 Units for the output axis)

For labels, refer to the following.

 Page 161 Cam operation control data: Cam position calculation

[Cd.612] Cam position calculation request

Set the following commands to calculate the cam position.

Setting value	Details
1	Cam axis feed current value calculation request
2	Cam axis current value per cycle calculation request

The result is stored in "[Md.600] Cam position calculation result" and the setting value is reset to "0" automatically after completion of cam position calculation.

If warnings occur when requesting the cam position calculation, the warning No. is stored in "[Md.24] Axis warning No." of axis 1 and the setting value is reset to "0" automatically.

When a value other than the request command values listed above is set, this calculation does not get executed and the setting value is reset to "0" automatically.

[Cd.613] Cam position calculation: Cam No.

Set the cam No. for the cam position calculation. If 0 is set for the cam No., the cam position is calculated as a linear cam.

[Cd.614] Cam position calculation: Stroke amount

Set the cam stroke amount for the cam position calculation.

[Cd.615] Cam position calculation: Cam axis length per cycle

Set the cam axis length per cycle for the cam position calculation.

[Cd.616] Cam position calculation: Cam reference position

Set the cam reference position for the cam position calculation.

[Cd.617] Cam position calculation: Cam axis current value per cycle

Set the cam axis current value per cycle for the cam position calculation when calculating the cam axis feed current value.

Set the cam axis current value per cycle as the starting point to search when calculating the cam axis current value per cycle and the cam position.

[Cd.618] Cam position calculation: Cam axis feed current value

Set the cam axis feed current value for the cam position calculation when calculating the cam axis current value per cycle.

This is not used when calculating the cam axis feed current value.

Cam position calculation monitor data

Monitor item	Storage details	Monitor value	Buffer memory address
[Md.600] Cam position calculation result	<ul style="list-style-type: none"> The result of the cam position calculation is stored. <p><u>Refresh cycle: At cam position calculation completion</u></p>	<p>■Monitoring is carried out in decimal.</p> <ul style="list-style-type: none"> When calculating the cam axis feed current value: -2147483648 to 2147483647 [Output axis position units^{*1}] When calculating the cam axis current value per cycle: 0 to (Cam axis length per cycle - 1) [Cam axis cycle units^{*2}] 	53800 53801

*1 Output axis position units (☞ Page 110 Units for the output axis)

*2 Cam axis cycle units (☞ Page 110 Units for the output axis)

For labels, refer to the following.

☞ Page 156 Cam operation monitor data: Cam position calculation

[Md.600] Cam position calculation result

The result of the cam position calculation is stored.

Cam position calculation	Storage details
When calculating the cam axis feed current value	Calculated value of the cam axis feed current value is stored.
When calculating the cam axis current value per cycle	Calculated value of the cam axis current value per cycle is stored. The cam reference position is not updated automatically by the cam position calculation function.

Search for the cam axis current value per cycle

When calculating the cam axis current value per cycle using cam data, the position corresponding to "[Cd.618] Cam position calculation: Cam axis feed current value" is searched using cam data based on the position specified by "[Cd.617] Cam position calculation: Cam axis current value per cycle".

The following shows the order of the search for "[Cd.618] Cam position calculation: Cam axis feed current value".

■Stroke ratio data format

When "the nth point of cam data \leq [Cd.617] Cam position calculation: Cam axis current value per cycle < the n + 1st point of cam data", the position corresponding to "[Cd.618] Cam position calculation: Cam axis feed current value" is searched from the nth point of cam data.


If "[Cd.617] Cam position calculation: Cam axis current value per cycle" is in the middle of the cam data and the corresponding position is not found until the last point of the cam data, return to the 0th point and search until the search starting point.

If the corresponding position is not found even though the whole area of the cam data has been searched, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur in reciprocated cam pattern.

For the feed cam, calculates "[Cd.618] Cam position calculation: Cam axis feed current value" by the stroke difference and searches again from the 0th point to the whole range. If the corresponding position is not found even though the search process starts again, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur.

Ex.


When "[Cd.617] Cam position calculation: Cam axis current value per cycle" is corresponding to the 0th point of cam data



- Searches until between the 255th point and the 256th point (last point) in order of the cam data between the 0th point and the 1st point and between the 1st point and the 2nd point.

Ex.

When "[Cd.617] Cam position calculation: Cam axis current value per cycle" is corresponding to the 128th point of cam data



- Searches until between the 255th point and the 256th point (last point) in order of the cam data between the 128th point and the 129th point and between the 130th point and the 131th point.

- If the corresponding position is not found until the last point of the cam data, searches from the 0th point of the cam data.
- Searches until between the 127th point and the 128th point in order of the cam data between the 0th point and the 1st point and between the 1st point and the 2nd point.

■Coordinate data format

(1) The range before the 1st point of cam data

When the 1st point of the cam data is larger than 0 and "[Cd.617] Cam position calculation: Cam axis current value per cycle < the 1st point of cam data", the position corresponding to "[Cd.618] Cam position calculation: Cam axis feed current value" is searched from the range before the 1st point of the cam data.


If the corresponding position is not found in the range of (1), searches in the range of (2). If the corresponding position is not found in the range of (2) either, searches in the range of (3).

If the corresponding position is not found even though the range of (1) to (3) has been searched, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur in reciprocated cam pattern.

For the feed cam, calculates "[Cd.618] Cam position calculation: Cam axis feed current value" by the stroke difference and searches again from the 0th point to the whole range. If the corresponding position is not found even though the search process starts again, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur.

Ex.

When "[Cd.617] Cam position calculation: Cam axis current value per cycle" is set before the 1st point of cam data



- Searches from the range of (1).
- If the corresponding position is not found in the range of (1), searches from the 1st point of the cam data in the range of (2).

(2) The range within the cam data

When "[Cd.617] Cam position calculation: Cam axis current value per cycle < the last point of cam data", the position corresponding to "[Cd.618] Cam position calculation: Cam axis feed current value" is searched from the range of the cam data.

When "the nth point of cam data \leq [Cd.617] Cam position calculation: Cam axis current value per cycle < the n + 1st point of cam data", the position corresponding to "[Cd.618] Cam position calculation: Cam axis feed current value" is searched from the nth point of cam data.

If "[Cd.617] Cam position calculation: Cam axis current value per cycle" is in the middle of the cam data and the corresponding position is not found until the last point of the cam data, returns to the 1st point and searches until the search starting point.


If the corresponding position is not found in the range of (2), searches in the range of (3).

If the corresponding position is not found even though the range of (2) and (3) has been searched, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur in reciprocated cam pattern.

For the feed cam, calculates "[Cd.618] Cam position calculation: Cam axis feed current value" by the stroke difference and searches again from the 0th point to the whole range. If the corresponding position is not found even though the search process starts again, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur.

Ex.


When "[Cd.617] Cam position calculation: Cam axis current value per cycle" is corresponding to the 1st point of cam data



- Searches until between the 4th point and the 5th point (last point) in order of the cam data between the 1st point and the 2nd point and between the 2nd point and the 3rd point.
- If the corresponding position is not found until the last point of the cam data, searches from the range of (3).

Ex.

When "[Cd.617] Cam position calculation: Cam axis current value per cycle" is corresponding to the 3rd point of cam data



- Searches in order of the cam data between the 3rd point and the 4th point and between the 4th point and the 5th point (last point).
- If the corresponding position is not found until the last point of the cam data, searches from the 1st point of the cam data.
- If the corresponding position is not found in the cam data between the 1st point and the 2nd point and between the 2nd point and the 3rd point, searches from the range of (3).


(3) The range from the last point of cam data to the cam axis length per cycle

When "the last point of cam data \leq [Cd.617] Cam position calculation: Cam axis current value per cycle < cam axis length per cycle", the position corresponding to "[Cd.618] Cam position calculation: Cam axis feed current value" is searched from the last point of the cam data or later.

If the corresponding position is not found even though the range of (3) has been searched, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur in reciprocated cam pattern. For the feed cam, calculates "[Cd.618] Cam position calculation: Cam axis feed current value" by the stroke difference and searches again from the 0th point to the whole range. If the corresponding position is not found even though the search process starts again, the warning "Cam position calculation cam axis 1 cycle current value calculation disable" (warning code: 0C64H) will occur.

Ex.

When "[Cd.617] Cam position calculation: Cam axis current value per cycle" is corresponding to the last point of cam data



- Searches from the range of (3).


5.6 Method to Restart Synchronous Control

The relationship of the synchronous position for synchronous control is always saved in the Simple Motion board. Synchronous control can be restarted without returning all axes to their starting points by restoring the synchronized relationship through the synchronous control initial position parameters ( Page 129 Synchronous Control Initial Position Parameters).

The reference axis used to restart synchronous control is different for each system. The following procedure shows an example of how to restore synchronized values based on the servo input axis as reference position.

Example

Restoring 2 output axes (axis 2, axis 3) based on the servo input axis (axis 1) as the reference position. (Press conveyance device)



■Procedure for synchronous control (first time)

1. Execute home position return for axis 1, 2 and 3, and position to the synchronization starting point.
2. Set the synchronous control initial position parameters for axis 2 and 3 as follows.

Setting item	Setting value
[Pr.460] Setting method of current value per cycle after main shaft gear	2: Calculate from input axis
[Pr.462] Cam axis position restoration object	0: Cam axis current value per cycle restoration
[Pr.463] Setting method of cam reference position	2: Feed current value
[Pr.468] Cam axis current value per cycle (Initial setting)	0

3. Turn ON the bits for axis 2 and 3 in "[Cd.380] Synchronous control start" to start synchronous control.

■Procedure for restarting synchronous control

1. Set the synchronous control initial position parameters for axis 2 and 3 as follows.

Setting item	Setting value
[Pr.460] Setting method of current value per cycle after main shaft gear	2: Calculate from input axis
[Pr.462] Cam axis position restoration object	2: Cam axis feed current value restoration
[Pr.463] Setting method of cam reference position	0: Previous value
[Pr.464] Setting method of cam axis current value per cycle	2: Current value per cycle after main shaft gear

2. Turn ON the bits for axes 2 and 3 in "[Cd.381] Synchronous control analysis mode", and then turn ON the bits for axes 2 and 3 in "[Cd.380] Synchronous control start" to execute the synchronous control analysis. The analyzed result is updated in [Md.400] to [Md.425].
3. Position axes 2 and 3 to "[Md.409] Cam axis feed current value" which has been updated in 2.
4. Turn OFF the bits for axes 2 and 3 in "[Cd.381] Synchronous control analysis mode", and then turn ON the bits for axes 2 and 3 in "[Cd.380] Synchronous control start" to start synchronous control.

APPENDICES

Appendix 1 List of Buffer Memory Addresses (for Synchronous Control)

The following shows the relation between the buffer memory addresses and the various items.

Refer to the following for the list of general buffer memory addresses.

📖 Simple Motion Board User's Manual (Application)

Refer to the following for the list of buffer memory addresses for network.

📖 Simple Motion Board User's Manual (Network)

If a label is used for some different classes, the class that is used more frequently is shown in the following lists.

Parameters

■ Servo input axis parameters

n: Axis No. - 1

Item	Buffer memory address	Label
[Pr.300] Servo input axis type	32800+10n	MMC_Axis::SvInpAxPrm.Type
[Pr.301] Servo input axis smoothing time constant	32801+10n	MMC_Axis::SvInpAxPrm.SmoothingTimeConstant
[Pr.302] Servo input axis phase compensation advance time	32802+10n 32803+10n	MMC_Axis::SvInpAxPrm.PhaseCompensationAdvanceTime
[Pr.303] Servo input axis phase compensation time constant	32804+10n	MMC_Axis::SvInpAxPrm.PhaseCompensationTimeConstant
[Pr.304] Servo input axis rotation direction restriction	32805+10n	MMC_Axis::SvInpAxPrm.RotationRestriction

■ Synchronous encoder axis parameters

j: Synchronous encoder axis No. - 1

Item	Buffer memory address	Label
[Pr.320] Synchronous encoder axis type	34720+20j	MMC_SyncEncoder::SyncEncAxPrm.Type
[Pr.321] Synchronous encoder axis unit setting	34721+20j	MMC_SyncEncoder::SyncEncAxPrm.Unit
[Pr.322] Synchronous encoder axis unit conversion: Numerator	34722+20j 34723+20j	MMC_SyncEncoder::SyncEncAxPrm.UnitConversionNumerator
[Pr.323] Synchronous encoder axis unit conversion: Denominator	34724+20j 34725+20j	MMC_SyncEncoder::SyncEncAxPrm.UnitConversionDenominator
[Pr.324] Synchronous encoder axis length per cycle	34726+20j 34727+20j	MMC_SyncEncoder::SyncEncAxPrm.LengthPerCycle
[Pr.325] Synchronous encoder axis smoothing time constant	34728+20j	MMC_SyncEncoder::SyncEncAxPrm.SmoothingTimeConstant
[Pr.326] Synchronous encoder axis phase compensation advance time	34730+20j 34731+20j	MMC_SyncEncoder::SyncEncAxPrm.PhaseCompensationAdvanceTime
[Pr.327] Synchronous encoder axis phase compensation time constant	34732+20j	MMC_SyncEncoder::SyncEncAxPrm.PhaseCompensationTimeConstant
[Pr.328] Synchronous encoder axis rotation direction restriction	34733+20j	MMC_SyncEncoder::SyncEncAxPrm.RotationRestriction
[Pr.329] Resolution of synchronous encoder via buffer memory	34734+20j 34735+20j	MMC_SyncEncoder::SyncEncAxPrm.SyncEncViaCPU_Resolution

A

■ Synchronous encoder axis parameters via link device

j: Synchronous encoder axis No. - 1

Item		Buffer memory address	Label
[Pr.710]	Synchronous encoder axis: Link device type	35520+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncAx.Type
[Pr.711]	Synchronous encoder axis: Link device start No.	35521+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncAx.FirstNo
[Pr.712]	Synchronous encoder axis: Link device count direction setting	35526+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncAx.CntDirection
[Pr.713]	Synchronous encoder axis: Ring counter maximum value	35522+20j 35523+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncAx.CntMax
[Pr.714]	Synchronous encoder axis: Ring counter minimum value	35524+20j 35525+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncAx.CntMin
[Pr.1010]	Synchronous encoder axis start request: Link device type	35530+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncStartReq.Type
[Pr.1011]	Synchronous encoder axis start request: Link device start No.	35531+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncStartReq.FirstNo
[Pr.1012]	Synchronous encoder axis start request: Link device bit specification	35532+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncStartReq.BitSpecification
[Pr.1013]	Synchronous encoder axis start request: Link device logic setting	35533+20j	MMC_CcieSyncEncoder::SyncEncAxPrmViaLinkDev.SyncEncStartReq.LogicSetting

■ Synchronous parameters: Main shaft

n: Axis No. - 1

Item		Buffer memory address	Label
[Pr.400]	Main input axis No.	36400+200n	MMC_Axis::SyncCtrlPrm.MainInputAxisNo
[Pr.401]	Sub input axis No.	36401+200n	MMC_Axis::SyncCtrlPrm.SubInputAxisNo
[Pr.402]	Composite main shaft gear	36402+200n	MMC_Axis::SyncCtrlPrm.MainShaftCompositeGear
[Pr.403]	Main shaft gear: Numerator	36404+200n 36405+200n	MMC_Axis::SyncCtrlPrm.MainShaftGearNumerator
[Pr.404]	Main shaft gear: Denominator	36406+200n 36407+200n	MMC_Axis::SyncCtrlPrm.MainShaftGearDenominator
[Pr.405]	Main shaft clutch control setting	36408+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchControlMode
[Pr.406]	Main shaft clutch reference address setting	36409+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchReferencePosition
[Pr.407]	Main shaft clutch ON address	36410+200n 36411+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchOnPosition
[Pr.408]	Movement amount before main shaft clutch ON	36412+200n 36413+200n	MMC_Axis::SyncCtrlPrm.MainShaftMovementAmountBeforeClutchOn
[Pr.409]	Main shaft clutch OFF address	36414+200n 36415+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchOffPosition
[Pr.410]	Movement amount before main shaft clutch OFF	36416+200n 36417+200n	MMC_Axis::SyncCtrlPrm.MainShaftMovementAmountBeforeClutchOff
[Pr.411]	Main shaft clutch smoothing method	36418+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchSmoothMethod
[Pr.412]	Main shaft clutch smoothing time constant	36419+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchSmoothTimeConstant
[Pr.413]	Slippage at main shaft clutch ON	36420+200n 36421+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchOnSlipAmount
[Pr.414]	Slippage at main shaft clutch OFF	36422+200n 36423+200n	MMC_Axis::SyncCtrlPrm.MainShaftClutchOffSlipAmount

■ Synchronous parameters: Auxiliary shaft

n: Axis No. - 1

Item	Buffer memory address	Label
[Pr.418]	Auxiliary shaft axis No.	36430+200n MMC_Axis::SyncCtrlPrm.AuxShaftAxisNo
[Pr.419]	Composite auxiliary shaft gear	36431+200n MMC_Axis::SyncCtrlPrm.AuxShaftCompositeGear
[Pr.420]	Auxiliary shaft gear: Numerator	36432+200n 36433+200n MMC_Axis::SyncCtrlPrm.AuxShaftGearNumerator
[Pr.421]	Auxiliary shaft gear: Denominator	36434+200n 36435+200n MMC_Axis::SyncCtrlPrm.AuxShaftGearDenominator
[Pr.422]	Auxiliary shaft clutch control setting	36436+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchControlMode
[Pr.423]	Auxiliary shaft clutch reference address setting	36437+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchReferencePosition
[Pr.424]	Auxiliary shaft clutch ON address	36438+200n 36439+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchOnPosition
[Pr.425]	Movement amount before auxiliary shaft clutch ON	36440+200n 36441+200n MMC_Axis::SyncCtrlPrm.AuxShaftMovementAmountBeforeClutchOn
[Pr.426]	Auxiliary shaft clutch OFF address	36442+200n 36443+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchOffPosition
[Pr.427]	Movement amount before auxiliary shaft clutch OFF	36444+200n 36445+200n MMC_Axis::SyncCtrlPrm.AuxShaftMovementAmountBeforeClutchOff
[Pr.428]	Auxiliary shaft clutch smoothing method	36446+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchSmoothMethod
[Pr.429]	Auxiliary shaft clutch smoothing time constant	36447+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchSmoothTimeConstant
[Pr.430]	Slippage at auxiliary shaft clutch ON	36448+200n 36449+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchOnSlipAmount
[Pr.431]	Slippage at auxiliary shaft clutch OFF	36450+200n 36451+200n MMC_Axis::SyncCtrlPrm.AuxShaftClutchOffSlipAmount

■ Synchronous parameters: Speed change gear

n: Axis No. - 1

Item	Buffer memory address	Label
[Pr.434]	Speed change gear	36460+200n MMC_Axis::SyncCtrlPrm.SpeedChangeGear
[Pr.435]	Speed change gear smoothing time constant	36461+200n MMC_Axis::SyncCtrlPrm.SpeedChangeGearSmoothTimeConstant
[Pr.436]	Speed change ratio: Numerator	36462+200n 36463+200n MMC_Axis::SyncCtrlPrm.SpeedChangeRatioNumerator
[Pr.437]	Speed change ratio: Denominator	36464+200n 36465+200n MMC_Axis::SyncCtrlPrm.SpeedChangeRatioDenominator

A

■Synchronous parameters: Output axis

n: Axis No. - 1

Item		Buffer memory address	Label
[Pr.438]	Cam axis cycle unit setting	36470+200n	MMC_Axis::SyncCtrlPrm.CamAxisCycleUnit
[Pr.439]	Cam axis length per cycle	36472+200n 36473+200n	MMC_Axis::SyncCtrlPrm.CamAxisLengthPerCycle
[Pr.440]	Cam No.	36474+200n	MMC_Axis::SyncCtrlPrm.CamNo
[Pr.441]	Cam stroke amount	36476+200n 36477+200n	MMC_Axis::SyncCtrlPrm.CamStrokeAmount
[Pr.442]	Cam axis length per cycle change setting	36471+200n	MMC_Axis::SyncCtrlPrm.CamAxisLengthPerCycleChangeMode
[Pr.444]	Cam axis phase compensation advance time	36482+200n 36483+200n	MMC_Axis::SyncCtrlPrm.CamAxisPhaseCompensationAdvanceTime
[Pr.445]	Cam axis phase compensation time constant	36484+200n	MMC_Axis::SyncCtrlPrm.CamAxisPhaseCompensationTimeConstant
[Pr.446]	Synchronous control deceleration time	36485+200n	MMC_Axis::SyncCtrlPrm.SyncCtrlDecelerationTime
[Pr.447]	Output axis smoothing time constant	36486+200n	MMC_Axis::SyncCtrlPrm.OutputAxisSmoothTimeConstant

■Synchronous parameters: Synchronous control initial position

n: Axis No. - 1

Item		Buffer memory address	Label
[Pr.460]	Setting method of current value per cycle after main shaft gear	36500+200n	MMC_Axis::SyncCtrlPrm.MainShaftGearPositionPerCycleMode
[Pr.461]	Setting method of current value per cycle after auxiliary shaft gear	36501+200n	MMC_Axis::SyncCtrlPrm.AuxShaftGearPositionPerCycleMode
[Pr.462]	Cam axis position restoration object	36502+200n	MMC_Axis::SyncCtrlPrm.CamPositionRestorationMode
[Pr.463]	Setting method of cam reference position	36503+200n	MMC_Axis::SyncCtrlPrm.CamReferencePositionMode
[Pr.464]	Setting method of cam axis current value per cycle	36504+200n	MMC_Axis::SyncCtrlPrm.CamPositionPerCycleMode
[Pr.465]	Current value per cycle after main shaft gear (Initial setting)	36506+200n 36507+200n	MMC_Axis::SyncCtrlPrm.MainShaftGearInitialPositionPerCycle
[Pr.466]	Current value per cycle after auxiliary shaft gear (Initial setting)	36508+200n 36509+200n	MMC_Axis::SyncCtrlPrm.AuxShaftGearInitialPositionPerCycle
[Pr.467]	Cam reference position (Initial setting)	36510+200n 36511+200n	MMC_Axis::SyncCtrlPrm.CamInitialReferencePosition
[Pr.468]	Cam axis current value per cycle (Initial setting)	36512+200n 36513+200n	MMC_Axis::SyncCtrlPrm.CamInitialPositionPerCycle

Monitor data

■ Servo input axis monitor data

n: Axis No. - 1

Item		Buffer memory address	Label
[Md.300]	Servo input axis current value	33120+10n 33121+10n	MMC_Axis::SvInpAxMntr.CommandPosition
[Md.301]	Servo input axis speed	33122+10n 33123+10n	MMC_Axis::SvInpAxMntr.Speed
[Md.302]	Servo input axis phase compensation amount	33124+10n 33125+10n	MMC_Axis::SvInpAxMntr.PhaseCompensationAmount
[Md.303]	Servo input axis rotation direction restriction amount	33126+10n 33127+10n	MMC_Axis::SvInpAxMntr.RotationRestrictionAmount

■ Synchronous encoder axis monitor data

j: Synchronous encoder axis No. - 1

Item		Buffer memory address	Label
[Md.320]	Synchronous encoder axis current value	35200+20j 35201+20j	MMC_SyncEncoder::SyncEncAxMntr.CommandPosition
[Md.321]	Synchronous encoder axis current value per cycle	35202+20j 35203+20j	MMC_SyncEncoder::SyncEncAxMntr.CommandPositionPerCycle
[Md.322]	Synchronous encoder axis speed	35204+20j 35205+20j	MMC_SyncEncoder::SyncEncAxMntr.Speed
[Md.323]	Synchronous encoder axis phase compensation amount	35206+20j 35207+20j	MMC_SyncEncoder::SyncEncAxMntr.PhaseCompensationAmount
[Md.324]	Synchronous encoder axis rotation direction restriction amount	35208+20j 35209+20j	MMC_SyncEncoder::SyncEncAxMntr.RotationRestrictionAmount
[Md.325]	Synchronous encoder axis status	35210+20j	MMC_SyncEncoder::SyncEncAxMntr.Status
	b0 Setting valid flag		MMC_SyncEncoder::SyncEncAxMntr.Status_SettingValid
	b1 Connecting valid flag		MMC_SyncEncoder::SyncEncAxMntr.Status_ConnectingValid
	b2 Counter enable flag		MMC_SyncEncoder::SyncEncAxMntr.Status_CounterEnable
	b3 Current value setting request flag		MMC_SyncEncoder::SyncEncAxMntr.Status_CurrentValueSetRequest
	b4 Error detection flag		MMC_SyncEncoder::SyncEncAxMntr.Status_Error
	b5 Warning detection flag		MMC_SyncEncoder::SyncEncAxMntr.Status_Warning
	b6 Start request flag		MMC_SyncEncoder::SyncEncAxMntr.Status_StartRequest
[Md.326]	Synchronous encoder axis error No.	35211+20j	MMC_SyncEncoder::SyncEncAxMntr.ErrorNo
[Md.327]	Synchronous encoder axis warning No.	35212+20j	MMC_SyncEncoder::SyncEncAxMntr.WarningNo

■ Synchronous control monitor data

n: Axis No. - 1

Item		Buffer memory address	Label
[Md.400]	Current value after composite main shaft gear	42800+40n 42801+40n	MMC_Axis::SyncCtrlMntr.MainShaftCompositeGearPosition
[Md.401]	Current value per cycle after main shaft gear	42802+40n 42803+40n	MMC_Axis::SyncCtrlMntr.MainShaftGearPositionPerCycle
[Md.402]	Current value per cycle after auxiliary shaft gear	42804+40n 42805+40n	MMC_Axis::SyncCtrlMntr.AuxShaftGearPositionPerCycle
[Md.406]	Cam axis phase compensation amount	42810+40n 42811+40n	MMC_Axis::SyncCtrlMntr.CamPhaseCompensationAmount
[Md.407]	Cam axis current value per cycle	42812+40n 42813+40n	MMC_Axis::SyncCtrlMntr.CamPositionPerCycle
[Md.408]	Cam reference position	42814+40n 42815+40n	MMC_Axis::SyncCtrlMntr.CamReferencePosition

A

Item		Buffer memory address	Label
[Md.409]	Cam axis feed current value	42816+40n 42817+40n	MMC_Axis::SyncCtrlMntr.CamCommandPosition
[Md.410]	Execute cam No.	42818+40n	MMC_Axis::SyncCtrlMntr.CurrentCamNo
[Md.411]	Execute cam stroke amount	42820+40n 42821+40n	MMC_Axis::SyncCtrlMntr.CurrentCamStrokeAmount
[Md.412]	Execute cam axis length per cycle	42822+40n 42823+40n	MMC_Axis::SyncCtrlMntr.CurrentCamAxisLengthPerCycle
[Md.420]	Main shaft clutch ON/OFF status	42828+40n	MMC_Axis::SyncCtrlMntr.MainShaftClutchStatus
[Md.421]	Main shaft clutch smoothing status	42829+40n	MMC_Axis::SyncCtrlMntr.MainShaftClutchSmoothingStatus
[Md.422]	Main shaft clutch slippage (accumulative)	42830+40n 42831+40n	MMC_Axis::SyncCtrlMntr.MainShaftClutchAccumulativeSlippage
[Md.423]	Auxiliary shaft clutch ON/OFF status	42832+40n	MMC_Axis::SyncCtrlMntr.AuxShaftClutchStatus
[Md.424]	Auxiliary shaft clutch smoothing status	42833+40n	MMC_Axis::SyncCtrlMntr.AuxShaftClutchSmoothingStatus
[Md.425]	Auxiliary shaft clutch slippage (accumulative)	42834+40n 42835+40n	MMC_Axis::SyncCtrlMntr.AuxShaftClutchAccumulativeSlippage

■Cam operation monitor data: Cam position calculation

Item		Buffer memory address	Label
[Md.600]	Cam position calculation result	53800 53801	MMC_Controller::CamCalculation.Mntr.Result

Control data

■Synchronous control system control data

Item		Buffer memory address	Label
[Cd.380]	Synchronous control start	36320	MMC_Axis::SynchronousControlStart
[Cd.381]	Synchronous control analysis mode	36322	MMC_Axis::SynchronousControlAnalysisMode

■Synchronous encoder axis control data

j: Synchronous encoder axis No. - 1

Item		Buffer memory address	Label
[Cd.320]	Synchronous encoder axis control start	35040+10j	MMC_SyncEncoder::SyncEncAxCtrl.StartControl
[Cd.321]	Synchronous encoder axis control method	35041+10j	MMC_SyncEncoder::SyncEncAxCtrl.ControlMethod
[Cd.322]	Synchronous encoder axis current value setting address	35042+10j 35043+10j	MMC_SyncEncoder::SyncEncAxCtrl.NewPosition
[Cd.323]	Synchronous encoder axis error reset	35044+10j	MMC_SyncEncoder::SyncEncAxCtrl.ResetError
[Cd.324]	Connection command of synchronous encoder via buffer memory	35045+10j	MMC_SyncEncoder::SyncEncAxCtrl.EnableSyncEncViaCPU
[Cd.325]	Input value for synchronous encoder via buffer memory	35046+10j 35047+10j	MMC_SyncEncoder::SyncEncAxCtrl.SyncEncViaCPU_InputValue

■Control data for synchronous control

n: Axis No. - 1

Item		Buffer memory address	Label
[Cd.400]	Main shaft clutch command	44080+20n	MMC_Axis::SyncCtrlAxCtrl.CommandMainShaftClutch
[Cd.401]	Main shaft clutch control invalid command	44081+20n	MMC_Axis::SyncCtrlAxCtrl.CommandMainShaftClutchInvalid
[Cd.402]	Main shaft clutch forced OFF command	44082+20n	MMC_Axis::SyncCtrlAxCtrl.CommandMainShaftClutchForcedOff
[Cd.403]	Auxiliary shaft clutch command	44083+20n	MMC_Axis::SyncCtrlAxCtrl.CommandAuxShaftClutch
[Cd.404]	Auxiliary shaft clutch control invalid command	44084+20n	MMC_Axis::SyncCtrlAxCtrl.CommandAuxShaftClutchInvalid
[Cd.405]	Auxiliary shaft clutch forced OFF command	44085+20n	MMC_Axis::SyncCtrlAxCtrl.CommandAuxShaftClutchForcedOff
[Cd.406]	Synchronous control change request	44086+20n	MMC_Axis::SyncCtrlAxCtrl.RequestSyncCtrlChange
[Cd.407]	Synchronous control change command	44087+20n	MMC_Axis::SyncCtrlAxCtrl.SyncCtrlChangeCommand
[Cd.408]	Synchronous control change value	44088+20n 44089+20n	MMC_Axis::SyncCtrlAxCtrl.SyncCtrlChangeValue
[Cd.409]	Synchronous control reflection time	44090+20n	MMC_Axis::SyncCtrlAxCtrl.SyncCtrlReflectionTime

■Cam operation control data: Cam data operation

Item		Buffer memory address	Label
[Cd.600]	Cam data operation request	600000	MMC_Controller::CamOperation.Request
[Cd.601]	Operation cam No.	600001	MMC_Controller::CamOperation.CamNo
[Cd.602]	Cam data first position	600002	MMC_Controller::CamOperation.FirstPosition
[Cd.603]	Number of cam data operation points	600003	MMC_Controller::CamOperation.Size
[Cd.604]	Cam data format	600004	MMC_Controller::CamOperation.Format
[Cd.605]	Cam resolution/coordinate number	600005	MMC_Controller::CamOperation.CamResolution
[Cd.606]	Cam data starting point	600006	MMC_Controller::CamOperation.StartingPoint
[Cd.607]	Cam data value	600008 to 862147	MMC_EM340GF::ExCamData.StrokeRatioData[0].Value : MMC_EM340GF::ExCamData.StrokeRatioData[32767].Value
Input value			MMC_EM340GF::ExCamData.CoordinateData[0].InputValue : MMC_EM340GF::ExCamData.CoordinateData[65534].InputValue
Output value			MMC_EM340GF::ExCamData.CoordinateData[0].OutputValue : MMC_EM340GF::ExCamData.CoordinateData[65534].OutputValue
Cam for rotary cutter (central reference) data			*1
Easy stroke ratio cam data			*2
Advanced stroke ratio cam data			*3

*1 The item details when "102: Cam auto-generation data format for rotary cutter cam (Central reference)" is selected in "[Cd.604] Cam data format" are shown below.

- Cam for rotary cutter (central reference) data

Details	Buffer memory address	Label
Resolution	600008 600009	MMC_EM340GF::ExCamData.RotaryCutter.Resolution
Auto-generation option	600010	MMC_EM340GF::ExCamData.RotaryCutter.Option
Synchronous section acceleration ratio	600011	MMC_EM340GF::ExCamData.RotaryCutter.SyncSectionAccelerationRatio

Details	Buffer memory address	Label
Sheet length	600012 600013	MMC_EM340GF::ExCamData.RotaryCutter.SheetLength
Sheet synchronization width	600014 600015	MMC_EM340GF::ExCamData.RotaryCutter.SheetSyncWidth
Synchronous axis length	600016 600017	MMC_EM340GF::ExCamData.RotaryCutter.SyncAxisLength
Synchronous position adjustment	600018 600019	MMC_EM340GF::ExCamData.RotaryCutter.SyncPointAdjustment
Acceleration/deceleration width	600020 600021	MMC_EM340GF::ExCamData.RotaryCutter.AccelerationWidth
Number of cutter	600022	MMC_EM340GF::ExCamData.RotaryCutter.CutterNum
Asynchronous speed result	600023	MMC_EM340GF::ExCamData.RotaryCutter.AsyncSpeedResult

*2 The item details when "103: Cam auto-generation data format for easy stroke ratio cam" is selected in "[Cd.604] Cam data format" are shown below.

• Easy stroke ratio cam data

Details	Buffer memory address	Label	
Resolution	600008 600009	MMC_EM340GF::ExCamData.SimpleStroke.Resolution	
Cam axis length per cycle	600010 600011	MMC_EM340GF::ExCamData.SimpleStroke.CamAxisLengthPerCycle	
Cam data starting point	600012 600013	MMC_EM340GF::ExCamData.SimpleStroke.StartingPoint	
Number of sections	600014	MMC_EM340GF::ExCamData.SimpleStroke.SectionNum	
Section 1	Cam curve type	600016	MMC_EM340GF::ExCamData.SimpleStroke.SimpleSection[0].CurveType
	End point	600018 600019	MMC_EM340GF::ExCamData.SimpleStroke.SimpleSection[0].EndPoint
	Stroke	600020 600021	MMC_EM340GF::ExCamData.SimpleStroke.SimpleSection[0].Stroke
⋮	⋮	⋮	⋮
Section 32	Cam curve type	600202	MMC_EM340GF::ExCamData.SimpleStroke.SimpleSection[31].CurveType
	End point	600204 600205	MMC_EM340GF::ExCamData.SimpleStroke.SimpleSection[31].EndPoint
	Stroke	600206 600207	MMC_EM340GF::ExCamData.SimpleStroke.SimpleSection[31].Stroke

*3 The item details when "104: Cam auto-generation data format for advanced stroke ratio cam" is selected in "[Cd.604] Cam data format" are shown below.

• Advanced stroke ratio cam data

Details	Buffer memory address	Label
Resolution	600008 600009	MMC_EM340GF::ExCamData.DetailsStroke.Resolution
Cam axis length per cycle	600010 600011	MMC_EM340GF::ExCamData.DetailsStroke.CamAxisLengthPerCycle
Cam stroke amount	600012 600013	MMC_EM340GF::ExCamData.DetailsStroke.CamStrokeAmount
Unit setting	600014	MMC_EM340GF::ExCamData.DetailsStroke.Unit
Cam data starting point	600016 600017	MMC_EM340GF::ExCamData.DetailsStroke.StartingPoint
Number of sections	600018	MMC_EM340GF::ExCamData.DetailsStroke.SectionNum

Details		Buffer memory address	Label
Section 1	Cam curve type	600020	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].CurveType
	End point	600022 600023	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].EndPoint
	Stroke	600024 600025	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].Stroke
	Curve applicable range (P1)	600026	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].CurveScopeP1
	Curve applicable range (P2)	600027	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].CurveScopeP2
Section 1	Acceleration/ deceleration range compensation (Range L1)	600028	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].AccelerationRangeCompensationL 1
	Acceleration/ deceleration range compensation (Range L2)	600029	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[0].AccelerationRangeCompensationL 2
⋮	⋮	⋮	⋮
Section 360	Cam curve type	603610	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].CurveType
	End point	603612 603613	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].EndPoint
	Stroke	603614 603615	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].Stroke
	Curve applicable range (P1)	603616	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].CurveScopeP1
	Curve applicable range (P2)	603617	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].CurveScopeP2
	Acceleration/ deceleration range compensation (Range L1)	603618	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].AccelerationRangeCompensatio nL1
	Acceleration/ deceleration range compensation (Range L2)	603619	MMC_EM340GF::ExCamData.DetailsStroke.DetailsSection[359].AccelerationRangeCompensatio nL2

■ Cam operation control data: Cam auto-generation

Item		Buffer memory address	Label
[Cd.608]	Cam auto-generation request	862200	MMC_EM340GF::ExAutomaticCam.Request
[Cd.609]	Cam auto-generation cam No.	862201	MMC_EM340GF::ExAutomaticCam.CamNo
[Cd.610]	Cam auto-generation type	862202	MMC_EM340GF::ExAutomaticCam.Type
[Cd.611]	Cam auto-generation data	Cam auto-generation data for rotary cutter (central reference)	862204 to 866295 *1
			Easy stroke ratio cam data for auto-generation *2
			Advanced stroke ratio cam data for auto-generation *3



*1 The item details when "2: Cam for rotary cutter (Central reference)" is selected in "[Cd.610] Cam auto-generation type" are shown below.

• Cam auto-generation data for rotary cutter (central reference)

Details	Buffer memory address	Label
Resolution	862204 862205	MMC_EM340GF::ExAutomaticCam.RotaryCutter.Resolution
Auto-generation option	862206	MMC_EM340GF::ExAutomaticCam.RotaryCutter.Option
Synchronous section acceleration ratio	862207	MMC_EM340GF::ExAutomaticCam.RotaryCutter.SyncSectionAccelerationRatio
Sheet length	862208 862209	MMC_EM340GF::ExAutomaticCam.RotaryCutter.SheetLength
Sheet synchronization width	862210 862211	MMC_EM340GF::ExAutomaticCam.RotaryCutter.SheetSyncWidth
Synchronous axis length	862212 862213	MMC_EM340GF::ExAutomaticCam.RotaryCutter.SyncAxisLength
Synchronous position adjustment	862214 862215	MMC_EM340GF::ExAutomaticCam.RotaryCutter.SyncPointAdjustment
Acceleration/deceleration width	862216 862217	MMC_EM340GF::ExAutomaticCam.RotaryCutter.AccelerationWidth
Number of cutter	862218	MMC_EM340GF::ExAutomaticCam.RotaryCutter.CutterNum
Asynchronous speed result	862219	MMC_EM340GF::ExAutomaticCam.RotaryCutter.AsyncSpeedResult

*2 The item details when "3: Easy stroke ratio cam" is selected in "[Cd.610] Cam auto-generation type" are shown below.

• Easy stroke ratio cam data for auto-generation

Details	Buffer memory address	Label	
Resolution	862204 862205	MMC_EM340GF::ExAutomaticCam.SimpleStroke.Resolution	
Cam axis length per cycle	862206 862207	MMC_EM340GF::ExAutomaticCam.SimpleStroke.CamAxisLengthPerCycle	
Cam data starting point	862208 862209	MMC_EM340GF::ExAutomaticCam.SimpleStroke.StartingPoint	
Number of sections	862210	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SectionNum	
Section 1	Cam curve type	862212	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SimpleSection[0].CurveType
	End point	862214 862215	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SimpleSection[0].EndPoint
	Stroke	862216 862217	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SimpleSection[0].Stroke
⋮	⋮	⋮	
Section 32	Cam curve type	862398	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SimpleSection[31].CurveType
	End point	862400 862401	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SimpleSection[31].EndPoint
	Stroke	862402 862403	MMC_EM340GF::ExAutomaticCam.SimpleStroke.SimpleSection[31].Stroke

*3 The item details when "4: Advanced stroke ratio cam" is selected in "[Cd.610] Cam auto-generation type" are shown below.

• Advanced stroke ratio cam data for auto-generation

Details	Buffer memory address	Label
Resolution	862204 862205	MMC_EM340GF::ExAutomaticCam.DetailsStroke.Resolution
Cam axis length per cycle	862206 862207	MMC_EM340GF::ExAutomaticCam.DetailsStroke.CamAxisLengthPerCycle
Cam stroke amount	862208 862209	MMC_EM340GF::ExAutomaticCam.DetailsStroke.CamStrokeAmount
Unit setting	862210	MMC_EM340GF::ExAutomaticCam.DetailsStroke.Unit
Cam data starting point	862212 862213	MMC_EM340GF::ExAutomaticCam.DetailsStroke.StartingPoint
Number of sections	862214	MMC_EM340GF::ExAutomaticCam.DetailsStroke.SectionNum

Details		Buffer memory address	Label
Section 1	Cam curve type	862216	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].CurveType
	End point	862218 862219	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].EndPoint
	Stroke	862220 862221	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].Stroke
	Curve applicable range (P1)	862222	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].CurveScopeP1
	Curve applicable range (P2)	862223	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].CurveScopeP2
	Acceleration/ deceleration range compensation (Range L1)	862224	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].AccelerationRangeCompensationL1
	Acceleration/ deceleration range compensation (Range L2)	862225	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[0].AccelerationRangeCompensationL2
⋮	⋮	⋮	⋮
Section 360	Cam curve type	865806	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].CurveType
	End point	865808 865809	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].EndPoint
	Stroke	865810 865811	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].Stroke
	Curve applicable range (P1)	865812	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].CurveScopeP1
	Curve applicable range (P2)	865813	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].CurveScopeP2
	Acceleration/ deceleration range compensation (Range L1)	865814	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].AccelerationRangeCompensationL1
	Acceleration/ deceleration range compensation (Range L2)	865815	MMC_EM340GF::ExAutomaticCam.DetailsStroke.DetailsSection[359].AccelerationRangeCompensationL2

■ Cam operation control data: Cam position calculation


Item		Buffer memory address	Label
[Cd.612]	Cam position calculation request	53780	MMC_Controller::CamCalculation.Ctrl.Request
[Cd.613]	Cam position calculation: Cam No.	53781	MMC_Controller::CamCalculation.Ctrl.CamNo
[Cd.614]	Cam position calculation: Stroke amount	53782 53783	MMC_Controller::CamCalculation.Ctrl.Stroke
[Cd.615]	Cam position calculation: Cam axis length per cycle	53784 53785	MMC_Controller::CamCalculation.Ctrl.LengthPerCycle
[Cd.616]	Cam position calculation: Cam reference position	53786 53787	MMC_Controller::CamCalculation.Ctrl.ReferencePosition
[Cd.617]	Cam position calculation: Cam axis current value per cycle	53788 53789	MMC_Controller::CamCalculation.Ctrl.CommandPositionPerCycle
[Cd.618]	Cam position calculation: Cam axis feed current value	53790 53791	MMC_Controller::CamCalculation.Ctrl.CommandPosition




Appendix 2 Sample Program of Synchronous Control

The following shows a sample program of executing synchronous control on the axis 1 with the axis 4 as an input axis. (The axis 4 is configured as the virtual servo amplifier.)


1. Select the Navigation window ⇒ "System Setting" ⇒ "CC IE Field Configuration", then set MR-J4-GF on the axis 1 and the axis 4.




2. Select the Navigation window ⇒ "Parameter", then set "1: Use as Virtual Servo Amplifier" on the axis 4 in "Pr.101: Virtual servo amplifier setting".




3. Select the Navigation window ⇒ "Synchronous Control Parameter" ⇒ "Input Axis Parameter", then set "1: Feed Current Value" on the axis 4 in "Pr.300: Servo input axis type".



4. Select the Navigation window ⇒ "Cam Data" and right-click ⇒ [Add New Data], then create the cam data (cam No.1).



5. Select the Navigation window ⇒ "Synchronous Control Parameter" ⇒ "Synchronous Parameter" ⇒ "Axis #1 Synchronous Parameter", then set the synchronous parameter of the axis 1.



6. Create the user program to start synchronous control.

Refer to the following manual and create the user program before the servo ON separately.

Simple Motion Board User's Manual (Startup)

Classification	Method name	Description
Method	MMC_Axis::StartSync	Starts the synchronous control.
	MMC_Axis::StartJog	Starts the JOG operation.
	MMC_Axis::StopJog	Stops the JOG operation.
	MMC_Axis::WaitPositioningDone	Waits until the positioning control is completed.
	MMC_Axis::StopSync	Completes the synchronous control.

Program example

C++

```
void SynchronizationSample( MMC_Controller *controller, MMC_Axis *axis1, MMC_Axis *axis4 )
{
    unsigned long retCode;

    /* start synchronous control */
    retCode = axis1->StartSync();
    if( retCode != MMC_OK ) { /* Error process */ }

    /* start JOG operation of the virtual axis */
    retCode = axis4->StartJog( 20000 );
    if( retCode != MMC_OK ) { /* Error process */ }

    /* arbitrary process */

    /* stop JOG operation of the virtual axis */
    retCode = axis4->StopJog();
    if( retCode != MMC_OK ) { /* Error process */ }

    /* wait until the positioning control of the virtual axis is completed */
    retCode = axis4->WaitPositioningDone( MMC_POSITIONING_DONE_BUSY, 10000 );
    if( retCode != MMC_OK ) { /* Error process */ }

    /* complete synchronous control */
    retCode = axis1->StopSync();
    if( retCode != MMC_OK ) { /* Error process */ }
}
```

MEMO

A

INDEX

A

Auxiliary shaft axis No.	86,87
Auxiliary shaft clutch command	93
Auxiliary shaft clutch control invalid command	93
Auxiliary shaft clutch control setting	88,89
Auxiliary shaft clutch forced OFF command	93
Auxiliary shaft clutch OFF address	88,91
Auxiliary shaft clutch ON address	88,90
Auxiliary shaft clutch ON/OFF status	120,122
Auxiliary shaft clutch reference address setting	88,90
Auxiliary shaft clutch slippage (accumulative)	120,122
Auxiliary shaft clutch smoothing method	88,92
Auxiliary shaft clutch smoothing status	120,122
Auxiliary shaft clutch smoothing time constant	89,92
Auxiliary shaft gear	
Denominator	86,87
Numerator	86,87

C

Cam auto-generation cam No.	67
Cam auto-generation data	67,68
Cam auto-generation request	67
Cam auto-generation type	67
Cam axis current value per cycle	119,121
Cam axis current value per cycle (Initial setting)	129,131
Cam axis cycle unit setting	111,112
Cam axis feed current value	119,121
Cam axis length per cycle	111,112
Cam axis length per cycle change setting	111,113
Cam axis phase compensation advance time	111,113
Cam axis phase compensation amount	119,121
Cam axis phase compensation time constant	111,114
Cam axis position restoration object	129,130
Cam data first position	63,64
Cam data format	63,65
Cam data operation request	63,64
Cam data starting point	63,65
Cam data value	63,66
Cam No.	111,113
Cam position calculation	
Cam axis current value per cycle	143,144
Cam axis feed current value	144
Cam axis length per cycle	143,144
Cam No.	143,144
Cam reference position	143,144
Stroke amount	143,144
Cam position calculation request	143,144
Cam position calculation result	145
Cam reference position	119,121
Cam reference position (Initial setting)	129,131
Cam resolution/coordinate number	63,65
Cam stroke amount	111,113
Composite auxiliary shaft gear	86,87
Composite main shaft gear	78,79

Connection command of synchronous encoder via buffer memory	47,49
Current value after composite main shaft gear	119,120
Current value per cycle after auxiliary shaft gear	119,121
Current value per cycle after auxiliary shaft gear (Initial setting)	129,131
Current value per cycle after main shaft gear	119,121
Current value per cycle after main shaft gear (Initial setting)	129,131

E

Execute cam axis length per cycle	119,121
Execute cam No.	119,121
Execute cam stroke amount	119,121

I

Input value for synchronous encoder via buffer memory	47,49
---	-------

M

Main input axis No.	78
Main shaft clutch command	85
Main shaft clutch control invalid command	85
Main shaft clutch control setting	80,81
Main shaft clutch forced OFF command	85
Main shaft clutch OFF address	80,83
Main shaft clutch ON address	80,82
Main shaft clutch ON/OFF status	120,122
Main shaft clutch reference address setting	80,82
Main shaft clutch slippage (accumulative)	120,122
Main shaft clutch smoothing method	80,84
Main shaft clutch smoothing status	120,122
Main shaft clutch smoothing time constant	81,84
Main shaft gear	
Denominator	78,79
Numerator	78,79
Movement amount before auxiliary shaft clutch OFF	88,91
Movement amount before auxiliary shaft clutch ON	88,91
Movement amount before main shaft clutch OFF	80,83
Movement amount before main shaft clutch ON	80,83

N

Number of cam data operation points	63,64
---	-------

O

Operation cam No.	63,64
Output axis smoothing time constant	111,114

R

Resolution of synchronous encoder via buffer memory	39,43
---	-------

S

Servo input axis current value	29
Servo input axis phase compensation advance time	26,27
Servo input axis phase compensation amount	29
Servo input axis phase compensation time constant	26,27
Servo input axis rotation direction restriction	26,28
Servo input axis rotation direction restriction amount	29,30
Servo input axis smoothing time constant	26,27
Servo input axis speed	29
Servo input axis type	26
Setting method of cam axis current value per cycle	129,130
Setting method of cam reference position	129,130
Setting method of current value per cycle after auxiliary shaft gear	129,130
Setting method of current value per cycle after main shaft gear	129,130
Slippage amount at auxiliary shaft clutch OFF	89,92
Slippage amount at auxiliary shaft clutch ON	89,92
Slippage amount at main shaft clutch OFF	81,84
Slippage amount at main shaft clutch ON	81,84
Speed change gear	108
Speed change gear smoothing time constant	108
Speed change ratio	
Denominator	108
Numerator	108
Sub input axis No.	78
Synchronous control change command	115,116
Synchronous control change request	115
Synchronous control change value	115,117
Synchronous control deceleration time	111,114
Synchronous control reflection time	115,118
Synchronous encoder axis	
Link device count direction setting	44,45
Link device start No.	44,45
Link device type	44,45
Ring counter maximum value	44,45
Ring counter minimum value	44,45
Synchronous encoder axis control method	47,49
Synchronous encoder axis control start	47,48
Synchronous encoder axis current value	50
Synchronous encoder axis current value per cycle	50
Synchronous encoder axis current value setting address	47,49
Synchronous encoder axis error No.	50,52
Synchronous encoder axis error reset	47,49
Synchronous encoder axis length per cycle	39,40
Synchronous encoder axis phase compensation advance time	39,42
Synchronous encoder axis phase compensation amount	50,51
Synchronous encoder axis phase compensation time constant	39,42

Synchronous encoder axis rotation direction restriction	39,43
Synchronous encoder axis rotation direction restriction amount	50,51
Synchronous encoder axis smoothing time constant	39,41
Synchronous encoder axis speed	50,51
Synchronous encoder axis start request	
Link device bit specification	44,46
Link device logic setting	44,46
Link device start No.	44,46
Link device type	44,46
Synchronous encoder axis status	50,51
Synchronous encoder axis type	39,40
Synchronous encoder axis unit conversion	
Denominator	39,40
Numerator	39,40
Synchronous encoder axis unit setting	39,40
Synchronous encoder axis warning No.	50,52

REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Description
August 2016	IB(NA)-0300326-A	First edition
June 2017	IB(NA)-0300326-B	■ Added or modified parts SAFETY PRECAUTIONS, TERMS, Section 2.1, 3.1, 4.3, 4.5, 4.8
January 2024	IB(NA)-0300326-C	■ Added or modified parts INFORMATION AND SERVICES, TRADEMARKS

Japanese manual number: IB-0300325-C

This manual confers no industrial property rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

©2016 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

INFORMATION AND SERVICES

For further information and services, please contact your local Mitsubishi Electric sales office or representative.
Visit our website to find our locations worldwide.

MITSUBISHI ELECTRIC Factory Automation Global Website

Locations Worldwide

www.MitsubishiElectric.com/fa/about-us/overseas/

TRADEMARKS

Ethernet is a registered trademark of Fuji Xerox Co., Ltd. in Japan.

Intel Core is either a trademark or a registered trademark of Intel Corporation and its subsidiaries in the United States and/or other countries.

Microsoft, Windows, Visual C++, and Visual Studio are trademarks of the Microsoft group of companies.

PCI Express is either a registered trademark or a trademark of PCI-SIG.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.

IB(NA)-0300326-C(2401)MEE

MODEL: EM340-U-ADV-E

MODEL CODE: 1XB050

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.