# MITSUBISHI Mitsubishi Industrial Robot

# **RV-6SD/6SDL Series**

INSTRUCTION MANUAL ROBOT ARM SETUP & MAINTENANCE




## ▲ Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

| ▲ CAUTION | All teaching work must be carried out by an operator who has received special training. (This also applies to maintenance work with the power source turned ON.)<br>Enforcement of safety training  |
|-----------|---|
| ▲ CAUTION | For teaching work, prepare a work plan related to the methods and procedures<br>of operating the robot, and to the measures to be taken when an error occurs<br>or when restarting. Carry out work following this plan. (This also applies to<br>maintenance work with the power source turned ON.)<br>Preparation of work plan |
| ⚠ WARNING | Prepare a device that allows operation to be stopped immediately during<br>teaching work. (This also applies to maintenance work with the power source<br>turned ON.)<br>Setting of emergency stop switch   |
| ▲ CAUTION | During teaching work, place a sign indicating that teaching work is in progress<br>on the start switch, etc. (This also applies to maintenance work with the power<br>source turned ON.)<br>Indication of teaching work in progress   |
| A WARNING | Provide a fence or enclosure during operation to prevent contact of the operator and robot.<br>Installation of safety fence   |
|           | Establish a set signaling method to the related operators for starting work, and follow this method.<br>Signaling of operation start  |
| ▲ CAUTION | As a principle turn the power OFF during maintenance work. Place a sign indicating that maintenance work is in progress on the start switch, etc. Indication of maintenance work in progress  |
| ▲ CAUTION | Before starting work, inspect the robot, emergency stop switch and other related devices, etc., and confirm that there are no errors.<br>Inspection before starting work  |

The points of the precautions given in the separate "Safety Manual" are given below. Refer to the actual "Safety Manual" for details.

| A CAUTION   | Use the robot within the environment given in the specifications. Failure to do so could lead to a drop or reliability or faults. (Temperature, humidity, atmosphere, noise environment, etc.)   |  |
|---|--|--|
| ▲ CAUTION   | Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.  |  |
| ▲ CAUTION   | Always use the robot installed on a secure table. Use in an instable posture could lead to positional deviation and vibration.   |  |
|   | Wire the cable as far away from noise sources as possible. If placed near a noise source, positional deviation or malfunction could occur.   |  |
| ▲ CAUTION   | Do not apply excessive force on the connector or excessively bend the cable.<br>Failure to observe this could lead to contact defects or wire breakage.  |  |
| ▲ CAUTION   | Make sure that the workpiece weight, including the hand, does not exceed the rated load or tolerable torque. Exceeding these values could lead to alarms or faults.  |  |
| <b>WARNING</b> Securely install the hand and tool, and securely grasp the workpiece observe this could lead to personal injuries or damage if the object of flies off during operation. |  |  |
| <b>⚠</b> WARNING  | Securely ground the robot and controller. Failure to observe this could lead to malfunctioning by noise or to electric shock accidents.  |  |
| ▲ CAUTION   | Indicate the operation state during robot operation. Failure to indicate the state could lead to operators approaching the robot or to incorrect operation.  |  |
| <u>∕</u> MWARNING   | When carrying out teaching work in the robot's movement range, always secure<br>the priority right for the robot control. Failure to observe this could lead to<br>personal injuries or damage if the robot is started with external commands. |  |
|   | Keep the jog speed as low as possible, and always watch the robot. Failure to do so could lead to interference with the workpiece or peripheral devices.   |  |
| A CAUTION   | After editing the program, always confirm the operation with step operation<br>before starting automatic operation. Failure to do so could lead to interference<br>with peripheral devices because of programming mistakes, etc.               |  |
| ⚠ CAUTION   | Make sure that if the safety fence entrance door is opened during automatic operation, the door is locked or that the robot will automatically stop. Failure to do so could lead to personal injuries.   |  |
|   | Never carry out modifications based on personal judgments, or use non-<br>designated maintenance parts.<br>Failure to observe this could lead to faults or failures.   |  |
| ⚠ WARNING   | When the robot arm has to be moved by hand from an external area, do not place hands or fingers in the openings. Failure to observe this could lead to hands or fingers catching depending on the posture.                                     |  |



#### **Revision history**

| Date of Point | Instruction Manual No. | Revision Details   |  |
|---------------|------------------------|--|--|
| 2008-09-02    | BFP-A8655              | First print  |  |
| 2008-11-10    | BFP-A8655-A            | $\cdot$ CE Marking specification was added. (Solenoid value of source type I/O)  |  |
| 2009–04–24    | BFP-A8655-B            | <ul> <li>Added that the origin data to input is written in the robot examination report sheet.</li> <li>When the minus driver was used, added that it is easier to remove the cover.</li> <li>The solenoid valve installation procedure changed into piping the pneumatic hose after wiring.</li> <li>Added that It is better to install option simultaneously. (Because the same cover)</li> <li>The error in writing of hand output cable installation was corrected.</li> </ul> |  |
| 2009-06-11    | BFP-A8655-C            | <ul> <li>The caution at pulling out spare wiring was added.</li> <li>Expression was corrected.<br/>(Origin data sheet), (Installing the option devices)</li> </ul>   |  |
| 2009-09-25    | BFP-A8655-D            | •The error in writing of "(5) Inputting the origin data" in "2.4.2 Setting the origin with the origin data input method" was corrected.  |  |
| 2009-09-29    | BFP-A8655-E            | <ul> <li>The error in writing of "(4) Selecting the origin setting method" in "2.4.2 Setting the<br/>origin with the origin data input method" was corrected.</li> </ul>   |  |
| 2009-10-29    | BFP-A8655-F            | The EC Declaration of Conformity was changed.     (Correspond to the EMC directive; 2006/42/EC)  |  |
| 2010-07-05    | BFP-A8655-G            | The type name of the controller was changed. (CR2D to CR2DA)   |  |
| 2010-07-28    | BFP-A8655-H            | Replacement procedure of packing was added and cover packing was added to the consumable part.   |  |
| 2010-08-12    | BFP-A8655-J            | The consumable part (packing) list was added.  |  |
| 2011-02-02    | BFP-A8655-K            | <ul> <li>The note of installing the hand input cable was added.</li> <li>Part code was added to the consumable part (packing).</li> </ul>  |  |
| 2011-05-19    | BFP-A8655-L            | The caution at installing and removing of the machine cable was added.   |  |
|               |                        |  |  |

## CONTENTS

|  | Page |
|--|------|
| 1 Before starting use  | 1–1  |
| 1.1 Using the instruction manuals  | 1–1  |
| 1.1.1 The details of each instruction manuals                                    | 1–1  |
| 1.1.2 Symbols used in instruction manual   | 1–2  |
| 1.2 Safety Precautions   | 1–3  |
| 1.2.1 Precautions given in the separate Safety Manual                            |      |
| 2 Unpacking to Installation  |      |
| 2.1 Confirming the product   |      |
| 2.2 Installation   |      |
| 2.2.1 Unpacking  |      |
| 2.2.2 Transportation procedures (Transporting with a crane)                      |      |
| 2.2.3 Installation procedures  |      |
| 2.2.4 Grounding procedures   |      |
| (1) Grounding methods  |      |
| (2) Grounding procedures   |      |
| 2.2.5 Connecting with the controller   |      |
| 2.3 Spare wiring   |      |
| 2.3.1 Fore arm area  |      |
| 2.3.2 Base area  |      |
| 2.3.3 Connection of piping for air pressurization                                |      |
| 2.3.4 Connection of piping for suction   |      |
| 2.4 Setting the origin   |      |
| 2.4.1 Installing the teaching pendant (T/B)                                      |      |
| 2.4.2 Setting the origin with the origin data input method                       |      |
| (1) Confirming the origin data   |      |
| <ul><li>(2) Turning ON the control power</li><li>(3) Preparing the T/B</li></ul> |      |
| (4) Selecting the origin setting method  |      |
| (5) Inputting the origin data  |      |
| (6) Installing the shoulder cover B.   |      |
| 2.5 Confirming the operation   |      |
| (1) JOINT jog operation  |      |
| (2) XYZ jog operation  |      |
| (3) TOOL jog operation   |      |
| (4) 3-axis XYZ jog operation   |      |
| (5) CYLNDER jog operation  |      |
| (6) Work jog operation   | 2-38 |
| 3 Installing the option devices  |      |
| 3.1 Installing the solenoid valve set (1S-VD0*-02(E))                            |      |
| 3.2 Installing the hand input cable  |      |
| 3.3 Installing the hand output cable   |      |
| 3.4 Changing the operating range   |      |
| 3.4.1 J1 axis  |      |
| 4 Basic operations   |      |
|  |      |
| 5 Maintenance and Inspection   |      |
| 5.1 Maintenance and inspection interval  | 5–52 |
| 5.2 Inspection items   | 5–53 |
| 5.2.1 Daily inspection items   |      |
| 5.2.2 Periodic inspection  |      |
| 5.3 Maintenance and inspection procedures  |      |
| 5.3.1 Robot arm structure  |      |
| 5.3.2 Installing/removing the cover  |      |

## CONTENTS

|  | Page        |
|--|-------------|
| 5.3.3 Packing Replacement Procedure                                |             |
| (1) Packing Replacement Instructions                               | 5–59        |
| 5.3.4 Inspection, maintenance and replacement of timing belt       |             |
| (1) Timing belt replacement period                                 |             |
| (2) Inspection, maintenance and replacement of J5-axis timing belt |             |
| (3) Timing belt tension  | 5–65        |
| 5.3.5 Lubrication  | 5–66        |
| (1) Lubrication position and specifications                        | 5–66        |
| (2) Lubrication method   |             |
| 5.3.6 Stopper exchange   |             |
| 5.3.7 Replacing the backup battery                                 |             |
| (1) Replacing the robot arm battery                                | 5–70        |
| 5.4 About Overhaul   |             |
| 5.5 Maintenance parts  | 5–72        |
| 5.6 Resetting the origin   | 5–75        |
| 5.6.1 Jig method   | 5–76        |
| (1) J1 axis origin setting   |             |
| (2) J2 axis origin setting   |             |
| (3) J3 axis origin setting   |             |
| (4) J4 axis origin setting   |             |
| (5) J5 axis origin setting   | 5–85        |
| (6) J6 axis origin setting   |             |
| 5.6.2 ABS origin method  |             |
| (1) Select the T/B   |             |
| 5.6.3 User origin method   |             |
| 5.6.4 Recording the origin data                                    |             |
| (1) Confirming the origin data label                               |             |
| (2) Confirming the origin data                                     |             |
| (3) Recording the origin data                                      | 5–93        |
| (4) Installing the cover   | 5–93        |
| SAppendix  | Appendix-94 |
| Appendix 1 : Configuration flag                                    | Appendix-94 |

#### 1 Before starting use

This chapter explains the details and usage methods of the instruction manuals, the basic terminology and the safety precautions.

#### 1.1 Using the instruction manuals

#### 1.1.1 The details of each instruction manuals

The contents and purposes of the documents enclosed with this product are shown below. Use these documents according to the application.

For special specifications, a separate instruction manual describing the special section may be enclosed.

| Safety Manual   | Explains the common precautions and safety measures to be taken for robot handling, sys <sup>-</sup><br>tem design and manufacture to ensure safety of the operators involved with the robot.   |
|---|---|
| Standard<br>Specifications<br>or<br>special<br>Specifications | Explains the product's standard specifications, factory-set special specifications, option configuration and maintenance parts, etc. Precautions for safety and technology, when incorporating the robot, are also explained.                                   |
| Robot Arm<br>Setup &<br>Maintenance                           | Explains the procedures required to operate the robot arm (unpacking, transportation, installation, confirmation of operation), and the maintenance and inspection procedures.  |
| Controller<br>Setup, Basic<br>Operation and<br>Maintenance    | Explains the procedures required to operate the controller (unpacking, transportation, installation, confirmation of operation), basic operation from creating the program to auto <sup>-</sup> matic operation, and the maintenance and inspection procedures. |
| Detailed<br>Explanation of<br>Functions and<br>Operations     | Explains details on the functions and operations such as each function and operation, com <sup>-</sup><br>mands used in the program, connection with the external input/output device, and parame <sup>-</sup><br>ters, etc.                                    |
| Troubleshooting   | Explains the causes and remedies to be taken when an error occurs. Explanations are given for each error No.  |
| Additional axis<br>function                                   | Explains the specifications, functions and operations of the additional axis control.   |
| Tracking Func⁻<br>tion Manual                                 | Explains the control function and specifications of conveyor tracking.  |

#### 1.1.2 Symbols used in instruction manual

The symbols and expressions shown in Table 1-1 are used throughout this instruction manual. Learn the meaning of these symbols before reading this instruction manual.

| Terminology | Item/Symbol                                | Meaning   |
|-------------|--|---|
| Item        | The "Robot controller" or the "Controller" | Indicates the controller which controls the robot arm.<br>Indicates the box which arranged control parts, such as robot CPU, servo<br>amplifier, and the safety circuit.                      |
| Symbol      | \land DANGER                               | Precaution indicating cases where there is a risk of operator fatality or<br>serious injury if handling is mistaken. Always observe these precautions to<br>safely use the robot.             |
|             |  | Precaution indicating cases where the operator could be subject to fatalities<br>or serious injuries if handling is mistaken. Always observe these precautions to<br>safely use the robot.    |
|             |  | Precaution indicating cases where operator could be subject to injury or<br>physical damage could occur if handling is mistaken. Always observe these<br>precautions to safely use the robot. |
|             | [JOG]                                      | If a word is enclosed in brackets or a box in the text, this refers to a key on the teaching pendant.   |
|             | [RESET] + [EXE]<br>(A) (B)                 | This indicates to press the (B) key while holding down the (A) key.<br>In this example, the [RESET] key is pressed while holding down the [+EXE]<br>key.                                      |
|             | T/B  | This indicates the teaching pendant.  |
|             | 0/P  | This indicates the operating panel on the front of the controller.  |

Table 1-1 : Symbols in instruction manual

#### 1.2 Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

|                 | All teaching work must be carried out by an operator who has received special training.<br>(This also applies to maintenance work with the power source turned ON.)<br>Enforcement of safety training   |
|-----------------|---|
| ▲CAUTION        | For teaching work, prepare a work plan related to the methods and procedures of<br>operating the robot, and to the measures to be taken when an error occurs or when<br>restarting. Carry out work following this plan. (This also applies to maintenance work<br>with the power source turned ON.)<br>Preparation of work plan |
| <b>企WARNING</b> | Prepare a device that allows operation to be stopped immediately during teaching work.<br>(This also applies to maintenance work with the power source turned ON.)<br>Setting of emergency stop switch  |
|                 | During teaching work, place a sign indicating that teaching work is in progress on the start switch, etc. (This also applies to maintenance work with the power source turned ON.)<br>Indication of teaching work in progress   |
| ▲ DANGER        | Provide a fence or enclosure during operation to prevent contact of the operator and robot.<br>Installation of safety fence   |
|                 | Establish a set signaling method to the related operators for starting work, and follow this method.<br>Signaling of operation start  |
|                 | As a principle turn the power OFF during maintenance work. Place a sign indicating that maintenance work is in progress on the start switch, etc.<br>Indication of maintenance work in progress   |
| ▲CAUTION        | Before starting work, inspect the robot, emergency stop switch and other related devices, etc., and confirm that there are no errors.<br>Inspection before starting work  |

1.2.1 Precautions given in the separate Safety Manual The points of the precautions given in the separate "Safety Manual" are given below. Refer to the actual "Safety Manual" for details.

| <b>▲DANGER</b>       | If the automatic operation of the robot is operated by two or more control equipment, design the right management of operation of each equipment of the customer.  |  |  |
|----------------------|--|--|--|
|                      | Use the robot within the environment given in the specifications. Failure to do so could lead to a drop or reliability or faults. (Temperature, humidity, atmosphere, noise environment, etc.)   |  |  |
|                      | Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.  |  |  |
|                      | Always use the robot installed on a secure table. Use in an instable posture could lear to positional deviation and vibration.   |  |  |
|                      | Wire the cable as far away from noise sources as possible. If placed near a noise source, positional deviation or malfunction could occur.   |  |  |
|                      | Do not apply excessive force on the connector or excessively bend the cable. Failure to observe this could lead to contact defects or wire breakage.   |  |  |
|                      | Make sure that the workpiece weight, including the hand, does not exceed the rated load or tolerable torque. Exceeding these values could lead to alarms or faults.  |  |  |
| <sup>▲</sup> WARNING | Securely install the hand and tool, and securely grasp the workpiece. Failure to observe this could lead to personal injuries or damage if the object comes off or flies off during operation.   |  |  |
|                      | Securely ground the robot and controller. Failure to observe this could lead to malfunctioning by noise or to electric shock accidents.  |  |  |
|                      | Indicate the operation state during robot operation. Failure to indicate the state could lead to operators approaching the robot or to incorrect operation.  |  |  |
| <sup>▲</sup> WARNING | When carrying out teaching work in the robot's movement range, always secure the priority right for the robot control. Failure to observe this could lead to personal injuries or damage if the robot is started with external commands.   |  |  |
|                      | Keep the jog speed as low as possible, and always watch the robot. Failure to do so could lead to interference with the workpiece or peripheral devices.   |  |  |
| ▲ CAUTION            | After editing the program, always confirm the operation with step operation before<br>starting automatic operation. Failure to do so could lead to interference with<br>peripheral devices because of programming mistakes, etc.<br>Make sure that if the safety fence entrance door is opened during automatic<br>operation, the door is locked or that the robot will automatically stop. Failure to do so<br>could lead to personal injuries. |  |  |
|                      | Never carry out modifications based on personal judgments, or use non-designated<br>maintenance parts.<br>Failure to observe this could lead to faults or failures.  |  |  |
| A WARNING            | When the robot arm has to be moved by hand from an external area, do not place<br>hands or fingers in the openings. Failure to observe this could lead to hands or fingers<br>catching depending on the posture.   |  |  |

# ▲ CAUTION Do not stop the robot or apply emergency stop by turning the robot controller's main power OFF. If the robot controller main power is turned OFF during automatic operation, the robot accuracy could be adversely affected. ▲ CAUTION Do not turn off the main power to the robot controller while rewriting the internal information of the robot controller such as the program or parameters. If the main power to the robot controller is turned off while in automatic operation or rewriting the program or parameters , the internal information of the robot controller may be damaged. ▲ DANGER When the SSCNETIII cable is removed, install the cap in the connector. If the cap is not installed, there is a possibility of malfunctioning by adhesion of the dust etc.

Don't remove the SSCNETIII cable, when the power supply of the robot controller is turned on. Don't face squarely the light emitted from the tip of the SSCNETIII connector or the cable. If light strikes the eyes, there is a possibility of feeling the sense of incongruity for the eyes. (The light source of SSCNETIII is equivalent to the class 1 specified to JISC6802 and IEC60825-1.)

#### 2 Unpacking to Installation

#### 2.1 Confirming the product

The standard configuration of the robot arm, part of the purchased product, is shown in Table 2–1. Confirm the parts.

Users who have purchased optional products should refer to the separate "Standard Specifications".

| No. | Part name  | Туре               | Qty.   | Remarks  |
|-----|--|--------------------|--------|--|
| 1   | Robot arm  | RV-6SD/6SDL series | 1 unit |  |
| 2   | Guarantee card   |                    | 1 сору |  |
| 3   | Installation bolts   | M8x40              | 4 pcs. |  |
| 4   | Spring washer for installation bolts                                   | For M8             | 4 pcs. |  |
| 5   | Plain washer for installation bolts                                    | For M8             | 4 pcs. |  |
| 6   | Suspension fitting   |                    | 2 pcs. | This is installed in the robot arm at<br>the time of shipment. |
| 7   | Suspension fitting installation bolt                                   | M10x25             | 1 set  |  |
| 8   | Spring washer for suspension fitting installation bolt                 | For M10            | 4 pcs. |  |
| 9   | Plain washer for suspension fitting instal <sup>-</sup><br>lation bolt | For M10            | 4 pcs. |  |
| 10  | Eye bolt   | M10                | 4 pcs. |  |
| 11  | Nut for eye bolt   | For M10            | 4 pcs. |  |
| 12  | Fixing plates  |                    | 1 pcs. |  |
| 13  | Fixing plate installation bolt   | M5x12              | 1 set  |  |
| 14  | Plain washer for fixing plate  | For M5             | 4 pcs. |  |

### 2.2 Installation

2.2.1 Unpacking





Fig.2-1 : Unpacking the robot arm

The robot is shipped from the factory in cardboard and plywood frame packing. Always refer to Fig. 2–1 and unpack the robot.Handle the robot arm according to "2.2.2Transportation procedures (Transporting with a crane)". The unpacking process is shown below.

- 1) Using a knife, etc., slit the tape  $\langle 1 \rangle$  fixing the upper lid  $\langle 2 \rangle$  of the cardboard box. (Fig. 2-1 (a))
- 2) Pull the upper lid  $\langle 2 \rangle$  of the cardboard box off with both hands. (Fig. 2-1 (b))
- Remove the hexagon socket bolts <3> (four positions) connecting the sleeper and the base unit. (Fig. 2-1 (c))
- 4) This completes the unpacking.






Fig.2-2 : Transportation procedures (transporting with a crane)


- Attach the suspension fittings to the left and right sides of the shoulder section, and securely fix with bolts (four M10 x 25, four spring washers for M10). At this time, fix two of the suspension fitting's three holes at the side closest to the robot front. Install the fixing plate to the flange face. (M5x12: Four)
- 2) Catch wires in the eye bolts installed on the suspension fittings, and quietly suspend the arm.
- 3) At this time, make sure that the wires, etc., do not interfere with the robot arm or covers. Always place cloth, etc., at interfering places.
- 4) When transferring to the installation place, take care not to apply vibration or impact.
- 5) After installing at the installation place, remove the above suspension fittings.
- 6) Always follow the above procedures and methods to transport the robot for secondary transportation, such as when changing the installation position.

If the arm is directly suspended without using the specified suspension fittings, or if it is suspended in the work posture, the configuration devices could be damaged, and the transportation workers will be subject to risk due to an inadequate center of gravity position.

#### 2.2.3 Installation procedures

The installation procedure of the robot arm is shown below.

- 1) The robot installation surface has been machine finished. Use the installation holes  $(4-\phi 9$  holes) opened at the four corners of the base, and securely fix the robot with the enclosed installation bolts (M8x40 hexagon socket bolts).
- 2) Installation of the robot arm is a very important step for ensuring the optimum functions of the robot. Observe the following points when designing.Install the robot on a level surface.
- 3) It is recommended that the surface roughness of the table onto which the robot is to be installed by 6.3a or more. If the installation surface is rough, the contact with the table will be poor, and positional deviation could occur when the robot moves.



4) When installing, use a common table to prevent the position of the devices and jigs subject to robot work from deviating.

- 5) The installation surface must have sufficient strength to withstand the arm reaction during operation, and resistance against deformation and vibration caused by the static (dynamic) load of the robot arm and peripheral devices, etc.
- 6) Remove the fixing plates after installing the robot.
- 7) When the robot is installed by hanging from the ceiling or on the wall, the MEGDIR parameter must be changed. For more information about parameters and how to change the parameters, refer to the separate "Instruction Manual/ Detailed Explana-tion of Functions and Operations".
- 8) The installation surface must have sufficient strength to withstand the arm reaction during moving the robot at high speed.

Fig.2-3 : Installation dimensions

| Item                         |      | Unit | Value |
|------------------------------|------|------|-------|
| Falling moment : ML          |      | N m  | 892   |
| Twist moment : MT            |      | N m  | 892   |
| Horizontal translation power | : FH | N    | 800   |
| Vertical translation power   | : FV | N    | 1,400 |

CAUTION Please secure the maintenance space required for connection of the machine cable, and exchange of the backup battery in the rear.

Please secure the maintenance space required for connection of the machine cable, and exchange of the backup battery in the rear side, and also space for J1 axis belt in the right side.

#### 2.2.4 Grounding procedures

(1) Grounding methods




Fig.2-4 : Grounding methods

#### (2) Grounding procedures




Fig.2-5 : Connecting the grounding cable

- There are three grounding methods as shown in Fig. 2-4, but the dedicated grounding (Fig. 2-4 (a)) should be used for the robot arm and controller when possible. (Refer to the separate " Controller Setup, Basic Operation and Maintenance" for details on the controller grounding.)
- Use Class D grounding (grounding resistance 100 Ω or less).
   Dedicated grounding separated from the other devices should be used.
- 3) Use a AWG#11(3.5mm<sup>2</sup>) or more stranded wire for the grounding wire. The grounding point should be as close to the robot arm and controller as possi<sup>-</sup> ble, and the length of the grounding wire should be short.

1) Prepare the grounding cable (AWG#11(3.5mm<sup>2</sup>) or more) and robot side installation screw and washer.

2) If there is rust or paint on the grounding screw section (A), remove it with a file, etc.

3) Connect the grounding cable to the grounding screw section.

2.2.5 Connecting with the controller





Fig.2-6 : Connecting the machine cables

Carry out the following procedure after installing the controller referring to the separate "Controller Setup, Basic Operation and Maintenance" manual.



The procedure of connecting the machine cable is shown below. (Although the figure of the robot arm is the example of RV-12SD, it is the same)

- 1) Make sure that the power switch on the front of the controller is turned OFF.
- 2) Connect the machine cable to its corresponding connector on the robot arm side.
- After connecting the connector, insert the hook attached to the connector on the machine cable side to the rear of the projection of the robot arm connector to fix securely in place.

CAUTION Be careful not to get your hand pinched.

4) To remove the cable, insert a minus screwdriver into the hook while padding with a cloth, and remove the cable by lifting the hook.

## 

When installing or removing the connector, to the connector of the other party in parallel, install or remove. If load strong against one side is applied, the connector pin may be damaged and it may not be connected securely.



The machine cable connectors are dedicated for the controller side and robot arm side, so take special care when connecting.

If connected incorrectly, the connector pins could bend or break. Thus, even if connected correctly, the robot will not operate correctly, creating a dangerous situation.

Take special care to the leading of the connection cable. If the cable is pulled with force or bent excessively, wires could break or the connector could be damaged.

Connect the machine cable at the place without the effect of the dust or oil mist. Please keep the dust and oil mist from being applied to of the robot-arm connector section, in the condition that the machine cable is removed. Since it becomes the cause of failure.



Please be careful not to catch the hand at installation and removal.

#### 2.3 Spare wiring

The interior of the spare wiring  $(AWG#28(0.1 mm^2) x4 pair (a total of eight cores) cab tire cable)$  is carried out to the robot arm from the base portion to the forehand arm side piece.

In this case, the cable clamp (refer to the following) is needed separately for wiring leading about out of the robot. Please prepare of the customer in advance.

Table 2-3 : Incentive item of cable clamp

|   | Туре     | Diameter of fit electric wire | Installation hole(mm) | Maker                  |
|---|----------|-------------------------------|-----------------------|------------------------|
| ľ | OA-W1606 | φ4~6                          | φ21                   | OHM ELECTRIC CO., LTD. |

## 

Do this work after turning OFF the power supply of the robot controller.

#### 2.3.1 Fore arm area

1) Remove safety socket (4) (M 4 x 8:4 bolts) which has stopped No.2 arm-cover C (3) or electromagnetic valve (5), and remove No.2 arm-cover C (3) or electromagnetic valve (5).




Fig.2-7 : Drawer of spare wiring (Fore arm side)

- 2) Take out the spare wiring (ADD) stored in the A section. (The spare wiring by the side of the fore arm is separable by the connector)
- 3) Since spare wiring is bundled in the union band, it removes the union band.
- 4) The connector is attached to spare wiring to both ends. Cut spare wiring near the connector (from the connector end to the about 10-20mm Refer to <figure-A> in Fig. 2-8), and let spare wiring pass to the cable clamp (customer preparation).
- 5) Remove one either among the grommets of No.2 arm cover C(3) or solenoid valve (5). After removing the grommet, the seal material which remained in the hole area of the sheet metal removes.
- 6) Remove the lock nut of attachment in the cable clamp.
- 7) Let the ADD connector side of spare wiring pass in the hole area of the cover, and surely fix with the lock nut.





Fig.2-8 : Installation and connection of spare wiring

- 8) Connect "ADD" of the pulled-out spare wiring with the connector of "ADD" stored by the part A.
- 9) Install No.2 arm-cover C (3) or solenoid valve (5) as before. Be careful not to damage the seal material of the shape of the sponge pasting on "A section" If it damages, there is a possibility that protection specification may fall.
- 10) If the installation is completed, No.2 arm-cover B (2) will be installed as before. Be careful not to insert the cable




When pulling out spare wiring, keep big power from being added to the cable, the air hose.

Please check packing not being broken or not having stripped at the time of cover installing and removing. Please contact the dealer, if it is broken or has stripped. If you use it, packing broken or stripped, oil mist etc. will invade in the arm and will cause failure.

When No.2 arm-cover C (3) or solenoid valve (5) are installed, please keep too much load from being applied to the cables inside the robot, and the air hoses.

If too much load is added, the breaking of a wire and the air hose break, and the robot cannot operate normally.



## 


When No.2 arm-cover C (3) or solenoid valve (5) are installed, catch neither the cable nor the air hose. If the bolt is tightened while it had been caught, the breaking of a wire and the air hose break, and the robot cannot operate normally. Moreover, packing does not stick and protection specification cannot be secured.

#### 2.3.2 Base area

1) Remove installation bolt and remove CONBOX cover.



CONBOX cover is completely inseparable with the robot arm. When you install and remove the cover, be careful of the cable etc. If too much power is applied, the robot may malfunction by the breaking of the cable.





- 2) Move CONBOX cover and secure the access space to spare wiring. Be careful of the cables and air hoses which are connected into the robot arm.
- 3) Take out spare wiring(ADD). Spare wiring of this part is inseparable.
- 4) Remove the union band of spare wiring.
- 5) Cut spare wiring near the connector (from the connector end to the about 10-20mm. Refer to figure-A in Fig. 2-9)
- 6) Remove the grommet of CONBOX cover. Remove the seal material which remained in the hole area of the metal plate .
- 7) Remove the lock nut of attachment in the cable clamp (customer preparation).
- 8) Let spare wiring pass from the robot arm side of CONBOX cover in the hole after removing the grommet. Let the lock nut pass to spare wiring previously at this time.
- 9) The tip area of spare wiring pass to the cable clamp. And fix with the lock nut securely.
- 10) Install CONBOX cover(2) as before. Apply the screw lock to installation bolt (1), fix it with torque (4.1Nm to 4.9Nm). (Recommendation screw lock: Lock tightness 242 (Henkel Japan maker:, Inc.) Be careful not to damage the seal material of the shape of the sponge pasting on "A section" I f it damages, there is a possibility that protection specification may fall. Also be careful not to insert the cable




When pulling out spare wiring, keep big power from being added to the cable, the air hose.

Please check packing not being broken or not having stripped at the time of cover installing and removing. Please contact the dealer, if it is broken or has stripped. If you use it, packing broken or stripped, oil mist etc. will invade in the arm and will cause failure.

## 

When CONBOX cover (2) is installed, please keep too much load from being applied to the cables and the air hoses. If too much load is applied, the cable will be broken and the hose is bent, therefore robot and pneumatic drive equipment cannot operate normally.




## 

When No.2 arm-cover C (3) or solenoid value (5) are installed, catch neither the cable nor the air hose.

If the bolt is tightened while it had been caught, the cable will be broken and the hose is bent, and the robot and pneumatic drive equipment cannot operate normally. More<sup>-</sup> over, packing does not stick and protection specification cannot be secured.

Servo motor

\* Store the air hose to the space on the right side of the servo motor (seeing from robot back), and install the CONBOX cover.



CONBOX cover

\* Do not catch the wires and air hoses while installing the CONBOX cover.

Fig.2-10 : Installation of the CONBOX cover

#### 2.3.3 Connection of piping for air pressurization

In use in oil mist environment, protection performance can be improved by pressurizing the inside of the robot arm. Please connect the phi8 air hose to the joint for pressurization of the robot arm base portion "AIR PURGE", and pressurize the inside of the robot arm.

Refer to the section of "Protection specification and the environment" of the "Standard specifications" separate volume.




Fig.2-11 : Air purge

#### 2.3.4 Connection of piping for suction

In use of the robot of clean specification, please connect the phi8 air hose to the joint for suction of the robot body base portion "VACUUM", and suck the inside of the robot body.

Refer to the section of "Clean specification" of the "Standard specifications" separate volume.




Fig.2-12 : Vacuum

#### 2.4 Setting the origin

The origin is set so that the robot can be used with a high accuracy. After purchasing the robot, always carry out this step before starting work. This step must also be carried out if the combination of robot and controller being used is changed.

There are several methods for setting the origin, but the origin data input method will be explained here. Refer to Page 75, "5.6 Resetting the origin" for the other methods.

The teaching pendant is required for this operation.

[Caution] If the origin data at shipment is erased due to out of battery, it is necessary to set the origin again. Refer to Page 75, "5.6 Resetting the origin" and reset the origin using the jig method or ABS method.

#### 2.4.1 Installing the teaching pendant (T/B)

When installing and removing the T/B, turn off the controller power supply. If T/B is installed or removed in the state of power supply ON, emergency stop alarm will occur.

If you use the robot wherein T/B is removed, please install the attached dummy connector. With the connector, put the dummy connector or draw it out.



Please do not pull the cable of T/B strongly or do not bend it too much. It becomes the breaking of a wire of the cable and the cause of breakage of the connector. Please installing and removing so that stress does not start the cable with the connector itself.

Explain the installation method of T/B below.

- 1) Check that the POWER (power supply) switch of the robot controller is OFF.
- 2) Connects T/B connector to the robot controller. Use as the upper surface the lock lever shown in Fig. 2-13, and push in until there is sound.




Fig.2-13 : Installing and removing the T/B

The installation of T/B is finished.

#### $\diamond \blacklozenge \diamond$ If error C0150 occurs $\diamond \blacklozenge \diamond$

At the time of the first power supply injection, error:C0150 (the serial number of the robot arm has not been set up) occur the robot after purchase.

Parameter: Please input the serial number of the robot body into RBSERIAL. Refer to "instructions manual / controller setup, and basic operation & maintenance" for the operation method.

The origin data to be input is noted in the origin data sheet enclosed with the arm, or on the origin data history table attached to the back side of the shoulder

Referring to Page 57, "5.3.2 Installing/ removing the cover", remove the shoulder cover B and confirm the value.

The value given in the default setting

calibration jig before shipment.

column is the origin settings set with the

cover B. (Refer to Fig. 2-14).

#### 2.4.2 Setting the origin with the origin data input method (1) Confirming the origin data

| <ul> <li>Origin data history table (Origin Data History) Serial No.ES804008</li> </ul> |         |        |                |        |
|--|---------|--------|----------------|--------|
| Date   | Default |        |                |        |
| D  | V!#S29  |        |                |        |
| J 1  | 06DTYY  |        |                |        |
| J 2  | 2?HL9X  |        |                |        |
| J3   | 1CP55V  |        |                |        |
| J 4  | T6!M\$Y |        |                |        |
| J 5  | Z2IJ%Z  |        |                |        |
| J 6  | A12%Z0  |        |                |        |
| Method   | E       | E·N·SP | E · N ·<br>S P | E·N·SP |
|  | 10 0111 |        |                |        |

• Origin data history table (Origin Data History) Serial No FS804008

(O: O(Alphabet), 0: Zero)

Note) Meanings of symbols in method column E: Jig method N: Not used

SP: Not used

Fig.2-14 : Origin data label (an example)

\* The origin data to input is found on also the robot examination report sheet.

WARNING Always install/remove the cover with the controller control power turned OFF. Failure to do so could lead to physical damage or personal injury should the robot start moving due to incorrect operations.

#### (2) Turning ON the control power

CAUTION Confirm that there are no operators near the robot before turning the power ON.

1) Turn the controller [POWER] switch ON. The control power will be turned ON, and "o. 100" will appear on the STATUS NUMBER display on the front of the controller.

#### (3) Preparing the T/B



Next, prepare to use the T/B 1) Set the [MODE] switch on the front of the controller to "MANUAL".

 Set the T/B [ENABLE] switch to "ENABLE". The menu selection screen will appear. The following operations are carried out with the T/B.

#### $\diamond \blacklozenge \diamond$ Operating from the T/B $\diamond \blacklozenge \diamond$

Always set the [MODE] switch (mode selection key switch) on the front of the controller to "MAMNUAL", and then set the T/B [ENABLE] switch to "ENABLE".

When the T/B is valid, only operations from the T/B are possible. Operations from the controller or external signals will not be accepted.

(4) Selecting the origin setting method <menu> 1) Press the [4] key on the menu screen, and display the 2. RUN 4. ORIGIN/BRK 6. ENHANCED 1. FILE/EDIT ORIGIN/BRAKE screen. 3. PARAM. 5. Set/INIT. 4 сні CLOSE 123 <ORIGIN/BRAKE> 2) Press the [1] key on the ORIGIN/BRAKE screen, and 1. ORIGIN 2. BRAKE display the origin setting method selection screen. **1** '() 123 CLOSE <ORIGIN> 1. DATA 2. MECH 3) Press the [1] key on the origin setting method selection 3. T00L 4. ABS screen, and select the data input method. 5. USER **1** '() CLOSE 123 <ORIGIN> DATA 4) Display the origin data input screen D:( ) ) J3( J1 ( ) J2( ) J4 ( ) J5( ) J6( ) J7 ( J8 ( ) CLOSE 123

 $\diamond \blacklozenge \diamond$  Selecting a menu  $\diamond \blacklozenge \diamond$ 

The menu can be selected with one of the following methods.


A: Press the numeral key for the No. of the item to be selected.

B: Using the [  $\downarrow$  ] and [  $\uparrow$  ] keys, etc., move the cursor to the item to be selected, and then press the [INP] key.

#### $\diamond \blacklozenge \diamond$ The input method of numeral $\diamond \blacklozenge \diamond$

The number can be inputted if the key displayed on the lower left of each key is pressed. Press the [CHARACTER] key, and in the condition that "123" is displayed on the screen lower side, press the number key.


#### (5) Inputting the origin data



Input the value confirmed in section Page 19, "(1) Confirming the origin data". The correspondence of the origin data label value and axis to be input is shown in Fig. 2–15.

Fig.2-15 : Correspondence of origin data label and axis

The method for inputting the origin data is explained below. The value shown in Fig. 2–14 will be input as an example.



1) Confirm that the cursor is at the  $\rm "D"$  position on the T/B display screen.

2) Input the D value "V!%S29". <u>Inputting "V"</u>
Press the [CHARACTER] key and set to the character input mode. (Condition that "ABC" was displayed under the screen)

Press the [TUV] key three times. "V" will be set.

#### Inputting "!"

Press the [, %] key five times. "!" will be set. Press the [ $\rightarrow$ ] key once and advance the cursor. Press the [, %] key twice (input "%"), and press the [PQRS] key four times (input "S").

Press the [CHARACTER] key and set to the numeral input mode. (Condition that  $\H{123}\H{}'$  was displayed under the screen)

Press the [2] key (input "2"), and press the [9] key (input "9").

"V!%S29" will appear at the "D" data on the teaching pendant screen.

3) Press the [  $\downarrow\,$  ] key, and move the cursor to the J1 input position.

4) Input the J1 value in the same manner as above.

Input the J2, J3, J4, J5 and J6 values in the same manner.

|   | DTYY) J2 | ( Z21J%Z)        | D: ( V!%S2<br>) J3 ( 1CP55<br>) J6 ( A12%2<br>)<br>CLOSE | 5V) |
|---|----------|------------------|--|-----|
| <origin< td=""><td></td><td></td><td></td><td></td></origin<> |          |                  |  |     |
| CHAN<br>Yes   | GE TO OR | 1GIN. OK?<br>123 | No   | F1  |

5) After inputting all of the values, press the [EXE] key. The origin setting confirmation screen will appear.

6) Press [F1] (Yes) to end the origin setting

♦♦ Moving the cursor ♦♦ Press the  $[\uparrow], [\downarrow], [\leftarrow]$  and  $[\rightarrow]$  keys.

Inputting characters 
Press the [CHARACTER] key and set to the character input mode. (Condition that "ABC" was displayed under the screen). The displayed character is scrolled each time at pressing the key.

 $\diamond \diamond \diamond$  Correcting an input  $\diamond \diamond \diamond$ After returning one character by pressing the [C L E A R] key, input the character again.

#### (6) Installing the shoulder cover B.

Return the shoulder cover B removed in section Page 19, "(1) Confirming the origin data" to its original position. This completes the setting of the origin with the origin data input method.



Always remove and install the cover with the controller power turned OFF. Failure to do so could lead to the robot moving because of incorrect operations, or to physical damage or personal injury.


#### $\Diamond \blacklozenge \Diamond$ If the origin input data is incorrect $\Diamond \blacklozenge \Diamond$

If the origin input data is incorrect, the alarm No. 1760 (origin setting data illegal) will occur when origin data input. In this case, reconfirm the value input for the origin data.


#### 2.5 Confirming the operation

In this section, the robot will be moved manually using the T/B to confirm that the operation is correct. Moving the robot manually is called "jog operation". This operation includes the JOINT jog that moves each axis, the XYZ jog that moves along the base coordinate system, the TOOL jog that moves along the tool coordinate system, and the CYLNDER jog that moves along the circular arc.

This operation is carried out while pressing the deadman switch on the back of the T/B.




Refer to Page 18, "2.4 Setting the origin" for details on setting the origin.



\* Each axis moves independently.


Fig.2-16 : JOINT jog operation



\* While maintaining the flange surface posture, the axis moves straight along the base coordinate system.

Also, while maintaining the flange surface position, the flange surface posture changes.


Fig.2-17 : XYZ jog operation



\* While maintaining the flange surface posture, the axis moves straight along the tool coordinate system.

Also, while maintaining the flange surface position, the flange surface posture changes.






\* The axis moves straight along the base coordinate system. At this time, the flange surface posture is not maintained.

Also, the flange surface posture changes. The flange surface position changes at this time.

Fig.2-19 : 3-axis XYZ jog operation



\* The current position is set as the arc centering on the Z axis, and the axis moves along that arc, expands and contracts in the radius direction, and moves vertically. At this time, the flange surface posture is maintained. Also, while maintaining the flange surface position, the flange surface posture changes.

Fig.2-20 : CYLINDER jog operation




Fig.2-21 : WORK jog operation

#### (1) JOINT jog operation

#### Select joint jog mode <CURRENT> JOINT 100% M1 Τ0 +0.00 +0.00 +90.00 +0.00 +0. 00 +0. 00 J1: J5: J6: J2: J3: J4: -ð F1 JOĞ TOOL JOG 3-XYZ CYLNDR XYZ Joint jog mode Set jog speed <CURRENT> JOINT 100% M1 Τ0 +0.00 +0.00 J1: J5: J2 J6: +0.00 +90.00 +0.00 J3: J4: OVRD $\downarrow$ OVRD 1 XYZ T00L JOG 3-XYZ CYLNDR Setting the speed

[JOG] Press the key and display the jog screen. ("JOG" is displayed on the screen bottom) Check that the "joint" in jog mode is displayed on the screen.


If other jog modes are displayed, please press the function key corresponding to the "joint." (If the jog mode which he wishes under the screen is not displayed, it is displayed that the [FUNCTION] key is pressed)

If it finishes jog operation, press the [JOG] key again, or function key which correspond to "close."

Whenever it presses the key of [OVRD  $\uparrow$  ], the override goes up. Conversely, if the [OVRD  $\downarrow$  ] key is pressed, it will go down.


The current setting speed is displayed on screen upper right, and "STATUS NUMBER" of the controller.

Set the override to 10% here for confirmation work




• When the [+X (J1)] keys are pressed, the J1 axis will rotate in the plus direction. When the [-X (J1)] keys are pressed, Rotate in the minus direction.

#### J2 axis jog operation




• When the [+Y (J2)] keys are pressed, the J2 axis will rotate in the plus direction. When the [-Y (J2)] keys are pressed, Rotate in the minus direction.  $\diamond igodot \diamond$  When the robot is in the transportation posture  $\diamond igodot \diamond$ 

The axes may be outside the movement area. Move these axes toward the inner side of the movement area.



- When the [+Z (J3)] keys are pressed, the J3 axis will rotate in the plus direction. When the [-Z (J3)] keys are pressed, Rotate in the minus direction.
- J4, J5 and J6 axis jog

J3 axis jog operation




- When the [+A (J4)] keys are pressed, the J4 axis will rotate in the plus direction. When the [-A (J4)] keys are pressed, Rotate in the minus direction.
- When the [-B (J5)] keys are pressed, Rotate in the minus direction.
- When the [+C (J6)] keys are pressed, the J6 axis will rotate in the plus direction When the [-C (J6)] keys are pressed, Rotate in the minus direction.

## $\diamond \bullet \diamond$ If the buzzer of T/B sounds and the robot does not move $\diamond \bullet \diamond$

If it is going to move the robot across the operation range, the buzzer of T/B sounds and the robot does not move. In this case, please move to the counter direction.

# (2) XYZ jog operation



[JOG] Press the key and display the jog screen. ("JOG" is displayed on the screen bottom) Check that the "XYZ" in jog mode is displayed on the screen.


If other jog modes are displayed, please press the function key corresponding to the "XYZ." (If the jog mode which he wishes under the screen is not displayed, it is displayed that the [FUNCTION] key is pressed)

If it finishes jog operation, press the [JOG] key again, or function key which correspond to "close."

Whenever it presses the key of [OVRD  $\uparrow$  ], the override goes up. Conversely, if the [OVRD  $\downarrow$  ] key is pressed, it will go down.

The current setting speed is displayed on screen upper right, and "STATUS NUMBER" of the controller.

Set the override to 10% here for confirmation work



• When the [+X (J1)] keys are pressed, the robot will move along the X axis plus direction. When the [-X (J1)] keys are pressed, Move along the minus direction.

• When the [+Y (J2)] keys are pressed, the robot will move along the Y axis plus direction.


- When the [-Y (J2)] keys are pressed, Move along the minus direction.
- When the [+Z (J3)] keys are pressed, the robot will move along the Z axis plus direction.
- When the [-Z (J3)] keys are pressed, Move along the minus direction.

## $\diamond igodold \diamond \diamond$ When the robot is in the transportation posture $\diamond igodold \diamond \diamond$

There are directions from which linear movement is not possible from the transportation posture. In this case, the robot will not move. Refer to section Page 28, "(1) JOINT jog operation"", and move the robot to a position where linear movement is possible, and then carry out XYZ jog.

 $\diamond \diamond \diamond$  If the buzzer of T/B sounds and the robot does not move  $\diamond \diamond \diamond$ 

If it is going to move the robot across the operation range, the buzzer of T/B sounds and the robot does not move. In this case, please move to the counter direction.



- When the [+A (J4)] keys are pressed, The X axis will rotate in the plus direction.
- When the [-A (J4)] keys are pressed, Rotate in the minus direction.
- When the [+B (J5)] keys are pressed, The Y axis will rotate in the plus direction.
- When the [-B (J5)] keys are pressed, Rotate in the minus direction.
- When the  $\ [+C (J6)]$  keys are pressed, The Z axis will rotate in the plus direction.
- When the [-C (J6)] keys are pressed, Rotate in the minus direction.


## $\diamond \blacklozenge \diamond$ When alarm No. 5150 occurs $\diamond \blacklozenge \diamond$

If alarm No. 5150 (ORIGIN NOT SET) occurs, the origin has not been set correctly. Reconfirm the value input for the origin data.

## $\diamond \blacklozenge \diamond$ Tool length $\diamond \blacklozenge \diamond$

The default tool length is 0mm, and the control point is the center of the end axis. After installing the hand, set the correct tool length in the parameters. Refer to the separate manual "Detailed Explanation of Functions and Operations" for details.

# (3) TOOL jog operation



[JOG] Press the key and display the jog screen. ("JOG" is displayed on the screen bottom) Check that the "TOOL" in jog mode is displayed on the screen.


If other jog modes are displayed, please press the function key corresponding to the "TOOL." (If the jog mode which he wishes under the screen is not displayed, it is displayed that the [FUNC<sup>-</sup> TION] key is pressed)


If it finishes jog operation, press the [JOG] key again, or function key which correspond to ″close.″

Whenever it presses the key of [OVRD  $\uparrow$  ], the override goes up. Conversely, if the [OVRD  $\downarrow$  ] key is pressed, it will go down.

The current setting speed is displayed on screen upper right, and "STATUS NUMBER" of the controller.

Set the override to 10% here for confirmation work





•When the [+X (J1)] keys are pressed, the robot will move along the X axis plus direction of the tool coordinate system

When the [-X (J1)] keys are pressed, Move along the minus direction.

•When the [+Y (J2)] keys are pressed, the robot will move along the Y axis plus direction of the tool coordinate system.

When the [-Y (J2)] keys are pressed, Move along the minus direction.

•When the [+Z (J3)] keys are pressed, the robot will move along the Z axis plus direction of the tool coordinate system


When the [-Z (J3)] keys are pressed, Move along the minus direction.

 $\diamond \bullet \diamond$  When the robot is in the transportation posture  $\diamond \bullet \diamond$ 

There are directions from which linear movement is not possible from the transportation posture. In this case, the robot will not move. Refer to section Page 28, "(1) JOINT jog operation"", and move the robot to a position where linear movement is possible, and then carry out XYZ jog.

 $\diamond \diamond \diamond$  If the buzzer of T/B sounds and the robot does not move  $\diamond \diamond \diamond$ 

If it is going to move the robot across the operation range, the buzzer of T/B sounds and the robot does not move. In this case, please move to the counter direction.



- When the[+A (J4)] keys are pressed, The X axis will rotate in the plus direction of the tool coordinate system. When the[-A (J4)] keys are pressed, Rotate in the minus direction.
- When the[+B (J5)] keys are pressed, The Y axis will rotate in the plus direction of the tool coordinate system.
   When the[-B (J5)] keys are pressed, Rotate in the minus direction.
- When the[+C (J6)] keys are pressed, The Z axis will rotate in the plus direction of the tool coordinate system. When the[-C (J6)] keys are pressed, Rotate in the minus direction.

#### $\diamond \blacklozenge \diamond$ When alarm No. 5150 occurs $\diamond \blacklozenge \diamond$


If alarm No. 5150 (ORIGIN NOT SET) occurs, the origin has not been set correctly. Reconfirm the value input for the origin data.

#### $\diamond \blacklozenge \diamond$ Tool length $\diamond \blacklozenge \diamond$

The default tool length is 0mm, and the control point is the center of the end axis.

After installing the hand, set the correct tool length in the parameters. Refer to the separate manual "Detailed Explanation of Functions and Operations" for details.

# (4) 3-axis XYZ jog operation



[JOG] Press the key and display the jog screen. ("JOG" is displayed on the screen bottom) Check that the "XYZ456" in jog mode is displayed on the screen.

If other jog modes are displayed, please press the function key corresponding to the "XYZ456." (If the jog mode which he wishes under the screen is not displayed, it is displayed that the [FUNC<sup>-</sup> TION] key is pressed)


If it finishes jog operation, press the [JOG] key again, or function key which correspond to <sup>′′</sup>close.′

Whenever it presses the key of [OVRD  $\uparrow$  ], the override goes up. Conversely, if the [OVRD  $\downarrow$  ] key is pressed, it will go down.

The current setting speed is displayed on screen upper right, and "STATUS NUMBER" of the controller.

Set the override to 10% here for confirmation work

Moving along the base coordinate system




\* The direction of the flange will change

 When the[+X (J1)] keys are pressed, the robot will move along the X axis plus direction. When the [-X (J1)] keys are pressed, Move along the minus direction.

- When the [+Y (J2)] keys are pressed, the robot will move along the Y axis plus direction. When the [-Y (J2)] keys are pressed, Move along the minus direction.
- When the[+Z (J3)] keys are pressed, the robot will move along the Z axis plus direction. When the [-Z (J3)] keys are pressed, Move along the minus direction.


 $\diamond \bullet \diamond$  The flange surface end axis posture cannot be maintained with 3-axis XYZ jog.  $\diamond \bullet \diamond$ With 3-axis XYZ jog, the flange surface end axis posture (orientation) is not maintained when moving linearly in the X, Y or Z axis direction.

Use XYZ jog to maintain the posture.



- When the[+A (J4)] keys are pressed, the J4-axis will rotate in the plus direction.
   At this time, to maintain the flange's position, other axes move simultaneously except J5 and J6.
   When the[-A (J4)] keys are pressed, Rotate in the minus direction.
- When the[+B (J5)] keys are pressed, the J5-axis will rotate in the plus direction.
   At this time, to maintain the flange's position, other axes move simultaneously except J4 and J6.
   When the[-B (J5)] keys are pressed, Rotate in the minus direction.
- When the [+C (J6)] keys are pressed, the J6-axis will rotate in the plus direction. When the [-C (J6)] keys are pressed, Rotate in the minus direction.

# (5) CYLNDER jog operation



[JOG] Press the key and display the jog screen. ("JOG" is displayed on the screen bottom) Check that the "CYLNDER" in jog mode is displayed on the screen.

If other jog modes are displayed, please press the function key corresponding to the "CYLNDER." (If the jog mode which he wishes under the screen is not displayed, it is displayed that the [FUNCTION] key is pressed)


If it finishes jog operation, press the [JOG] key again, or function key which correspond to "close."

Whenever it presses the key of [OVRD  $\uparrow$  ], the override goes up. Conversely, if the [OVRD  $\downarrow$  ] key is pressed, it will go down.

The current setting speed is displayed on screen upper right, and "STATUS NUMBER" of the controller.

Set the override to 10% here for confirmation work


Moving along an arc centering on the Z axis



Assuming that the current position is on an arc centering on the Z axis, the robot moves along that arc.

- When the [+X (J1)] keys are pressed, the robot will expand in the radial direction.
  - When the [-X (J1)] keys are pressed, Contract in the radial direction.
- When the [+Y (J2)] keys are pressed, the robot will move along the arc in the plus direction.
- When the [-Y (J2)] keys are pressed, Move in the minus direction.
- When the[+Z (J3)] keys are pressed, the robot will move along the Z axis plus direction.
   When the[-Z (J3)] keys are pressed, Move along the minus direction.

#### Changing the flange surface posture



- When the [+A (J4)] keys are pressed, The X axis will rotate in the plus direction. When the [-A (J4)] keys are pressed, Rotate in the minus direction.
- When the [+B (J5)] keys are pressed, The Y axis will rotate in the plus direction. When the [-B (J5)] keys are pressed, Rotate in the minus direction.
- When the [+C (J6)] keys are pressed, The Z axis will rotate in the plus direction. When the [-C (J6)] keys are pressed, Rotates in the minus direction.

# (6) Work jog operation

Setting of the work coordinates system is necessary.

By this jog operation, robot can be move along with the direction of work (or working table etc.), so teaching operations get easier.

When jog operation, select by which work coordinates the robot moves

The setting method of the work coordinates system using T/B (R32TB) is shown in the following. (Parameter: Setting the coordinate value to WKnCORD ("n" is meaning the number (1-8) of work coordinates) can also set up the work coordinates system. Refer to the separate manual "Detailed Explanation of Functions and Operations" for details of parameter.)


In addition, this jog operation is available at the following software versions. The below-mentioned "6.ENHANCED" menu is not displayed in the other versions.

T/B :Ver.1.3 or later


SQ series: N8 or later

SD series :P8 or later

The work coordinates system teaches and sets up the three points (WO, WX, WY).



hand is the same)




The setting (definition) method of the work coordinates system is shown in the following.

1) Select "6.ENHANCED" screen on the <MENU> screen.



2) Press the [2] keys in the menu screen and select "2. WORK COORD."




3) Selection of the work coordinates number


Press the [FUNCTION] keys, and display "W: JUMP" function. Press the function key corresponding to "W: JUMP"

| <pre><work coord=""> X: 0.00 Y: 0.00 Z: 0.00</work></pre> | WORK NUMBER (1)<br>TEACHING POINT (WO) | <b>→</b> | <work jump=""><br/>CHOOSE ONE OF THE WORK NUMBER<br/>1-8.</work> |  |
|---|--|----------|--|--|
| W. JUMP W. GRID   | 123 CLOSE                              |          | 123 CLOSE  |  |

Press numeral key [1] - [8] and specify the work coordinates number. The coordinate value of the specified work coordinates system is displayed.



Operation will be canceled if the [CLOSE] key is pressed.



The screen is the example which specified the work coordinates number 2. ("2" at the upper right of the screen)

4) The teaching of the work coordinates system

Teach the three points shown in Fig. 2-22. Confirm the name currently displayed on the "TEACHING POINT" at the upper right of the screen. If it differs, press the function key corresponding to each point(WO, WX, WY) to teach. Move the robot's arm by jog operation (other jogging movement), and press the function key corresponding to "TEACH."([F1]) The confirmation screen is displayed.

| <pre><work coord=""> X: 0.00 Y: 0.00 Z: 0.00</work></pre> |        | NUMBER (2)<br>POINT (WO) |
|---|--------|--------------------------|
| TEACH WX  | 123 WY | DEFINE                   |

Specify the teaching point [WO],[WX],[WY] teaching the position [TEACH]

| <work co<="" th=""><th>oord&gt;</th><th></th><th>WORK</th><th>NUMBER</th><th>(2)</th><th></th></work> | oord>               |     | WORK | NUMBER | (2) |  |
|---|---------------------|-----|------|--------|-----|--|
|   | NG POINT<br>CURRENT |     | ION. |        |     |  |
| Yes   |                     | 123 |      | Ν      | 0   |  |

Presses the function key corresponding to"Yes", the robot's current position is registered, and the registered coordinates value is displaye. Operation will be canceled if the [CLOSE] key is pressed.



Teach the three points, WO, WX, and WY, by the same operation.

The position data taught here is each registered into the following parameters. ("n" means the work coordinates numbers 1-8)

WO= parameter: WKnWO WX= parameter: WKnWX WY= parameter: WKnWY

vv Y = parameter: vvKnvv Y


5) Setting of work coordinates (definition)


If the function key corresponding to "DEFINE" ([F1]) is pressed, the work coordinates system will be calculated using the three points, and the result will be displayed.



The alarm occurs if the work coordinates system is incalculable. (There are the three points on the straight line, or the two points have overlapped) In this case, reset alarm and re-teach the three points. This work coordinate data is registered into parameter: WKnCORD. ("n" means the work coordinates numbers 1-8)


If the function key corresponding to "CLOSE" is pressed, it will return to the previous screen.





6) Finishing of setting the work coordinates

Press the [FUNCTION] keys, and display "CLOSE" function. Press the function key corresponding to "CLOSE". Returns to the <MENU> screen.




| <emhanced></emhanced> |     |         |        |  |
|-----------------------|-----|---------|--------|--|
| 1. SQ DIRECT          | 2   | 2. WORK | COORD. |  |
|                       |     |         |        |  |
|                       |     |         |        |  |
|                       | 123 |         | CLOSE  |  |

Although setting of work coordinates is finishing above, confirmation of work coordinates can be done by press<sup>-</sup> ing the function key corresponding to "W GRID."([F2])


| <work coord=""></work>              |     | NUMBER (2)<br>POINT (WO) |
|-------------------------------------|-----|--------------------------|
| X: 214.12<br>Y: -61.23<br>Z: 553.30 |     |                          |
| W.JUMP W.GRID                       | 123 | CLOSE                    |

**→** 




Return to the previous screen by pressing the [CLOSE] ([F4]) key.

Then, the operation method of the work jog is shown. Change to the work jog after nearing the work.



#### Confirmation and selection of the



[JOG] Press the key and display the jog screen. ("JOG" is displayed on the screen bottom)

Check that the "WORK" in jog mode is displayed on the screen.

If other jog modes are displayed, please press the function key corresponding to the "WORK." (If the jog mode which he wishes under the screen is not displayed, it is displayed that the [FUNCTION] key is pressed)

If it finishes jog operation, press the [JOG] key again, or function key which correspond to "close."

Confirm the target work coordinates system. The current target number is displayed on the screen upper right. (W1Å`W8) The number of work coordinates can be changed by the arrow key [Upper arrow], [Lower arrow]


Push the key [Upper arrow], the number will increase. (W1, W2, ..... W8) Conversely, push the key [Lower arrow], the number will decrease

▲ CAUTION

**N** Always confirm that the number of the target work coordinates system is displayed correctly (Display of W1-W8 at the upper right of the screen)

If mistaken, the robot will move in the direction which is not meant and will cause the damage and the personal injuries.


#### Set jog speed



Whenever it presses the key of [OVRD(Upper arrow)], the override goes up. Conversely, if the [OVRD(Lower arrow)] key is pressed, it will go down.

The current setting speed is displayed on screen upper right, and "STATUS NUMBER" of the controller.

Set the override to 10% here for confirmation work



\* The direction of the flange will not change. Move the control point with a straight line in accordance with the work coordinates system

• When the [+X (J1)] keys are pressed, the robot will move along the X axis plus direction on the work coordinates system.

When the [-X (J1)] keys are pressed, Move along the minus direction.


• When the [+Y (J2)] keys are pressed, the robot will move along the Y axis plus direction on the work coordinates system.

When the [-Y (J2)] keys are pressed, Move along the minus direction.

• When the[+Z (J3)] keys are pressed, the robot will move along the Z axis plus direction on the work coordinates system.

When the [-Z (J3)] keys are pressed, Move along the minus direction.

#### Changing the flange surface posture



2-42 Confirming the operation

•When the[+A (J4)] keys are pressed, The X axis will rotate in the plus direction of the work coordinate system. When the[-A (J4)] keys are pressed, Rotate in the minus direction.

•When the[+B (J5)] keys are pressed, The Y axis will rotate in the plus direction of the work coordinate system. When the[-B (J5)] keys are pressed, Rotate in the minus direction.

•When the[+C (J6)] keys are pressed, The Z axis will rotate in the plus direction of the work coordinate system. When the[-C (J6)] keys are pressed, Rotate in the minus direction.

 $\diamond igodold \diamond \diamond$  When the robot is in the transportation posture  $\diamond igodold \diamond \diamond$ 

There are directions from which linear movement is not possible from the transportation posture. In this case, the robot will not move. Refer to section Page 28, "(1) JOINT jog operation"", and move the robot to a position where linear movement is possible, and then carry out XYZ jog.

♦ ♦ If the buzzer of T/B sounds and the robot does not move ♦ ♦ ♦
If it is going to move the robot across the operation range, the buzzer of T/B sounds and the robot does not move. In this case, please move to the counter direction.


#### $\diamond \blacklozenge \diamond$ Tool length $\diamond \blacklozenge \diamond$

The default tool length is 0mm, and the control point is the center of the end axis. After installing the hand, set the correct tool length in the parameters. Refer to the separate manual "Detailed Explanation of Functions and Operations" for details.

# 3 Installing the option devices

The installation of the solenoid valve set, the hand input cable, the hand output cable and retrieval of the spare wiring require removal of the same cover. Therefore, it is better to install them simultaneously.

3.1 Installing the solenoid valve set (1S-VD0\*-02(E))






Fig. 3–1 and Fig. 3–2 shows the solenoid valve installation procedures and the solenoid valve connector connection procedures. The installation procedures are as follow. This work must be carried out with the controller power turned OFF.

- 1) Refer to Page 57, "5.3.2 Installing/removing the cover" and remove the No. 2 arm cover B <2>, and the No. 2 arm cover C <3>.
- 2) If you are not using the spare line (ADD: stored in a coil) in section A shown in Fig. 3-1, remove it. The spare line is connected to a connector inside section A.
- 3) Connect the connectors of "GR1" and "GR2" stored in section A to the connectors of "GR1" and "GR2" coming out of the solenoid valves. Store the connectors near the location marked with O shown in Fig. 3-2.




Fig.3-2 : Solenoid valve installation diagram details 1

- 4) The length of the two air hoses ( $\phi$  6) stored in section A is longer than necessary by assuming the use of a solenoid valve set not manufactured by Mitsubishi. Cut off the air hoses to an appropriate length, and connect them to the couplings.
- 5) Of the two air hoses (\$\phi\$ 6\$), the one marked with "AIR IN" is for connecting the quick coupling (P port) <6> of the solenoid values, and the other marked with "RETURN" is for connecting the quick coupling (R port) <7> of the solenoid values. If you use the joint of "RETURN" on the base of robot, remove the cap for protection against dust. If it uses attached, exhaust pressure increases and the solenoid value may not operate normally. And, the hose can be connected to this joint and the exhaust can be drawn.
- 6) Using the screw holes of the No. 2 arm cover C <3>, mount the solenoid valves with the socket bolts (four M4 x 8) attached to the solenoid valves. When mounting the solenoid valves, be careful not to damage the sponge sealing material attached to the opening of section A. If the sealing material is damaged, it may degrade the protection specification.




Fig.3-3 : Solenoid valve installation diagram details 2

7) When you have completed the installation, reinstall the No.2 arm cover B <2> to its original position, and be careful not to entangle the cables when you do so.

The connections after the installation appear as in Table 3-1 for single type valves, hand 2 is not applicable.

| Hand   | Hand port | Solenoid valve port | Solenoid valve used |
|--------|-----------|---------------------|---------------------|
| Hand 1 | OPEN      | 1                   | First set           |
|        | CLOSE     | 2                   | FIRST SET           |
| Hand 2 | OPEN      | 3                   | Second set          |
|        | CLOSE     | 4                   | Second set          |
| Hand 3 | OPEN      | 5                   | Third set           |
| Hand 3 | CLOSE     | 6                   | i nira set          |
| Hand 4 | OPEN      | 7                   | Fourth set          |
| Hand 4 | CLOSE     | 8                   | Fourth Set          |

Table 3-1 : Solenoid valve ports and hoses: Correspondence of couplings and hand ports

# 3.2 Installing the hand input cable

The procedure for installing the hand input cable is as follows. Conduct work by referring to Page 44 "Fig. 3– 1Solenoid valve installation procedures" and Page 47 "Fig. 3–4Installing the hand input cable" below. This work must be carried out with the controller power turned OFF.





Fig.3-4 : Installing the hand input cable

- 1) Refer to Page 57, "5.3.2 Installing/removing the cover" and remove the No. 2 arm cover B <2>, and the No. 2 arm cover C <3> or the solenoid valves <5>.
- 2) If you are not using the spare line (ADD: stored in a coil) in section A shown in Fig. 3-1, remove it. The spare line is connected to a connector inside section A.
- 3) The hand input cable can be fixed to either the No. 2 arm cover C  $\langle 3 \rangle$  or the solenoid values  $\langle 5 \rangle$ .
- 4) Remove one of the two grommets on either the No. 2 arm cover C <3> or the solenoid valves <5>. After removing the grommet, peal off the sealing material left on the hole section of the plate.
- 5) After removing the lock nut attached to the hand input cable, feed the connector side of the hand input cable (with a cable clamp) through the hole on the plate. Replace the removed lock nut in position and fasten it securely.
- 6) Connect the connectors of "HC1" and "HC2" stored in section A shown in Fig. 3-1 to "HC1" and "HC2" of the hand input cable.
- 7) Mount the No. 2 arm cover C <3> or the solenoid valves <5> to section A shown in Fig. 3-1. When mounting, be careful not to damage the sponge sealing material attached to the opening of section A. If it is damaged, the protection performance may be lowered.
- 8) When you have completed the installation, reinstall the No.2 arm cover B <2> to its original position, and be careful not to entangle the cables when you do so.

# 3.3 Installing the hand output cable

The procedure for installing the hand output cable is as follows. This work must be carried out with the controller power turned OFF.






Fig.3-5 : Installing the hand output cable

- 1) Refer to Page 57, "5.3.2 Installing/removing the cover" and remove the No. 2 arm cover B <2>, and the No. 2 arm cover C <3>.
- 2) If you are not using the spare line (ADD: stored in a coil) in section A shown in Fig. 3-1, remove it. The spare line is connected to a connector inside section A.
- The hand output cable will be fixed to the No. 2 arm cover C <3>. (attached to the solenoid valve set)
- 4) Remove one of the two grommets on either the No. 2 arm cover C <3>. After removing the grommet, peal off the sealing material left on the hole section of the plate.
- 5) After removing the lock nut attached to the hand output cable, feed the connector side of the hand output cable (with a cable clamp) through the hole on the plate. Replace the removed lock nut in position and fasten it securely.
- 6) Connect the connectors of "GR1" and "GR2" stored in section A shown in Fig. 3-1 to "GR1" and "GR2" of the hand output cable.
- 7) Mount the No. 2 arm cover C <3> to section A shown in Fig. 3-1. When mounting, be careful not to damage the sponge sealing material attached to the opening of section A. If it is damaged, the protection performance may be lowered.
- 8) When you have completed the installation, reinstall the No.2 arm cover B <2> to its original position, and be careful not to entangle the cables when you do so.

# 3.4 Changing the operating range

## 3.4.1 J1 axis

The operating range of the J1 axis can be changed to the range shown in Table 3-2. (Option)

|     | Axis        |                    | Standard |      | Alternative angle |     |                         |                         |
|-----|-------------|--------------------|----------|------|-------------------|-----|-------------------------|-------------------------|
|     | +side Angle |                    | Angle    |      | +170 +135         | +90 | +45                     | One of the points shown |
|     | TSIde       | Insertion position | None     | A    | В                 | С   | on the left             |                         |
| J 1 | ida         | Angle              | -170     | -135 | -90               | -45 | One of the points shown |                         |
|     | -side       | Insertion position | None     | а    | b                 | с   | on the left             |                         |

#### Table 3-2 : Operating range alternative range

Note) The insertion position given in the table indicates the insertion position for the operating range change stopper. (Refer to Fig. 3-6.)

The operating range is changed with robot arm settings and parameter settings.

#### (1) Setting the robot arm

- 1) Move the upper arm to the posture as shown in Fig. 3-6 by jog operation.
- 2) Turn OFF the controller power.
- 3) By referring to Table 3-2 and Fig. 3-6, insert the two stoppers (M10 x 20) used to change the movement range of J1 axis at the angular position to be changed, and fix securely by applying a clamping torque of 70 to 86 N · m.



Do not remove the stopper for the standard specification of  $\pm\,170$  degree shown in Fig. 3-6.




Fig.3-6 : Installation of operating range change option

(2) Setting the parameters

- Change the values of the first element (J1 axis minus side) and second element (J1 axis plus side) of the joint operating range parameter MEJAR. Set the value to the angle corresponding to the position where the operating range change stopper was inserted in "(1)Setting the robot arm" above. Refer to the separate "Instruction Manual/Detailed Explanation of Functions and Operations" for details on changing the parameter.
- 2) When completed changing the parameters, turn the controller power OFF and ON. Move the waist axis to the operating range limit with JOINT jog operation, and confirm that the limit over occurs and the robot stops at the angle changed for both the +/- sides.

This completes setting the parameters and the changing of the operating range.

# 4 Basic operations

The basic operations from creating the program to automatic operation are explained in section "4. Basic operations" in the "From Controller Setup to Maintenance" manual. Refer that manual as necessary.

# 5 Maintenance and Inspection


The maintenance and inspection procedures to be carried out to use the robot for a long time without trouble are described in this chapter. The types and replacement methods of consumable parts are also explained.

## 5.1 Maintenance and inspection interval

Maintenance and inspection are divided into the inspections carried out daily, and the periodic inspections carry out at set intervals. Always carry these out to prevent unforeseen trouble, to maintain the product for a long time, and to secure safety.

#### (1) Inspection schedule

In addition to the monthly inspection, add the following inspection items every three months (estimated at 500 Hr operation hours).



Operating time

<Guideline for inspection period> For one shift 8 Hr/day × 20 days/month × 3 months = approx. 500 Hr 10 Hr/day × 20 days/month × 3 months = approx. 600 Hr For two shifts 15 Hr/day × 20 days/month × 3 months = approx. 1000 Hr

[Caution] When using two lines, the 3-month inspection, 6-month inspection and yearly inspection must be carried out when half the time has passed.

Fig.5-1 : Inspection schedule

# 5.2 Inspection items

The inspection items for the robot arm are shown below.

Also refer to section "5. Maintenance and inspection" in the "Controller setup, basic operation, and maintenance" manual, and inspect the controller.

#### 5.2.1 Daily inspection items

Carry out the daily inspections with the procedures given in Table 5-1.

| Procedure     | Inspection item (details)   | Remedies   |
|---------------|---|--|
| Before turni  | ng power ON (Check the following items before turning the power ON.)  |  |
| 1             | Are any of the robot installation bolts loose? (Visual)   | Securely tighten the bolts.                                      |
| 2             | Are any of the cover tightening screws loose? (Visual)  | Securely tighten the screws.                                     |
| 3             | Are any of the hand installation bolts loose?<br>(Visual)   | Securely tighten the bolts                                       |
| 4             | Is the power supply cable securely connected?<br>(Visual)   | Securely connect.  |
| 5             | Is the machine cable between the robot and controller securely connected?   | Securely connect.  |
|               | (Visual)  |  |
| 6             | Are there any cracks, foreign contamination or obstacles on the robot and controller cover?   | Replace with a new part, or take remedial measures.              |
| 7             | Is any grease leaking from the robot arm?<br>(Visual)   | After cleaning, replenish the grease.                            |
| 8             | Is there any abnormality in the pneumatic system? Are there any air<br>leaks, drain clogging or hose damage? Is the air source normal?<br>(Visual)  | Drain the drainage, and remedy the air leaks (replace the part). |
| After turning | the power ON (Turn the power ON while monitoring the robot.)  |  |
| 1             | Is there any abnormal motion or abnormal noise when the power is turned ON?   | Follow the troubleshooting section.                              |
| During opera  | ation (try running with an original program)  |  |
| 1             | <ul> <li>Check whether the movement points are deviated?</li> <li>Check the following points if there is any deviation.</li> <li>1. Are any installation bolts loose?</li> <li>2. Are any hand installation section bolts loose?</li> <li>3. Are the positions of the jigs other than the robot deviated?</li> <li>4. If the positional deviation cannot be corrected, refer to "Troubleshooting", check and remedy.</li> </ul> | Follow the troubleshooting section.                              |
| 2             | Is there any abnormal motion or abnormal noise?<br>(Visual)   | Follow the troubleshooting section.                              |

Table 5-1 : Daily inspection items (details)

#### 5.2.2 Periodic inspection

Carry out periodic inspection with the procedures given in Table 5-2.

| Procedure    | Inspection item (details)   | Remedies  |
|--------------|---|---|
| Monthly insp | pection items   |   |
| 1            | Are any of the bolts or screws on the robot arm loose?  | Securely tighten the bolts.   |
| 2            | Are any of the connector fixing screws or terminal block terminal screws loose?                         | Securely tighten the screws.  |
| 3            | Remove the cover at each section, and check the cables for wear damage and adherence of foreign matter. | Check and eliminate the cause.<br>If the cables are severely damaged, contact the<br>Mitsubishi Service Department. |
| 3-month ins  | pection items   |   |
| 1            | Is the timing belt tension abnormal?  | If the timing belt is loose or too tense, adjust it.  |
| 6-month ins  | pection items   |   |
| 1            | Is the friction at the timing belt teeth severe?  | If the teeth are missing or severe friction is found, replace the timing belt.                                      |
| Yearly inspe | ection items  |   |
| 1            | Replace the backup battery in the robot arm.  | Exchange it referring to Page 69, "5.3.7 Replacing the backup battery".   |
| 3-year inspe | ection items (6,000Hr)  |   |
| 1            | Lubricate the grease at the harmonic reduction gears for each axis.                                     | Lublicate it referring to Page 66, "5.3.5 Lubrication".   |

Table 5-2 : Periodic inspection items (details)

# 5.3 Maintenance and inspection procedures

The procedures for carrying out the periodic maintenance and inspection are described in this section. Thoroughly read the contents, and follow the instructions. This work can be commissioned to the Mitsubishi Service Department for a fee. (Never disassemble, etc., the parts not described in this manual.)

The maintenance parts, etc., required for the customer to carry out maintenance and inspection are described in Page 72, "5.5 Maintenance parts" of this manual. Always contact your dealer when parts are needed.



A CAUTION The origin of the machine system could deviate when this work is carried out. "Review of the position data" and "re-teaching" will be required.

#### 5.3.1 Robot arm structure

An outline structure drawing is shown in Fig. 5-2.. Each part is as shown below.

- 1) The J1 axis rotation is driven by the J1 axis motor  $\langle 1 \rangle$  and reduction gears  $\langle 2 \rangle$  arranged in the base. Non-excitation magnetic brakes are mounted in the J1axis motor  $\langle 1 \rangle$ .
- 2) The J2 axis rotation is driven by the J2 axis motor  $\langle 3 \rangle$  and reduction gears  $\langle 4 \rangle$  arranged in the shoulder. Non-excitation magnetic brakes are mounted in the J2 axis motor  $\langle 3 \rangle$ .
- 3) The J3 axis rotation is driven by the J3 axis motor  $\langle 5 \rangle$  and reduction gears  $\langle 6 \rangle$  arranged in the shoulder. Non-excitation magnetic brakes are mounted in the J3 axis motor  $\langle 5 \rangle$ .
- 4) The J4 axis rotation is driven by the J4 axis motor  $\langle 7 \rangle$  and reduction gears  $\langle 8 \rangle$  arranged in the elbow block. Non-excitation magnetic brakes are mounted in the J4 axis motor  $\langle 7 \rangle$ .
- 5) The rotation of the J5 axis motor  $\langle 9 \rangle$  arranged in the forearm is conveyed to the reduction gears  $\langle 11 \rangle$  via the timing belt  $\langle 10 \rangle$  to rotate the wrist housing and following parts. Non-excitation magnetic brakes are mounted in the J5 axis motor  $\langle 9 \rangle$ .
- 6) The rotation of the J6 axis is driven by the J6 axis motor  $\langle 12 \rangle$  arranged in the wrist housing and the reduction gears  $\langle 13 \rangle$ .

Non-excitation magnetic brakes are mounted in the J6 axis motor  $\langle 12 \rangle$ .





Fig 5-2 : Outline structure of robot arm

# 5.3.2 Installing/removing the cover



 $\mathsf{Fig.5-3}$  : Installing/removing the cover

| Table 5-3 : | Cover and | Packing | names |
|-------------|-----------|---------|-------|
|-------------|-----------|---------|-------|

| No.   | Cover names       | Qty. | Pa                          | cking        |                | Fixing torque |  |
|-------|-------------------|------|-----------------------------|--------------|----------------|---------------|--|
| 110.  | No. Cover hames   |      | Names                       | Part code    | Sticking side  | (N • m)       |  |
| RV-65 | SD/6SDC           |      |                             |              |                |               |  |
| 1     | Bottom plate      | 1    | Base bottom cover packing A | K07S24345651 | Robot arm side | 1.39 ~ 1.89   |  |
|       |                   |      | Base bottom cover packing B |              | Robot arm side | 1.39 ~ 1.89   |  |
| 2     | Shoulder cover B  | 1    | Shoulder cover B packing    | K07S24319401 | Robot arm side | 1.39 ~ 1.89   |  |
| 3     | No. 1 arm cover   | 1    | No.1arm cover packing A     | K07S24317251 | Robot arm side | 1.39 ~ 1.89   |  |
|       |                   |      | No.1arm cover packing B     |              | Robot arm side | 1.39 ~ 1.89   |  |
|       |                   |      | No.1arm cover packing C     |              | Robot arm side | 1.39 ~ 1.89   |  |
| 4     | Shoulder cover    | 2    | Shoulder cover packing A    | K07S24317151 | Cover side     | 1.39 ~ 1.89   |  |
|       |                   |      | Shoulder cover packing B    |              | Cover side     | 1.39 ~ 1.89   |  |
| 5     | Elbow cover A     | 1    | Elbow cover packing         | K07S24344901 | Cover side     | 1.39 ~ 1.89   |  |
| 6     | No. 2 arm cover C | 1    | No.2 arm cover C packing    | K07S24401502 | Robot arm side | 1.39 ~ 1.89   |  |
| 7     | No. 2 arm cover A | 1    | No.2 arm cover packing      | K07S24342001 | Cover side     | 1.39 ~ 1.89   |  |
| 8     | No. 2 arm cover B | 1    | No.2 arm cover packing      | K07S24342001 | Cover side     | 1.39 ~ 1.89   |  |
| 9     | Wrist cover       | 1    | Wrist cover packing         | K07S24401602 | Robot arm side | 1.39 ~ 1.89   |  |

| No.   | Cover names       | Qty. | Pa                          | Fixing torque |                |             |
|-------|-------------------|------|-----------------------------|---------------|----------------|-------------|
| NO.   | oover names       |      | Names                       | Part code     | Sticking side  | (N • m)     |
| RV-6S | SDL/6SDCL         |      |                             |               |                |             |
| 1     | Bottom plate      | 1    | Base bottom cover packing A | K07S24345651  | Robot arm side | 1.39 ~ 1.89 |
|       |                   |      | Base bottom cover packing B |               | Robot arm side | 1.39 ~ 1.89 |
| 2     | Shoulder cover B  | 1    | Shoulder cover B packing    | K07S24319401  | Robot arm side | 1.39 ~ 1.89 |
| 3     | No. 1 arm cover   | 1    | No.1 arm L cover packing A  | K07S24322451  | Robot arm side | 1.39 ~ 1.89 |
|       |                   |      | No.1 arm L cover packing B  |               | Robot arm side | 1.39 ~ 1.89 |
|       |                   |      | No.1 arm L cover packing C  |               | Robot arm side | 1.39 ~ 1.89 |
| 4     | Shoulder cover    | 2    | Shoulder cover packing A    | K07S24317151  | Cover side     | 1.39 ~ 1.89 |
|       |                   |      | Shoulder cover packing B    |               | Cover side     | 1.39 ~ 1.89 |
| 5     | Elbow cover A     | 1    | Elbow cover packing         | K07S24344901  | Cover side     | 1.39 ~ 1.89 |
| 6     | No. 2 arm cover C | 1    | No.2 arm cover C packing    | K07S24401502  | Robot arm side | 1.39 ~ 1.89 |
| 7     | No. 2 arm cover A | 1    | No.2 arm cover packing      | K07S24342001  | Cover side     | 1.39 ~ 1.89 |
| 8     | No. 2 arm cover B | 1    | No.2 arm cover packing      | K07S24342001  | Cover side     | 1.39 ~ 1.89 |
| 9     | Wrist cover       | 1    | Wrist cover packing         | K07S24401602  | Robot arm side | 1.39 ~ 1.89 |
| 10    | Joint arm cover R | 1    | Joint arm cover R packing   | K07S24430401  | Robot arm side | 1.39 ~ 1.89 |
| 11    | Joint arm cover U | 1    | Joint arm cover U packing   | K07S24430301  | Robot arm side | 1.39 ~ 1.89 |

Note) This robot has packing. Refer to Page 72, "Table 5-7 : Consumable part list" for type name of packing.

Table 5-4 : Cover installation screw list

| No. | Installation screw name                    | Qty. | Remarks              |
|-----|--|------|----------------------|
| а   | Socket bolt (Safety socket) M4×8           | 4    |                      |
| b   | Socket bolt (Safety socket) M4 × 10        | 10   |                      |
| с   | Socket bolt (Safety socket) $M4 \times 30$ | 4    |                      |
| d   | Socket bolt (Safety socket) $M4 \times 55$ | 8    |                      |
| е   | Truss screw M4×10                          | 8    | RV-6SD/6SDC series   |
|     |  | 10   | RV-6SDL/6SDLC series |
| f   | Truss screw M4×8                           | 8    | RV-6SD/6SDC series   |
|     |  | 16   | RV-6SDL/6SDLC series |
| g   | Flat head screw M4 × 8                     | 4    |                      |

(1) Refer to Fig. 5-3 and remove the cover.

- (2) The names of the covers are given in Table 5-3, and a list of the cover installation screws is given in Table 5-4.
- (3) There are some covers that may be difficult to remove due to the robot posture. In this case, change the robot posture with jog operation, and then remove the cover. If the minus driver is inserted, it will be easy to remove the cover. Be careful not to damage packing.
- (4) When attaching the cover after maintenance and inspection, use the detaching procedure in reverse.

The part Nos. and symbols in Table 5–3 and Table 5–4 correspond to Fig. 5–3.



Check to see that the packing has not been torn or peeled off when the cover was mounted/removed. If it has been torn or peeled off, please contact your nearest Mitsubishi Electric System & Service office (please refer to the back side of this Standard Specifications Manual for the contact information). If the cover is used with the packing torn or peeled off, oil mist and other substances may enter inside the arm and cause a malfunction.

## 5.3.3 Packing Replacement Procedure

The packing gets deteriorated with the passage of time and must be replaced as required. Table 5-5 provides guidelines for replacing the packing. Replace the packing in accordance with the instructions given below. If the packing is not replaced in a timely manner, water or oil will be allowed to intrude the robot, possibly making it inoperative.

| Service environment | Whether or not robot is pressurized | When packing must be replaced                                    |  |  |
|---------------------|-------------------------------------|--|--|--|
| General environment | Not pressurized Note1)              |  |  |  |
| Clean room          | Not pressurized Note1)              | When signs of cracking or peeling are noted in the packing.      |  |  |
| Oil mist            | Pressurized                         |  |  |  |
|                     | Not pressurized                     | When the cover mounted on the robot is removed/put back in place |  |  |

Table 5-5 : Packing replacement guideline

Note1) When used in the "general" or "clean room" environment, robot can do away with pressurization.

## (1) Packing Replacement Instructions

Stick again new packing as before.

- 1) Remove the old packing, and clean and degrease the surface on which it has been placed.
- 2) The sticking surface of packing is double-coated adhesive tape. Referring to "Fig.5-4 : Example of sticking packing (good example)" and "Fig.5-6: Sticking the cord-like packing", and stick the packing in line with form . Be careful for the packing not to slide. The example of unsuitable packing slid is shown in "Fig.5-5 : Example of sticking packing (bad example)".
- 3) Some of the packing are to be stuck to the robot body; others, to the robot cover. The location of sticking the packing is shown in "Table 5-3 : Cover and Packing names'
- 4) Although the CONBOX cover, shoulder cover and No. 1 arm cover (L) sticks two or more packings per place, it has length with which packing ends overlap. Stick packing in the following procedures. For more information, see "Fig.5-7: Examples of packing overlaps". Examples of improperly treated cut edge are shown, as well.
  - a) Stick packing in line with form of the sticking surface. Finally, cut packing so that adjoining pieces have a 1mm overlap at the end.
  - b) Apply liquid gasket to the cut edges. (Designated liquid gasket: 1212 (Maker: Three Bond))
  - c) Stick so that the gap may not be made to each other's packing.



CAUTION Do not install the cover immediately after sticking packing. Install the cover, after the 6 hours pass after sticking packing for gasket hardening.

5) Confirm that packing is stuck correctly and install the cover. When tightening the bolts fixing the cover, avoid tightening them to a specified torgue at a time. Tighten the bolt in the order shown as much as possible in the "Fig. 5-10: Example of order which tighten bolts." The torque which tightens the fixing bolt of each cover is shown in "Table 5-3 : Cover and Packing names".



Stick the packing securely, pressing down with the finger. If sticking is insufficient, when the cover is installed, packing slides by the pressure, and there is a possibility that it may become impossible to secure protection performance.

Completion of packing replacement



Fig.5-4 : Example of sticking packing (good example)







Fig.5-5 : Example of sticking packing (bad example)




5-60 Maintenance and inspection procedures





- [1] Cut the packing so that there is a 1mm overlap at the end.
- [2] Apply liquid gasket to the cut edges.



[3] Stick the packing so that there is no gap between the adjacent pieces.




Fig.5-7 : Examples of packing overlaps




Fig.5-8 : Example of order which tighten bolts

#### 5.3.4 Inspection, maintenance and replacement of timing belt

This robot uses a timing belt for the drive conveyance system of the J5 axis. Compared to gears and chains, the timing belt does not require lubrication and has a low noise. However, if the belt usage method and tension adjustment are inadequate, the life could drop and noise could be generated. Sufficient aging to remove the initial elongation of the belt, and adjustment of the belt tension have been carried out before shipment from the factory. However, depending on the robot working conditions, elongation will occur gradually over a long time. The tension must be confirmed during the periodic inspection. The timing belt must be replaced in the following cases. In addition, it is serviceable if there is the sound wave type belt tension gauge in inspection and adjustment of the timing belt. The recommendation gauge is shown below. Please prepare by customer. Refer to the Page 65, "(3) Timing belt tension" for the tension adjustment value of the timing belt.

Maker:Gates Unitta Asia Company, Type:U-505

#### (1) Timing belt replacement period

The timing belt life is greatly affected by the robot working conditions, so a set time cannot be given. However, if the following symptoms occur, replace the belt.

- 1) When cracks from at the base or back of the belt teeth.
- 2) When the belt expands due to adherence of oil, etc.
- 3) When the belt teeth wear (to approx. half of the tooth width).
- 4) When the belt teeth jump due to belt teeth wear.
- 5) When the belt snaps.



Due to the manufacturing of the timing belt, initial wear will occur. Wear chips may accumulate in the cover after approx. 300 Hr of operating the robot, but this is not a fault. If the wear chips appear soon after wiping them off, replace the belt.

# 

When the belt is replaced, the machine system origin may deviate. In this case, the position data must be reviewed.

(2) Inspection, maintenance and replacement of J5-axis timing belt




Fig.5-9 : Inspection, maintenance and replacement of J5-axis timing belt

Inspecting the J5 axis timing belt

- 1) Confirm that the robot controller power is OFF.
- 2) Refer to Page 57, "5.3.2 Installing/removing the cover", and remove the No. 2 arm cover A.
- 3) Visually confirm that the symptoms indicated in "(1)Timing belt replacement period" have not occurred with the timing belt.
- 4) Confirm that the belt tension is adjusted to slacken approx. 2.3mm when the center of the belt is lightly pressed with a finger (approx. 1.3N) as shown in "Fig.5-10 : Belt tension".
- Adjusting the J5 axis timing belt
  - 1) Carry out steps "1)" and "2)" indicated in " Inspecting the J5 axis timing belt" above.
  - 2) Lightly loosen the two motor installation bolts  $\langle 1 \rangle$ . (Do not loosen too much.)
  - 3) Move the motor <3> in the directions of the arrows shown in Fig. 5-9, using the tension adjustment screw while checking the tension of the timing belt <2>. Lightly pushing the center of the belt with your finger (approximately 1.3 N), move the motor to the position where the belt flexes about 2.3 mm.
  - 4) The belt tension will increase when moved in the direction of arrow "a", and will decrease when moved in the direction of arrow "b".
  - 5) If the belt is loosened too much when adjusting the tension causing it to come off the timing pulleys <4> and <5>, or if the belt and pulley teeth engagement is deviated, the machine system's origin will deviate.
  - 6) After adjusting, securely tighten the two motor installation bolts <1>. Improper tightening can cause the belt to loosen with vibration.
- Replacing the J5 axis timing belt
  - 1) Fig. 5-9 shows the methods for inspecting, adjusting and replacing the timing belt.
  - Move the robot posture with the teaching pendant so that the J5 axis may be downward.(Turn it to the direc<sup>−</sup> tion of gravity.)
  - 3) Make sure that the pulleys do not move while replacing the belt.
  - 4) If the pulley <4> and <5> position relation deviates, the position could deviate.
  - 5) Make marks on the timing belt <2> and timing pulleys <4> and <5> with a felt-tip pen as shown in Fig. 5-9 so that the engagement of the timing belt <2> and timing pulleys <4> and <5> does not deviate.
  - 6) Loosen the two motor installation screws  $\langle 1 \rangle$ , and remove the belt.
  - 7) Copy the marks onto the new timing belt. Make sure that both belts are tense when making the marks.
  - 8) Align the new timing belt with the marks on the timing pulleys  $\langle 4 \rangle$  and  $\langle 5 \rangle$ , and install.

  - 10) The position could deviate after the belt is replaced. Confirm that the position has not deviated. If deviated, refer to Page 75, "5.6 Resetting the origin", and reset the origin position.

# (3) Timing belt tension

| f : Pressing force s : Span d : Slack T : Tension |           |                |                          |   |  |  |
|---|-----------|----------------|--------------------------|---|--|--|
| Axis  | Belt type | Span : s (mr   | m)                       |   |  |  |
| J5  | 393-3GT-4 | 145            |                          |   |  |  |
| ■ Inspection<br>Tension : T (N) Slack : d (mm)    |           | Slack : d (mm) | Pressing force : f (N)   |   |  |  |
| 9.8 or more and 30 or less                        |           | 2.3            | 0.7 or more and 2or less |   |  |  |
| Adjustme  | ent       |                |                          | - |  |  |
| Tension : T (N) Slack :                           |           | lack:d (mm)    | Pressing force : f (N)   |   |  |  |
| 19.6  |           | 2.3            | 1.3                      |   |  |  |
| ■ Exchange (New article installation)             |           |                |                          |   |  |  |
| Tension : T (N)     Slack : d (mm)                |           | ack : d (mm)   | Pressing force : f (N)   |   |  |  |
| 28 2.3  |           | 0.0            | 1.9                      |   |  |  |

Fig.5-10 : Belt tension

The timing belt can satisfactorily convey the drive and keep a durable force only when it has an adequate tension. The belt tension should not be too tight or too lose. Instead, it should be adjusted to a degree that elasticity is felt when the belt is pressed with the thumb. If the belt tension is too weak, the belt loosening side will vibrate. On the other hand, if the belt tension is too strong, a sharp sound will be heard and the belt tension side will vibrate. The detailed adjustment (tension) is shown in Fig. 5-10.

Check and adjust with the belt pressing force f and the slack amount d between span s.

### 5.3.5 Lubrication

(1) Lubrication position and specifications




Fig.5-11 : Lubrication positions

Table 5-6 : Lubrication specifications

| No. | Parts to be lubricated  | Oiling method           | Lubrication oil<br>(maker)      | Default charge<br>amount    | Lubrication<br>interval | Lubrication<br>amount | Cover to remove  |  |
|-----|-------------------------|-------------------------|---------------------------------|-----------------------------|-------------------------|-----------------------|------------------|--|
| 1   | J1 axis reduction gears |                         | Grease<br>Harmonic grease SK-1A | 66ml(60g)                   | 6000Hr                  | 14ml(13g)             | Shoulder cover B |  |
| 2   | J2 axis reduction gears | Grease nipple<br>WA-610 |                                 | 66ml(60g)                   |                         | 14ml(13g)             | No.1 arm cover   |  |
| 3   | J3 axis reduction gears |                         |                                 | 43ml(40g)                   |                         | 7.6ml(7g)             | No.1 arm cover   |  |
| 4   | J4 axis reduction gears | Grease nipple<br>WB-610 | Grease nipple                   | (Japan Harmonic<br>Systems) | 16g                     | 0000111               | 4g               |  |
| 5   | J5 axis reduction gears |                         | Gystellis/                      | 11ml(10g)                   |                         | 1.6ml(1.5g)           | Wrist cover      |  |
| 6   | J6 axis reduction gears |                         |                                 | 11ml(10g)                   |                         | 1.6ml(1.5g)           | Wrist cover      |  |

The lubrication specifications for each place are shown in Fig. 5-6.

[Caution]

- The "Lubrication interval" in Table 5-6 is usually based on the three-year inspection. 8Hr x 20 days x 36 months = 6,000 Hr.
- Depending on the robot operation state, the lubrication time will fluctuate, so determine the time according to the state so that the grease does not run out.
- With the maintenance forecast function of the personal computer support software (option), the guidance of lubrication time is calculated according to the operating environment of the customer.
- The numbers in the Table 5–6 correspond to the supply positions in Fig. 5–11.
- •Avoid excessive lubrication since it may lead to grease leak. Also, the number of lubrications is limited to 3 times.

### (2) Lubrication method

- 1) Set the robot to the posture shown in Fig. 5-11.
- 2) Refer to the Page 57, "5.3.2 Installing/removing the cover" and remove the covers.
- 3) Remove the drain bolt or plug.
- 4) Insert the grease shown in Table using a grease gun from the lubrication grease nipple.
- 5) IInstall the drain bolt or plug.
- 6) Replace the covers with the removal procedure in reverse.



Use manual grease gun, and inject grease with pressure 0.03Mpa or less. Do not use the grease gun, which derived by the factory air presser to avoid injecting by too high pressure.

### 5.3.6 Stopper exchange

The resin stopper is installed in the J1 axis – the J3 axis. This is the incorrect setup of the origin etc. and is for absorbing the energy at clashing with the mechanical stopper. Please exchange, if it clashes with the mechanical stopper and the resin stopper is damaged.




Fig.5-12 : Stopper installation position

### 5.3.7 Replacing the backup battery

An absolute encoder is used for the position detector, so the position must be saved with the backup battery when the power is turned OFF. The controller also uses a backup battery to save the program, etc. These batteries are installed when the robot is shipped from the factory, but as these are consumable parts, they must be replaced periodically by the customer.

The guideline for replacing the battery is one year, but this will differ according to the robot's usage state.

Error No. 7520 :Battery consumption time is over Error No. 133n :Encoder battery voltage low. (n indicates the axis number.) (The encoder battery voltage of the robot arm is low.)

Error No. 7510 :Battery voltage low (R/C)

(The battery voltage of the controller is low.)

Error No. 7500 :No battery voltage

(The battery of the controller is depleted.)



If error No. 7500 occurs, the program data and other data in the controller is lost and it becomes necessary to load the data again.

If any of the battery-related errors above occur and the robot continues to be used, the data integrity of the memory cannot be guaranteed. If an error occurs, replace the batteries of both the robot arm and controller promptly.

It is also recommended to save programs and position data on the personal computer side via the personal computer support software and so forth in advance.

### (1) Replacing the robot arm battery



Don't disconnect connector, etc. While replacing the battery, the encoder position data is saved by the power supplied from the controller. Thus, if the cable connection is incomplete, the encoder position data will be lost when the controller power is turned OFF. Several batteries are used in the robot arm, but replace all old batteries with new batteries at the same time.




Fig.5-13 : Replacing the battery

- 1) Confirm that the robot arm and controller are connected with a cable.
- 2) Turn the controller control power ON.

The position data is retained by the power supplied from the controller while replacing the battery. Thus, if the cable is not connected correctly, or if the controller power is OFF, the position data will be lost.

- 3) Press the emergency stop button to set the robot in the emergency stop state. This is a measure for safety, and must always be carried out.
- 4) Remove the two installation screws  $\langle 2 \rangle$ , and remove the battery cover  $\langle 1 \rangle$ .
- 5) The battery holder is located in the connector box <3>. Remove the old battery from the holder, and disconnect the lead connector.
- 6) Insert the new battery into the holder, and connect the lead connector. Replace all batteries with new ones at the same time.
- 7) All the batteries should check that it has been exchanged newly. If the old battery is contained, generating heat and damaging may occur.
- 8) Install battery cover <1>.
- 9) Initialize the battery consumption time.

Always carry out this step after replacing the battery, and initialize the battery usage time. Refer to the separate "Instruction Manual/Detailed Explanation of Functions and Operations" for details on the operation methods.

[Caution] If the old battery is replaced because it has been used up, it is necessary to set the origin again. Refer to Page 75, "5.6 Resetting the origin" and reset the origin using the jig methodor ABS origin method.

# 5.4 About Overhaul

Robots which have been in operation for an extended period of time can suffer from wear and other forms of deterioration. In regard to such robots, we define overhaul as an operation to replace parts running out of speci<sup>-</sup> fied service life or other parts which have been damaged, so that the robots may be put back in shape for contin<sup>-</sup> ued use. Overhaul interval for robots presumably varies with their operating conditions and thus with the degree of the equipment's wear and loss of performance. As a rule of thumb, however, it is recommended that overhaul be carried out before the total amount of servo-on time reaches the predetermined levels (24,000 hours for the robot body and 36,000 hours for the controller). (See Fig. 5–14.) For specific information about parts to be replaced and timing of overhaul, contact your local service representative.




Fig.5-14 : Periodic inspection/overhaul periods

# 5.5 Maintenance parts

The consumable parts that must be replaced periodically are shown in Table 5–7, and spare parts that may be required during repairs are shown in Table 5–9. Purchase these parts from the dealer when required. Some Mit-subishi-designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and con-troller serial No. and purchase the parts from the dealer.

Table 5-7 : Consumable part list

| No. | Part name       | Type <sup>Note1)</sup> Usage place |                              | Q'ty      | Supplier            |
|-----|-----------------|------------------------------------|------------------------------|-----------|---------------------|
| 1   | Timing belt     |                                    | J5 axis                      | 1         |                     |
| 2   | Grease          | SK-1A                              | Reduction gears of each axis | An needed | Mitsubishi Electric |
| 3   | Lithium battery | A6BAT                              | In battery cover             | 5         |                     |

Note1)Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

| No.   | part name   | Details of configuration    |                | Usage place       |            |                |
|---|---|-----------------------------|----------------|-------------------|------------|----------------|
|   | part name   | Packing name                | Qty.           | Cover name        | Qty.       | Sticking side  |
| RV-65   | SD/6SDC   |                             |                |                   |            |                |
| 1   | Shoulder cover packing                                | Shoulder cover packing A    | 2              | Shoulder cover    | 1          | Cover side     |
| Part Code : K07S24317151                              |   | Shoulder cover packing B    | 2              | Shoulder cover    | 1          | Cover side     |
| 2   | Elbow cover packing<br>Part Code:K07S24344901         | Elbow cover packing         | 1              | Elbow cover A     | 1          | Cover side     |
| 3   | No.2 arm cover packing                                | No.2 arm cover packing      | 1              | No. 2 arm cover A | 1          | Cover side     |
|   | Part Code : K07S24342001                              |                             | '              | No. 2 arm cover B | 1          | Cover side     |
| 4   | No.1arm cover packing                                 | No.1arm cover packing A     | 1              |                   | 1          | Robot arm side |
|   | Part Code : K07S24317251                              | No.1arm cover packing B     | 1              | No. 1 arm cover   | 1          | Robot arm side |
|   |   | No.1arm cover packing C     | 2              |                   | 2          | Robot arm side |
| 5   | Wrist cover packing<br>Part Code : K07S24401602       | Wrist cover packing         | 1              | Wrist cover       | 1          | Robot arm side |
| 6   | No.2 arm cover C packing<br>Part Code:K07S24401502    | No.2 arm cover C packing    | 1              | No. 2 arm cover C | 1          | Robot arm side |
| 7   | Base Packing  | Conbox cover packing A      | 1              | CONBOX cover      | 1          | Robot arm side |
|   | Part Code : K07S24345651                              | Conbox cover packing B      | 1              | CONBOX COVE       | 1          | Robot arm side |
|   |   | Base bottom cover packing A | 1              | Bottom plate      | 1          | Robot arm side |
|   |   | Base bottom cover packing B | 1              | Bottom plate      | 1          | Robot arm side |
| 8   | Battery bracket packing<br>Part Code : K07S24412401   | Battery bracket packing     | 1              | Battery cover     | 1          | Cover side     |
| 9   | Shoulder cover B packing<br>Part Code : K07S24319401  | Shoulder cover B packing    | 1              | Shoulder cover B  | 1          | Robot arm side |
| RV-65   | SDL/6SDCL   |                             |                |                   |            |                |
| 10 Shoulder cover packing<br>Part Code : K07S24317151 | Shoulder cover packing A                              | 2                           | Shoulder cover | 1                 | Cover side |                |
|   | Part Code : K07S24317151                              | Shoulder cover packing B    | 2              | Shoulder cover    | 1          | Cover side     |
| 11  | Elbow cover packing<br>Part Code:K07S24344901         | Elbow cover packing         | 1              | Elbow cover A     | 1          | Cover side     |
| 12  | No.2 arm cover packing                                | No.2 arm cover packing      | 1              | No. 2 arm cover A | 1          | Cover side     |
|   | Part Code : K07S24342001                              |                             | 1              | No. 2 arm cover B | 1          | Cover side     |
| 13  | No.1arm L cover packing                               | No.1 arm L cover packing A  | 1              | No. 1 arm cover   | 1          | Robot arm side |
|   | Part Code : K07S24322451                              | No.1 arm L cover packing B  | 1              |                   | 1          | Robot arm side |
|   |   | No.1 arm L cover packing C  | 2              |                   | 2          | Robot arm side |
| 14  | Wrist cover packing<br>Part Code : K07S24401602       | Wrist cover packing         | 1              | Wrist cover       | 1          | Robot arm side |
| 15  | No.2 arm cover C packing<br>Part Code:K07S24401502    | No.2 arm cover C packing    | 1              | No. 2 arm cover C | 1          | Robot arm side |
| 16  | Base Packing<br>Part Code : K07S24345651              | Conbox cover packing A      | 1              |                   | 1          | Robot arm side |
|   |   | Conbox cover packing B      | 1              | CONBOX cover      | 1          | Robot arm side |
|   |   | Base bottom cover packing A | 1              | Pottom plata      | 1          | Robot arm side |
|   |   | Base bottom cover packing B | 1              | Bottom plate      | 1          | Robot arm side |
| 17  | Battery bracket packing<br>Part Code : K07S24412401   | Battery bracket packing     | 1              | Battery cover     | 1          | Cover side     |
| 18  | Shoulder cover B packing<br>Part Code : K07S24319401  | Shoulder cover B packing    | 1              | Shoulder cover B  | 1          | Robot arm side |
| 19  | Joint arm cover U packing<br>Part Code : K07S24430301 | Joint arm cover U packing   | 1              | Joint arm cover U | 1          | Robot arm side |
| 20  | Joint arm cover R packing<br>Part Code : K07S24430401 | Joint arm cover R packing   | 1              | Joint arm cover R | 1          | Robot arm side |

# Table 5-8 : Consumable part (packing) list

### Table 5-9 : Spare parts list

| No. | Names                    | Usage place   | Q'ty   | Supplier            |
|-----|--------------------------|---------------|--------|---------------------|
| 1   | AC servo motor           | J1 axis       | 1      |                     |
| 2   |                          | J2 axis       | 1      |                     |
| 3   |                          | J3 axis       | 1      |                     |
| 4   |                          | J4 axis       | 1      |                     |
| 5   |                          | J5 axis       | 1      |                     |
| 6   |                          | J6 axis       | 1      |                     |
| 7   | Resin stopper            | J1 to J3 axis | 2/axis |                     |
| 8   | Reduction gears (RV-6SD/ | J1 axis       | 1      |                     |
| 9   | 6SDLC)                   | J2 axis       | 1      |                     |
| 10  |                          | J3 axis       | 1      | Mitsubishi Electric |
| 11  |                          | J4 axis       | 1      |                     |
| 12  |                          | J5 axis       | 1      |                     |
| 13  |                          | J6 axis       | 1      |                     |
| 14  | Reduction gears(RV-6SD/  | J1 axis       | 1      |                     |
| 15  | 6SDLC)                   | J2 axis       | 1      |                     |
| 16  |                          | J3 axis       | 1      | ]                   |
| 17  |                          | J4 axis       | 1      | ]                   |
| 18  |                          | J5 axis       | 1      | ]                   |
| 19  |                          | J6 axis       | 1      | ]                   |

# 5.6 Resetting the origin

The origin is set so that the robot can be used with a high accuracy. After purchasing the robot, always carry out this step before starting work. The origin must be reset if the combination of robot and controller being used is changed or if the motor is changed causing an encoder area. The types of origin setting methods are shown in Table 5-10.

[Caution] If the old battery is replaced because it has been used up, it is necessary to set the origin again.Reset the origin using the jig method or ABS origin method.

| No | Method                      | Explanation  | Remarks  |
|----|-----------------------------|--|--|
| 1  | Origin data input<br>method | The origin data set as the default is input from the T/B.                                      | The setting method is explained in Page 18, "2.4 Setting the origin" .   |
| 2  | Jig method                  | The origin posture is set with the calibration jig installed.                                  | The setting method is explained in Page 76, "5.6.1 Jig method" .   |
| 3  | ABS origin method           | This method is used when the encoder backup<br>data lost in the cause such as battery cutting. | Before using this method, the origin must be set with the<br>other method with same encoder. The setting method is<br>explained in Page 89, "5.6.2 ABS origin method". |
| 4  | User origin method          | A randomly designated position is set as the origin posture.                                   | The setting method is explained in Page 91, "5.6.3 User origin method".  |

Table 5-10 : Origin setting method

Note) Although "Origin setting" by the mechanical stopper method can also be selected, it is not recommended for this robot. Please use one of the methods listed in Table 5–10.

### 5.6.1 Jig method

This method is using the origin setting tool. If the origin setting tool is required, please ask nearby dealer. The reference figure of the origin setting tool is shown in Fig. 5-15.




Fig.5-15 : Reference dimension of origin setting tool

The procedure of setting the origin with the origin setting tool is shown below.

### Carry out this method for each axis.


First, set each axis by the origin position. There are the method of releasing the brake and adjusting with the origin position manually and the method of adjusting with the origin position by jog feed. Here, explain operation by brake release.


Then, do origin setting operation and set up the origin.



To ensure safety, the brake-release procedure described below should always be done by two persons.

This operation is carried out with the teaching pendant. Set the [MODE] switch on the front of the controller to "MANUAL", and set the [ENABLE] switch on the teaching pendant to "ENABLE" to enable the teaching pendant. Do the following operations, pressing down the enabling switch of T/B lightly.






### $\diamondsuit \blacklozenge \diamondsuit$ Release the brake $\diamondsuit \blacklozenge \diamondsuit$

Do cursor movement into the parenthesis of each axis by the arrow key. The brakes can be released only for the axis for which a "1" is displayed on the screen. If the brakes are not to be released, press the [0] key and display a "0". If the [F1] key on the teaching pendant or the enabling switch is detached while the brakes are released, the brakes will be work immediately.

# $\diamond igodsim \diamond$ Select the axis of origin setting $\diamond igodsim \diamond$

Do cursor movement into the parenthesis of each axis by the arrow key. The origin is set only for the axis for which a  $1^{''}$  is displayed on the screen. If the origin is not to be set, press the [0] key and display a  $0^{''}$ .


(2) J2 axis origin setting



- 1) Press the [4] key on the menu screen, and dis<sup>-</sup> play the Origin/Break selection screen.
- 2) Press the [2] key , and display the Break release selection screen.
- Release the brake of the J2 axis. Input "1" into the J2 axis. Set "0" to other axes.
- 4) Confirm the axis for which the brakes are to be released.
- 5) One worker must securely support the upper arm with both hands.
- 6) Pressing the [F1] key is kept with the enabling switch of T/B pressed down. The brake is released while pressing the key.
- 7) Move the J2 axis slowly toward the front using both hands. Align the pinhole of the No.1 arm and the pinhole at the base section, feed through the origin jig ( $\phi$  8) into the pinholes and fasten.

For safety purposes, the step for releasing the brakes must be carried out by two workers. One worker must operate the T/B, and the other must support the arm. When the brakes are released, the robot arm could drop by its own weight depending on the posture.

**CAUTION** If [F1] key or enable switch of T/B is released, the brakes will be work immediately.




 $\diamond \blacklozenge \diamond$  Release the brake  $\diamond \blacklozenge \diamond$ 


Do cursor movement into the parenthesis of each axis by the arrow key. The brakes can be released only for the axis for which a "1" is displayed on the screen. If the brakes are not to be released, press the [0] key and display a "0". If the [F1] key on the teaching pendant or the enabling switch is detached while the brakes are released, the brakes will be work immediately.

### $\diamond igodsim \diamond$ Select the axis of origin setting $\diamond igodsim \diamond$

Do cursor movement into the parenthesis of each axis by the arrow key. The origin is set only for the axis for which a  $1^{''}$  is displayed on the screen. If the origin is not to be set, press the [0] key and display a  $0^{''}$ .

(3) J3 axis origin setting






 $\diamond \blacklozenge \diamond$  Release the brake  $\diamond \blacklozenge \diamond$ 


Do cursor movement into the parenthesis of each axis by the arrow key. The brakes can be released only for the axis for which a "1" is displayed on the screen. If the brakes are not to be released, press the [0] key and display a "0". If the [F1] key on the teaching pendant or the enabling switch is detached while the brakes are released, the brakes will be work immediately.

# $\diamond igodsim \diamond$ Select the axis of origin setting $\diamond igodsim \diamond$

Do cursor movement into the parenthesis of each axis by the arrow key. The origin is set only for the axis for which a "1" is displayed on the screen. If the origin is not to be set, press the [0] key and display a "0".


(4) J4 axis origin setting





- 1) Press the [4] key on the menu screen, and dis<sup>-</sup> play the Origin/Break selection screen.
- 2) Press the [2] key , and display the Break release selection screen.
- Release the brake of the J4 axis. Input "1" into the J4 axis. Set "0" to other axes.
- 4) Confirm the axis for which the brakes are to be released.
- 5) One worker must securely support the upper arm with both hands.
- Pressing the [F1] key is kept with the enabling switch of T/B pressed down. The brake is released while pressing the key.
- 7) Slowly rotate the J4 axis in the direction of minus with both hands. Align the pinholes of the No. 1 arm and shoulder, feed through the origin jig ( $\phi$  6) into the pinholes and fasten.

 B) Detach the [F1] key and work the brake. Press the [F4] key and return to the origin / brake screen.




 $\diamondsuit \blacklozenge \diamondsuit$  Release the brake  $\diamondsuit \blacklozenge \diamondsuit$ 

Do cursor movement into the parenthesis of each axis by the arrow key. The brakes can be released only for the axis for which a "1" is displayed on the screen. If the brakes are not to be released, press the [0] key and display a "0". If the [F1] key on the teaching pendant or the enabling switch is detached while the brakes are released, the brakes will be work immediately.


### $\diamond igodot \diamond$ Select the axis of origin setting $\diamond igodot \diamond$

Do cursor movement into the parenthesis of each axis by the arrow key. The origin is set only for the axis for which a "1" is displayed on the screen. If the origin is not to be set, press the [0] key and display a "0".



# **CAUTION** For safety purposes, the step for releasing the brakes must be carried out by two workers. One worker must operate the T/B, and the other must support the arm. When the brakes are released, the robot arm could drop by its own weight depending on the posture.

# **CAUTION** If [F1] key or enable switch of T/B is released, the brakes will be work immediately.




 $\diamond \blacklozenge \diamond$  Release the brake  $\diamond \blacklozenge \diamond$ 

Do cursor movement into the parenthesis of each axis by the arrow key. The brakes can be released only for the axis for which a "1" is displayed on the screen. If the brakes are not to be released, press the [0] key and display a "0". If the [F1] key on the teaching pendant or the enabling switch is detached while the brakes are released, the brakes will be work immediately.

# $\diamond \blacklozenge \diamond$ Select the axis of origin setting $\diamond \blacklozenge \diamond$


Do cursor movement into the parenthesis of each axis by the arrow key. The origin is set only for the axis for which a "1" is displayed on the screen. If the origin is not to be set, press the [0] key and display a "0".

(6) J6 axis origin setting



- 1) Install the bolts (two M5 bolts prepared by customer) at opposing positions on the mechanical interface.
- 2) Press the [4] key on the menu screen, and dis<sup>-</sup> play the Origin/Break selection screen.
- 3) Press the [2] key , and display the Break release selection screen.
- Release the brake of the J6 axis. Input "1" into the J6 axis. Set "0" to other axes.
- 5) Confirm the axis for which the brakes are to be released.
- Pressing the [F1] key is kept with the enabling switch of T/B pressed down. The brake is released while pressing the key.
- 7) Hold the bolts mounted in step "1)" above with hands, rotate them slowly and align the ABS mark of the J6 axis with the ABS mark of the wrist area.

 B) Detach the [F1] key and work the brake. Press the [F4] key and return to the origin / brake screen.



# $\diamond \blacklozenge \diamond$ Release the brake $\diamond \blacklozenge \diamond$

Do cursor movement into the parenthesis of each axis by the arrow key. The brakes can be released only for the axis for which a "1" is displayed on the screen. If the brakes are not to be released, press the [0] key and display a "0". If the [F1] key on the teaching pendant or the enabling switch is detached while the brakes are released, the brakes will be work immediately.

# $\diamond \blacklozenge \diamond$ Select the axis of origin setting $\diamond \blacklozenge \diamond$

Do cursor movement into the parenthesis of each axis by the arrow key. The origin is set only for the axis for which a "1" is displayed on the screen. If the origin is not to be set, press the [0] key and display a "0".

### 5.6.2 ABS origin method

When the origin setting of the robot is performed for the first time, this product records the angular position of the origin within one rotation of the encoder as the offset value. If the origin setting is performed according to the ABS origin method, this value is used to suppress variations in the origin setting operations and to reproduce the initial origin position accurately.

This operation is carried out with the teaching pendant. Set the [MODE] switch on the front of the controller to "MANUAL", and set the [ENABLE] switch on the teaching pendant to "ENABLE" to enable the teaching pendant. First, set to the ABS mark arrow of the axis for which the origin is to be set with jog operation. This can be set for all axes simultaneously or each axis independently.

When setting the ABS mark, always view the operations from the mark, and set at the end of the triangular mark. The positions where the ABS mark is attached are shown in below. Refer to Page 24, "2.5 Confirming the operation" for details on the jog operation.

Note that if the ABS marks are peeled off, the positions can be matched using the following alternative methods. \*Match the ruling lines of the ABS mark mounting position surfaces. In this case, the installing and removing of the cover are unnecessary.




Fig.5-16 : ABS mark attachment positions

The procedures for setting the origin with the ABS method are explained below.

个

F1

1 '()

CLOSE

No

0

0

CL OSF

) )

J3:(

) J6: (

123

123

0

0

123

CHANGE TO ORIGIN. OK?

J2

J5 J8

 $\rightarrow$ 

EXE

(1) Select the T/B

J4: ( J7: (

REL

Yes


<ABS> J1:

J4: J7:

RF

C

<ORIGIN> ABS



- 1) Press the [4] key on the menu screen, and dis<sup>-</sup> play the Origin/Break selection screen.
- 2) Press the [1] key , and display the Origin setting selection screen.
- 3) Press the [4] key , and display the ABSI selec<sup>-</sup> tion screen.

- 4) Input "1" into the axis to origin setting. Press the [EXE] key , and display Confirmation screen.
- 5) Press the [F1] key , and the origin position is set up.

This completes the setting of the origin with the ABS method.

### 5.6.3 User origin method



A CAUTION Before using this method, the origin must be set with the other method. The setting method is explained in Page 75, "Table 5-10 : Origin setting method".

The procedure for setting the origin with the user origin method is explained below.

This operation is carried out with the teaching pendant. Set the [MODE] switch on the front of the controller to "AMNUAL", and set the [ENABLE] switch on the teaching pendant to "ENABLE" to enable the teaching pendant. The operation method is shown below.

When setting the origin for the first time using this method, carry out the operations in order from step 1). For the second and following time, move the robot arm to the user origin position with jog operation, and accurately position all axes. Then start the procedure from step 4).


1) Determine the user origin position

Move the robot to the position to be set as the origin with jog operation. Refer to Page 24, "2.5 Confirming the operation" for details on the jog operation.



A CAUTION Choose the user origin position as the position where it doesn't move by the gravity. This position is left as a guideline to position all axes with jog operation when setting the origin again with this method.

- 2) Enter the JOINT jog mode, and display the joint coordinates on the teaching pendant screen. Record the value of the axis for which the origin is to be set.
- 3) Input the value recorded in the "user designated origin parameter (USRORG)". The parameter details and input methods are described in the separate "Instruction Manual/Detailed Explanation of Functions and Operations". Refer to that manual and input the user designated origin position.



- 4) Next, set the origin. Display the menu screen.
- 5) Press the [4] key on the menu screen, and dis<sup>-</sup> play the Origin/Break selection screen.
- 6) Press the [1] key , and display the Origin setting selection screen.
- 7) Press the [5] key , and display the User selec<sup>-</sup> tion screen.

| <user>         J1: (       1       ) J2: (       0       ) J3: (       0       )         J4: (       0       ) J5: (       0       ) J6: (       0       )         J7: (       0       ) J8: (       0       )         CLOSE</user> | $ \begin{array}{c}                                     $ | 8) Input "1" into the axis to origin setting. Press<br>the [EXE] key , and display Confirmation screen. |
|---|--|---|
| <origin> user</origin>  |  | 9) Press the [F1] key , and the origin position is set up.  |
| CHANGE TO ORIGIN. OK?   |  |   |
| Yes 123 No  | <b>F1</b>  |   |

This completes the setting of the origin with the user origin method.

### 5.6.4 Recording the origin data

When the origin has been set with the jig method, record that origin data on the origin data label. With this, the ori<sup>-</sup> gin can be set with the origin data input method the next time.

Confirm the origin data on the teaching pendant screen (origin data input screen). The origin data label is enclosed with the arm or attached on the back of the shoulder cover B.

The teaching pendant operation method and shoulder cover B removal method for confirming the origin data is the same as the methods for setting the origin with the origin data input method. Refer to Page 19, "2.4.2 Setting the origin with the origin data input method", and write the origin data displayed on the teaching pendant onto the ori<sup>-</sup> gin label.

### (1) Confirming the origin data label

Remove the shoulder cover B. Refer to Page 57, "5.3.2 Installing/removing the cover", and remove the shoulder cover B.

### (2) Confirming the origin data

Confirm the value displayed on the teaching pendant's Origin Data Input screen. Refer to Page 19, "2.4.2 Setting the origin with the origin data input method", "(5)Inputting the origin data", and display the Origin Data Input screen on the teaching pendant display screen.

### (3) Recording the origin data

Write the origin data displayed on the teaching pendant to the origin data label attached to the back of the shoulder cover B. Refer to Page 19, "Fig.2-14 : Origin data label (an example)", and Page 22, "Fig.2-15 : Correspondence of origin data label and axis" for details on the origin data label.

### (4) Installing the cover

Install the shoulder cover B removed in step "(1)Confirming the origin data label" above. Refer to Page 57, "5.3.2 Installing/removing the cover", and replace the shoulder cover B.

This completes the recording of the origin data.

# 6 Appendix

# Appendix 1 : Configuration flag

The configuration flag indicates the robot posture.

For the 6-axis type robot, the robot hand end is saved with the position data configured of X, Y, Z, A, B and C. However, even with the same position data, there are several postures that the robot can change to. The posture is expressed by this configuration flag, and the posture is saved with FL1 in the position constant (X, Y, Z, A, B, C) (FL1, FL2).

The types of configuration flags are shown below.

### (1) RIGHT/LEFT

P is center of flange in comparison with the plane through the J1 axis vertical to the ground.

Q is center of J5 axis rotation in comparison with the plane through the J1 axis vertical to the ground.




Fig.6-1 : Configuration flag (RIGHT/LEFT)

### (2) ABOVE/BELOW

Q is center of J5 axis rotation in comparison with the plane through both the J3 and the J2 axis.




Fig.6-2 : Configuration flag (ABOVE/BELOW)

### (3) NONFLIP/FLIP

This means in which side the J6 axis is in comparison with the plane through both the J4 and the J5 axis.




Fig.6--3: Configuration flag (NONFLIP/FLIP)



HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 5-1-14, YADA-MINAMI, HIGASHI-KU, NAGOYA 461-8670, JAPAN

Authorised representative: MITSUBISHI ELECTRIC EUROPE B.V. GERMANY Gothaer Str. 8, 40880 Ratingen / P.O. Box 1548, 40835 Ratingen, Germany

May., 2011 MEE Printed in Japan on recycled paper.