# **MITSUBISHI**

# Mitsubishi Industrial Robot

**SQ** Series

RV-18SQ-S/18SQC-S

Special Specifications Manual (CR3Q-709M/CR3Q-709 Controller)

This robot is manufactured with a special specification. When ordering, the details of the specification will be discussed and then determined. The Production Specifications will be submitted separately.



# Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

**⚠** CAUTION

All teaching work must be carried out by an operator who has received special training. (This also applies to maintenance work with the power source turned ON.)

Enforcement of safety training

**⚠** CAUTION

For teaching work, prepare a work plan related to the methods and procedures of operating the robot, and to the measures to be taken when an error occurs or when restarting. Carry out work following this plan. (This also applies to maintenance work

with the power source turned ON.)

Preparation of work plan

**WARNING** 

Prepare a device that allows operation to be stopped immediately during teaching work.

(This also applies to maintenance work with the power source turned ON.)

Setting of emergency stop switch

**A** CAUTION

During teaching work, place a sign indicating that teaching work is in progress on the start switch, etc. (This also applies to maintenance work with the power source turned

ON.)

Indication of teaching work in progress

**⚠** WARNING

Provide a fence or enclosure during operation to prevent contact of the operator and

robot

Installation of safety fence

**A** CAUTION

Establish a set signaling method to the related operators for starting work, and follow

this method.

Signaling of operation start

**A** CAUTION

As a principle turn the power OFF during maintenance work. Place a sign indicating that

maintenance work is in progress on the start switch, etc.

Indication of maintenance work in progress

**A** CAUTION

Before starting work, inspect the robot, emergency stop switch and other related

devices, etc., and confirm that there are no errors.

Inspection before starting work

The points of the precautions given in the separate "Safety Manual" are given below. Refer to the actual "Safety Manual" for details.

| <b>⚠</b> CAUTION | Use the robot within the environment given in the specifications. Failure to do so could lead to a drop or reliability or faults. (Temperature, humidity, atmosphere, noise environment, etc.) |
|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>⚠</b> CAUTION | Transport the robot with the designated transportation posture. Transporting the robot                                                                                                         |

| Always use the robot installed on a secure table. Use in an instable posture could lead to positional deviation and vibration. |
|--------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                |

Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.

| <b>⚠</b> CAUTION | Wire the cable as far away from noise sources as possible. If placed near a noise source, |
|------------------|-------------------------------------------------------------------------------------------|
|                  | positional deviation or malfunction could occur                                           |

| <b>⚠</b> CAUTION | Do not apply excessive force on the connector or excessively bend the cable. Failure to observe this could lead to contact defects or wire breakage. |
|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
|                  |                                                                                                                                                      |

| ∠!\ CAUTION | Make sure that the workpiece weight, including the hand, does not exceed the rated load |
|-------------|-----------------------------------------------------------------------------------------|
|             | or tolerable torque. Exceeding these values could lead to alarms or faults.             |

| /!\WARNING   |                                                                                            |
|--------------|--------------------------------------------------------------------------------------------|
| 213 WARINING | Securely install the hand and tool, and securely grasp the workpiece. Failure to observe   |
|              | this could lead to personal injuries or damage if the object comes off or flies off during |
|              | operation.                                                                                 |

| <u>Z!\</u> WARNING | Securely ground the robot and controller. Failure to observe this could lead to |
|--------------------|---------------------------------------------------------------------------------|
|                    | malfunctioning by noise or to electric shock accidents.                         |

| <b>⚠</b> CAUTION | Indicate the operation state during robot operation. Failure to indicate the state could |
|------------------|------------------------------------------------------------------------------------------|
|                  | lead to operators approaching the robot or to incorrect operation.                       |

| <b>⚠</b> WARNING | When carrying out teaching work in the robot's movement range, always secure the              |
|------------------|-----------------------------------------------------------------------------------------------|
| _                | priority right for the robot control. Failure to observe this could lead to personal injuries |
|                  | or damage if the robot is started with external commands.                                     |

| <b>A</b> CAUTION | Keep the jog speed as low as possible, and always watch the robot. Failure to do so |
|------------------|-------------------------------------------------------------------------------------|
|                  | could lead to interference with the workpiece or peripheral devices.                |

| CAUTION | After editing the program, always confirm the operation with step operation before        |
|---------|-------------------------------------------------------------------------------------------|
|         | starting automatic operation. Failure to do so could lead to interference with peripheral |
|         | devices because of programming mistakes, etc.                                             |

| CAUTION | Make sure that if the safety fence entrance door is opened during automatic operation,       |
|---------|----------------------------------------------------------------------------------------------|
|         | the door is locked or that the robot will automatically stop. Failure to do so could lead to |
|         | personal injuries.                                                                           |

| <b>A</b> CAUTION | Never carry out modifications based on personal judgments, or use non-designated |
|------------------|----------------------------------------------------------------------------------|
|                  | maintenance parts.                                                               |
|                  | Failure to observe this could lead to faults or failures.                        |

# WARNING When the robot arm has to be moved by hand from an external area, do not place hands or fingers in the openings. Failure to observe this could lead to hands or fingers catching depending on the posture.

# **A** CAUTION

Do not stop the robot or apply emergency stop by turning the robot controller's main power OFF. If the robot controller main power is turned OFF during automatic operation, the robot accuracy could be adversely affected. Moreover, it may interfere with the peripheral device by drop or move by inertia of the arm.

# **A** CAUTION

Do not turn off the main power to the robot controller while rewriting the internal information of the robot controller such as the program or parameters. If the main power to the robot controller is turned off while in automatic operation or rewriting the program or parameters, the internal information of the robot controller may be damaged.

# **A** CAUTION

Use the USB devices confirmed by manufacturer. In other case, it might have care difficulty by the effect of temperature, noise and so on. When using it, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm of the operation by the customer

#### ■ Revision history

| Date of print | Specifications No. | Details of revisions |
|---------------|--------------------|----------------------|
| 2009-09-15    | BFP-A8767          | First print          |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |
|               |                    |                      |

#### ■ Introduction

This series is a full-scale industrial vertical multi-joint type robot that is designed for use in machining processes and assembling. This series supports the oil mist environment as standard, offering a variety of specifications including clean specification and long-arm specification.

However, to comply with the target application, a work system having a well-balanced robot arm, peripheral devices or robot and hand section must be structured.

When creating these standard specifications, we have edited them so that the Mitsubishi robot's characteristics and specifications can be easily understood by users considering the implementation of robots. However, if there are any unclear points, please contact your nearest Mitsubishi branch or dealer. Mitsubishi hopes that you will consider these standard specifications and use our robots.

Note that in this specification document the specifications related to the robot arm is described "2 Robot arm" on page 7, the specifications related to the controller" on page 33, and software functions and a command list "4 Software" on page 68 separately.

This document has indicated the specification of the following types robot.

\*RV-18SQ-S \*RV-18SQC-S

- No part of this manual may be reproduced by any means or in any form, without prior consent from Mitsubishi.
- The contents of this manual are subject to change without notice.
- The specifications values are based on Mitsubishi standard testing methods.
- The information contained in this document has been written to be accurate as much as possible. Please interpret that items not described in this document "cannot be performed.". Please contact your nearest dealer if you find any doubtful, wrong or skipped point.
- Microsoft, Windows, Microsoft Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

## Contents

|                                                                                |    | Pa | age |
|--------------------------------------------------------------------------------|----|----|-----|
| 1 General configuration                                                        |    | 1- | -1  |
| 1.1 Structural equipment                                                       |    | 1- | -1  |
| 1.1.1 Standard structural equipment                                            |    |    |     |
| 1.1.2 Special specifications                                                   |    | 1- | -1  |
| 1.1.3 Options                                                                  |    | 1- | -1  |
| 1.1.4 Maintenance parts                                                        | '  | 1- | -1  |
| 1.2 Model type name of robot                                                   |    | 1- | .2  |
| 1.2.1 How to identify the robot model                                          |    |    |     |
| 1.2.2 Combination of the robot arm and the controller                          | '  | 1- | ·2  |
| 1.3 Indirect export                                                            |    | 1- | ·2  |
| 1.4 Instruction manuals                                                        |    | 1- | -2  |
| 1.4.1 Functions                                                                |    | 1- | ·2  |
| 1.5 Contents of the structural equipment                                       |    | 1- | -3  |
| 1.5.1 Robot arm                                                                |    |    |     |
| 1.5.2 Controller                                                               |    | 1- | -4  |
| 1.6 Contents of the Option equipment and special specification                 |    | 1- | -5  |
| 2 Robot arm                                                                    |    | 2- | -7  |
| 2.1 Standard specifications                                                    |    |    |     |
| 2.1.1 The counter-force applied to the installation surface                    |    |    |     |
| 2.2 Definition of specifications                                               |    |    |     |
| 2.2.1 Pose repeatability                                                       |    |    |     |
| 2.2.2 Rated load (mass capacity)                                               |    |    |     |
| 2.2.3 Protection specifications                                                |    |    |     |
| (1) Types of protection specifications                                         |    |    |     |
| (2) About the use with the bad environment                                     |    |    |     |
| 2.2.4 Clean specifications                                                     | 2- | -1 | 3   |
| (1) Types of clean specifications                                              | 2- | -1 | 3   |
| 2.3 Names of each part of the robot                                            | 2- | -1 | 4   |
| 2.4 Outside dimensions • Operating range diagram                               | 2- | -1 | 5   |
| (1) RV-18SQ-S/18SQC-S                                                          | 2- | -1 | 5   |
| 2.5 Tooling                                                                    |    |    |     |
| 2.5.1 Wiring and piping for hand                                               |    |    |     |
| 2.5.2 Internal air piping                                                      |    |    |     |
| (1) Standard type                                                              |    |    |     |
| (2) Clean type                                                                 |    |    |     |
| 2.5.3 Internal wiring for the hand check input cable                           |    |    |     |
| 2.5.4 Internal wiring for the hand check input cable(Standard type/Clean type) |    |    |     |
| 2.5.5 Spare Wiring                                                             |    |    |     |
| 2.5.6 iring and piping system diagram for hand                                 |    |    |     |
| 2.5.7 Electrical specifications of hand input/output                           |    |    |     |
| 2.5.8 Air supply circuit example for the hand                                  |    |    |     |
| 2.6 Options                                                                    |    |    |     |
| (1) Machine cable extension                                                    |    |    |     |
| (2) Changing the operating range                                               |    |    |     |
| (3) Solenoid valve set                                                         |    |    |     |
| (4) Hand input cable                                                           |    |    |     |
| (5) Hand output cable                                                          |    |    |     |
| (6) Hand curl tube                                                             | 2- | -3 | 1   |
| 2.7 Maintenance parts                                                          | 2- | -3 | 2   |
| 3 Controller                                                                   | 3- | -3 | 3   |
| 3.1 Standard specifications                                                    |    |    |     |
| 3.1.1 Standard specifications                                                  |    |    |     |
| 3.1.2 Protection specifications and operating supply                           |    |    |     |
| 3.2 Names of each part                                                         |    |    |     |
| 3.2.1 Names of each part of the drive unit                                     |    |    |     |
| 3.2.2 Padlock specification                                                    |    |    |     |
|                                                                                |    |    |     |

### Contents

|                                                                                     | Page        |
|-------------------------------------------------------------------------------------|-------------|
| 3.2.3 Names of each part of the robot CPU                                           | 3–39        |
| 3.3 Outside dimensions/Installation dimensions                                      | 3-40        |
| 3.3.1 Outside dimensions                                                            | 3–40        |
| 3.3.2 Installation dimensions                                                       | 3-42        |
| (1) Outside dimensions of robot CPU                                                 | 3–44        |
| 3.4 External input/output                                                           | 3–45        |
| 3.4.1 Types                                                                         | 3–45        |
| 3.5 Dedicated input/output                                                          | 3-46        |
| 3.6 Emergency stop input and output etc.                                            | 3–48        |
| 3.6.1 Connection of the external emergency stop                                     | 3–48        |
| 3.6.2 Special stop input(SKIP)                                                      |             |
| 3.6.3 Door switch function                                                          |             |
| 3.6.4 Enabling device function                                                      |             |
| 3.7 Additional Axis Function                                                        |             |
| 3.7.1 Wiring of the Additional Axis Interface                                       |             |
| 3.8 Magnet contactor control connector output (AXMC) for addition axes              | 3–56        |
| 3.9 Options                                                                         |             |
| (1) Teaching pendant (T/B)                                                          |             |
| (2) Pneumatic hand interface                                                        |             |
| (3) RT ToolBox2/RT ToolBox2 mini                                                    |             |
| (4) Instruction Manual(bound edition)                                               |             |
| 3.10 Maintenance parts                                                              | 3–67        |
| 4 Software                                                                          | 4–68        |
| 4.1 List of commands                                                                | 4–68        |
| 4.2 List of parameters                                                              | 4-70        |
| 5 Instruction Manual                                                                | 5-72        |
| 5.1 The details of each instruction manuals                                         | 5-72        |
| 6 Safety                                                                            | 6-73        |
| 6.1 Safety                                                                          |             |
| 6.1.1 Self-diagnosis stop functions                                                 |             |
| 6.1.2 External input/output signals that can be used for safety protection measures |             |
| 6.1.3 Precautions for using robot                                                   | 6–74        |
| 6.1.4 Safety measures for automatic operation                                       | 6–75        |
| 6.1.5 Safety measures for teaching                                                  |             |
| 6.1.6 Safety measures for maintenance and inspections, etc.                         |             |
| 6.1.7 Examples of safety measures                                                   | 6–76        |
| 6.2 Working environment                                                             | 6-82        |
| 6.3 Precautions for handling                                                        |             |
| 7Appendix                                                                           |             |
| Appendix 1 : Specifications discussion material                                     | Appendix-84 |

#### 1 General configuration

#### 1.1 Structural equipment

Structural equipment consists of the following types.

#### 1.1.1 Standard structural equipment

The following items are enclosed as a standard.

- (1) Robot arm
- (2) Controller
- (3) Machine cable
- (4) Robot arm installation bolts
- (5) Arm fixing bolts
- (6) Safety manual, Instruction manual, CD-ROM (Instruction manual)
- (7) Guarantee card

#### 1.1.2 Special specifications

For the special specifications, some standard configuration equipments and specifications have to be changed before factory shipping. Confirm the delivery date and specify the special specifications at the order.

#### 1.1.3 Options

User can install options after their delivery.

#### 1.1.4 Maintenance parts

Materials and parts for the maintenance use.

#### 1.2 Model type name of robot

#### 1.2.1 How to identify the robot model

## RV-18SQ C -Sxx

(a). RV-18SQ.....Indicates the RV-18SQ series.

(b). C ......Indicates environment specification. Examples)

> Blank: Standard Specifications C: Clean Specifications

(c). <u>-SXX</u>......[1] Indicates a special model number. In order, limit special specifica-

#### 1.2.2 Combination of the robot arm and the controller

Table 1-1: Combination of the robot arm and the controller

| Protection specification | Robot arm  | Arm length   | Controller                  |
|--------------------------|------------|--------------|-----------------------------|
| Stardard specification   | RV-18SQ-S  | standard arm | CR3Q-709M <sup>Note1)</sup> |
| Clean specification      | RV-18SQC-S | standard arm | CR3Q-709                    |

Note1)Protection specification. (IP54)

#### 1.3 Indirect export

The display in English is available by setting parameter LNG as "ENG."

#### 1.4 Instruction manuals

The instruction manuals supplied in CD-ROM, except for the Safety Manual. This CD-ROM (electronic manual) includes instruction manuals in both Japanese and English versions.

#### 1.4.1 Functions

This robot is special specification. Some functions are restricted and cannot be used. The restricted functions are shown below.

Table 1-2: Restricted functions

| (1) | (1) MELFA-BASIC V                                              |  |  |  |  |
|-----|----------------------------------------------------------------|--|--|--|--|
|     | 1) Optimum acceleration/deceleration rate specification (Oadl) |  |  |  |  |
|     | 2) Compliance specification (Cmp Pos, Cmp Tool, Cmp Off)       |  |  |  |  |
| (2) | (2) RT ToolBox 2 (optional)                                    |  |  |  |  |
|     | 1) Position recovery support                                   |  |  |  |  |
|     | 2) Resetting maintenance forecast                              |  |  |  |  |
| (3) | (3) Other control functions                                    |  |  |  |  |
|     | 1) Deflection compensation                                     |  |  |  |  |

#### 1.5 Contents of the structural equipment

#### 1.5.1 Robot arm

The list of structural equipment is shown in Fig. 1-1.




Fig.1-1: Structural equipment (Robot arm)

#### 1.5.2 Controller

The devices shown below can be installed on the controller.

The controllers that can be connected differ depending on the specification of the robot.




Fig.1-2: Structural equipment

#### 1.6 Contents of the Option equipment and special specification

A list of all Optional equipments and special specifications are shown below.

Table 1-2: The list of Option equipment and special specification

| Item                                                               | Туре                       | Specifications                                                                                                                                                         | Classificati<br>on <sup>Note1)</sup> | Descripsion                                                          |  |
|--------------------------------------------------------------------|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|----------------------------------------------------------------------|--|
| Stopper for changing the operating range of the J1 axis            | 1S-DH-01                   | Stopper part One each of the following can be selected. + side: +135, +90, or +45 deg side: -135, -90, or -45 deg. ± 170 deg. are used for the standard specification. | 0                                    | This must be installed by the customer.                              |  |
| Extended machine cable                                             | 1S- □□ CBL-02              | For fixing (Set of power, signal and ground)                                                                                                                           | 0                                    | 5, 10, 15m                                                           |  |
|                                                                    | 1D- □□ LCBL-02             | For bending (Set of power, signal and ground)                                                                                                                          | 0                                    | 5, 10, 15m                                                           |  |
| Solenoid valve set                                                 | 1S-VD01-01/<br>1S-VD01E-01 | 1 set (Sink type)/(Source type)                                                                                                                                        | 0                                    |                                                                      |  |
|                                                                    | 1S-VD02-01/<br>1S-VD02E-01 | 2 set (Sink type)/(Source type)                                                                                                                                        | 0                                    | A colonoid value cat for the appropriate hand                        |  |
|                                                                    | 1S-VD03-01/<br>1S-VD03E-01 | 3 set (Sink type)/(Source type)                                                                                                                                        | 0                                    | A solenoid valve set for the pneumatic hand                          |  |
|                                                                    | 1S-VD04-01/<br>1S-VD04E-01 | 4 set (Sink type)/(Source type)                                                                                                                                        | 0                                    |                                                                      |  |
| Hand output cable                                                  | 1S-GR35S-01                | Robot side: connector.<br>Hand side: wire.                                                                                                                             | 0                                    | The cable is connected to the hand output connector by the customer. |  |
| Hand input cable                                                   | 1S-HC25C-01                | Robot side: connector.<br>Hand side: wire.                                                                                                                             | 0                                    | The cable is connected to the sensor by the customer.                |  |
| Hand curl tube                                                     | 1N-ST0602C                 | For solenoid valve 1set.: Φ6x2                                                                                                                                         | 0                                    |                                                                      |  |
|                                                                    | 1N-ST0604C                 | For solenoid valve 2set.: Φ6x4                                                                                                                                         | 0                                    | 2.1.                                                                 |  |
|                                                                    | 1N-ST0606C                 | For solenoid valve 3set.: Φ6x6                                                                                                                                         | 0                                    | Curl type air tube                                                   |  |
|                                                                    | 1N-ST0608C                 | For solenoid valve 4set.:Φ6x8                                                                                                                                          | 0                                    |                                                                      |  |
| Teaching pendant                                                   | R32TB                      | Cable length 7m                                                                                                                                                        | 0                                    |                                                                      |  |
|                                                                    | R32TB-15                   | Cable length 15m                                                                                                                                                       | 0                                    | Milah 2 masiki malasaharan sudash                                    |  |
|                                                                    | R56TB                      | Cable length 7m                                                                                                                                                        | 0                                    | With 3–position deadman switch                                       |  |
|                                                                    | R56TB-15                   | Cable length 15m                                                                                                                                                       | 0                                    |                                                                      |  |
| Pneumatic hand interface                                           | 2A-RZ365                   | DO: 8 point(Sink type)                                                                                                                                                 | 0                                    | It is necessary when the hand output signal of the                   |  |
|                                                                    | 2A-RZ375                   | DO: 8 point(Source type)                                                                                                                                               | 0                                    | robot arm is used.                                                   |  |
| RT ToolBox2<br>(Personal computer Sup-<br>port software)           | 3D-11C-WINE                | CD-ROM                                                                                                                                                                 | 0                                    | MS-Windows2000/XP/Vista<br>(With the simulation function)            |  |
| RT ToolBox2 mini<br>(Personal computer Sup-<br>port software mini) | 3D-12C-WINE                | CD-ROM                                                                                                                                                                 | 0                                    | MS-Windows2000/XP/Vista                                              |  |
| TU cable for robot                                                 | 2Q-TUCBL □ M               | Cable length 05、10、20、30m                                                                                                                                              | 0                                    | For communication between robot CPU and DU.                          |  |
| DISP cable for robot                                               | 2Q-DISPCBL ☐ M             | Cable length 05、10、20、30m                                                                                                                                              | 0                                    | For communication between robot CPU and DU.                          |  |
| EMI cable for robot                                                | 2Q-EMICBL ☐ M              | Cable length 05、10、20、30m                                                                                                                                              | 0                                    | For a robot CPU emergency stop input.                                |  |
| SSCNET III cable for robot                                         | MR-J3BUS □ M-A             | Cable length 05、10、20m                                                                                                                                                 | 0                                    | For the servo communication between robot CPU and                    |  |
|                                                                    | MR-J3BUS30M-B              | Cable length 30m                                                                                                                                                       | 0                                    | DU .                                                                 |  |
| Caster specifications controller                                   | CR3Q-709/709M              | Specifications with casters                                                                                                                                            |                                      | The controller height<br>will be h =615                              |  |
| Instruction Manual                                                 | 5S-QY00-PE01               | RV-18SQ-S/18SQC-S                                                                                                                                                      | 0                                    | A set of the instructions manual bookbinding editions                |  |

Note1) O: option,  $\square$ : special specifications.

[Reference]:The recommendation products of the USB cable are shown below.

Table 1-3: Recommendation article of the USB cable

| Name                                        | Type name      | Supplier                                       |
|---------------------------------------------|----------------|------------------------------------------------|
| USB cable                                   | USB2-30        | ELECOM CO., LTD.                               |
| (USB A type-USB B type)                     | AU230          | BUFFALO KOKUYO SUPPLY INC.                     |
| USB cable                                   | KU-AMB530      | SANWA SUPPLY INC.                              |
| (USB A type-USB mini B type)                | USB-M53        | ELECOM CO., LTD.                               |
|                                             | GT09-C20USB-5P | MITSUBISHI ELECTRIC SYSTEM & SERVICE CO., LTD. |
|                                             | MR-J3USBCBL3M  | MITSUBISHI ELECTRIC CO., LTD.                  |
| USB adapter<br>(USB B type-USB mini B type) | AD-USBBFTM5M   | ELECOM CO., LTD.                               |



Caution

Be careful to the USB cable to apply neither the static electricity nor the noise.

Otherwise, it becomes the cause of malfunction.



Caution

Use the USB devices confirmed by manufacturer. In other case, it might have care difficulty

The state of temperature, noise and so on. When using it, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm the operation by customer

#### 2 Robot arm

#### 2.1 Standard specifications

Table 2-1: Standard specifications of robot

|                                                                    | tem                                                          | Unit      | Specific                                                 | cations                                                |  |
|--------------------------------------------------------------------|--------------------------------------------------------------|-----------|----------------------------------------------------------|--------------------------------------------------------|--|
|                                                                    |                                                              |           | RV-18SQC-S                                               |                                                        |  |
| Туре                                                               |                                                              |           | 6-axis sta                                               |                                                        |  |
| Type of robot                                                      |                                                              |           | Standard                                                 | Clean (Special Specifications)                         |  |
| Degree of freed                                                    |                                                              |           | (                                                        |                                                        |  |
| Installation pos                                                   | ture                                                         |           | On floor                                                 | On floor                                               |  |
| Structure                                                          |                                                              |           | Vertical, multi                                          |                                                        |  |
| Drive system                                                       |                                                              |           | AC servo motor (brake                                    |                                                        |  |
| Position detect                                                    |                                                              |           | Absolute encoder                                         |                                                        |  |
|                                                                    | Shoulder shift                                               |           | 15                                                       |                                                        |  |
|                                                                    | Upper arm                                                    |           | 40                                                       |                                                        |  |
| Arm length                                                         | Fore arm                                                     | mm        | 53                                                       |                                                        |  |
|                                                                    | Elbow shift                                                  |           | 8                                                        |                                                        |  |
|                                                                    | Wrist length                                                 |           | 9                                                        |                                                        |  |
|                                                                    | Waist (J1)                                                   | W         | 1,3                                                      |                                                        |  |
|                                                                    | Shoulder (J2)                                                |           | 1,3                                                      |                                                        |  |
| Motor capacity                                                     | Elbow (J3)                                                   |           | 48                                                       |                                                        |  |
|                                                                    | Wrist twist (J4)                                             |           | 24                                                       |                                                        |  |
|                                                                    | Wrist pitch (J5)                                             |           | 20                                                       |                                                        |  |
|                                                                    | Wrist roll (J6)                                              |           | 10                                                       |                                                        |  |
|                                                                    | Waist (J1)                                                   |           | 340(-170                                                 |                                                        |  |
|                                                                    | Shoulder (J2)                                                |           | 230(-100                                                 |                                                        |  |
| Operating                                                          | Elbow (J3)                                                   | Degree    | 290(-130                                                 |                                                        |  |
| range                                                              | Wrist twist (J4)                                             | 8         | 320(-160 to +160)<br>240(-120 to +120)                   |                                                        |  |
|                                                                    | Wrist pitch (J5)                                             |           |                                                          |                                                        |  |
|                                                                    | Wrist roll (J6)                                              |           | 720(-360 to +350)                                        |                                                        |  |
|                                                                    | Waist (J1)                                                   |           | 6                                                        |                                                        |  |
|                                                                    | Shoulder (J2)                                                |           | 6                                                        |                                                        |  |
| Speed of                                                           | Elbow (J3)                                                   | Degree/s  | 6                                                        |                                                        |  |
| motion                                                             | Wrist twist (J4)                                             | _         | 9                                                        |                                                        |  |
|                                                                    | Wrist pitch (J5)                                             |           | 11                                                       |                                                        |  |
|                                                                    | Wrist roll (J6)                                              | ,         | 15                                                       |                                                        |  |
|                                                                    | tant velocity <sup>Note1)</sup><br>Maximum <sup>Note2)</sup> | mm/sec    | Approx. 2,300<br>18 (176.4)                              |                                                        |  |
| Load                                                               |                                                              | kg<br>(N) |                                                          |                                                        |  |
| Pose repeatabi                                                     | Rating<br>Note3)                                             | (N)       | 12 (1                                                    | 0.10                                                   |  |
|                                                                    |                                                              | mm<br>°C  | ± 0 to                                                   |                                                        |  |
| Ambient tempe                                                      | rature                                                       |           |                                                          |                                                        |  |
| mass                                                               | Wrist twist (J4)                                             | kg<br>N·m | Approx. 95<br>49                                         |                                                        |  |
| Allowable                                                          | Wrist twist (J4) Wrist pitch (J5)                            | IN : III  | 4                                                        |                                                        |  |
| moment load                                                        | Wrist roll (J6)                                              |           | 1                                                        |                                                        |  |
|                                                                    | Wrist twist (J4)                                             | kg·m²     | 1.                                                       |                                                        |  |
| Allowable                                                          | Wrist twist (J4) Wrist pitch (J5)                            | ng III    | 1.                                                       |                                                        |  |
| inertia                                                            | Wrist roll (J6)                                              |           |                                                          |                                                        |  |
| Arm reachable radius froot p-axis                                  |                                                              | mm        | 0.14                                                     |                                                        |  |
| center point                                                       | radius iroot p axis                                          |           | 1,0                                                      | 086                                                    |  |
| Tool wiring Note                                                   | e4)                                                          |           | Hand input 8 point /                                     | hand output 8 point                                    |  |
| _                                                                  |                                                              |           | Six spare wires : AWG#28(0.1mm²) (shielded)              | Four spare wires : AWG#22(0.3mm <sup>2</sup> )         |  |
| Tool pneumatic pipes                                               |                                                              |           | Primary side: $\Phi$ 6 x 2, Secondary side: $\Phi$ 6 × 8 |                                                        |  |
| Supply pressure                                                    |                                                              | MPa       | 0.49 =                                                   |                                                        |  |
| Protection spec                                                    | cification <sup>Note5)</sup>                                 |           | J1 to J3 axis : IP54,                                    | J4 to J6 axis : IP65                                   |  |
| Degree of clear                                                    |                                                              |           | _                                                        | $10(0.3\mu\mathrm{m})$<br>Internal suction requirement |  |
| Painting color Light gray (Equivalent to Munsell: 0.08GY7.64/0.81) |                                                              |           | · · · · · · · · · · · · · · · · · · ·                    |                                                        |  |
| Painting color                                                     |                                                              |           | Light gray (Equivalent to                                | WIGHSON, 0.00G17.07/0.01/                              |  |

Note1) This is the value on the mechanical interface surface when all axes are combined.

Note2) The maximum load capacity is the mass with the mechanical interface posture facing downword at the ± 10° limit. The workpiece's center of gravity position is 183mm or less from the mechanical interface surface of the J6 axis.

Note3) The pose repeatability details are given in Page 9, "2.2.1 Pose repeatability"

Note4) The air hand interface (option) is required when the tool (hand) output is used. Also, if the solenoid set (option) is used, eight points of hand outputs are used for other options.  $_{\mbox{\tiny o}}$ 

Note5) The protection specification details are given in Page 11, "2.2.3 Protection specifications".

Note6) The clean specification details are given in Page 13, "2.2.4 Clean specifications". A down flow(0.3m/s or more) in the clean room is the necessary conditions for the cleanliness.

2.1.1 The counter-force applied to the installation surface

The counter-force applied to the installation surface for the strength design of the robot installation surface is

Table 2-2: Value of each counter-force

| Item                                         | Unit | Value  |
|----------------------------------------------|------|--------|
| Falls moment: M <sub>L</sub>                 | N•m  | 1, 530 |
| Torsion moment: M <sub>T</sub>               | N•m  | 1, 530 |
| Horizontal translation force: F <sub>H</sub> | N    | 1, 300 |
| Vertical translation force: F <sub>V</sub>   | N    | 2, 300 |

#### 2.2 Definition of specifications

The accuracy of pose repeatability mentioned in catalogs and in the specification manual is defined as follows.

#### 2.2.1 Pose repeatability

For this robot, the pose repeatability is given in accordance with JIS 8432 (Pose repeatability). Note that the value is based on 100 measurements (although 30 measurements are required according to JIS).

[Caution] The specified "pose repeatability" is not guaranteed to be satisfied under the following conditions.

- [1] Operation pattern factors
  - 1) When an operation that approaches from different directions and orientations are included in relation to the teaching position during repeated operations
  - 2) When the speed at teaching and the speed at execution are different
- [2] Load fluctuation factor
  - 1) When work is present/absent in repeated operations
- [3] Disturbance factor during operation
  - 1) Even if approaching from the same direction and orientation to the teaching position, when the power is turned OFF or a stop operation is performed halfway
- [4] Temperature factors
  - 1) When the operating environment temperature changes
  - 2) When accuracy is required before and after a warm-up operation
- [5] Factors due to differences in accuracy definition
  - 1) When accuracy is required between a position set by a numeric value in the robot's internal coordinate system and a position within the actual space
  - 2) When accuracy is required between a position generated by the pallet function Note1) and a position within the actual space

The pallet function is a function that teaches only the position of the work used as reference (3 to 4 points) and obtains the remaining positions by calculations, for an operation that arranges works orderly or for an operation that unloads orderly arranged works. By using this function, for example, in the case of an operation that arranges works on grid points of  $100 \times 100$ , by teaching only three points of four corners, the remaining grid points are automatically generated; thus, it is not necessary to teach all 10,000 points. For more information about the pallet function, refer to the separate volume, "Instruction Manual/Detailed Explanation of Functions and Operations."

Note1)

#### 2.2.2 Rated load (mass capacity)

The robot's mass capacity is expressed solely in terms of mass, but even for tools and works of similar mass, eccentric loads will have some restrictions. When designing the tooling or when selecting a robot, consider the following issues.

- (1) The tooling should have the value less or equal than the smaller of the tolerable inertia and the tolerable moment found in Page 7, "Table 2-1: Standard specifications of robot"
- (2) Fig. 2-1 shows the distribution dimensions for the center of gravity in the case where the volume of the load is relatively small. Use this figure as a reference when designing the tooling.
- (3) When the load is not mass, but force, you should design the tooling so that it does not exceed the value for allowable moment described in Page 7, "Table 2-1: Standard specifications of robot"

[Caution] The mass capacity is greatly influenced by the operating speed of the robot and the motion posture. Even if you are within the allowable range mentioned previously, an overload or generate an overcurrnt alarm could occur. In such cases, it will be necessary to change the time setting for acceleration/deceleration, the operating speed, and the motion posture.

[Caution] The overhang amount of the load for the specified moment and inertia in this section is the dynamic limit value determined by the motor driving each axis and by the capacity of the reduction gears. Consequently, accuracy cannot be guaranteed for the entire tooling area. Since accuracy is based on the center point of the mechanical interface surface, position accuracy can diminish as you go away from the mechanical interface surface, or vibration can result, with tooling that is not rigid or that is long.

[Caution] Even within the allowable range previously mentioned, an overload alarm may be generated if an ascending operation continues at a micro-low speed. In such a case, it is necessary to increase the ascending speed.




Fig.2-1: Position of center of gravity for loads (for loads with comparatively small volume):RV-18SQ-S Series

#### 2.2.3 Protection specifications

#### (1) Types of protection specifications

The robot arm has protection specifications that comply with the IEC Standards. The protection specifications and applicable fields are shown in .

Even oil mist environment can be used in addition to the general environment.

Table 2-3: Protection specifications and applicable fields

| Туре      | Protection<br>specifications<br>(IEC Standards value) | Classification                                     | Applicable field                                                        | Remarks                                                                                                 |
|-----------|-------------------------------------------------------|----------------------------------------------------|-------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| RV-18SQ-S | IP54<br>(J1 to J3 axis)                               | General-purpose<br>environment speci-<br>fications | General assembly<br>Slightly dusty environment                          |                                                                                                         |
|           | IP65<br>(J4 to J6 axis)                               | Oil mist specifications                            | Machine tool (cutting) Machine shop with heavy oil mist Dusty work shop | Note that if the cutting machine contains abrasive materials, the robot machine line will be shortened. |

The evaluation regarding oil mist specifications has been confirmed with Mitsubishi's standard testing methods using the cutting oils shown in Table 2-4.

Table 2-4: Tested cutting oil for oil mist specifications

| Name              | Maker                | Relevant JIS   | Main characteristics                  | Application                          |
|-------------------|----------------------|----------------|---------------------------------------|--------------------------------------|
| Emulcut<br>FA-800 | Kyodo Yushi Co., Ltd | Class A1 No. 2 | Water soluble cutting oil  • Base oil | Water soluble cutting oil<br>Emulcut |

#### [Information]

#### • The IEC IP54

The IEC IP54 standard refers to protection structure designed to prevent any harmful effects by fresh water scattering vertically onto the testing equipment in a radius of 180 degrees from a distance of 300 to 500 mm, with  $10 \pm 0.5$  liters of water every minute, at a water pressure of 80 to 100kPa, covering the entire area of the robot with the exception of the installation section at 1  $\text{m}^2$  per minute, for a total of 5 minutes or more.

#### • The IEC IP65

Protection against water infiltration as specified in IP65 indicates a protective structure that is not harmfully affected when  $12.5 \pm 5\%$  liters of water is supplied from a test device at a position approx. 3m away in various directions and a water pressure of 30kPa at the nozzle section. The water is filled one minute per  $1\text{m}^2$  of test device surface area for a total of three minutes.

The IEC IP symbols define the degree of protection against solids and fluids, and do not indicate a protective structure against the entry of oil or water.

#### (2) About the use with the bad environment

This robot has protection methods that conform to IEC's IP54 (for J1 to J3 axis) and IP65 (for J4 to J6 axis) standards (splashproof type). Recommended usage conditions.

- 1) The robot is designed for use in combination with machining device.
- 2) Use confirmed cutting oil (Table 2-3) In case of applying not confirmed oil, customer should attempt it for a while if it matches
- 3) Take measures so that the robot will not be exposed to water, oil and/or chips for a long period of time.
- 4) Protection performance can be improved by pressurizing the inside of the robot arm. Since the joint (AIR PURGE) of phi 8 is prepared at the rear of the base section, please supply the dry air for pressurization from this joint. The specification of the dry air for pressurization is shown in Table 2-5.

Table 2-5: Specification of the dry air for pressurization

| Item          | Dew point                                                 | Pressure     |
|---------------|-----------------------------------------------------------|--------------|
| Specification | The atmospheric pressure dew point is -20 degree or less. | 0 to 0.01MPa |

The warranty is invalid for any faults that occur when the robot is used under the following conditions.

Also, if the cover and/or other parts are damaged by interferences caused by the peripheral devices and the robot, the protection specification (seal performance, etc.) may be degraded. Therefore, please pay extra attention when handling the robot.

Refer to Page 82, "6.2 Working environment".

- 5) In surroundings that generate inflammable gases or corrosive gasses.
- 6) Atmosphere used excluding cutting oil shown in Table 2-4.
- 7) Environment where the robot is exposed to water, oil and/or chips for a long period of time.
- 8) In surroundings where chips fall directly on the robot. In surroundings where the minimum diameter of chips is less than 0.5mm.
- 9) Mist atmosphere exceeding the specification.
- 10) Pressurization by the dry air exceeding the specification of Table 2-5

#### 2.2.4 Clean specifications

#### (1) Types of clean specifications

The robot arm with clean specification is made by order. Please check the delivery schedule.

Table 2-6: Clean specifications

| Clean specifications | Туре        | Degree of cleanliness                              | Internal suction                                     |
|----------------------|-------------|----------------------------------------------------|------------------------------------------------------|
| RV-18SQC-S           | 10(0.3 μ m) | Concentrated suction with vaccum generating valve. | The use of a vacuum generating valve is recommended. |

Table 2-7: Specifications of vacuum generation valve

| Туре    | Maker               | Air pressure   |
|---------|---------------------|----------------|
| MEDT 14 | KONEGAI CORPORATION | 0.2 to 0.6 MPa |

#### ■ Precautions for use

- 1) When using a device that moves or rotates the robot arm, the down flow may not be secured because of the air flow. In this case, the degree of cleanliness cannot be ensured.
- 2) A  $\phi$  8 coupling is provided in the base section of the robot arm for suction inside the robot arm. When using the robot, connect this coupling with the vacuum generating valve and vacuum pump (furnished by the customer).
  - \* Install the vacuum generating valve downstream of the downflow or install a filter in the exhaust air section so that the exhaust air from the vacuum generating valve does not affect cleanness.

    Recommended filter: Exhaust filter EF300-02, Koganei Corporation
  - \* If any vacuum pump is prepared by the customer, assure on the vacuum side flow rate 30 liters/min.(ANR) or more .
- 3) When using the Mitsubishi standard option solenoid valve set, use the spare piping ( $\Phi$ 6 pneumatic hose) of the primary piping to exhaust the air.

If the exhaust leaks into the robot arm, the degree of cleanliness could be affected.

#### 2.3 Names of each part of the robot




Fig.2-2: Names of each part of the robot

#### 2.4 Outside dimensions • Operating range diagram

#### (1) RV-18SQ-S/18SQC-S





Fig.2-3: Outside dimensions: RV-18SQ-S/18SQC-S



 $Fig. 2-4: Operating\ range\ diagram: RV-18SQ-S/18SQC-S$ 

#### 2.5 Tooling

#### 2.5.1 Wiring and piping for hand

Shows the wiring and piping configuration for a standard-equipped hand.




Fig.2-5: Wiring and piping for hand

#### 2.5.2 Internal air piping

#### (1) Standard type

- 1) The robot has two  $\phi$  6 x 4 urethane hoses from the pneumatic entrance on the base section to the shoulder cover.
- 2) One hose is the primary piping for the pneumatic equipment. The remaining pipe is used for air exhaust.
- 3) The optional solenoid is provided with a maximum of eight couplings for the  $\phi$  6 air hose.
- 4) The pneumatic inlet in the base section has a  $\phi$  6 pneumatic coupling bridge.
- 5) Refer to Page 27, "(3) Solenoid valve set" for details on the electronic valve set (optional).
- 6) Protection performance can be improved by pressurizing the inside of the robot arm. Since the joint (AIR PURGE) of phi 8 is prepared at the rear of the base section, please supply the dry air for pressurization from this joint. Refer to Page 11, "2.2.3 Protection specifications" for the details of dry air.

#### (2) Clean type

- 1) The clean type basically includes the same piping as the standard type.
- 2) With the clean specification, a  $\phi$ 8 coupling is provided in the base section for suction inside the machine. For use, connect it to the suction port of the vacuum pump or the coupling on the "VACUUM" side of the vacuum generating valve. Moreover, to clean the exhaust from the vacuum pump or vacuum generator, use the exhaust filter (prepared by the customer).
- 3) Refer to Page 13, "2.2.4 Clean specifications" for details of the vacuum for suction.
- 4) Use clean air as the air supplied to the vacuum generator.

#### 2.5.3 Internal wiring for the hand check input cable

- 1) The hand output primary cable extends from the connector PCB of the base section to the inside of the forearm. (AWG#24(0.2mm²)x 2:8 cables) The cable terminals have connector bridges for eight hand inputs. The connector names are HC1 and HC2. The terminal section is connected to the connector in the forearm section.
- 2) The hand check signal of the pneumatic hand is input by connecting this connector. To extend the wiring to the outside of the arm, a separate cable (optional "hand input cable "1S-HC25C-01" IP65 is recommended) is required.

#### 2.5.4 Internal wiring for the hand check input cable(Standard type/Clean type)

- 1) The air hand output can be used by installing the pneumatic hand interface (2A-RZ365/2A-RZ375) of the option in the controller. The hand output primary cable extends from the connector PCB of the base section to the inside of the forearm. (AWG#24(0.2mm²)x 2: 8 cables) The cable terminals have connector bridges for eight hand inputs. The connector names are HC1 and HC2. The terminal section is connected to the connector in the forearm section.
- 2) The hand check signal of the pneumatic hand is input by connecting this connector. To extend the wiring to the outside of the arm, a separate cable (optional "hand input cable "1S-HC25C-01" IP65 is recommended) is required.

#### 2.5.5 Spare Wiring

#### (1) Standard type

As spare wiring, four pairs of AWG#27(0.1mm²) cab tire cables (total of eight cores) are preinstalled between the base section and the forearm side section. The connector is attached to both ends. Customer can be use. Refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" for details.

Both ends of the wire terminals are unprocessed. Use them under the following circumstances:

- For folding as the hand output cable when installing the solenoid valve in outside the robot.
- For when installing six or more hand I/O points for the sensor in the hand section (Connects to the parallel I/O general purpose input.)

Reference) Pin assignment of the connector, and the matching connector

#### Pin assignment

| Pin | Color  |
|-----|--------|
| A1  | Red    |
| A2  | Brown  |
| A3  | Breen  |
| A4  | Brack  |
| B1  | Orange |
| B2  | White  |
| B3  | Yellow |
| B4  | Blue   |

#### Robot side connector

| Connection place | Connector   | Contactor | Maker                     |
|------------------|-------------|-----------|---------------------------|
| Base portion     | 2-1318115-4 | -         | Tyco Electronics AMP K.K. |
| Fore arm portion | 2-1717834-4 | -         |                           |

#### Other party connector (recommendation)

| Connection place | Connector   | Contactor | Maker                     |
|------------------|-------------|-----------|---------------------------|
| Base portion     | 2-1717834-4 | 1318108-1 | Tyco Electronics AMP K.K. |
| Fore arm portion | 2-1318115-4 | 1318112-1 |                           |

#### 2.5.6 iring and piping system diagram for hand

Shows the wiring and piping configuration for a standard-equipped hand.




Fig.2-6: Wiring and piping system diagram for hand and example the solenoid valve installation(Sink type)




Fig.2-7: Wiring and piping system diagram for hand and example the solenoid valve installation(Source type)

#### 2.5.7 Electrical specifications of hand input/output

Table 2-8: Electrical specifications of input circuit

| Item               |         | Specifications                         | Internal circuit              |
|--------------------|---------|----------------------------------------|-------------------------------|
| Туре               |         | DC input                               | ⟨Sink type⟩                   |
| No. of input point | s       | 8                                      | 04)/□                         |
| Insulation method  | I       | Photo-coupler insulation               | 24V <del></del>               |
| Rated input volta  | ge      | 12VDC/24VDC                            | <u></u>                       |
| Rated input curre  | nt      | Approx. 3mA/approx. 7mA                | 7~ ↓ 1820                     |
| Working voltage r  | ange    | DC10.2 to 26.4V(ripple rate within 5%) | HCn*                          |
| ON voltage/ON o    | urrent  | 8VDC or more/2mA or more               | 3.3K J <sub>OV(COM)</sub>     |
| OFF voltage/OFF    | current | 4VDC or less/1mA or less               |                               |
| Input resistance   |         | Approx. 3.3kΩ                          | (0,, 1,)                      |
| Response time      | OFF-ON  | 10ms or less(DC24V)                    | <pre> <source type=""/></pre> |
|                    | ON-OFF  | 10ms or less(DC24V)                    | +24V <del>□</del>             |
|                    |         |                                        | 3.3K<br>HCn*<br>B20<br>24GND  |
|                    |         |                                        | * HCn = HC1 ~ HC8             |

Table 2-9: Electrical specifications of output circuit

| Item                    |               | Specification                                           | Internal circuit                            |  |
|-------------------------|---------------|---------------------------------------------------------|---------------------------------------------|--|
| Туре                    |               | Transistor output                                       | <sink type=""></sink>                       |  |
| No. of output points    |               | 8                                                       | 24V                                         |  |
| Insulation method       |               | Photo coupler insulation                                | (Internal power supply)                     |  |
| Rated load voltage      |               | DC24V                                                   |                                             |  |
| Rated load voltage rang | ge            | DC21.6 to 26.4VDC                                       | $\overline{}$                               |  |
| Max. current load       |               | 0.1A/ 1 point (100%)                                    | GRņ*                                        |  |
| Current leak with power | r OFF         | 0.1mA or less                                           |                                             |  |
| Maximum voltage drop v  | with power ON | DC0.9V(TYP.)                                            | * * * * * * * * * * * * * * * * * * *       |  |
| Response time           | OFF-ON        | 2ms or less (hardware response time)                    |                                             |  |
|                         | ON-OFF        | 2 ms or less (resistance load) (hardware response time) | Fuse                                        |  |
| Fuse rating             |               | 1.6A (each one common) Cannot be exchanged              | 1.6A                                        |  |
|                         |               |                                                         | <del>'</del><br>0∨                          |  |
|                         |               |                                                         |                                             |  |
|                         |               |                                                         | <source type=""/>                           |  |
|                         |               |                                                         | Fuse +24V                                   |  |
|                         |               |                                                         | 1.6A                                        |  |
|                         |               |                                                         | GRn*                                        |  |
|                         |               |                                                         |                                             |  |
|                         |               |                                                         | <b>                                    </b> |  |
|                         |               |                                                         | $\vdash$                                    |  |
|                         |               |                                                         |                                             |  |
|                         |               |                                                         | 24GND(COM)                                  |  |
|                         |               |                                                         | * GRn = GR1 ∼ GR8                           |  |

Note) An optional air hand interface (2A-RZ365/2A-RZ375) is required to use hand output.

#### 2.5.8 Air supply circuit example for the hand

Fig. 2-8 shows an example of pneumatic supply circuitry for the hand.

- (1) Place diodes parallel to the solenoid coil.
- (2) When the factory pneumatic pressure drops, as a result of the hand clamp strength weakening, there can be damage to the work. To prevent it, install a pressure switch to the source of the air as shown in Fig. 2-8 and use the circuit described so that the robot stops when pressure drops. Use a hand with a spring-pressure clamp, or a mechanical lock-type hand, that can be used in cases where the pressure switch becomes damaged.
- (3) The optional hand and solenoid valve are of an oilless type. If they are used, don't use any lubricator.




Fig.2-8: Air supply circuit example for the hand

#### 2.6 Options

#### ■ What are options?

There are a variety of options for the robot designed to make the setting up process easier for customer needs. customer installation is required for the options. Options come in two types: "set options" and "single options".

- 1. Set options ......A combination of single options and parts that together, from a set for serving some purpose.
- 2. Single options ......That are configured from the fewest number of required units of a part. Please choose customer's purpose additionally.

#### (1) Machine cable extension

■ Order type : ● Fixed type 1S-□□ CBL-02

◆ Flexed type 1D- □□ LCBL-02 Note) The numbers in the boxes □□ refer the length.

Outline



This cable is extended to the machine cable (5 m for fix type) that was supplied as standard

A fixed type and flexible type are available.

The fix and flexible types are both configured of the motor signal cable and motor power cable.

#### ■ Configuration

Table 2-10: Configuration equipments and types

| Part name                            |                                | Type              | Qty.      |           | Remarks                                |
|--------------------------------------|--------------------------------|-------------------|-----------|-----------|----------------------------------------|
|                                      |                                | Турс              | Fixed     | Flexed    | - Nomarks                              |
| Fixed Set of signal and power cables |                                | 1S- □□ CBL-02     | 1 set     | -         | 5m, 10m, or 15m each <sup>Note1)</sup> |
|                                      | Motor signal cable             | 1S- □□ CBL(S)-01  | (1 cable) | -         | -<br>-                                 |
|                                      | Motor power cable              | 1S- □□ CBL(P)-01  | (1 cable) | -         |                                        |
| Flexed                               | Set of signal and power cables | 1D- □□ LCBL-02    | -         | 1 set     | 5m, 10m, or 15m each <sup>Note1)</sup> |
|                                      | Motor signal cable             | 1S- □□ LCBL(S)-01 | -         | (1 cable) |                                        |
|                                      | Motor power cable              | 1D- □□ LCBL(P)-01 | -         | (1 cable) |                                        |
| Nylon cla                            | amp                            | NK-14N            | -         | 2 pcs.    | for motor signal cable                 |
| Nylon clamp                          |                                | NK-18N            | -         | 2 pcs.    | for motor power cable and ground cable |
| Silicon rubber                       |                                |                   | -         | 4 pcs.    |                                        |

Note1)The numbers in the boxes  $\square \square$  refer the length.

#### ■ Specifications

The specifications for the fixed type cables are the same as those for standard cables.

Shows usage conditions for flexed type cables in Table 2-11.

Table 2-11: Conditions for the flexed type cables

| Item                                   |    | Specifications                                                                    |  |
|----------------------------------------|----|-----------------------------------------------------------------------------------|--|
| Minimum flexed radius                  |    | 100R or more                                                                      |  |
| Cable bare, etc., occupation rate      |    | 50% or less                                                                       |  |
| Maximum movement spee                  | ed | 2000mm/s or less                                                                  |  |
| Guidance of life count                 |    | 7.5 million times                                                                 |  |
| Environmental proof                    |    | Oil-proof specification sheath (for silicon grease, cable sliding lubricant type) |  |
| Cable configuration Motor signal cable |    | $\phi$ 7 x 6and $\phi$ 1.7 x 1                                                    |  |
| Motor power cable                      |    | $\phi$ 7.5 x 2 and $\phi$ 6 x 8                                                   |  |

[Caution] The guidance of life count may greatly differ according to the usage state (items related to Table 2-11 and to the amount of silicon grease applied in the cable conduit.

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

#### ■ Cable configuration

The configuration of the flexible cable is shown in Table 2-12. Refer to this table when selecting the cable bare.

Table 2-12: Cable configuration

| Item              | Motor signal cable<br>1S− □ □ LCBL(S)-01                                                   |                        |                      | Motor pow<br>1D− □□ LC          |                                 |
|-------------------|--------------------------------------------------------------------------------------------|------------------------|----------------------|---------------------------------|---------------------------------|
| No. of cores      | AWG#24(0.2mm <sup>2</sup> )-4P AWG#24(0.2mm <sup>2</sup> )-7P AWG#18(0.75mm <sup>2</sup> ) |                        |                      | AWG#17(1.25mm <sup>2</sup> )-4C | AWG#19(0.75mm <sup>2</sup> )-3C |
| Finish dimensions | Approx. φ6mm                                                                               | Approx. <i>φ</i> 8.5mm | Approx. $\phi$ 1.7mm | Approx. <i>φ</i> 7.5mm          | Approx. φ6mm                    |
| No.of cables used | 5 cables 1 cable 1 cable                                                                   |                        | 2 cable              | 8 cable                         |                                 |
| No. in total      | 7 cables                                                                                   |                        |                      | 10 cat                          | oles                            |

#### ■ Fixing the flexible cable

- (1) Connect the connector to the robot arm.
- (2) Wind the silicon rubber around the cable at a position 300 to 400 mm from the side of robot arm and extension section as shown in Fig. 2-9, and fix with the nylon clamp to protect the cable from external stress.




Fig.2-9: Fixing the flexible cable

#### (2) Changing the operating range

■ Order type: J1 axis.....1S-DH -01

#### Outline



The J1 axis operating range is limited by the robot arm's mechanical stopper and the controller parameters.

If the axis could interfere with the peripheral devices, etc., and the operating range need to be limited, use this.

#### ■ Configuration

Table 2-13: Configuration devices

| Part name                                      | Туре     | Qty.   | Remarks                                                              |
|------------------------------------------------|----------|--------|----------------------------------------------------------------------|
| Stopper for changing the operating range of J1 | 1S-DH-01 | 2 pcs. | Hexagon socket bolt: M10 x 20 plating (strength classification 10.9) |

#### ■ Specifications

Table 2-14: Specifications

| Ax | (is    | Standard | Changeable angle                 |
|----|--------|----------|----------------------------------|
| 11 | + side | +170°    | One point from +135°, +90°, +45° |
| J1 | - side | −170°    | One point from -135°, -90°, -45° |

- (1) The changeable angle shown in Table 2-14 indicates the operation range by the software.


  The limit by the mechanical stopper is positioned 1 degrees outward from that angle, so take care when designing the layout.
- (2) The changeable angle can be set independently on the + side and side.
- (3) The operating range is changed with robot arm settings and parameter settings. Refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" or "Instruction Manual/Detailed Explanation of Functions and Operations" for details.

#### (3) Solenoid valve set

■ Order type: One set: 1S-VD01-01(Sink type)/1S-VD01E-01(Source type)

> Two sets: 1S-VD02-01(Sink type)/1S-VD02E-01(Source type) Three sets: 1S-VD03-01(Sink type)/1S-VD03E-01(Source type) 1S-VD04-01(Sink type)/1S-VD04E-01(Source type) Four sets:

#### Outline



The solenoid valve set is an option that is used for controlling toolings when various toolings, such as the hand, are installed at the end of the arm. All have double solenoid specification, and either one or two or three sets can be selected. This solenoid valve set has a hand output cable attached to the solenoid valve. Also, for easy installation of this electromagnetic set onto the robot, it comes equipped with a manifold, couplings, silencers, among other things.

When using the robot arm's hand output signal, the pneumatic hand interface option must be installed on the separate controller.

#### ■ Configuration

Table 2-15: Configuration equipment

| Dout name                   | Т                          | Q'ty  |          |            |           | Remark                                                 |
|-----------------------------|----------------------------|-------|----------|------------|-----------|--------------------------------------------------------|
| Part name                   | Part name Type             |       | Two sets | Three sets | Four sets | Remark                                                 |
| Solenoid valve set (1 set)  | 1S-VD01-01/<br>1S-VD01E-01 | 1 pc. | _        | _          | _         | M4x8 four screws (installation screws).                |
| Solenoid valve set (2 sets) | 1S-VD02-01/<br>1S-VD02E-01 | _     | 1 pc.    | _          | _         | 1S-VD01-01/VD02-01/VD03-01/VD04-01 are                 |
| Solenoid valve set (3 sets) | 1S-VD03-01/<br>1S-VD03E-01 | _     | _        | 1 pc.      | _         | the sink type.  1S-VD01E-01/VD02E-01/VD03E-01/VD04E-01 |
| Solenoid valve set (4 sets) | 1S-VD04-01/<br>1S-VD04E-01 | _     | _        | _          | 1 pc.     | are the source type.                                   |

#### ■ Specifications

Table 2-16: Valve specifications

| Item                                | Specifications                                        |
|-------------------------------------|-------------------------------------------------------|
| Number of positions                 | 2                                                     |
| Port                                | 5 Note1)                                              |
| Valve function                      | Double solenoid                                       |
| Operating fluid                     | Clean air <sup>Note2)</sup>                           |
| Operating method                    | Internal pilot method                                 |
| Effective sectional area (CV value) | 0.64mm                                                |
| Oiling                              | Unnecessary                                           |
| Operating pressure range            | 0.1 to 0.7MPa                                         |
| Guaranteed proof of pressure        | 1.0MPa or more                                        |
| Response time                       | 22msec or less (at 0.5 MPa)                           |
| Max. operating frequency            | 5c/s                                                  |
| Ambient temperature                 | -5 to 50 °C (However, there must be no condensation.) |

Note1) Couplings of unused solenoid valves must be blocked with plugs. If they are not blocked, supplied air will blow out from the couplings, lowering the air pressure of the solenoid valves being used and making them nonfunctional


(recommended plugs: KQ2P-04 plugs made by SMC).



CAUTION Note2) The air to be provided must be clean, i.e., filtered with a mist separator or air filter. Failing to do so may lead to malfunctions.

Table 2-17: Solenoid specifications

| Item                                        | Specifications |
|---------------------------------------------|----------------|
| Coil rated voltage                          | DC24V ± 10%    |
| Power consumption                           | 0.55W          |
| Voltage protection circuit with power surge | Diode          |
| protection                                  |                |



## (4) Hand input cable

■ Order type: 1S-HC25C-01

#### Outline



The hand input cable is used for customer-designed pneumatic hands.

It is necessary to use this to receive the hand's open/close confirmation signals and grasping confirmation signals, at the controller.

One end of the cable connects to the connector for hand input signals, which is in the wrist section of the hand. The other end of the cable connects to the sensor inside the hand customer designed.

## ■ Configuration

Table 2-18: Configuration equipment

| Part name        | Туре        | Qty.    | Remarks |
|------------------|-------------|---------|---------|
| Hand input cable | 1S-HC25C-01 | 1 cable |         |

## ■ Specifications

## Table 2-19: Specifications

| Item              | Specifications                                         | Remarks                                       |
|-------------------|--------------------------------------------------------|-----------------------------------------------|
| Size x cable core | AWG#24 (0.2mm <sup>2</sup> ) × 12                      | One-sided connector, one-sided cable bridging |
| Total length      | 800mm (Including the curl section, which is 300mmlong) |                                               |




Fig.2-10: Outside dimensional drawing and pin assignment

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

# (5) Hand output cable

■ Order type: 1S-GR35S-01

#### Outline



The hand output cable (solenoid valve connection cable) is an option that is used when an solenoid valve other than one of the solenoid valve set options, is used. One end of the cable has a connector that connects to the input terminal inside the robot. The other end of the cable is connected.

## ■ Configuration

Table 2-20 : Configuration equipment

| Part name         | Туре        | Qty.    | Remarks |
|-------------------|-------------|---------|---------|
| Hand output cable | 1S-GR35S-01 | 1 cable |         |

#### ■ Specifications

Table 2-21: Specifications

| Item              | Specifications                         | Remarks                                          |  |
|-------------------|----------------------------------------|--------------------------------------------------|--|
| Size x Cable core | AWG#24(0.2mm <sup>2</sup> ) x 12 cores | One side connector and one side cable connection |  |
| Total length      | 400mm                                  |                                                  |  |




Fig.2-11: Outline dimensional drawing and pin assignment

## (6) Hand curl tube

■ Order type: Four set: :1N-ST0608C

#### ■ Outline



The hand curl tube is a curl tube for the pneumatic hand.

# ■ Configuration

Table 2-22 : Configuration equipment

| Part name                         | Туре       | Qty.  | Remarks              |
|-----------------------------------|------------|-------|----------------------|
| Hand curl tube (Four set: 8 pcs.) | 1N-ST0608C | 1 pc. | $\phi$ 6 tube, 8pcs. |

## ■ Specifications

This option can be installed on clean-type, but its cleanliness is not under warranty.

Table 2-23: Specifications

| Item     | Specifications                                         |  |
|----------|--------------------------------------------------------|--|
| Material | Urethane                                               |  |
| Size     | Outside diameter: $\phi$ 6 x Inside diameter: $\phi$ 4 |  |




Fig.2-12: Outline dimensional drawing

[Caution] This option can be installed on clean-type, but its cleanliness is not under warranty.

# 2.7 Maintenance parts

The consumable parts used in the robot arm are shown in Table 2-24. Purchase these parts from the designated maker or dealer when required. Some Mitsubishi-designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and controller serial No. and purchase the parts from the dealer.

Table 2-24: Consumable part list

| No. | Part name       | Type Note1) | Usage place                  | Qty.      | Supplier              |
|-----|-----------------|-------------|------------------------------|-----------|-----------------------|
| 1   | Grrase          | SK-1A       | Reduction gears of each axis | As needed | Mitsubishi Electric   |
| 2   | Lithium battery | A6BAT       | In the battery cover         | 5 pcs.    | Willsubistii Electric |

Note1)Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

# 3 Controller

# 3.1 Standard specifications

# 3.1.1 Standard specifications

Table 3-1: Standard specifications of controller

| Item            |                                       | Unit          | Specification                                             | Remarks                                                    |
|-----------------|---------------------------------------|---------------|-----------------------------------------------------------|------------------------------------------------------------|
| Туре            |                                       |               | CR3Q-709M/CR3Q-709                                        | CR3Q-709M: RV-18SQ-S series<br>CR3Q-709: RV-18SQC-S series |
| Number of       | control axis                          |               | Simultaneously 6(Maximum)                                 |                                                            |
| CPU             |                                       |               | 6 4 bit R I S C / D S P                                   |                                                            |
| Memory capacity | Programmed positions and No. of steps | point<br>step | 13,000<br>26,000                                          |                                                            |
|                 | Number of programs                    |               | 2 5 6                                                     |                                                            |
| Robot langu     | Robot language                        |               | MELFA — BASICV<br>or<br>MELFA — BASICIV <sup>Note1)</sup> |                                                            |
| Teaching m      | ethod                                 |               | Pose teaching method ,MDI method                          |                                                            |
| External        | input and output                      | point         | Input 0 point/Output 0 point                              | Multi-CPU share device                                     |
| input and       | Dedicated input/output                |               | Assign to the multi-CPU share device.                     | Input 8192/Output 8192 (Max.)                              |
| output          | Special stop input                    | point         | 1                                                         |                                                            |
|                 | Hand open/close input/output          | point         | Input 8 point/Output 0 point                              | Up to 8 output points can be added as an option Note2)     |
|                 | Emergency stop input                  | point         | 1                                                         | Dual emergency line                                        |
|                 | Door switch input                     | point         | 1                                                         | Dual door switch line                                      |
|                 | Enabling device input                 | point         | 1                                                         | Dual enabling switch line                                  |
|                 | Emergency stop output                 | point         | 1                                                         |                                                            |
|                 | Mode output                           | point         | 1                                                         |                                                            |
|                 | Robot error output                    | point         | 1                                                         |                                                            |
|                 | Addition axis synchronization         | point         | 1                                                         |                                                            |
| Interface       | RS-422                                | port          | 1                                                         | Only for the teaching pendant                              |
|                 | Ethernet                              | port          | 1 : Only for the teaching pendant                         | 100BASE-TX                                                 |
|                 | Hand dedicated slot                   | slot          | 1                                                         | Dedicated for pneumatic hand interface                     |
|                 | Additional axis interface             | Channel       | 1                                                         | SSCNET III                                                 |

Note1)The program of MELFA-BASICIV can be used by MELFA-BASICV, if program is converted by RT ToolBox2 (option).

Note2)It is when an pneumatic hand interface (2A-RZ365/2A-RZ375) is installed.

Table 3-2: Standard specifications of drive unit

| Item                        |                               | Unit  | Specification                                                                                                      |                    | Remarks                                                  |
|-----------------------------|-------------------------------|-------|--------------------------------------------------------------------------------------------------------------------|--------------------|----------------------------------------------------------|
| Туре                        |                               |       | DU3-709M/DU3-709                                                                                                   |                    | DU3-709M: RV-18SQ-S series<br>DU3-709: RV-18SQC-s series |
| External                    | input and output              | point | 0/                                                                                                                 | 0                  | Multi-CPU share device                                   |
| input and                   | Dedicated input/output        |       | Assign to the multi-                                                                                               | -CPU share device. | Input 8192/Output 8192 (Max.)                            |
| output                      | Special stop input            | point | 1                                                                                                                  |                    |                                                          |
|                             | Hand open/close input/output  | point | Input 8 point/0                                                                                                    | Output 0 point     | Up to 8 output points can be added as an option Note1)   |
|                             | Emergency stop input          | point | 1                                                                                                                  |                    | Dual emergency line                                      |
|                             | Door switch input             | point | 1                                                                                                                  |                    | Dual door switch line                                    |
|                             | Enabling device input         | point | 1                                                                                                                  |                    | Dual enabling switch line                                |
|                             | Emergency stop output         | point | 1                                                                                                                  |                    |                                                          |
|                             | Mode output                   | point | 1                                                                                                                  |                    |                                                          |
|                             | Robot error output            | point | 1                                                                                                                  |                    |                                                          |
|                             | Addition axis synchronization | point | 1                                                                                                                  |                    |                                                          |
| Interface                   | RS-422                        | port  | 1                                                                                                                  |                    | Only for the teaching pendant                            |
|                             | Ethernet                      | port  | 1 : Only for the teaching pendant                                                                                  |                    | 100BASE-TX                                               |
|                             | Hand dedicated slot           | slot  | 1                                                                                                                  |                    | Dedicated for pneumatic hand interface                   |
| Power source                | Input voltage range           | ٧     | 3-phase, AC 1                                                                                                      | 80~253             | Note2)                                                   |
|                             | Power capacity                | kVA   | 3.0                                                                                                                |                    | Does not include rush current Note3)<br>Note4)           |
|                             | Power supply frequency        | Hz    | 50/                                                                                                                | <b>6</b> 0         |                                                          |
| Outline dir                 | mensions                      | mm    | DU3-709M:450(W)x440(D)x625(H)<br>DU3-709:450(W)x380(D)x625(H)                                                      |                    | Excluding protrusions                                    |
| Mass                        |                               | kg    | Approx.                                                                                                            |                    |                                                          |
| Construction                |                               |       | DU3-709M:Self-contained floor type, Closed type(IP54)Note5) DU-3-709: Self-contained floor type, Opened typeNote6) |                    |                                                          |
| Operating temperature range |                               | °C    | 0~                                                                                                                 | 4 0                |                                                          |
| Ambient h                   | umidity                       | %RH   | 45~85                                                                                                              |                    | Without dew drops                                        |
| Grounding                   |                               | Ω     | 100 or less                                                                                                        |                    | D class grounding earth <sup>Note7)</sup>                |
| Paint color                 |                               |       | Light gray                                                                                                         |                    | Munsell 0.08GY7.64/0.81                                  |

Note1) It is when an pneumatic hand interface (2A-RZ365/2A-RZ375) is installed.

Note2) Please use the controller with an input power supply voltage fluctuation rate of 10% or less.

Note3)The power capacity is the rating value for normal operation. The power capacity does not include the rush current when the power is turned ON. The power capacity is a guideline and the actual operation is affected by the input power voltage. The short circuit breaker should use the following.

\*Operate by the current leakage under the commercial frequency domain (50-60Hz).

If sensitive to the high frequency ingredient, it will become the cause in which below the maximum leak current value carries out the trip.

Note4)If the earth leakage breaker is installed in the primary side power supply circuit of the drive unit, please select the earth leakage breaker of the specification of the amperage rating 20A and 10mA of sensed current. (The leak current of the controller is set to about 7.5mA)

Note5)The DU3-7xxM drive unit exchanges heat using the internal air circulation self-cooling method. Furthermore, the rear side sucks in the outside air and the top and bottom sections of the rear side discharges the inside air. And, has the protection structure which fitted IP54.

Note6)The DU3-7xx drive unit is a general environment specification.

Note7)The robot must be grounded by the customer.

Table 3-3: Robot CPU unit standard specification

| Item                        |                               | Unit | Specification                 | Remarks           |
|-----------------------------|-------------------------------|------|-------------------------------|-------------------|
| Туре                        |                               |      | Q172DRCPU                     |                   |
| Interface                   | Addition axis synchronization | port | 1                             |                   |
| Power source                | Power capacity (DC5V)         | Α    | 1. 25                         |                   |
| Outline dimensions          |                               | mm   | 27.4 (W) x 98 (D) x 119.3 (H) |                   |
| Mass                        |                               | kg   | 0.33                          |                   |
| Operating temperature range |                               | °C   | 0~55                          |                   |
| Ambient humidity            |                               | %RH  | 5~95                          | Without dew drops |

## 3.1.2 Protection specifications and operating supply

The IEC IP symbols refer only to the degree of protection between the solid and the fluids, and don't indicated that any special protection has been constructed for the prevention against oil and water.

### [Information]

## • The IEC IP20

It indicates the protective structure that prevents an iron ball  $12^{+0.05}_{0}$ mm diameter, which is being pressed with the power of 3.1 kg  $\pm$  10%, from going through the opening in the outer sheath of the supplied equipment.

#### • The IEC IP54

The IEC IP54 standard refers to protection structure designed to prevent any harmful effects by fresh water scattering vertically onto the testing equipment in a radius of 180 degrees from a distance of 300 to 500 mm, with  $10\,\pm\,0.5$  liters of water every minute, at a water pressure of 80 to 100kPa , covering the entire area of the robot with the exception of the installation section at 1 m per minute, for a total of 5 minutes or more.

Refer to the section 82Page "6.2Working environment" for details on the working environment.

# 3.2 Names of each part

# 3.2.1 Names of each part of the drive unit




Fig.3-1: Names of drive unit parts


| 1 POWER switch             | This turns the control power ON/OFF. (With earth leakage breaker function) * 1)                                                          |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|                            | This executes the program and operates the robot. The program is run continuously.                                                       |
|                            | This stops the robot immediately. The servo does not turn OFF.                                                                           |
|                            | This resets the error. This also resets the program's halted state and resets the program.                                               |
|                            | This stops the robot in an emergency state. The servo turns OFF.                                                                         |
|                            | This changes the details displayed on the display panel in the order of "Override" $\rightarrow$ "Program No." $\rightarrow$ "Line No.". |
| 7 END button               | This stops the program being executed at the last line or END statement.                                                                 |
| 8 SVO.ON button            | This turns ON the servo power. (The servo turns ON.)                                                                                     |
| 9 SVO.OFF button           | This turns OFF the servo power. (The servo turns OFF.)                                                                                   |
| 10 STATUS NUMBER           |                                                                                                                                          |
| (display panel)            | The alarm No., program No., override value (%), etc., are displayed.                                                                     |
| 1 T/B connection connector | This is a dedicated connector for connecting the T/B. When not using $T/B$ , connect the                                                 |
|                            | attached dummy connector.                                                                                                                |
| 12 MODE key switch         | This changes the robot's operation mode.                                                                                                 |
| AUTOMATIC                  | operations from the controller or external equipment are valid. Operations for                                                           |
|                            | which the operation mode must be at the external device or $T/B$ are not possible. It                                                    |
|                            | is necessary to set the parameter for the rights of operation to connection                                                              |
|                            | between the operation panel and external equipment. For details, please refer to                                                         |
|                            | "INSTRUCTION MANUAL/Detailed explanations of functions and operations" of                                                                |
|                            | the separate volume.                                                                                                                     |
| MANUAL                     | When the $T/B$ is valid, only operations from the $T/B$ are valid. Operations for                                                        |
|                            | which the operation mode must be at the external device or controller are not pos-                                                       |
| _                          | sible.                                                                                                                                   |
| _                          | This scrolls up or down the details displayed on the "STATUS. NUMBER" display panel.                                                     |
| 14 Interface cover         | Unused in this drive unit. Please use closing this cover, because of to prevent                                                          |
| _                          | deterioration of protection performance.                                                                                                 |
| 15 Power cable clamp       | Fix the primary power cable                                                                                                              |
|                            |                                                                                                                                          |

- \*1)The power switch of DU2-700/DU3-700 series can be locked by installing the padlock etc. Please prepare the padlock by the customer. Padlock specification is shown in "3.2.2Padlock specification"
- [Note] The RS232 connection connector is not prepared by this controller. If you use it, please prepare sequencer CPU or the unit corresponding to the sequencer

## 3.2.2 Padlock specification

If the robot is not used, the power switch can be locked with the padlock so that power supply ON cannot be done easily. The specification is shown in the following.

## < CR3Q-700 >



## Usage of lock function

- 1 Turn the handle to the reset direction until the mark of the lock plate and the case mark is in match.
- 2 Push in the lock plate.
- 3 Return the handle to the OFF position, with pushing the lock plate.
- 4 Lock the handle with the padlock.

The lock device which can be used



## Dimension of the padlock

| Dimension (mm) |          |     |  |  |  |
|----------------|----------|-----|--|--|--|
| A B C          |          |     |  |  |  |
| 35(0.11)       | 19       | 5   |  |  |  |
| 40(0.13)       | 22 or 23 | 5.5 |  |  |  |

The maximum size of "C" which can be installed is 8mm.

Fig.3-2: Operation lock of the power switch(CR3Q-700)




Fig.3-3: Names of each part (Rear side DU3-700 series)




Fig.3-4: Names of each part (Rear side DU3-700 series)

# 3.2.3 Names of each part of the robot CPU




Fig.3-5: Names of each part of the robot CPU

| Seven segments LEDIndicates operational status and error information     Rotary switch(SW1)Set up operation mode. Always set it as "0."     Rotary switch(SW2)Set up operation mode. Always set it as "0." |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4 RUN/STOPswitchUnused                                                                                                                                                                                     |
| (5) Emergency stop input(EMI) <sup>Note1)</sup> The input connector which makes the servo amplifier of all the axes the emergency stop at once.                                                            |
| EMI ON (open) : Emergency stop                                                                                                                                                                             |
| EMI OFF (Supply DC24V.) : Emergency stop release                                                                                                                                                           |
| 6 CN1 connector Note2)                                                                                                                                                                                     |
| ⑦ CN2 connector Note2)                                                                                                                                                                                     |
| 8 Lever for unit installation                                                                                                                                                                              |
| 9 Hook for unit fixing Note3)The hook which fixes the unit to the base unit (For the support at installation)                                                                                              |
| ① Unit fixing screw                                                                                                                                                                                        |
| The projection for unit fixing The projection for fixing to the base unit                                                                                                                                  |
| 1 Battery connector(BAT)Note4)The connector for connection with battery holder unit Q170DBATC                                                                                                              |
| ① The connector for the networks (DISPLAY I/F)                                                                                                                                                             |
| The connector of the LAN access for T/B (For R56TB).                                                                                                                                                       |
| \$ RS422 connector(TU I/F)The connector for RS422 connection with the drive unit                                                                                                                           |

Note1)Please be sure to use the emergency stop input cable. The emergency stop cannot be canceled if it does not use. If it manufactures the emergency stop input cable in the customer, cable length should use 30m or less

Note2)Please store in the duct or fix the cable section near robot CPU with the bunch wire rod so that prudence of the cable is not applied to CN1 and CN2 connector section.

Note3)It is equipment for the support when installing the unit in the basic base unit. Please be sure to fix the unit to the basic base unit with the attached fixing screw.

Note4)Please be sure to use the external battery. Unless the battery cable is connected surely, the program in SRAM with a built-in robot CPU, the parameter, origin position data, etc. are not held.

# 3.3 Outside dimensions/Installation dimensions

# 3.3.1 Outside dimensions




Fig.3-6: Outside dimensions(DU3-7xxM)




Fig.3-7: Outside dimensions of controller (DU3-700M Supplement)




Fig.3-8: Outside dimensions of controller (DU3-700 Supplement)

# 3.3.2 Installation dimensions




Fig.3-9 : Installation of controller (DU3-700/700M)

The controller has the openings parts for pulling out the cable as shown in Fig. 3-10.




Fig.3-10: Cable lead-in and dimension of the controller (DU3-7xx Series)

# (1) Outside dimensions of robot CPU




Fig.3-11: Outside dimensions of robot CPU

# 3.4 External input/output

# 3.4.1 Types

| (1) Dedicated input/outputThese inputs and outputs carry out the robot remote operation and    |  |
|------------------------------------------------------------------------------------------------|--|
| status display.                                                                                |  |
| (2) General-purpose input/outputThese are inputs and outputs that the customer can program for |  |
| peripheral device control.                                                                     |  |
| (0) 11 12 1/ 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1                                                     |  |

(3) Hand input/output ...... These are inputs and outputs related to the hand that the customer can program. (The hand output is an option. The Page 62, "(2) Pneumatic hand interface" is required.)

Table 3-4: Emergency stop/Door switch input

| Name                | No. of input/ | output points | Connection |
|---------------------|---------------|---------------|------------|
| name                | Input         | Output        | format     |
| Emergency stop      | 1             | 1             | Connector  |
| Special stop switch | 1             | -             |            |
| Door switch         | 1             | -             | 1          |
| Enabling device     | 1             | -             | 1          |

The wiring for the safe security of the emergency stop etc. is shown after The hand output is an option. Refer to Page 62, "(2) Pneumatic hand interface" for details

# 3.5 Dedicated input/output

Show the main function of dedicated input/output in the Table 3-5. Refer to attached instruction manual "Detailed explanations of functions and operations" in the product for the other functions. Each parameter indicated with the parameter name is used by designated the signal No., assigned in the order of input signal No. and output signal No.

Table 3-5: Dedicated input/output list

| Parameter                |                                                                                                                                                                      | Input                                                                                                                      | Note1) |                                           | Output                                                                    |
|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------------|---------------------------------------------------------------------------|
| name                     | Name                                                                                                                                                                 | Function                                                                                                                   | Level  | Name                                      | Function                                                                  |
| TEACHMD                  | None                                                                                                                                                                 |                                                                                                                            |        | Teaching mode output signal               | Outputs that the teaching mode is entered.                                |
| ATTOPMD                  |                                                                                                                                                                      | None                                                                                                                       |        | Automatic mode output signal              | Outputs that the automatic mode is entered.                               |
| ATEXTMD                  |                                                                                                                                                                      | None                                                                                                                       |        | Remote mode output signal                 | Outputs that the remote mode is entered.                                  |
| RCREADY                  |                                                                                                                                                                      | None                                                                                                                       |        | Controller power ON complete signal       | Outputs that external input signals can be received.                      |
| AUTOENA                  | Automatic opera-<br>tion enabled input<br>signal                                                                                                                     | Allows automatic operation.                                                                                                | L      | Automatic operation enabled output signal | Outputs the automatic operation enabled state.                            |
| START                    | Start input signal                                                                                                                                                   | Starts all slots.                                                                                                          | E      | Operating output sig-<br>nal              | Outputs that the slot is operating.                                       |
| STOP                     | Stop input signal                                                                                                                                                    | Stops all slots. The input signal No. is fixed to 0. Note) Use the emergency stop input for stop inputs related to safety. | L      | Wait output signal                        | Outputs that the slot is temporarily stopped.                             |
| STOP2                    | The program during operation is stopped. Unlike the STOP parameter, change of the signal number is possible. Notes) specification is the same as the STOP parameter. |                                                                                                                            | L      | Wait output signal                        | Outputs that the slot is temporarily stopped.                             |
| SLOTINIT                 | Program reset input signal Resets the wait state.                                                                                                                    |                                                                                                                            | Е      | Program selection enabled output signal   | Outputs that the slot is in the program selection enabled state.          |
| ERRRESET                 | Error reset input Resets the error state. signal                                                                                                                     |                                                                                                                            | Е      | Error occurring output signal             | Outputs that an error has occurred.                                       |
| CYCLE                    | Cycle stop input signal                                                                                                                                              | Carries out cycle stop.                                                                                                    | Е      | In cycle stop operation output signal     | Outputs that the cycle stop is operating.                                 |
| SRVOFF                   | Servo ON enabled input signal                                                                                                                                        | Turns the servo OFF for all mechanisms.                                                                                    | L      | Servo ON enabled output signal            | Outputs servo-on disable status. (Echo back)                              |
| SRVON                    | Servo ON input signal                                                                                                                                                | Turns the servo ON for all mechanisms.                                                                                     | E      | In servo ON output signal                 | Outputs the servo ON state.                                               |
| IOENA                    | Operation rights input signal                                                                                                                                        | Requests the operation rights for the external signal control.                                                             | L      | Operation rights output signal            | Outputs the operation rights valid state for the external signal control. |
| MELOCK                   | Machine lock input signal                                                                                                                                            | Sets/resets the machine lock state for all mechanisms.                                                                     | E      | In machine lock out-<br>put signal        | Outputs the machine lock state.                                           |
| SAFEPOS                  | Evasion point Requests the evasion point return return input signal operation.                                                                                       |                                                                                                                            | E      | In evasion point return output signal     | Outputs that the evasion point return is taking place.                    |
| OUTRESET                 | Γ General-purpose Resets the general-purpose output output signal reset signal.                                                                                      |                                                                                                                            | E      |                                           | None                                                                      |
| EMGERR                   | None                                                                                                                                                                 |                                                                                                                            |        | Emergency stop output signal              | Outputs that an emergency stop has occurred.                              |
| S1START<br>:<br>S32START | Start input Starts each slot.                                                                                                                                        |                                                                                                                            | E      | In operation output                       | Outputs the operating state for each slot.                                |
| S1STOP<br>:<br>S32STOP   | Stop input Stops each slot.                                                                                                                                          |                                                                                                                            | L      | In wait output                            | Outputs that each slot is temporarily stopped.                            |

| Parameter                       | . Input No.                                                                                                       |                                                                                     |       |                                                                                           | Output                                                                                                                                                                                                                 |  |
|---------------------------------|-------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| name                            | Name                                                                                                              | Function                                                                            | Level | Name                                                                                      | Function                                                                                                                                                                                                               |  |
| PRGSEL                          | Program selection input signal Designates the setting value for the program No. with numeric value input signals. |                                                                                     | E     |                                                                                           | None                                                                                                                                                                                                                   |  |
| OVRDSEL                         | Override selection input signal                                                                                   | Designates the setting value for the override with the numeric value input signals. | E     | None                                                                                      |                                                                                                                                                                                                                        |  |
| IODATA<br>Note2)                | Numeric value input<br>(start No., end No.)                                                                       | Used to designate the program name, override value., mechanism value.               | L     | Numeric value output<br>(start No., end No.)                                              | Used to output the program name, override value., mechanism No.                                                                                                                                                        |  |
| PRGOUT                          | Program No. out-<br>put request                                                                                   | Requests output of the program name.                                                | E     | Program No. output signal                                                                 | Outputs that the program name is being output to the numeric value output signal.                                                                                                                                      |  |
| LINEOUT                         | Line No. output request                                                                                           | Requests output of the line No.                                                     | E     | Line No. output signal                                                                    | Outputs that the line No. is being output to the numeric value output signal.                                                                                                                                          |  |
| OVRDOUT                         | Override value output request                                                                                     | Requests the override output.                                                       | E     | Override value out-<br>put signal                                                         | Outputs that the override value is being output to the numeric value output signal.                                                                                                                                    |  |
| ERROUT                          | Error No. output request                                                                                          | Requests the error No. output.                                                      | E     | Error No. output sig-<br>nal                                                              | Outputs that the error No. is being output to the numeric value output signal.                                                                                                                                         |  |
| JOGENA                          | Jog valid input sig-<br>nal                                                                                       | Validates jog operation with the external signals                                   | E     | Jog valid output sig-<br>nal                                                              | Outputs that the jog operation with external signals is valid.                                                                                                                                                         |  |
| JOGM                            | Jog mode input 2- Designates the jog mode. bit                                                                    |                                                                                     | L     | Jog mode output 2-<br>bit                                                                 | Outputs the current jog mode.                                                                                                                                                                                          |  |
| JOG+                            | Jog feed + side for 8-axes Requests the + side jog operation.                                                     |                                                                                     | L     |                                                                                           | None                                                                                                                                                                                                                   |  |
| JOG-                            | Jog feed - side for<br>8-axes                                                                                     | Requests the - side jog operation.                                                  | L     | None                                                                                      |                                                                                                                                                                                                                        |  |
| HNDCNTL1<br>:<br>HNDCNTL3       |                                                                                                                   |                                                                                     |       | Mechanism 1 hand<br>output signal status<br>:<br>Mechanism 3 hand<br>output signal status | Mechanism 1: Outputs the status of general-purpose outputs 900 to 907.  Mechanism 2: Outputs the status of general-purpose outputs 910 to 917.  Mechanism 3: Outputs the status of general-purpose outputs 920 to 927. |  |
| HNDSTS1<br>:<br>HNDSTS3         | None                                                                                                              |                                                                                     |       | Mechanism 1 hand<br>input signal status<br>:<br>Mechanism 3 hand<br>input signal status   | Mechanism 1: Outputs the status of hand inputs 900 to 907.  Mechanism 2: Outputs the status of hand inputs 910 to 917.  Mechanism 3: Outputs the status of hand inputs 920 to 927.                                     |  |
| HNDERR1<br>:<br>HNDERR3         | Mechanism 1 hand error input signal :  Mechanism 3 hand error input signal  Requests the hand error occurrence.   |                                                                                     | L     | Mechanism 1 hand<br>error output signal<br>:<br>Mechanism 3 hand<br>error output signal   | Outputs that a hand error is occurring.                                                                                                                                                                                |  |
| AIRERR1 : AIRERR3               | Pneumatic pressure error 1 input signal : Pneumatic pressure error 3 input signal                                 |                                                                                     | L     | Pneumatic pressure error 1 output signal. : Pneumatic pressure error 3 output signal.     | Outputs that a pneumatic pressure error is occurring.                                                                                                                                                                  |  |
| M1PTEXC<br>:<br>M3PTEXC         | None                                                                                                              |                                                                                     | L     | Maintenance parts replacement time warning signal                                         | Outputs that the maintenance parts have reached the replacement time.                                                                                                                                                  |  |
| USER-<br>AREA <sup>Note3)</sup> | None                                                                                                              |                                                                                     |       | User-designated area<br>8-points                                                          | Outputs that the robot is in the userdesignated area.                                                                                                                                                                  |  |

Note1) The level indicates the signal level.

L: Level signal → The designated function is validated when the signal is ON, and is invalidated when the signal is OFF.

E: Edge signal → The designated function is validated when the signal changes from the OFF to ON state, and the function maintains the original state even when the signal then turns OFF.

Note2) Four elements are set in the order of input signal start No., end No., output signal start No. and end No. Note3) Up to eight points can be set successively in order of start output signal No. and end output signal No.

### 3.6 Emergency stop input and output etc.

Do wiring of the external emergency stop, the special stop input, the door switch, and the enabling device from the "special input/output" terminal connector.

Table 3-6: Special input/output terminal

| Item   | Name                                                        | Function                                                                                                                |  |
|--------|-------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|--|
| Input  | Emergency stop                                              | Applies the emergency stop. Dual emergency line                                                                         |  |
| Input  | Special stop input                                          | Applies the stop. (Refer to Page 51, "3.6.2 Special stop input(SKIP)")                                                  |  |
| Input  | Door switch                                                 | Servo-off                                                                                                               |  |
| Input  | Enabling device                                             | Servo-off                                                                                                               |  |
| Output | Robot error output                                          | Contactor is opening during error occurrence                                                                            |  |
| Output | Mode output                                                 | MANUAL mode: contactor is opening, AUTO mode: contactor is closing                                                      |  |
| Output | Magnet contactor control connector output for addition axes | When an additional axis is used, the servo ON/OFF status of the additional axis can be synchronized with the robot arm. |  |

<sup>\*</sup>At the time of the power supply OFF, the output point of contact is always open.

[Note] The contact capacity of each input/output terminal is DC24V/10mA - 500mA. Don't connect the equipment except for this range. The use exceeding contact capacity causes failure.

Pin number assignment of each terminal and the circuit diagram are shown in Fig. 3-13.

## 3.6.1 Connection of the external emergency stop


The external emergency stop input and door switch input and enabling device input are opened at shipment as shown in Fig. 3-13.

Connect the external emergency stop switch and door switch with the following procedure.

- 1) Prepare the "emergency stop switch", "enabling device" and "door switch".
- 2) Securely connect the external emergency stop's contacts across 3A-4A, 3B-4B, and the door switch's contacts across 8A-9A, 8B-9B, and the enabling device switch's contacts across 10A-11A, 10B-11B, on the terminal block.

[Caution] When wiring the emergency stop switch (double emergency line type), wire both contacts to the two terminal blocks on the controller. If both contacts are wired to only one of the terminal blocks, errors cannot be cancelled using the door switch. The cable uses the shielded cable and installs the ferrite core. Install the ferrite core in less than 30cm from the contact button.

# <DU3-700/700M>



Pin allotment of EMGIN and the EMGOUT connector is shown in Page 50, "Fig.3-13: External emergency stop connection".

Fig.3-12 : Emergency stop cable connection(DU3-700)




Fig.3-13: External emergency stop connection



**CAUTION** Please be sure to install the emergency stop switch and it is connection to the controller, to stop the robot immediately at emergency




Be careful of the short circuit at cable connection. And, don't give plating solder to the electric wire. Loose connection may occur.

# 3.6.2 Special stop input(SKIP)

The skip is the input signal to stop the robot. Wire 1A-1B of the special stop connector (SKIP) shown in Page 52, "Fig.3-14: Connection of the special-stop-input".

Table 3-7 : Special stop input electric specification

|                                 | Item Specifications |                                             | Internal circuit |  |
|---------------------------------|---------------------|---------------------------------------------|------------------|--|
| Туре                            |                     | DC input                                    |                  |  |
| No. of input po                 | int                 | 1                                           |                  |  |
| Insulation meth                 | od                  | Phto-coupler insulation                     |                  |  |
| Rated inpit volt                | age                 | DC24V                                       | ı                |  |
| Rated input cu                  | rrent               | approx. 11mA                                | 1A<br>+24V(COM)  |  |
| Working voltage range           |                     | DC 21.6 ~ 26.4V<br>(Ripple rate within 5 %) | 330              |  |
| ON voltage/ON current           |                     | DC 8V or more / 2mA or more                 | 1B<br>2.2k Input |  |
| OFF voltage/O                   | FF current          | DC 4V or less / 1mA or less                 |                  |  |
| Input resistanc                 | е                   | approx. 2.2 k Ω                             |                  |  |
| Response OFF → ON               |                     | 1ms or less                                 |                  |  |
| time $ON \rightarrow OFF$       |                     | 1ms or less                                 |                  |  |
| Common method                   |                     | 1 point per common                          |                  |  |
| External wire connection method |                     | Connector                                   |                  |  |



<The connector connection method>

The electric wire skins covering 7mm.

In the condition that the minus driver is inserted, insert the electric wire, and remove the minus driver.

The electric wire is locked by the connector.

Fig.3-14: Connection of the special-stop-input

### 3.6.3 Door switch function

This function retrieves the status of the switch installed on the door of the safety fence, etc., and stops the robot when the door is opened. This differs from an emergency stop in that the servo turns OFF when the door is opened and an error does not occur. Follow the wiring example shown in Fig. 3–13, and wire so that the contact closes when the door is closed. Details of this function according to the robot status are shown below.

• During automatic operation ............When the door is opened, the servo turns OFF and the robot stops. An error occurs.

The process of the restoration : Close the door, reset the alarm, turn on the servo, and restart

• During teaching...... Even when the door is opened, the servo can be turned ON and the robot moved using the teaching pendant.




Fig.3-15: Door switch function

## 3.6.4 Enabling device function

When the abnormalities occur in teaching operations etc., the robot's servo power can be immediately cut only by switch operation of the enabling device Note1) (servo-off), and the safety increases. To use the robot safely, please be sure to connect the enabling device.

- When door is opening.....Please do teaching by two-person operations. One person has T/B, the other has enabling device. Turn on the servo power, in the condition that both of switches are pushed. (Enable switch of T/B and enabling device) Then the jog operation will be available. You can off the servo power only by releasing the switch of the enabling device. And, care that the servo-on and releasing the brake cannot be done in the condition that the switch of the enabling device is released.
- When door is closing.....You can turn on the servo power by operation of only T/B

Note1)Recommendation products: HE1G-L20MB (IDEC)

## 3.7 Additional Axis Function

This controller is equipped with an additional axis interface for controlling an additional axis when a traveling axis or rotary table is added to the robot. A maximum of eight axes of servo motors can be controlled at the same time by connecting a general-purpose servo amplifier (MR-J3-B series) that supports Mitsubishi's SSC Net III . Refer to the separate "Additional axis interface Instruction Manual" for details on the additional axis function.

# 3.7.1 Wiring of the Additional Axis Interface


Table 3-8 shows the connectors for additional axes inside the controller and Fig. 3-16 shows a connection example (configuration example). The magnet contactor control connector for additional axes, AXMC1, is designed to accommodate circuit connection with improved safety in Mitsubishi's industrial robot systems connecting additional axes.

Please implement the appropriate circuit connection by refere to Page 56, "3.8 Magnet contactor control connector output (AXMC) for addition axes".

Table 3-8: Dedicated Connectors inside the Controller

| Name                                                   | Connector name | Details                                                                                                       |
|--------------------------------------------------------|----------------|---------------------------------------------------------------------------------------------------------------|
| Connector for additional axes                          | OPT2           | This connector is used to connect between general-purpose servo amplifiers and the controller.                |
| Magnet contactor control connector for additional axes | EMGOUT         | This contact output is used to turn ON/OFF the motor power by connecting to general-purpose servo amplifiers. |

# <DU3-700/700M>



\*It cannot communicate, if connection of CN1A and CN1B is mistaken.

Fig.3-16: Example of addition axis connection (DU3-700/700M)

# 3.8 Magnet contactor control connector output (AXMC) for addition axes

When an additional axis is used, the servo ON/OFF status of the additional axis can be synchronized with the servo ON/OFF status of the robot itself by using the output contact (AXMC) provided on the rear or inside of the controller and configuring a circuit so that the power to the servo amplifier for the additional axis can be turned off when this output is open.

Fig. 3-17 shows an example of its circuit, and Fig. 3-18 show the layout drawings of the output contact (AXMC1). When you are using an additional axis, please perform appropriate circuit connections by referring to these draw-

Refer to the separate "Additional axis interface Instruction Manual" for details on the additional axis function.

Note1) you use the addition axis function as a user mechanism who became independent of the robot arm, please do not connect this output signal. Servo-on of the user mechanism may be unable.




Fig.3-17: Example of circuit for addition axes of Magnet contactor control output

# <DU3-700/700M> Safty unit (R700SFT) EMGOUT EMGOUT connector Internal circuit EMGOUT1 Contactor control output for addition axes (AXMC1) ⊗ 5A ⊗ 6A EMGOUT2 Contactor control output for addition axes (AXMC1) ⊗ 5B Electric wire plug area AWG#24~#18 (0.2~0.75mm²) ⊗ 6B Minus driver plug area (Custmer) (Controller) Type :1-1871940-6

Fig.3-18: EMGOUT connector (DU3-700/700M)

# 3.9 Options

## ■ What are options?

There are a variety of options for the robot designed to make the setting up process easier for user needs. User installation is required for the options.

Options come in two types: "set options" and "single options".

| 1. | Set optionsA combination of single options and parts that together, form a set for serving |  |
|----|--------------------------------------------------------------------------------------------|--|
|    | some purpose.                                                                              |  |

2. Single options......That are configured from the fewest number of required units of a part. Please choose user's purpose additionally.

# (1) Teaching pendant (T/B)

■ Order type: R32TB :Cable length 7m

R32TB-15 :Cable length 15m

#### Outline



This is used to create, edit and control the program, teach the operation position and for jog feed, etc.

For safety proposes, a 3-position enable switch is mounted. Note1)

## ■ Configuration

# Table 3-9: Configuration device

| Part name        | Туре     | Qty.           | Remarks                                      |
|------------------|----------|----------------|----------------------------------------------|
| Teaching pendant | R32TB    | Either one pc. | Cable length is 7m. Hand strap is attached.  |
|                  | R32TB-15 | Either one pc. | Cable length is 15m. Hand strap is attached. |

## ■ Specifications

#### Table 3-10: Specifications

| Items              | Specifications Remarks                                                |  |  |  |
|--------------------|-----------------------------------------------------------------------|--|--|--|
| Outline dimensions | 195(W) x 292(H) x 106(D) (refer to outline drawing)                   |  |  |  |
| Body color         | Dark gray                                                             |  |  |  |
| Mass               | rox. 0.9kg (only arm, excluding cable)                                |  |  |  |
| Connection method  | Connection with controller and square connector (24-pin)              |  |  |  |
| Interface          | RS-422                                                                |  |  |  |
| Display method     | LCD method: 24 characters x 8 lines, LCD illumination: with backlight |  |  |  |
| Operation section  | 36 keys                                                               |  |  |  |

Note1) <3-position enable switch>

In ISO/10218 (1992) and JIS-B8433 (1993), this is defined as an "enable device". These standards specify that the robot operation using the teaching pendant is enabled only when the "enable device" is at a specified position. With the Mitsubishi Electric industrial robot, the above "enable device" is configured of an "Enable/Disable switch" and "Deadman switch".

The 3-position deadman switch has three statuses. The following modes are entered according to the switch state.

3-59

<sup>&</sup>quot;Not pressed"......The robot does not operate. \*)

<sup>&</sup>quot;Pressed lightly"......The robot can be operated and teaching is possible.

<sup>&</sup>quot;Pressed with force" ......The robot does not operate.  $^{*)}$ 

<sup>\*)</sup> Operations, such as program editing and status display, other than robot operation are possible.

Safety is secured as the servo power is turned OFF simultaneously with the input of the emergency stop.




Fig.3-19: Outside dimensions of teaching pendant

## ■ Installation method

The teaching pendant is connected to the  $\ensuremath{\mathsf{T/B}}$  connector on the front of the controller.

## ■ Key layout and main functions




Fig.3-20: Teaching pendant key layout and main functions

## (2) Pneumatic hand interface

■ Order type: 2A-RZ365(Sink type)/2A-RZ375(Source type)

# Outline



This interface is required to use the robot arm's hand output signals. This interface is pre-installed on the controller.

- Up to eight hand output points can be used with this interface.
- The eight hand input points can be used without this interface.
- The previous pneumatic hand interface can be used. .

# ■ Configuration

Table 3-11 : Configuration device

| Part name                | Туре                  | Qty.    | Remarks                    |
|--------------------------|-----------------------|---------|----------------------------|
| Pneumatic hand interface | 2A-RZ365(Sink type)   | Either  | Output 8 points expansion. |
|                          | 2A-RZ375(Source type) | one pc. |                            |

#### ■ Specifications

Table 3-12: Specifications

| Item                               |        | Specification                                           | Internal circuit        |
|------------------------------------|--------|---------------------------------------------------------|-------------------------|
| Туре                               |        | Transistor output                                       | <sink type=""></sink>   |
| No. of output points               |        | 8                                                       | 24V                     |
| Insulation method                  |        | Photo coupler insulation                                | (Internal power supply) |
| Rated load voltage                 |        | DC24V                                                   | <b>十</b> 、              |
| Rated load voltage range           |        | DC21.6 to 26.4VDC                                       |                         |
| Max. current load                  |        | 0.1A/ 1 point (100%)                                    | GRn*                    |
| Current leak with power OFF        |        | 0.1mA or less                                           |                         |
| Maximum voltage drop with power ON |        | DC0.9V(TYP.)                                            |                         |
| Response time                      | OFF-ON | 2ms or less (hardware response time)                    | l                       |
|                                    | ON-OFF | 2 ms or less (resistance load) (hardware response time) | Fuse S                  |
| Fuse rating                        |        | Fuses 1.6A (each one common)                            | 1.6A                    |
| Common method                      |        | 8 points, 1 common                                      |                         |
|                                    |        |                                                         | 0V                      |
|                                    |        |                                                         | <source type=""/>       |
|                                    |        |                                                         | Fuse +24V<br>1.6A       |
|                                    |        |                                                         | GRn*                    |
|                                    |        |                                                         |                         |
|                                    |        |                                                         | 24GND(COM)              |
|                                    |        |                                                         | * GRn = GR1 ∼ GR8       |

#### ■ Installation method

This is mounted in the controller.

Attach the pneumatic hand interface (2A-RZ365/2A-RZ375) to the CNHNDOUT/CNHND connector of the hand interface relay card (2D-TZ315) securely. Refer to separate "Instruction Manual/ Controller setup, basic operation, and maintenance" for details on the installing method.




Fig.3-21: Installation of the pneumatic hand interface (DU3-700/700M)

## (3) RT ToolBox2/RT ToolBox2 mini

■ Order type : ● RT ToolBox2

\*For windows CD-ROM : 3D-11C-WINE

■ RT ToolBox2 mini

\*For windows CD-ROM : 3D-12C-WINE

#### Outline



This is handy software that fully uses the personal computer functions. It can be used in various stages from the robot specifications study (tact study, etc.) to the design support (creation and editing of programs), start up support (execution, control and debugging of program), and maintenance

The "personal computer support software" which supports these function fully, and the "personal computer support software mini" which does not have the simulation function are available.

#### ■ Configuration

Table 3-13: Product configuration

| Part name        | Туре        | Medium | Remarks |
|------------------|-------------|--------|---------|
| RT ToolBox2      | 3D-11C-WINE | CD-ROM |         |
| RT ToolBox2 mini | 3D-12C-WINE | CD-ROM |         |

#### ■ Features

(1) Simple operation with guidance method and menu method

The Windows standard is used for windows operation, so the controller initialization and startup operations can be carried out easily by following the instructions given on the screen. Even a beginner can easily carry out the series of operations from program creation to execution.

(2) Increased work efficiency with ample support functions

The work efficiency is greatly improved with the multi-window method that carries out multiple steps and displays in parallel. The renumbering function, and copy, search, syntax check and step execution are especially sufficient, and are extremely useful when editing or debugging the program.

With the simulation function support, the program can be debugged and the tact checked before starting the machine at the site. This allows the on-site startup work efficiently to be greatly improved.

## ■ Functions

Table 3-14: Functions

| Function                  |                        | Functional existence Note1) |                                                                                                                                                                                                                                                                                                                                                                                                                   | Details                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------|------------------------|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Compatible mode           | I                      | 0                           | 0                                                                                                                                                                                                                                                                                                                                                                                                                 | Personal computer running Microsoft Windows2000/XP/Vista.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Program editing functions | Editing functions      | 0                           | 0                                                                                                                                                                                                                                                                                                                                                                                                                 | MELFA BASIC V language compatible     Multiple editing screen simultaneously display     Command input, comment writing     Position data editing     File operation (writing to controller, floppy disk, personal computer)     Search and replace function (using characters, line Nos., labels)     Copy, cut, paste, insert (per character, line), undo (per command statement, position conversion)     Line No. automatic generation, renumbering     Batch syntax check     Command template     Position conversion batch editing     Position variable template     Print, print preview |
|                           | Control func-<br>tions | 0                           | 0                                                                                                                                                                                                                                                                                                                                                                                                                 | Program file control (list, copy, movement, delete, content comparison, name change, protect)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|                           | Debugging functions    | 0                           | 0                                                                                                                                                                                                                                                                                                                                                                                                                 | Direct editing of program in controller  Confirmation of robot program operation (step execution, direct execution)  Tact time measurement Note2)                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Simulation function       |                        | 0                           | ×                                                                                                                                                                                                                                                                                                                                                                                                                 | Off-line simulation of robot program operation using CG (computer graphics)     Tact time calculation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| tions O O                 |                        | 0                           | Robot operation monitor (robot operation state, stop signal, error monitor, program monitor (execution program, variables), general-purpose input/output signals (forced output possible), dedicated input/output signals, operation confirmation (operation range, current position, hand, etc.)     Operation monitor (working time statistics, production information, robot version)     Servo monitor (load) |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Maintenance function      |                        | 0                           | 0                                                                                                                                                                                                                                                                                                                                                                                                                 | Parameter setting     Batch, divided backup                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|                           |                        |                             |                                                                                                                                                                                                                                                                                                                                                                                                                   | RT ToolBox2 mini (3D-12C-WINE) RT ToolBox2 (3D-11C-WINE)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

Note1)The functions included with the RT ToolBox2 and the RT ToolBox2 mini are shown below.

O : Function provided × : Function not provided

Note2)When using the RT ToolBox2 mini, connect with the controller and measure.

# (4) Instruction Manual(bound edition)

■ Order type : ● 5S-QY00-PE01 (RV-18SQ-S/18SQC-S)

## Outline



This is a printed version of the CD-ROM (instruction manual) supplied with this product.

## ■ Configuration

Table 3-15: Product configuration(RV-18SQ-S/18SQC-S series)

|       | Name                                              | Туре         | Specifications                                                                                    |
|-------|---------------------------------------------------|--------------|---------------------------------------------------------------------------------------------------|
| İnstr | uction Manual                                     | 5S-QY00-PE01 |                                                                                                   |
|       | Safety Manual                                     | BFP-A5948    | Items relating to safety in handling the robot                                                    |
|       | Standard Specifications                           | BFP-A8767    | Specification of the robot arm and controller                                                     |
|       | Robot Arm Setup & Maintenance                     | BEP-A8/68    | Installation method of the robot arm, jog operation, and maintenance and inspection procedures    |
|       | Controller Setup, Basic Operation and Maintenance |              | Installation method of the controller, basic operation, and maintenance and inspection procedures |
|       | Detailed Explanation of Functions and Operations  | BED-A8586    | Functions of the controller and T/B, operation method, and explanation of MELFA-BASIC V           |
|       | Troubleshooting                                   | BFP-A8588    | Causes of errors occurred and their countermeasures                                               |
|       | Additional axis function                          | BFP-A8663    | Function of the additinal axis, operation method.                                                 |

# 3.10 Maintenance parts

The consumable parts used in the controller are shown in Table 3–16. Purchase these parts from your dealer when required. Some Mitsubishi–designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and controller serial No. and purchase the parts from your dealer.

Table 3-16: Contloller consumable parts list

| No.   | Name                | Type Note1) | Qty. | Usage place                      | Supplier                                        |  |  |  |
|-------|---------------------|-------------|------|----------------------------------|-------------------------------------------------|--|--|--|
| CR3Q- | CR3Q-700 controller |             |      |                                  |                                                 |  |  |  |
| 1     | Lithium battery     | Q6BAT       | 1    | Robot CPU unit                   |                                                 |  |  |  |
| 2     | Fan (40 square)     |             | 5    | Amplifier unit<br>Converter unit | Mitsubishi Electric Sys-<br>tem Service;Co.,Ltd |  |  |  |
| 3     | Fan (90 square)     |             | 1    | Control unit                     | tem Service;Co.,Ltd                             |  |  |  |
| 4     | Filter              |             | 1    | Controller rear                  |                                                 |  |  |  |

Note1)Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

## 4 Software

# 4.1 List of commands

The available new functions in MELFA-BASIC  $\,V\,$  are given in Table 4-1.

Table 4-1 : List of MELFA-BASIC  $\,V\,$  commands

| Туре                           | Class                       | Function                                                                                                                                                                    | Input format (example)                          |
|--------------------------------|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|
|                                | Joint interpolation         | Moves to the designated position with joint interpolation.                                                                                                                  | Mov P1                                          |
|                                | Linear interpolation        | Moves to the designated position with linear interpolation.                                                                                                                 | Mvs P1                                          |
|                                | Circular interpolation      | Moves along a designated arc (start point $\rightarrow$ passing point $\rightarrow$ start point (end point)) with 3-dimensional circular interpolation (360 degrees).       | Mvc P1,P2,P1                                    |
|                                |                             | Moves along a designated arc (start point $\rightarrow$ passing point $\rightarrow$ end point) with 3-dimensional circular interpolation.                                   | Mvr P1,P2,P3                                    |
|                                |                             | Moves along the arc on the opposite side of a designated arc (start point $\rightarrow$ reference point $\rightarrow$ end point) with 3-dimensional circular interpolation. | Mvr2 P1,P9,P3                                   |
|                                |                             | Moves along a set arc (start point $\rightarrow$ end point) with 3-dimensional circular interpolation.                                                                      | Mvr3 P1,P9,P3                                   |
|                                | Speed designation           | Designates the speed for various interpolation operations with a percentage (0.1% unit).                                                                                    | Ovrd 100                                        |
|                                |                             | Designate the speed for joint interpolation operation with a percentage (0.1% unit).                                                                                        | JOvrd 100                                       |
|                                |                             | Designates the speed for linear and circular interpolation with a numerical value (mm/s unit).                                                                              | Spd 123.5                                       |
| <u>,</u>                       |                             | Designates the acceleration/deceleration time as a percentage in respect to the predetermined maximum acceleration/deceleration. (1% unit)                                  | Accel 50,80                                     |
| ntr                            | Operation                   | Performance of movement is upgraded corresponding to the application.                                                                                                       | MvTune 4                                        |
| 8                              |                             | Adds a process unconditionally to the operation.                                                                                                                            | Wth                                             |
| ion                            |                             | Adds a process conditionally to the operation.                                                                                                                              | Wthif                                           |
| rat                            |                             | Designates smooth operation.                                                                                                                                                | Cnt 1,100,200                                   |
| bec                            |                             | Designates the positioning completion conditions with a No. of pulses.                                                                                                      | Fine 200                                        |
| ρ<br>P                         |                             | Designates the positioning completion conditions with a joint interpolation.                                                                                                | Fine 0.5, J, 2                                  |
| Position and operation control |                             | Designates the positioning completion conditions with a distance in a straight line                                                                                         | Fine 1, P                                       |
| sit                            |                             | Turns the servo power ON/OFF for all axes.                                                                                                                                  | Servo OFF                                       |
| Po                             |                             | Limits the operation of each axis so that the designated torque is not exceeded.                                                                                            | Torq 4,10                                       |
|                                | Position control            | Designates the base conversion data.                                                                                                                                        | Base P1                                         |
|                                |                             | Designates the tool conversion data.                                                                                                                                        | Tool P1                                         |
|                                | Pallet                      | Defines the pallet.                                                                                                                                                         | Def Plt 1,P1,P2,P3,P4,5,3,1                     |
|                                |                             | Operates the pallet grid point position.                                                                                                                                    | Plt 1,M1                                        |
|                                | Singular point pas-<br>sage | Move to a specified position using linear interpolation passing through a singular point.                                                                                   | Mvs P1 TYPE 0,2                                 |
|                                | Branching                   | Branches unconditionally to the designated place.                                                                                                                           | GoTo 120                                        |
|                                |                             | Branches according to the designated conditions.                                                                                                                            | If M1=1 Then GoTo 100<br>Else GoTo 20<br>End If |
|                                |                             | Repeats until the designated end conditions are satisfied.                                                                                                                  | For M1=1 TO 10                                  |
|                                |                             |                                                                                                                                                                             | Next M1                                         |
| Program control                |                             | Repeats while the designated conditions are satisfied.                                                                                                                      | While M1<10                                     |
| 9                              |                             |                                                                                                                                                                             | Wend                                            |
| ащ                             |                             | Branches corresponding to the designated expression value.                                                                                                                  | On M1 GOTO 100,200,300                          |
| ro gr                          |                             | Executes program block corresponding to the designated expression value                                                                                                     | Select                                          |
| Δ.                             |                             |                                                                                                                                                                             | Case 1                                          |
|                                |                             |                                                                                                                                                                             | Break                                           |
|                                |                             |                                                                                                                                                                             | Case 2                                          |
|                                |                             |                                                                                                                                                                             | Break<br>End Select                             |
|                                |                             | Moves the program process to the next line.                                                                                                                                 | Skip                                            |
| <u> </u>                       | Impact detection            | Set to enable/disable the impact detection.                                                                                                                                 | ColChk ON/OFF                                   |
|                                | Impact detection            | Set the detection level of the impact detection.                                                                                                                            | ColLvl 100,80,,,,,                              |
| ļ                              |                             | oet the detection level of the impact detection.                                                                                                                            | GGILVI 100,00,,,,,,                             |

| Туре               | Class              | Function                                                                                                    | Input format (example)   |
|--------------------|--------------------|-------------------------------------------------------------------------------------------------------------|--------------------------|
|                    | Subroutine         | Executes the designated subroutine. (Within program)                                                        | GoSub 200                |
|                    |                    | Returns from the subroutine.                                                                                | Return                   |
|                    |                    | Executes the designated program.                                                                            | CallP "P10",M1,P1        |
|                    |                    | Defines the program argument executed with the CALLP command.                                               | FPrm M10,P10             |
|                    |                    | Executes the subroutine corresponding to the designated expression value.                                   | On M1 GOSUB 100,200,300  |
|                    | Interrupt          | Defines the interrupt conditions and process.                                                               | Def Act 1, M1=1 GOTO 100 |
|                    |                    | Enables/disables the interrupt.                                                                             | Act 1=1                  |
| ro                 |                    | Defines the start line of the program to be executed when an interrupt is                                   | 0 0 (1) 000010 100       |
| Program control    |                    | generated from the communication line.                                                                      | On Com(1) GOSUB 100      |
| E                  |                    | Enables the interrupt from the communication line.                                                          | Com(1) ON                |
| gra                |                    | Disables the interrupt from the communication line.                                                         | Com(1) OFF               |
| Pro                |                    | Stops the interrupt from the communication line.                                                            | Com(1) STOP              |
|                    | Wait               | Designates the wait time, and the output signal pulse output time. (0.01s unit)                             | Dly 0.5                  |
|                    |                    | Waits until the variable becomes the designated value.                                                      | Wait M_IN(1)=1           |
|                    | Stop               | Stops the program execution.                                                                                | HIt                      |
|                    |                    | Generates an error. During program execution, continue, stop or servo OFF can be designated.                | Error 9000               |
|                    | End                | Ends the program execution.                                                                                 | End                      |
| рι                 | Hand open          | Opens the designated hand.                                                                                  | HOpen 1                  |
| Hand               | Hand close         | Closes the designated hand.                                                                                 | HClose 1                 |
| ¥                  | Assignment         | Defines the input/output variables.                                                                         | Def IO PORT1=BIT,0       |
| rt<br>Tbr          | Input              | Retrieves the general-purpose input signal.                                                                 | M1=M_IN (1)              |
| Input/output       | Output             | Calls out the general-purpose output signal.                                                                | M_Out(1) =0              |
| _                  | Mechanism designa- | Acquires the mechanism with the designated mechanism No.                                                    | GetM 1                   |
| tior               | tion               | Releases the mechanism with the designated mechanism No.                                                    | RelM 1                   |
| noe                | Selection          | Selects the designated program for the designated slot.                                                     | XLoad 2,"P102"           |
| ě                  | Start/stop         | Carries out parallel execution of the designated program.                                                   | XRun 3,"100",0           |
| le le              |                    | Stops parallel execution of the designated program.                                                         | XStp 3                   |
| Parallel execution |                    | Returns the designated program's execution line to the head and enters the program selection enabled state. | XRst 3                   |
|                    | Definition         | Defines the integer type or real number type variable.                                                      | Def Inte KAISUU          |
|                    |                    | Defines the character string variable.                                                                      | Def Char MESSAGE         |
|                    |                    | efines the layout variable. (Up to 3-dimensional possible)                                                  | Dim PDATA(2,3)           |
|                    |                    | Defines the joint variable.                                                                                 | Def Jnt TAIHI            |
|                    |                    | Defines the position variable.                                                                              | Def Pos TORU             |
|                    |                    | Defines the function.                                                                                       | Def FN TASU(A,B)=A+B     |
| Others             | Clear              | Clears the general-purpose output signal, variables in program, variables between programs, etc.            | Clr 1                    |
|                    | File               | Opens a file.                                                                                               | Open "COM1:" AS #1       |
|                    |                    | Closes a file.                                                                                              | Close #1                 |
|                    |                    | Inputs data from a file.                                                                                    | Input# 1,M1              |
|                    |                    | Outputs data to a file.                                                                                     | Print# 1,M1              |
|                    | Comment            | Describes a comment.                                                                                        | Rem "ABC"                |
|                    | Label              | Indicates the branching destination.                                                                        | *SUB1                    |

# 4.2 List of parameters

show the main parameter in the Table 4-2.

Table 4-2: List of parameters

| Parameter                  |                          | Details                                                                                                                                                                                                                                              |
|----------------------------|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Standard tool coordinates. | MEXTL                    | Set the default value for the tool data. Unit: mm or deg.                                                                                                                                                                                            |
| Standard base coordinates  | MEXBS                    | Set the relation of the world coordinate system and robot coordinate system.  Unit: mm or deg.                                                                                                                                                       |
| XYZ operation range        | MEPAR                    | Designate the overrun limit value for the world coordinate system.                                                                                                                                                                                   |
| JOINT operation range      | MEJAR                    | Set the overrun limit value for each joint axis.                                                                                                                                                                                                     |
| Free plane limit           |                          | This is the overrun limit set with the free plane. Create a plane with the three coordinates x1, y1, z1 to x3, y3, z3, and set the outer side of the plane as the outside operation range (error). The following three types of parameters are used. |
|                            | SFC1P<br>:<br>SFC8P      | Eight types of free plane limits can be set in SFC1P to SFC8P.  There are nine elements, set in the order of x1, y1, z1, x2, y2, z2, x3, y3, z3.                                                                                                     |
|                            | SFC1ME<br>:<br>SFC8ME    | Designate which mechanism to use eight types of set free plane limits.  The mechanism No. to use is set with 1 to 8.                                                                                                                                 |
|                            | SFC1AT<br>:<br>SFC8AT    | Set the validity of the eight types of set free plane limits. (Valid $1/Valid\ 2/invalid\ =\ 1/-1/0$ )                                                                                                                                               |
| User-defined area          |                          | An area (cube) defined with two XYZ coordinate points can be designated and that area set as the outside operation range. Furthermore, a signal can be output when the axis enters that area. Up to 32 types of area can be designated.              |
|                            | AREA1CS<br>:<br>AREA32CS | Specify the coordinate system of the user definition area *.  0: Base coordinate system (conventional compatibility)  1: Robot coordinate system                                                                                                     |
|                            | AREA1P1<br>:<br>AREA32P1 | Designated the 1st point of the area.  There are eight elements, set in the order of x, y, z, a, b, c, L1, L2.  (L1 and L2 are the additional axes.)                                                                                                 |
|                            | AREA1P2<br>:<br>AREA32P2 | Designated the 2nd point of the area.  There are eight elements, set in the order of x, y, z, a, b, c, L1, L2.  (L1 and L2 are the additional axes.)                                                                                                 |
|                            | AREA1ME<br>:<br>AREA32ME | Designate which mechanism to use the eight types of set area.  The mechanism No. to use is set with 1 to 8                                                                                                                                           |
|                            | AREA1AT<br>:<br>AREA32AT | Designate the area check type. (Invalid/zone/interference = 0/1/2) Zone: The dedicated output signal USRAREA turns ON. Interference: An error occurs                                                                                                 |
| Automatic return setting   | RETPATH                  | Set to restart the program after returning to the interrupt position when resuming operation after an interruption.                                                                                                                                  |
| Buzzer ON/OFF              | BZR                      | Designate whether to the turn buzzer ON or OFF.                                                                                                                                                                                                      |
| Jog setting                | JOGJSP                   | Designate the joint jog and step operation speed. (Set dimension H/L amount, max. override.)                                                                                                                                                         |
|                            | JOGPSP                   | Designate the linear jog and step operation speed. (Set dimension H/L amount, max. override.)                                                                                                                                                        |
| Jog speed limit value      | JOGSPMX                  | Limit the operation speed during the teaching mode. Max. 250[mm/s]                                                                                                                                                                                   |

| Parameter                                            |                    | Details                                                                                                                                                                                                                 |
|------------------------------------------------------|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hand type                                            | HANDTYPE           | Set the hand type of the single/double solenoid, and the signal No. (Single/double = S/D) Set the signal No. after the hand type. Example) D900                                                                         |
| Stop input B contact designation                     | INB                | Change the dedicated input (stop) between the A contact and B contact.                                                                                                                                                  |
| User-designated origin                               | USERORG            | Designate the user-designated origin position.                                                                                                                                                                          |
| Program selection memory                             | SLOTON             | Select the program selected previously when initializing the slot. The non-selected state will be entered when not set.                                                                                                 |
| Communication setting                                | CBAU232            | Set the baud rate.                                                                                                                                                                                                      |
|                                                      | CLEN232            | Set the character length.                                                                                                                                                                                               |
|                                                      | CPRTY232           | Set the parity.                                                                                                                                                                                                         |
|                                                      | CSTOP232           | Set the stop bit.                                                                                                                                                                                                       |
|                                                      | CTERM232           | Set the end code.                                                                                                                                                                                                       |
| Slot table                                           | SLT1<br>:<br>SLT32 | Make settings (program name, operation type, order of priority, etc.) for each slot during slot initialization.                                                                                                         |
| No. of multi-tasks                                   | TASKMAX            | Designate the No. of programs to be executed simultaneously. (Max. 32)                                                                                                                                                  |
| Select the function of singular point adjacent alarm | MESNGLSW           | Designate the valid/invalid of the singular point adjacent alarm. (Invalid/Valid = $0/1$ ) When this parameter is set up "VALID", this warning sound is buzzing even if parameter: BZR (buzzer ON/OFF) is set up "OFF". |
| Specification of singular point passage jog mode     | FSPJOGMD           | Specify an operation mode for singular point passage jog.                                                                                                                                                               |
| Display language.                                    | LNG                | Change the language to display on the LCD display of teaching pendant.                                                                                                                                                  |

## 5 Instruction Manual

# 5.1 The details of each instruction manuals

The contents and purposes of the documents enclosed with this product are shown below. Use these documents according to the application.

Instruction manuals enclosed in dashed lines in the list below are for optional products.

For special specifications, a separate instruction manual describing the special section may be enclosed.

Safety Manual

Explains the common precautions and safety measures to be taken for robot handling, system design and manufacture to ensure safety of the operators involved with the robot.

Standard Specifications Explains the product's standard specifications, factory-set special specifications, option configuration and maintenance parts, etc. Precautions for safety and technology, when incorporating the robot, are also explained.

Robot Arm Setup & Maintenance Explains the procedures required to operate the robot arm (unpacking, transportation, installation, confirmation of operation), and the maintenance and inspection procedures.

Controller Setup, Basic Operation and Maintenance

Explains the procedures required to operate the controller (unpacking, transportation, installation, confirmation of operation), basic operation from creating the program to automatic operation, and the maintenance and inspection procedures.

Detailed Explanation of Functions and Operations

Explains details on the functions and operations such as each function and operation, commands used in the program, connection with the external input/output device, and parameters, etc.

Troubleshooting

Explains the causes and remedies to be taken when an error occurs. Explanations are given for each error No.

Additional axis function

Explains the specifications, functions and operations of the additional axis control.

# 6 Safety

# 6.1 Safety

Measures to be taken regarding safety of the industrial robot are specified in the "Labor Safety and Sanitation Rules". Always follow these rules when using the robot to ensure safety.

## 6.1.1 Self-diagnosis stop functions

This robot has the self-diagnosis stop functions shown in Table 6-1 and the stop functions shown in Table 6-2 for safe use.

Table 6-1: Self-diagnosis stop functions

| No. | Function                                 |                    | Details                                                                                     | Remarks                                                                |                                                                                                                           |                                                                        |
|-----|------------------------------------------|--------------------|---------------------------------------------------------------------------------------------|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
| 1   | Overload protection function             |                    | Activates when the total servo current time exceeds the specified value.                    | The drive circuit is shut off. The robot stops, and an alarm displays. |                                                                                                                           |                                                                        |
| 2   | Overcurrent function                     | diagnosis          | Activates when an overcurrent flows to the motor circuit.                                   | The drive circuit is shut off. The robot stops, and an alarm displays. |                                                                                                                           |                                                                        |
| 3   | Encoder disconnection diagnosis function |                    |                                                                                             |                                                                        | Activates when the encoder cable is disconnected.                                                                         | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 4   | Deflection over diagnosis function       |                    | function ma                                                                                 |                                                                        | Activates when an error occurs between the command value and actual position, and the error exceeds the specified amount. | The drive circuit is shut off. The robot stops, and an alarm displays. |
| 5   | AC power voltage drop diagnosis function |                    | Activates when the AC power voltage drops below the specified value.                        | The drive circuit is shut off. The robot stops, and an alarm displays. |                                                                                                                           |                                                                        |
| 6   | CPU error detection function             |                    | Activates when an error occurs in the CPU.                                                  | The drive circuit is shut off. The robot stops, and an alarm displays. |                                                                                                                           |                                                                        |
| 7   | Overrun Software prevention detection    |                    | This is the limit provided by the software to enable operation only in the operation range. | The drive circuit is shut off. The robot stops, and an alarm displays. |                                                                                                                           |                                                                        |
|     | function                                 | Mechanical stopper | This is the mechanical stopper provided outside the software.                               | The robot mechanically stops, and function 1 or 2 activates.           |                                                                                                                           |                                                                        |

Table 6-2: List of stop functions

| Table 0 2 . Elst of stop functions |                 |                  |                |                                                                                                                                                                                                                                     |  |
|------------------------------------|-----------------|------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| Stop<br>function                   | Operation panel | Teaching pendant | External input | Details                                                                                                                                                                                                                             |  |
| Emergency<br>stop                  | 0               | 0                | 0              | This is the stop with the highest degree of emergency. The servo power is shut off, and the mechanical brakes (all axes) activate to stop the robot.  To recover, reset the alarm, and turn the servo ON with the servo ON command. |  |
| Stop                               | 0               | 0                | 0              | This is a stop operation with a high degree of emergency. The robot immediately decelerates and stops.  Note that the servo power is not shut off. Use this when using the collision evasion sensor, etc.                           |  |

## 6.1.2 External input/output signals that can be used for safety protection measures

Table 6-3: External input/output signals that can be used for safety protection measures

|        | Signal                          | Command              | Functions                                                                               | Usage method                                                                                                                   |
|--------|---------------------------------|----------------------|-----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|        | External emer-<br>gency stop    | Terminal<br>(EMG IN) | This servo power is shut off, and the robot stops immediately.                          | Externally installed emergency stop switch.  Door switch on safety protection fence.  Stopping at high-level error occurrence. |
|        | Door switch                     |                      |                                                                                         | The door switch of the safe protection fence                                                                                   |
| Input  | Enabling device input           |                      |                                                                                         | Enabling device. The safety switch during teaching work                                                                        |
| In     | Stop                            | STOP                 | The program execution is stopped, and the robot stops. The servo power is not shut off. | The robot is stopped when a peripheral device fault occurs. The servo power is not shut off.                                   |
|        | Servo OFF                       | SRVOFF               | The servo power can be shut off.                                                        | The robot is stopped when a peripheral device fault occurs. The servo power is not shut off.                                   |
|        | Automatic opera-<br>tion enable | AUTOENA              | Disables automatic operation when inactive.                                             | Door switch on safety protection fence                                                                                         |
|        | In servo ON                     | SRVON                | The servo power ON/OFF state is output.                                                 | The servo power ON/OFF state is shown and alerted with the display lamps.                                                      |
| Output | Waiting                         | STOP                 | Outputs that the robot is temporarily stopped.                                          | The temporary stop state is shown and alerted with the display lamps.                                                          |
|        | In alarm                        | ERRRESET             | Outputs when an alarm occurs in the robot.                                              | The alarm state is shown and alerted with the display lamps.                                                                   |

[Caution] The external emergency stop input is prepared as a b contact for safety proposes. Thus, if the emergency stop input circuit is opened when the robot is started up, the robot will not operate. Refer to Page 76, "6.1.7 Examples of safety measures" for details.

#### 6.1.3 Precautions for using robot

The safety measures for using the robot are specified in the "Labor Safety and Sanitation Rules". An outline of the rules is given below.

## (1) Robot installation

- Secure sufficient work space required to safely perform work such as teaching and maintenance related to the robot.
- Install the controller outside the robot's motion space. (If a safety fence is provided, install outside the fence.)
- Install the controller where the entire robot operation can be viewed.
- Install display lamps, etc., to indicate the robot's operation state.
- Securely fix the robot arm onto the fixing table with the designated bolts.

#### (2) Prevention of contact with operator

- Install a safety fence or enclosure so that the operator cannot easily enter the robot's motion space.
- Install an interlock function that will stop the robot if the safety fence or enclosure door is opened.

#### (3) Work procedures

- · Create and observe work procedures for the robot teaching, operation, inspection and emergencies.
- Create hand signals to be followed when several operators are working together.
- Create displays such as "Teaching in Progress" and "Inspection in Progress" to be put up when an operator is in the robot's motion space so that other operators will not operate the operation panel (controller, control panel).

#### (4) Training

- Train the operators about the operations, maintenance and safety required for the robot work.
- Only trained and registered operators must operate the robot.
   Participation in the "Special training for industrial robots" sponsored by the Labor Safety and Sanitation Committee, etc., is recommended for safety training.

### (5) Daily inspection and periodic inspection

- Iways inspect the robot before starting daily operations and confirm that there are no abnormalities.
- Set the periodic inspection standards in view of the robot's ambient environment and operation frequency, and perform periodic inspections.
- Make records when periodic inspections and repairs have been done, and store the records for three or more years.

#### 6.1.4 Safety measures for automatic operation

- (1) Install safety fences so that operators will not enter the operation area during operation and indicate that automatic operation is in progress with lamps, etc.
- (2) Create signals to be given when starting operation, assign a person to give the signal, and make sure that the operator follows the signals.

### 6.1.5 Safety measures for teaching

Observe the following measures when teaching, etc., in the robot's operation range.

- (1) Specify and follow items such as procedures related to teaching work, etc.
- (2) Take measures so that operation can be stopped immediately in case of trouble, and measures so that operation can be restarted.
- (3) Take measures with the robot start switch, etc., to indicate that teaching work is being done.
- (4) Always inspect that stop functions such as the emergency stop device before starting the work.
- (5) Immediately stop the work when trouble occurs, and correct the trouble.
- (6) Take measures so that the work supervisor can immediately stop the robot operation when trouble occurs.
- (7) The teaching operator must have completed special training regarding safety. (Training regarding industrial robots and work methods, etc.)
- (8) Create signals to be used when several operators are working together.

### 6.1.6 Safety measures for maintenance and inspections, etc.

Turn the power OFF and take measures to prevent operators other than the relevant operator from pressing the start switch when performing inspections, repairs, adjustments, cleaning or oiling.

If operation is required, take measures to prevent hazards caused by unintentional or mistaken operations.

- (1) Specify and follow items such as procedures related to maintenance work, etc.
- (2) Take measures so that operation can be stopped immediately in case of trouble, and measures so that operation can be restarted.
- (3) Take measures with the robot start switch, etc., to indicate that work is being done.
- (4) Take measures so that the work supervisor can immediately stop the robot operation when trouble occurs.
- (5) The operator must have completed special training regarding safety. (Training regarding industrial robots and work methods, etc.)
- (6) Create signals to be used when several operators are working together.

#### 6.1.7 Examples of safety measures

Two emergency-stop input circuits are prepared on the user wiring terminal block of the controller. Create a circuit as shown below for safety measures. In addition, the figure shows the normal state which is not in the emergency stop state.




Fig.6-1: Example of safety measures (Wiring example 1)




Fig.6-2: Example of safety measures (Wiring example 2)




Fig.6-3: Example of safety measures (Wiring example 3)




Fig.6-4: Example of safety measures (Wiring example 4)

(Wiring example 5): Connect the emergency stop switch of peripheral equipment, and the door switch to two robot controllers, and it interlocks. Connect the enabling device to the robot controller. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side. Operation of the emergency stop> If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of robot controller OFF, peripheral equipment state can be the emergency stop also. Emergency stop switch (4- contact type) \*1) Peripheral equipment Robot controller #1 \*1) \*2) \*5) Power supply in the robot controller 24V FMGIN1/2 \*2) Power supply24V OP 1A/1B -1 ¹ Not connected Emer-2A/2B gency stop 3A/3B Circuit -(RA \*7) button 4A/4B \*6) 5A/5B ΤB 6A/6B 【**\*3**) Emer-gency stop 7A/7B Door switch input button \*4) Monitor 9A/9B 0A/10B <del>-</del>0 1<u>A/11B</u>L \*8) EMGOUT1/2 Internal emergency 1A/1B stop circuit Safety fence doo 2A/2B | Error output 3A/3B 5A/5B Monitor مزما 6A/6B Robot controller #1 \*5) OP Emer-gency stop Power supply in the robot controller 24V EMGIN1/2 \*2) 1A/1B 4 Not connected 2A/2B 3A/3B (RA) button \*7)<sub>(RA)</sub> 4A/4B \*6) 5A/5B TB 6A/6B ( \*3) Emergency Monitor 7A/7B Door switch input \*4) button 010 9A/9B (RA) 11A/11B Enabling device 10A/10B ⊸ (RA) \*1)EMGIN1/2, and EMGOUT1/2 have the two terminals separately, and show that they are the two lines. Always connect the two lines \*8) If necessary to stop two robots simultaneously by one emergency stop switch please use the 4 contact type emergency stop switch. EMGOUT1/2 \*2) 1A/1B, and 2A/2B terminal of EMGIN is short-circuited at factory Internal emergency 1A/1B shipments. Remove it, and connect the emergency stop switch 2A/2B ] Error output stop circuit and power supply of peripheral equipment. Connect the power 3A/3B supply of peripheral equipment by the polarity shown in the figure. \*3)5A/5B, and 6A/6B terminal of EMGIN is short-circuited at 5A/5B 6A/6B Contactor control output for additional axes factory shipments. Remove it and connect with the power supply ground of peripheral equipment. Notes) Please use 5A/5B and 6A/6B terminal, connected. \*4) Please use a A contact type of the relay with the compulsive guide. \*5) The emergency stop button of the robot controller operation panel. \*6) The emergency stop button of T/B connected to the robot controller. \*7) Emergency stop input relay. \*8) Refer to Page 53, "3.6.4 Enabling device function" for the enabling device. [Caution] Since we have omitted the information in part because of explanation, there is the section different from the product. Also refer to Page 50, "Fig.3-13: External emergency stop connection".

Fig.6-5: Example of safety measures (Wiring example 5)

- (1) Use a 2-contact type switch for all switches.
- (2) Install a limit switch on the safety fence's door. With a constantly open contact (a contact), wire to the door switch input terminal so that the switch turns ON (is conducted) when the door is closed, and turns OFF (is opened) when the door is open.
- (3) Use a manual-return type 2b-contact for the emergency stop button.
- (4) Classify the faults into minor faults (faults that are easily restored and that do not have a great effect) and major faults (faults that cause the entire system to stop immediately, and that require care in restoration), and wire accordingly.

[Caution] The emergency stop input(terminal block) on the user wiring in the controller can be used for safety measures as shown in Fig. 6-1 to Fig. 6-5. Note that there are limits to the No. of switch contacts, capacity and cable length, so refer to the following and install.

| Switch contact          | Prepare a 2-contact type.                                     |
|-------------------------|---------------------------------------------------------------|
| Switch contact capacity | Use a contact that operates with a switch contact capacity of |
|                         | approx. 1mA to 100mA/24V. Note1)                              |
| Cable length            | The length of the wire between the switch and terminal block  |
|                         | must be max. 15m or less. Please use the shield line, in case |
|                         | of the cable may receive the noise etc. by other equipment,   |

such as servo amplifier. And, since the ferrite core is attached as noise measures parts, please utilize.

Note1)The minimum load electric current of the switch is more than 5mA/24V.

## 6.2 Working environment

Avoid installation in the following places as the equipment's life and operation will be affected by the ambient environment conditions. When using in the following conditions, the customer must pay special attention to the preventive measures.

## (1) Power supply

- · Where the voltage fluctuation will exceed the input voltage range.
- Where a momentary power failure exceeding 20ms may occur.
- · Where the power capacity cannot be sufficiently secured.



Please use the controller with an input power supply voltage fluctuation rate of 10% or less. In the case of 200 VAC input, for example, if the controller is used with 180 VAC during the day and 220 VAC during the night, turn the servo off once and then on again. If this is not performed, an excessive regeneration error may occur.

#### (2) Noise

• Where a surge voltage exceeding 1000V, 1  $\mu$  s may be applied on the primary voltage. Near large inverters, high output frequency oscillator, large contactors and welding machines. Static noise may enter the lines when this product is used near radios or televisions. Keep the robot away from these items.

#### (3) Temperature and humidity

- Where the atmospheric temperature exceeds 40 degree, lower than 0 degree.
- Where the relative humidity exceeds 85%, lower than 45%, and where dew may condense.
- · Where the robot will be subject to direct sunlight or near heat generating sources such as heaters.

#### (4) Vibration

• Where excessive vibration or impact may be applied. (Use in an environment of 34m/s<sup>2</sup> or less during transportation and  $5m/s^2$  or less during operation.)

### (5) Installation environment

- Where strong electric fields or magnetic fields are generated.
- Where the installation surface is rough. (Avoid installing the robot on a bumpy or inclined floor.)
- · Where there is heavy powder dust and oil mist present.

## 6.3 Precautions for handling

- (1) This robot has brakes on all axes. The precision of the robot may drop, looseness may occur and the reduction gears may be damaged if the robot is moved with force with the brakes applied.
- (2) Avoid moving the robot arm by hand. When unavoidable, gradually move the arm. If moved suddenly, the accuracy may drop due to an excessive backlash, or the backed up data may be destroyed.
- (3) Note that depending on the posture, even when within the movement range, the wrist section could interfere with the base section. Take care to prevent interference during jog. Note 1)
- (4) The robot arm is configured of precision parts such as bearings. Grease is used for lubricating these parts. When cold starting at low temperatures or starting operation after long-term stoppage, the position accuracy may drop or servo alarms may occur. If these problems occur, perform a 5 to 10 minute running-in operation at a low speed (about a half of normal operating speed).
- (5) The robot arm and controller must be grounded with Class D grounding to secure the noise resistance and to prevent electric shocks.
- (6) The items described in these specifications are conditions for carrying out the periodic maintenance and inspections described in the instruction manual.
- (7) When using the robot arm on a mobile axis or elevating table, the machine cables enclosed as standard configuration may break due to the fixed installation specifications. In this case, use the machine cable extension (for flexed)" factory shipment special specifications or options.
- (8) If this robot interferes with the workpiece or peripheral devices during operation, the position may deviate, etc. Take care to prevent interference with the workpiece or peripheral devices during operation.
- (9) Do not attach a tape or a label to the robot arm and the controller. If a tape or a label with strong adhesive power, such as a packaging tape, is attached to the coated surfaces of the robot arm and controller, the coated surface may be damaged when such tape or label is peeled off.
- (10) If the robot is operated with a heavy load and at a high speed, the surface of the robot arm gets very hot. It would not result in burns, however, it may cause secondary accidents if touched carelessly.
- (11) Do not shut down the input power supply to stop the robot. If the power supply is frequently shut down during a heavy load or high-speed operation, the speed reducer may be damaged, backlash may occur, and the program data may be destroyed.
- (12) If the J1, J2 and J3 axes collide with the mechanical stopper during the automatic operation of the robot, it is necessary to replace the resin part of the mechanical stopper unit. For the replacement of the resin parts, please contact Mitsubishi or Mitsubishi's dealer.
  - If the resin part is not replaced, the mechanism unit and the speed reducer may be damaged significantly when the axes collide with the mechanical stopper next or subsequent time.
- (13) During the robot's automatic operation, a break is applied to the robot arm when the input power supply is shut down by a power failure, for instance. When a break is applied, the arm may deviate from the operation path predetermined by automatic operation and, as a result, it may interfere with the mechanical stopper depending on the operation at shutdown. In such a case, take an appropriate measure in advance to prevent any dangerous situation from occurring due to the interference between the arm and peripheral devices. Example) Installing a UPS (uninterruptible power supply unit) to the primary power source in order to reduce interference.
- (14) Do not conduct an insulated voltage test. If conducted by mistake, it may result in a breakdown. If conducting an insulation test, although it is not covered by warranty, set the leakage current to 100 mA. If a leakage current of 10 mA is set, a low measurement value will be shown due to the leakage current of the built-in AC line filter.
- (15) Fretting may occur on the axis which moving angle or moving distance move minutely, or not moves. Fretting is that the required oil film becomes hard to be formed if the moving angle is small, and wear occurs. The axis which not moved is moving slightly by vibration etc. To make no fretting recommends to move these axes about once every day the 30 degree or more, or the 30mm or more.

Note1) Jog operation refers to operating the robot manually using the teaching pendant.

|                        |                                             | informati           | on           |                                                           |                     |                                 |                                                                         |                                  |  |  |
|------------------------|---------------------------------------------|---------------------|--------------|-----------------------------------------------------------|---------------------|---------------------------------|-------------------------------------------------------------------------|----------------------------------|--|--|
| Company name           |                                             |                     |              |                                                           |                     |                                 | Name                                                                    |                                  |  |  |
| Address                |                                             |                     |              |                                                           |                     | Telephone                       |                                                                         |                                  |  |  |
| urcl                   | hased                                       | d mode              |              |                                                           |                     |                                 |                                                                         |                                  |  |  |
| Specification          |                                             |                     | Туре         |                                                           |                     |                                 |                                                                         |                                  |  |  |
| Standard specification |                                             |                     | □ RV-18SQ-S  |                                                           |                     |                                 |                                                                         |                                  |  |  |
| Clean specification    |                                             |                     | □ RV-18SQC-S |                                                           |                     |                                 |                                                                         |                                  |  |  |
| Shipp                  | oing s                                      | special spe         | ecificati    | ons (S                                                    | ettings can be m    | nade only                       | at time of shipme                                                       | nt)                              |  |  |
| <b>I</b> tem           |                                             |                     |              | Standard specifications                                   |                     | Special shipping specifications |                                                                         |                                  |  |  |
| Conti                  | roller                                      | Structure           | ructure      |                                                           | ☐ Floor type        |                                 | ☐ Caster type                                                           |                                  |  |  |
|                        |                                             |                     |              | CR3D-709M(IP54): RV-18SQ-S<br>CR3D-709(Clean): RV-18SQC-S |                     |                                 | CR3D-709M(IP54): RV-18SQ-S<br>CR3D-709(Clean): RV-18SQC-S               |                                  |  |  |
| \~+:~                  | (I                                          | l<br>nstallable     | oft on ok    | l                                                         |                     | U-S                             | GR3D=709(Glean) : RV                                                    | -185QC-S                         |  |  |
| puc                    | ons (I                                      | ristaliable<br>Item | arter sr     | iipmer                                                    | Type                |                                 | Dravisian and                                                           | specifications when provided     |  |  |
|                        | Operating range change                      |                     |              |                                                           | 1S-DH-01            | □ N <sub>ℓ</sub>                | Provision, and specifications when provided.  □ Not provided □ Provided |                                  |  |  |
|                        | Machine cable extention  Solenoid valve set |                     |              |                                                           | 1S- □□ CBL-02       |                                 | □ Not provided □ 5m fixing □ 10m fixing □ 15m fixing                    |                                  |  |  |
| _                      |                                             |                     |              |                                                           | 1S- □□ LCBL-02      |                                 | □ Not provided □ 5m bending □ 10m bending □ 15m bending                 |                                  |  |  |
| Robot arm              |                                             |                     |              |                                                           | 1S-VD0 □ -01        |                                 | □ Not provided □ 1 set □ 2 sets □ 3 sets □ 4 stes                       |                                  |  |  |
| bot                    |                                             |                     |              |                                                           | 1S-VD0 □ E-01       |                                 | ☐ Not provided ☐ 1 set ☐ 2 sets ☐ 3 sets ☐ 4 stes                       |                                  |  |  |
| ಹ                      | Hand input cable                            |                     |              |                                                           | 1S-HC25C-01         | □ No                            | ☐ Not provided ☐ Provided                                               |                                  |  |  |
|                        | Hand                                        | Hand output cable   |              |                                                           | 1S-GR35S-01         | □No                             | ☐ Not provided ☐ Provided                                               |                                  |  |  |
|                        | Hand                                        | l curl tube         |              |                                                           | 1N-ST060 □ C        | □ No                            | ☐ Not provided ☐ 1 set ☐ 2 sets ☐ 3 sets ☐ 4 stes                       |                                  |  |  |
| Controller             | Simple teaching pendant                     |                     |              |                                                           | R32TB- □□           | □ No                            | □ Not provided □ 7m □ 15m                                               |                                  |  |  |
|                        | Highly efficient teaching pendant           |                     |              | nt                                                        | R56TB- □□           | ☐ No                            | □ Not provided □ 7m □ 15m                                               |                                  |  |  |
|                        | Pneumatic hand interface                    |                     |              |                                                           | 2A-RZ365/2A-RZ3     | 75 🗆 No                         | □ Not provided □ 2A-RZ365(Sink) □ 2A-RZ375(Source)                      |                                  |  |  |
|                        | RT ToolBox2                                 |                     |              |                                                           | 3D-11C-WINE         | ☐ No                            | □ Not provided □ Windows2000/XP/Vista Englishi CD-ROM                   |                                  |  |  |
|                        | RT ToolBox2 mini                            |                     |              |                                                           | 3D-12C-WINE         |                                 | □ Not provided □ Windows2000/XP/Vista Englishi CD-ROM                   |                                  |  |  |
|                        | Network vision sensor                       |                     |              | 4D-2CG5***-PKG                                            |                     |                                 |                                                                         |                                  |  |  |
|                        | Instructions manual                         |                     |              | 5S-QY00-PE01 ☐ Not p                                      |                     | ot provided  Provided ( ) set   |                                                                         |                                  |  |  |
| <b>Maint</b>           | tenar                                       | ice parts           | (Consun      | nable į                                                   | oarts)              |                                 |                                                                         |                                  |  |  |
| Mai                    | ntena                                       | nce parts           | ☐ Back       | up batte                                                  | eries A6BAT ( ) pc: | s. 🛮 Bad                        | kup batteries Q6BAT                                                     | ( ) pcs.                         |  |  |
| Robo                   | t sele                                      | ection che          | eck list     |                                                           |                     |                                 |                                                                         |                                  |  |  |
|                        | descr                                       |                     |              | andring                                                   | ☐ Assembly ☐ Ma     | chining L                       | UL ☐ Sealing ☐ Test                                                     | ting and inspection              |  |  |
|                        |                                             | mass (              | ) g Ha       | and mas                                                   | s ( )g Atmo         |                                 |                                                                         | ☐ Clean ☐ Dust provided ☐ Other( |  |  |

Copy this page and use the copy.



HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 5-1-14, YADA-MINAMI, HIGASHI-KU, NAGOYA 461-8670, JAPAN