

Mitsubishi Industrial Robot

CR750-Q/CR751-Q series controller CRnQ-700 series controller

iQ Platform Supporting Extended Function Instruction Manual



▲ Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

▲ CAUTION	All teaching work must be carried out by an operator who has received special training. (This also applies to maintenance work with the power source turned ON.) Enforcement of safety training
▲ CAUTION	For teaching work, prepare a work plan related to the methods and procedures of operating the robot, and to the measures to be taken when an error occurs or when restarting. Carry out work following this plan. (This also applies to maintenance work with the power source turned ON.) Preparation of work plan
⚠ WARNING	Prepare a device that allows operation to be stopped immediately during teaching work. (This also applies to maintenance work with the power source turned ON.) Setting of emergency stop switch
▲ CAUTION	During teaching work, place a sign indicating that teaching work is in progress on the start switch, etc. (This also applies to maintenance work with the power source turned ON.) Indication of teaching work in progress
A DANGER	Provide a fence or enclosure during operation to prevent contact of the operator and robot. Installation of safety fence
	Establish a set signaling method to the related operators for starting work, and follow this method. Signaling of operation start
▲ CAUTION	As a principle turn the power OFF during maintenance work. Place a sign indicating that maintenance work is in progress on the start switch, etc. Indication of maintenance work in progress
▲ CAUTION	Before starting work, inspect the robot, emergency stop switch and other related devices, etc., and confirm that there are no errors. Inspection before starting work

The points of the precautions given in the separate "Safety Manual" are given below. Refer to the actual "Safety Manual" for details.

🕂 DANGER	When automatic operation of the robot is performed using multiple control devices (GOT, programmable controller, push-button switch), the interlocking of operation rights of the devices, etc. must be designed by the customer.		
▲ CAUTION	Use the robot within the environment given in the specifications. Failure to do so could lead to a drop or reliability or faults. (Temperature, humidity, atmosphere, noise environment, etc.)		
▲ CAUTION	Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.		
▲ CAUTION	Always use the robot installed on a secure table. Use in an instable posture could lead to positional deviation and vibration.		
	Wire the cable as far away from noise sources as possible. If placed near a noise source, positional deviation or malfunction could occur.		
	Do not apply excessive force on the connector or excessively bend the cable. Failure to observe this could lead to contact defects or wire breakage.		
▲ CAUTION	Make sure that the workpiece weight, including the hand, does not exceed the rated load or tolerable torque. Exceeding these values could lead to alarms or faults.		
⚠ WARNING	Securely install the hand and tool, and securely grasp the workpiece. Failure to observe this could lead to personal injuries or damage if the object comes off or flies off during operation.		
[▲] WARNING	Securely ground the robot and controller. Failure to observe this could lead to malfunctioning by noise or to electric shock accidents.		
▲ CAUTION	Indicate the operation state during robot operation. Failure to indicate the state could lead to operators approaching the robot or to incorrect operation.		
<u>∕</u> MARNING	When carrying out teaching work in the robot's movement range, always secure the priority right for the robot control. Failure to observe this could lead to personal injuries or damage if the robot is started with external commands.		
	Keep the jog speed as low as possible, and always watch the robot. Failure to do so could lead to interference with the workpiece or peripheral devices.		
	After editing the program, always confirm the operation with step operation before starting automatic operation. Failure to do so could lead to interference with peripheral devices because of programming mistakes, etc.		
▲ CAUTION	Make sure that if the safety fence entrance door is opened during automatic operation, the door is locked or that the robot will automatically stop. Failure to do so could lead to personal injuries.		
	Never carry out modifications based on personal judgments, or use non- designated maintenance parts. Failure to observe this could lead to faults or failures.		

A WARNING	When the robot arm has to be moved by hand from an external area, do not place hands or fingers in the openings. Failure to observe this could lead to hands or fingers catching depending on the posture.	
▲ CAUTION	Do not stop the robot or apply emergency stop by turning the robot controller's main power OFF. If the robot controller main power is turned OFF during automatic operation, the robot accuracy could be adversely affected. Moreover, it may interfere with the peripheral device by drop or move by inertia of the arm.	
▲ CAUTION	Do not turn off the main power to the robot controller while rewriting the internal information of the robot controller such as the program or parameters. If the main power to the robot controller is turned off while in automatic operation or rewriting the program or parameters, the internal information of the robot controller may be damaged.	
⚠ DANGER	Do not connect the Handy GOT when using the GOT direct connection function of this product. Failure to observe this may result in property damage or bodily injury because the Handy GOT can automatically operate the robot regardless of whether the operation rights are enabled or not.	
⚠ DANGER	Do not connect the Handy GOT to a programmable controller when using an iQ Platform compatible product with the CR750–Q/CR751–Q controller. Failure to observe this may result in property damage or bodily injury because the Handy GOT can automatically operate the robot regardless of whether the operation rights are enabled or not.	
⚠ DANGER	Do not remove the SSCNET III cable while power is supplied to the multiple CPU system or the servo amplifier. Do not look directly at light emitted from the tip of SSCNET III connectors or SSCNET III cables of the Motion CPU or the servo amplifier. Eye discomfort may be felt if exposed to the light. (Reference: SSCNET III employs a Class 1 or equivalent light source as specified in JIS C 6802 and IEC60825-1 (domestic standards in Japan).)	
A DANGER	Do not remove the SSCNET III cable while power is supplied to the controller. Do not look directly at light emitted from the tip of SSCNET III connectors or SSCNET III cables. Eye discomfort may be felt if exposed to the light. (Reference: SSCNET III employs a Class 1 or equivalent light source as specified in JIS C 6802 and IEC60825-1 (domestic standards in Japan).)	
🗥 DANGER	Attach the cap to the SSCNET III connector after disconnecting the SSCNET III cable. If the cap is not attached, dirt or dust may adhere to the connector pins, resulting in deterioration connector properties, and leading to malfunction.	
▲ CAUTION	Make sure there are no mistakes in the wiring. Connecting differently to the way specified in the manual can result in errors, such as the emergency stop not being released. In order to prevent errors occurring, please be sure to check that all functions (such as the teaching box emergency stop, customer emergency stop, and door switch) are working properly after the wiring setup is completed.	




Use the network equipments (personal computer, USB hub, LAN hub, etc) confirmed by manufacturer. The thing unsuitable for the FA environment (related with conformity, temperature or noise) exists in the equipments connected to USB. When using network equipment, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm the operation by customer. Guarantee and maintenance of the equipment on the market (usual office automation equipment) cannot be performed.

*CR751-D or CR751-Q controller

Notes of the basic component are shown.

Please install the earth leakage breaker in the primary side supply power supply of the controller of CR751-D or CR751-Q because of leakage protection.



- Note 1) Crimping swage is recommended for connecting the attachment ACIN connector (soldering is also possible) Recommendation compression tools: 234171-1(Tyco Electronics)
- Note 2) The earth leakage breaker is the customer preparation. Always use the cover below. Recommendation:

For single primary power supply......NV30FAU-2P-10A-AC100-240V-30mA, (Cover: TCS-05FA2)

- For three primary power supply.....NV30FAU-3P-10A-AC100-240V-30mA, (Cover: TCS-05FA3)
- Note 3) If necessary, as shown in the figure, connects the noise filter between ACIN terminal blocks and primary power supply.

(Recommended noise filter: SUP-EL20-ER6 *OKAYA ELECTRIC INDUSTRIES)

- Please prepare the following: Leakage current breaker (with terminal cover), cable for connecting the primary power supply, cable for connecting the secondary power supply (both AWG #14 (2mm²)), cables to ground the primary power supply (AWG #12 (3.5mm² or above).
- 2) Confirm that the primary power matches the specifications.
- 3) Confirm that the primary power is OFF and that the earth leakage breaker power switch is OFF.
- 4) Connect the secondary power cable to secondary terminal (lower terminal) of earth leakage breaker. Connect the opposite side of this cable with following pin numbers of the ACIN connector attached. For single phase: 1 and 3
 - For three phase: 1, 2, and 3

Recommends connection by the Solderless terminal.

Or, connect by the attachment power cable.

- 5) Connect this connector to the ACIN connector on the controller.
- 6) Connect the grounding cable to the PE terminal. (M4 screw)
- 7) Connect the primary power cable to the primary side terminal (upper terminal) of the earth leakage breaker.

Revision history

Date of print	Specifications No.	Details of revisions
2009-12-04	BFP-A8787-*	First edition created.
2012-03-05	BFP-A8787-A	CR750-Q/CR751-Q series controller were added.
2012-12-05	BFP-A8787-B	The statement about trademark registration was added.
2014-08-06	BFP-A8787-C	 The cover and corporate logo mark of this manual was changed. The statement about trademark registration was modified.
2014-12-16	BFP-A8787-D	 Correction of errors in a timing chart was corrected. Correction of errors in "(3) Hand control image" was corrected. The corporate logo mark of illustrations in this manual was changed.

*Introduction

Thank you for buying the industrial robot MELFA manufactured by Mitsubishi Electric. This document provides the instructions for iQ Platform supporting extended functions. Our extended functions allows the sequencer easily to monitor the robot through shared memory between sequencer and robot, set up data, and operate the robot without a program (sequencer direct performance). This document provides the detailed description of data configuration of shared memory, monitoring, and operating procedures.

Please carefully read and fully understand this document before making use of the extended functions.

Target controller of this document

This document supports the robot controller below:

CR750-Q/CR751-Q series controller: ... Ver. R3 or later

CRnQ-700 series controller: Ver. N8 or later

Robot language MELFA BASIC V or later

- No part of this manual may be reproduced by any means or in any form, without prior consent from Mitsubishi.
- The contents of this manual are subject to change without notice.
- The specifications values are based on Mitsubishi standard testing methods.
- The information contained in this document has been written to be accurate as much as possible. Please interpret that items not described in this document "cannot be performed." or "alarm may occur".

Please contact your nearest dealer if you find any doubtful, wrong or skipped point.

- •This specifications is original.
- Microsoft, Windows, Windows XP, Windows Vista, Windows 7, Windows 8, Windows 8.1 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Windows®XP, Windows Vista®, Windows® 7, Windows® 8, Windows® 8.1 are either product names of Microsoft Corporation in the United States.
- Ethernet is registered trademarks or trademarks of Xerox Corporation in the United States.
- All other company names and production names in this document are the trademarks or registered trademarks of their respective owners.

Copyright(C) 2009-2014 MITSUBISHI ELECTRIC CORPORATION

Contents

	Page
1 Overview	1-1
1.1 Shared Memory Extended Function List	1-1
1.2 Features	
1.3 Shared Memory Configuration	1-4
1.3.1 Memory Configuration for Valid/Invalid Extended Function	
1.3.2 Memory Map of Extended Function Area	1-5
2 Preparation for Using Extended Function	
2.1 Operation flow	
2.1.1 Set up Sequencer's Multiple CPUs 2.1.2 Set up Robot's Multiple CPUs	
2.1.3 Set up Parameter for Selecting Shared Memory Extended Function	
2.1.4 Check Robot Language Setting	
2.1.5 Allocation Example of Shared Memory	
(1) Multiple CPU Configuration with One Sequencer plus One Robot	
(2) Multiple CPU Configuration with One Sequencer plus Three Robots	2-13
O Marcillan Dahad Jafansa dian	0.47
3 Monitor Robot Information	
3.1 Operation Flow	
3.1.1 Select Monitoring Items 3.1.2 Select Target Mecha	
3.1.3 Timing Chart	
3.1.4 Sample Ladder	
3.2 Monitoring Item	
3.2.1 Monitor Operation Control Setting Values	
3.2.2 Monitor Activities	3-25
3.2.3 Monitor Current and Aimed Positions	
3.2.4 Monitor Position and Joint Information	
(1) Select Position and Joint Data	
(2) Position and Joint Data 3.2.5 Monitor Maintenance Information	
4 Reads/Writes Robot's Variables	4-34
4.1 Function Description	4-34
4.2 Operation Flow	4-34
4.3 How to Operate Variables	
4.3.1 Data List	
(1) Sequencer output data	
(2) Robot output data	4-36
(3) Completion status	
(4) Data description	
4.3.2 Timing Chart	
4.3.3 Sample Ladder	4-40
5 Read Current Line of Robot Program	
5.1 Function Description	
5.2 Operation flow	
5.3 How to Operate Program	
5.3.1 Data List	
5.3.2 Timing Chart	
5.3.3 Sample Ladder	
6 Set up Robot's Maintenance	
6.1 Function Description	
6.2 Operation flow	
6.3 How to Operate Maintenance	6-51

Contents

	Page
6.3.1 Data List	6-51
6.3.2 Timing Chart	
6.3.3 Sample Ladder	
7 Read Robot Information	7-56
7.1 Function Description	
7.2 Operation flow	
7.3 How to Operate Robot Information	
7.3.1 Data List	
7.3.2 Timing Chart	
7.3.3 Sample Ladder	
8 Perform Sequencer Direct	
8.1 Sequencer Direct Performance Function	
8.2 Operation flow	
8.2.1 Parameter Setting	
8.2.2 Teaching	
(1) Position Data	
(2) Position Teaching in Position Box (R32TB)	
8.2.3 Prepare to Perform Sequencer Direct	8-71
8.3 How to Operate Sequencer Direct	8-72
8.3.1 Operation Command	
(1) Sequencer output	
(2) Robot output	8–74
(3) Data description	
8.3.2 Timing Chart for Performing Operation Command	
(1) Perform Operation (Normal Operation)	
(2) Operation Command Is Impracticable:	
(3) Suspend/Resume Operation	
(4) Support on Occurrence of Error	
(5) Suspension when Robot's External Operation Authority Gets Invalid(6) Cancel Based on Command Request OFF Signal	
8.3.3 Sample Ladder for Performing Operation Command	
8.3.4 Control Robot Hand	
(2) Mapping hand signal with parameter HANDTYPE	
(3) Hand control image	
8.3.5 Timing Chart for Robot Hand Control	
8.3.6 Sample Ladder for Robot Hand Control	
8.4 Samples	8-100
8.4.1 Robot Program	
8.4.2 Sample Ladder Program	
8.4.3 Sample Operation Setting in GOT Screen	8-109
8.5 Precautions for Sequencer Direct Performance	8-113
8.5.1 Requirements	8-113
8.5.2 Running together with Program	
8.5.3 Prohibit Program Startup with always Running Program	
8.5.4 Robot Language Setting	
8.5.5 Operation Panel Display	8-114
9 Shared Memory Extended Function Relevant Parameter	9-115
9.1 Parameter of Selecting Shared Memory Extended Function	9-115
9.2 Function Definition Parameter	
10 Extended Function Relevant Error List	10-118
TO EXCONDUT UNDER THORAGE ENDER AND A STATE AND A STAT	10-110


1 Overview

These specifications describe the functions (sequencer direct performances) which extend the shared memory in CR750-Q/CR751-Q series and CRnQ-700 series robot controller, exchange various robot information between sequencer and robot through the extended shared memory, and operate the robot without a robot program.

Note: These shared memory extended functions only support MELFA-BASIC V or later. They do not support MELFA-BASIC IV.

(For more information, refer to Page 10, "2.1.4 Check Robot Language Setting")

Sequencer direct performance does not support mecha 2 and 3 for multiple mecha. It supports additional axis.



Note) The figure is the DU-700 series drive unit. The DU750-Q/DU751-Q series drive unit is also the same.

1.1 Shared Memory Extended Function List

These shared memory extended functions are largely classified into monitoring and operation functions. Monitoring function periodically updates and outputs the data in shared memory on the robot. Operation function outputs a request from the sequencer to the robot as needed and exchanges the data. Shared memory extended functions also provide a direct performance function to directly operate the robot.

No	b Item		Description	I/F btwn Robots	Update Cycle
1	Monitor- ing func- tion	Monitor operation con- trol setting values	Monitors the setting values relating to operation control command and opera- tion control.	Motoring output (Robot side peri-	7.1msec
2		Monitor activities	Monitors the robot's activities (current speed, arrival factor to the aimed position, etc.)	odically updates the data in shared memory)	7.1msec
3		Monitor current and aimed positions	Monitors current and aimed positions of robot.		7.1msec
4		Monitor general position and joint information	Monitors various position type data (ori- entation at collision, etc.) and joint type data (current value, load factor, etc.)		It may differ accord- ing to each item. Refer to Page 28, "3.2.4 Monitor Posi- tion and Joint Infor- mation".
5		Monitor maintenance information	Monitors the maintenance information (battery and grease remaining times).		Depending on the parameter MFINTVL

No	b Item		Description	I/F btwn Robots	Update Cycle
6	Operation	Read/write variables	Reads/ writes variables used in the	Request reply	Responds within 1s
	function		robot's program.	method	(It may vary accord-
7		Read program's current	Reads currently performing line of the		ing to the load status
		line	robot program on a per line basis (up to	(The robot side	of robot control)
			128 characters).	answers by the	
8		Set up maintenance	Resets the servomotor information.	output request of	
9		Read error information	Reads detailed error information (pro-	the sequencer,	
			gram name, occurred line, etc.)	and delivers the	
10		Read product information	Reads the robot's product information	data on the	
			(model name, version, and serial num-	shared memory)	
			ber).		
11		Perform sequencer direct	Operates the robot from the sequencer		
			through shared memory		

1.2 Features

- (1) Fulfilling functions to monitor and operate robot from GOT. Advances T/B and PC-less solution.
 - \rightarrow Various functions can be performed by reading/ writing the data in shared memory from GOT.
 - Allows you to check activities, position information, and setting values of operation control command and thereby analyze the operation in case of debugging or problem. (Monitoring current and aimed positions, activities, and operation control setting values)
 - Allows you to read and write the contents of program and variables and thereby change the robot's operation in case of debugging or problem.
 - Allows you to check and set up maintenance status.
 - Allows you to check error's detailed content. (Reading error information)
 - Allows you to display and check various information in the robot (product, servo information, etc.)

(2) Controls peripheral devices and system according to the robot activities with the sequencer The sequencer allows you to monitor the data in shared memory and responsively control the peripheral device connected to the sequencer according to the monitored value.

- Allows you to control the peripheral devices by monitoring the robot's activities (current speed, arrival factor to the aimed position, etc.)
- Allows you to generate an alarm to the system and report to the upper side by monitoring the maintenance and servomotor information (load factor, etc.)
- (3) Analyzes the data and performs the quality control by logging the robot information through sequencer Allows you to analyze the system data and perform the products' quality control by sending the logged robot information in shared memory to the sequencer and upper device connected to the sequencer.
 - Allows you to control the system's operating situation by logging error information.
 - Allows you to perform the quality control of product assembly by logging servo monitor information (current value, etc.)

- (4) Allows to operate the robot without learning robot language (sequencer direct performance)
 - Allows to operate the robot without knowing robot language. Allows you to operate the robot by writing predetermined setting value into the specified address in shared memory. Therefore, this function can be fulfilled regardless of sequencer language (ladder, ST language, SFC, etc.)
 - Allows you to select either joint or linear interpolation. Also, allows you to adequately specify the robot operations such as override, acceleration and deceleration, tool setting.

Command		Action	
Operation con-	Mov	Move for joint interpolation	
trol	Mvs	Move for linear interpolation	
	Ovrd	Specify the overall speed	
	Spd	Specify the linear interpolation speed	
	Accel	Specify the acceleration and deceleration speed	
Definition com- mand	Tool	Specify the tool data	
Hand command	Hopen/Hclose	Open/close a hand	

- Allows you to operate the robot with a sense, which is familiar to the sequencer programmer, to move a positioning unit.
- Allows you to control the system operations only with sequencer. Makes the program management easy so that a sequencer programmer can support for the change of system specification and the problem.
- Allows you to control the system settings only with the sequencer in the GOT screen.
 A sequencer programmer can support for the change of system specification and the problem so that the program management gets so easy.


1.3 Shared Memory Configuration

Here, describes the shared memory configuration among multiple CPUs.

1.3.1 Memory Configuration for Valid/Invalid Extended Function

To use the shared memory extended functions, enable the shared memory extended functions with the parameter "IQMEM".

After enabling the shared memory extended functions, the shared memory is used by extending the robot I/ O area by 0.5 K word.



Sequencer shared memory address (per word) * Above notation is an offset address from the beginning.

Note) Only the user area can be referred to by robot program, signal monitor, and dedicated I/O signal allocation. They cannot refer to the extended function area.

1.3.2 Memory Map of Extended Function Area

The table below lists the memory map of extended function area in the shared memory among multiple CPUs.

<u>* As the sequencer address may differ according to each CPU device, the sequencer address is described</u> in the offset address from start address.
 <u>* When not otherwise specified, the values are stored in binary format.</u>


(2) Robot output (sequencer input) area

(1) Robot input (sequencer output) area

Shared Memory Addr Sequencer Addr	Description	Shared Memory Addr Sequencer Addr	Description
512	Common setting area of extended function Sequencer direct performance area	512	Common setting area of extended function Sequencer direct performance area Common area of operation function Read/write variables
600		600	Reading area of program's current line Reset area of servo monitor information
700	Common area of operation function Reading/ writing/ teaching area of variables Reading area of program's current line	700	Reading area of information Common area of monitoring function Monitoring area of operation control setting values
800	Reset area of servo monitor information Reading area of error and product information Common area of monitoring function Monitoring area of general position and joint information (Reserved: Future extended area)	800	Monitoring area of activities Monitoring area of current and aimed posi- tions
900		900	Monitoring area of general position and joint information Monitoring area of maintenance information
1000 1023		1000 1023	(Reserved)
1024		1024	

2 Preparation for Using Extended Function

2.1 Operation flow



"8Perform Sequencer Direct"

2.1.1 Set up Sequencer's Multiple CPUs

Here, sets up the multiple CPU setting as a sequencer's PC parameter. Also refer to the description of sequencer link I/O functions described in Supplement volume "Instruction Manual, Detailed Description of Functions and Operations."

Multiple CPU settings		X
No. of PLC (*) No. of PLC 4 Host CPU number No specification Operating mode (*) Error operation mode at the stop of PLC	Online module change(*) Enable online module change with another PLC. When the online module change is enabled with another PLC, I-O status outside the group cannot be taken. I/O sharing when using Multiple CPUs (*) All CPUs can read all inputs All CPUs can read all outputs	
 All station stop by stop error of PLC1 All station stop by stop error of PLC2 All station stop by stop error of PLC3 All station stop by stop error of PLC3 All station stop by stop error of PLC4 	Multiple CPU high speed transmission area setting Communication area setting (refresh setting) Image: White the speed transmission Image: White transmission CPU specific send range(*) User setting area PLC User setting area	
Multiple CPU synchronous startup setting(*) Target PLC V No.1 No.2 No.3 No.4	point(K) I/O No. point Start End point Setting No.1 3 J3E0 3072 G10000 G13071 0 Setting No.2 1 J3E1 1024 G10000 G11023 0 Setting No.3 1 J3E2 1024 G10000 G11023 0 Setting No.4 1 J3E3 1024 G10000 G11023 0 Setting Set aluto refresh setting if it is needed Tot setting / Already set) ////////////////////////////////////	
(*)Settings should be set as same when using multiple CPU	Import Multiple CPU Parameter Check End Cancel	

GX-Developer multiple CPU setting screen (three robots. The shared memory extended functions are valid in all robots)

Setting Item	Description	Setting Value
CPU quantity	Set up the quantity of CPU units used in multiple CPU system.	2 - 4
Synchronous startup among multiple CPUs	Set up this to synchronize the startup times of CPU units in multiple CPU system. * Because the robot CPU takes a dozen second for startup, select the synchronize startup	Required for check
High-speed communica- tion area setting among multiple CPUs	Set up this when the data is transferred by using the high-speed communication area ^{Note1)} among multiple CPUs. The necessary area for robot is as follows: Shared memory extended functions are valid: • Robot input area: 1.0K • Robot output area: 1.0K Shared memory extended functions are invalid: • Robot input area: 0.5K • Robot output area: 0.5K	<shared are="" extended="" functions="" memory="" valid:=""> Device #1: Sum of the size (1K) of the data to be sent to the robot and the size of the data to be sent to other devices Robot device: Set 1K for it Other devices: Set its own transmission size Shared memory extended functions are invalid:> Device #1: Sum of the size (0.5K) of the data to be sent to the robot and the size of the data to be sent to the robot and the size of the data to be sent to other devices Robot device: Set 1K for it ^{Note2} Other devices: Set its own transmission size Note 2: Because the area is set up in 1K unit, allocate 1K even in case of 0.5K.</shared>
Automatic refresh setting	Set up this when the device data is automatically refreshed by using the high-speed communication area among multiple CPUs. * Robot CPU is not supported. Always set this to zero.	Robot device: Set zero point for it Other devices: To use automatic refresh function, set its score and target device

Note1) For information about multiple CPUs and high-speed communication area among multiple CPUs, refer to the QCPU manual (QCPU User Manual, Multiple CPU System).

Note2) Because the area is set up in 1K unit, allocate 1K even in case of 0.5K.

2.1.2 Set up Robot's Multiple CPUs

Here, sets up the multiple CPUs as a robot's parameter. In the description below, parameter setting screen of RT ToolBox 2 illustrates this setting. This can also be set up by specifying the parameter name in the teaching box's parameter setting screen.

Oct the Sal		<u>, as sp</u>	comean	in age	1, 2.1.	i Sei up Seque		
🖬 Multiple	CPU se	tting 1	RG1 (Or	line)				
No. of CPU(QMLTCPUN) No. of CPU 4 Please set the number of Multiple CPU. Image: CPU 1 Image: CPU 2 Image: CPU 3 Image: CPU 4 Image: CPU 4						etting word) ¥G10000	The multiple CPU input offset parameter "QMLTCPUS" can also be set.	
			Send ra	inge for e	ach CPU			
CPU		User setting area				Automatic Refresh		
	Point(K)	I/O No.	Point	Start	End	Point		
No.1	3	U3E0	3072	G10000	G13071	0		
No.2	1	U3E1	1024	G10000	G11023	0		
No.3	1	U3E2	1024	G10000	G11023	0		
No.4	1	U3E3	1024	G10000	G11023	0		
Total 6K Point Advanced setting The total is up to 12K points.								
					heck	Explain	W <u>r</u> ite	

RT-ToolBox2 multiple CPU setting screen (three robots. Shared memory extended functions are valid in all robots)

[Start address of robot input offset]

The Table 2-1 lists the start addresses of robot input area in the robot's initial setting (multiple CPU input offset parameter "QMLTCPUS" is set to "-1") (The start address changes according to whether the shared memory extended functions are enabled or not).

Table 2-1:Start address of robot input area when the multiple CPU input offset parameter is initial value

Device No	Shared Memory Extended Functions		
	Invalid	Valid	
Device #2 (robot 1)	0K	0K	
Device #3 (robot 2)	0.5K	1.0K	
Device #4 (robot 3)	1.0K	2.0K	

The start address of robot's input area may differ, when the valid/invalid setting for shared memory extended function may differ in other devices or when a unit other than robot is installed. In these cases, set up the multiple CPU input offset parameter (QMLTCPUS).

For setting example, refer to Page 11, "2.1.5 Allocation Example of Shared Memory".

About input offset parameter (QMLTCPUS)

Sets up the offset of robot's input signals in multiple CPUs in 1K word unit.

For example, when QMLTCPUS is set to one, the start address of robot's input area is an address (U3E0\G11024) offset by 1K word from the start address of transmission area of device #1 (sequencer). When QMLTCPUS is set to -1 (initial value), the start address of robot's input area is as listed in the table above.

2.1.3 Set up Parameter for Selecting Shared Memory Extended Function

The parameter "IQMEM" for selecting the shared memory extended function is 16bit data. Set the bit 0 to one to use the extended functions (monitoring, operation functions). Set the bit 1 to one to use the sequencer direct performance function. Both bits can be set to one.


For information on how to set up a parameter, refer to Supplement volume "Instruction Manual, Detailed Description of Functions and Operations."

Parameter	Parameter Name	Array Qty Character Qty	Description	Factory Default
Select shared memory extended function	ТQМЕМ	1 digit inte- ger	Set validity (1)/ invalidity (0) for the function. Sets each bit by allocating a function to each bit. 0000000000000000 bit2-15: Not used +- bit0: Use the shared memory extended function + bit1: Sequencer direct performance function	000000000000000000000000000000000000000

To use the shared memory extended functions and sequencer direct performance functions, set each bit as follows:

	Bit 1	Bit 0
Use the shared memory extended function	0	1
Use the sequencer direct performance function	1	1

When using the sequencer direct performance function, robot's internal memory is extended as follows:



When the sequencer direct performance function is valid, external program variable and system state variable areas are extended in the robot controller (extended variables). When the function gets invalid, the extended variable area is cleared. Consequently, after the sequencer direct performance function was enabled once, the robot location was taught, and the data was set, when the parameter is turned back, be aware that the previous teaching and setting data will disappear.

2.1.4 Check Robot Language Setting

The shared memory extended functions can be carried out only when the robot language is set to MELFA-BASIC V.

Check the value of robot language setting parameter "RLNG".

To use the shared memory extended function, set the parameter "RLNG" to 2.

For information on how to set up a parameter, refer to Supplement volume "Instruction Manual, Detailed Description of Functions and Operations."

Parameter	Parameter Name	Array Qty Character Qty	Description	Factory Default
Robot language	RLNG	1 digit inte- ger	Select the robot language to be used: 2: MELFA-BASIC V 1: MELFA-BASIC IV	2

The robot controller's factory default is MELFA-BASIC V. But, when you have selected MELFA-BASIC IV, an error "L3994" or "L3996" occurs on controller startup.




When the robot language setting is changed from MELFA-BASIC V to MELFA-BASIC N, the extended variable area is cleared. Consequently, be aware that the teaching and setting data for shared memory extended function/ sequencer direct performance function will disappear.

2.1.5 Allocation Example of Shared Memory


(1) Multiple CPU Configuration with One Sequencer plus One Robot

1) Case 1: Robot: Extended function is enabled, input offset parameter is initial value The robot uses each 1K word for I/O.



2) Case 2: Robot: Extended function is disabled, input offset parameter is initial value The robot uses each 0.5K word for I/O.


> As the transmission score is set yet in 1K word unit, the transmission score setting is as follows:



(2) Multiple CPU Configuration with One Sequencer plus Three Robots


1) Case 1: All robots: Extended function is enabled, input offset parameter is initial value All robots use each 1K word for I/O.

The beginning of robot 2 input area starts at 1.0K offset from the beginning of shared memory address, and the beginning of robot 3 input area starts at 2.0K offset from the beginning of shared memory address.




2) Case 2: All robots: Extended function is disabled, input offset parameter is initial value All robots use each 0.5K word for I/O.

The beginning of robot 2 input area starts at 0.5K offset from the beginning of shared memory address, and the beginning of robot 3 input area starts at 1.0K offset from the beginning of shared memory address.




The setting is in 1K word unit as follows:

3) Case 3: Robots 1, 2: Extended function is disabled, Robot 3: Extended function is enabled (#1) By default, the robot 3 input area starts at 2.0K offset from the beginning of shared memory (By default, the extended function of robots 1, 2 is also assumed to be enabled, similar to robot 3). Therefore, the multiple CPU input offset parameter (QMLTCPUS) of robot 3 should be set to "1."



4) Case 4: Robots 1, 2: Extended function is disabled, Robot 3: Extended function is enabled (#2) <u>This example allocates 1K area in advance so that the allocation is not changed even when</u> <u>the extended function is enabled in the future, while the extended function was disabled and</u> <u>the extended area was not allocated.</u>

Empty area of 0.5K is kept at the back of each transmission area of robot 1 (for robots 2, 3). By default, the robot 2 input area starts at 0.5K offset from the beginning of shared memory (By default, the extended function of robots 1 is also assumed to be disabled, similar to robot 2). Therefore, the multiple CPU input offset parameter (QMLTCPUS) of robot 2 should be set to "1".




3 Monitor Robot Information

The Table 3-1 lists the robot information monitored from sequencer. Setting values are also monitored during performing sequencer direct.

Table 3-1: Monitoring item list

No	Item	Description	I/F betw Robots	Update Cycle	Mecha No Setting	Section No
1	Monitor operation control setting val- ues	Monitors the setting values relating to operation control command and opera- tion control	Monitoring output (Robot side peri-	7.1msec	O (necessary)	"3.2.1"
2	Monitor activities	Monitors the robot's activities (current speed, arrival factor to the aimed position, etc.)	odically updates the data in shared memory	7.1msec	0	"3.2.2"
3	Monitor current and aimed posi- tions	Monitors current and aimed positions of robot		7.1msec	0	"3.2.3"
4	Monitor position and joint informa- tion	Monitors various position type data (ori- entation at collision, etc.) and joint type data (current value, load factor, etc.)		Differ accord- ing to items	0	"3.2.4"
5	Monitor mainte- nance information	Monitors the maintenance information (battery and grease remaining times)		Depending on the parameter MFINTVL	0	"3.2.5"

3.1 Operation Flow



3.1.1 Select Monitoring Items

Here, selects the monitoring functions output by the robot from the sequencer. Only the data specified by items (set to "1") selected with each bit can be monitored. For more information on each monitoring data, refer to Page 23, "3.2 Monitoring Item" and after.

(1) Sequencer output data

a) Word data

Sequencer Addr (offset)	Description	Remarks
512	Function selection [Allocated to each bit, 0: invalid, 1: valid] bit15 0 000000000000000 +bit0: (Reserved) +bit1: (Reserved) +bit2: Monitor operation control settings +bit3: Monitor activities +bit4: Monitor current and aimed positions +bit5: Monitor position and joint information +bit6: Monitor maintenance information +bit7: (Reserved)	

(2) Robot output data

a) Word data

Sequencer Addr (offset)	Description	Remarks
540	Function performing [allocated to each bit, 0: invalid, 1: valid] bit15 0 00000000000000 +bit0: (Reserved) +bit1: (Reserved)	
512	<pre> +bit2: Monitor operation control settings +bit3: Monitor activities +bit4: Monitor current and aimed positions +bit5: Monitor position and joint information +bit6: Monitor maintenance information +bit7: (Reserved)</pre>	

3.1.2 Select Target Mecha

Here, selects the target mecha number of monitoring data output by the robot from the sequencer. The robot outputs the data with selected mecha number. The number (1 to 3) is selectable for mecha numbers. When the number other than 1 - 3 is specified, the data is initialized (zeros are put in the whole target area)

(1) Sequencer output data

a) Word data

Sequencer Addr (offset)	Description	Remarks
841	Specify a mecha number [1 - 3]	

(2) Robot output data

a) Word data

Sequencer Addr (offset)	Description	Remarks
731	Mecha number [1 - 3]	

3.1.3 Timing Chart




Fig.3-1:Timing chart for selecting monitoring items and target mecha

- (1) When the sequencer sets the target bit of "Select function" to "ON", the robot sets the target bit of "Performing function" to "ON" to start the monitoring output of target item. Here, when "Specify mecha number" is other than 1 - 3, the robot waits to update the data.
- (2) When the sequencer sets "Specify mecha number" to one, the robot starts to update mecha 1's data.
- (3) When the target bit of "Select function" is set to "ON" while the sequencer sets "Specify mecha number", the robot starts to update the data of target item while at the same time the robot sets the target bit of "Performing function" to "ON".
- (4) When the sequencer changes "Specify mecha number", the robot outputs the data of specified mecha.
- (5) When the sequencer sets "Mecha number" to other than 1 3, the robot clears the output data.
- (6) When the sequencer re-sets "Mecha number", the robot outputs the data of target mecha.
- (7) When the sequencer sets the target bit of "Select function" to "OFF", the robot sets the target bit of "Performing function" to "OFF" to initialize the output data.



The synchronization of data in shared memory is guaranteed on a per 32bit (2 word) basis. But, the synchronization in the unit more than this bit cannot be guaranteed. Therefore, be aware that the position type and joint type data is guaranteed for each axis, the data is not guaranteed as a whole.

3.1.4 Sample Ladder

Here, shows the sample ladder to retrieve current and aimed positions and maintenance information into the internal device by specifying the monitoring item and mecha number.

[Target function]

Select monitoring items (monitoring current and aimed positions, monitoring data of maintenance information) and mecha

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Description]

When the device with desired function to be monitored is set to "ON" of monitoring request (M14) for current and aimed positions, monitoring request (M15) for maintenance information, and device of selecting mechas 1 - 3 (M21 - M23), target data is output to the internal device for monitoring. The data of current and aimed positions is stored in D1000 - D1071.

The data of maintenance information is stored in D1100 - D1133.

Example:

To output the current and aimed positions data of mecha 1, set M14 and M21 to "ON" (M22 and M23 are "OFF") to output the monitoring data to D1000 to D1071.

To output the maintenance information data of mecha 1, set M16 and M21 to "ON" (M22 and M23 are "OFF") to output the monitoring data to D1100 to D1133.

[Device details]

M14: Request to monitor the current and aimed positions

M16: Request to monitor the maintenance information

M21: Selects mecha 1

M22: Selects mecha 2

M23: Selects mecha 3

M34: Monitoring the current and aimed positions

M36: Monitoring the maintenance information


M41: Mecha 1 selected

M42: Mecha 2 selected

M43: Mecha 3 selected

D1000 - D1071: Stores the current and aimed positions data from the robot

D1100 - D1133: Stores the monitoring data of maintenance information from the robot



3.2 Monitoring Item

3.2.1 Monitor Operation Control Setting Values

Here, periodically outputs the robot's operation control commands and the setting values for operation control to the shared memory.

(1) Monitoring data list

Sequencer Addr (Offset)		Supported State Variable	Update Cycle	
777	ColChk setting value	Collision detection setting [0: Invalid/ 1: Valid (error occurred)/ 2: Valid (error not occurred)		7.1msec
778	ColLvl setting value	Collision detection level, J1 axis [%: 1 - 500]		
779		Collision detection level, J2 axis [%: 1 - 500]		
780		Collision detection level, J3 axis [%: 1 - 500]		
781		Collision detection level, J4 axis [%: 1 - 500]		
782		Collision detection level, J5 axis [%: 1 - 500]		
783		Collision detection level, J6 axis [%: 1 - 500]		
784		(Reserved)		
785		(Reserved)		
794	CMP Pos/Tool/Jnt set- ting values	Compliance coordinate type [0: Invalid/ 1: Perpendicular/ 2: Tool/ 3: Joint]		
795		Specify a compliance coordinate type [Specify target axis with bit] [Setting values to specify compliance axis of CMP Pos/Tool/Jnt setting values] The values below are set by setting up bit: bit7 0 00000000 +bit0:J1/X axis +bit1:J2/Y axis +bit1:J2/Y axis +bit3:J4/A axis +bit3:J4/A axis +bit5:J6/C axis +bit6: (Reserved) +bit7: (Reserved)		
796	CmpG setting value	Compliance J1/X axis gain [10 ⁻² : 1 - 100]		
797		Compliance J2/Y axis gain [10 ⁻² : 1 - 100]		
798		Compliance J3/Z axis gain [10 ⁻² : 1 - 100]		
799		Compliance J4/A axis gain [10 ⁻² : 1 - 100]		
800		Compliance J5/B axis gain [10 ⁻² : 1 - 100]		
801		Compliance J6/C axis gain [10 ⁻² : 1 - 100]		
802		(Reserved)		
803		(Reserved)		
804	MvTune/Prec setting val- ues	Operation characteristic [1: Standard/ 2: High- speed/ 3: Track preferred/ 4: Vibration restricted]		

<Precautions>

- When the target mecha does not exist, outputs the data zero.
- The value below is output as ColChk:
 - When multiple mechas are in use or when the element 1 of parameter COL is zero (collision detection unavailable),
 - → zero is output
 - Otherwise (collision detection available):
 - When being in operation (including step feed, position jump operation, and sequencer direct performance),
 - \rightarrow the initial value is the value of element 2 of parameter COL, and then the output value is the value changed by ColChk command.
 - When not being in operation (including suspension and jog operation),
 - \rightarrow it is set to the value of element 3 of parameter COL.
- The value below is output as ColLvI:
 - When multiple mechas are in use or when the element 1 of parameter COL is zero (collision detection unavailable) and
 - being in operation,
 - → the initial value is the value of parameter COLLVL, and then the output value is the value changed by ColLvl command.
 - When not being in operation,
 - \rightarrow it is the value during automatic operation is held when being in suspension, and it is the value of parameter COLLVL when being stopped.
 - Otherwise (collision detection available),
 - When being in operation,
 - → the initial value is the value of parameter COLLVL, and then the output value is the value changed by ColLvl command.
 - When not being in operation,
 - \rightarrow it is the value of parameter COLLVLJG.
- CMP Pos/Tool/Jnt setting values are set to zero when mechas 2, 3 are selected during using multiple mechas.

(User mecha cannot use compliance)

3.2.2 Monitor Activities

Here, periodically outputs the robot's activities (current speed, arrival factor to the aimed position, etc.) to the shared memory.

(1) Monitoring data list

Sequencer Addr (offset)	Description	Supported State Variable	Update Cycle
810	Current instruction speed [10 ⁻⁴ mm/s]	M_RSpd	
811			
812	Current distance remained [10 ⁻⁴ mm]	M_RDst	
813			
814	Distance between instructed and feedback positions [10 ⁻⁴ mm]	M_Fbd	
815			
816	Arrival factor [%] to the current aimed position	M_Ratio	7.1msec
817	Current acceleration and deceleration state [0: Stopped/ 1: Accelerated/ 2: Constant speed/ 3: Decelerated]	M_AclSts	1.111000
818	Collision detection [1: Collided/ 0: Otherwise] Note1)	M_ColSts	
819	819 Going over the limit during performing compliance [1: Almost go over the limit/ 0: Does not go over the limit]		
820	Deviance amount between instructed and actual positions during performing	M_CmpDst	
821	compliance [10 ⁻⁴ mm]		

Note1) Robot state variable (M_ColSts) is "1" for about 7.1ms between collision detection and servo OFF. But, the data "1" is output to the shared memory for 1sec after the collision is detected.

<Precautions>

- When the target mecha does not exist, outputs the data zero.
- When the data is dependent on a slot and the slot does not exist which has the control of target mecha, outputs the data zero. The data dependent on a slot is as follows:
 - Current distance remained (M_RDst)
 - Arrival factor to the current aimed position (M_Ratio)
 - Current acceleration and deceleration state (M_ActSts)

3.2.3 Monitor Current and Aimed Positions

Here, periodically outputs robot's current and aimed positions to the shared memory.

(1) Monitoring data list

Sequencer Addr (offset)	Description			
830 831		X coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	7.1msec	
832				
833		Y coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
834		Z coordinate value [10 ⁻⁴ mm/10-4deg]		
835	•		_	
836 837	•	A coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
838			-	
839	Current accition (normandiaulan)	B coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
840	Current position (perpendicular)	C coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
841				
842		L1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
843 844			_	
845		L2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
846				
847		Structure flag		
848		Multi-turn data		
849			_	
850 851	-	X coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
851	-		-	
853		Y coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
854				
855		Z coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
856	•	A coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
857	•		_	
858 859		B coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
860	Aimed position (perpendicular)		-	
861		C coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
862		L1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
863				
864		L2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]		
865 866			-	
867		Structure flag		
868				
869		Multi-turn data		

Sequencer Addr (offset)	Description				
870 871		J1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
872 873		J2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
874		J3 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
875 876					
877	Current position (joint)	J4 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
878 879		J5 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
880		J6 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
881 882					
883	•	J7 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
884 885		J8 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
886 887		J1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
888		J2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
889 890					
891		J3 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
892 893	Aimed position (joint)	J4 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
894 895	Aimed position (joint)	J5 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
896		J6 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
897 898					
899		J7 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			
900 901		J8 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]			

<Precautions>

- When the target mecha and axis do not exist, outputs the data zero.
- When the origin is not established, outputs zero for the both perpendicular and joint components of current position.
- (2) Data description

[Perpendicular data]

- The unit is 10^{-4} mm or 10^{-4} deg.
- Only lower one word is used for the structure flag. Upper one word is a reserved area.

[Joint data]

• The unit is 10^{-4} mm or 10^{-4} deg.

3.2.4 Monitor Position and Joint Information

Here, periodically outputs the robot's various position type and joint type data to the shared memory. <u>The sequencer selects the data output by the robot.</u> The area exists for one pieces of position type data and three pieces of joint type data and the data output for monitoring can be individually set by the sequencer.

(1) Select Position and Joint Data

In the sequencer, set up the number for position and joint data output by the robot.

The robot outputs the monitoring data corresponding to the selected data number.

The area exists for one pieces of position type data and three pieces of joint type data and the data can be individually set.

When the sequencer specifies the data with the number which is out of range, the robot sets all monitoring data to zero.

(1) Data list

a) Sequencer output

Sequencer Addr (offset)	Description
850	Position data selection [1 - 4] 1: (Reserved) 2: (Reserved) 3: (Reserved) 4: Direction at the time of collision
851	Joint data selection-1 [1 - 13] 1: (Reserved) 2: (Reserved) 3: Difference between estimated and actual torques when detecting a collision 4: (Reserved) 5: Current instruction 6: Maximum current instruction 1 7: Maximum current instruction 2 8: Current feedback 9: Allowable current instruction, minus side 10: Allowable current instruction, plus side 11: Effective current 12: Axis load level 13: Maximum axis load level
852	Joint data selection-2 [1 - 13] For setting values, refer to 851 above.
853	Joint data selection-3 [1 - 13] For setting values, refer to 851 above.

b) Robot output

Sequencer Addr (offset)	Description
906	Position data number [1 - 4]
907	Joint data number-1 [1 - 13]
908	Joint data number-2 [1 - 13]
909	Joint data number-3 [1 - 13]

(2) Timing chart




Fig.3-2: Joint data output, Timing chart

- (1) When the sequencer selects "Joint data selection-1," the robot outputs the target data to "Joint data-1" area.
- (2) When the sequencer changes "Joint data selection-1," the robot outputs the changed target data to "Joint data-1" area.
- (3) When the sequencer selects the data out of valid range for "Joint data selection-1," the robot clears "Joint data-1" (set all components to zero) and outputs zero for "Joint number-1."
- (4) When the sequencer reselects "Joint data selection-1", the robot outputs the target data to "Joint data-1" area.

* The same applies to Joint data-2, 3 and position data.

(2) Position and Joint Data

(1) Data list

b) Robot output

Sequencer Addr (offset)	Description	
910		X coordinate value
911 912		
913		Y coordinate value
914		
915		Z coordinate value
916		A coordinate value
917		
918	Position data [1 - 4] 1: (Reserved)	B coordinate value
919 920	2: (Reserved)	
920	3: (Reserved)	C coordinate value
922	4: Direction at the time of collision	
923		L1 coordinate value
924		L2 coordinate value
925		
926		Structure flag
927		
928		Multi-turn data
929		
931		J1 coordinate value
932	Joint data-1 [1 - 13]	
933	1: (Reserved) 2: (Reserved)	J2 coordinate value
934	3: Difference between estimated and actual torques when	J3 coordinate value
935	detecting a collision	
936	4: (Reserved) 5: Current instruction	J4 coordinate value
937 938	6: Maximum current instruction 1	
939	7: Maximum current instruction 2 8: Current feedback	J5 coordinate value
940	9: Allowable current instruction, minus side	
941	10: Allowable current instruction, plus side	J6 coordinate value
942	11: Effective current 12: Axis load level	J7 coordinate value
943	13: Maximum axis load level	
944		J8 coordinate value
945 946		
946		J1 coordinate value
948		
949		J2 coordinate value
950		J3 coordinate value
951		
952		J4 coordinate value
953 954	Joint data-2 [1 - 13] * The data is similar to Joint data-1.	
954		J5 coordinate value
956		
957		J6 coordinate value
958		J7 coordinate value
959		
960		J8 coordinate value
961		

Sequencer Addr (offset)	Descriț	otion
962		J1 coordinate value
963		31 coordinate value
964		J2 coordinate value
965		32 coordinate value
966		J3 coordinate value
967		
968		J4 coordinate value
969	Joint data-3 [1 - 13]	
970	* The data is similar to Joint data-1	J5 coordinate value
971		
972		J6 coordinate value
973		
974		J7 coordinate value
975		
976		J8 coordinate value
977		

<Precautions>

• When the target mecha and axis do not exist, outputs the data zero.

(2) Data description

The table below lists the content of each data item.

	Item	Description	Setting Value (unit)	Supported State Variable	Update cycle
Position data	4: Direction at the time of collision ^{Note1)}	Robot's direction when the collision is detected	Divides the direction at the time of collision to components X, Y, Z. Specify the value with the proportion when the	P_ColDir	7.1msec
	3: Difference between estimated and actual torques when detect- ing a collision ^{Note1)}	Maximum difference value between esti- mated and actual torques when detecting a collision is valid	[10 ⁻³ %]	J_Colmxl	7.1msec
	5: Current instruction	Outputs the current instruction value.	[10 ⁻³ Arms]		57msec
	6: Maximum current instruction		[10 ⁻³ Arms]		1.8sec
	7: Maximum current instruction 2	Outputs the maximum current instruction value for past 2sec.	[10 ⁻³ Arms]		1.8sec
	8: Current feedback	Outputs the current value generated in the servo motor.	[10 ⁻³ Arms]		7.1msec
Joint data	9: Allowable current instruction, minus side	Outputs the maximum allowable value (minus side) of the current generated in the servo motor. * The value may vary according to jog and automatic operations.	[10 ⁻³ Arms]		7.1msec
io	10: Allowable current instruction, plus side	Outputs the maximum allowable value (plus side) of the current generated in the servo motor. * The value may vary according to jog and automatic operations.	[10 ⁻³ Arms]		7.1msec
	11: Effective current	Outputs the effective value of current feed- back.	[10 ⁻³ Arms]		57msec
	12: Axis load level	Outputs the motor's load level. The big- ger this value, the heavier the load on the motor. Roughly it should be 80% or less. * It takes a few minutes until the value will stable.	[10 ⁻³ %]		1.8sec
	13: Maximum axis load level	Outputs the maximum value of axis load level after power-up. Reset when the power supply is shut off.	[10 ⁻³ %]		1.8sec

Note1) Because the collision detection function is unavailable during using multiple mechas, outputs zero.

3.2.5 Monitor Maintenance Information

Here, periodically outputs the robot's scheduled maintenance data (battery, grease, and belt remaining times) to the shared memory.

(1) Monitoring data list

Sequencer Addr (offset)	Description	Update Cycle	
980 981	Battery remaining time [Hr]		
982 983	Grease remaining time - J1 axis [Hr]		
984	Grease remaining time - J2 axis [Hr]		
985 986			
987	Grease remaining time - J3 axis [Hr]		
988 989	Grease remaining time - J4 axis [Hr]		
990 991	Grease remaining time - J5 axis [Hr]		
992 993	Grease remaining time - J6 axis [Hr]		
994 995	Grease remaining time - J7 axis [Hr]	Updated at sched-	
996	Grease remaining time - J8 axis [Hr]	uled interval set up in the second ele-	
997 998		ment of parameter	
999	Belt remaining time - J1 axis [Hr]		
1000 1001	Belt remaining time - J2 axis [Hr]		
1002 1003	Belt remaining time - J3 axis [Hr]		
1004 1005	Belt remaining time - J4 axis [Hr]		
1006 1007	Belt remaining time - J5 axis [Hr]		
1008 1009	Belt remaining time - J6 axis [Hr]		
1003 1010 1011	Belt remaining time - J7 axis [Hr]		
1012 1013	Belt remaining time - J8 axis [Hr]		

<Precautions>

- When the target mecha does not exist, outputs all the data with zero.
- When the target mecha exists but the maintenance schedule is not supported, outputs all the data with "-1".
- When the target axis is not updated by the maintenance schedule, outputs the data "-1".

(2) Data description

[Battery remaining time]: Outputs the remaining time until the battery exchange. [Grease remaining time]: Outputs the remaining time until the grease-up of each axis. [Belt remaining time]: Outputs the remaining time until the belt exchange of each axis.

4 Reads/Writes Robot's Variables

4.1 Function Description

(1) Function list

The table below lists the variable operations performed from the sequencer:

Table 4-1:Variable operation function list

No	Item	Description	Robot's response time
1	Read numeric variable	Reads variable content by specifying slot number and variable name.	
2	Write numeric variable	Rewrites variable content by specifying slot number, variable name, and vari- able content.	Answered within
3	Read position variable	Reads variable content by specifying slot number and variable name.	1sec (it may vary
4	Write position variable	Rewrites variable content by specifying slot number, variable name, and vari- able content.	according to the robot control's
5	Read joint variable	Reads variable content by specifying slot number and variable name.	load state)
6	Write joint variable	Rewrites variable content by specifying slot number, variable name, and vari- able content.	


(2) Functional requirements

Always available when a program is selected for robot's target slot and the target variable exists. When the target is external variable, the variable operation is possible by specifying zero for a slot number, even when a program is not selected.

Be careful fully to change variable value.

The robot's location and behavior may be changed by changing the variable value, thereby interfering with surrounding devices. Because it is especially dangerous when the robot is in operation, sufficiently check the value to be changed.

4.2 Operation Flow



4.3 How to Operate Variables

Here, in the sequencer, operates the robot's variables (read/ write variables) by specifying function number, slot number, variable name, and variable data.

Function number setting allows you to select work type (read/ write variable) and variable type (numeric/ position/ joint variables) and specify a variable name (designation of ASCII character).

4.3.1 Data List

(1) Sequencer output data

1) Word data

Setting values when specifying ASCII character for variable and program names

Sequencer	s when <u>speciry</u>	Setting Value for Specifying ASCII Character						
Åddr	Item	Nume	ric Var	Position Var		Joint Var		
(offset)	(offset)		Write	Read	Write	Read	Write	
701	(Reserved)			(Reserved)			
702	Function No	101	102	104	105	107	108	
703	Slot No	Slot number [0, 1 to the value of parameter TASKMAX]						
704								
705								
706	Program name		(Not used)					
707	(Not used)			(Not useu)			
708								
709								
710								
711		Variable name [ASCII data, up to 16 characters]						
712								
713	Variable name							
714	Valiable fiame							
715								
716								
717								
718			Integer		X coordinate		J1 coordinate	
719					value		value	
720					Y coordinate		J2 coordinate	
721					value		value	
722					Z coordinate		J3 coordinate	
723					value		value	
724					A coordinate value		J4 coordinate value	
725 726								
720					B coordinate value	(Not	J5 coordinate value	
728	Variable data	(Not used)	(Not used)	(Not used)		used)		
729					C coordinate value	4004)	J6 coordinate value	
729					L1 coordinate		J7 coordinate	
730					value		value	
732					L2 coordinate		J8 coordinate	
733					value		value	
734						-		
735					Structure flag			
736						-	(Not used)	
737					Multi-turn data			

2) Bit signal

Sequencer Address		
Addr (offset)	Bit position	Description
700	0	Request for variable operation

(2) Robot output data

1) Word data

Setting values when specifying ASCII character for variable and program names

Sequencer	es when <u>specityii</u>			alue for Spec			
Åddr	r Item Numeric Var Position Var		on Var	Join	t Var		
(offset)		Read	Write	Read	Write	Read	Write
551	Completion status		Comple	OK/ other that	n 1: NG]		
552	Function No	101	102	104	105	107	108
553	Slot No	Slot number [0, 1 to the value of parameter TASKMAX]					
554							
555							
556	Program name		Program	name, ASCII d	ata un to 12 c	characters]	
557	riogrammanie		riogrami		ulu, up to 12 t	indidoteroj	
558							
559							
560							
561							
562							
563	Variable name	Variable name [ASCI] data un te 16 charactere]					
564	valiable fiame	Variable name [ASCII data, up to 16 characters]					
565							
566							
567							
568		Inte	eger	X coordin	ate value	J1 coordir	nate value
569				X coordin		51 600141	
570				Y coordin	ate value	J2 coordinate value	
571					ate value	52 COOldin	
572				Z coordinate value	J3 coordinate value		
573	Variable data				ate value	35 0001011	
574	variable data	(Not used)	(Not used)	A coordin	ate value	J4 coordir	nate value
575				Accordin			
576				B coordin	ate value	J5 coordir	nate value
577							
578				C coordin	ate value	J6 coordir	nate value
579							
580				L1 coordir	nate value	J7 coordir	nate value
581							
582		L2 coordinate value J8 coordinate value					nate value
583							
584				Structu	ire flag		
585				Olidold			
586				Multi-tu	rn data	(Not used)	(Not used)
587				intall to			

2) Bit signal

Sequencer A	Address	
Addr (offset)	Bit position	Description
550	0	Variable operation completed

(3) Completion status

The values below are established as completion status:

Setting Value	Description
1	Successfully completed
2	Specified data (function number, slot number, variable number, element number, or external variable specification) out of range
3	Program not selected for the target slot
4	Target variable does not exist
5	(Reserved)
6	Not the formal variable data (at the time of writing variable)
7	Target variable not writable (at the time of writing variable)
8	Target variable value out of range at the time of reading variable: Not in the range between -32768 and 32767 (at the time of reading numeric variable)
10	NG because of a factor other than 2 to 8

(4) Data description

[Function No]

Select the target function.

Function number setting allows you to select work type (read/ write variable) and variable type (numeric/ position/ joint variables) and specify a variable name (designation of ASCII character).

[Slot number]

Select the target slot.

In general, specify a value between 1 and the value of parameter TASKMAX (factory default: 8). In case of external variable, "0" can be specified.

[Program name]

Program name is displayed in ASCII character.

• Specifying ASCII character

- Specify ASCII program name in 6 words area (12 characters).
- To specify ASCII characters, specify all 12 characters or string data including terminating code. However, leading and ending blank characters (space) are ignored.
- When target is an external variable and zero is specified for slot number, the program name becomes NULL.

[Variable name]


To specify a variable name, specify ASCII characters.

• Specifying ASCII character

- Specify the variable name (including leading character) in the 8 words area (16 characters, robot specification).
- To specify ASCII characters, specify all 16 characters or string data including terminating code. However, leading and ending whitespace characters (space) are ignored.
- The character underscore (_) used in array and external variable is also available, and array or external variable can be specified.

<ASCII data setting example>

- Set up the data in order from low to high byte of start address.
- Specify zero as a terminating code.
 - (Be compliant with the character input specification of the sequencer)



Specify zero as'a terminating code

<Available character>

Available characters are compliant with robot specification. (Refer to the table below.)

Category	Available Characters	Program Name	Variable Name
Alphabetic	ABCDEFGHIJKLMNOPQRSTUVWXYZ	0	0
character	abcdefghijklmnopqrstuvwxyz	×	0
Figure	0 1 2 3 4 5 6 7 8 9	0	△ Note1)
Symbol	"'&()*+,/:;=<>?[\]^{}~ !#\$%	×	× Note2)
Symbol	'_' (underscore)	×	△ Note3)
White space	Whitespace character	×	×

Note1) Only the alphabetic characters are available at the beginning of variable name. A figure is available for second and after characters.

Note2) Parentheses "()" for specifying an array are available.

Note3) Available for second and after characters. The variable whose second character is underscore '_' is an external variable.

[Variable data, numeric variable]

- One word is prepared for a numeric variable and only an integer can be specified.
- Therefore, its range is between -32768 and 32767, and digits after decimal point are discarded.

[Variable data, position and joint variables]

• The unit is 10^{-4} mm or 10^{-4} deg.

However, the number of significant figures for position and joint variable data output from the robot is dependent on the parameter PRGDPNTM (digits after decimal point: factory default is 2 or 3 digits (it may vary according to the robot model)), and the portion less than the significant figures is rounded off. For example, when PRGDPNTM is two, to round off 1.2345 gives 12300 and to round off 6.7890 gives 67900.

• Only lower one word is used for the structure flag of position variable, and upper one word is a reserved area.

- When a variable in undefined state (a variable exists but its data is empty) is read, zero is set to the undefined portion of data.
- Because each component value is handled as a single-precision floating type real number in the robot, <u>the</u> <u>number of significant figures is about 7 digits.</u>

(The value which can be expressed with 24bit when expressed in binary number is about 7 digits when expressed in decimal number).

• When the data is successfully written into a variable, the variable data in the robot after the writing is read again and sent.

Therefore, even when writing into a position or joint variable is successfully ended, the data specified by the sequencer may be different from the data to be sent by the robot. The robot's posture data or the number of significant figures of data's digits after decimal point may differ.

4.3.2 Timing Chart




Fig.4-1:Variable operation timing chart

- (1) The sequencer sets up "Function number", "Slot number", "Variable name", and "Variable data" (only for writing variable) and turns ON "Request for variable operation".
- (2) When the robot receives "Request for variable operation ON", the robot operates the variable based on received data. When "Function number", "Slot number", "Variable name", "Variable data", and "Completion status" are specified after the operation, the robot turns ON "Variable operation completed".

When the operation cannot be carried out, the robot specifies a number indicating NG and turns ON "Variable operation completed".

- (3) When "Variable operation completed ON" is received, the sequencer turns OFF "Request for variable operation".
- (4) When received "Request for variable operation OFF", the robot turns OFF "Variable operation completed" and clears the data.

4.3.3 Sample Ladder

Here, describes a ladder example which reads the data by specifying a position variable name.

[Target function]

Reads position variable (designation of ASCII character)

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Description]

Turn ON the position variable read trigger (M100) to read the data of position variable P200 in slot 1. The read position variable data is stored in D118 and after.

When the read handling is completed, M104 is turned ON. In this case, successful completion turns M102 ON and abnormal completion turns M103 ON.

When M104 is turned ON, turn OFF the position variable read trigger (M100).

[Device details]

D10 - D17: Specify variable name

M100: Position variable read trigger

M101: Position variable successfully received

M102: Position variable reception OK completed

M103: Position variable reception NG completed

M104: Reading position variable completed

D101: Received data from the robot (completion status)


D102: Received data from the robot (function number)

D103: Received data from the robot (slot number)

D104 - D109: Received data from the robot (program name)

D110 - D117: Received data from the robot (variable name)

D118 - D137: Received data from the robot (position variable data)



5 Read Current Line of Robot Program

5.1 Function Description

(1) Function list

The Table 5-1 lists the program operations performed from the sequencer.

Table 5-1: Program operation function list
--

No	Item	Description	Robot's Response Time
1	Read program's cur- rent line	 Reads currently performing robot program (one line, 128 characters) by specifying a slot number. Practicable when a program is selected for robot's slot. 	Responds within 1s (it may vary accord- ing to the robot con- trol's load state)

(2) Program data


The program data is as follows:

- The data is one line of program (up to 128 characters) in ASCII.
- When the data is less than 128 characters, terminating code 0 (NULL) is added at the end of string.
- Shift JIS codes are used for kanji character (similar to GOT specification).

When a program line can be longer than 128 characters, the data after 128th character cannot be read.

Consequently, when the program whose line is longer than 128 characters is read and the data is written as-is into the robot, be careful that the data which exceeds 128 characters will be deleted.

5.2 Operation flow



5.3 How to Operate Program

Here, in the sequencer, operates the robot program by specifying function number, slot number, program name, and program data.

Setting function number to '103' allows you to select a work type (read current line) and specify a program name (designation of ASCII character).

5.3.1 Data List

(1) Sequencer output data

1) Word data

Sequencer Addr	Item	Setting Value for Specifying ASCII Character			
(offset)	nem	Program			
· · ·		Read current line			
740	(Reserved)	(Reserved)			
741	Function No	103			
742	Slot No	Slot number [1 to the value of parameter TASKMAX]			
743					
744					
745	Program name	(Not used)			
746	riogrammanic				
747					
748					
749	Line No	(Not used)			
750	(Reserved)	(Reserved)			
751					
752					
	Program data	(Not used)			
813					
814					
511					

2) Bit signal

Sequencer A	Address		
Addr (offset)	Bit position	Description	
700	1	Request for program operation	

(2) Robot output data

1) Word data

Sequencer		Setting Value for Specifying ASCII Character			
Addr (offset)	Item	Program			
(enect)		Read current line			
590	Completion status	Completion status [1: OK/ other than 1: NG]			
591	Function No	103			
592	Slot No	Slot number [1 to the value of parameter TASKMAX]			
593					
594					
595	Program name	Program name, ASCII data, up to 12 characters			
596	riogrammanie	riogrammanic, noon data, up to 12 onardotero			
597					
598					
599	Line No	Line No [1 - 32767]			
600	Number of pro- gram characters	Number of program characters			
601	gram one doloro				
602					
•					
•					
		Program to be read			
	Program data	[ASCII data, up to 128 characters]			
		* Shift JIS code for kanji			
663					
664					
504					

2) Bit signal

Sequencer A	Address			
Addr (offset)	Bit position	Description		
550	1	Program operation completed		

(3) Completion status

The values below are established as completion status:

Setting Value	Description
1	Successfully completed
2	Specified data (function number, slot number, program number) out of range
3	Program not selected for the target slot
4	(Reserved)
5	(Reserved)
6	(Reserved)
7	(Reserved)
10	NG because of a factor other than 2 to 7

(4) Data description

[Function No]

Selects the target function.

Function number setting allows you to select a work type (read current line) and specify a program name (designation of ASCII character).

[Slot number]

Select the target slot. Specify a value (factory default: 8) in the range between 1 and the value of parameter TASKMAX.

[Program name]

ASCII characters of the output program name.

- Specifying ASCII character
- Specify ASCII program name in 6 words area (12 characters).
- To specify ASCII characters, specify all 12 characters or string data including terminating code. However, leading and ending whitespace characters (space) are ignored.

For information about ASCII data, available characters, refer to Page 37, "(4) Data description".

[Line No]

The line number of the read line is output.

When a program is selected but program is in abeyance (program is not running), the line number of first line is output.

[Number of program characters]

Outputs the number of characters of target line in the target program.

Count and specify the number of characters from the leading to final character (exclusive of line feed/ terminating characters) including comment line (exclusive of line number).

When the target line is longer than 128 characters, up to 128 characters are read as a program data, but the number of counted characters is set as-is as the number of program characters. When writing into a program, the number of characters of written line is set.

Example 1: A line is less than 128 characters:

MOV P1 ' Move to the aime	ed position <cr></cr>				
L F					
Number of program characters	25				
Encoify the	- number of the	actora fr	adina ta th	مم المما مام	ana atan (a

Specify the number of characters from the leading to the final character (exclusive of terminting character)

Example 2: A line is more than 128 characters:

Stored in program data area (128 characters)

	PHOSEI=PBASE*INV(PTOOL)*PDATA		' Calculate correction calculation <cr></cr>	
	L			_
Number of program characters 132		132		
	Specific the number of characters from the leading to the final character (avaluative of			

Specify the number of characters from the leading to the final character (exclusive of terminting character)

[Program data]

- The data is in ASCII format and up to 128 characters of program content are stored.
- Shift JIS codes are used for kanji.
- Line number is excluded from the program data.

5.3.2 Timing Chart




Fig.5-1:Program operation timing chart

- (1) The sequencer sets up necessary data of "Function number", "Slot number", "Program name", "Line number", and "Program data" and turns ON "Request for program operation".
- (2) When the robot receives "Request for program operation ON", the robot operates the program based on received data. When "Function number", "Slot number", "Program name", "Program data", and "Completion status" are specified after the operation, the robot turns ON "Program operation completed".

When the operation cannot be carried out, the robot specifies a number indicating NG and turns ON "Program operation completed".

- (3) When "Program operation completed ON" is received, the sequencer turns OFF "Request for program operation".
- (4) When received "Request for program operation OFF", the robot turns OFF "Program operation completed" and clears the data.

5.3.3 Sample Ladder

Here, describes a ladder example which reads the current line of a program performed by the robot.

[Target function]

Reads program's current line (designation of ASCII character)

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Description]

Turn ON the program read trigger (M110) to read the program data of current line in slot 1.

The read program data is stored in D210 and after.

When the read handling is completed, M114 is turned ON. In this case, successful completion turns M112 ON and abnormal completion turns M113 ON.

When M114 is turned ON, turn OFF the program read trigger (M110).

[Device details]

M110: Program read trigger

M111: Program successfully received

M112: Program reception OK completed

M113: Program reception NG completed

M114: Reading program completed

D200: Received data from the robot (completion status)


D201: Received data from the robot (function number)

D202: Received data from the robot (slot number)

D203 - D208: Received data from the robot (program name)

D209: Received data from the robot (line number)

D210 - D273: Received data from the robot (program data)



6 Set up Robot's Maintenance

6.1 Function Description

(1) Function list

The Table 6-1 lists the maintenance setting performed from the sequencer.


Table 6-1: Maintenance setting function list

No	Item	Description	Robot's Response Time
1	Reset maximum ser- vomotor value	Resets the servo monitor's maximum values (current value, load factor, etc.) stored by robot to zero.	Responds within 1s (it may vary according to the robot control's load state)

(2) Functional requirements

Always practicable.

6.2 Operation flow



6.3 How to Operate Maintenance

Here, in the sequencer, operates the maintenance setting by specifying function number and setting data corresponding to the function.

Function number setting allows you to select function items.

6.3.1 Data List

(1) Sequencer output data

1) Word data

	Item	Setting Value		
Sequencer Addr (offset)		Reset Servo Monitor's Maximum/Minimum Values		
820	(Reserved)	(Reserved)		
821	Function No	6		
822	Mecha No	Mecha No[1-3]		
823	Mecha No			
824				
825		(Not used)		
826				
827				
828				

2) Bit signal

Sequencer Address			
Addr (offset)	Addr (offset)	Description	
700	2	Request for maintenance setting	

(2) Robot output data

1) Word data

Sequencer		Setting Value	
Addr (offset)	Item	Reset Servo Monitor's Maximum/Minimum Values	
670	Completion sta- tus	Completion status [1: OK/ other than 1: NG]	
671	Function No	6	
672	Mecha No	Mecha No[1-3]	
673			
674			
675	Mecha No	(Not used)	
676	Mecha No	(Not used)	
677			
678			

2) Bit signal

Sequencer Address		
Addr (offset)	Addr (offset)	Description
550	2	Maintenance setting completed

(3) Completion status

The values below are established as completion status:

Setting Value	Description
1 Successfully completed	
2	Specified "Function number" and "Mecha number" are out of range (including the case that the target mecha does not exist).
3	(Not used)
4	No target function (the function specified by target mecha does not exist)
10	NG because of a factor other than 2 to 4

(4) Data description

[Function No]

Selects the target function.

[Mecha No]

Select the target mecha. Specify a mecha in the range of mechas 1 - 3.

6.3.2 Timing Chart




Fig.6-1:Maintenance function timing chart

- (1) The sequencer sets up necessary data of "Function number" and "Setting data" and turns ON "Request for maintenance setting."
- (2) When the robot received "Request for maintenance setting ON," the robot operates the maintenance setting based on received data. When "Function number", "Setting data", and "Completion status" are specified after the operation, the robot turns ON "Maintenance setting completed." When the operation cannot be carried out, the robot specifies a number indicating NG and turns ON "Maintenance setting completed."
- (3) When "Maintenance setting completed ON" is received, the sequencer turns OFF "Request for maintenance setting."
- (4) When "Request for maintenance setting OFF" is received, the robot turns OFF "Maintenance setting completed" and clears the data.

6.3.3 Sample Ladder

Here, describes a ladder example which resets the servo data's maximum values (current value, load factor) stored in the robot.

[Target function]

Reset the maximum servo monitor value

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Description]


Turn ON the maintenance setting read trigger (M120) to reset the maximum servo monitor values. Output data from the robot is stored in D302 and after.

When the reset handling is completed, M124 is turned ON. In this case, successful completion turns M122 ON and abnormal completion turns M123 ON.

When M124 is turned ON, turn OFF the maintenance setting read trigger (M120).

[Device details]

- M120: Maximum servo monitor value reset trigger
- M121: Maximum servo monitor value successfully reset
- M122: Maximum servo monitor value reset OK completed
- M123: Maximum servo monitor value reset NG completed
- M124: Maximum servo monitor value reset completed
- D300: Received data from the robot (completion status)
- D301: Received data from the robot (function number)
- D302: Received data from the robot (mecha number)



7 Read Robot Information

7.1 Function Description

(1) Function list

The Table 7-1 lists the robot information reading performed from the sequencer.


Table 7-1:Robot information reading function list

No	Item	Description	Robot's Response Time
1	Read error information	Reads the detailed error information generated in the robot. When multiple errors occur, three information can be read at the same time, and the information to be read can be changed by specifying the start number.	Responds within 1s (it may vary according to the robot control's load
2	Read product information Read the robot's product information.		state)

(2) Functional requirements

Always practicable.

7.2 Operation flow



7.3 How to Operate Robot Information

Here, reads the robot information from the sequencer by specifying function number and setting data. Function number allows you to select the robot information to be read.

7.3.1 Data List

(1) Sequencer output data

1) Word data

		Setting Value		
Sequencer Addr (offset)	Item	Read Error Information	Read Product Information	
830	(Reserved)	(Rese	erved)	
831	Function No	3	4	
832	Setting No	Start number [1 -]	(Not used)	

2) Bit signal

Sequencer Address		
Addr (offset)	Addr (offset)	Description
700	3	Request for reading information

(2) Robot output data

1) Word data

Sequencer		Setting	g Value
Addr (offset)	Item	Read Error Information	Read Product Information
680	Completion status	Completion status [1: OK/	other than 1: NG]
681	Function No	3	4
682		Start number [1 -]	(Not used)
683		Number of errors occurred	
684		Information 1 (error No)	
685			
686		Information 1	Debatting
687		(error occurred program name)	Robot type name [ASCII data, up to 20
688		[ASCII data, up to 12	characters]
689		characters]	
690			
691		Information 1 (occurred line No)	
692		Information 1	
693		(detailed error No)	Controller version
694		Information 1 (occurred slot No)	[ASCII data, up to 6 characters]
695			ondiductoroj
696	1	(Reserved)	
697			
698		Information 2 (error No)	
699			Controller serial No [ASCII data, up to 16
700		Information 2	characters]
701		(error occurred program name)	
702		[ASCII data, up to 12	
703		characters]	
704	Read data		_
705		Information 2 (occurred line No)	
706		Information 2	Robot serial No
707		(detailed error No)	[ASCII data, up to 16
708		Information 2 (occurred slot No)	characters]
709			
710		(Reserved)	
711			
712		Information 3 (error No)	
713		Information 3	
714		(error occurred program	
715		name)	
716		[ASCII data, up to 12	
717		characters]	
718 719		Information 3	(Not used)
719		(occurred line No) Information 3	
721		(detailed error No)	
722		Information 3 (occurred slot No)	1
723 724 725		(Reserved)	

2) Bit signal

Sequencer Address Addr (offset) Addr (offset) 550 3		
		Description
		Reading information completed

(3) Completion status

The values below are established as completion status:

Setting Value	Description
1	Successfully completed
2	Specified "Function number" out of range
3	Specified "Setting data" out of range
10	NG because of a factor other than 2 and 3

(4) Data description

[Function No]

Selects the target function.

[Start No of read data]

Specify the information's start number to be read.

The robot reads and stores three pieces of information from the specified number in the shared memory. Specify 1: Reads first to third pieces of registered information.

Specify 2: Reads second to fourth pieces of registered information.

Specify 3: Reads third to fifth pieces of registered information.

Of information 1 - 3, the information with small number is a new error.

When the target information with the specified number does not exist, the robot sets all read data to zero.

7.3.2 Timing Chart




Fig.7-1:Information reading timing chart

- (1) The sequencer sets up necessary data of "Function number" and "Start number" and turns ON "Request for reading information."
- (2) When "Request for reading information ON" is received, the robot specifies requested "Read data" and "Completion status" and turns ON "Reading information completed." When the operation cannot be carried out, the robot specifies a number indicating NG and turns ON "Reading information completed."
- (3) When "Reading information completed" is received, the sequencer turns OFF "Request for reading information."
- (4) When "Request for reading information OFF" is received, the sequencer turns OFF "Reading information completed."

7.3.3 Sample Ladder

Here, describes a ladder example which reads the detailed error information occurred in the robot.

[Target function]

Read error information

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Description]

Turn ON the error information read trigger (M130) to read the robot error information (first thee pieces of information from start).

The read error information is stored in D403 and after.

When the read handling is completed, M134 is turned ON. In this case, successful completion turns M132 ON and abnormal completion turns M133 ON.

When M134 is turned ON, turn OFF the error information read trigger (M130).

[Device details]

M130: Error information read trigger

M131: Error information received successfully

M132: Error information reception OK completed

M133: Error information reception NG completed


M134: Reading error information completed

D400: Received data from the robot (completion status)

D401: Received data from the robot (function number)

D402: Received data from the robot (start number)

D403 - D445: Received data from the robot (error information)




8 Perform Sequencer Direct

8.1 Sequencer Direct Performance Function

The sequencer direct performance function directly operates the robot by using the extended shared memory.

The performance function is composed of robot operation, hand open/close, working speed/ acceleration setting, position data management, etc.


The figure below shows the data flow between sequencer and robot when performing the sequencer direct.



- (1) The sequencer specifies a command (instruction) to directly operate the robot (sequencer direct performance).
- (2) The sequencer controls a hand (dedicated I/O signal control).
- (3) The sequencer specifies the command conditions and speed, acceleration, tool setting, etc. for the sequencer direct performance.
- (4) The sequencer prepares up to 999 pieces of position data for sequencer direct performance in the robot controller.(Teaching data does not occupy all the memory area of the sequencer device.)
- (5) The sequencer can move the robot relatively with reference to robot's current position.
- (6) The sequencer moves the robot to the position by specifying the position data.


8.2 Operation flow

The figure below shows the operation flow when performing the sequencer direct.



They are not necessary for operation after the startup.

8.2.1 Parameter Setting



For information on how to set up parameters, refer to Page 6, "2 Preparation for Using Extended Function".

8.2.2 Teaching

Here, teaches the position data for performing the robot's sequencer direct.

(1) Position Data

The position data handled in the sequencer direct performance shall be position type data only. The joint type data is not handled.

The table below lists the available positions:

Position No	Score	Description	Remarks
1 - 999	999	Position type data in robot controller	
5000	1	Robot's current position	State variable P_Curr is sup- ported
5100 - 5102	3	Position type data specified by the sequencer in the shared memory	

How to use positions 5100 - 5102


Use these positions when performing sequencer direct with the position data created in the sequencer. Sequencer direct can be performed by storing the position data created in the sequencer in the position type data area (5100 - 5102) in the sequencer shared memory and specifying the position number 5100 - 5102.

Specifying the tool data

Before teaching, specify the tool data. The tool data specifies the control point of hand or tool mounted on the robot. For more information, refer to Page 78, "(8) Tool data setting"

Note that when tool data is specified or changed after teaching, previous teaching data will be unavailable. (When you try to move the robot to previous teaching position before setting or changing of tool data, the robot moves to the wrong position.) (2) Position Teaching in Position Box (R32TB)






* When an error occurs while displaying the teach confirmation screen, the screen returns to the SQ DIRECT teach screen by resetting the error.

2) Description of screens

2-1) Menu screen



"6. ENHANCED" is displayed as a menu item. It is always possible to move to the ENHANCED menu screen.

2-2) ENHANCED function menu screen

<enhanced></enhanced>			
1. SQ DIRECT	2	2. WORK C	OORD.
	123		CLOSE
		la m la vil	

["1. SQ DIRECT" display]

Although the sequencer direct function is valid or not, "1. SQ DIRECT " is displayed.

[Selecting "1. SQ DIRECT "]


When "1. SQ DIRECT " is selected, the sequencer direct teach screen is displayed. <Condition>

All the conditions below should be met:

- a) Connected to the following robot controller CRnQ-700 series controllerVer. N8 or later CR750-Q/CR751 series controller ... Ver. R3 or later
- b) Sequencer direct performance function is valid Both bits 1, 0 of parameter (IQMEM) for selecting the shared memory extended function are "1"
- c) In robot controller's MANUAL mode
- d) T/B is valid

<Action when screen change is impossible>

When above conditions a, b are not met, the warning screen below is displayed.




- When an error occurs, changes to the error screen. The screen returns to the ENHANCED menu screen by resetting the error.
- Push [JOG] key to change to the JOG screen. Push [JOG] key again to change to the ENHANCED menu screen.
- Push [HAND] key to change to the hand screen. Push [HAND] key again to change to the ENHANCED menu screen.
- Push [MONITOR] key to change to the monitoring screen. Push [MONITOR] key again to change to the ENHANCED menu screen.

Disable T/B to change to the ENHANCED menu screen.

When the warning screen above is displayed while an error occurs, push [RESET] key to reset the error and then change to the ENHANCED menu screen.

When the conditions "c)", "d)" above are not met while the conditions "a)", "b)" above are met, the buttons are grayed out. The warning screen is not displayed.

2-3) SQ DIRECT teach screen



For information on teaching operation, refer to the description about position edit screen in "Instruction Manual, Detailed Description of Functions and Operations."

[Position check]

The robot moves to the displayed position while pushing [F1] (MOVE) key. <Condition>

All the conditions below should be met:


a) In robot controller's MANUAL mode

b) T/B is valid

- c) T/B enabled switch (3-positioned switch) is turned ON (intermediate position)
- d) Servo is turned ON

[Teaching position]

Push [F2] (TEACH) key to display the confirmation screen below.



Push [F1] (Yes) key in the confirmation screen to teach you that current position is at the displayed position and come back to the screen.

Push [F4] (No) key to come back to the screen without teaching.

[Teaching position]

Teaching in the SQ DIRECT teach screen always sets up current position for mecha 1. Even when mecha 2 or 3 is selected by T/B, it sets up current position for mecha 1.

[MDI (Manual Data Input) registration/ modification of position]

A position can be registered by directly inputting numeric value to each axis's component of position data.

Push arrow key to move the cursor to the data to be modified, input numeric value, and push [EXE] key.

-	-	,				
<sq< th=""><th>DIR</th><th>ECT></th><th>JNT</th><th>100% P</th><th>OS. 1</th><th></th></sq<>	DIR	ECT>	JNT	100% P	OS. 1	
	Х	+0.	00	A:	+0.00	
	Y	: +0.	00	B:	+0.00	
	Z	: +0.	00	C:	+0.00	
	L1	: +0.	00	L2:	+0.00	
	FL1	: 000000	00	FL2:00	000000	
MO	VE	TEACH	123	Prev	Next	⇒

[Changing position display]

(a) Forward/ backward feed

Each time [F3] (Prev) or [F4] (Next) key is pushed, displayed position is changed.

- The display changes as follows:
 - [F3] (Prev): From 1 to 999, 998, 997, ..., 1
 - [F4] (Next): From 1 to 2, 3, ..., 999, 1
- (b) Call number

Push [FUNCTION] key, change the function key allocation, and push [F2] (NUMBER) key to display the position number input screen below.

<sq direct=""></sq>				
POSITION NUM	BER ()		
	123		CLOSE	∣⇒

Input a position number and push [EXE] key to come back to the screen and display the target position.

When a number other than 1 to 999 is entered, the [EXE] key gets unavailable. Push [F4] (CLOSE) key to come back to the previous screen.

[Displaying menu screen]

Push [FUNCTION] key, change the function key allocation, and push [F4] (CLOSE) key to come back to the ENHANCED menu screen.


[Handling when T/B became invalid]

When T/B became invalid while displaying the sequencer direct teach screen (including the teach confirmation and position number input screens), saves the position data and comes back to the ENHANCED menu screen.

[Handling when entered into AUTOMATIC mode]

When changed to AUTOMATIC mode while displaying the sequencer direct teach screen (including the teach confirmation and position number input screens), an error "H5000 TB Enable key is ON " occurs and an error screen appears. The screen comes back to the previous screen by resetting the error.

8.2.3 Prepare to Perform Sequencer Direct



- (1) In the sequencer, get the robot's external operation authority.
 - 1) Change the MODE switch to "AUTOMATIC" on the robot operation panel.
 - 2) Turn ON the sequencer's operation authority signal (IOENA).
 - 3) Wait until the robot successfully gets the operation authority (robot's operation authority (IOENA) signal is ON).
- (2) In the sequencer, check that H or L level error is not occurring in the robot. Check the robot's error state (robot's HLVLERR and LLVLERR signals OFF). When either one is turned ON, turn ON sequencer's ERRRESET signal to reset the error.
- (3) In the sequencer, check that robot's program is available (program is not running). Check the robot's program availability (robot's SLOTINIT signal ON). When it is not turned ON, turn ON sequencer's SLOTINIT signal to reset the error.
- (4) In the sequencer, turn ON the robot's servo.

Check the robot's servo ON (robot's SRVON signal ON). When it is not turned ON, turn ON sequencer's SRVON signal and wait until the robot turns ON the servo.

* The order of steps (1) to (4) are not necessarily the same as above. But, in the sequencer, to reset a program and turn ON the servo, it is necessary to get external operation authority.

8.3 How to Operate Sequencer Direct

Here, describes the robot's operation commands and how to control hand.

To issue an operation instruction to the robot, set up the command data (command number + auxiliary data) and command condition data and turn ON the command request signal. The robot runs according to the specified command. Control the hand by turning ON/OFF the hand output signal.

8.3.1 Operation Command

Memory map of sequencer direct performance area corresponding to the robot operation commands is as follows:

(1) Sequencer output

Sequencer Output Addr (offset)		Description	Remarks
520	Bit signal	Command request signal Bit allocation bit15 0 00000000000000000000000000000000000	
521		(Reserved)	
522		(Reserved)	
523		(Reserved)	
524	Command data	Command No	
525		Command data 1	
526		Command data 2	
527	(Reserved)		
528	(Reserved)		
529	(Reserved)		
530		Override [%: 1 - 100, 0]	100% when zero
531		Acceleration rate [%: 1 - 100, 0]	100% when zero
532		Deceleration rate [%: 1 - 100, 0]	100% when zero
533		(Reserved)	
534		(Reserved)	
535		Speed setting [mm/s: 1 - 10000, 0]	When either 0 or 10000, it operates at maximum speed.
536	Command con- dition data	Shortcut/roundabout specification [0: Initial value/ 1: Opposite of initial value]	 <joint interpolation=""></joint> 0: Roundabout (teaching posture) 1: Shortcut <linear circular="" interpolation=""></linear> 0: Shortcut /1: Roundabout
537		Auxiliary operation specification [0: Equivalent rotation/1: Orthogonal triaxis/2: Sin- gularity pass]	Valid for linear/ circular interpolation
538		Tool setting [0: Current tool/ 1- 4: Tool number]	
539 - 639	(Reserved)		

Sequencer Output Addr (offset)		Description	Remarks
640		X coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
641 642			
643		Y coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
644 645		Z coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
646		A coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
647 648			
649	Position data 1	B coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
650 651	(5100)	C coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
652			
653 654		L1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
655		L2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
656		Structure flag	
657 658			
659		Multi-turn data	
660 661		X coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
662		Y coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
663 664	Position data 2 (5101)		
665		Z coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
666 667		A coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
668			
669		B coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
670 671		C coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
672		L1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
673 674			
675		L2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
676 677		Structure flag	
678		Multi-turn data	
679 680			
681		X coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
682 683		Y coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
684		Z coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
685 686	Position data 3 (5102)		
687		A coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
688 689		B coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
690			
691		C coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
692 693		L1 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
694		L2 coordinate value [10 ⁻⁴ mm/10 ⁻⁴ deg]	
695 696			
697		Structure flag	
698 699		Multi-turn data	
000		1	1

(2) Robot output

Sequencer Input Addr (offset)		Description	Remarks
520	Bit signal	Command completion signal bit15 0 0000000000000000 +- bit0: Completed + bit1: Working	
521		(Reserved)	
522		Completion status [1: OK/ other than 1: NG]	
523		(Reserved)	
524	Command data	Command No	
525		Command data 1	
526		Command data 2	
527 - 549	(Reserved)		

(3) Data description

[Command data]

Command number (524), command data 1 (525), command data 2 (526)

Instruction data (sequencer output 524 - 526) to the robot for sequencer direct performance and returned data from the robot (robot output 524 - 526). The setting values according to the instructed operations are as follows:

Action		Symbol Note1)	Command No	Command data 1	Command data 2	Remarks
Joint interpola- tion	Moves to the specified position. Specify the Z direction tool distance to move by specified distance away to the Z axis direction in the tool coordinate system.	Mov	1	Destination Position No	Z direction tool distance [10 ⁻¹ mm]	When the setting value of data 2 is set to zero, moves to the specified position.
	Moves the robot to the position with coordinate value of the destination position added by the coordinate of the approach coordinate position.	MovA	2	Destination position num- ber	Approach coor- dinate position number	
Linear interpola- tion	Moves to the specified position. Specify the Z direction tool distance to move by specified distance away to the Z axis direction in the tool coordinate system.	Mvs	11	Destination position num- ber	Z direction tool distance [10 ⁻¹ mm]	When the setting value of data 2 is set to zero, moves to the specified position.
	Moves the robot to the position with coordinate value of the destination position added by the coordinate of the approach coordinate position.	MvsA	12	Destination position num- ber	Approach coor- dinate position number	

Note1) These symbols MovA, MvsA are different from the robot language. They are used for description below.

• Completion status (sequencer input 522)

When the sequencer direct is successfully performed or when the sequencer direct cannot be received, the completion status is set.

The values below are established as completion status:

Setting Value	Description	Remarks			
1	Successfully completed				
2	External operation authority invalid	The command cannot be received			
3	H or L level error is occurring				
4	Program is not available (program running)				
5	Not robot servo ON				
6	Stop signal inputting				
7	Returning to retracting point				
8	Remote Jog working				
9	Variable not extended (For more information, refer to Page 115, "9.1 Parameter of Selecting Shared Memory Extended Function")				
10	Origin not set				
11	Command number out of range				
12	Command data 1 out of range				
13	Command data 2 out of range				
14	Operating condition data out of range (Only the available operating conditions for the target operation are checked)				
20	Sequencer direct impracticable because of other causes				
30	Sequencer direct performance suspended	Command suspended			

[Command condition data] (sequencer output 530 - 538)

The table below lists the data specified as command condition data:

Name	Description	Setup range	Operation for Initial Value (0)	Corresponding Command MELFA-BASIC
Override	Specify the speed rate [%] of robot operation [1 - 100, 0]	1 - 100, 0 (100% when zero)	100%	Ovrd
Acceleration rate	Specify the acceleration rate [%] of robot operation [1 - 100, 0]	1 - 100, 0 (100% when zero)	100&	Accel
Deceleration rate	Specify the deceleration rate [%] of robot operation	1 - 100, 0 (100% when zero)	100%	
Speed setting	Specify the speed [mm/s] of robot's linear interpolation	1 - 10000, 0 (When either 0 or 10000, it operates at maximum speed)	Maximum speed	Spd
Shortcut/round- about specifica- tion ^{Note1)}	Specify the robot's shortcut/roundabout [0: Initial value/ 1: Opposite of initial value] <joint interpolation=""> 0: Roundabout (teaching posture) /1: Short- cut <linear interpolation=""> 0: Shortcut /1: Roundabout</linear></joint>	Refer to the left	Joint interpola- tion → Roundabout Linear interpola- tion → Shortcut	Type specifica- tion of operation command
Auxiliary opera- tion specification	Auxiliary specification for robot's linear interpolation	0: Equivalent rotation 1: Orthogonal triaxis 2: Singularity pass	Equivalent rota- tion	
Tool setting	Sets the tool number. Tool data (MEXTL 1 - 4) with specified num- ber is used as the current tool data and is set to parameter MEXTL.	0: Current tool 1 - 4: Tool number	Current tool	M_Tool

Note1) Shortcut/roundabout specification value

When the shortcut/roundabout specification value is zero, it specifies the initial value (without Type specification) of the robot program commands (Mov, Mvs). When it is one, it specifies reverse initial value. They are different from the value set up by Type specification of robot program command.

[Position data 1 - 3] (sequencer output 640 - 699)

Used during setting up the position data in the sequencer when performing the sequencer direct.

The unit is 10^{-4} mm or 10^{-4} deg.

Only lower one word is used for the structure flag of position variable, and upper one word is a reserved area.

[Command/ command condition description]

- (1) Joint interpolation: Mov, MovA
 - Evenly interpolate the robot's each axis difference between joint angles of start and end positions. Therefore, end's track draws a smooth arc.

MovA moves the robot to the position with coordinate values of the destination position added by the coordinate values of the approach coordinate position.


For example, when Z value of approach coordinate position is the distance A shown in the figure right below, joint interpolates to position A over the aimed position.

(2) Linear interpolation movement: Mvs, MvsA Linear interpolation moves the robot so that the track of control points from robot's start to the end becomes a straight line.

The hand's posture changes evenly from the start to the end.

MvsA moves the robot to the position with coordinate values of the destination position added by the coordinate values of the approach coordinate position.

For example, when Z value of approach coordinate position is the distance A shown in the figure right above, linear interpolates to position A over the aimed position.



(3) Override: Ovrd

Specify the speed of robot operation with the value between 1 and 100%.

(4) Acceleration/ deceleration rate: Accel

Specify the acceleration and deceleration in rate (%) during robot operation.

Specify the acceleration/deceleration rate with the value between 1 and 100% with reference to the acceleration and deceleration time set up for robot in advance. The initial value is 100% (maximum acceleration and deceleration) for both acceleration and deceleration. Adjust the acceleration/deceleration rate according to the robot activity.

(5) Speed: Spd

Specify the speed of the end when the robot moves for linear interpolation. The unit is mm/s. This value does not impact on the joint interpolation command.

When zero or 10000mm/s is specified as the speed, the robot is in the maximum speed control mode.

The maximum speed control mode allows you to reduce the takt time by adjusting the motor speed of robot's each axis while keeping linear track. Consequently, linear speed may change.


Actual linear speed is a value specified by override command multiplied by a speed specified by this speed setting command.

Example: When override = 50% and speed setting = 300mm/s, actual linear speed = 0.5 x 300 = 150mm/s

(6) Shortcut/roundabout specification

There are three types of hand rotation direction below when performing a move command:

- a) Shortcut specification
- b) Roundabout specification
- c) Move to teaching posture (Roundabout joint interpolation)




(7) Auxiliary operation specification

Specify the hand posture control type during linear interpolation.

a) Equivalent rotation: Evenly interpolates from start posture (A, B, C) to the posture (A, B, C) at aimed position. b) Orthogonal triaxis: Interpolates with joint angle (J4, J5, J6) instead of hand posture (A, B, C). Evenly interpolates from start posture (J4, J5, J6) to the posture (J4, J5, J6) at aimed position. Effective when passing by near a singularity. c) Singularity pass: Specification to pass by a singularity specific to six axes robot (singularity posture is posture B shown in the right figure (2)). Restricted by some positions and postures.


> For more information on the operation, refer to "Instruction Manual, Detailed Description of Functions and Operations".



(8) Tool data setting

Select the tool data (1 - 4) set up by parameters in advance.

The tool data indicates the end (grip point) of hand and is specified by shift amount from the center of robot flange and rotation angle.



[How to decide tool data]

The tool data has the same components as the position data.


X, Y, Z: Shift amount. Moving amount from the center of flange to the tool position. (Unit is mm)

A, B, C: Rotation angles of coordinate axes. (Unit is deg)

- A: Rotation angle around X axis
- B: Rotation angle around Y axis
- C: Rotation angle around Z axis


To decide each data, move the mechanical interface coordinate system at the center of flange in order of (1) shift amount, (2) Z axis rotation, (3) Y axis rotation, (4) X axis rotation to accord with the aimed tool coordinate system. In this case, the move amounts (1) - (4) (rotation amounts) indicates the tool data.

Based on the example shown in the figure above, the figure below shows the steps to decide each data. In this example, because steps 2 and 4 of steps (1) - (4) are not necessary, the steps 2 and 4 are omitted.



[Tool data setting example]


A sample hand attachment and sample tool data setting in the coordinate system are shown below:



8.3.2 Timing Chart for Performing Operation Command

(1) Perform Operation (Normal Operation)

The sequencer operates the robot by setting the data for command number and command data 1, 2. When the command condition data is set to zero, the robot runs based on the default setting. The robot runs based on the instructed setting by setting value for condition data.



- (1) The sequencer sets up "Command data" and "Condition data" and sends "Command request ON".
- (2) When "Command request ON" is received, the robot imports "Command data" and "Condition data". When the imported data is formal and sequencer direct is practicable, the robot sets up "Command data" (returned data), sends "Command running ON", and carries out the instructed robot operation.
- (3) When the robot successfully completed the operation, the robot sends "Command running OFF", sets "Completion status" to one, and sends "Command completed ON".
- (4) When the sequencer received "Command completed ON", the sequencer imports "Completion status" and sends "Command request OFF".
- (5) When the robot received "Command request OFF", the robot clears "Completion status" and "Command data" to zero and sends "Command completed OFF".


Robot's arrival point when operation command is completed

"Command completed" signal for performing an operation command is turned ON when the robot arrived at the aimed position (encoder feedback position is not checked).

Therefore, when performing operations continuously, the robot may perform next operation before arriving at the aimed position. In order to avoid this situation, make sure that the sequencer takes a delay time before carrying out next operation after sequencer direct was completed.

(2) Operation Command Is Impracticable:


When the command data instructed by the sequencer is not formal or when the robot is out of work, the robot stores a number indicating an impracticable reason in "Completion status" against "Command request" from the sequencer and then returns "Command completed".



- (1) The sequencer sets up "Command data" and "Condition data" and sends "Command request ON."
- (2) When "Command request ON from OFF" is received, the robot imports "Command data" and "Condition data." When the imported data is not official or when the robot is impracticable of sequencer direct, the robot sets "Command data" (returned data) and "Completion status" to other than one, and sends "Command completed ON."
- (3) When the sequencer receives "Command completed ON", the sequencer imports "Completion status" and sends "Command request OFF".
- (4) When the robot receives "Command request OFF", the robot clears "Completion status" and "Command data" and sends "Command completed OFF".

(3) Suspend/Resume Operation

When the robot stops due to the robot's stop operation or stop input while performing the sequencer direct, the operation is suspended and the command is also suspended (Completion status = 30, suspended). To resume after suspension, set up "Command data" and "Condition data" again and send "Command request" signal again.



<Suspension handling>


- (1) When the robot stops while performing the sequencer direct, the robot sends "Command running OFF", sets "Completion status" to 30 (suspended), and sends "Command completed ON".
- (2) When the sequencer receives "Command completed ON", the sequencer imports "Completion status" and sends "Command request OFF".
- (3) When the robot receives "Command request OFF", the robot clears "Completion status" and "Command data" to zero and sends "Command completed OFF".

<Resume handling>

- (4) When a resume operation is carried out in the sequencer, the sequencer sets up "Command data" and "Condition data" and sends "Command request ON".
- (5) When "Command request ON" from OFF is received, the robot imports "Command data" and "Condition data", sets up "Command data" (returned data), sends "Command running ON", and carries out the instructed robot operation.

(4) Support on Occurrence of Error

When H or L level error occurs while performing the sequencer direct, the operation is suspended. To resume after suspension, reset the error, re-set up "Command", "Command data", and "Condition data", and send "Command request" signal again (I/F for suspension and resume is the same as Page 83, "(3) Suspend/Resume Operation").




<Handling on error occurrence>

- (1) When H or L level error occurs in the robot while performing the sequencer direct, the operation is suspended. The robot sends "Command running OFF", sets "Completion status" to 30 (suspended), and sends "Command completed ON".
- (2) When the sequencer receives "Command completed ON", the sequencer imports "Completion status" and sends "Command request OFF".
- (3) When the robot receives "Command request OFF", the robot clears "Completion status" and "Command data" to zero and sends "Command completed OFF".
- <Error reset handling>
 - (4) Error reset operation clears the robot error.
- <Resume handling>
 - (5) When a resume operation is carried out in the sequencer, the sequencer sets up "Command data" and "Condition data" and sends "Command request ON".
 - (6) When "Command request ON" from OFF is received, the robot imports "Command data" and "Condition data", sets up "Command data" (returned data), sends "Command running ON", and carries out the instructed robot operation.

(5) Suspension when Robot's External Operation Authority Gets Invalid

When the robot's external operation authority gets invalid while performing the sequencer direct (robot's dedicated signal - operation authority output (IOENA) is turned OFF), the operation is suspended. The conditions which make the robot's external operation authority invalid are as follows:

1) The MODE switch is changed from AUTOMATIC to MANUAL on the robot operation panel (robot is turned servo OFF)




2) The sequencer set the robot's operation authority signal (IOENA) to "OFF"

- (1) When the robot's external operation authority gets invalid while performing the sequencer direct, the robot stops, sends "Command running OFF", sets "Completion status" to 30 (suspended), and sends "Command completed ON".
- (2) When the sequencer receives "Command completed ON", the sequencer imports "Completion status" and sends "Command request OFF".
- (3) When the robot receives "Command request OFF", the robot clears "Completion status" and "Command data" to zero and sends "Command completed OFF".

(6) Cancel Based on Command Request OFF Signal

When sequencer's "Command request" is turned OFF while performing the sequencer direct, the robot' operation can be terminated halfway (the robot slows down and stops in the same manner as stop input).



- (1) When the sequencer wants to terminate the robot operation halfway while performing the sequencer direct, the sequencer sends "Command request OFF".
- (2) When the robot receives "Command request OFF", the robot stops, clears "Command data" to zero and sends "Command running OFF".

8.3.3 Sample Ladder for Performing Operation Command

Here, describes a ladder program example which runs an operation command of sequencer direct performance function.

[Target function]

Runs an operation command of sequencer direct performance function (moves to position 1 with joint interpolation (command number: 1))

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Description]

Turn ON the sequencer direct performance trigger (M150) to run an operation command.

Operation result (completion status) is stored in D20.

When the operation is completed, M151 is turned ON. In this case, successful completion turns M152 ON, halfway suspension turns M153 ON, and abnormal completion turns M154 ON.

When M151 is turned ON, turn OFF the sequencer direct performance trigger (M150).

[Device details]

M150: Sequencer direct performance trigger

M151: Sequencer direct performed

M152: Sequencer direct performed successfully

M153: Sequencer direct performed suspendedly

M154: Sequencer direct performed abnormally


D20: Received data from the robot (completion status)

Precautions

To run an operation command, put the sequencer and robot in the state below in advance.

(For more information, refer to Page 71, "8.2.3 Prepare to Perform Sequencer Direct")

- The sequencer has gotten the robot's external operation authority.
- The robot is not in H or L level error state.
- The robot can select a program.
- The robot's servo is turned ON.



8.3.4 Control Robot Hand

Dedicated I/O signals allows you to control a robot hand.

Controls the hand by allocating an I/O signal number for hand control according to the parameters listed in the table below.

The condition to control the robot hand through external signal is "T/B invalid"

(1) Dedicated I/O parameters for hand control

Parameter Name	Category	Name	Function	Signal Level	Factory Default Signal No
HANDENA	Input	Hand control per- mission input	Permits (ON)/ prohibits (OFF) the robot hand control through external signal. Note: The robot can control a hand during automatic oper- ation. For security purposes, make sure to interlock the robot and external equipment such as a sequencer.	Level	-1,
	Output	Hand control per- mission output	Outputs the permission (ON)/ prohibition (OFF) of the robot hand control through external signal. When the hand control permission input signal is turned ON while T/B is invalid, it gets permitted (ON).		-1
HANDOUT	Input	Hand output con- trol signal	Sets up external input signal range for robot hand control. <u>The specified external input signals are mapped in</u> <u>order to the hand signals established by the param-</u> <u>eter HANDTYPE.</u> Note1) Element 1: Start number of hand output control signal Element 2: End number of hand output control signal	Edge	-1,-1

Note1) Hand type

Factory default setting assumes that a hand of double solenoidal type is used. To use a single solenoidal type or to control the hand through general-purpose signals, change the parameter (HANDTYPE) as follows:

Table 8-1: Factory default parameter setting

Parameter Name	Initial value
HANDTYPE	D900, D902, D904, D906, , , ,

The values from left to right corresponds to the hand numbers 1, 2, ... The initial values are as follows:

Hand 1: Accesses the signal numbers 900, 901

Hand 2: Accesses the signal numbers 902, 903

Hand 3: Accesses the signal numbers 904, 905

Hand 4: Accesses the signal numbers 906, 907

<How to set up>

To use double solenoidal type, specify the number by attaching 'D' at the beginning of signal number. For double solenoidal type, the hands 1 - 4 are available.

To use single solenoidal type, specify the number by attaching 'S' at the beginning of signal number.

For single solenoidal type, the hands 1 - 8 are available.

Example:

(1) To allocate two general-purpose signal numbers beginning with #10 to the hands of double solenoidal type:

HANDTYPE=D10, D12, , , , ,

(2) To allocate three general-purpose signal numbers beginning with #10 to the hands of single solenoidal type:

HANDTYPE=S10, S11, S12, , , , ,

(3) To allocate general-purpose signal #10 to the hand 1 of double solenoidal type, #12 to the hand 2 of single solenoidal type:

HANDTYPE=D10, S12, , , , ,

(2) Mapping hand signal with parameter HANDTYPE

When the parameter HANDTYPE setting is changed, robot hand signal corresponding to the hand output control signal may change. The signals allocated to hand signals correspond to the hand output control signals in order.

The tables below list the correspondence to the robot hand output signals, <u>when hand output control signals</u> (<u>HANDOUT</u>) are set to "10080, 10087":

Hand No	1		2		3		4	
Open/Close	Open	Close	Open	Close	Open	Close	Open	Close
Robot hand output sig	900	901	902	903	904	905	906	907
Hand output cont sig	10080	10081	10082	10083	10084	10085	10086	10087

a) Parameter HANDTYPE=D900,D902,D904,D906, , , , (factory defaults):

b) Parameter HANDTYPE=D10,D12, , , , , ;:

Hand No	1		2		3		4	
Open/Close	Open	Close	Open	Close	Open	Close	Open	Close
Robot hand output sig	10	11	12	13	-	-	-	-
Hand output cont sig	10080	10081	10082	10083	-	-	-	-

The areas 10084 - 10087 are not used.

c) Parameter HANDTYPE=S10, , ,S13, , , , :

Hand No	1		2		3		4	
Open/Close	Open	Close	Open	Close	Open	Close	Open	Close
Robot hand output sig	10		-	-	-	-	1	3
Hand output cont sig	10080		-	-	-	-	100	081

The areas 10082 - 10087 are not used.

d) Parameter HANDTYPE=D10,S12, , , , , ,:

Hand No	1		2		3		4	
Open/Close	Open	Close	Open Close		Open	Close	Open	Close
Robot hand output sig	10	11	12		-	-	-	-
Hand output cont sig	10080	10081	10082		-	-	-	-

The areas 10083 - 10087 are not used.

• It also supports hands 5 - 8 of parameter HANDTYPE.

When parameter HANDTYPE=D900, D902, D904, D906, D10, D12, D14, D16,

hand output control signal (HANDOUT) are set to "10080, 10095":

Hand No	1		2		3		4	
Open/Close	Open	Close	Open	Close	Open	Close	Open	Close
Robot hand output sig	900	901	902	903	904	905	906	907
Hand output cont sig	10080	10081	10082	10083	10084	10085	10086	10087

Hand No	5		6		7		8	
Open/Close	Open	Close	Open	Close	Open	Close	Open	Close
Robot hand output sig	10	11	12	13	14	15	16	17
Hand output cont sig	10088	10089	10090	10091	10092	10093	10094	10095


(3) Hand control image

The hand control image is shown below based on the robot parameter setting below (HANDTYPE is factory default):

- HANDENA (hand control permitted) = 10079,10079
- HANDOUT (hand output control signal) = 10080,10087

a) T/B is valid:

T/B controls a robot hand. Hand control through external signals is prohibited.




b) T/B is invalid:

Allows you to select either external signals or controller (robot program or forced output) for the robot hand control according to the hand control permission (HANDENA) signal.

b-1) HANDENA signal is ON:

External signal controls the robot hand.


 \rightarrow Changes the hand output signal by detecting the edge (ON to OFF or OFF to ON) of general-purpose input signal which is allocated to the hand output control signal.



b-2) HANDENA signal is OFF:

Controller (robot program or forced output) controls the robot hand.


 \rightarrow The hand signal control through program command changes hand output signals.



8.3.5 Timing Chart for Robot Hand Control


The figure below shows the hand control timing chart when the robot parameter is set up as follows:

- HANDENA (hand control permitted) = 10079,10079
- HANDOUT (hand output control signal) = 10080,10087
- HNDCNTL1 (hand output signal) = 10048, 10055 (factory defaults)
- HANDTYPE (hand type) = D900, D902, D904, D906, , , , (factory defaults)
- a) Changes of hand control enabled state according to T/B valid/ invalid




- (1) When an external controller (sequencer, etc.) sends "Hand control permission input ON" while the robot is in MANUAL mode and T/B is invalid, the robot sends "Hand control permission output ON" to enable the hand control through external signal (hand output control signal).
- (2) When T/B gets valid, the robot sends "Hand control permission output OFF" to prohibit the hand control through external signal.
- (3) When T/B gets invalid again, the robot sends "Hand control permission output ON" to enable the hand control through external signal.
- (4) When T/B gets valid even while the robot is in MANUAL mode, the robot sends "Hand control permission output OFF" to prohibit the hand control through external signal. (Error "H5000 Teaching" occurs.)

b) Robot hand control through external signal



- (1) An external controller (sequencer, etc.) sends "Hand control permission input ON". When T/B is invalid, the robot sends "Hand control permission output ON" to enable the hand control through external signal (hand output control signal).
- (2) When "Hand control permission output" is ON, the robot hand output signal changes according to the edge (ON to OFF or OFF to ON) of signals which are allocated to the hand output control signal.

c) Robot hand control 1 when T/B gets invalid




- (1) When "Hand control permission output" is ON, the robot hand output signal changes according to the edge (ON to OFF or OFF to ON) of signals which are allocated to the hand output control signal.
- (2) When T/B gets valid, the robot sends "Hand control permission output OFF" to prohibit the hand control through external signal.
- (3) When T/B opens/closes a hand while T/B is valid, the hand output signal changes and the hand operates.
- (4) When T/B gets invalid, the robot sends "Hand control permission output ON" again to enable the hand control through external signal.

In this case, because the edge of "Hand output control signal" is not detected even when "Hand output control signal" is different from "Hand output", "Hand output" does not change.

(5) To operate a hand, change "Hand output control signal". (Refer to the caution below.)

CAUTION When T/B gets enabled halfway and T/B operates a hand, "Hand output control signal" from the sequencer may be different from actual "Hand output". In this case, when "Hand output control signal" from the sequencer is not accorded with actual "Hand output", as described in the timing chart above, single hand operation may not complete the hand operation. d) Robot hand control 2 when T/B gets invalid (recommended)




- (1) When "Hand control permission output" is ON, the robot hand output signal changes according to the edge (ON to OFF or OFF to ON) of signals which are allocated to the hand output control signal.
- (2) When T/B gets valid, the robot sends "Hand control permission output OFF" to prohibit the hand control through external signal.
- (3) When T/B opens/closes a hand while T/B is valid, the hand output signal changes and the hand operates.

When "Hand control permission output" is OFF, external controller (sequencer, etc.) reads "Hand output" signals and always output them as "Hand output control signals," thereby according the hand state with "Hand output control signal".

- (4) When T/B gets invalid, the robot sends "Hand control permission output ON" again to enable the hand control through external signal.
- (5) Even after the robot side controlled a hand, the hand can be controlled with "Hand output control signal" without any restriction.

e) Switch between hand control with external signal and hand control with robot program



- (1) To control the robot hand with external signals, send "Hand control permission input ON". When T/B is invalid, the robot sends "Hand control permission output ON" to enable the hand control through external signal (hand output control signal).
- (2) When "Hand control permission output" is ON, a robot hand can be operated with "Hand output control signal".
- (3) When "Hand control permission output" is ON, the hand will not operate even if a robot program issues a hand control command.
- (4) To control a hand from the robot, send "Hand control permission input OFF". When the robot confirmed that "Hand control permission output" is OFF, the robot sends "Hand control permission output OFF".
- (5) When "Hand control permission output" is OFF, the robot program's hand control command can operate the hand. (T/B operation and forced output from RT ToolBox also can operate the hand). <u>When "Hand control permission output" is OFF, external controller (sequencer, etc.) reads "Hand output" signals and always output them as "Hand output control signals" to accord the hand state with "Hand output control signal". Then, when "Hand control permission output" is turned ON again, the hand can be controlled without any restriction.</u>
- (6) To control the robot hand with external signals again, send "Hand control permission input ON." When T/B is invalid, the robot sends "Hand control permission output ON" to enable the hand control through external signal (hand output control signal).

8.3.6 Sample Ladder for Robot Hand Control

Here, describes a ladder program example which controls a robot hand with robot dedicated signals in the sequencer.

[Target function]

Controls a robot hand (opens/closes hand 1)

[Target robot]

The target robot is robot 2 of multiple CPUs (robot's multiple CPU input offset parameter is initial value)

[Robot parameter setting]

- HANDENA (hand control permitted) = 10079,10079
- HANDOUT (hand output control signal) = 10080,10087
- HNDCNTL1 (hand output signal status) = 10048, 10055 (factory defaults)
- HANDTYPE (hand type) = D900, D902, D904, D906, , , , (factory defaults)

[Description]

When the robot is in AUTOMATIC mode, the sequencer controls a robot hand.

When M160 is turned ON (M161 is turned OFF), hand 1 opens. When M161 is turned ON (M160 is turned OFF), hand 1 closes.

When the robot is in MANUAL mode ("Hand control permission output" is OFF), the sequencer reads "Hand output signal status" and always outputs it as "Hand output control signal", thereby according the hand state with "Hand output control signal" output from the sequencer.


Robot's dedicated output and input signals are batch transferred to B0/ B100 and after respectively.

[Device details]

M160: Hand 1 open trigger M161: Hand 1 close trigger

B14F: Hand control permission input signal B150: Hand output control signal (open hand 1) B151: Hand output control signal (close hand 1)

M4F: Hand control permission output signal B30: Hand output signal status (open hand 1) B31: Hand output signal status (close hand 1)



8.4 Samples

Here, as samples for sequencer direct performance, describes the examples that the robot takes out works. The examples are a robot program which takes out works, a ladder which uses sequencer direct performance command plus hand control function, and an operation setting in the GOT screen.

8.4.1 Robot Program




Fig.8-1:Robot operation

200mm

(7) HClose 1 (Closes hand)
(8) Wait M_In(901)=1 (Wait for close signal)
(9) Dly 0.1 (Waits for 0.1)

8.4.2 Sample Ladder Program

- (1) Condition
 - [CPU configuration]

Sequencer plus one robot

[Sequencer multiple CPUs setting]

The figure below shows the multiple CPU parameter setting of the sequencer:

Multiple CPU settings	
No.of PLC (*) No. of PLC 2 - Host CPU number	Online module change(*) Enable online module change with another PLC. When the online module change is enabled with another PLC, I-O status outside the group cannot be taken.
No specification Operating mode (*)	I/O sharing when using Multiple CPUs (*) Allocates 1K to the sequencer (#1) and robot (#2) respectively All CPUs can read all inputs robot (#2) respectively
Error operation mode at the stop of PLC All station stop by stop error of PLC1 All station stop by stop error of PLC2 All station stop by stop error of PLC2	Multiple CPU high speed transmission area setting Communication area setting (refresh setting)
All station stop by stop error of PLC3 All station stop by stop error of PLC4 -Multiple CPU synchronous startup setting(*)	PLC CPU specific send range(") User setting area Auto refresh point(KV 1/0 No. point Start End point Setting
Target PLC ✓ No.2 ✓ No.3	No.1 1 J3E0 1024 G10000 G11023 0 Setting No.2 1 J3E1 1024 G10000 G11023 0 Setting No.3
₩ 100 ₩ No.4	Set auto refresh setting if it is needed(No setting / Already set) Total 2K points Advanced settings(*) Assignment confirmation The total number of points is up to 14K.
(*)Settings should be set as same when	Import Multiple CPU Parameter Check End Cancel

[Robot parameter setting]

- Selecting shared memory extended function
 - IQMEM: Set both bits 0, 1 to one to enable the sequencer direct performance function
- Robot output signal control
 - HANDENA (hand control permitted): 10079, 10079
 - HANDOUT (hand output control signal): 10080, 10087

Use the robot input signals (10080 - 10087) to control the robot hand output signal (900 - 907) Refer to Table 8-2.

[Robot hand]

Table 8-2:Hand output

Hand No	1		2	2	3		4	
Open/Close	Open	Close	Open	Close	Open	Close	Open	Close
Robot hand output sig	900	901	902	903	904	905	906	907
Hand output control signal	10080	10081	10082	10083	10084	10085	10086	10087

[Allocating robot dedicated I/O signals]

Allocate the signals HANDENA, HANDOUT as well as the dedicated signals allocated in initial setting. To handle the robot dedicated I/O signals in the sequencer, replace the robot dedicated I/O signals with device B.

Parameter Name	Robot Input Signal Name	Robot Output Signal Name	Robot N	lapping	Seque Mappir	
Nume	Name		Input	Output	Output	Input
STOP	Stop input	Pausing output	10000	10000	100	000
RCREADY	-	Controller power ON ready	-	10001	-	001
ATEXTMD	-	Remote mode output	-	10002	-	002
TEACHMD	-	Teaching mode output	-	10003	-	003
ATTOPMD	-	Automatic mode output	-	10004	-	004
IOENA	Operation rights input	Operation rights output	10005	10005	105	005
START	Start input	Operating output	10006	10006	106	006
STOPSTS	-	Stop signal input	-	10007	-	007
SLOTINIT	Program reset input	Program selection enabled out- put	10008	10008	108	008
ERRRESET	Error reset input	Error occurring output	10009	10009	109	009
SRVON	Servo ON input	In servo ON output	10010	10010	10A	00A
SRVOFF	Servo OFF input	Servo ON disable output	10011	10011	10B	00B
CYCLE	Cycle stop input	In cycle stop operation output	10012	10012	10C	00C
SAFEPOS	Safe point return input	In safe point return output	10013	10013	10D	00D
BATERR	-	Battery voltage drop	-	10014	-	00E
OUTRESET	General-purpose out- put signal reset	-	10015	-	10F	-
HLVLERR	-	High level error output	-	10016	-	010
LLVLERR	-	Low level error output	-	10017	-	011
CLVLERR	-	Warning level error output	-	10018	-	012
EMGERR	-	Emergency stop output	-	10019	-	013
PRGSEL	Program selection input	-	10020	-	114	-
OVRDSEL	Override selection input	-	10021	-	115	-
PRGOUT	Program No. output request	Program No. output	10022	10022	116	016
LINEOUT	Line No. output request	Line No. output	10023	10023	117	017
OVRDOUT	Override value request	Override value output	10024	10024	118	018
ERROUT	Error No. output request	Error No. output	10025	10025	119	019
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
IODATA	Numeric value input 0	Numeric value output 0	10032	10032	120	020
1	Numeric value input 1	Numeric value output 1	10033	10033	121	021
1	Numeric value input 2	Numeric value output 2	10034	10034	122	022
1	Numeric value input 3	Numeric value output 3	10035	10035	123	023
1	Numeric value input 4	Numeric value output 4	10036	10036	124	024
1	Numeric value input 5	Numeric value output 5	10037	10037	125	025
1	Numeric value input 6	Numeric value output 6	10038	10038	126	026
1	Numeric value input 7	Numeric value output 7	10039	10039	127	027
1	Numeric value input 8	Numeric value output 8	10040	10040	128	028
1	Numeric value input 9	Numeric value output 9	10041	10041	129	029
1	Numeric value input 10	Numeric value output 10	10042	10042	12A	02A

Parameter Name	Robot Input Signal Name	Robot Output Signal Name	Robot N	Mapping	Sequencer Mapping (B)		
Nume	Nume		Input	Output	Output	Input	
1	Numeric value input 11	Numeric value output 11	10043	10043	12B	02B	
1	Numeric value input 12	Numeric value output 12	10044	10044	12C	02C	
1	Numeric value input 13	Numeric value output 13	10045	10045	12D	02D	
1	Numeric value input 14	Numeric value output 14	10046	10046	12E	02E	
1	Numeric value input 15	Numeric value output 15	10047	10047	12F	02F	
HNDCNTL1	-	Hand output signal state 900	-	10048	-	030	
1	-	Hand output signal state 901	-	10049	-	031	
1	-	Hand output signal state 902	-	10050	-	032	
↑	-	Hand output signal state 903	-	10051	-	033	
1	-	Hand output signal state 904	-	10052	-	034	
↑	-	Hand output signal state 905	-	10053	-	035	
1	-	Hand output signal state 906	-	10054	-	036	
1	-	Hand output signal state 907	-	10055	-	037	
HNDSTS1	-	Hand input signal state 900	-	10056	-	038	
1	-	Hand input signal state 901	-	10057	-	039	
1	-	Hand input signal state 902	-	10058	-	03A	
1	-	Hand input signal state 903	-	10059	-	03B	
1	-	Hand input signal state 904	-	10060	-	03C	
1	-	Hand input signal state 905	-	10061	-	03D	
↑	-	Hand input signal state 906	-	10062	-	03E	
1	-	Hand input signal state 907	-	10063	-	03F	
USRAREA	-	User defined area 1	-	10064	-	040	
1	-	User defined area 2	-	10065	-	041	
1	-	User defined area 3	-	10066	-	042	
1	-	User defined area 4	-	10067	-	043	
1	-	User defined area 5	-	10068	-	044	
1	-	User defined area 6	-	10069	-	045	
1	-	User defined area 7	-	10070	-	046	
1	-	User defined area 8	-	10071	-	047	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
HANDENA	Hand control permis- sion input	Hand control permission output	10079	10079	14F	04F	
HANDOUT	Hand output control 900	-	10080	-	150	-	
1	Hand output control 901	-	10081	-	151	-	
1	Hand output control 902	-	10082	-	152	-	
↑	Hand output control 903	-	10083	-	153	-	
1	Hand output control 904	-	10084	-	154	-	
↑	Hand output control 905	-	10085	-	155	-	
1	Hand output control 906	-	10086	-	156	-	
↑	Hand output control 907	-	10087	-	157	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	
-	-	-	-	-	-	-	

Allocation added with dedicated I/ O parameters HANDENA, HANDOUT


(2) Details


[Sequencer device mapping]


Device	Name	Description
M1	Robot transfer instruction	Turn it ON when carrying out an operation to take out works in the system.
M5	System running	Turn it ON when system is running. Turn it OFF when a suspension or error occurred.
M7	Error reset instruction	When instructing an error reset in the system, turn it ON.
M200 - M209	Work takeout operation	Sets up the flow of work takeout operation.
M240	Sequencer direct practicable condition	Turn it ON, when the sequencer direct is practicable.
M250	Sequencer direct performance trigger	When requesting for sequencer direct performance, turn it ON.
M251	Sequencer direct performed	When the sequencer direct performance is completed, turn it ON.
M252	Sequencer direct performed successfully	When the sequencer direct performance is successfully completed, turn it ON.
M253	Sequencer direct performance sus- pended	When the sequencer direct performance is suspended (paused), turn it ON. →It is necessary to issue this signal to suspend the system.
M254	Sequencer direct performance error exit	When the sequencer direct performance is unavailable, turn it ON. →It is necessary to issue this signal to admit the system error.
D20	Sequencer direct performance comple- tion status	Stores the completion status of sequencer direct performance.
D104-D106	Command data value	Sets up the command data for sequencer direct performance.
D110-D118	Command condition data value	Sets up the command condition data for sequencer direct perfor- mance.
T10	Work takeout position arrival check	A timer to set up the delay time for arrival check after moving to the work takeout position.
T20	Hand close delay timer	A timer to set up the delay time after hand close.


[Description]

- (1) When M1 (transfer instruction) is turned ON, carries out an operation to take out a work. When the operation is completed, Work transfer completed (M209) is turned ON.
- (2) The robot operates only when the System running (M5) is ON.
 - When the sequencer direct performance is suspended (M253 is turned ON) and becomes error (M254 is turned ON), carry out a system control (create it separately) to stop the system and turn OFF System running (M5). When System running (M5) is turned ON due to the resume, the robot operation resumes.
- (3) The robot hand control in the sequencer is carried out only in AUTOMATIC mode.
- (4) When Error reset instruction (M7) is turned ON, the robot error is reset.










8.4.3 Sample Operation Setting in GOT Screen

Realizes a robot operation without user program by entering the robot operation into GOT. Sequencer handling is provided by function block or ladder program. Also GOT screen is provided. (Refer to MELFANS Web.)




- (1) Input robot control commands sequentially in GOT.
 - The input data is stored in the sequencer device table.
- (2) When a robot operation is generated in the system control, the sequencer calls up the device table control by designating the table number.
- (3) As for the device table control, the sequencer reads the setting values for target device table and carries out the control steps (4) (6) in order according to the setting values.
- (4) As for robot movement, the sequencer sends the instruction of sequencer direct performance to the robot based on the values in device table.
- (5) As for hand control, the sequencer sends the dedicated signals for hand control.
- (6) As for inner sequencer processing, the sequencer carries out the sequencer's target operation.
- (7) The robot carries out operations instructed by sequencer direct performance and hand control.

<s for<="" th="" w=""><th>robot o</th><th>peration></th></s>	robot o	peration>
---	---------	-----------


Item	Target	Program to be prepared
Program created by the customer	Sequencer	None
	Robot	None
Function block and screen pro- vided by us	Sequencer	 GOT setting Device table control Inner sequencer processing (waiting for time and signal, signal output, etc.) I/F handling of sequencer direct performance Hand control I/F handling
	GOT	Command edit screen

[GOT screen image (sample)]


In the GOT screen, enter setting values, such as operation command, position, speed, acceleration, to operate the robot based on the specified steps. The figure below shows an example of operation command input screen.



The figure below shows the change of pages when entering an operation command in the GOT screen.



<Operating procedure>



MAIN MENU

Robot#	able#	[Edit	C	omma	and] [▶2	
01	Hand Open	Hand Number	Si	gnal √0FF				
Motion Command	l HOpen	0		0	X	0	0	
02					1			
Motion Command Comman		7	8	9	閉る	0	0	
03		4	5	6	CLR			
Motion Contro Command Comman	el id	1	2	3	DEL	0	0	•
04		0		+/-	Enter			
Motion Command Comman	ol Id	0		0		0	0	
Setting Lin	e Insert)Lin	e Delete	в	ack)			

- Display the numeric keypad by pushing a number display to enter the data necessary for the command.
 - * Necessary data may vary according to the command. Enter the data according to the guidance display at the top of number display.
- 4) Carry out the steps "2)" and "3)" as many as the number of commands to end the editing.

MAIN MENU)					
Robot # 🔳	Table#	[Edit	Comma	and]	▶2	
01	Hand Open	Hand Number	Signal On/OFF			
	trol mand H0pen	1	0	0	0	
02	Joint 1	Dest. Position	Tool Dist [mm]	OVRD [X]	Acc[%]	
	trol Mand	1	-200	0	0	
03	linear 1	Dest. Position	Tool Dist [mm]	OVRD[X]	Acc[X]	
Motion Command Com		1	0	70	50	•
04	Hand Close	Hand Number	Signal On/OFF			
	trol mand HClose	1	1	0	0	
Setting]	ine Insert)Line	e De lete	Back)		

1) Select target robot and table number to display the command edit screen.

 Push the [Action cmd]/[Control cmd] button to display the command select screen and select a command.

8.5 Precautions for Sequencer Direct Performance

8.5.1 Requirements

Sequencer direct performance can be carried out when all conditions below are met:

- (1) Valid operation authority (robot output IOENA is ON)
- (2) No H or L level error (robot signals HLVLERR, LLVLERR are OFF)
- (3) Program is available (robot output SLOTINIT is ON)
- (4) Robot servo is ON (robot output SRVON is ON)
- (5) No stop input (robot output STOPSTS is OFF)
- (6) Not returning to retracting point (robot output SAFEPOS is OFF)
- (7) Remote JOG is not working (robot output JOGENA is OFF)
- (8) Robot's origin has been set up
- (9) Parameter ALWENA is set to zero (refer to Page 113, "8.5.3 Prohibit Program Startup with always Running Program")
- (10) Robot language is set to "MELFA-BASIC V" (parameter RLNG=2) (Refer to Page 113, "8.5.4 Robot Language Setting")

8.5.2 Running together with Program

Even when sequencer direct performance function is valid, the program startup through external signal is possible. However, they cannot run simultaneously. The Table 8-3 lists whether it is possible to run each program simultaneously.

Table 8-3: Possibility to run each program as well as sequencer direct performance

Item	Decision	Description
Start up a program with startup condition START simultaneously	×	START program is unavailable during performing sequencer direct Sequencer direct is unavailable during running START program
Start up a program with startup condition ALWAYS simultaneously	0	Sequencer direct is available during running ALWAYS program
Start up a program with startup condition ERROR simultaneously	Δ	 ERROR program is available during performing sequencer direct Sequencer direct is unavailable during running ERROR program

The robot program and the position edit/variable monitor can the handle position data for sequencer direct performance.

The table below lists the handling of each position:

Positon No	Variable Name Used in Program	Function	Reference as a Command Note1)	Definition as a Command Note2)	Display Variable	Teach/ Edit Variable	Delete Variable
1 - 999	P_DM(1) - P_DM(999)	External program variable	0	×	0	0	×
5000	P_D5000	System state variable	0	×	0	×	×
5100 - 5102	P_D5100 - P_D5102						

Note1) Mov P_DM(1), etc. Note2) Def Pos P DM, etc.

8.5.3 Prohibit Program Startup with always Running Program


When the sequencer direct performance function is valid, ALWENA=0 is assumed regardless of the parameter ALWENA setting (X^{**}, SERVO, RESET ERR commands in the always running program are prohibited). When the controller starts up with parameter ALWENA=1 while the sequencer direct performance function is valid, an **error "L3995 Unavailable together with the function (sequencer direct, ALWENA)"** occurs.

8.5.4 Robot Language Setting

The sequencer direct performance is enabled only when MELFA-BASIC V is selected for robot language (factory default: parameter RLNG=2). When MELFA-BASIC IV is selected (parameter RLNG=1), an **error "L3996 Sequencer direct function unavailable"** occurs on controller startup. This error cannot be reset.

8.5.5 Operation Panel Display

During performing sequencer direct, the program number display changes to "DMODE" in the operation panel (O/P).



It may be possible to select and start a program with O/P during DMODE display

When program name display of STATUS NUMBER is "DMODE", it is impossible to select and start up a program with O/P. However, under conditions below, be aware that it is possible to select and start up a program with O/P even during DMODE display (no program is selected).

• O/P has the operation authority, but the sequencer turned ON "Command request" signal

(In this case, completion status is specified by the robot, and "Command completion" signal is turned ON)

To carry out the sequencer direct performance, make sure to get external operation authority and then turn on the "Command request" signal. Also, turn OFF sequencer side's "Command request" signal just after "Command completion" signal was turned ON.

9 Shared Memory Extended Function Relevant Parameter


Here, describes a parameter relating to shared memory extended function.

When a parameter is changed, make sure to turn on again the robot controller' power supply (OFF to ON) or reset the sequencer. The parameter setting does not become effective only with the parameter change.

9.1 Parameter of Selecting Shared Memory Extended Function

Parameter	Parameter Name	Array Qty Character Qty	Description	Factory Default
Select shared mem- ory extended func- tion	IQMEM	1 digit inte- ger	Set validity (1)/ invalidity (0) for the function. Sets each bit by allocating a function to each bit. 0000000000000000 bit2-15: Not used +- bit0: Use the extended function + bit1: Sequencer direct performance function	000000000000000000000000000000000000000

When sequencer direct performance is valid, external program variables P_DM(1) - P_DM(999) (999 in total) in the robot controller and system state variables P_D5000, P_D5100 - P_D5102 are extended (extended variables are referred to as "extended variable", below).



(1) Variable extension timing

When the controller is started up while the sequencer direct performance function is valid (both bits 0, 1 of parameter IQMEM for selecting shared memory extended function are set to one), external program variables and system state variables are extended.

User defined external variable with the same name is used:

When the user defined external variable with the same name is in use, an **error "L4811 User defined external variable redefinition error"** occurs, but the variables for sequencer direct performance are extended. However, because already created user defined external variable still remains, there are two variables with same name. In this case, because the extended variables for sequencer direct performance is preferred for variable reference, the values of extended variables for sequencer direct performance are displayed in the variable monitor.

When the sequencer direct performance gets invalid, the user defined external variable becomes available as before.

Out of memory:

In case of out of memory, **errors "C7010 Out of memory"**, **"L4800 System based program unavailable"** occur. Here, because the system based program itself is not created, the variables are not extended.

Change of parameter PRGGBL (external variable extension)

When the system starts up while sequencer direct performance function is valid, this parameter PRGGBL is changed to one (valid) even if PRGGBL was set to zero (invalid). The factory default of PRGGBL is one, but when its value was changed by the user, the valid setting of sequencer direct performance changes the value.

(2) Deletion timing of extended variables

When the controller is started up while the sequencer direct performance function is invalid (either bits 0, 1 of parameter IQMEM for selecting shared memory extended function is set to zero), extended external program variables and extended system state variables are deleted. The user available memory space increases.

(3) Add controller program check

When the definition (Def Pos P_DM, etc.) of extended variable is tried to be entered into the controller while sequencer direct performance function is valid, an error "4350 Duplicated variable definition tried" occurs.

(4) Program syntax check

The definition (Def Pos P_DM, etc.) error of extended variable is not checked by syntax check in the RT ToolBox2 (because the syntax check of RT ToolBox2 cannot determine whether the sequencer direct performance function is valid or not). Its error is checked by the controller's program check during transferring the program to the controller.

(5) Treatment when sequencer direct is performed while the variables were not extended

The sequencer direct performance is not received without variable extension.

The completion status is set to the number indicating an impracticable reason (refer to Page 82, "(2) Operation Command Is Impracticable:").

9.2 Function Definition Parameter

Parameter	Parameter Name	Array Qty Character Qty	Description	Factory Default
Define function	IQSPEC	1 digit inte- ger	Set up function for robots. Set each function allocated by each bit. 000000000000000 bit1-15: Not used + bit0: Direction to write into shared memory 0: Reads/writes in order from first to last address (until Ver. N7) 1: Reads in order from first to last address, writes in order from last to first address (communication specification among iQ Platform multiple CPUs)	000000000000000000000000000000000000000

The access sequence of the shared memory before the software version N7 of the robot controller is direction to the final address from the top address for both of reading and writing. However, the sequencer's communication specification among iQ Platform multiple CPUs is direction from last to start address for writing. Thus, when a system is designed according to the shared memory map specification, the interlock of dataset may be impossible. (For more information, refer to the Fig. 9-1.)

Therefore, when utilizing shared memory expanded function, it is necessary to make the shared memory access order the same as the specification of the sequencer. We provide the parameter (IQSPEC) to solve it. The initial value is set to the same specification as the sequencer, so its change by customer is not necessary at all. But, in order to assure the compatibility with previous models, the behavior based on the previous specification is possible.

Prevention of separation of data over 32 bits

When user's free area is used

The program reads in order from start of user's free area. In write command, the transmission data is written in order from last to start address of user's free area.

Consequently, the interlock device at the start of data for communication can prevent separation of data for communication




Fig.9-1:Change the writing order of shared memory data

10 Extended Function Relevant Error List

(1) Error occurred when MELFA-BASIC IV is selected while shared memory extended function is valid

Error No	Error Cause and Measure		
L3994	Error message	Shared memory extended function unavailable (MB4)	
	Cause	Shared memory extended function is unavailable in MELFA-BASIC IV. The parameter RLNG=1 (MELFA-BASIC IV) is selected while shared memory extended function is valid. Make sure to set the parameter RLNG to 2 (MELFA-BASIC V).	
	Measure	Set the parameter RLNG to 2 (MELFA-BASIC V).	

(2) Error occurred when the parameter ALWENA is set to one (enabled) while the sequencer direct performance is valid

Error No	Error Cause and Measure		
L3995	Error message	Unavailable together with the function (sequencer direct, ALWENA)	
	Cause	Unavailable together with the function (sequencer direct, ALWENA) The parameter ALWENA is set to one (enabled) while the sequencer direct performance function is valid. During performing sequencer direct, X** commands are unavailable in the always run- ning program. Make sure to set the parameter ALWENA to zero (disabled).	
	Measure	Set the parameter ALWENA to zero (disabled).	

(3) Error occurred when MELFA-BASIC IV is selected while the sequencer direct performance is valid

Error No	Error Cause and Measure		
L3996	Error message	Sequencer direct function unavailable (MB4)	
	Cause	Sequencer direct function is unavailable in MELFA-BASIC IV. The parameter RLNG=1 (MELFA-BASIC IV) is selected while the sequencer direct perfor- mance function is valid. Make sure to set the parameter RLNG to 2 (MELFA-BASIC V).	
	Measure	Set the parameter RLNG to 2 (MELFA-BASIC V).	

MITSUBISHI ELECTRIC CORPORATION HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 5-1-14, YADA-MINAMI, HIGASHI-KU NAGOYA 461-8670, JAPAN

Authorised representative: MITSUBISHI ELECTRIC EUROPE B.V. GERMANY Gothaer Str. 8, 40880 Ratingen / P.O. Box 1548, 40835 Ratingen, Germany