



This manual is a simple version.
Please contact our Service Network for a detailed
version of User's Manual.

MITSUBISHI Electronic Multi-Measuring Instrument

Types

| | |
|---------------|-------------|
| ME110SSR | ME110SSR-C |
| ME110SSR-4AP | ME110SSR-CH |
| ME110SSR-4APH | ME110SSR-MB |
| ME110SSR-4A2P | |

- Before operating the instrument, you should first read thoroughly this operation manual for safe operation and optimized performance of the product.

Deliver this user's manual to the end user.

Safety precaution

(Always read these instructions before using this equipment)

For personnel and product safety please read the contents of these operating instructions carefully before using.

Please save this manual to make it accessible when required and always forward it to the end user.

CAUTION Indicates that incorrect handling may cause hazardous conditions. Always follow the instructions because they are important to personal safety. Otherwise, it could result in electric shock, fire, erroneous operation, and damage of the instrument.

Normal service conditions

CAUTION

Use the instrument in an environment that meets the Normal service conditions as following points:

- Ambient temperature : -5 to 50°C, average day temperature exceeds 35°C
- Humidity : 30~85%RH, non condensing.
- Altitude : 1000m or less
- Pollution Degree : 2
- Atmosphere without corrosive gas, dust, salt, oil mist.
- A place without excessive shocks or vibration.
- Do not expose to rain and water drips.
- Do not expose to direct sunlight.
- An area in where are no pieces of metal and an inductive substance disperse.
- Do not expose to strong electromagnetic field and ambient noises.

Installation instructions

CAUTION

This instrument should be installed and used by a qualified electrician.

- The instrument must not be powered and used until its definitive assembly on the cabinet's door.
- Verify the following points;
 - Auxiliary power supply and Measuring ratings

| | | |
|------------------------|---|---|
| Auxiliary power supply | 100-240V AC+10-15%(50-60Hz) 10VA 100V DC+40-25% 6W | |
| Ratings | Voltage | 277V AC phase to neutral / 480V AC phase to phase |
| | Current | 5A or 1A (via current transformer) |
| | Frequency | 50/60Hz |

- Current circuits, C1, C2 and C3 are Measurement category I .
- Voltage circuits, P1, P2 and P3 are Measurement category III.
- The instrument is to be mounted on panel. All connections keep inside the cabinet.
- Tighten the terminal screws with the specified torque and use the suitable pressure connectors and suitable wire size.
- When wiring in the instrument, be sure that it is done correctly by checking the instrument 's wiring diagrams.
- Be sure there are no foreign substances such as sawdust or wiring debris inside the instrument.
- Do not drop this instrument from high place. If you drop it and the display is cracked, do not touch the liquid crystal and or get it in your mouth. When touch the liquid crystal, wash it away at once.
- In order to prevent invasion of noise, do not bunch the control wires or communication cables with the main circuit or power wire, or install them close to each other. Keep the distance between communicational signal lines, input signal lines and power lines, high voltage lines are shown below, when run parallel to each other.

| Conditions | Length |
|---------------------------------|--------------|
| Below 600V, or 600A power lines | 30cm or more |
| Other power lines | 60cm or more |

Operation instructions

CAUTION

- When the external terminals are connected to the external equipments, the instrument and the external equipments must not be powered and used until its definitive assembly on the cabinet's door.
- The rating of the terminal of the external equipment should satisfy the rating of the external terminal of this instrument. (See Specifications.)

Maintenance instructions

CAUTION

- Do not touch the terminals while all the circuits connected to this instrument are alive.
- Do not disassemble or modify the instrument.
- Do not contact a chemical dust cloth contact the instrument for a long time, or do not wipe it with benzene, thinner, alcohol.

- Wipe dirt on surface with a soft dry cloth.
- Check the following points,
 - Condition of the appearance
 - Condition of the Display
 - Unusual sound, a smell, and generation of heat
 - Condition of the wiring and the attachment

Storage conditions

- Ambient temperature the : -20 to 60°C, average day temperature exceeds 35°C
- Humidity range 30~85%RH, non condensing.
- Atmosphere without corrosive gas, dust, salt, oil mist.
- A place without excessive shocks or vibration.
- Do not expose to rain and water drips.
- Do not expose to direct sunlight.
- An area in where are pieces of metal and an inductive substance disperse.

Disposal

- When disposing of this product , treat it as industrial waste..
- The battery is not used for this product.

Guarantee

The period of guarantee is for 1 year from the sale date, except in the case that the failure has been caused by bad handling of the product, provided that it has been installed according to the manufacture's instructions.

EMC DIRECTIVE INSTRUCTION

This section summarizes the precautions on conformance to the EMC Directive of the cabinet constructed using this Instrument.

However, the method of conformance to the EMC Directive and the judgment on whether or not the cabinet conforms to the EMC Directive has to be determined finally by the manufacturer.

1. EMC Standards

- EN 61326-1:2006
- EN 61000-3-2:2006/A1:2009/A2:2009
- EN 61000-3-3:2008

1. 2. Installation (EMC directive)

The instrument is to be mounted on panel of a cabinet.

Therefore, the construction of a cabinet is important not only for safety but also for EMC.

The instrument is examined by the following conditions.

- Use a conductive cabinet.
- Six faces of a cabinet have to be ensured conductivity for each other.
- A cabinet has to be connected to earth by a thick wire of low impedance.
- Holes on faces of cabinet have to be 10 cm or less in diameter.
- The terminals for protective earth and functional earth have to be connected to earth by a thick wire of low impedance.

(A terminal for protective earth is important not only for safety but also for EMC.)



Protective earth: Maintains the safety of the instrument and improves the noise resistance.




Functional earth: Improves the noise resistance.

- All connections should be kept inside the cabinet.
- Wirings outside the cabinet have to be used with the shielded cable.

The following diagram shows how to provide good contact of the shielded cable.

- Remove part of the outer cover.
- Remove part of the paint musk on the cabinet.
- Connect those parts with the clamp.



Check on your delivery

Check the following point as soon as you receive Mitsubishi Electronic Multi-Measuring Instrument :


- The package is in good condition.
- The product has not been damaged during transit.
- The product corresponds to your order specifications.
- This product had the following accessories.

| Parts name | Quantity | Specifications |
|-------------------------------|----------|--|
| User's Manual (this document) | 1 | A3 size |
| Attaching nuts | 2 | M5 belleville spring nuts (contained in a bag) |

Mounting


1. Dimensions of the panel

The panel hole dimensions are as shown below. And it can be attached to a panel of thickness 1.6 - 4.5mm.



2. View angle

The contrast of the display changes at view angles.



3. Attachment


When to insert the main body into the panel hole, insert it slowly until the stopper at the bottom of the main body goes into the panel. After insertion, the effect of the stopper prevents the main body from dropping off even when you release your hand from it. Fasten the attachment nut (M5 nut with Belleville spring) with torque about 1.47 - 1.96Nm.

Wiring

Wiring of the terminals have to be fastened according to the following table.

| External diameter | Measurements inputs auxiliary power input terminal | Output terminal | Protective erasing terminal |
|-------------------|---|---|---|
| | M4 screw | M3 screw | M4 screw |
| Terminal | For M4 screw of external diameter below 8.5 | For M3 screw of external diameter below 6.0 | For M4 screw of external diameter below 8.5 |
| Fastening torque | 0.98 - 1.47N.m | 0.5 - 0.6N.m | 1.2 - 1.47N.m |


Do not fasten three wires or more to one terminal. Otherwise, it may generate heat or ignition.



Wiring Diagram


Three phase 4-wire type :

Example of ME110SSR-4AP (with VT)




Three phase 4-wire type :

Example of ME110SSR-4A2P (for direct input)




Three phase 3-wire(3CT) type :

Example of ME110SSR-4APH (with VT)




Three phase 3-wire(2CT) type :

Example of ME110SSR-C (with VT)




Single phase 3-wire type :

Example of ME110SSR-CH



Single phase 2-wire type :

Example of ME110SSR-MB (with VT)




① Auxiliary power supply 100-240 VAC 100 VDC
 ② Fuses gG type(IEC269) or M type rated between 0.5 and 5A
 ※1 For low voltage circuits, grounding of the secondary side of VT and CT is not necessary.
 ※2 Do not connect to NC terminal.
 ※3 (*) shows terminal block No. for 3P3W,1P3W,1P2W

Display and button functions

Functions of operation buttons

The operation button have various functions according to how they are pressed down.



Meaning of code : ○ (press), □ (press over 1 second), ⊙ (press over 2 seconds), — (press simultaneously)

| Operation Mode | Button Name | | | | | | Function | | |
|----------------|--|---|---|-------|---------|-------|----------|--|---|
| | SET | - | + | RESET | Max/Min | PHASE | | DISPLAY | |
| BASIC | | | | | | | ○ | Display changes. | |
| | | | | | | | ○ | Phase changes. | |
| | | | | | ○ | | | Mode changes to the max./min. display and the instantaneous display | |
| | | ○ | ○ | | | | | The item expressed with the bar graph is changed. | |
| | | | | | | | | Harmonics number changes when harmonics displayed. | |
| | | | | | | | | displays change cyclically. | |
| | | | | | | | | phases change cyclically. | |
| | | | | | | | | The counting values of three digits of low rank are displayed. After pressing once again, the display returns. | |
| | | | | | | | | Maximum values and minimum values on the display are reset to the present value. Only available for maximum/minimum value screen | |
| | | | | | | | | All of the Maximum values and minimum values are reset to the present value. | |
| Special | | | | | | | ⊙ | All of the counting values are zero reset. | |
| | | | | | | | ⊙ | the operation time is zero reset (Screen operation time only) | |
| | | | | | | | ○ | An alarm condition is canceled. (Screen element is canceled) | |
| | | | | | | | ⊙ | All alarm conditions are canceled. (Element is canceled for all screens) | |
| | | | | | | | ⊙ | The latching data of digital input on the display is canceled. (Available only for contact point input screen) | |
| | | | | | | | ⊙ | The display of Set value confirmation mode appears. | |
| | | | | | | | ⊙ | The display of Setup mode appears. | |
| | | | | | | | ○ | The set-up items are saved, and set-up item is changed to next item. | |
| | | | | | | | ○ | Back to the previous item. | |
| | | | | | | | ○ | The values of set-up is changed. (If it presses for 1 sec or more fast forward or fast return.) | |
| Mode Switch | | | | | | | ⊙ | Back to the Setup display. | |
| | | | | | | | ⊙ | Returns from infrared mode to operation mode (Available only for infrared mode) | |
| | | | | | | | ⊙ | Back to the Setup display. | |
| | | | | | | | ⊙ | Returns set contents to the default settings (Only effective in CANCEL display) | |
| | Setting mode/Setting value confirmation mode | | | | | | | ○ | The set-up items are saved, and set-up item is changed to next item. |
| | | | | | | | | ○ | Back to the previous item. |
| | | | | | | | | ○ | The values of set-up is changed. (If it presses for 1 sec or more fast forward or fast return.) |
| | | | | | | | | ○ | Back to the Setup display. |
| | | | | | | | | ⊙ | Returns from infrared mode to operation mode (Available only for infrared mode) |
| | | | | | | | | ⊙ | Back to the Setup display. |
| | | | | | | | ⊙ | Returns set contents to the default settings (Only effective in CANCEL display) | |
| | | | | | | | ○ | The set-up items are saved, and set-up item is changed to next item. | |
| | | | | | | | ○ | Back to the previous item. | |
| | | | | | | | ○ | The values of set-up is changed. (If it presses for 1 sec or more fast forward or fast return.) | |


While the back light is off, if the operation key is pressed, the back light is always lit. If the operation button is pressed once again, the function in the above table appears.

Note: When all of the counting values are zero reset the CO2 emission value is also cleared.

CAUTION

- If the function of "maximum value and minimum value reset" and "Wh, varh zero reset" are done, data will be lost. If this data is needed, please record the data before the reset operation.
- If the function of "meter restart" is done, the entire measurement (measurement display, alarm, analog output, pulse) stops.

Display




Note: The above display is an example for explanation.

| No. | Segment Name | Description |
|-----|--|---|
| 1 | LEAD status | Show direction power factor or reactive power on bar graph. |
| 2 | LAG status | Turns on at the additional display of reactive energy. |
| 3 | Scale of the bar graph | Show the scales at the bar graph. |
| 4 | Under scale input | Turns on when measuring values fall below the minimum scale. |
| 5 | Over scale input | Turns on when measuring values exceed the maximum scale. |
| 6 | Alarm indicator | When upper/lower limit alarm set, flickers at the limit setting value. |
| 7 | Index indicator | When set, turns on at the index indicator setting value. |
| 8 | Bar graph status | Shows the item displayed on the bar graph. When the item is the same as a digital displayed item, indicated with "▶", otherwise indicated with "▲". |
| 9 | Digital status | Phase status, "123N", "MAX/MIN", demand etc. displayed. |
| 10 | Digital display | Measured values displayed in digital. |
| 11 | Units | Units of measuring value displayed. |
| 12 | Multiplying factor | Indicates the multiplying factor for calculating energy. |
| 13 | Metering status | Flickers when counting active energy. (Note.1) |
| 14 | Harmonics | Turns on when harmonics displayed. |
| 15 | Setup mode status | Turns on at setting mode. Flickers at setting value confirmation mode. |
| 16 | Test mode status | Turns on at the test mode. |
| 17 | Upper/lower limit alarm status | Flickers when upper/lower limit alarm is generated. |
| 18 | Status display for products with transmission function | Turns on when the instrument equipped with communication function. Flickers at communication error condition. |

Note 1. The blinking cycle is constant regardless of the size of the measured input.

Setting flow



Basic Operations while Executing Settings

| Function | Operation | Remarks |
|--|---------------------------------|--|
| Select a set value | Press (+) or (-) | Fast-forward when pressed over 1 sec. |
| Set-up items are saved | Press (SET) | Set-up item will be saved and shift to the next item. |
| Go back to the previous setting item | Press (DISPLAY) | |
| Skip removing setting items during setting | Press and hold (SET) for 1 sec. | The set value for the setting item just before returning is still available. |

Setting Menu 1: Setting the Phase Wire System, Display Pattern, VT/Direct Voltage, CT Primary Current, and Time constant for Demand

In this setting menu 1, There are setting the basic contents as following for correct measurement .

In the operation mode, after pressing the (SET) and the (RESET) simultaneously for 2 seconds or more, the following operation becomes available.

Setting Menu

① Phase Wire system

② Display Pattern

③ VT / Direct Voltage


④ Primary Current

⑤ Time constant for Active power demand

⑥ Time constant for current demand

Set-up Menu

Set the setting menu number to "1".



Set the phase wire system.

Supplemental Information:
Underlined portions indicate the default values. (Same from here.)

3P4 : Three-phase 4-wire
 2CT 3P3 : Three-phase 3-wire (2CT)
 3CT 3P3 : Three-phase 3-wire (3CT)
 1N2 1P3 : Single-phase 3-wire (1N2)
 1N3 1P3 : Single-phase 3-wire (1N3)
 1P2 : Single-phase 2-wire



Set the display pattern.

The following table shows the measurement elements that can be displayed by each display pattern. (For more details about display patterns, refer to detailed edition.) In addition, if there is no display pattern that you want from P01 to P13 (P14 and P15), select the special display pattern P00 to configure the screen freely. (For more information about setting the special display pattern P00.)

○ : Displayable at this display setting.
 △ : Set at other additional settings.
 □ : Select "P00" and set the display order and display position.

(a) For three-phase 4-wire

| Display Pattern | Current | Active demand current | Phase Voltage | Active Power | Reactive power | Frequency | Active Energy | Reactive Energy | Apparent power (Exported) | Active Energy (Special) | Harmonic current | Harmonic voltage | Operation time | CO2 Emission |
|-----------------|---------|-----------------------|---------------|--------------|----------------|-----------|---------------|-----------------|---------------------------|-------------------------|------------------|------------------|----------------|--------------|
| P01 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P02 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P03 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P04 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P05 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P06 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P07 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P08 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P09 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P10 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P11 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P12 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P13 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P14 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P15 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P00 | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ |

(b) For other phase wire system except three-phase 4-wire

| Display Pattern | Current | Active demand current | Voltage | Active Power | Reactive power | Frequency | Active Energy | Reactive Energy | Apparent power (Exported) | Active Energy (Special) | Harmonic current | Harmonic voltage | Operation time | CO2 Emission |
|-----------------|---------|-----------------------|---------|--------------|----------------|-----------|---------------|-----------------|---------------------------|-------------------------|------------------|------------------|----------------|--------------|
| P01 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P02 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P03 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P04 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P05 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P06 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P07 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P08 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P09 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P10 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P11 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P12 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P13 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P14 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P15 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| P00 | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ |

Note: The following settings are required for displaying elements on an additional screen.

| Measurement element on additional screen | Setting item |
|---|---|
| Active Energy (Exported) / Reactive (Special) | Setting Menu 3 ● Expanded counting |
| Harmonic current / Harmonic voltage | Setting Menu 3 ● Harmonics Display |
| Digital input (DI1 to DI3) | Setting Menu 7 ● Digital input setting |
| Operation time | Setting Menu 8 ● Operation time display |
| CO2 emission | Setting Menu 8 ● CO2 emission display |

Set the "Special Primary Voltage" (Default value: 10,000V)

- From top digit, select the value of the flickering digit by (+) and (-).
- The setting digit can be moved to right by the (SET).
- The setting digit can be moved to left by the (DISPLAY).
- Setting is available in range from 60 to 750000V.
 - Less than 100V : Upper 2 digits setting
 - Over 100V : Upper 3 digits setting
- Error display (E05) appears when set out of 60 to 750000V range. After that, please press (SET), review the setting value and set it once again.
- Press (SET) at the lowest digit, the setting step will shift to the next one.




To ④ CT Primary Current

(2) For direct input (without VT)
Set the direct voltage.

(a) For three-phase 4-wire (phase to neutral voltage / phase to phase voltage)

63.5/110V ↔ 100V/173V ↔ 110V/190V ↔ 220V/380V ↔ 240V/415V ↔ 254V/440V ↔ 277V/480V

(b) When setting for three-phase 3-wire (2CT, 3CT) or single-phase 2-wire
110V ↔ 220V



(a) For Three-phase 4-wire
Set the primary current (Default Setting: 5A)

(b) For other phase wire system except Three-phase 4-wire
Set the primary current of the CT.

| | | | | |
|------|------|-------|-------|-------|
| 1A | 50A | 500A | 1.6kA | 6000A |
| 5A | 60A | 600A | 2000A | 6kA |
| 6A | 75A | 750A | 2kA | 7500A |
| 7.5A | 80A | 800A | 2500A | 7.5kA |
| 8A | 100A | 1000A | 2.5kA | 8000A |
| 10A | 120A | 1kA | 3000A | 8kA |
| 12A | 150A | 1200A | 3kA | 10kA |
| 15A | 200A | 1.2kA | 4000A | 12kA |
| 20A | 250A | 1500A | 4kA | 20kA |
| 25A | 300A | 1.5kA | 5000A | 25kA |
| 30A | 400A | 1600A | 5kA | 30kA |
| 40A | | | | |



Note 1: If there is no primary current in the above that you want to set, select "SP" for special primary current setting.

Setting except "SP": To ⑤ Time constant for active power demand
When setting "SP": To following "Special Primary Current"

Set the "Special Primary Current" (Default value: 5A)

- From top digit, select the value of the flickering digit by (+) and (-).
- The setting digit can be moved to right by the (SET).
- The setting digit can be moved to left by the (DISPLAY).
- Setting is available in range from 1.0A to 30000.0A.
 - Less than 10A : Upper 2 digits setting
 - Over 10A : Upper 3 digits setting
- Error display (E05) appears when set out of 1.0 to 30000.0A range. After that, please press (SET), review the setting value and set it once again.
- Press (SET) at the lowest digit, the setting step will shift to the next one.



To ⑤ Time constant for Active power demand

⑩ Set up the time constant for active power demand.

| | | | | |
|------------|------------|-----------|------------|------------|
| 0 second | 40 seconds | 3 minutes | 7 minutes | 15 minutes |
| 10 seconds | 50 seconds | 4 minutes | 8 minutes | 20 minutes |
| 20 seconds | 1 minute | 5 minutes | 9 minutes | 25 minutes |
| 30 seconds | 2 minutes | 6 minutes | 10 minutes | 30 minutes |



Note) Even when the display pattern not display the active power demand, this screen appears. If the active power demand is not necessary, press the (SET) as it is.

⑪ Set the time constant for current demand.

| | | | | |
|------------|------------|-----------|------------|------------|
| 0 second | 40 seconds | 3 minutes | 7 minutes | 15 minutes |
| 10 seconds | 50 seconds | 4 minutes | 8 minutes | 20 minutes |
| 20 seconds | 1 minute | 5 minutes | 9 minutes | 25 minutes |
| 30 seconds | 2 minutes | 6 minutes | 10 minutes | 30 minutes |



Note) Even when the display pattern not display the current demand, this screen appears. If the current demand is not necessary, press the (SET) as it is.

According to the set-up diagram, save the changed contents, or continue to the other set-up menu.



Note. If the contents in the set-up menu 1 are changed, the maximum value, minimum value, demand value of related measurement items will be reset. (However, active energy and reactive energy will not be reset.)

4


Basic Operation

The following explains basic usages during operation.

● Switch display

By pressing **(DISPLAY)**, the measurement display will switch over.


Display items differ depending on the phase wire system setting, display pattern settings and additional screen.



● Switch phase


By pressing **(PHASE)**, the current phase and the voltage phase will switch over.

The phase cannot be switched in the following cases.
 • Measurement Elements without Phase (Frequency)
 • Active power, reactive power, and power factor for settings other than 3-phase 4-wire
 • When the setting is 1-phase 2-wire
 • The measurement elements for upper, middle, and under are the same



● Bar Graph Display

Bar graph displays the measurement element indicated with "▶" or "◀"



● Selection of bar graph


Press **(+)** or **(-)**, to select measurement elements to be displayed on the bar graph.

As for power factor, voltage, frequency, they can be displayed on the bar graph even if they are not set to display pattern.

The bar graph cannot be displayed in the following cases.
 • When active energy / reactive energy are selected
 • When a line without measurement display is selected
 • Harmonics Display Screen

For 3-phase 4-wire

(Clockwise rotation) (Counterclockwise rotation)



For 3-phase 3-wire, 1-phase 3-wire



For 1-phase 2-wire




● Cyclic Display

In cyclic display, display and phases automatically change at every 5 seconds.

When **(DISPLAY)** is pressed for about 2 seconds, the cyclic display appears.

When **(PHASE)** is pressed for about 2 seconds, the cyclic phase appears.

Note 1: Before shifting to the cyclic display change screen, the display flickering 3 times.
 Note 2: By pressing any other key than the **(SET)** and the **(RESET)** it goes back to manual change.
 Note 3: In the maximum value and the minimum value display, cyclic display is not available.
 Note 4: In the cyclic display, drawing number is not displayed.




● Maximum / Minimum Value Display

For the maximum / minimum value display, the maximum value, current value, and minimum value for each measurement item are displayed on one screen.


However, only the following maximum values are displayed for harmonics.
 Harmonic Current: Total, 1st, 3rd, 5th, 7th, 9th, 11th, and 13th RMS values for where the phase was largest for each phase
 Harmonic Voltage: Total distortion ratio, 1st RMS value, 3rd, 5th, 7th, 9th, 11th, and 13th distortion ratio for where the phase was largest for each phase

■ Example Screen Display



● Display of Maximum/Minimum Value

When **(MAX/MIN)** is pressed, the display is changed into the maximum value and minimum value display.
 When **(MAX/MIN)** is pressed, the display changes back to the present value display.



As with the present value display, it is possible to change the following display from the Maximum value and minimum value display.

| Key Operation | Function |
|--------------------------------------|---|
| Press (DISPLAY) | Measurement items are changed as the following. However, measurement items that are not included in the phase wire system display pattern setting and additional screens are not displayed. $\Delta \rightarrow A_N \rightarrow DA \rightarrow DA_N \rightarrow V \rightarrow W \rightarrow DW \rightarrow var$ $\leftarrow HV \leftarrow H_{1N} \leftarrow HI \leftarrow Hz \leftarrow \cos\phi \leftarrow VA$ |
| Press (PHASE) | 3-phase 4-wire Setting: A and DA are changed as the following Δ Average \rightarrow Phase1 \rightarrow Phase2 \rightarrow Phase3 V is changed as the following $\Delta V_{AVGL-N} \rightarrow V_{1N} \rightarrow V_{2N} \rightarrow V_{3N} \rightarrow V_{AVGL-U} \rightarrow V_{12} \rightarrow V_{23} \rightarrow V_{31}$ W, DW, var, VA, and $\cos\phi$ are changed as the following Δ Total Effective Value \rightarrow 1-Phase \rightarrow 2-Phase \rightarrow 3-Phase A_N , DA_N , and H_z do not have phase change. 3-Phase 3-Wire, 1-Phase 3-Wire Setting: Phases for A, DA, and V are changed. 1-Phase 2-Wire Setting: No phase switching. |
| Press (+) or (-) | The harmonics degree is changed. (Only for harmonics display) |
| Press (DISPLAY) for 2 seconds | Display changes cyclically. |
| Press (PHASE) for 2 seconds | Phase changes cyclically. |


● Reset the Maximum/Minimum Value

When **(RESET)** is pressed for 2 second or more, the displayed maximum value and minimum value can be reset. ("Reset" means that maximum/minimum value turns into the same value as the present value.)
 When **(RESET)** and **(+)** are pressed simultaneously for 2 seconds or more, all the maximum values and minimum values are reset.

● Enlarged 3 digital figures

When **(+)** and **(-)** are pressed simultaneously for 2 seconds, values of active energy and reactive energy are enlarged by 3 figures.
 Use this for confirming the active energy measurement.
 It will automatically return to normal display if no button is pressed for 5 minutes or if it is switched to cyclic display.

[Note 1: This function is made only on active energy and reactive energy displayed.]



● Wh and varh zero reset

When **(SET)**, **(RESET)**, and **(PHASE)** are pressed simultaneously for 2 seconds, the measured values of active energy (Wh) and reactive energy (varh) are reset. (This is effective only in the instantaneous value display.)


[Note 1: All of active energy (Wh) and reactive energy (varh) not displayed are reset too.]

Initializing All Setting Contents

When the following operations are executed, all setting contents return to the factory default settings. Only the setting contents return to the default settings. Adjusted values (Test Mode Menu 2) and electric energy measured values are not changed.


To return all setting contents to the default settings, execute the following operation from the Settings Mode CANCEL screen.

For more information about how to get to the CANCEL screen, refer to Setting Flow (page 3).



If you have any question or technical troubles in using the product, contact Mitsubishi Electric System & Service or your nearest branch of Mitsubishi Electric Corporation. (Refer to the end of this instruction manual for details.)

- The product is under free warranty for one year from purchase or 18 months after production, whichever comes first.
- The charge-free warranty shall apply only if the product is being used properly in the conditions, with the methods and under the environments in accordance with the terms and precautions described in the catalogue and instruction manual, etc.
- Replacement shall be charged for the following cases even during the charge-free warranty period.
 - ① Failures due to improper storage, improper handling, carelessness, or negligence
 - ② Failures due to improper installation
 - ③ Failures due to improper usage and unauthorized modifications
 - ④ Failures due to external factors such as fire, and abnormal voltage, and force majeure such as an earthquake, wind, or flooding.
 - ⑤ Failures due to matters unpredictable based on the level of science technology at the time of shipping.
- Our company shall not be liable to compensate for any loss arising from events not attributable to our company, opportunity loss and lost earnings of the customer due to failure of the product, and loss, secondary loss, accident compensation, damage to other products besides our products and other operations caused by a special reason regardless of our company's ability to foresee it



Specifications

| Item | | Specification | | | | | | |
|--|---|--|---------------|---------|----------------|-------------------------------|------|------|
| Type | | ME110SSR,ME110SSR-4AP,ME110SSR-4APH,ME110SSR-4A2P,ME110SSR-C,ME110SSR-CH,ME110SSR-MB | | | | | | |
| Phase wire system | | Three phase 4-wire(3P4W),Three phase 3-wire(3P3W),Single phase3-wire(1P3W),Single phase 2-wire(1P2W) | | | | | | |
| Rating | Current | 5AAC , 1AAC (1AAC is special-purpose item) | | | | | | |
| | Voltage | 3P4W: max277/480VAC 3P3W,1P2W: 110VAC,220VAC 1P3W, 220VAC (110/220VAC) | | | | | | |
| | Frequency | 50-60Hz | | | | | | |
| Measuring Items and accuracy | | 3P4W | 3P3W,1P3W | 1P2W | Display | Output | | |
| | Current (A) | A1, A2, A3, AN, Aavg | A1, A2, A3 | A1 | 0.5% | 0.5% | | |
| | Current Demand (DA) | DA1, DA2, DA3, DAN, DAavg | DA1, DA2, DA3 | DA1 | | | | |
| | Voltage (V) | V12, V23, V31, Vavg(L-L), V1N, V2N, V3N, Vavg(L-N) | V12, V23, V31 | V12 | | | | |
| | Active Power (W) | ΣW, W1, W2, W3 | ΣW | ΣW | | | | |
| | Active Demand Power (DW) | Σ DW, DW1, DW2, DW3 | ΣDW | ΣDW | | | | |
| | Reactive Power (var) | Σ var, var1, var2, var3 | Σvar | Σvar | | | | |
| | Apparent Power (VA) | ΣVA, VA1, VA2, VA3 | - | - | | | | |
| | Power Factor (cosφ) | Σcosφ, cosφ1, cosφ2, cosφ3 | Σcosφ | Σcosφ | | | 2.0% | 2.0% |
| | Frequency (Hz) | Hz | | | | | 0.5% | 0.5% |
| | Active Energy (Wh) | Import, Export | | | | | 2.0% | 2.0% |
| | Reactive Energy (varh) | Import Capacitive, Import Inductive, Export Capacitive, Export Inductive | | | 2.0% | 2.0% | | |
| | Harmonics Current (HI) | HI1, HI2, HI3, HIN | | HI1,HI3 | HI1 | 2.5% | | |
| | | THD, h1...h13 (without even number) RMS value and Distortion ratio (max.100%) | | | | (Total RMS, 0 to Rated x 60%) | | |
| Harmonics Voltage (HV) | HV1N, HV2N, HV3N | | HV12, HV23 | HV12 | 2.5% | | | |
| | THD, h1...h13 (without even number) RMS value and Distortion ratio (max.20%) | | | | (THD,0 to 20%) | | | |
| Measuring Method | Instantaneous Value | A,V: RMS calculation, W,var,VA,Wh,varh: Digital multiplication, cosφ:Power ratio calculation Hz: Zero-cross, HV,HI: FTT | | | | | | |
| | Demand Value | Thermal type calculation | | | | | | |
| Display | Type | LCD with backlight | | | | | | |
| | Number of display digits | A,DA,V,W,DW,var,VA,cosφ: 4 digits Hz,HI,HV: 3 digits Wh,varh: 6 digits | | | | | | |
| | Bar graph | 21 Segment-Bar graph, 22 Segment-Indicator | | | | | | |
| | Display updating time interval | 0.5s / 1s | | | | | | |
| Response time | Display: 4s or less, Analog output: 4s or less In HI and HV, 10s or less | | | | | | | |
| Analog output (ME110SSR-4AP/-4APH/-4A2P) | Range | 4~20mA DC | | | | | | |
| | Load resistance | 600Ω max | | | | | | |
| Alarm output (ME110SSR-4APH-CH) | No-voltage 'a' contact 35VDC, 0.2A | | | | | | | |
| Pulse output (ME110SSR-4AP/-4APH) | No-voltage 'a' contact 35VDC, 0.1A | | | | | | | |
| Digital input (ME110SSR-CH) | Rated 24VDC(19 to 30VDC) | | | | | | | |
| Power Failure Compensation | Non volatile memory (Items: setting value, max/min value, active/reactive energy) | | | | | | | |
| VA Consumption | VT | 0.1VA/phase, 0.2VA/phase (at direct input) | | | | | | |
| | CT | 0.1VA/phase | | | | | | |
| | Auxiliary power | 8VA at 110VAC, 9VA at 220VAC, 6W at 100VDC | | | | | | |
| | Digital input | DC19-30V, under 7mA | | | | | | |
| Auxiliary power | 100 to 240VAC (+10%,-15%) 50/60Hz 100VDC (+10%,-30%) | | | | | | | |
| Weight | 0.5kg | | | | | | | |
| Dimension | 110(H)x110(W)x98(D) | | | | | | | |
| Enclosure | Thermoplastic self-extinguish (UL94V0) | | | | | | | |
| Operating temperature | -5~50°C (average operating temperature ; 35°C or less per day) | | | | | | | |
| Operating humidity | 85%RHmax, non condensing | | | | | | | |
| Storage temperature | -20~60°C | | | | | | | |
| Standard | EMC:EN61326-1:2006 LVD:EN61010-1/2001 | | | | | | | |

Note1: Accuracy is specified according to the maximum scales value of rated value.
 Note2: Measurement of harmonics which its distortion ratio is exceeded 100% may exceed the accuracy
 Note3: Harmonics cannot be measured without voltage input.

Communication Specifications

ME110SSR-C,ME110SSR-CH

| Item | Specifications |
|--------------------------------------|---|
| CC-Link station type | Remote device station (ver. 1 remote device station or ver. 2 remote device station) |
| Number of occupied stations | Ver. 1 remote device station (ver. 1 compatible slave station) setting:1 station Ver. 2 remote device station (ver. 2 compatible slave station) setting:1 station (Expanded cyclic setting: Octuple) |
| CC-Link version | CC-Link Ver 1.10 / 2.00 |
| Transmission speed | Can select from 156 kbps/ 625 kbps/ 2.5 Mbps/ 5 Mbps/ 10 Mbps |
| Maximum number of connected stations | If the system is configured by only this instrument, up to 42 units can be connected.(note 1) |

note1: As for details, refer to the following manuals.

| Manual Name | Manual Number (Model Code) |
|---|----------------------------|
| CC-Link System Master/Local Module User's Manual type QJ61BT11N Describes the system configuration, performance specifications, functions, handling, wiring and troubleshooting of the QJ61BT11N. (Optionally available) | SH-080394E (13JR64) |

■CC-Link Dedicated Cable

Use the CC-Link dedicated cables for the CC-Link system. If a cable other than the CC-Link dedicated cable is used, the performance of the CC-Link system cannot be guaranteed.

For the specifications of the CC-Link dedicated cables or any other inquiries, visit the following website:

CC-Link Partner Association:<http://www.CC-Link.org/>

REMARK

For details, refer to the CC-Link cable wiring manual issued by CC-Link Partner Association

■ About Programming

In addition to this manual, read the following documents too.

- Electronic multi-Measuring Instrument programming manual (CC-Link) LAN040503
- Electronic multi-Measuring Instrument programming manual (CC-Link) (For ver.2 remote device station)..... LAN110300

ME110SSR-MB

| Item | Specifications |
|-------------------------------|---|
| Interface | RS485, 2 wires half duplex |
| Protocol | ModBus RTU (binary data) |
| Speed | 2400, 4800, 9600, 19200, 38400bps |
| Distance | 1000m |
| address | 1-255 |
| Station number | 31 |
| Resistance at end of the link | 120Ω 1/2W |
| Recommended cables | Shielded twisted pair, AWG26 (or wider) gauge |

As for details of ModBus communication, refer to "Modbus. org.Website" "Modbus. org.Website": <http://www.modbus.org>

Handling precautions

사용자안내문

| 기종별 | 사용자안내문 |
|--------------------|---|
| A급 기기(업무용 방송통신기자재) | 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다. |

Precautionary note written in Korean

(Distributors and users must understand that this product meets the electromagnetic compatibility requirements and is designed for industrial use(Class A).Do not use the product in a residential area.)

note1: This is the notification for the KC mark (Korea Certification)

MITSUBISHI Electronic Multi-Measuring Instrument

Service network

| Country/Region | Company | Address | Telephone |
|----------------|--|---|---------------------|
| Australia | Mitsubishi Electric Australia Pty. Ltd. | 348 Victoria Road, Rydalmere, N.S.W. 2116, Australia | +61-2-9684-7777 |
| China | Mitsubishi Electric Automation (CHINA) Ltd. | 17/F., ChuangXing Financial Center, No.288 West Nanjing Road, Shanghai, 200003 | +86-21-2322-3030 |
| China | Mitsubishi Electric Automation (HongKong) Ltd. | 10/F., Manulife Tower, 169 Electric Road, North Point, Hong Kong | +852-2887-8810 |
| Europe | Mitsubishi Electric Europe B.V. | Gothaer Strasse 8, D-40880 Ratingen, Germany | +49-(0)2102-486-0 |
| Indonesia | P. T. Sahabat Indonesia | P.O.Box 5045 Kawasan Industri Pergudangan, Jakarta, Indonesia | +62-(0)21-6610651-9 |
| Korea | Mitsubishi Electric Automation Korea Co., Ltd | 1480-6, Gayang-Dong, Gangseo-Gu, Seoul, Korea | +82-2-3660-9572 |
| Lebanon | Comptoir d'Electricite Generale-Liban | Cebaco Center - Block A Autostrade Dora, P.O. Box 11-2597 Beirut - Lebanon | +961-1-240445 |
| Philippines | Edison Electric Integrated, Inc. | 24th Fl. Galleria Corporate Center, Edsa Cr. Ortigas Ave., Quezon City Metro Manila, Philippines | +63-(0)2-634-8691 |
| Singapore | Mitsubishi Electric Asia Pte. Ltd. | 307, Alexandra Road, #05-01/02 Mitsubishi Electric Building, Singapore 159943 | +65-6473-2308 |
| South Africa | CBI-electric: low voltage | Private Bag 2016, Isando, 1600, South Africa | +27-(0)11-9282000 |
| Taiwan | Setsuyo Enterprise Co., Ltd | 6th Fl., No.105, Wu Kung 3rd, Wu-Ku Hsiang, Taipei, Taiwan, R.O.C. | +886-(0)2-2298-8889 |
| Thailand | United Trading & Import Co., Ltd. | 77/12 Bamrungmuang Road, Klong Mahanak, Pomprab Bangkok Thailand | +66-223-4220-3 |
| Vietnam | CTY TNHH-TM SA GIANG | 10th Floor, Room 1006-1007, 255 Tran Hung Dao St., Co Giang Ward, Dist 1, Ho Chi Minh City, Vietnam | +84-8-8386727/28/29 |