

Energy Measuring Unit **MODEL**

EMU4-BD1A-MB EMU4-HD1A-MB

User's Manual

 Before operating the instrument, you should first read thoroughly this operation manual for safe operation and optimized performance of the product.
 Deliver this user's manual to the end user.

Safety precautions

Thank you for purchasing the energy measuring unit.

This manual describes mounting method and usage for energy measuring unit EcoMonitorLight (Model: EMU4-BD1A-MB, EMU4-HD1A-MB).

Before using the product, please read this manual carefully to ensure correct use.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference. Make sure to deliver this manual to the end-user.

Disclaimer This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law.

■Related materials

Related material as follows. Read them together as necessary.

Related materials	Ref. No.	Summary
About this product		
Before using the instrument	IB63G63	Provides a concise explanation of how to handle the product. Included with the instrument.
Abou related option units		
B/NET Communication Unit for Energy Measuring Unit User's Manual	IB63792	Describes how to handle the B/NET communication unit of the energy measuring unit.
CC-Link Communication Unit for Energy Measuring Unit User's Manual	IB63791	Describes how to handle the CC-Link communication unit for the energy measuring unit.
CC-Link IE Field Network Basic Communication Unit for Energy Measuring Unit User's Manual	IB63E27	Describes how to use the CC-Link IE Field Network Basic communication unit for the energy measuring unit.
Logging Unit for Energy Measuring Unit User's Manual	IB63780	Describes in detail how to handle the logging unit for the energy measuring unit.
About a sequencer ladder program		
Energy Measuring Unit Programming Manual (B/NET transmission sequencer I/F unit edition)	LAN030518	Describes the communication specifications and message specifications when using B/NET communication.
Energy Measuring Unit Programming Manual (CC-Link edition) for ver.1 remote device station	LEN160305	Describes the communication specifications and message specifications when using CC-Link Ver.1 communication.
Energy Measuring Unit Programming Manual (CC-Link edition) for ver.2 remote device station	LEN130271	Describes the communication specifications and message specifications when using CC-Link Ver.2 communication.
Energy Measuring Unit Programming Manual (CC-Link IE Field Network Basic edition) (SLMP edition)	LEN180123	Describes the communication specifications and message specifications when using CC-Link IE Field Network Basic communication.
Energy Measuring Unit EcoMonitorLight/EcoMonitorPlus Series MODBUS I/F Specification	LSPY-9025	Describes the communication specifications and message specifications when using MODBUS RTU communication.
About construction		
B/NET Design Construction Manual (Transmission edition)	IB63308	Describes how to install and construct B/NET communication equipment.

$\blacksquare Explanation of terms$

This instruction manual uses the following terms.

Terms	Description
СТ	Refers to the current transformer. *"CT" is also included in the model's name and phase wire system of split-type current sensors. Please be careful not to make a mistake.
Current sensor	This is a sensor that senses current. You must use a dedicated current sensor.
VT	Refers to the voltage transformer for instrument.
Three-phase 3-wire system	Refers to both three-phase 3-wire system (2CT) and three-phase 3-wire system (3CT).
Three-phase 3-wire system (2CT)	This is a method to measure the circuit by attaching split type current sensors to the 1st and 3rd phases of the three-phase 3-wire system. Find the 2nd phase current with vector math.
Three-phase 3-wire system (3CT)	This method measures the circuit by attaching a split current sensor to each phase of a three-phase, 3-wire system. Measure the 2nd phase current with a split current sensor.
2 circuit measurement	This is a function that can measure two circuits only when used in a single-phase 2-wire system. Single-phase two-wire system between 1-N and single-phase 2-wire system between 3-N branched from single-phase 3-wire system can be measured. (For details, refer to <u>"9.1.3 2-circuit measurement function"</u> .)
Simple measurement	This function enables simple power measurement without voltage input. Calculates each measurement element using the fixed values (set values) of voltage and power factor and the input current value. (For details, refer to <u>"9.1.4 Simple measurement function"</u> .)
Upper / lower limit alarm	Monitors the upper limit and lower limit of measured values. If the measured value exceeds the upper limit alarm value or falls below the lower limit alarm value, an alarm will be occurred. (For details, refer to <u>"9.3.1 Upper / lower limit alarm function"</u> .)
Waveform band monitoring	When measuring the load current of the equipment that repeats the same operation, the load current of each operations a function to detect equipment abnormalities by monitoring the current waveform by using the same value and waveform. (For details, refer to <u>"9.3.2 Waveform band monitoring"</u> .)
B/NET	Mitsubishi power distribution control network B/NET is an abbreviation for base network, and is a network developed as a field network for our power distribution control equipment.
CC-Link	This is an FA network that uses dedicated cables. Use a linked device to communicate data regularly (cyclic transmission) between the master station and the slave station.
CC-Link IE Field Network Basic	This is an FA network that utilizes general-purpose Ethernet. Use a linked device to communicate data regularly (cyclic transmission) between the master station and the slave station.

Features

[EMU4-BD1A-MB]

- This energy measuring unit can measure various types of electric quantity such as voltage, current, electric power and electric energy.
- MODBUS RTU communication function (built-in) and various types of communication via an optional unit (sold separately) allow measurement data to be transmitted to a superior monitoring system, etc.
- The measurement setting support function automatically determines the setting value (phase wire system, primary voltage) of this unit from the input voltage, contributing to reduction of setting man-hours and prevention of setting errors.
- The simple measurement function enables simple power measurement without voltage input.

[EMU4-HD1A-MB]

- This energy measuring unit can measure various types of electric quantity such as voltage, current, electric power and electric energy.
- MODBUS RTU communication function (built-in) and various types of communication via an optional unit (sold separately) allow measurement data to be transmitted to a superior monitoring system, etc.
- The measurement setting support function automatically determines the setting value (phase wire system, primary voltage) of this unit from the input voltage, contributing to reduction of setting man-hours and prevention of setting errors.
- The simple measurement function enables simple power measurement without voltage input.
- The unit has one external input and one external output, each of which can be switched between pulse input/output and contact input/output. With pulse input set, you can measure the production volume or the utility other than electricity, such as water, gas and air. With contact input set, you can monitor status or alarm and measure the operating time of facilities or the operating power.
- The waveform band monitoring function allows you to monitor the normal/abnormal status of equipment that repeats the same operation.

Table of Content

Safet	Safety precautions1			
Featu	Features			
Table	e of Content	4		
1. P	recautions for Use	6		
1.1	Precautions for Operating Environment and Conditions	6		
1.2	Installation and Wiring Precautions	7		
1.3	Matters concerning the precaution before use	8		
1.4	Precautions for Use	9		
1.5	Precautions for case of failure or abnormality	9		
1.6	Maintenance Precautions	9		
1.7	Storage Precautions	.10		
1.8	Disposal Precautions	.10		
2.	Name and quantity of package contents	. 11		
3.	Option devices	.12		
4.	Name and function of each part	.14		
4.1	Name of each part	.14		
4.2	Functions of LCD.	.17		
_ 4.3	Operation buttons	. 18		
5.	Attaching and removing	. 19		
5.1	Mounting on IEC rail	. 19		
5.2	Mounting on JIS agreement type attachment	. 21		
5.3	Mounting on panel	.22		
6. 1	Wiring	.24		
6.1	Example of wiring for measuring circuit	.25		
6.2	Connection of external input / external external external	.34		
6.3	Connection of external input / external output	.35		
0.4	Connection of MODBOS RTO communication cable	.37		
/. 0	Coefficient of the second seco	.40		
о. о 1	Drecodures for setting	.41		
0.1	Setting many 1. Phase wire system primary voltage, concer type	.42		
0.2	Setting menu 1. Pridse wire system, primary voltage, sensor type,	15		
02	Sotting many 2 · MODBUS PTU communication	.40		
0.J 8 /	Setting menu 3 : External input/output electric energy converted value	.52		
0.4	barmonic operating time atc	Б Л		
85	Setting menu A · Waveform hand monitoring upper / lower limit alarm etc	.54		
8.5	Setting menu 5: Setting related to logging unit	.00		
8.0	Initialization of related items by change of setting	.00		
8.8	Other setting	69		
g 0.0	Operation	74		
9.1	Measurement functions	74		
9.2	Display function(Operating mode)	82		
93	Monitoring function	94		
10	Confirmation mode / Test mode	05		
10	Confirmation mode: Confirmation of setting values in setting menu 1 to 5	105		
10	2 How to use test mode	105		
10	3 Test menu 1. Discrimination support function for improper connection	107		
10.4	4 Test menu 2: Communication test	109		
10	5 Test menu 3: Pulse output test	110		
10	6 Test menu 4: Alarm output test	111		
10	7 Test menu 5: F/W version indication	112		
11.	Requirement for the compliance with EMC Directives	113		
12	Specifications	114		
12.	1 Common specifications	114		

12.2	Specifications of MODBUS RTU communications	.116
12.3	External dimensions	.117
12.4	Specifications of option devices(Split type current sensor)	.121
12.5	External dimensions of option devices	.123
13. Care	e	.126
14. Stor	rage	.126
15. Mai	ntenance	.127
16. Trou	ubleshooting	.128
16.1	In case you think the unit is in failure	.128
16.2 About error number		.129
16.3	Q&A	.130
17. App	pendix: Discrimination support function for improper	.132
connectio	on	.132
Warranty		.142
Trademar	Trademarks of other companies	
About license information for open-source software144		.144

1. Precautions for Use

In this instruction manual, the following safety alert symbols are used in the following meanings.

Symbol	Content
A DANGER	Indicates that incorrect handling occurs hazardous conditions, resulting in death or severe injury.
A WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in Severe injury.
A CAUTION	Indicates that incorrect handling may cause in personal injury.
NOTICE	Indicates that incorrect handling may cause in damage machines.

Even the items listed in "A CAUTION" and "NOTICE" may have serious consequences depending on the situation.

1.1 Precautions for Operating Environment and Conditions

- Do not use this product in the places listed below. Failure to follow the instruction may cause malfunctions and a life decreases of product.
 - · Places the Ambient temperature exceeds the range -5℃ to +55℃.
 - Places the average daily temperature exceeds +35℃
 - \cdot Places the Relative humidity exceeds the range 30% to 85% or places with dewfall.
 - Dirt, corrosive gas(Note), saline and oil smoke exist.
 - (Note) Gas that attacks metals and plastics (Such as sulfur dioxide, ammonia, hydrogen sulfide).
 - \cdot Vibration and impact exceed the specifications.
 - \cdot Places exposed to rain or water drop.
 - Places exposed to direct sunlight.
 - Place exposed to strong induction noises, electric fields, magnetic fields.
 - \cdot Places exposed to large amounts of external noise.
 - Altitude exceeds 2000 m.
 - Places metal fragments or conductive substance are flying.
- Over voltage category of measuring circuit in this unit is CAT III (Note), and that of auxiliary power circuit is overvoltage category III (Note).
- This unit is premised on being used in pollution degree 2 (Note) environment. When used in higher pollution degree, protect this unit from pollution on another device side to be incorporated.
- For notes on when to adapt the equipment that you have configured in this equipment to the EMC Directive, please refer to <u>"11. Requirement for the compliance with EMC Directives</u>".

(Note) For the definition of the pollution degree and the over voltage category, refer to EN 61010-1.

▲ CAUTION	 Any person who is involved should be fully competent to do this work. This unit is the open type device, which are designed to be housed within another device for prevention of electric shock. House this unit within the device such as the control panel before use. (Indoor use) To prevent persons with little knowledge about electric equipment from electric shock, panel must be taken either following measure. Lock the panel so that only those who get an education about electric equipment and have sufficient knowledge can unlock. Shut off power supply automatically by opening the panel. Use a control panel of IP2X or higher to protect against electric shock.
-----------	--

1.2 Installation and Wiring Precautions

A DANGER	Do not touch the live part such as the connection terminal while it is energized. Failure to do so may cause electric shock, a fire, a failure etc.
≜ WARNING	 Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause electric shock, a fire, a failure etc. Check the Wiring Diagram carefully before making any connections. Failure to do so may cause electric shock, a fire, a failure etc. Make sure that the circuit to be connected to this equipment is within the Rating. If used outside the rating, it may cause electric shock, a fire, a failure etc. Strip the wires with proper length. Overlong stripping length may cause short to next wire. Shorter stripping length may cause contact failure. After wiring, confirm whether there is a wiring forgetting or a faulty wiring. Failure to do so may cause electric shock, a fire, a failure etc. Use only wires and solderless terminals that conform to the applicable requirements. Use of inappropriate wires or solderless terminals may cause electric shock, a fire, a malfunction etc. Do not use spade solderless terminals. If the screws become loose, they may fall off, and cause electric shock, a fire, a failure etc. Tighten the crimp terminal after confirming that there is no dirt, foreign matter, plating peeling, deformation, etc. on the contact surface. It may cause overheating or fire. After tightening the screws, be sure to check all the screws tightened. Loose screw may cause electric shock, a fire, a failure etc. Be sure to ground the protective conductor terminal to use. The ground resistance is 100 Ω or less. Be sure to attach the terminal cover after installation and connection. Connect an overcurrent protection device (fuse, circuit breaker, etc.) to the voltage input terminal and auxiliary power supply terminal. Doing so can cause failure or malfunction of the unit. This product make sure to use it in combination with the dedicated current sensor. This product cannot connect with the secondary side (5 A) of current transformer. The dedicated current sensor (E
▲ CAUTION	 Any person who is involved in the installation and the wiring of this unit should be fully competent to do this work. Take care not to entering any foreign objects such as chips and wire pieces into this unit. Failure to do so may cause electric shock, a failure of the unit, a fire etc. In order to prevent short circuits and ground faults caused by falling metal pieces, cover exposed charging parts with taping or insulating tubes. Do not touch the conductive parts or electronic parts of this unit directly. It may cause an electric shock accident, injury, equipment failure or malfunction. Do not pull on the wire while it is connected to this device. It may cause equipment failure or malfunction. Also, if you pull it too hard, it may cause electric shock or fire due to damage to the wire.

	●Do not damage the outer circumference	of the device. If there is damage on the outer
	circumference or terminals, the accurac	y may be lost, and the life may be shortened due
	to the influence of dust, etc. Please har	dle with care.
	•Do not apply a strong impact to the liqu	d crystal display. Doing so may cause damage.
	•When using stranded wire, please use it	after twisting the tip so that the thin wire does
	not come apart.	d The corous may leasen over time
	Tighten the screw within the specified t	orque Under tightening can cause drop short
	circuit or malfunction. Over tightening c	an damage the screw.
	•The wires to be connected to this unit s	hall be placed in a duct or fixed together by
	cramping. If the electric wires are not pl	aced in the duct or cramped together, loosen wires
	or their movement or careless stretch m	ay cause a breakage of the unit or wire or a
	malfunction due to poor contact of elec	tric wires.
	•Lay the cable to be connected to the in	strument indoors. However, some communication
	standards permit outdoor wiring. In that	case, follow the communication standards.
NOTICE	•For protection against noise, all wires sr	f there is concern about the influence of poise
	even if the distance is as follows, we re	commend using a shielded cable
	Condition	Distance
	High-voltage line 600 V or less	300 mm or more
	Other high-voltage line	600 mm or more
	The colit type current concer has a pole	rity (directionality). Be careful about it when
	installing the unit (K: power source side	(directionality). De careful about it when
	•The maximum wire wiring length for the	split type current sensor is as follows. FMU-C***.
	EMU-CT***-A are extendable up to 50 m	. EMU2-CT5, EMU2-CT5-4W are extendable up to
	11 m (using together with the extension	cable).
	Do not ground the secondary side of the	e current sensor.
	Output to two wires can be connected to on	e terminal of the screw terminal block. If three or
	more are connected, the meshing may b	ecome weak and may come off.
	Unly one wire should be connected to o	ne terminal of the spring clamp terminal block. If
	you connect two or more, the engageme	int may become weak and may come off.

1.3 Matters concerning the precaution before use

	Do not touch the live part such as the connection terminal while it is energized. Failure to do so may cause electric shock, a fire, a failure etc.
	Make sure that the circuit to be connected to this equipment is within the rating. If used outside the rating, it may cause electric shock, a fire, a failure etc.
▲ CAUTION	 Any person who is involved should be fully competent to do this work. Check that active bare wire and so on does not exist around the product. If any bare wire exists, stop the operation immediately, and take an appropriate action such as isolation protection. Shut off the external power supply for the unit in all phases before installing and removal. Failure to do so may cause an electric shock or damage of this unit.
NOTICE	 Do not apply a strong impact to the liquid crystal display. Doing so may cause damage. The setting of this unit is necessary before use it. If the setting is wrong, it will not work properly. (Note) For the setting method, refer to "8. Setting method" in this manual. In the event of a power outage during the setting, the unit is not set correctly. Please set again after power recovery. Do not exceed the specified voltage when doing an insulation resistance test and a withstand voltage test.

1.4 Precautions for Use

A DANGER	 Do not disassemble or modify this unit. It may cause electric shock, a fire, a failure, a malfunction etc. Do not touch the live part such as the connection terminal while it is energized. It may cause electric shock, a fire, a failure, a malfunction etc. If the voltage applied to the instrument drops below approximately 40V, the display will disappear, but do not touch the terminals or circuits as voltage may be applied. It may cause electric shock, a fire, a failure, a malfunction etc.
	Make sure that the circuit to be connected to this equipment is within the Rating. If used outside the rating, it may cause electric shock, a fire, a failure etc.
	Check that active bare wire and so on does not exist around the product. If any bare wire exists, stop the operation immediately, and take an appropriate action such as isolation protection.
NOTICE	 Push the switch with an appropriate force. Do not apply a strong impact to the liquid crystal display. Doing so may cause damage.

1.5 Precautions for case of failure or abnormality

If you have any questions or the product is broken down, contact our sales representative near you. For details, refer to the end of this manual.

Please refer to <u>"16.1 Troubleshooting"</u> for information on how to easily identify failures and how to deal with them yourself.

A DANGER	Do not touch the live part such as the connection terminal while it is energized. It may cause electric shock, a fire, a failure, a malfunction etc.
A WARNING	If an abnormal sound, bad-smelling smoke, fever break out from this unit, switch it off promptly and do not use it.

1.6 Maintenance Precautions

Please refer to <u>"15 Maintenance</u>" for the maintenance details.

A DANGER	Do not touch the live part such as the connection terminal while it is energized. It may cause electric shock, a fire, a failure, a malfunction etc.
M WARNING	Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause electric shock, a fire, a failure etc.
CAUTION	Any person who is involved should be fully competent to do this work.

1.7 Storage Precautions

●Please refer to <u>"14. Storage"</u> about storage.

- •For long-time storage, avoid the following places.
 - Places the Ambient temperature exceeds the range -10°C to +60°C.
 - Places the average daily temperature exceeds +35°C.
 - $\cdot\,$ Places the Relative humidity exceeds the range 30% to 85% or places with dewfall.
 - Dirt, corrosive gas (Note), saline and oil smoke exist.
 - (Note) Gas that attacks metals and plastics (Such as sulfur dioxide, ammonia, hydrogen sulfide)
 Vibration and impact exceed the specifications.
 - Places exposed to rain or water drop.
 - Places exposed to direct sunlight.
 - Place exposed to strong induction noises, electric fields, magnetic fields.
 - Places metal fragments or conductive substance are flying.

▲ DANGER	Do not touch the live part such as the connection terminal while it is energized. It may cause electric shock, a fire, a failure, a malfunction etc.
	•Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause electric shock, a fire, a failure etc.

1.8 Disposal Precautions

When disposing of this unit, treat it as industrial waste.

2. Name and quantity of package contents

This following items for this device and included in package. Check that no items are missing.

Item	Quantity	Specifications
Main unit	1	Model EMU4-BD1A-MB
Before using the instrument	1	

3. Option devices

Option devices of this unit are showed below.

(1) Option unit

Product name	Model	Sales unit	with UL	Note
B/NET Communication Unit for Energy Measuring Unit EMU4-CM-B		1	_	You can use B/NET communication by connecting main unit.
CC-Link Communication Unit for Energy Measuring Unit EMU4-CM-C		1	0	You can use CC-Link communication by connecting main unit.
Logging Unit for Energy Measuring Unit	EMU4-LM	1	0	You can log the measured data by connecting main unit.
CC-Link IE Field Network Basic Communication Unit for Energy Measuring Unit	EMU4-CM-CIFB	1	0	You can use CC-Link IE Field Network Basic communication by connecting main unit.

(2) Option

①Option for Energy Measuring Unit

Product name	Model	Sales unit	with UL	Note
Attachment for panel mounting	EMU4-PAT	1	0	This attachment is used when mounting the instrument on the panel.

2 Option for Logging Unit

Product name	Model	Sales unit	with UL	Note
SD Memory Card for Logging Unit	EMU4-SD2GB	1	0	This is an SD memory card used in the logging unit.
Lithium battery for Energy Measuring Unit	EMU4-BT	1	0	By connecting to the logging unit, it will keep timekeeping operation and logging data in case of power failure.。

Option devices

(3) Accessory

①Split type current sensor

Product name	Model	Sales unit	with UL	Note
Split type current sensor	EMU-CT5-A	1	-	
(Connection with general	EMU-CT50-A	1	I	
wire type)	EMU-CT100-A	1	I	
	EMU-CT250-A	1	I	
	EMU-CT400-A	1	0	Connect to this unit for general wire.
	EMU-CT600-A	1	0	
	EMU-CT50	1	0	
	EMU-CT100	1	0	
	EMU-CT250	1	0	
Split type current sensor (Connection with dedicated cable type)	EMU2-CT5	1	0	Connect to this unit for dedicated cable. Single-phase 2-wire, single-phase 3-wire, three-phase 3-wire(2CT) system only.
	EMU2-CT5-4W	1	0	Connect to this unit for dedicated cable. Three-phase 3-wire(3CT), three-phase 4-wire system only.

②Dedicated cable

Using together with Split type current sensor (dedicated cable type).

Product name	Model	Sales unit	with UL	Note
Split type 5A current sensor cable	EMU2-CB-Q5A	1	0	Connect the EMU2-CT5 and the current input terminal of the instrument.
	EMU2-CB-Q5A- 4W	1	0	Connect the EMU2-CT5-4W and the current input terminal of the instrument.
Extension cable	EMU2-CB-T1M	1	0	Used to extend the connection distance
(Standard type)	EMU2-CB-T5M	1	0	between the split type current sensor (cable
	EMU2-CB-T10M	1	0	type) and this instrument.
Extension cable	EMU2-CB-T1MS	1	0	Used to extend the connection distance
(Separate type)	EMU2-CB-T5MS	1	0	between the EMU2-CT5-4W and this
	EMU2-CB-T10MS	1	Ō	instrument.

4. Name and function of each part

4.1 Name of each part

Front view (Model:EMU4-BD1A-MB)



Name of each part	Function
① Voltage input terminals	Connect the voltage input wire for the measuring circuit.
② Protective conductor terminal	Connect to ground (D type ground).
③ Auxiliary power supply terminals	Connect the power supply voltage line for operating the main unit.
④ LCD display	Displays measured values, element information, and operating status (Communication, weighing, settings). Refer to <u>"4.2 Functions of LCD"</u> .
⑤ Operation buttons	Various settings and display switching during operation are performed. Refer to <u>"4.3 Operation buttons"</u> .
© Current input terminals	Connect the secondary output of the dedicated current sensor connected to the measurement circuit's current wire.
⑦ MODBUS RTU communication terminals	Connect the communication wire (MODBUS RTU).

Front view (Model:EMU4-HD1A-MB)



Name of each part	Function
① Voltage input terminals	Connect the voltage input wire for the measuring circuit.
② Protective conductor terminal	Connect to ground (D type ground).
③ Auxiliary power supply terminals	Connect the power supply voltage line for operating the main unit.
④ LCD display	Displays measured values, element information, and operating status (Communication, weighing, settings). Refer to <u>"4.2 Functions of LCD"</u> .
⑤ Operation buttons	Various settings and display switching during operation are performed. Refer to <u>"4.3 Operation buttons"</u> .
© Current input terminals	Connect the secondary output of the dedicated current sensor connected to the measurement circuit's current wire.
⑦ MODBUS RTU communication terminals	Connect the communication wire (MODBUS RTU).
8 External input terminals	Connect pulse / contact input wires.
	Connect pulse / contact output wires.

Back view (Model: EMU4-BD1A-MB, Model: EMU4-HD1A-MB Common regardless of model.)



Name of each part	Function
IEC rail fixture	Fixing the device to the IEC rail.

4.2 Functions of LCD



Indicator	Description			
① Measured value	Display measured values in digital numbers.			
② Measured item	Display measuring elements expressed in digital numbers.			
③ Option unit connection status	Light when connecting optional device.			
④ Energy Measurement	Light when measuring electric energy (incoming). (Light off: Not measuring, Lighting: Measuring)			
⑤ Setting	Indicator SET light up in the setting mode.			
© Measurement circuit number	Represent circuit number. (Note) Two circuits measuring mode only.			

4.3 Operation buttons

Operation buttons have many functions as below. For details, refer to each chapter.

Meaning of symbols:

O(Press), □(Press more than 1 sec.), ©(Press more than 2 sec.), −(Press both at the same time)

Operation Mode			Name of Button	1	Event
		DISP/SET	+/PHASE	-/RESET	Event
		0			Switch the measurement screen.
			0		Switch phase screen.
				0	Switch harmonics order. (In the harmonics screen only)
				O	Clear alarm. (At alarm keeping.)
		O			Enter the confirmation mode.
e		0	O		Enter the setting mode.
ing moc	Contact display			Ø	Clear contact latch. (When the contact input reset status is latched.)
rat	Integrated		©	O	Transition to preset display.
Ope	value display	0		©	Transition to reset display of all data.
	Date		O		Change of date format.
	indication		©	©	Transition to clock setting.
	Band out rate		©	©	Move to the reference waveform generation screen for waveform band monitoring. (When on the Band out rate display screen.)
mode		0			Enter the setting menu.
	Menu display		0 (□)	0 (□)	Moving up or down of menu number. (Move at fast speed when pressing more than 1sec.)
firmation	Setting display	0			Change of setting items. (Forward) Transition to setting menu number. (At final setting item)
e 🗸 Conf			0 (□)	0 (□)	Moving up or down of setting value. (Move at fast speed when pressing more than 1 sec.) (Note)Only effective at setting mode.
ğ					Return to the setting menu.
ting r	END display	0			Memorize changed setting and transition to operating mode.
Set	CANSEL	0			Annul changed setting and transition to operating mode.
	display		©	O	Reset setting values to factory default.

5. Attaching and removing

Mounting means have "on the IEC rail", "on JIS agreement type attachment" and "on the panel".

	 Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause electric shock, a fire, a failure etc. Be sure to attach the terminal cover after installation and connections are completed.
▲ CAUTION	 Any person who is involved should be fully competent to do this work. Take care not to entering any foreign objects such as chips and wire pieces into this unit. Failure to do so may cause electric shock, a failure of the unit, a fire etc. Check that active bare wire and so on does not exist around the product. If any bare wire exists, stop the operation immediately, and take an appropriate action such as isolation protection. Shut off the external power supply for the unit in all phases before installing and removal. Failure to do so may cause an electric shock or damage of this unit.

5.1 Mounting on IEC rail

When showing the display part by cutting the panel face in mounting the IEC rail, cut the panel at where it is more than 50 mm away from the fulcrum of the open/close of the door. (Please refer to <u>"5.3 Mounting on panel"</u> for panel cut dimensions.)

• Applicable IEC rail (35 mm)



Mounting

①Slide the IEC rail fixture to the middle position. (Note.1)





(Note.1) The position of IEC rail fixtures have 3 levels.



• Removing



5.2 Mounting on JIS agreement type attachment

When showing the display part by cutting the panel face in mounting the JIS agreement type attachment, cut the panel at where it is more than 50 mm away from the fulcrum of the open/close of the door. (Please refer to "5.3 Mounting on panel" for panel cut dimensions.)

• JIS agreement type attachment



5.3 Mounting on panel

Panel cut dimensions are made larger than the product considering tolerance in panel cut. If you want to prevent dust and other intrusion the gap of panel cut, cut the panel according to the product to be mounted.

- (1) Only this unit
- Dimensions of hole panel (76 mm × 44.5 mm)



Mounting

Recommended screws: *Cross recessed head screw with captive spring washer and flat washer M3 × 10 2pcs. (Note) Screws are not included.



Unit[mm]

- (2) Measuring unit with optional unit
- Dimensions of hole panel (101 mm × 44.5 mm)



Mounting

Recommended screws:

*Cross recessed head screw with captive spring washer and flat washer M3 × 10 2pcs. (Note) Screws are not included.



Unit[mm]

- (3) When using the measuring unit and the attachment for panel mounting
- Dimensions of hole panel (76 mm × 44.5 mm)



Mounting

*The screws (mounting screws and screws for panel mounting attachment) are supplied with panel mounting attachment. *Please screw up the panel mounting attachment where there are high levels of vibration.



*The screws (mounting screws and screws for

Unit[mm]

Mounting

(4) Measuring unit with optional unit, when using the attachment for panel mounting

- Dimensions of hole panel (101 mm × 44.5 mm)
- panel mounting attachment) are supplied with panel mounting attachment. *Please screw up the panel mounting attachment Outline of the measuring unit where there are high levels of vibration. CL 2+ 04 Mounting screws -⊕ (Unit) 44.5 ŝ CL -43. ഹ 53. ±⊕-Mounting screws 27 ŝ 22. Panel 67 (Unit) (25) (75) 101
 - Outline of the option unit

Unit[mm]

6. Wiring Do not touch the live part such as the connection terminal while it is energized. It may cause \Lambda DANGER electric shock, a fire, a failure, a malfunction etc. •Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause electric shock, a fire, a failure etc. •Check the Wiring Diagram carefully before making any connections. Failure to do so may cause electric shock, a fire, a failure etc. Make sure that the circuit to be connected to this equipment is within the rating. If used outside the rating, it may cause electric shock, a fire, a failure etc. •Use only wires and solderless terminals that conform to the applicable requirements. Use of inappropriate wires or solderless terminals may cause electric shock, a fire, a malfunction etc. •After tightening the screws, be sure to check all the screws tightened. Loose screw may cause electric shock, a fire, a failure etc. •Be sure to ground the protective conductor terminal to use. WARNING The ground resistance is 100 Ω or less. ulletBe sure to attach the terminal cover after installation and connections are completed. •Connect an overcurrent protection device (fuse, circuit breaker, etc.) to the auxiliary power supply terminal. Do not input voltage and current at NC terminals. Doing so can cause failure or malfunction of the unit. •This product make sure to use it in combination with the dedicated current sensor. •This product cannot connect with the secondary side (5 A) of current transformer. ●The dedicated current sensor (EMU-CT***, EMU-CT***-A) is used only for low voltage circuit. If it connects to a high voltage circuit by mistake, it may cause a burnout of the device and a fire. When measuring a high-voltage circuit, connect the EMU2-CT5. EMU2-CT5-4W and EMU-CT5-A to the secondary side (5 A) of the current transformer. •Any person who is involved in the installation and the wiring of this unit should be fully competent to do this work. •Take care not to entering any foreign objects such as chips and wire pieces into this unit. A CAUTION Failure to do so may cause electric shock, a failure of the unit, a fire etc. Check that active bare wire and so on does not exist around the product. If any bare wire exists, stop the operation immediately, and take an appropriate action such as isolation protection. •When using stranded wire, please use it after such as twisting the tip so that the fine wires do not scatter. •Do not plate the wires with solder. The screws may become loose over time. • For protection against noise, all wires shall not be placed close to or bound together with the power lines and high-voltage lines. If there is concern about the influence of noise even if the distance is as follows, we recommend using a shielded cable. Condition Distance High-voltage line 600 V or less 300 mm or more Other high-voltage line 600 mm or more

The setting of this unit is necessary before use it. If the setting is wrong, it will not work properly. (Note) For the setting method, refer to <u>"8. Setting method"</u> in this manual.
In the event of a power outage during the setting, the unit is not set correctly. Please set again after power recovery.
The split type current sensor has a polarity (directionality). Be careful about it when installing the unit. (K: power source side, L: load side)
The maximum wire wiring length for the split type current sensor is as follows. EMU-C***, EMU-CT***-A are extendable up to 50 m. EMU2-CT5, EMU2-CT5-4W are extendable up to

Disclaimer A are extendable up to 50 m. Lino2-C13, Lino2-C13-4W are extendable up to 11 m. (using together with the extension cable)
 Do not ground the secondary side of the current sensor.
 Up to two wires can be connected to one terminal of the screw terminal block. If three or more are connected, the meshing may become weak and may come off.
 Only one wire should be connected to one terminal of the spring clamp terminal block. If you connect two or more, the engagement may become weak and may come off.
 DISCLAIMER
 Connect to ground by using thick wires to decrease impedance.
 For the communication signal line, use an appropriate cable according to each communication method and ground it appropriately. Also, be sure to insulate the shield of the communication signal line with insulating tape or the like.

Example of wiring for measuring circuit 6.1

Example of wiring for this instrument is as follows. (EMU4-HD1A-MB is taken as an example.)

For split type current sensors that can be used, refer to "3. Option devices".

Also, when the simple measurement function is enabled, the circuit voltage is not connected to the instrument. Read this assuming that no circuit voltage is connected to the instrument.



*1: If UL/CE Marking/UKCA Marking compliant, a fuse is required. Below are the recommended fuses. Rated current: 0.5 A. Rated breaking capacity: 250 V AC 1,500 A / 250 V DC 1,500 A (a UL certified product)

*2: The 3 side of the current sensor cable is not used. For disposal of unnecessary cables, refer to "6.1.2 Secondary wiring of split type current sensor".



*1: If UL/CE Marking/UKCA Marking compliant, a fuse is required. Below are the recommended fuses. Rated current: 0.5 A, Rated breaking capacity: 250 V AC 1,500 A / 250 V DC 1,500 A (a UL certified product)

●1P3W/3P3W(2CT)(For low voltage circuit)



●1P3W/3P3W(2CT)(For High voltage circuit)



- *1: If UL/CE Marking/UKCA Marking compliant, a fuse is required. Below are the recommended fuses. Rated current: 0.5 A, Rated breaking capacity: 250 V AC 1,500 A / 250 V DC 1,500 A (a UL certified product)
 - ●3P3W(3CT)(For low voltage circuit)





*1: If UL/CE Marking/UKCA Marking compliant, a fuse is required. Below are the recommended fuses. Rated current: 0.5 A, Rated breaking capacity: 250 V AC 1,500 A / 250 V DC 1,500 A (a UL certified product)

●3P4W(For low voltage circuit)

Power source side Power source side Voltage transfer Fuse *1 Fuse *1 X സ * സ 888 MAMB A 12882 RS-485 (MODBUS RTU) O(Current transfer (***/5A) RS-485 (MODBUS RTU) ſп \bigcirc) External output Current sensor =} External input ſ RS-485(MODBUS RTU) _} External output ➡} External input ΨI Ì Æ đ RS-485(MODBUS RTU) Current sensor Load side Load side

●3P4W(For High voltage circuit)

*1: If UL/CE Marking/UKCA Marking compliant, a fuse is required. Below are the recommended fuses. Rated current: 0.5 A, Rated breaking capacity: 250 V AC 1,500 A / 250 V DC 1,500 A (a UL certified product)

6.1.1 Installation of split type current sensor

Install the current sensor to the cable of the circuit to be measured by the following method.

(1) EMU-CT5/CT50/CT100/CT250-A

■Procedure for wiring of current sensor

- ① Press the locking claw of the moving core, please open the moving core by removing the engagement (Figure 1). Before inserting the cable, check the symbols K and L to fit the current sensor in the correct direction. (The direction from the power supply side to the load side is indicated with → (arrow).) (Figure 3)
- ② After checking that the core parting faces are free from dirt, close the moving core. Push down the moving core until the stoppers are securely locked. (Locking claw of the moving core is applied to the stopper, you hear click.) (Figure 2)
- ③ Pass the tying bands into the current sensor locking holes to secure the sensor with the cable. (Figure 3)
- ④ Cut off the excess length of the bands by nipper or the like.



	●Do not open the r	noving core	more than 90°	. The current se	nsor may be dama	aged.	
	•Electric wire size	•Electric wire size which can be penetrated (reference) should refer to the following table.					
			EMU-CT5-A	EMU-CT50-A	EMU-CT100-A	EMU-CT250-A	
	Usable wires	IV cable	38mm ²	38mm ²	60mm ²	200mm ²	
NOTICE	size (reference)	CV cable	22mm ²	22mm ²	60mm ²	150mm ²	
NOTICE	*Size of electric wires conforms to what is described in the catalog of general PVC insulated wires. Thickness of external PVC insulation is different for different wire. Check with the external dimension diagram of this product and make sure the wire can go through the given space.						

POINT	The current sensor has a polarity (directionality).
	Check the direction of the arrow printed on the side of the current sensor and the direction of
	the primary conductor (power supply side/load side), and be careful not to connect it incorrectly.

■Procedure for connecting of current sensor

① Remove the terminal protective cover on the secondary terminal by lifting the center and connect it to the measurement unit with the appropriate wire/cable.

POINT The current sensor has a polarity (directionality). Check the terminal symbol printed on the secondary side terminal surface of the current sensor and be careful of incorrect connection.
--

(2) EMU-CT400/CT600-A

Procedure for wiring of current sensor

- ① Press the locking claw of the moving core, please open the moving core by removing the engagement (Figure 1). Before inserting the cable, check the symbols K and L to fit the current sensor in the correct direction. (The direction from the power supply side to the load side is indicated with → (arrow).) (Figure 3)
- ② After checking that the core parting faces are free from dirt, close the moving core. Push down the moving core until the stoppers are securely locked. (Locking claw of the moving core is applied to the stopper, you hear click.) (Figure 2)
- ③ Pass the tying bands into the current sensor locking holes to secure the sensor with the cable. (Figure 3)
- ④ Cut off the excess length of the bands by nipper or the like.



	•Do not open the moving core more than 90°. The current sensor may be damaged.				
	Electric wire size w	nich can be pe	inetrated (reference)	should refer to the	
			EMU-CI400-A	EMU-CI600-A	
	Usable wires	IV cable	500mm ²	500mm ²	
	size (reference)	CV cable	400mm ²	400mm ²	
NOTICE	*1 Size of electric wir	es conforms to	o what is described ir	n the catalog of gene	ral PVC insulated
	wires. Thickness o	f external PVC	insulation is differer	nt for different wire.	Check with the
	external dimensior	n diagram of th	is product and make	sure the wire can go	through the given
	space.				
	*2 When conforming	to UL / c-UL st	andards, use AWM wi	res that satisfy the f	ollowing
	three conditions((a), (b), (c)).			
	(a)Working voltage	e (voltage to gi	round)		
	150 Vac or less: /	AWM wire (UL7	58) with a rated voltag	e of 150 Vac or more.	
	150 Vac to 300 Vac: AWM wire with rated voltage of 600 Vac or more and AWG 1 or more (UL758).				
	(b)Wire diameter:	500kcmil(253r	nm^2) or more.		
	(c)Temperature ra	ting:Temperat	ure rating of 105°C o	r higher.	
	•				

	The current sensor has a polarity (directionality).
POINT	Check the direction of the arrow printed on the side of the current sensor and the direction of
	the primary conductor (power supply side/ load side), and be careful not to connect it incorrectly.

■Procedure for connecting of current sensor

① Remove the terminal protective cover on the secondary terminal by lifting the center and connect it to the measurement unit with the appropriate wire/cable.

POINT	The current sensor has a polarity (directionality). Check the terminal symbol printed on the secondary side terminal surface of the current sensor and be careful of incorrect connection.
-------	--

Wiring

(3) EMU-CT50/CT100/CT250

Procedure for wiring of current sensor

- ① Open the moving core as shown in the right figure. Slowly lift the moving core locking claws on both sides of the moving core to open and remove them from the stoppers. Be careful not to force it open and break the claws.
- ② Draw the cable of the circuit to be measured through the center hole of the current sensor. Before drawing the cable through the hole, check the installation direction of the current sensor. There is an arrow indicating K*L.
- ③ To fix the current sensor, draw a and through the locking hole located on both sides of the sensor, and lightly fix them together with the cable.
- ④ Pass the tying band (included with the current sensor) through the current sensor locking hole and fix it to the cable. Be careful not to over-tighten it so that it stops lightly (current sensor locking holes are on both sides of the current sensor).
- ⑤ Cut off the excess length of the bands by nipper or the like.
- ⑥ Lift the center of the protective cover of the secondary terminal and remove it, then connect the specified sensor cable.



	Do not open the mov	ing core more tha	n 90°. The curren	t sensor may be dar	maged.	
	•Electric wire size which can be penetrated (reference) should refer to the following table.					
			EMU-CT50	EMU-CT100	EMU-CT250	
	Usable wires	IV cable	60mm ²	60mm ²	150mm ²	
	size (reference)	CV cable	380mm ²	38mm ²	150mm ² *1	
	*1 100 mm ² is recom	mended				
	*2 Size of electric wi	res conforms to v	vhat is described	in the catalog of ge	eneral PVC insulated	
	wires. Thickness	of external PVC ir	sulation is differe	ent for different wi	re. Check with the	
	external dimension diagram of this product and make sure the wire can go through the given					
NOTICE	space.					
	*3 When conforming	to UL / c-UL stand	dards, use AWM w	rires that satisfy the	e following	
	three conditions((a), (b), (c)).				
	(a) Working voltage (voltage to ground)					
	150 Vac or less:	AWM wire (UL758) with a rated volta	ge of 150 Vac or moi		
	150 Vac to 300	Vac: AWM wire with	n rated voltage of 6	500 Vac or more and	AWG I or more (UL758).	
		each current sens	or			
		(5.201 mm^2)	or more			
	EMU-CT250: AW	IG 3/0 (85 03 mm^	2) or more			
	(c)Temperature rati	ng: Temperature ra	ating of 105°C or hi	igher.		
L						

	The current sensor has a polarity (directionality).
POINT	Check the direction of the arrow printed on the side of the current sensor and the direction of the
	primary conductor (power supply side/load side) and be careful not to connect it incorrectly.

■Procedure for connecting of current sensor

① Remove the terminal protective cover on the secondary terminal by lifting the center and connect it to the measurement unit with the appropriate wire/cable.

DOINT	The current sensor has a polarity (directionality).
POINT	Check the terminal symbol printed on the secondary side terminal surface of the current sensor and
	be careful of incorrect connection.

Wiring

(4) EMU2-CT5/EMU2-CT5-4W

Procedure for wiring of current sensor

- ① Please let me slide a lock pin in the direction of an arrow.
- ② It lets an electric wire pass in a clamp, and close a clamp again.
- ③ Please hold a clamp in the fully close state with a finger, and push in until a lock pin is locked.
- ④ Use the tying band, when fixing the penetrating electric wire and the sensor. A thing W= 2.6mm or less should be used for the tying band used when it fixes the electric wire and sensor to penetrate. When it fixes, a tying band is fixed to one place of the hole for current sensor fixation with a through cable. Be careful not to fasten too much by the grade which stops lightly (a total of four hole)
- ⑤ Cut off the excess length of the bands by nipper or the like.

	A lock pin is metal. Keep in mind that the contact to a charge part has failure of an electric shock accident and equipment and fear of a fire.
NOTICE	 If impossible power is applied where a clamp is opened, there is fear of breakage. Normal measurement cannot be performed if a direction is mistaken. When conforming to UL/c-UL standards, use AWM wires (UL758) with a rated voltage of 150 Vac or higher and AWG22(0.325mm²) and or more and temperature rating of 105°C or higher.

POINT	The current sensor has a polarity (directionality). Check the direction of the arrow printed on the side of the current sensor and the direction of the primary conductor (power supply side/load side), and be careful not to connect it incorrectly.

■Procedure for connecting of current sensor

① Combine the cable connected to the current sensor with the dedicated cable (EMU2-CB-Q5A) and connect it to the measurement unit. For details, refer to <u>"6.1.2 Secondary wiring of split type current sensor"</u>.

	The current sensor has a polarity (directionality).
POINT	Check the terminal symbol on the dedicated cable (EMU2-CB-Q5A/EMU2-CB-Q5A) and be careful not to connect it by mistake.





Binding band

Locking hole



6.1.2 Secondary wiring of split type current sensor

Notes on connection are also described in <u>"1.2 Installation and Wiring Precautions"</u>, so please read them as well.

•The split type current sensor (dedicated cable type) has a sensor cable that do not use with the single-phase 2-wire system.

Please wire according to the following procedure.



- •Split type current sensor (dedicated cable) is extensible in the following ways.
 - (1) When extending EMU2-CT5 with a current sensor extension cable (standard type).
 - 1 Remove the connector.



O Connect the current sensor extension cable.



(2) When extending EMU2-CT5-4W with a current sensor extension cable (standard type) and a current sensor extension (separate type).



 $\ensuremath{\textcircled{O}}$ Connect the current sensor extension cable.



(3) EMU2-CT5, EMU2-CT5-4W are extendable up to 11 m, using together with the extension cable. To extend the wire further, use the current transformer (CT) for split-type instrument in combination, extending the secondary wiring on current transformer (CT) side.

6.2 Terminal Specifications, Applicable wire

Applicable wire, Applicable solderless terminal and tightening torque is below. ●Screw terminal block

Item	Voltage input terminal Auxiliary power supply terminal				
Applicable wire	Stranded wire: AWG26 to 14 (0.13 mm ² to 2.00 mm ²)				
	Single wire: AWG26 to 14 (\$\phi0.41 mm to 1.61 mm)				
Tightening torque	0.8 N·m to 1.0 N·m				
Applicable solderless terminal	For M3.5 screw of external diameter below 5.6 mm				

•Spring clamp terminal block

Item	Current input terminal External input terminal *1 External output terminal *1	MODBUS RTU communication terminal	
Applicable wire *2	Stranded wire: AWG22 to 16 (0.33 mm ² to 1.25 mm ²)	SPEV(SB)-MPC-0.2×3P (Produced by Fujikura Dia Cable) or its equivalent	
	Single wire: AWG22 to 16 (\$\$\phi\$0.13 mm to 2.00 mm)		
Tightening torque	-	_	
Applicable solderless terminal	TGV TC-1.25-11T (by NICHIFU) equivalent	TGV TC-1.25-11T (by NICHIFU) equivalent	

*1 EMU4-HD1A-MB only. EMU4-BD1A-MB not used.

*2 Stripping length of the used wire has to be 8 to 9mm.

6.3 Connection of external input / external output

6.3.1 How to connection

In case using external input and/or external output, refer to the following.

(1) External input

For the case of contact input No-voltage a-contact / open collector

Voltage of the contact is 5 V DC, and current is 7 mA, so use something appropriate for the switching condition.



- (2) External output
 - ■For the case of alarm output and digital output No-voltage a-contact
 - 35 V DC 75 mA or 24 V AC 75 mA (power factor: 1)



Describe the pulse wiring length for each wire diameter. *Polyethylene insulating vinyl sheath cable FCPEV wire.

Wire diameter [mm]	Resistivity[Ω/km]	Wiring length[m]
0.5	94	300
0.65	56.8	400
0.9	29.2	750
1.2	16.5	1000

For notes on when to connect the product, please refer to <u>"1.2 Installation and Wiring Precautions"</u> and <u>"6. Wiring"</u> in this manual. Please refer to <u>"6.2 Terminal Specifications, Applicable wire"</u> in this manual about terminal specifications.

■For the case of pulse input No-voltage a-contact / open collector

Voltage of the contact is 5 V DC, and current is 7 mA, so use something appropriate for the switching condition. Please connect GND side to COMX1 when output of transmitter is open collector pulse.



For the case of pulse output No-voltage a-contact

35 V DC 75 mA or 24 V AC 75 mA (power factor: 1)


6.3.2 How to use for spring clamp terminal block

■Name of each part spring clamp terminal block



(1) Connection of wire

■For stranded wires

- ①Press the push button with a flathead screwdriver at a 90° angle to the surface of the terminal block.
- ②Insert the wire into the insertion hole at a 90° angle to the surface of the terminal block.

①Insert the wire into the insertion hole at a 90° angle to the surface of

③Release the flathead screwdriver from the push button.

For single wire or bar crimp terminals

the terminal block.



Wire 0 90°

POINT	If it is difficult to insert, please insert while pressing the push button in the same way as "For stranded wires".
-------	---

(2) Disconnection of wire

Press the push button with a flathead screwdriver at a 90° angle to the surface of the terminal block.

②Pull out the wire in a 90° direction to the terminal block surface.
 ③Release the flathead screwdriver from the push button.



NOTICE Use a screwdriver with a blade tip thickness of 0.6 mm and a blade width of 3.5 mm.

6.4 Connection of MODBUS RTU communication cable

6.4.1 How to connection



*1 Termination resistances of 120 $\boldsymbol{\Omega}$

Connect the termination resistances (120 $\Omega)$ to both ends of the devices connected the MODBUS transmission line.

NOTICE	If you use a termination resistor other than 120 Ω (master station accessories, etc.), be sure to check the reliability of communication, etc.
--------	---

Refer to <u>"6.4.2 Example of wiring</u>" for a typical wiring example with the master station.

6.4.2 Example of wiring



For notes on when to connect the product, please refer to <u>"1.2 Installation and Wiring Precautions"</u> and <u>"6. Wiring"</u> in this manual.

Please refer to <u>"6.2 Terminal Specifications, Applicable wire</u>" in this manual about terminal specifications. Please refer to <u>"6.3.2 How to use for spring clamp terminal block</u>" in this manual about how to connection for spring clamp terminal block

Wiring



Note: Connect 110 Ω termination resistors on the MODBUS module (QJ71MB91, QJ71C24N) side. For details, refer to [MODBUS Interface Module User's Manual] (Ref. No. SH-080578ENG) and [Q Corresponding Serial Communication Module User's Manual (Basic)] (Ref. No. SH-080006).

Connection with MELSEC iQ-F series programmable controller



Note: Connect 110 Ω termination resistors on the MELSEC iQ-F programmable controller side. For details, refer to [MELSEC iQ-F FX5 User's Manual (MODBUS Communication)] (Ref. No. JY997D56101).



Note: Connect 110 Ω termination resistors on the MELSEC iQ-R programmable controller side. For details, refer to Before Using the Product for RJ71C24, RJ71C24-R2 and RJ71C24-R4 (Ref.NO. BCN-P5999-0075E).

■Connection with GOT (GOT1000, GOT2000)



- Note: Set the termination resistor of the GOT (GOT1000, GOT2000) side to 110 Ω. For details, refer to [GOT1000 Series Connection Manual (Microcomputers, MODBUS Products, Peripherals) for GT Works3] (Ref.NO. SH-080871ENG) and [GOT2000 Series Connection Manual (Microcomputers,
 - MODBUS / Fieldbus Products, Peripherals) for GT Works3 Version1] (Ref.NO. SH-081200ENG).

7. Operating mode

This unit has the operating modes. Switch these modes according to the purposes. The operating mode is displayed immediately after the auxiliary power loading.

Mode	Function	Reference
Operating mode	Display measured value digitally. It can display the condition of contact input (*1) and present time (*2) other than the present value of the measured values.	Chapter 9.2
Setting mode	Make settings related to basic settings (e.g. phase wire system, primary voltage, primary current, sensor type) and alarm monitoring (e.g. waveform band monitoring presence/absence, upper/lower limit alarm presence / absence), etc.	<u>Chapter 8</u>
Confirmation mode (Test mode)	 Mode to confirm the setting value for each setting item. (The setting cannot be changed in this mode, so it can be prevented setting change by human error.) In addition, this unit has the test function that can be used for such as set up of an equipment. Discrimination support display for incorrect wiring: Display useful to discriminate for incorrect wiring such as phase angle display of voltage, current. Pulse, Alarm test: Switch pulse output contact and alarm contact without measurement (voltage and current) input. Communication test: Send back fixed numerical data without measurement (voltage and current) input. F/W version display: Display the F/W version of this unit. 	<u>Chapter 10</u>
Reset mode / Preset mode	Reset: Integrated values (electric energy, operating time, etc.) can be zeroed. Preset: Preset of electric energy and reactive energy.	Chapter 8.8.1

*1: EMU4-HD1-MB only.

*2: Only when connecting logging unit.



A DANGER	Do not touch the live part such as the connection terminal while it is energized. Failure to do so may cause electric shock, a fire, a failure etc.
	If an abnormal sound, bad-smelling smoke, fever break out from this unit, switch it off promptly and do not use it.
NOTICE	 The setting of this unit is necessary before use it. If the setting is wrong, it will not work properly. (Note) For the setting method, refer to <u>"8. Setting method"</u> in this manual. In the event of a power outage during the setting, the unit is not set correctly. Please set again after power recovery.
DISCLAIMER	 Setting menu 5 related to the logging unit is shifted to setting mode from operating mode, and please go in a procedure to set only setting menu 5. (Please refer to <u>"8.6.5 Setting related to logging unit"</u> in this manual.) If you change setting, related setting items and measured data are initialized. Please check them beforehand. (Please refer to <u>"8.7 Initialization of related items by change of setting."</u>)

Procedures for setting 8.1

Set items such as phase wire system, primary voltage, and primary current in the setting mode to measure and monitor. Under normal use, it shall be sufficient to set the setting menu 1 (Basic setting) only. For details, refer to after the following page.

■How to set

①Go into the setting mode by pressing both [DISP/SET] and [+/PHASE] at the same time for 2 seconds. ②Select the setting menu number by pressing [+/PHASE] or [-/RESET].

③Determine the setting menu number by pressing [DISP/SET].

④After all setting are done, select "End" on the setting menu and press [DISP/SET].⑤When prompted for End display, select "End" and press [DISP/SET].

Operations for each setting item

Function	Operation	Supplement
Choose setting value	Press [+/PHASE] or [-/RESET]	Press for more than one second to fast forward.
Confirm setting value	Press [DISP/SET]	After setting value is confirmed, transition to next item.
Go back to setting menu during setting	Press [DISP/SET] for one second	Setting value of the last item before return is effective.





8.2 Setting menu 1 : Phase wire system, primary voltage, sensor type, primary current, demand time, etc.

In this menu, set phase wire system, primary voltage, sensor type, primary current, demand time, etc. In operating mode, press both [DISP/SET] and [+/PHASE] at the same time for more than two seconds to transition to setting mode and enable the following operations.

The underlined values each setting value are the defaults.







	Setting of special primary voltage									
(7) Special primary	 The setting range differs depending on the setting of "(2) Phase wire system". In case of Three-phase 3-wire, Single-phase 2-wire: Setting range: 1 V to 110000 V (Set the upper three digit of the value) Default value: <u>440 V</u> 	Set according to the following conditions according to the phase wire system. •Single-phase 2-wire: Line voltage •Single-phase 3-wire:								
	 In case of Three-phase 4-wire: •Three-phase 3 Setting range: 1 V to 63500 V Line voltage (Set the upper three digit of the value) Three-phase 4 Default value: 254 V Phase voltage Setting operation (Set the value in order from the upper digits (at flashing digits). Press [+/PHASE] or [-/RESET] to choose the value at flashing digit. (2Press [DISP/SET] for the setting digit (flashing digit) to shift to the next (3) Press [DISP/SET] at the lowest digit to transition to "(8) Special secondary voltage". 									
	*The values set the upper fourth digit and lowers to are value flashes three times, transition to "(8) Special set *In case you set the value for out of range, indicate th When indicating the error, press [DISP/SET] to check new value again.	e rounded down. After setting econdary voltage". e error (E005). the setting values and set the								
DISP/SET										
	Set the special secondary voltage of combined VT.									
	Setting range: 1 V to 220 V									
(8) Special secondary	●For Three-phase 3-wire, Single-phase 2-wire:	For Three-phase 4-wire								
	Default value: <u>110 V</u>	Default value: <u>64 V</u>								
	 Setting operation ①Set the value in order from the upper digits(flashing Press [+/PHASE] or [-/RESET] to choose the value at @Press [DISP/SET] for the setting digit (flashing digit. ③Press [DISP/SET] at the lowest digit to transition to 	digits). t flashing digit.) to shift to the next digit. "(9) Sensor type".								
	*In case you set the value for out of range, indicate th When indicating the error, press [DISP/SET] to check new value again.	e error (E005). the setting values and set the								
DISP/SET	-									
	Set the type of combined split type current sensor.									
(9) Sensor type	<u>dirEct</u> ⇔ 5 A									
	 ●You use split type current sensor (connection with g (except for EMU-CT5-A): ⇒ Choose "dirEct" and press [DISP/SET] to transition (Direct sensor)". 	eneral wire type) on to "(10) Primary current								
	 ●You use split type current sensor (connection with d EMU-CT5-A: ⇒ Choose "5 A" [DISP/SET] and press to transition (5 A sensor)". 	edicated cable type) or to "(11) Primary current								
DISP/SET										





(16) Simple measurement (Power factor)	 Set the power factor value in the simple measurement. Setting range: -0.1 to -99.9, 100.0 to 0.0 Default value: 100.0 Setting operation ①Set the blinking part in the order of the sign and the numerical value (the numerical value is from the upper digit). Press [+/PHASE] or [-/RESET] to choose the value at flashing digit. ②Press [DISP/SET] for the setting digit (flashing digit) to shift to the next digit. ③Press [DISP/SET] at the lowest digit to transition to "Setting menu". *In case you set the value for out of range, indicate the error (E005). When indicating the error, press [DISP/SET] to check the setting values and set the new value again. *If "(3) 2 circuits measurement function availability" is set to "yES", set each circuit. Set the first circuit ([1] is displayed at the bottom left of the screen) and the second circuit ([2] is displayed at the bottom left of the screen) in order.
DISP/SET	
Setting menu	Complete the setting or continue in other menu according to procedures for setting.
	For procedures for setting, refer to <u>"8.1 Procedures for setting"</u> .

8.3 Setting menu 2 : MODBUS RTU communication

In this menu, set address, baud rate, parity and stop bit for MODBUS RTU communication.

In operating mode, press both [DISP/SET] and [+/PHASE] at the same time for more than two seconds to transition to setting mode and enable the following operations.

The underlined values each setting value are the defaults.





8.4 Setting menu 3 : External input/output, electric energy converted value, harmonic, operating time, etc.

In this menu, set External input/output, electric energy converted value, harmonic, operating time, etc. In operating mode, press both [DISP/SET] and [+/PHASE] at the same time for more than two seconds to transition to setting mode and enable the following operations.

The underlined values each setting value are the defaults.







DISP/SET







8.5 Setting menu 4 : Waveform band monitoring, upper / lower limit alarm, etc.

In this menu, configure settings related to waveform band monitoring and upper/lower limit alarms. In operating mode, press both [DISP/SET] and [+/PHASE] at the same time for more than two seconds to transition to setting mode and enable the following operations.







	Set the upper / lower Setting range is as fo	limit alarm values. llows:		
	Measurement element	Setting range	Threshold	Unit
	DA upper limit DA(N) upper limit	0% to <u>100</u> %	Primary current ×	А
	DA lower limit	<u>0</u> % to 100%		
	V(L-L) upper limit V(L-N) upper limit	0% to 136% (Default value is <u>110</u>)	Primary voltage ×	V
	V(L-L) lower limit V(L-N) lower limit	<u>0</u> % to 136%	Setting value	V
	DW upper limit	-100% to 0% to <u>100</u> %	Full load power ×	1.1.1
10) Upper / lower limit	DW lower limit	-100% to <u>0</u> % to 100%	Setting value	ĸW
alarm value	PF upper limit	-5% to 100% to 5% (Default value is <u>-50</u>)	Catting value	0/
• •	PF lower limit	-5% to 100% to 5% (Default value is <u>50</u>)	- Setting value	%
	PULSE upper limit	1 to 999999 (Default value is <u>100000</u>)	Setting value	
	UNb.A upper limit	0.01 to 999.99 (Default value is <u>30.00</u>)	Catting walks	0/
DA upper limit)	UNb.V upper limit	0.01 to 999.99 (Default value is <u>3.00</u>)	Setting value	%
	Setting operation ()Set the value in ord Press [+/PHASE] of ()Press [DISP/SET] fo ()Press [DISP/SET] at *In case you set the v When indicating the new value again. *If "(3) 2 circuits mea Set the first circuit (circuit ([2] is display	er from the upper digits(flashi r [-/RESET] to choose the value or the setting digit (flashing dig t the lowest digit to transition value for out of range, indicate error, press [DISP/SET] to che asurement function availability [1] is displayed at the bottom lef yed at the bottom left of the so	ng digits). ue at flashing digit. git) to shift to the next to "(11) Alarm delay tir the error (E005). ck the setting values a " is set to "yES", set ea eft of the screen) and t creen) in order.	t digit. ne". and set t ach circu the seco
DISP/SE	т			





8.6 Setting menu 5: Setting related to logging unit

In this menu, set the logging unit ID or logging data clear.

In operating mode, press both [DISP/SET] and [+/PHASE] at the same time for more than two seconds to transition to setting mode and enable the following operations.





8.7 Initialization of related items by change of setting

The following operation will change the corresponding settings, the accumulated values, maximum values and minimum values to the default values.

■To be	changed	the se	ettina va	alues	and t	he r	eference	waveform.
	chungeu	110 30		aluc J	unu		CICICICC	waveronn.

										C	Cha	nge	ed :	set	tin	g v	alu	е							
							M	enι	J 1						Me	enu	13				Me	enu	4		
		Setting item	Phase wire system	Use or non-use of VT	2 circuits measuring function availability	Primary voltage(Direct)	Primary voltage(With VT)	Special primary voltage	Special secondary voltage	Sensor type	Primary current (Direct sensor)	Primary current(5 A sensor)	Special primary current	Use or non-use of external input	Pulse converted rate	Reset method of contact input	Use or non-use of external output	The object of external output circuit	Use or non-use of waveform band monitoring	Waveform band monitoring element	Sampling cycle	Upper / lower limit alarm monitoring elements	Upper / lower limit alarm value	Upper / lower limit alarm monitoring elements(CH2)	Upper / lower limit alarm value(CH2)
		Use or non-use of VT	\bullet																						
		2 circuits measuring function availability	\bullet															Ш					_		
		Primary voltage(Direct)	•		•													\vdash					_		
	-	Primary voltage(With VI)																\vdash				-			
	nue	Special primary voltage																\vdash	-	\vdash			-+		
	Σ	Special secondary voltage																\vdash	-	\vdash			-+		
		Sensor type	$\overline{\bigcirc}$	-			-	-	-	\bigcirc								Н	\vdash	\vdash		-			
		Primary current(Direct sensor)	$\overline{0}$							\bigcirc								Н	\vdash		$ \square$	-	\rightarrow		-
		Special primary current	$\overline{\bigcirc}$				-		-	$\overline{\bigcirc}$								\vdash	\vdash	\vdash			-		
		Special primary current	\cup	_					-	U							_	Н	+	\vdash	$ \neg$		-	-	
ed	m	Peset method of contact input		-	-		-		-									H	$\overline{\mathbf{L}}$	\vdash	$ \neg$	-	-	_	
bu	חר			-	-		-		-									H	$\overline{\mathbf{L}}$	\vdash	$ \neg$	-	-	_	
cha	٨er	The object of external output circuit		-			-	-	-	-									$\overline{\mathbf{L}}$	\vdash			-		
e	~	Unit amount of pulse output	$\stackrel{\circ}{\circ}$	\cap	0	\cap	\cap	\cap	\cap	\cap	\cap	\cap	\bigcirc						~				\rightarrow		—
0 0		Use or non-use of waveform band monitoring	$\overline{0}$		$\overline{0}$					$\overline{0}$	$\overline{0}$	$\overline{0}$	0	\bigcirc		\cap	0	\cap					-	_	
e		Waveform band monitoring element	Õ		Õ					0	Õ	\overline{O}	0	Ŭ		~	~	Ĭ							
alu		Sampling cycle	Õ		Õ					0	Õ	\overline{O}	0							\bigcirc					
×		Band width factor	Õ		Õ					0	Õ	\overline{O}	0							Õ	0				
Ei Di		Standard deviation lower limit	Õ		Õ					Õ	Õ	Õ	Õ							Õ	Õ				
et	_	Waveform band monitoring value	Õ		Õ					Õ	Õ	Õ	Õ							Õ	Ō			_	
N I	n 4	Use or non-use of upper / lower limit alarm	Õ	0	Õ	0	0	0		Õ	Õ	Õ	Õ					0	0					_	
	len	Upper / lower limit alarm monitoring elements	0	0	0	0	0	0		0	0	0	0					0							_
	≥	Upper / lower limit alarm value	0	0	Ο	Ο	0	Ο		Ο	Ο	Ο	0					Ο				0			
		Multiplication factor of monitor value	Ο	Ο	Ο	Ο	Ο	Ο		Ο	Ο	Ο	Ο					Ο				Ο	Ο		
		Use or non-use of upper / lower limit alarm(CH2)	0	0	Ο	Ο	Ο	Ο		Ο	Ο	Ο	0					Ο	Ο						
		Upper / lower limit alarm monitoring elements(CH2)	0	0	0	Ο	Ο	Ο		Ο	Ο	Ο	0					Ο							
		Upper / lower limit alarm value(CH2)	0	0	0	Ο	0	Ο		Ο	Ο	0	Ο					Ο						0	
		Multiplication factor of monitor value(CH2)	Ο	Ο	Ο	Ο	Ο	Ο		Ο	Ο	Ο	Ο					Ο						Ο	0
	Sta	ndard waveform	0		0					Ο	Ο	Ο	Ο							Ο	Ο				
	Sta	ndard deviation	0		0					0	0	0	0					Щ		0	0		\rightarrow		
	Nun	nber of standard waveform data	0		0					0	0	0	Ο							Ο	\cup				
sym	nbol			Det	ail	s																			
()) It will be changed to the initial value.																							
	It will be changed to the initial value corresponding to the phase and wire system.																								
		When "pulse conversion value upper limit" is set in the limit alarm monitoring element [2]", and "Use or non-u	e "l Ise	Jpr of	er/ ext	/lov :err	ver nal	r lin inp	nit out	ala " is	rm ch	mo ang	nit jed	orin fro	ng (om	ele "p	me uls	nt" e ir	or Ipu	"Uı ıt" 1	ppe to '	er/l 'co	ow nta	er	
L		input", it will be changed to the initial value.																							
4	•	If the upper/lower limit alarm monitoring element is so	et t	0"	pul	se	co	nve	ersi	on	val	ue	up	ber	lin	nit"	, it	wi	<u>ll b</u>	e c	:ha	nge	ed t	to t	he
		when the waveform band monitoring is changed from	No No	on-	use	e t	0″	USE	е",	cha	ang	le t	ne	set	tin	Igs	as	tol	IOM	/S.					
		•Change "Reset method of contact input" to "Auto-re	501	." "	л.																				
'		•Change "Use or non-use of external output" to "alan	ສອເ m ດ	utr	out	".																			
		•Change "The object of external output circuit" to "1"	,	• r																					

 $(\overline{CH2})$ is the setting for the second circuit.

This can be set when the 2-circuits measurement function is enabled.

Settings and measurement items with nothing written on them represent the setting items for the first circuit.

■To be changed the accumulated values, maximum values and minimum values.

		Changed setting value																																
			Menu 1 Menu 3 Menu 4														4																	
Setting item			Phase wire system	Use or non-use of VT	2 circuits measuring function availability	Primary voltage(Direct)	Primary voltage(with VT)	Primary special voltage	Secondary special voltage	Sensor type	Primary current(Direct)	Primary current(5A sensor)	Primary special current	Current demand time	Current demand time(CH2)	Power demand time	Power demand time(CH2)	Use or non-use of external input	Reset method of contact input	Use or non-use of external output	The object of external output circuit	Counting method of operating time	Counting method of operating time(CH2)	Use or non-use of waveform band monitoring	Waveform band monitoring element	Sampling cycle	Use or non-use of upper / lower limit alarm	Upper / lower limit alarm monitoring elements	Upper / lower limit alarm value	Alarm delay time	Use or non-use of upper $/$ lower limit alarm(CH2)	Upper $/$ lower limit alarm monitoring elements(CH2)	Upper / lower limit alarm value(CH2)	Alarm delay time(CH2)
		Periodic electric energy																0																
	s	Pulse count value																0																
	alue	Pulse converted value																0																
	∧ b∈	Operating time																				0									\square			
	Dperating time(CH2)																						0								$ \square $			
	nm	Alarm cumulative time	0	0	0	0	0	0	0	0	0	0	0											0			0	0	0	0	\square			
	Acc	Alarm cumulative time(CH2)	0	0	0	0	0	0	0	0	0	0	0											0							0	0	0	0
	`	Band alarm count	0		0					0	0	0						0	0	0	0			0	0	0					\vdash			-
		Band cycle count	0		0					0	0	0						0	0	0	0			0	0	0					\square			
÷		Line voltage	0	0	0	0	0	0	0																						\vdash			
efau		Line voltage(CH2)	0	0	0	0	0	0	0																					⊢	\vdash			
e q		Phase voltage	0	0	0	0	0	0	0	_	_																			⊢	⊢			
e th	nes	Power factor	0	0	0	0	0	0	0	0	0	0	0																	\vdash	⊢			
d o	val	Power factor(CH2)	0	0	0	0	0	0	0	0	0	0	0	_																\vdash	⊢			
ue t	mn	Current demand time	0		0					0	0	0	0	Ο	_															⊢	⊢			
val	axin	Current demand time(CH2)	0		0				_	0	0	0	0		0	_															\vdash			
Ired	Ř	Power demand time	0	0	0	0	0	0	0	0	0	0	0			0											\vdash			┝──┥	⊢			
asu		Power demand time(CH2)	0	0	0	0	0	0	0	0	0	0	0				0										\vdash			┝──┥	⊢			
ž		Current unbalance rate	0		0				_	0	0	0	0														\vdash			\vdash	\vdash			
		Voltage unbalance rate	0	0	0	0	0	0	0																					⊢	\vdash			
		Line voltage	0	0	0	0	0	0	0																		\vdash			┝──┥	⊢			
	ŝ	Line voltage(CH2)	0	0	0	0	0	0	0																					\vdash	⊢			
	lue	Phase voltage	0	0	0	0	0	0	0	((⊢	⊢			$ \square$
	r va	Power factor	0	0	0	0	0	Ö	0	0	0	Ö	Ö																	┢──┤				
	nun	Power factor(CH2)	00	0		0	0	0	0	00	00	0	0																	┢──┤	\square			
	Ainir	Current demand time	0							00	00			0								_								⊢	\square		_	
	~						0		0		00	0	0		-					-		_		-	-	\vdash	\square		\vdash	\vdash	\dashv	\dashv		
		Power demand time(CH2)	0	R	0	0	0	0	0	0		0	0				\cap		_	_				_										
sym	nbol Details																																	
C	O It will be initialized (changed to default value).																																	

(CH2) is the setting for the second circuit.

This can be set when the 2-circuit measurement function is enabled.

Settings and measurement items with nothing written on them represent the setting items for the first circuit.

■Initialize all settings.

Enter CANCEL display in setting mode and press both [DISP/SET] and [+/PHASE] at the same time for more than two seconds to initialize all settings. (For entering CANCEL display, refer to <u>"8.1 Procedures for setting"</u>.)

Settings are only initialized. Integrated values (such as electric energy, reactive energy, and operating time) are not changed.

However, if the counting method of operating time is contact input, the operating time will be cleared.

8.8 Other setting

Explain the setting operation other than the setting mode.

8.8.1 Preset and all data reset (Reset/Preset mode)

It is possible to zero clear or preset the integrated value of each measured value (electric energy, operating time, etc.).

■Preset

Preset the following measurement items (integrated values).

Electric energy (incoming), Reactive energy, Electric energy (transmission), periodic electric energy, Electric energy converted value, Pulse converted value, Operation time



■All data reset

Zero clear the follow	ving measurement items (integrated value, maximum value, minimum value).
Integrated value	Electric energy (incoming), Reactive energy, Electric energy (transmission), Periodic electric energy, Electric energy converted value, Pulse count value, Pulse converted value, Operation time, Alarm cumulative time, Band alarm count, Band cycle count
Maximum value	Current demand, Voltage, Electric power demand, Power factor, Current unbalance rate, Voltage unbalance rate
Minimum value	Current demand, Voltage, Electric power demand, Power factor



8.8.2 Clock setting and logging data clear

When connecting logging unit, you can set the clock of it.

On the date indication in operating mode, press both [+/PHASE] and [-/RESET] at the same time for more than two seconds to transition to clock setting and enable the following operations.

*The date is not indicated in operating mode when the logging unit is not connected.


Setting method



8.8.3 Change of date format

In date format setting, you can choose from "YY.MM.DD", "MM.DD.YY" or "DD.MM.YY" format. On the date indication in operating mode, press [+/PHASE] for more than two seconds to transition to date format setting and enable the following operations.

*The date is not indicated in operating mode when the logging unit is not connected.



9. Operation

▲ DANGER	Do not touch the live part such as the connection terminal while it is energized. It may cause electric shock, a fire, a failure, a malfunction etc.
	If an abnormal sound, bad-smelling smoke, fever break out from this unit, switch it off promptly and do not use it.

9.1 Measurement functions

9.1.1 Measurement items

The measurement items of this unit are shown in the table below.

Support range				EMU4-HD1A-MB			
	Support range			EMU4-BD1A-MB			
Measurement items of circuit			1P2W	1P3W	3P3W	3P4W	
Electric energy (incoming)	Present		•	•	•	•	
Electric energy (transmission) *1	Present		•	•		•	
Reactive energy (incoming lag)	Present		• *3	•		•	
Detailed electric energy (incoming)	Present		•	•		•	
Detailed electric energy (transmission)	Present		•	•		•	
Detailed reactive energy (transmission lag)	Present		• *3	•		•	
Periodic electric energy	Present		Ø	0	O	Ø	
Electric energy converted value	Present		Ø	0	O	Ø	
Operating time	Present		0	0	0	0	
		Phase 1	\bullet	•		•	
		Phase 2	—	\bullet	\bullet	\bullet	
Current	Present	Phase 3	—	\bullet	\bullet	\bullet	
		Phase N	—	—	-	\bullet	
		Total	\bullet	\bullet	•	\bullet	
		Phase 1	\bullet	•		•	
	Prosont	Phase 2	—	\bullet		\bullet	
Current demand	Flesent	Phase 3	—	\bullet		\bullet	
		Phase N	—	—	—	\bullet	
	Max, Min		\bullet	\bullet		\bullet	
		1-2 line	•	•		•	
		2-3 line	—	•		\bullet	
		3-1 line	—			\bullet	
Valtaga *2	Present	1-N phase	—	—	—	\bullet	
Voltage *2		2-N phase	—	—	—	\bullet	
		3-N phase	—	—	—	\bullet	
		Total	•	\bullet		\bullet	
	Max, Min						

•: Measured data

O: Measured data by settings

©: Measured data by settings (Only EMU4-HD1A-MB)

Not measured data

*1: In case you set the simple measurement effective, the setting value will be a fixed value (0).

*2: In case you set the simple measurement effective, the setting value will be a fixed value (Setting value).

*3: In case you set 2 circuits measuring function effective, it will not be measured.

*4: The degree of harmonic is displayed 1st, 3rd, 5th, 7th, 9th, 11th, 13th.

*5: Only displayed in setting 3P3W(3CT).

*6: The number of monitoring circuits for the waveform band monitoring function is only one (only one phase current).

In case you set 2 circuits measuring function effective, it will only monitor the circuit you yet.

Support range			EMU4-HD1A-MB			
			E			
Measurement items of circuit			1P2W	1P3W	3P3W	3P4W
Electric power	Present			•		•
Electric power demand	Present			•		•
Electric power demand	Max, Min		•	•	•	•
Reactive power	Present		•	•		•
Apparent power	Present		Ι	_	—	•
Power factor *2	Present		\bullet			•
Fower factor *2	Max, Min		\bullet			•
Frequency *1	Present		•		\bullet	•
Harmonics current total		Phase 1	Ø	Ø	O	Ø
PMS value / distortion	Procont	Phase 2	—	_	© *5	Ø
	Flesent	Phase 3	—	Ø	O	Ø
···, -		Phase N	-	-	—	Ô
		1-2 line	Ø	Ø	O	Ø
Harmonics voltage total		2-3 line	—	Ø	O	O
RMS value / distortion	Present	1-N phase	—	—	—	Ø
*1, 4		2-N phase	_	—	—	Ø
		3-N phase	-	—	—	O
1 1011 h		Phase 1	Ø	O	O	O
PMS value / content rate	Drocont	Phase 2	—	—	© *5	O
*1, 4	Present	Phase 3	—	Ø	O	O
		Phase N	_	_	—	O
		1-2 line	Ø	Ø	O	O
1-13N harmonics voltage		2-3 line	—	Ø	Ø	Ø
RMS value / content rate	Present	1-N phase	—	_	—	Ø
*1, 4		2-N phase	_	—	—	Ø
		3-N phase	-	-	—	Ô
Current unbalance rate	Present		—		\bullet	\bullet
	Max		_			•
Voltago unbalanco rato *1	Present		—		\bullet	\bullet
	Max		_			•
Alarm cumulative time	Present		0	0	0	0
Band out rate	Present		© *6	Ø	O	Ø
Band alarm count	Present		© *6	Ø	O	O
Band cycle count	Present		© *6	Ø	O	O
		Other me	easurement iter	ns		
Pulse count value	Present				0	
Pulse converted value	Present	Present ©				
Contact input status	Present			©		

•: Measured data

O: Measured data by settings

©: Measured data by settings (Only EMU4-HD1A-MB)

-: Not measured data

*1: In case you set the simple measurement effective, the setting value will be a fixed value (0).

*2: In case you set the simple measurement effective, the setting value will be a fixed value (Setting value).

*3: In case you set 2 circuits measuring function effective, it will not be measured.

*4: The degree of harmonic is displayed 1st, 3rd, 5th, 7th, 9th, 11th, 13th.

*5: Only displayed in setting 3P3W(3CT).

*6: The number of monitoring circuits for the waveform band monitoring function is only one (only one phase current).

In case you set 2 circuits measuring function effective, it will only monitor the circuit you yet.

The details of measurement items showed below table.

Measurement	Details			
	Details of the sign is showed	below figure.		
Electric power Reactive power Power factor	transmission lead 90° W:- W:+ Var:- Var:+ PF:- PF:+ Var:+ Var:+ Var:+ Var:+ Var:+ Var:+ Var:+ Var:+ PF:- PF:+ Var:+ Var:+ Var:+	incoming lag O° incoming lead		
	Calculated depending on the	phase-wire system.		
	Single-phase 2-wire	phase 1 current		
Current total value	Single-phase 3-wire, Three-phase 3-wire(2CT)	(phase 1 current + phase 3 current) / 2		
	Three-phase 3-wire(3CT), Three-phase 4-wire	(phase 1 current + phase 2 current + phase 3 current) / 3		
	Calculated depending on the	phase-wire system.		
	Phase-wire system	Calculating formula		
Voltage total value	Single-phase 3-wire, Three-phase 3-wire	(voltage V12 + voltage V23) / 2		
	Three-phase 4-wire	(voltage V12 + voltage V23 + voltage V31) / 3		
Pulse count value	Measure the input pulse. Mea Measurement range 0 to 999999	asure the output pulse of equipment by connecting it. Unit Pulse		
Pulse converted value	It is calculated by multiplying converted rate. Pulse converted value = *Pulse converted rate: 0.001	the measured pulse count value by the set pulse Pulse count value \times Pulse converted rate to 10000 (Initial value: 1.000)		
Contact input state	Measuring the contact input a the contact output as an alar Contact information ON、OFF	state. By connecting other equipment, you can capture m.		
Operating time	Measuring the time during co Measurement range 0 to 999999	ntact input is ON or measuring current. Unit hour[hour], minute[min], second[sec]		
	Extended electric energy is the data. The number of digits of energy data.	he data of lower three digits more than electric energy response data is the same as the amount of electric		
Electric energy (expansion) Reactive energy (expansion) (expansion) (expansion) Electric energy(extended) In the case measuring device has "12345.6789" as internal data.		ergy(extended) e has ata. Electric energy data:"123456" 12345.6789		
	(Please multiply multiplying factor in electric energy for calculate measured value.)Extended electric energy data:"45675			
Periodic electric	Measuring the electric energy	y (incoming) during contact input is ON.		
Electric energy converted value	It is calculated by multiplying electric energy conversion ra Electric energy converted Electric energy *Electric energy converted ra	the measured electric energy (incoming) by the set te. value = (incoming) × Electric energy converted rate te: 0.001 to 10000 (Initial value: 1.000)		

Measurement	Details				
elements	2 orang				
Alarm cumulative time	Measured when the upper/lower limit alarm is enabled. Measures the time during which the upper/lower limit alarm is occurring. Integration is performed every measurement cycle (250ms), and 1 count indicates 250ms.				
	Measurement range	Unit	in or diarm candidative time		
	0 to 99999999	none			
Band alarm count	Measure when the waveform band monitoring is enabled.Waveform band monitoring is performed, and the number of alarm occurrences is measured (integrated).Measurement rangeUnit0 to 999999none				
	Measure when the waveform Measures (integrates) the nu monitoring.	band monitoring is mber of waveform o	enabled. data acquired during waveform band		
Band cycle count	Measurement range	Unit			
	0 to 999999	none			
	If it exceeds 999999, it will r	ecount from 0.			

■Measurement items that can be monitored by communication/logging

The measurement items that can be monitored by communication and logging are as follows. For details on the measurement items that can be monitored, refer to the programming manual for each communication, the MODBUS I/F specifications, and the logging unit instruction manual.

*For CC-Link IE Field Basic communication and SLMP communication, refer to "CC-Link communication" in the table below.

Monitored and displayed items of circuit		B/NET communication	CC-Link communication	MODBUS RTU communication	Logging unit
Electric energy (Incoming)	Present	•	•	•	•
Electric energy (Transmission)	Present	•	•	•	•
Reactive energy (Incoming lag)	Present	•	•	•	•
Detailed electric energy (Incoming)	Present	•	•	•	•
Detailed electric energy (Transmission)	Present	•	•	•	٠
Detailed reactive energy (Incoming lag)	Present	•	•	•	•
Periodic electric energy	Present	•	•	•	•
Electric energy converted value	Present	●	●	●	•
Operating time	Present				•
Current	Present		•		•
Current domand	Present	•	•	•	•
Current demand	Max, Min	_	_		_
Voltago	Present				\bullet
vollage	Max, Min	—	—	\bullet	—
Electric power	Present	•			•
Electric power demand	Present Max, Min	• -	• -	•	-
Reactive power	Present	•	•	•	
Apparent power	Present	-	•	•	•
	Present	•	•	•	•
Power factor	Max. Min	_	_		_
Frequency	Present	•	•		
Harmonics current total	-			-	
RMS value / distortion *1	Present	•	•	•	•
Harmonics voltage total RMS value / distortion *1	Present	•	•	•	•
1-13N harmonics current RMS value / content rate *1	Present	•	•	•	•
1-13N harmonics voltage RMS value / content rate *1	Present	•	•	•	•
Current unbalance rate	Present	—	•	•	\bullet
	Max	-	-	-	_
Voltage unbalance rate	Present	-			•
	Max	-	-	-	_
Alarm cumulative time	Present				
Band out rate	Present	-	-	•	-
Band alarm count	Present	•	•	•	\bullet
Band cycle count	Present	•	•	•	•
Other monitored and displa	ayed items	B/NET communication	CC-Link communication	MODBUS RTU communication	Logging unit
Pulse count value	Present	•	•	•	•
Pulse converted value	Present				
Contact input status	Present				

•: Monitorable data

-: Not monitorable data

*1: The degree of harmonic is displayed 1st, 3rd, 5th, 7th, 9th, 11th, 13th.

9.1.2 Restrictions of measured data

Measurement and communication are not performed in a few seconds (about 10seconds) after the power loading to this unit.

Measurement and communication are not performed in a few seconds after the configuration or the change of the rating to it.

Behaviors during operation are as follows.

Measurement	Behaviors of this unit				
elements	Display part indication	Communication data			
Current	Indicate "0 A" if RMS value is less than 0.1% range of rating.	Same as on the left			
Voltage	Indicate "0 V" if RMS value is under 11 V. *1	Same as on the left			
Electric power	Indicate "0 W", "0 var" or "0 VA" if indicated voltage values of all	Same as on the left			
Reactive power	phases are 0 V or indicated current values of them are 0 A.				
Apparent power					
Power factor	Indicate 100.0% If indicated voltage values of all phases are 0 v	Same as on the left			
	or indicated current values of them are U A.				
Frequency	Vollage condition:	0			
	Frequency condition:	11 F			
	Indicate "" if frequency is under 11 5 Hz	44.5			
	Indicate "" if frequency is over 99.9 Hz				
RMS value of	Current condition:	0			
harmonic current	Indicate "0 A" at only applicable phase if displayed current is 0 A	0			
	Voltage condition:	0			
	Indicate "" at all phases if voltage V12 (voltage V1N for 3P4W)	č			
	is 0 V				
	Frequency condition:	0			
	Indicate "" at all phases if frequency is under 44.5 Hz.	-			
Content rate of	Harmonic current condition:	0			
harmonic current	Indicate "0%" at only applicable phase if displayed current is 0 A.				
(Modulation	Voltage condition:	0			
distortion)	Indicate "0%" at all phases if voltage V12 (voltage V1N for 3P4W)				
	is 0 V.				
	Frequency condition:	0			
	Indicate "" at all phases if frequency is under 44.5 Hz.				
RMS value of	Voltage condition:	0			
harmonic voltage	Indicate "0 V" at only applicable phase if displayed voltage is 0 V.				
	Indicate "" at all phases if voltage V12 (voltage V1N for 3P4W)				
	is 0 V.				
	Frequency condition:	0			
	Indicate "" at all phases if frequency is under 44.5 Hz.				
Content rate of	Voltage condition:	0			
harmonic voltage	Indicate "" at only applicable phase if voltage is 0 V.				
	indicate at all phases if voltage v12 (voltage v1N for 3P4W)				
distortion)	IS 0 V.				
	Indicate "" at all phases if frequency is under 11.5 Hz	0			
Electric energy	The electric energy is measured with a load that is about 0.4% or	Same as on the left			
Licethe chergy	more of full load power. Even if the indicated value is "0"	Same as on the terr			
	measurement value will increase.				
Pulse converted	In case of "Use or non-use of upper / lower limit alarm" is "on" and	Same as on the left			
value	"Upper / lower limit alarm element" is "Pulse converted value (upper				
	limit)". If it exceeds 999999.999, it becomes a fixed value of				
	999999.999.				
	In case of "Use or non-use upper / lower limit alarm" is "off" or	Same as on the left			
	"Upper / lower limit alarm element" is other than "Pulse conversion				
	value (upper limit value)". If it exceeds 999999.999, it will start				
	counting again from 0.				
Operating time *2	Indicate "999999 h" if operating time is over 999999 h.	Same as on the left			
Current	Indicate "999.99%" if current unbalance rate is over 999.99%.	Same as on the left			
unbalance rate					
Voltage	Indicate "999.99%" if voltage unbalance rate is over 999.99%.	Same as on the left			
unbalance rate					

*1: In single-phase, three-wire system, indicate "0 V" if RMS value is under 22 V.

*2: Operation time is reference value.

9.1.3 2 circuits Measuring function

This is a function that can measure only two circuits of the single-phase two-wire system (between 1-N and between 3-N), which are branched from the single-phase three-wire system, together. To enable this function, set the following values in <u>"8.2 Setting menu 1: Setting of phase wire system, primary</u> voltage, sensor type, primary current, demand time limit, etc."

●(2) Phase wire system

- ···· 1P2 : Single-phase 2-wire
- ●(3) 2 circuits measuring function availability yES : 2 circuits measuring effective



9.1.4 Simple measurement function

This function enables simple power measurement without voltage input. Each measurement elements calculated by the voltage and power factor and input current.

Measurement resolution is not guarantee. To enable this function, set the following values in <u>"8.2 Setting menu 1:</u> Setting of phase wire system, primary voltage, sensor type, primary current, demand time limit, etc."

●(15) Simple measurement function availability
 ●(16) Simple measurement (Power factor)
 W yES: Simple measurement effective.
 W Any value.

Restrictions on the measurement data when the simple measurement function is enabled are as follows.

Measurement	Behaviors of this unit				
elements	Indication of Display Unit	Communication data			
Current	Current is 0A when input current is less than 0.1% range of rating.	Same as on the left			
Electric power	Indicate "0 W", "0 var" or "0 VA" if indicated current values of all	Same as on the left			
Reactive power	phases are 0 A.				
Apparent power					
Pulse converted value	When use of upper / lower limit alarm = on and upper / lower limit alarm element = pulse count (upper limit), it is fixed to 999999 when 999999 have been exceeded.	Same as on the left			
	When use of upper / lower limit alarm = oFF or upper / lower limit alarm element ≠ pulse count (upper limit), counting restarts from 0 when 999999 have been exceeded.	Same as on the left			
Operating time *1	Indicate "999999 h" if operating time is over 999999 h.	Same as on the left			
Current unbalance rate	Indicate "999.99%" if current unbalance rate is over 999.99.%	Same as on the left			

*1: Operation time is reference value.



9.2 Display function(Operating mode)

This unit indicates the measured value of each item in operating mode. (For the measured items which can be indicated, refer to <u>"9.2.1 Change the measured item"</u>.)

Operation procedure to change the screet	n indicated is as follows:
--	----------------------------

Action	Operation	Details
Change of the measured item	Press [DISP/SET]	Change the measurement items to be displayed. The order of changing, refer to <u>"9.2.1 Change the measured item"</u> .
Change of the phase		Change the phase to be displayed. The order of changing, refer to <u>"9.2.2 Change phase</u> ".
Change of the circuits		In case you set 2 circuits measuring effective, change the circuit to be displayed.
Change of the orders	Press [-/RESET]	In case you indicate the following measured item, change the degree indicated. •RMS value of harmonic current •Content rate of harmonic current (modulation distortion) •RMS value of harmonic voltage •Content rate of harmonic voltage (modulation distortion)
Display of the measurement items where the alarm occurred	_	Transition to applicable measured item indicated, when alarm status is no alarm; alarm status is occurred at the upper / lower limit alarm function or waveform band monitoring function. If alarm occurs with multiple phases at the upper / lower limit alarm, transition to the display at first alarm occurrence.

9.2.1 Change the measured item

Measured item with "Enable" can be changed from the phase to be displayed. (Refer to <u>"9.2.2 Change phase"</u>.)

Measured item / Example of display	Unit	Change phase	Supplement
Electric energy (Incoming)	kWh MWh	_	_
Current	A	Enable	
Current demand	A	Enable	_

Measured item / Example of display	Unit	Change phase	Supplement
Voltage	V	Enable	In case you set the simple measurement effective, it will not be displayed.
Electric power	kW MW	_	_
Electric power demand	kW MW	Enable	_
Reactive power	kvar Mvar	_	_
Apparent power	kVA MVA	_	For EMU4-BD1A-MB, it will not be displayed. If you do not set phase wire system 3P4W, it will not be displayed.
Power factor	%	Enable	In case you set the simple measurement effective, it will not be displayed.

Measured item / Example of display	Unit	Change phase	Supplement
Frequency	Hz	_	In case you set the simple measurement effective, it will not be displayed.
RMS value of harmonic current	A	Enable	For EMU4-BD1A-MB, it will not be displayed. In case you set the harmonic current indication invalid, it will not be displayed. In case you set the simple measurement effective, it will not be displayed.
Content rate of harmonic current (Modulation distortion)	%	Enable	
RMS value of harmonic voltage	V	Enable	For EMU4-BD1A-MB, it will not be displayed. In case you set the harmonic current indication invalid, it will not be displayed. In case you set the simple measurement effective, it will not be displayed.
Content rate of harmonic voltage (Modulation distortion)	%	Enable	
Reactive energy (Incoming lag)	kvarh Mvarh	_	In case you set the 2 circuits measuring function effective, it will not be displayed.

Measured item / Example of display	Unit	Change phase	Supplement
Electric energy (Transmission)	kWh MWh	_	In case you set the simple measurement effective, it will not be displayed.
Periodic electric energy	kWh MWh	_	For EMU4-BD1A-MB, it will not be displayed. Not displayed if the external input is other than contact input.
Electric energy converted value	×1	_	For EMU4-BD1A-MB, it will not be displayed. In case you set the electric energy converted value indication invalid, it will not be displayed.
Pulse converted value	×1	_	For EMU4-BD1A-MB, it will not be displayed. In case you set the pulse input invalid, it will not be displayed.
Contact input status	_	_	For EMU4-BD1A-MB, it will not be displayed. Not displayed if the external input is other than contact input.
Operating time	hour min sec	_	In case you set the operating time indication invalid, it will not be displayed.

*1: The unit of electric energy converted value and pulse converted value depends on the setting. For the setting, refer to <u>"8.4 Setting menu 3: Setting of external input/output, electric energy converted value, harmonic, operating time, etc."</u>

Measured item / Example of display	Unit	Change phase	Supplement
Current unbalance rate	%	Enable	If you set phase wire system 1P2W, it will not be displayed.
Voltage unbalance rate	%	Enable	If you set phase wire system 1P2W, it will not be displayed. In case you set the simple measurement effective, it will not be displayed.
Alarm cumulative time	_	_	In case you set the upper / lower limit alarm invalid, it will not be displayed.
Band out rate	%	Enable	For EMU4-BD1A-MB, it will not be displayed. In case you set the waveform band monitoring invalid, it will not be displayed. In case you set the 2 circuits measuring function effective, it will be displayed the circuit to be monitored. Indicator [1] light up : Phase 1 current Indicator [2] light up : Phase 3 current
Date / Time indication	_	_	In case you do not connect the logging unit, it will not be displayed.

9.2.2 Change phase

Measured items	Display order
Current	For Single-phase 2-wire Phase 1 \rightarrow Total $\rightarrow \cdots$ For Single-phase 3-wire, Three-phase 3-wire Phase 1 \rightarrow Phase 2 \rightarrow Phase 3 \rightarrow Total $\rightarrow \cdots$ For Three-phase 4-wire Phase 1 \rightarrow Phase 2 \rightarrow Phase 3 \rightarrow Phase N \rightarrow Total $\rightarrow \cdots$
Current demand	For Single-phase 2-wire No change for phase (only phase 1 displayed.). For Single-phase 3-wire, Three-phase 3-wire Phase 1 \rightarrow Phase 2 \rightarrow Phase 3 $\rightarrow \cdots$ For Three-phase 4-wire Phase 1 \rightarrow Phase 2 \rightarrow Phase 3 \rightarrow Phase N $\rightarrow \cdots$
Voltage	For Single-phase 2-wire Line 1-2 \rightarrow Total \rightarrow Max \rightarrow Min $\rightarrow \cdots$ For Single-phase 3-wire, Three-phase 3-wire Line 1-2 \rightarrow Line 2-3 \rightarrow Line 3-1 \rightarrow Total \rightarrow Max \rightarrow Min $\rightarrow \cdots$ For Three-phase 4-wire Line 1-2 \rightarrow Line 2-3 \rightarrow Line 3-1 \rightarrow Phase 1-N \rightarrow Phase 2-N \rightarrow Phase 3-N \rightarrow Total \rightarrow Max \rightarrow Min $\rightarrow \cdots$
Electric power demand	Present \rightarrow Max \rightarrow Min $\rightarrow \cdots$
Power factor	
RMS value of harmonic current	For Single-phase 2-wire No change for phase (only phase 1 displayed.). For Single-phase 3-wire, Three-phase 3-wire (2CT) Phase 1 → Phase 3 → ···
Content rate of harmonic current (Modulation distortion)	Three-phase 3-wire (3CT) Phase 1 \rightarrow Phase 2 \rightarrow Phase 3 $\rightarrow \cdots$ For Three-phase 4-wire Phase 1 \rightarrow Phase 2 \rightarrow Phase 3 \rightarrow Phase N $\rightarrow \cdots$
RMS value of harmonic voltage	For Single-phase 2-wire No change for phase (only Line 1-2 displayed.). For Single-phase 3-wire. Three-phase 3-wire
Content rate of harmonic voltage (Modulation distortion)	Line $1-2 \rightarrow \text{Line } 2-3 \rightarrow \cdots$ For Three-phase 4-wire Line $1-2 \rightarrow \text{Line } 2-3 \rightarrow \text{Phase } 1-\text{N} \rightarrow \text{Phase } 2-\text{N} \rightarrow \text{Phase } 3-\text{N} \rightarrow \cdots$
Current unbalance rate	Present \rightarrow Max $\rightarrow \cdots$
Voltage unbalance rate	
Band out rate	For no alarm and no failure. No change for phase. For alarm occurs. Band out rate → Alarm case → … For waveform acquisition fails. Band out rate → Check the failure factors → …

For the total current and total voltage, refer to <u>"9.1.1 Measurement items"</u>.

9.2.3 Measured item indication in operating mode

The indication format of electric energy, reactive energy and periodic electric energy. It is as follows depending on the full load power.

Full load power [kW] =
$$\frac{\alpha \times (\text{Primary voltage}) \times (\text{Primary current})}{1000}$$

 $\begin{bmatrix} \alpha \colon 1 \text{ Single-phase 2-wire} \\ 2 \text{ Single-phase 3-wire} \\ \sqrt{3} \text{ Three-phase 3-wire} \\ 3 \text{ Three-phase 4-wire} \end{bmatrix}$

- *1: The primary voltage is calculated with a setting value either primary voltage (direct) or primary voltage (with VT).
- *2: The primary current is calculated with a setting value either primary current (direct sensor) or primary current (5 A sensor).
- *3: The primary voltage of the three phase 4-wire system is calculated by the phase voltage.

Full load power [kW]		Indicatio	Indication format		
		Digital indication	Unit		
	less than 12	8888.88	414/6		
12 or more and	less than 120	88888.8	KVVII		
120 or more and less than 1200		888888	KValli		
1200 or more and	less than 12000	8888.88	Mark		
12000 or more and	less than 120000	88888.8	Muarb		
120000 or more		888888	Mivdfff		

The indication format of current and current demand. It is as follows depending on the primary current.

Primary current [A]		Indicatio	Indication format		
		Digital indication	Unit		
	less than 40	888.888			
40 or more and	less than 400	8888.88	^		
400 or more and	less than 4000	88888.8	A		
4000 or more and		888888			

■The indication format of voltage.

It is as follows depending on the primary voltage.

^{*1:} In three-phase 4-wire system, the indication of VT primary voltage and direct voltage depends on the phase voltage.

	Indication format		
	Digital indication	Unit	
less than300	88888.8	V	
300 or more and	888888	v	

The indication format of electric power, electric power demand, reactive power and apparent power. It is as follows depending on the full load power.

(For procedures for the full load power, refer to "The indication format of electric energy, reactive energy and periodic electric energy".)

Full load power [kW]		Indication format		
		Digital indication	Unit	
	less than 12	888.888		
12 or more and	less than 120	8888.88	KVV	
120 or more and less than 1200		88888.8		
1200 or more and	less than 12000	888888		
12000 or more and	less than 120000	8888.88	MW	
120000 or more		88888.8	MVA	

The sign of electric power and reactive power represents the following state. (For details, refer to "9.1.1 Measurement items".)

Sign	Electric power	Reactive power			
Unsigned	Incoming	Lag			
-	Transmission	Lead			

■The indication format of power factor.

The sign of electric power factor represents the following state. (For details, refer to <u>"9.1.1 Measurement items"</u>.)

Sign	Power factor
Unsigned	Lag
_	Lead

■The indication format of harmonics current and Harmonics voltage.

It is as follows depending on the full load power. (For procedures for the full load power, refer to "The indication format of electric energy, reactive energy and periodic electric energy.".)

To indicate harmonic current and harmonic voltage, the indication setting of them is needed in advance.

Massurement alements	Indication format		
Measurement elements	Digital indication	Unit	
RMS value of harmonic current	same as current	same as current	
Content rate of harmonic current (Modulation distortion)	888.8	%	
RMS value of harmonic voltage	same as voltage	same as voltage	
Content rate of harmonic voltage (Modulation distortion)	888.8	%	

■The indication format of electric energy (converted value).

It is shown in the table below depending on the electric energy converted unit and the full load power.

(For procedures for the full load power, refer to "The indication format of electric energy, reactive energy and periodic electric energy".)

Significant digits are the lower 6 digits.

To display it, you need to set the electric energy converted value display setting in advance.

When the unit of electric energy converted value is set to MWh, kl, or t.

Full load power [k]W]		Indication format		Supplement
Full load power [kw]		Digital indication	Unit	Supplement
l	less than 12	8888.88	MWh	
12 or more and l	less than 120	88888.8	kl	_
120 or more		888888	t	

*When monitoring the electric energy converted value by communication, the resolution of the LCD display value may be smaller than the monitor value depending on the size of the full load power.

Example: Full load power: 1200 kW, electric energy conversion value: 5433330

LCD display value: 433330

Monitor value in communication: 5433330 = 543333 (data part) $\times 10^{1}$ (Multiplication part)

②When the unit of electric energy converted value is set to kWh, l, or kg.

Full load power [kW]	Indication	format	Supplement
	Digital indication	Unit	Supplement
less than 12	8888.88		The set unit of electric energy converted value is displayed.
12 or more and less than 120	88888.8	kWh l kg	= = = = = = = = = = = = = = = = = = =
120 or more and less than 1200	888888		
1200 or more and less than 12000	8888.88		The unit larger than the set electric energy converted value unit is displayed.
12000 or more and less than 12000	0 88888.8	MWh kl t	
120000 ore more	888888		≠0000000 [1] ⊆ SE DM

③When the unit of electric energy converted value is set to other units.				
Full load n	ower [k]	Indication format		Supplement
		Digital indication	Unit	Supplement
	less than 12	8888.88		
12 or more and	less than 120	88888.8		
120 or more and	less than 1200	888888		
1200 or more and	less than 12000	8888.88		Indicator "K" light up (Multiplier: Represented × 10 ³)
12000 or more and	less than 120000	88888.8	Set unit	<u>=</u> 200000
120000 or more and	less than 1200000	888888		¥ [1]
1200000 or more		8888.88		Indicator "M" light up (Multiplier: Represented × 10 ⁶)

■The indication format of pulse converted value.

It is as follows depending on the pulse converted unit and the pulse converted rate.

The effective number is the last 6 digits.

To indicate pulse converted value, the indication setting of external pulse input is needed in advance.

①When the unit of pulse converted value is set to MWh, kl, or t.

Dulas services durate		Indication	format	Currelansent
Pulse cor	iverted rate	Digital indication	Unit	Supplement
	less than 0.01	888.888	N/N/b	
0.01 or more and	less than 0.1	8888.88		_
0.1 or more and	less than 1	88888.8	КI +	_
1 or more		888888	L	

@When the unit of pulse converted value is set to Wh, kWh, l, g, kg.

Pulso convorted rate		Indication format		Supplement	
Puise com	Verteurate	Digital indication Unit		Supplement	
0.001 or more and	less than 0.01	888.888		The set unit of pulse converted value is displayed.	
0.01 or more and	less than 0.1	8888.88	Wh kWh	PLEXAD	
0.1 or more and	less than 1	88888.8	g kg		
1 or more and	less than 10	888888			
10 or more and	less than 100	8888.88	k\w/b	The unit larger than the set pulse converted value unit is displayed.	
100 or more and	less than 1000	88888.8	MWh kl kg		
1000 or more		888888	t	*0000000 ∦ [2] © s∋ dm	

③When the unit of pulse converted value is set to other units.

Pulse converted rate		Indication format		Supplement	
Puise com	verteurate	Digital indication	Unit	Supplement	
0.001 or more and	less than 0.01	888.888			
0.01 or more and	less than 0.1	8888.88			
0.1 or more and	less than 1	88888.8		¥ŬŬŬ,ŬŬŜ	
1 or more and	less than 10	888888		[1] C SEI DM	
10 or more and	less than 100	8888.88	Set unit	Indicator "K" light up (Multiplier: Represented × 10 ³)	
100 or more and	less than 1000	88888.8		₩₩₩₩₩₩ ₽ 00000	
1000 or more		888888			

■The indication format of operating time.

To indicate operating time, the indication setting of them is needed in advance.

Indication format		
Digital indication	Unit	
	hour	
8888.88	min	
	sec	

■<u>The indication format of current un</u>balance rate and voltage unbalance rate.

Indication format		
Digital indication Unit		
8888.88	%	

■The indication format of alarm cumulative time.

It is as follows depending on the monitor multiplier.

To indicate upper / lower limit alarm, the indication setting of them is needed in advance.

Monitor	Indication format		Supplement
multiplier	Digital indication	Unit	Supplement
1	888888		
10	8888.88	_	Indicator "K" light up (Multiplier: Represented × 10 ³)
100	88888.8		±000000
1000	888888		¥ □□□□□□□ <mark>€</mark> [1] ⊆ ⊆ ΞΞ DM

■The indication format of Band out rate.

Indication format		
Digital indication Unit		
888.8	%	

9.3 Monitoring function

9.3.1 Upper / lower limit alarm function

Monitor the upper and lower limits of the measured value.

Alarm will occur when the measured value exceeds the upper limit alarm value or below the lower limit alarm value.

Monitoring elements

This instrument can set the upper/lower limit alarm value for each measured value individually.

Monitoring elements	EMU4-BD1A-MB	EMU4-HD1A-MB
Current demand upper limit alarm		•
Current demand lower limit alarm	•	
Line voltage upper limit alarm		•
Line voltage lower limit alarm		
Phase voltage upper limit alarm	-	• *1
Phase voltage lower limit alarm	-	• *1
Electric energy demand upper limit alarm		
Electric energy demand lower limit alarm		
Power factor upper limit alarm		•
Power factor lower limit alarm		
Phase N current demand upper limit alarm	-	• *1
Pulse conversion value upper limit alarm	-	
Current unbalance rate upper limit alarm	• *2	● *2
Voltage unbalance rate upper limit alarm	• *2	● *2
		Monitorable data

-: Not monitorable data

*1: Only monitored in 3P4W setting.

*2: Only systems other than the single-phase two-wire system can be monitored.

■Upper / lower limit alarm setting

To make the upper / lower limit alarm, you must be set the following items :

For the setting value and setting range of each item, refer to <u>"8.5 Setting menu 4: Waveform band monitoring, upper</u> / lower limit alarm, etc.".

●Upper limit alarm value

Alarm will occur when the measured value exceeds the upper limit alarm value.

•Lower limit alarm value

Alarm will occur when the measured value below the lower limit alarm value.

●Alarm delay time

Set the value in case you want to remove the inrush current of the load, etc. from the objects of monitoring. Alarm does not occur when the measured value goes below the upper limit or goes over the lower limit within the configured time.

Alarm reset method

Alarm recovery operation is different according to the alarm reset method.

Reset method	Alarm recovery operation
Auto-reset	Reset the alarm automatically if the measured value goes below the upper limit or goes
(Auto)	over the lower limit.
Self-retention	The alarm is held after the measured value goes below the upper limit or goes over the
(HoLd)	lower limit. Alarm is cleared by alarm reset.

For alarm reset operation, refer to "■Alarm reset operation method".

■Alarm occurrence / recovery condition					
Measured items	Alarm reset method	Monitoring items	Alarm status	Alarm occurrence / recovery condition	
		Upper limit monitoring	Occurrence	Measured value > Upper limit alarm value (Alarm delay time is available)	
	Auto-reset		Recovery	Measured value ≦ Upper limit alarm value	
	(Auto)	Lower limit	Occurrence	Measured value < Lower limit alarm value (Alarm delay time is available)	
Current demand		monitoring	Recovery	Measured value \geq Lower limit alarm value	
Phase N current demand Voltage	Self- retention (HoLd)		Occurrence	Measured value > Upper limit alarm value (Alarm delay time is available)	
Power factor		Upper limit monitoring	Retention	Measured value ≦ Upper limit alarm value	
Current unbalance rate Voltage unbalance rate			Recovery	Measured value ≦ Upper limit alarm value and Alarm reset	
		Lower limit monitoring	Occurrence	Measured value < Lower limit alarm value (Alarm delay time is available)	
			Retention	Measured value \geq Lower limit alarm value	
			Recovery	Measured value ≧ Lower limit alarm value and Alarm reset	
	Auto-reset	Upper limit	Occurrence	Measured value ≧ Upper limit alarm value	
	(Auto)	monitoring	Recovery	Measured value < Upper limit alarm value	
Pulse converted value	Self-	l la a an lin: 't	Occurrence	Measured value ≧ Upper limit alarm value	
	retention	monitoring	Retention	Measured value < Upper limit alarm value	
	(HoLd)	monitoring	Recovery	Measured value < Upper limit alarm value	

*Since the measured value of pulse conversion value is an integrated value, it does not decrease.

When an alarm occurs, it is necessary to satisfy the recovery condition by one of the following methods. • Reset pulse conversion value.

Preset pulse conversion value less than setting value of upper limit alarm value.

•Setup upper limit alarm value more than pulse conversion value.

For pulse conversion value preset operation, refer to <u>"8.8.1 Preset and all data reset (Reset/Preset mode)"</u>.

■Indication at alarm status

When an alarm occurs, the display(turn on, flashing) will change.

		Alarm occurrence		Alarm retention	
	No alarm	When indicating the alarm- occurrence phase	When indicating the other phase	When indicating the alarm- occurrence phase	When indicating the other phase
Elements Information indication	•	Ø	Ø	Δ	Δ
Other indication	•	Ø	•	Δ	•

•: Turn on

©: Flashing(250ms ON/250ms OFF)

 \triangle : Flashing(500ms ON/500ms OFF)

Examples of alarm occurring (except for the upper limit of pulse conversion value)

(1) When the alarm reset method is "Auto-reset (Auto)".



(2) When the alarm reset method is "Self-retention (HoLd)".



■Alarm reset operation method

The method of resetting the alarm differs depending on the setting of the alarm reset method.

Alarm reset method	Alarm recovery operation
Auto-reset (Auto)	Reset the alarm automatically if the measured value goes below the upper limit or goes over the lower limit.
Self-retention (HoLd)	The alarm is held after the measured value goes below the upper limit or goes over the lower limit. Clear the alarm as below after the value goes below the upper limit or goes over the lower limit.
	 Pressing the [-/RESET] button for two seconds on the current value display screen in the operation mode will reset the alarm. (Alarm clear is effective even in other than the alarm-occurrence phase.)

■Measurement of alarm cumulative time

Alarm cumulative time measures the time during alarm occurrence. It does not count during alarm delay time or self- retention.



9.3.2 Waveform band monitoring function

*It is a function that can only be used by EMU4-HD1A-MB.

Waveform band monitoring function is a function to monitor the load current of the facilities.

When measuring the load current of "equipment that repeats the same operation" as shown in the figure below, the load current for each operation has the same value and waveform(*).

However, if the equipment continues to operate, the value and waveform of the load current will differ from normal due to equipment wear and abnormalities.

The waveform band monitoring function is a function for "detecting abnormalities in equipment that repeats the same operation."

*It cannot be used with equipment that does not produce the same waveform.



The waveform band monitoring function sets the band (upper and lower thresholds) for the load current waveform. An alarm is output when a waveform that deviates from the band over a certain percentage is detected.



This instrument performs the waveform band monitoring function as follows.

■Waveform measurement method and anomaly detection

This instrument recognizes the waveform from the contact input and waveform data (load current value). It recognizes the start/stop of equipment operation (beginning/end of waveform) by ON/OFF of contact input. While the contact input is ON, the waveform data is measured at intervals of the Sampling cycle (set value).



The normality/abnormality of the measured waveform is determined using the Band out rate. The Band out rate indicates the rate at which the waveform data deviates from the band.



A threshold can be set for the Band out rate. (Default value : 30%) When the Band out rate exceeds the threshold, it is determined that an abnormality has occurred and an alarm is output.

■Bandwidth determination method

This instrument determines the band from the reference waveform. Bands are calculated with the following formula:

Band = Reference waveform \pm (Bandwidth factor (setting value) × Standard deviation)



The reference waveform is generated from the waveform of the load current. Acquire waveforms for 10 cycles, and the average value becomes the reference waveform. Also, determine the standard deviation from the load current when generating the reference waveform.

Note that, a lower limit can be set for the standard deviation.

In case of "Standard deviation" < ("Primary current" \times "Standard deviation lower limit" [%]) calculated as "Primary current" x "Standard deviation lower limit".

	Q. What kind of scene should the standard deviation lower limit level employ you in?
	A. Basically, you can use the default values as they are.
	For example, it can be useful in the following cases:
	If the trend of the load current of the equipment to be measured is very clean, the waveform data
POINT	for 10 cycles may approximate. The standard deviation at this time is very small, and even a slight
	disturbance in the waveform may be detected as abnormal.
	By setting a large lower limit of standard deviation, the bandwidth can be widened so that
	disturbances in the waveform due to external disturbances, etc., are not detected as abnormalities.

■Alarm reset method and operation method

Depending on the alarm reset method, the screen display and whether or not the alarm reset operation is performed will differ.

Alarm reset method	Alarm recovery operation
Auto-reset (Auto)	The alarm is automatically reset when the Band out rate falls below the threshold.
Self-retention (HoLd)	The alarm is retained even after the Band out rate falls below the threshold. After the Band out rate falls below the threshold, perform the following alarm release operation. •Pressing the [-/RESET] button for two seconds on the current value display screen in the operation mode will reset the alarm. (Cancellation is also valid for phases other than the alarm generation phase.)

(1) Alarm reset method = In the case of automatic reset (Auto)



(2) Alarm reset method = In the case of self-retention (HoLd)



■Waveform band monitoring operation method

- (1) Setting the reference waveform and waveform band monitoring
- Set the parameters for generating the reference waveform and the items required for monitoring.
- For the setting, refer to "8.5 Setting Menu 4: Setting Waveform band monitoring, upper / lower limit alarm, etc.".

(2) Generation of reference waveforms

A reference waveform is automatically generated by collecting the load current.

To generate a reference waveform, do the following:





(3) Performing waveform band monitoring

Waveform band monitoring is performed during operation mode.

The alarm occurrence status changes as follows according to the monitoring result.

Monitoring result	Alarm occurrence status	Remarks
Normal	Non-occurrence	In this case, the Band out rate is below the threshold.
Alarm occurrence	occurrence	In this case, the Band out rate exceeds the threshold and an alarm is occurred.
Alarm holding status	Retention	In this case, the Band out rate exceeds the threshold and then falls below the threshold.
Waveform acquisition failure	Non-occurrence	This is a case of failure to acquire waveform data, such as when the number of data is small.

It operates as follows according to the alarm occurrence status.

Contact output

When an alarm occurs, the contact output status changes as follows.

Alarm occurrence status	Contact output	Remarks
Non-occurrence	OFF	The contact output will turn OFF.
Alarm holding status	ON	When the alarm reset operation has not been performed.
	OFF	When the alarm reset operation is performed.
Occurrence	ON	The contact output will turn ON. If the alarm output was ON last time as well, the ON state will be continued.

•Screen display

When an alarm occurs, the screen display changes as follows.

Alarm occurrence	Display	Displayed content	
status	Display	Elements display	Other display
Non-occurrence	Band out rate	•	•
Alarm holding status	Band out rate	0	0
	Alarm case	\bullet	•
Occurronco	Band out rate	Ø	Ø
Occurrence	Alarm case		•

•: Turn on

©: Flashing(250ms ON/250ms OFF)

O: Flashing(500ms ON/500ms OFF)

Also, when an alarm occurs, you can transition to the "alarm case" screen.

The alarm case screen displays the alarm case number according to the alarm occurrence status.

Alarm case No.	Details
1	There is waveform data that exceeds the upper and lower limit value of the band.
2	There is waveform data that exceeds the lower limit value of the band.
3	There is waveform data that exceeds the upper limit value of the band.

•Waveform acquisition failure

If acquisition of waveform data fails, you will be able to transition to the failure factor confirmation screen. On the failure factor confirmation screen, the failure factor number corresponding to the content of the error is displayed ("----" is displayed for the Band out rate).

Failure reason No.	Details
1	The number of collected load current waveform data is less than 10.
2	The amount of waveform data is larger than that of the reference waveform. (Number of waveform data of reference waveform +3 < Number of waveform data of collected load current)
3	The amount of waveform data is smaller than that of the reference waveform. (Number of waveform data of reference waveform -3 < Number of waveform data of collected load current)

10. Confirmation mode / Test mode

A DANGER	Do not touch the live part such as the connection terminal while it is energized. It may cause electric shock, a fire, a failure, a malfunction etc.
	If an abnormal sound, bad-smelling smoke, fever break out from this unit, switch it off promptly and do not use it.

10.1 Confirmation mode: Confirmation of setting values in setting menu 1 to 5

In operating mode, press [DISP/SET] for more than two seconds to transition to confirmation mode and enable operation.

Transition of display and operation of setting menu 1 to 5 is as same as those of setting mode. For setting menu 1 to 5, refer to "8.2" to "8.6". (Change of setting is not available in confirmation mode.)

10.2 How to use test mode

Test mode has the functions which you can utilize in such as the launch of equipment.

Test menu	Details
1. Discrimination support function for improper connection	Indicate the phase angle of current and voltage, electric power value, voltage value and current value of each phase. By checking each displayed value, it becomes easier to determine whether there is a misconnection in the measurement (voltage/current) input connection.
2. Communication test	For models with communication functions, fixed numerical data can be returned without measurement (voltage/current) input. Please use it for the facing test with the host system.
3. Pulse output test	In case of EMU4-HD1A-MB, you can check the pulse output operation without measurement (voltage/current) input. Use for such as the check of the connection to the receiving device.
4. Alarm output test	In the case of EMU4-HD1A-MB, you can check the alarm output operation without measurement (voltage/current) input. Please use it to check the connection with the receiving device.
5. F/W version indication	Displays the F/W version of the instrument.

■How to test

Press [DISP/SET] for two seconds to enter confirmation mode.

- ② Press [+/PHASE] or [-/RESET] to choose confirmation menu 6.
- (As shown in the right figure.)

③ Press [DISP/SET] to enter test mode.

 \circledast Test for the each menu.



■Flow of the test function



10.3 Test menu 1: Discrimination support function for improper connection

In test mode, the following operations can be possible.


■Operation and transition of display. (Examples of a three-phase 4-wire)



*1: When the voltage value or the current value is 0, indicate "----".

POINT Refer to the judgment example (<u>"17 Appendix : Display example of discrimination support fu</u> for improper connection") and check the result.
--

10.4 Test menu 2: Communication test



10.5 Test menu 3: Pulse output test



10.6 Test menu 4: Alarm output test



10.7 Test menu 5: F/W version indication



11. Requirement for the compliance with EMC Directives

EMC Directives prescribe both "Emission (electromagnetic interference): Do not radiate strong electromagnetic waves outside" and "Immunity (electromagnetic susceptibility): Do not be influenced by electromagnetic waves from outside".

This section compiles the precautions for the compliance of the system incorporating the energy measuring unit (Target model: EMU4-BD1A-MB and EMU4-HD1A-MB) with the EMC Directives. The following description is based on the requirement of the regulations and the standards we understand, but we do not guarantee to comply with the directives above for the whole system built in accordance with this description.

The manufacturer of the system finally needs to evaluate the way of the compliance with EMC Directives and whether the system complies with them or not.

(1) Harmonized standard for EMC Directives: EN 61326-1

(a)Compatibility condition for harmonized standard

The energy measuring unit is the open type device (i.e. the device incorporated in other device), and needs to be installed in the conductive control panel.

The unit is tested with installed in the control panel for the radiated emission and the immunity out of the test items for the standard.

- (2) Condition for installation in the control panel
 - (a) Control panel
 - •Control panel needs to have conducting property.
 - •When bolting the top panel, bottom panel etc. of the control panel, mask the grounding part of the panel so as not to be painted.
 - •In inner panel, keep the conductivity in as large area as possible by masking the bolting part to the main panel to keep the electric contact to main panel.
 - •Ground the main panel by the thick wire so as to keep low impedance even for high-frequency wave.

(b) Installation of power line and ground line

- •Set up the ground point to the control panel near the energy measuring unit, and ground the protective conductor terminal of the unit to the ground terminal of the control panel (PE) by as thick and short wires as possible.(Wire length is 300 mm or shorter.)
- (c) Cable

•External input signal line, External output signal line Wiring of each connection wire should satisfy the following conditions.

- \cdot For wiring inside buildings, the wiring length should not exceed 30 m.
- \cdot Do not route wiring from the inside of the building to the outside of the building.

12. Specifications

12.1 Common specifications

Items				Specifications				
Model				EMU4-BD1A-MB EMU4-HD1A-MB				
Phase-wir	re system			Single-phase 2-wire/	Single-phase 2-wire/			
(Change d	of setting)			Single-phase 3-wire/	Single-phase 3-wire/			
				Three-phase 3-wire	Three-phase 3-wire/			
	N/ 1/	<u> </u>		110.1/ 220.1/ 40	I hree-phase 4-wire			
Rating	Voltage	Sing	le-phase 2-wire	110 V, 220 V AC common	(Delta composition: May 220)/			
	v1	Inre	e-phase 3-wire		(Detta connection: Max 220% , Star connection: Max 440%)			
	*	Sing	le-nhase 3-wire	110 V AC (Between 1 and 2 line, 2 and 3 line).	110 V AC (Between 1 and 2 line, 2 and 3 line).			
		Jing	te pluse 5 wire	220 V AC (Between 1 and 3 line)	220 V AC (Between 1 and 3 line),			
					220 V AC (Between 1 and 2 line, 2 and 3 line),			
		Thre	a phase 4 wire		440 V AC (Between I and 3 line)			
		THE	e-phase 4-wire		Min. 63.5 V/ 110 V AC, Max: 277 V/ 480 V AC			
	Current c	ircuit	*2	5 A, 50 A, 100 A, 250 A, 400 A, 600 A A				
				*Each value refers to the split type curre	ent at the primary side of the current			
				sensor.				
	Frequenc	у		50 Hz/ 60 Hz (Auto-detect)				
Auxiliary p	power supp	oly rat	ing	100 V to 240 V AC (+10%, -15%) 50 Hz /	60 Hz 10 VA			
				Transient voltage 4000 V				
Measurab	le circuit c	ounts		Single-phase 3-wire/ Inree-phase 3-wire Single-phase 2-wire: 2 circuit	e/ Inree-phase 4-wire: I circuit			
Consumpt	tion	Volt	age circuit	Fach phase 0.1 VA (at 110 V AC), 0.2 VA	(at 220 V AC), 0.4 VA (at 440 V AC)			
VA		Curr	ent circuit	Each phase 0.1 VA (at the VAC) 0.2 VA (at 220 VAC), 0.1 VA (at the VAC)				
		Auxi	liary power	At 110 V AC: 9 VA				
		supp	oly circuit	At 220 V AC: 10 VA				
Allowable	tolerance	*3, *4		Current, voltage, electric power, reactive power,				
				apparent power, frequency :±1.0% (100% of the rating)				
				Power factor $\pm 3.0\%$ (against the electric angle 90°)				
				Electric energy :±2.0% (5 to 100% range of the rating,				
				Reactive energy $:= 2.5\% (10 \text{ to } 100\% \text{ range of the rating})$				
				nedetive energy ·= 2	power factor=0)			
				Harmonic current, harmonic voltage :±2	.5%			
Data upda	ate interval			250 msec				
Range of	demand tir	ne set	ting	0, 10 s, 20 s, 30 s, 40 s, 50 s, 1 to 15 min (1 min intervals),				
				20 min, 25 min, 30 min				
Alarm	Upper	/	Monitoring	Current demand upper limit alarm,	Current demand upper limit alarm,			
monitoring	g lower l	imit	element	Current demand lower limit alarm,	Current demand lower limit alarm,			
	alarm			Line voltage upper limit alarm,	Line voltage upper limit alarm,			
				Ellectric energy demand upper limit	Electric energy demand upper limit			
				alarm.	alarm.			
				Electric energy demand lower limit	Electric energy demand lower limit			
				alarm,	alarm,			
				Power factor upper limit alarm,	Power factor upper limit alarm,			
				Power factor lower limit alarm,	Power factor lower limit alarm,			
				Current unbalance rate upper limit	Pulse conversion value upper limit			
				alarm,	alarm,			
				vollage unpalance rate upper limit	current unpatance rate upper limit			
				alarm,	Voltage unbalance rate upper limit			
					alarm,			
			Alarm reset	Choose from auto-reset or self-retention	1			
			method					
	Wavefo	orm	Monitoring	-	Band out rate			
	band monito	ring	Alarm resot		Selectable from either auto-rosot			
	monito	9	method		or self-retention			

Specifications

Items			仕様 Specifications				
External	Input sign	nal	-	Non-voltage Form A contact, or open			
input	1112 010 0131			collector 1 input			
	Function		-	Pulse count: 0 to 999999 counts			
				Contact monitoring *5			
	Isolation		-	By photo coupler			
	Rated inp	out voltage and	-	5 V DC, 7 mA (Supplied by this unit)			
	current						
Input co		idition	_	ON time :30 ms or longer OFF time :30 ms or longer Chattering time :3 ms or shorter 3 ms or shorter :30 ms or longer ON			
				0FF			
External	Output si	gnal	-	Non-voltage Form A contact, 1 output			
output	T L L			(Choose the function from below)			
	Isolation		-	By semiconductor relay			
	and current		_	24 V AC, 75 mA 24 V AC, 75 mA (Power factor = 1)			
	Alarm output		-	Upper / lower limit alarm,			
				Waveform band monitoring			
	Pulse output	Output	-	Electric energy (Incoming)			
			_	0 001/ 0 01/ 0 1/ 1/ 10/ 100/			
		onit of pulse		1000/10000 (kWh/ pulse)			
		Pulse width	-	0.1 to 0.15 s			
Compensation for power failure	Stored ite	ems	Stored in the nonvolatile memory (Setting values, integrated values, operating time)				
Standard *6			UL:UL61010-1 CE Marking / UKCA Marking (EMC: EN 61	326-1. I VD' EN 61010-1)			
Usage	Operating	temperature	-5°C to +55°C (Daily average temperature	e is +35°C or lower)			
environment	Operating	humidity	30% to 85%RH(No condensation)				
	Storage t	emperature	-10°C to +60°C				
Operating altitude			2000 m or below				
Commercial free	uency with	stand voltage	2000 V AC, 1 min				
			•Between all terminals (Except for protective conductor terminal) and casing.				
			•Between all terminals of current input, voltage input and all terminals of auxiliary power				
			•Between all terminals of current input, voltage input, auxiliary power (Except for protective conductor terminal) and all terminals of communication. •Between all terminals of current input, voltage input, auxiliary power (Except for protective conductor terminal) and all terminals of communication.				
Insulation resist	ance		10 MΩ or more(500 V DC)				
Mass			0.25 kg				
External dimens	ions		$75(W) \times 90(H) \times 75(D)$ (Except for the protruding portions)				
			(Maximum dimension including the protructing portions: $79(W) \times 90(H) \times 75(D)$)				

*1: In case you measure the larger voltage than instrument rating, please use the transformer (VT) for the instrument. (For single-phase 2-wire and three-phase 3-wire: The measurable range is the primary voltage of VT up to 110000 V and the secondary voltage of VT up to 220 V)

(For single-phase 3-wire: Cannot measure the voltage)

(For three-phase 4-wire: The measurable range is the primary voltage of VT up to 110000 V and the secondary voltage of VT up to 220 V)

The transformer of star - delta connection and delta - star connection can't measure correctly because of the phase shifting. Please use transformer of same wire connection.

*2: In case you measure the larger current than instrument rating, please use the transformer (CT) for the instrument. (The measurable range is the primary current of CT up to 30000 A, the secondary current of CT is fixed to 5 A.)

*3: Do not include the relative error of the division form current sensor.

For relative error of current sensor, refer to <u>"12.4 Specifications of option devices (Split type current sensor)"</u>. *4: The following measurement items (virtual measurement values) shall have an accuracy of 2%. Current: 2-phase current (1P3W, 3P3W), N-phase current (3P4W)

Voltage: 1 and 3 line voltage (1P3W, 3P3W), 1 and 2 line voltage, 2 and 3 line voltage, 1 and 3 line voltage (3P4W) *5: As a function linked to contact monitoring, the periodic electric energy and the operating time can be measured.

*6: When combined with the following products, it will be out of the conformity standard. Option unit: B/NET Communication Unit (Model: EMU4-CM-B) Split type current sensor: (Model: EMU-CT5-A, EMU-CT50-A, EMU-CT100-A, EMU-CT250-A)

12.2 Specifications of MODBUS RTU communications

Items	Specifications
Communication method	RS-485 2-wire half duplex
Communication protocol	MODBUS RTU mode (binary data transfer)
Synchronization method	Asynchronous
Transmission wiring type	Multi-point bus (either directly on the trunk cable, forming a daisy-chain)
Baud rate	2400, 4800, 9600, 19200, 38400 bps (default: 19200 bps)
Data bit	8 bits
Stop bit	1, 2 bit (default: 1 bit)
Parity bit	EVEN, ODD, NONE (default: EVEN)
Slave address	1 to 255 (default: 1)
	(But 0 is impossible of authorization for a broadcast address. 248 to 255 is reserve.)
Response time	1 second or shorter from completion of receiving query data to response transmission
Communications distance	Maximum 1200 m
Connectable devices	Maximum 31 devices
Termination resistor	120 Ω 1/2 W
Applicable wire	SPEV(SB)-MPC- 0.2 × 2 P (produced by Fujikura Dia Cable) or its equivalent

12.3 External dimensions

(1) Energy Measuring Unit only ■EMU4-BD1A-MB



Unit: mm

■EMU4-HD1A-MB





Unit: mm

(2) Combination with option unit ■EMU4-BD1A-MB (connect EMU4-CM-B or EMU4-CM-C)





15

35.2 60

h

35.

27

Unit: mm

*The figure above shows a combination with EMU4-CM-C. The external dimensions are the same when combined with EMU4-CM-B.

■EMU4-HD1A-MB (connect EMU4-CM-B or EMU4-CM-C)

Unit: mm

*The figure above shows a combination with EMU4-CM-C. The external dimensions are the same when combined with EMU4-CM-B. ■EMU4-BD1A-MB (connect EMU4-LM or EMU4-CM-CIFB)

Unit: mm

35.4

27

*The figure above shows a combination with EMU4-LM.

The external dimensions are the same when combined with EMU4-CM-CIFB.

■EMU4-HD1A-MB (connect EMU4-LM or EMU4-CM-CIFB)

Unit: mm

*The figure above shows a combination with EMU4-LM.

The external dimensions are the same when combined with EMU4-CM-CIFB.

(3) Mounting on panel ■EMU4-BD1A-MB (use EMU4-PAT)

*The external dimensions for EMU4-HD1A-MB are the same.

Unit: mm

ぼう

12.4 Specifications of option devices(Split type current sensor)

Item	Specifications					
Model	EMU-CT50	EMU-CT100	EMU-CT250			
Rated primary current	50 A AC	250 A AC				
Rated secondary current	16.66 mA	66.66 mA				
Rated load		0.1 VA				
Relative error	$\pm 1\%$ (5 to 100% range of rating, RL \leq 10 $\Omega)$					
Variability of phase difference	$\pm 30'~(5~to~100\%~range~of~rating,~RL \le 10~~\Omega)$					
Pollution degree	2					
Operating temperature range	-5 to +55°C (Daily average temperature is +35°C or lower)					
Operating humidity range	5 to 95%RH (No condensation)					
Standard for CE Marking/UKCA Marking	EN 61010-2-032					
Mass (per device)		0.1 kg				

ACAUTION

Use an electric wire of the size of penetrating this current sensor for a primary side cable, do not use a non-insulation electric wire or a metal for a primary cable. Please check the maximum voltage for the combination measurement unit.

Item	Specifications						
Model	EMU-CT50-A	EMU-CT50-A EMU-CT100-A EMU-CT250-A		EMU-CT400-A	EMU-CT600-A		
Rated primary current	50 A AC	100 A AC	250 A AC	400 A AC	600 A AC		
Rated secondary current	16.66 mA 33.33 mA		66.66 mA	66.66 mA	66.66 mA		
Rated load			0.1 VA				
Relative error	\pm 1% (5 to 100% range of rating, RL \leq 10 Ω)						
Variability of phase difference	$\pm 45'$ (10% to 100% of rating, RL≤10 Ω) $\pm 60'$ (5% of rating, RL≤10 Ω) $\pm 40'$ (5% to 100% of rating, RL				, RL≦10Ω)		
Pollution degree		-			2		
Operating temperature Range (*1)	-5 to +55°C (Daily average temperature is +35°C or lower)						
Operating humidity range	30 to 85%RH (No condensation)						
Standard for CE Marking/UKCA Marking	- EN			EN 6101	0-2-032		
Mass (per device)	0.1 kg 0.2 kg 0.3 kg 0.4 kg				0.4 kg		
∗1 When using EMU-CT600-A to comply with UL/c-UL standards, please use it within the range of -5℃ to +50℃.							

CAUTIONUse an electric wire of the size of penetrating this current sensor for a primary side cable, do
not use a non-insulation electric wire or a metal for a primary cable.
Please check the maximum voltage for the combination measurement unit.

Specifications

Item	Specifications							
Model	EMU2-CT5 EMU2-CT5-4W		EMU-CT5-A					
Rated primary current		5 A AC						
Rated secondary current		1.66 mA						
Rated load		0.1 VA						
Relative error	\pm 1% (5 to 100% range of rating, RL \leq 10 Ω)							
Variability of phase difference	$\pm 30'~(5~to~100\%~range~of~rating,~RL \leq 10~\Omega)$		±45′ (10% to 100% of rating, RL≦10 Ω) ±60′ (5% of rating, RL≦10 Ω)					
Pollution degree		2	-					
Operating temperature range	-5 to +55°C (Daily average temperature is +35°C or lower)							
Operating humidity range	5 to 95%RH (No condensation)		30 to 85%RH (No condensation)					
Standard for CE marking/UKCA Marking	EN 61010-2-032		_					
Mass (per device)	0.1 kg							

12.5 External dimensions of option devices

Describes the external dimensions of option devices. For Option units and options (option for Logging Unit), refer to the instruction manual for each instrument.

12.5.1 Option for Energy Measuring Unit

■The attachment for panel mounting (EMU4-PAT)

Unit: mm

12.5.2 Split type current sensor

■Split type current sensor (Connection with general wire type) (EMU-CT50, EMU-CT100, EMU-CT250)

						Unit: mr	n
Model	A	В	С	D	E	F	
EMU-CT50、EMU-CT100	31.5	39.6	55.2	25.7	15.2	18.8	
EMU-CT250	36.5	44.8	66	32.5	22	24	

■Split type current sensor (Connection with general wire type) (EMU-CT5-A, EMU-CT50-A, EMU-CT100-A)

							Unit: mm
Model	A	В	С	D	E	F	G
EMU-CT5-A、EMU-CT50-A	37.4	31.6	57.5	12.2	12.8	14	5
EMU-CT100-A	43.6	33.6	65	16.2	16.2	19	5

Specifications

Split type current sensor (Connection with general wire type) (EMU-CT250-A, EMU-CT400-A, EMU-CT600-A)

							Unit: mm
Model	A	В	С	D	E	F	G
EMU-CT250-A	42.6	49.4	74.5	24	24	25.2	4.5
EMU-CT400-A、EMU-CT600-A	44.9	67.2	94	36	36	27	4.5

■Split type current sensor(Connection with dedicated cable type) (EMU2-CT5)

■Split type current sensor(Connection with dedicated cable type) (EMU2-CT5-4W)

124

12.5.3 Dedicated cable

■Split type 5A current sensor cable (EMU2-CB-Q5A-4W)

Unit: mm

■Split type 5A current sensor extension cable (standard type) (EMU2-CB-T**M)

Model	EMU2-CB-T1M	EMU2-CB-T5M	EMU2-CB-T10M
L size	1000	5000	10000
			Unit: mm

■Split type 5A current sensor extension cable (separate type) (EMU2-CB-T**MS)

Model	EMU2-CB-T1MS	EMU2-CB-T5MS	EMU2-CB-T10MS
L size	1000	5000	10000
			Unit: mm

Care

13.	Care	
	•Do not touch the live part such as the connection terminal while it is energized. Failure to]

A DANGER	 If the voltage applied to the instrument drops below approximately 40 V, the display wil disappear, but please do not touch the terminals or circuits as voltage may be applied. It may cause electric shock, a fire, a failure, a malfunction etc.

	Any person who is involved in the installation and the wiring of this unit should be fully competent to do this work.
--	---

Care as follows:

- (1) If the surface of this equipment is dirty with dust, wipe it with a dry cloth each time.
- (2) Do not let a chemical cloth remain on the surface for an extended period of time nor wipe the surface with thinner or benzene. Cause deformation.

14. Storage

A DANGER	 Do not touch the live part such as the connection terminal while it is energized. Failure to do so may cause electric shock, a fire, a failure etc. If the voltage applied to the instrument drops below approximately 40 V, the display will disappear, but please do not touch the terminals or circuits as voltage may be applied. It may cause electric shock, a fire, a failure, a malfunction etc.
<u> </u>	

▲ WARNING	Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause
	electric shock, a fire, a failure etc.

	Any person who is involved in the installation and the wiring of this unit should be fully competent to do this work.
--	---

Storage as follows:

(1) Removing the unit

①Turn off the power to the circuit to which is connected.

②Disconnect any cables that are connected.

③Remove the unit in the reverse order of the mounting. (Please refer to <u>"5. Attaching and removing</u>".)

(2) Storage

Turn off the power, disconnect the wires, remove the unit from the panel, and store it in a polyethylene bag.

15. Maintenance

A WARNING	Work under the electric outage condition. Do not do hot-line work. Failure to do so may cause electric shock, a fire, a failure etc.
-----------	--

A CAUTION	Any person who is involved in the installation and the wiring of this unit should be fully
	competent to do this work.

Maintenance as follows:

(1) Daily maintenance

 $\textcircled{}{}^{}$ No damage on this unit.

②No abnormal heat.

③No abnormal noise or smell.

⁽⁴⁾No interfere with the reading of the displayed values by dust and dirt or LCD failure.

⑤No dust or dirt adhering to the current-carrying part.

(2) Periodical maintenance

Please maintenance every year the listed below:

①No damage on this unit.

②No cable disconnection.

③No looseness wire connection to terminal blocks. If there is any looseness, retighten with the appropriate torque.

16. Troubleshooting

This chapter explains the details of problems and how to deal with them. If the contents described here do not solve the problem, contact our sales representative near you. (For details, (For details, refer to the end of this manual.).

16.1 In case you think the unit is in failure

If you think the unit is in failure, check the following before sending for repair.

Phenomenon	There is a difference in the measured value. Example 1: Electric energy (Integrated value) is not measured even if the current value is indicated. Example 2: The measured value is different compared to other measuring instruments.
Check point	 Are the power supply side and the load side of the power line connection reversed? Are the set values (Phase wire system, primary voltage, primary current) correct? Are the wiring short-circuited or disconnected?
Phenomenon	The current value measured by another measuring instrument and this instrument is different (More than the allowable error).
Check point	Check that the measuring instrument used for comparison indicates the rms value correctly. The instrument indicates rms values. If the measuring instrument used for comparison measures an average value instead of rms value, distortion caused by harmonic etc. in the current of the circuit to be measured causes a significant difference of values.

16.2 About error number

In case the display part indicates the error number as below, adopt measures indicated in the table below. If the unit does not resume after measures, it may be in failure. Contact our sales representative near you.

Error No.	Details of the error	Measures	
002	FRAM error	Press the reset button until the display (LCD) turns off or restore	
003	Memory error	- auxiliary power supply.	
004	Timeout error	1	
005	Setting value out of range error	Press [DISP/SET] button.	
009	Communication module error	Make sure that the communication module is connected properly, then turn on the power again auxiliary.	
261	Communication error	The communication line is broken or not properly connected. Check that the signal symbols are correct, and that the communication connector and terminal screws are not loose.	
262		Communication lines are busy. It will automatically return after a while. If it occurs repeatedly, please contact sales outlet.	
263	Measuring unit failure	The energy measuring unit has failed. Please contact Mitsubishi Electric system service or sales outlet (Please mention the error number when you contact us).	
264	- Communication error	 In the case of B/NET transmission The following three points can be considered. Please confirm it. Is the B/NET transmission dedicated power supply turned off? Is the B/NET transmission line disconnected? Are the transmission lines connected correctly? (Check that the signal symbols D, N, and S are correct, and that the screws for the B/NET transmission connector and each terminal are not loose.) 	
265		 In the case of CC-Link communication The following two points can be considered. Please confirm it. Is the CC-Link communication line disconnected? Are the communication lines connected correctly? (Check that the signal symbols DA, DB, DG, and SLD are correct, and that the screws of the CC-Link communication connector and each terminal are not loose.) 	
266	Communication error between option units	Communication between the energy measuring unit and option unit has failed. Please reset the energy measuring unit.	
281	B/NET communication error	B/NET address is duplicated. Please check all addresses or station numbers of the energy measuring unit and terminals connected to it.	
901		The write protect switch of the SD memory card of the logging unit is ON. Turn off the write protect switch.	
902	Logging unit error	A measuring element that cannot be measured by the energy measuring unit is set as a logging element. Please reset the logging conditions.	
903	Memory error in option	Reading the internal memory has failed.	
904	unit	Turn on the auxiliary power again.	
905	Time error	Please reset the current time.	
907	Logging setting error	The logging setting data file specifications may be incorrect or out of the data range. Check the contents of the setting data file again.	
912	Communication error between option units	(Refer to " Error No.266" in this chapter.)	

16.3 Q&A

 Q To what degree is the unit durable against overvoltage and over current? Durability is as follows: Momentary*: Up to 10 times as high as rated current and 2 times as high as rated voltage. A *Momentary means: Energizing 9 times for 0.5 seconds at 1-minute intervals, and then 1 time for 5 seconds. Continuous : Up to 1.1 times as high as rated voltage and rated current. Q Can the unit be used as an electric energy meter? This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. Q Are errors in wiring verifiable easily? They are verifiable by the indication for discrimination support function for improper connection. (Please refer to"<u>17</u>. Appendix: Discrimination support function for improper connection x.") 	■General		
Durability is as follows: Momentary*: Up to 10 times as high as rated current and 2 times as high as rated voltage. *Momentary*: Up to 10 times as high as rated current and 2 times as high as rated voltage. *Momentary means: Energizing 9 times for 0.5 seconds at 1-minute intervals, and then 1 time for 5 seconds. Continuous : Up to 1.1 times as high as rated voltage and rated current. Q Can the unit be used as an electric energy meter? This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. Q Are errors in wiring verifiable easily? A They are verifiable by the indication for discrimination support function for improper connection. (Please refer to"17. Appendix: Discrimination support function for improper connection x.")	Q	To what degree is the unit durable against overvoltage and over current?	
 Momentary means: Energizing 9 times for 0.5 seconds at 1-minute intervals, and then 1 time for 5 seconds. Continuous : Up to 1.1 times as high as rated voltage and rated current. Can the unit be used as an electric energy meter? This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. Are errors in wiring verifiable easily? They are verifiable by the indication for discrimination support function for improper connection. (Please refer to"<u>17. Appendix: Discrimination support function for improper connection x</u>.") 		Durability is as follows: Momentary: Up to 10 times as high as rated current and 2 times as high as rated voltage.	
Q Can the unit be used as an electric energy meter? A This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. Q Are errors in wiring verifiable easily? A They are verifiable by the indication for discrimination support function for improper connection. (Please refer to" <u>17. Appendix: Discrimination support function for improper connection x</u> .")	А	*Momentary means: Energizing 9 times for 0.5 seconds at 1-minute intervals, and then 1 time for 5 seconds.	
 <i>Q</i> Can the unit be used as an electric energy meter? <i>A</i> This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. <i>Q</i> Are errors in wiring verifiable easily? <i>A</i> They are verifiable by the indication for discrimination support function for improper connection. (Please refer to"<u>17. Appendix: Discrimination support function for improper connection x</u>.") 		Continuous : Up to 1.1 times as high as rated voltage and rated current.	
 <i>Q</i> Can the unit be used as an electric energy meter? This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. <i>Q</i> Are errors in wiring verifiable easily? They are verifiable by the indication for discrimination support function for improper connection. (Please refer to"<u>17. Appendix: Discrimination support function for improper connection x</u>.") 			
 A This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law. A Are errors in wiring verifiable easily? A They are verifiable by the indication for discrimination support function for improper connection. (Please refer to"<u>17. Appendix: Discrimination support function for improper connection x</u>.") 	Q	Can the unit be used as an electric energy meter?	
Q Are errors in wiring verifiable easily? They are verifiable by the indication for discrimination support function for improper connection. (Please refer to" <u>17. Appendix: Discrimination support function for improper connection x</u> .")	A	This unit cannot be used for deal and proof of electric energy measurement stipulated in the measurement law.	
Q Are errors in wiring verifiable easily? They are verifiable by the indication for discrimination support function for improper connection. (Please refer to" <u>17. Appendix: Discrimination support function for improper connection x</u> .")			
A They are verifiable by the indication for discrimination support function for improper connection. (Please refer to" <u>17. Appendix: Discrimination support function for improper connection x</u> .")	Q	Are errors in wiring verifiable easily?	
	A	They are verifiable by the indication for discrimination support function for improper connection. (Please refer to" <u>17. Appendix: Discrimination support function for improper connection x</u> .")	

Q	Is it OK to open the secondary terminals of the current sensor?
A	Do not open the secondary terminal of the current sensor. The split type current sensor has a built-in secondary terminal open protection circuit, so it will not cause an immediate fire, burnout, or other accident, but for safety, do not open it.

■Q&A about specifications

Q	What does "Allowable tolerance" mean?	
A	 For electric energy, it indicates the tolerance range for the measurement reading. For example, if the reading is 10KWh, the error is ±0.2KWh. For measurement elements other than electric energy, the allowable error range for rated input is shown. For current, when the rated current is set to 5A, the allowable range is ±1% of 5A. 	
Q	Is accuracy of the split type current sensor included?	

Q	Is accuracy of the split type current sensor included?
A	Accuracy of the split type current sensor is not included in accuracy of the unit. A maximum value of tolerance is obtained by summing tolerance of the unit and that of a current sensor.

Q	To what degree an area of micro current is measured?
A	A current value is measured from the area exceeding 0.1% of the rated current. In an area below 0.1%, measurement result is indicated as "0" (zero). However, in that case, still, the amount of electricity is being measured. Even if the indicated value is "0," measurement value will increase in continuing measurement for a long time. The amount of electricity is measured with a load that is about 0.1% or more of full load power.

Q	Is measurement of inverter circuit possible?
A	Measuring the secondary side of the inverter is impossible due to the large fluctuation of frequency. Make measurement on the primary side of the inverter. However, since a current waveform on the primary side of the inverter has a distortion containing the harmonic components, a slight error occurs.

Troubleshooting

Q&A about i	nstallation		
Q	What is wire diameter that allows installing the split type current sensor?		
	The following lists the	nominal cross-sectional areas of th	e conductor of 600-V vinyl coated wires
	that can penetrate. (V	alues for reference)	
	形名 Model	IV wire (600-V vinyl insulated wire)	CV wire (600-V vinyl insulated wire)
	EMU-CT50-A	38mm ²	22mm ²
	EMU-CT100-A	60mm ²	60mm ²
	EMU-CT250-A	200mm ²	150mm ²
Λ	EMU-CT400-A	500mm ²	400mm ²
А	EMU-CT600-A	500mm ²	400mm ²
	EMU-CT50	60mm ²	38mm ²
	EMU-CT100	60mm ²	38mm ²
	EMU-CT250	150mm ²	150mm ² (100mm ² is recommended)
	The above shows the standard nominal cross-sectional areas.		
	Due to the outer differ	rence of finished vinyl insulation ar	nd deformation (bending) depending on
	manufacturers, a wire	may not penetrate.	
	Make verification on si	te.	
Q	What are the points wh	nen installing the split type current	sensor?
	The split type current	sensor are split-type.	
Λ	It split surfaces are no	t engaged sufficiently or a foreign of	object exists between the split surfaces,
А	adequate performance	es are not obtained.	

■Q&A about connection

Pay attention in installation.

Q	Does polarity exist in connection between the split type current sensor and the unit?
A	Yes. Make connections so that secondary terminals of the split type current sensor (k, l) and terminal symbols of unit agree with each other. If polarity is incorrect, the current value is measurable, but the electric power and the electrical energy cannot be measured correctly.

Q	Are there any key points in avoiding errors in wiring?
А	Check polarity of the split type current sensor on the primary current side. Power supply side of the circuit is indicated as "K," and the load is indicated as "L." An arrow indicates the direction from K to L. Check the split type current sensor and the module are connected correctly for the 1-side circuit, 2-side circuit and 3-side circuit. Besides, check that voltage inputs for voltage transform unit are connected correctly among P1, P2, P3, and P0.

Q	How do wires extend between the split type current sensor and the module?	
A	The split type current sensor (Connection with general wire type) is extendable up to 50m. The split type current sensor (Connection with dedicated cable type) is extendable up to 11 m, using together with an extension cable. To extend the wire further, use the current transformer CW-5S/ CW-5SL for split-type instrument in combination, extending the secondary wiring on CW-5S/ CW-5SL side.	

■Q&A about setting

Q	Is the setting required?	
А	At least, settings of phase wires, primary current and primary voltage are required. Specify settings in accordance with a circuit to be connected.	
Q	If a primary current setting value is different from that of rated current on a connected the split type current sensor, does it cause a breakdown?	
A	It does not cause breakdown or burning. However, measurement values will be totally incorrect.	

Appendix: Discrimination support function for improper 17. connection

UISPIC * Th	ay examp ne shaded a	ole ((areas i	Conn n the t	ecti table	on ex are aft	kample for [·]	three-phase :	3-wire(2CT)) Also, the broken I	ines	in th	ne co	 onnectior	Indicate	es improper connection
	Power				At e	quilibrium load	$(V_{12}=V_{23}, I_1=I_3)$						Conn	ection
No.	factor (Input)	Pha	ase ang	le dis	play	Electric power display	Voltage display	Current display	V	oltag	e	Cur	rent	Wiring
	Ferried	∠V ₁₂	∠V ₂₃	∠I ₁	∠I ₃	W ₁ W ₃	V ₁₂ V ₂₃ V ₃₁	I ₁ I ₂ I ₃	1	2	3	(side"1"	(side"3"	
	Forward 70.7% Forward 86.6%	-		345 0	225 240	W ₁ >W ₃								
Normal status	100.00%	0	300	30	270	W ₁ =W ₃	$V_{12} = V_{23} = V_{31}$	$I_1 = I_2 = I_3$	Р1	P2	P3	Forward	Forward	
	Delayed 86.6%	-		60	300	W W								
	Delayed 70.7%			75	315	W1 ~ W3								
	Forward 70.7%	-		165	45									Connection between P1 and P2 are reversed. 1 2 3
	Forward 86.6%	-		180	60	W1=Negative								
1	100.00%	0	60	210	90	value W3=Positive value	$V_{12} = V_{23} = V_{31}$	$I_1 = I_2 = I_3$	P2	P1	Р3	Forward	Forward	
	Delayed 86.6%	-		240	120									V S V P1 V S V P2 V S V P2
	Delayed 70.7%			255	135									$\begin{array}{c c} & & & & \\ \hline & & & \\ \hline \\ \hline \\ \hline \\ \hline \\ \hline \\$
	Forward 70.7%	-		165	45									is reversed. 1 2 3 K 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
2	86.6%		120	180	60	W1=Negative value	N -N -N	1 -1 -1	62	D1	62	Ferrurad	Comment	
2	Delayed		120	210	90	W3=Positive value	v ₁₂ = v ₂₃ < v ₃₁	I ₁ =I ₂ =I ₃	P2	PI	P3	Forward	Forward	
	86.6% Delayed	-		240	120									
	Forward			165	225									Connection of CT on side "1" is reversed.
	Forward			180	240									1 2 3
3	100.00%	o	300	210	270	W1=Negative value W3=Positive	$V_{12} = V_{23} = V_{31}$	I ₁ =I ₃ <i<sub>2</i<sub>	Р1	P2	P3	1K 1L	Forward	
	Delayed 86.6%	-		240	300	value						Reverse		
	Delayed 70.7%			255	315	•								
	Forward 70.7%			225	345	W1=Negative value								CT on side "1" and "3" are swapped.
	Forward 86.6%			240	0	W3=Positive value								K 1K 1L
4	100.00%	o	300	270	30	W ₁ =W ₃ =0	$V_{12} = V_{23} = V_{31}$	$I_1 = I_2 = I_3$	P1	P2	P3	3K 3L Forward	1K 1L Forward	Ц Ц Ц Ц Ц Ц
	Delayed 86.6%			300	60	W ₁ =Positive value								
	Delayed 70.7%			315	75	w ₃ =Negative value								The VI terminals are connected to
	Forward 70.7%	-		225	105	W ₁ =Negative value W ₃ =Negative								the measuring instrument's P1, P2, and P3 terminals in the order of P2, P3, and P1.
	Forward 86.6%			240	120	value W1=0								
5	100.00%	0	300	270	150	W ₃ =Negative value	$V_{12} = V_{23} = V_{31}$	$I_1 = I_2 = I_3$	P3	P1	P2	Forward	Forward	
	86.6% Delayed	-		300	180	W1=Positive value W3=Negative value								

Display example of discrimination support function for improper connection

Display example (Connection example for three-phase 3-wire(2CT))

*This table is an example for a three-phase three-wire system (2CT).

In the case of three-phase three-wire system (3CT), the misconnection support display is the same. However, it cannot detect misconnection of CT on the 2nd side.

Displa	ay examp	ole ((ectio	on ex	cample for	single-phase	3-wire)	ines	in th		Ir	dicates	s improper connection
	Power				At eq	uilibrium load(v12=v23, I1=I3)						Conn	ection
No.	factor (input)	Pha	ase ang	le dis	play	Electric power display	Voltage display	Current display	V	oltag	le	Cur	rent	Wiring
	Forward	∠V ₁₂	∠V ₂₃	∠I ₁	∠I ₃	W ₁ W ₃	V ₁₂ V ₂₃ V ₃₁	I ₁ I ₂ I ₃	1	2	3	(side"1"	(side"3"	
	70.7%			315	135									
	Forward 86.6%			330	150									
Normal status	100.00%	0	180	0	180	$W_1 = W_3$	V ₁₂ =V ₂₃ <v<sub>31</v<sub>	$I_1 = I_3$ $I_2 = 0$	P1	P2	Р3	Forward	Forward	
	Delayed 86.6%			30	210									P1 P2
	Delayed 70.7%			45	225									
	Forward 70.7%			135	315									Connection between P1 and P2 are reversed. 1 2 3
	Forward 86.6%			150	330									
1	100.00%	0	0	180	0	W1=Negative value W3=Positive	$V_{12} = V_{23} < V_{31}$	$I_1 = I_3 \\ I_2 = 0$	P2	P1	Р3	Forward	Forward	
	Delayed 86.6%			210	30	value								P1
	Delayed 70.7%			225	45									P3
	Forward 70.7%			135	315									The VT terminals are connected to the measuring instrument's P1, P2, and P3 terminals in the order of P2,
	Forward 86.6%			150	330									P3, and P1. 1 2 3 K 1K
2	100.00%	0	о	180	0	W1=Negative value W3=Positive value	V ₁₂ >V ₂₃ =V ₃₁	$I_1 = I_3 I_2 = 0$	P2	Р3	P1	Forward	Forward	
	Delayed 86.6%			210	30	, and a								<u>P1</u>
	Delayed 70.7%			225	45									P3
	Forward 70.7%			315	315									Connection of CT on side "3" is reversed.
	Forward 86.6%			330	330	W1 - Desitive								
3	100.00%	0	180	0	0	value W3=Negative value	$V_{12} = V_{23} < V_{31}$	$I_1 = I_3 < I_2$	Р1	P2	Р3	Forward	3K 3L Reverse	ЗК ЗL
	Delayed 86.6%			30	30									P1 P2
	Delayed 70.7%			45	45									
	Forward 70.7%			135	315									1 2 3
	Forward 86.6%			150	330	W1=Negotive								
4	100.00%	0	180	180	0	value W3=Negative value	$V_{12} = V_{23} < V_{31}$	$I_1 = I_3$ $I_2 = 0$	P1	P2	Р3	3K 3L Forward	1K 1L Forward	K L L 3K L
	Delayed 86.6%			210	30									P1 P2
	Delayed 70.7%			225	45									P3
	Forward 70.7%			135	315									The VT terminals are connected to the measuring instrument's P1, P2, and P3 terminals in the order of P3, P2 and P1
	Forward 86.6%			150	330	W1=Negative								
5	100.00%	0	180	180	0	value W3=Negative value	$V_{12} = V_{23} < V_{31}$	$I_1 = I_3$ $I_2 = 0$	Р3	P2	Р1	Forward	Forward	
	Delayed 86.6%			210	30									3L ,P1
	Delayed 70.7%			225	45									P3

Displ	ay exai he shade	mple d are	e (Co as in	onne the ta	ectio	on e are af	xam fecte	ple for th	ree-phase 4	1-wire) Also, the broke	n lir	nesi	in tł	ne c	onnecti	indicat	es imp ram are	roper connection the improper connections.
	Power				A	t equi	libriun	n load(V _{1N} =V _{2N=}	$V_{3N} I_{1=} I_2 = I_3)$						1	Co	nnection	Γ
No.	factor (input)		Pha	se ang	le disp	olay		display	Voltage display	Current display		Volt	tage	_	СТ	Current	СТ	Wiring
	Ferrierd	∠V _{1N}	∠V _{2N}	∠V _{3N}	∠I ₁	∠I ₂	∠I ₃	W1 W2 W3	V _{1N} V _{2N} V _{3N}	I ₁ I ₂ I ₃	1	2	3	0	(side"1"	(side"2"	(side"3"	
	70.7%				315	75	195											
	Forward 86.6%				330	90	210											
Normal status	100.00%	0	120	240	0	120	240	W1=W2=W3	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	Р3	Р0	Forward	Forward	Forward	
	Delayed 86.6%	-			30	150	270	-										
	Delayed 70.7%				45	165	285											
	Forward 70.7%				315	75	195											Negative phase sequence.
	Forward 86.6%				330	90	210											
1	100.00%	0	120	240	0	120	240	W1=W2=W3	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	Р3	Р1	P2	Р0	3K 3L Forward	1K 1L Forward	2K 2L Forward	к <u>ЗL</u>
	Delayed 86.6%				30	150	270											
	Delayed 70.7%				45	165	285											
	Forward 70.7%																	Negative phase sequence.
	Forward 86.6%	-																K K L L L L L L L L L L L L L
	100.00%							Same as above			P3	P1	P2	Р0	2K 2L Forward	3K 3L Forward	1K 1L Forward	3K
	Delayed 86.6%	-																V V PI U V V PI P3
	Delayed 70.7%																	
	Forward 70.7%				190	315	75	W ₁ =Negative value W ₂ =Positive value W ₃ =Positive value										are reversed.
	Forward 86.6%				210	330	90	W1=Negative value W2=0 W3=Positive value										
2	100.00%	0	240	120	240	0	120	W ₁ =Negative value W ₂ =Negative value W ₃ =Positive value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P2	P1	Р3	Р0	Forward	Forward	Forward	
	Delayed 86.6%				270	30	150	W1=0 W2=Negative value W3=Positive value										
	Delayed 70.7%				285	45	165	W ₁ =Positive value W ₂ =Negative value W ₃ =Positive value										
	Forward 70.7%				315	75	195	W ₁ =Positive value W ₂ =Negative value W ₃ =Positive value										are reversed.
	Forward 86.6%				330	90	210	W ₁ =Positive value W ₂ =Negative value W ₃ =0										
3	100.00%	0	240	120	0	120	240	W ₁ =Positive value W ₂ =Negative value W ₃ =Negative value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	Р3	P2	Р0	Forward	Forward	Forward	
	Delayed 86.6%				30	150	270	W ₁ =Positive value W ₂ =0 W ₃ =Negative value										
	Delayed 70.7%				45	165	285	W1=Positive value W2=Positive value W3=Negative value										
	Forward 70.7%	-			75	195	315	W1-POSITIVE value W2=Positive value W3=Negative value										are reversed.
	Forward 86.6%				90	210	330	W1=0 W2=Positive value W3=Negative value										
4	100.00%	0	240	120	120	240	0	W ₂ =Positive value W ₃ =Negative value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 \!=\! I_2 \!=\! I_3$	P3	P2	P1	P0	Forward	Forward	Forward	
	Delayed 86.6%	-			150	270	30	W ₂ =Positive value W ₃ =0										
	Delayed 70.7%				165	285	45	W ₂ =Positive value W ₃ =Positive value										Connection between P1 and P0
	Forward 70.7%				135	255	15											are reversed.
	86.6%	-			150	270	30	W1=Negative value W2=Positive										
5	100.00%	0	330	30	180	300	60	w∠=Positive value W3=Positive value	$V_{1N} < V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	PO	P2	Р3	P1	Forward	Forward	Forward	
	Belayed 86.6%	-			210	330	90											
	Delayed 70.7%				225	345	105											

Displ	ay exar	nple	e (Co	onne		on e	xam	ple for th	ree-phase	4-wire)	n li-	200	in +4]	ndicat	es imp	roper connection
* 1					ADIE 2	At equi	libriun	n load(V _{1N} =V _{2N=}	V_{3N} , $I_{1=}I_2=I_3$)	Also, the broke		les		le c	onnecti	Coi	nnection	
No.	Power factor (input)		Pha	ise ang	le disp	olay		Electric power display	Voltage display	Current display		Vol	tage			Current		Wiring
	(input)	∠V _{1N}	∠V _{2N}	∠V _{3N}	∠I ₁	∠I ₂	∠I ₃	W ₁ W ₂ W ₃	V _{1N} V _{2N} V _{3N}	I ₁ I ₂ I ₃	1	2	3	0	CT (side"1"	CT (side"2"	CT (side"3"	Connection between P2 and P0
	Forward 70.7%				345	105	225											are reversed.
	Forward 86.6%				0	120	240	W1=Positive										
6	100.00%	0	330	300	30	150	270	value W2=Negative value	V _{1N} =V _{3N} >V _{2N}	$I_1 = I_2 = I_3$	P1	P0	P3	P2	Forward	Forward	Forward	
	Delayed				60	180	300	W3=Positive value										
	Delayed	-			75	195	315											
	Forward				285	45	165											Connection between P3 and P0 are reversed.
	70.7% Forward	-			200	60	190											
7	86.6%	0	60	20	300	00	210	W1=Positive value W2=Positive	V -V -V	I –I –I	D1	20	PO	D2	Forward	Forward	Forward	
'	Delayed	0	80	30	330	90	210	value W3=Negative value	V1N-V2N/V3N	11-12-13	PI	P2	PU	P3	Forward	Forward	Forward	3K 3L U U U P1
	86.6%	-			0	120	240											U u
	70.7%				15	135	255											Connection of CT on side "1"
	Forward 70.7%	-			135	75	195											is reversed.
	Forward 86.6%	-			150	90	210	W1=Negative										
8	100.00%	0	120	240	180	120	240	W2=Positive value W3=Positive	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	Р3	Р0	1K 1L Reverse	Forward	Forward	
	Delayed 86.6%				210	150	270	value										
	Delayed 70.7%				225	165	285											
	Forward 70.7%				315	255	195											Connection of CT on side "2" is reversed.
	Forward 86.6%				330	270	210	W1=Positive										
9	100.00%	o	120	240	0	300	240	value W2=Negative value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	Р3	Р0	Forward	2K 2L Reverse	Forward	
	Delayed 86.6%				30	330	270	W3=Positive value										
	Delayed 70.7%				45	345	285											
	Forward				315	75	15											Connection of CT on side "3" is reversed.
	Forward				330	90	30											
10	100.00%	0	120	240	0	120	60	W1=Positive value W2=Positive	V1N=V2N=V3N	$I_1 = I_2 = I_3$	P1	P2	P3	PO	Forward	Forward	3K 3L	
	Delayed				30	150	90	W3=Negative value									Reverse	
	86.6% Delayed	-			45	100	105											
	70.7% Forward				40	105	105	W1=Positive value				-	-					CT on side "1" and "2" are swapped.
	70.7%	-			75	315	195	W2=Negative value W3=Positive value W1=0										
	86.6%	-			90	330	210	W ₂ =Negative value W ₃ =Positive value W ₁ =Negative value							2К	1К		
11	100.00%	0	120	240	120	0	240	W ₂ =Negative value W ₃ =Positive value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	Р3	P0	2L Forward	1L Forward	Forward	
	Delayed 86.6%				150	30	270	W ₂ =0 W ₃ =Positive value										
	Delayed 70.7%				165	45	285	W1=Negative value W2=Positive value W3=Positive value										
	Forward 70.7%				315	195	75	W1=Positive value W2=Positive value W3=Negative value										1 2 3 0
	Forward 86.6%				330	210	90	W ₁ =Positive value W ₂ =0 W ₃ =Negative value										
12	100.00%	0	120	240	0	240	120	W ₁ =Positive value W ₂ =Negative value W ₃ =Negative value	V _{1N} =V _{2N} =V _{3N}	$I_1 = I_2 = I_3$	Р1	P2	Р3	Р0	Forward	3K 3L Forward	2K 2L Forward	2L 3K 3L
	Delayed 86.6%	1			30	270	150	W ₁ =Positive value W ₂ =Negative value W ₂ =0										
	Delayed 70.7%				45	285	165	W ₁ =Positive value W ₂ =Negative value	+									

Disp	ay exar	nple	e (Co	onne	ectio	on e	xam	ple for th	ree-phase 4	4-wire)]	indicat	es imp	roper connection
*	ne snade	d are	as m	the ta		are at At equi	libriun	n load(V _{1N} =V _{2N=}	V_{3N} , $I_{1=}I_2=I_3$)	Also, the broke	n ur	nes	in tr	ie c	onnecu	On diagi Cor	nnection	the improper connections.
No.	Power factor (input)		Pha	ase ang	le disp	olay		Electric power display	Voltage display	Current display		Vol	tage			Current	1	Wiring
	(input)	∠V _{1N}	∠V _{2N}	∠V _{3N}	$\angle I_1$	∠I₂	∠I ₃	W ₁ W ₂ W ₃	V _{1N} V _{2N} V _{3N}	I ₁ I ₂ I ₃	1	2	3	0	CT (side"1"	CT (side"2"	CT (side"3"	CT on side "1" and "3" are swapped
	Forward 70.7%				195	75	315	W ₂ =Positive value W ₃ =Positive value										
	Forward 86.6%				210	90	330	W ₁ =Negative value W ₂ =Positive value										
13	100.00%	0	120	240	240	120	0	W ₃ =0 W ₁ =Negative value W ₂ =Positive value W ₃ =Negative value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	P3	P0	3K 3L Forward	Forward	1K 1L Forward	
	Delayed 86.6%				270	150	30	W ₁ =0 W ₂ =Positive value W ₃ =Negative value										
	Delayed 70.7%				285	165	45	W ₁ =Positive value W ₂ =Positive value										
	Forward 70.7%				15	315	75	W ₃ =Negative value W ₁ =Positive value W ₂ =Positive value W ₂ =Positive value										Connection between P1 and P2 are reversed. And connection of CT on side "1" is reversed.
	Forward 86.6%				30	330	90	W1=Positive value W2=0										1 2 3 0 K 1 1 1 1 1 1 1 1 1 1 1 1 1
14	100.00%	0	240	120	60	0	120	W ₃ =Positive value W ₁ =Positive value W ₂ =Negative value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P2	P1	P3	P0	1K 1L Peverse	Forward	Forward	
	Delayed 86.6%	-			90	30	150	W ₃ =Positive value W ₁ =0 W ₂ =Negative value W ₃ =Positive value							Neverse			
	Delayed 70.7%	1			105	45	165	W1=Negative value W2=Negative value										
	Forward				125	75	105	W ₃ =Positive value W ₁ =Negative value										Connection between P2 and P3 are reversed. And connection of CT
	70.7% Forward	-			150	90	210	W ₂ =Negative value W ₁ =Negative value W ₂ =Negative value										on side "1" is reversed.
15	100.00%	0	240	120	180	120	240	W ₃ =0 W ₁ =Negative value W ₂ =Negative value	V _{1N} =V _{2N} =V _{3N}	I1=I2=I3	P1	P3	P2	P0	1K 1L	Forward	Forward	
	Delayed	-			210	150	270	W ₃ =Negative value W ₁ =Negative value W ₂ =0							Reverse			
	Delayed	-			225	165	285	W ₃ =Negative value W ₁ =Negative value W ₂ =Positive value										
	Forward				255	195	315	W ₃ =Negative value W ₁ =Negative value W ₂ =Positive value										Connection between P1 and P3 are reversed. And connection of CT
	Forward	-			270	210	330	W ₃ =Negative value W ₁ =0 W ₂ =Positive value										on side "1" is reversed.
16	100.00%	0	240	120	300	240	0	W ₃ =Negative value W ₁ =Positive value W ₂ =Positive value	V _{1N} =V _{2N} =V _{3N}	I ₁ =I ₂ =I ₃	P3	P2	P1	PO	1K 1L	Forward	Forward	
	Delayed	-			330	270	30	W ₃ =Negative value W ₁ =Positive value W ₂ =Positive value							Reverse			
	Delayed	-			345	285	45	W ₃ =0 W ₁ =Positive value W ₂ =Positive value										
	Forward 70.7%				315	255	15	W ₃ =Positive value										Connection between P1 and P0 are reversed. And connection of CT on side "1" is reversed
	Forward 86.6%	-			330	270	30	W1=Positive										
17	100.00%	0	330	30	0	300	60	value W2=Positive value	$V_{1N} < V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	PO	P2	Р3	P1	1K 1L Reverse	Forward	Forward	
	Delayed 86.6%				30	330	90	W3=Positive value										
	Delayed 70.7%	-			45	345	105											
	Forward 70.7%				165	105	225											Connection between P2 and P0 are reversed. And connection of CT on side "1" is reversed.
	Forward 86.6%				180	120	240	W1=Negative										
18	100.00%	0	330	300	210	150	270	value W2=Negative value	$V_{1N} = V_{3N} > V_{2N}$	$I_1 = I_2 = I_3$	Р1	РО	Р3	P2	1K 1L Reverse	Forward	Forward	
	Delayed 86.6%				240	180	300	value										
	Delayed 70.7%				255	195	315											
	Forward 70.7%				105	45	165											Connection between P3 and P0 are reversed. And connection of CT on side "1" is reversed.
	Forward 86.6%				120	60	180	W1=Negative										
19	100.00%	0	60	30	150	90	210	value W2=Positive value W3=Nocotive	$V_{1N} = V_{2N} > V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	PO	P3	1K 1L Reverse	Forward	Forward	
	Delayed 86.6%	1			180	120	240	value										
	Delayed 70.7%	-			195	135	255											

C	Displ	ay exar	nple	e (Co	onne	ectio	on e	xam	ple for th	ree-phase 4	4-wire)					I	ndicat	es imp	roper connection
	*	Power				ADIE 2	At equi	librium	n load(V _{1N} =V _{2N=}	V_{3N} , $I_{1=}I_2=I_3$)	Also, the broke		les		le c	onnecti	Cor	nection	
	No.	factor (input)		Pha	ise ang	le disp	olay		Electric power display	Voltage display	Current display		Volt	tage	_	СТ	Current	ст	Wiring
		Forward	∠V _{1N}	∠V _{2N}	∠V _{3N}	∠I ₁	∠l ₂	∠l ₃	W1 W2 W3 W1=Negative value W2=Negative value	V _{1N} V _{2N} V _{3N}	l ₁ l ₂ l ₃	1	2	3	0	(side"1"	(side"2"	(side"3"	Connection between P1 and P2 are reversed. And connection of CT
	-	70.7% Forward	-			210	155		W ₃ =Positive value W ₁ =Negative value										on side "2" is reversed.
		86.6%	-			210	150	90	W2=0 W3=Positive value W1=Negative value								2К		
	20	100.00%	0	240	120	240	180	120	W ₂ =Positive value W ₃ =Positive value W ₁ =0	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P2	P1	Р3	P0	Forward	2L Reverse	Forward	
		Delayed 86.6%	-			270	210	150	W ₂ =Positive value W ₃ =Positive value										
		Delayed 70.7%				285	225	165	W ₁ =Positive value W ₂ =Positive value W ₃ =Positive value										
		Forward 70.7%				315	255	195	W ₁ =Positive value W ₂ =Positive value W ₃ =Positive value										are reversed. And connection of CT on side "2" is reversed.
		Forward 86.6%				330	270	210	W ₁ =Positive value W ₂ =Positive value W ₃ =0										
	21	100.00%	o	240	120	0	300	240	W ₁ =Positive value W ₂ =Positive value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P3	P2	Р0	Forward	2K 2L Poverse	Forward	
		Delayed 86.6%				30	330	270	W ₁ =Positive value W ₂ =0								Neverse		
	·	Delayed				45	345	285	W ₃ =Negative value W ₁ =Positive value W ₂ =Negative value										U U V V V V V V V V V V V V V V V V V V
		Forward				75	15	315	W ₃ =Negative value W ₁ =Positive value W ₂ =Negative value										Connection between P1 and P3 are reversed. And connection of CT
		Forward	-				20	220	W ₃ =Negative value W ₁ =0										on side "2" is reversed.
		86.6%				90	30	330	W ₂ =Negative value W ₃ =Negative value W ₁ =Negative value								2K		
	22	100.00%	0	240	120	120	60	0	W ₂ =Negative value W ₃ =Negative value W ₁ =Negative value	V _{1N} =V _{2N} =V _{3N}	I ₁ =I ₂ =I ₃	P3	P2	P1	PO	Forward	2L Reverse	Forward	
	-	86.6%	-			150	90	30	W ₂ =Negative value W ₃ =0										
		Delayed 70.7%				165	105	45	W ₂ =Negative value W ₃ =Positive value										
		Forward 70.7%				135	75	15											are reversed. And connection of CT on side "2" is reversed. $1 \ 2 \ 3 \ 0$
		Forward 86.6%				150	90	30	W1=Negative										
	23	100.00%	o	330	30	180	120	60	value W2=Negative value	$V_{1N} < V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	PO	P2	Р3	P1	Forward	2K 2L Reverse	Forward	
	-	Delayed 86.6%				210	150	90	value										
		Delayed 70.7%				225	165	105											
		Forward				345	285	225											Connection between P2 and P0 are reversed. And connection of CT
	-	Forward				0	300	240											on side "2" is reversed.
	24	100.00%	0	330	300	20	220	270	W1=Positive value W2=Positive	V=V>V	I.=I.=I.	D1	PO	D 3	P 2	Forward	2K	Forward	
	24	Delayed		330	300	30	330	270	value W3=Positive value	v1N-v3N / v2N	11-12-13		FU	-3	F2	Forward	Reverse	Forward	
	-	86.6%	-			60	0	300											
		70.7%				75	15	315											Connection between P3 and P0
	-	Forward 70.7%	-			285	225	165	-										are reversed. And connection of CT on side "2" is reversed.
		Forward 86.6%	-			300	240	180	W1=Positive										
	25	100.00%	0	60	30	330	270	210	W2=Negative value W3=Negative	$V_{1N} = V_{2N} > V_{3N}$	$I_1 \!=\! I_2 \!=\! I_3$	P1	P2	P0	P3	Forward	2K 2L Reverse	Forward	
		Delayed 86.6%				0	300	240	value										
		Delayed 70.7%				15	315	255											
F		Forward 70.7%				195	315	255	W ₁ =Negative value W ₂ =Positive value										Connection between P1 and P2 are reversed. And connection of CT on side "3" is reversed
		Forward	-			210	330	270	W ₁ =Negative value W ₂ =0										
	26	100.00%	0	240	120	240	0	300	W ₃ =Negative value W ₁ =Negative value W ₂ =Negative value	V _{1N} =V _{2N} =V _{3N}	I ₁ =I ₂ =I ₃	P2	P1	Р3	PO	Forward	Forward	3K 3L	
		Delayed				270	30	330	W ₃ =Negative value W ₁ =0 W ₂ =Negative value									Reverse	U ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓
		86.6% Delayed	-			210	50	330	W ₃ =Negative value W ₁ =Positive value										
		70.7%				285	45	345	w ₂ =Negative value W ₃ =Negative value										▎▕▕▕▕▕└ं╯╧╰ど──╈

Disp * T	l ay exa i The shade	nple d are	e (Co as in	onne the ta	ectio	on e are af	xam fecte	ple for th	ree-phase 4 er connection.	<mark>1-wire)</mark> Also, the broke	n lir	nes	in tł	ne c] onnecti	Indicat on diag	es imp ram are	roper connection the improper connections
	Power				Å	At equi	libriun	n load(V _{1N} =V _{2N=}	$V_{3N} I_{1=} I_2 = I_3)$							Co	nnection	
No.	factor		Pha	ise ang	le disp	olay		Electric power display	Voltage display	Current display		Vol	tage			Current		Wiring
	(input)	$\angle V_{1N}$	∠V _{2N}	∠V _{3N}	$\angle I_1$	$\angle I_2$	$\angle I_3$	W ₁ W ₂ W ₃	V _{1N} V _{2N} V _{3N}	I_1 I_2 I_3	1	2	3	0	CT (side"1"	CT (side"2"	CT (side"3"	wining
	Forward 70.7%				315	75	15	W ₁ =Positive value W ₂ =Negative value W ₃ =Negative value										Connection between P2 and P3 are reversed. And connection of CT on side "3" is reversed.
	Forward 86.6%				330	90	30	W ₁ =Positive value W ₂ =Negative value W ₃ =0										
27	100.00%	0	240	120	0	120	60	W ₁ =Positive value W ₂ =Negative value W ₃ =Positive value	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P1	P3	P2	P0	Forward	Forward	3K 3L Reverse	
	Delayed 86.6%				30	150	90	W ₁ =Positive value W ₂ =0 W ₃ =Positive value										
	Delayed 70.7%				45	165	105	W ₂ =Positive value W ₃ =Positive value W ₁ =Positive value										Connection between P1 and P3
	Forward 70.7%				75	195	135	W ₂ =Positive value W ₃ =Positive value W ₁ =0										are reversed. And connection of CT on side "3" is reversed.
	86.6%				90	210	150	W ₂ =Positive value W ₃ =Positive value W ₁ =Negative value									3K	
28	Delayed	U	240	120	120	240	180	W ₂ =Positive value W ₃ =Positive value W ₁ =Negative value	V _{1N} =V _{2N} =V _{3N}	I ₁ =I ₂ =I ₃	P3	P2	PI	PU	Forward	Forward	Reverse	K 3K 3L 3L 3L
	86.6% Delayed				165	285	210	W ₂ =Positive value W ₃ =0 W ₁ =Negative value W ₂ =Positive value										
	70.7% Forward 70.7%				135	255	195	W ₃ =Negative value										Connection between P1 and P0 are reversed. And connection of CT
	Forward 86.6%				150	270	210	W1=Negative										on side 3 is reversed. $1 \xrightarrow{2} 3 \xrightarrow{3} 0$ $1 \xrightarrow{1} \xrightarrow{1} \xrightarrow{1} \xrightarrow{1} \xrightarrow{1} \xrightarrow{1} \xrightarrow{1} 1$
29	100.00%	0	330	30	180	300	240	value W2=Positive value	$V_{1N} < V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P0	P2	P3	P1	Forward	Forward	3K 3L Reverse	
	Delayed 86.6%				210	330	270	value										
	Delayed 70.7%				225	345	285											
	Forward 70.7%				345	105	45											Connection between P2 and P0 are reversed. And connection of CT on side "3" is reversed.
	Forward 86.6%				0	120	60	W1=Positive value									24	
30	100.00%	0	330	300	30	150	90	W2=Negative value W3=Negative value	$V_{1N} = V_{3N} > V_{2N}$	$I_1 = I_2 = I_3$	P1	P0	Р3	P2	Forward	Forward	3L Reverse	
	Belayed 86.6%				60	180	120											
	70.7%				75	195	135											Connection between P3 and P0
	70.7% Forward				300	45 60	345											on side "3" is reversed.
31	86.6%	0	60	30	330	90	30	W1=Positive value W2=Positive	V _{1N} =V _{2N} >V _{3N}	I ₁ =I ₂ =I ₃	P1	P2	PO	P3	Forward	Forward	3K 3L	
	Delayed				0	120	60	W3=Positive value									Reverse	
	Delayed 70.7%				15	135	75											

Dis	splay	y exar	nple	e (Co	onne	ectio	on e	xam	ple f	or th	ree-	pha	ise 4	4-w	ire)	volco			;+h			Indicat	es imp	roper connection
	* me	snaue		as 111		4 שוטג 4	t equi	libriun	n load(V	1N=V2N=	V _{3N} , I ₁₌	$I_2 = I_3$	1011.	AISU,	the t	JIOKE		les		le c	onnecti	Co	nnection	the improper connections.
No	.	Power factor		Pha	ise ang	le disp	olay		Electric	power	Volta	ge dis	play	Curi	rent dis	splay		Vol	tage			Current		
	((input)	∠V _{1N}	∠V _{2N}	∠V _{3N}	$\angle I_1$	∠I₂	∠I ₃	W ₁ V	/ ₂ W ₃	V _{1N}	V_{2N}	V_{3N}	I ₁	I ₂	I ₃	1	2	3	0	CT (side"1"	CT (side"2"	CT (side"3"	Wiring
	F	Forward 70.7%				315	195	75													(side i	(Side 2	(side 5	Connection between P1 and P2 are reversed. And CT on side "1" and "2" are swapped.
	F	Forward 86.6%				330	210	90																1 2 3 0 ====================================
32	2 1	100.00%	0	240	120	0	240	120	W1=V	/2=W3	V1N	=V _{2N} =\	V _{3N}		I1=I2=I	3	P2	P1	Р3	P0	2K 2L Forward	1K 1L Forward	Forward	
		Delayed 86.6%				30	270	150																
	[Delayed 70.7%				45	285	165																Connection between P2 and P3
	F	Forward 70.7%																						are reversed. And CT on side "2" and "3" are swapped.
	F	Forward 86.6%																				ЗК	2K	
	1	100.00%							Same a	s above							P1	P3	P2	P0	Forward	3L Forward	2L Forward	к <u>2L</u> К <u>3K</u> Ц
		86.6%																						
		70.7%																						Connection between P1 and P3
	F	70.7% Forward																						and "3" are swapped.
	1	86.6%							Same a	above							P3	P2	P1	PO	3K 3L	Forward	1K 1L	
		Delayed																			Forward		Forward	K 3K L 3K L 3L V 2F V 3K v 1 − P1
	C	Delayed 70.7%																						U U U P2 U V S V P3 U V S V P2
	F	Forward 70.7%				75	315	195																Connection between P2 and P3 are reversed. And CT on side "1" and "2" are swapped.
	F	Forward 86.6%				90	330	210																
33	3 1	100.00%	0	240	120	120	0	240	W ₁ =V	/2=W3	V _{1N}	=V _{2N} =\	V _{3N}		I ₁ =I ₂ =I	3	P1	P3	P2	P0	2K 2L Forward	1K 1L Forward	Forward	
		Delayed 86.6%				150	30	270	-															
		Delayed 70.7%				165	45	285																Connection between P1 and P3
		70.7%																						are reversed. And CT on side "2" and "3" are swapped.
		86.6%							Come -	above							DO	20	D1	DO.	Former	3K	2K	
	1	Delayed							same a	anove							P3	72	PT	PU	rorward	Forward	Forward	
	C	86.6% Delayed																						
	F	Forward 70.7%																						Connection between P1 and P2 are reversed. And CT on side "1" and "3" are swapped
	F	Forward 86.6%																						
	1	100.00%							Same a	s above							P2	Р1	P3	P0	3K 3L Forward	Forward	1K 1L Forward	
	C	Delayed 86.6%																						
	C	Delayed 70.7%																						

[Displ * T	ay exai	mple d_are	e (Co as in	onne the ta	ectio	on e are af	xam	ple for th	ree-phase 4 er connection.	<mark>4-wire</mark>) <u>Also,</u> the broke	en lir	nes	in tł	<u>ne</u> c] <u>on</u> necti	Indicat	es imp _{ram} are	roper connection the improper connections.
		Power				A	At equi	librium	load(V _{1N} =V _{2N=}	$V_{3N} I_{1=} I_2 = I_3$						n	Сог	nnection	
	No.	factor (input)		Pha	ise ang	le disp	olay		Electric power display	Voltage display	Current display		Vol	tage		СТ	Current	СТ	Wiring
			∠V _{1N}	∠V _{2N}	∠V _{3N}	∠I ₁	∠I ₂	∠I ₃	W ₁ W ₂ W ₃	V _{1N} V _{2N} V _{3N}	I ₁ I ₂ I ₃	1	2	3	0	(side"1"	(side"2"	(side"3"	Connection between P1 and P3
		Forward 70.7%				195	75	315											are reversed. And CT on side "1" and "2" are swapped.
		Forward 86.6%				210	90	330											
	34	100.00%	o	240	120	240	120	0	W1=W2=W3	$V_{1N} = V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	P3	P2	Р1	P0	2K 2L Forward	1K 1L Forward	Forward	
		Delayed 86.6%				270	150	30											
		Delayed 70.7%				285	165	45											
		Forward 70.7%																	Connection between P1 and P2 are reversed. And CT on side "2" and "3" are swapped.
		Forward 86.6%																	
		100.00%							Same as above			P2	P1	Р3	Р0	Forward	3K 3L	2K 2L	
		Delayed															Forward	Forward	
		Delayed	1																
		Forward																	Connection between P2 and P3 are reversed. And CT on side "1"
		Forward																	and "3" are swapped.
		100.00%							Same as above			D1	P3	P 2	PO	3K 3L	Forward	1K 11	
		Delaved							Same as above				13	12	10	Forward	Torward	Forward	
		86.6% Delayed	-																
		70.7%							W1=Negative value										Connection between P1 and P0
		70.7%				255	135	15	W ₂ =Negative value W ₃ =Positive value W ₁ =0										are reversed. And CT on side "1" and "2" are swapped.
		86.6%	_			270	150	30	W ₂ =Negative value W ₃ =Positive value							2K	1K		Ц К 2К
	35	100.00%	0	330	30	300	180	60	W Positivo valuo	$V_{1N} < V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	PO	P2	Р3	P1	2L Forward	1L Forward	Forward	
		Delayed 86.6%				330	210	90	W ₂ =Negative value W ₃ =Positive value										
		Delayed 70.7%				345	225	105											
		Forward 70.7%				105	345	225	W1=Negative										are reversed. And CT on side "1" and "2" are swapped.
		Forward 86.6%				120	0	240	W2=Positive value W3=Positive										
	36	100.00%	0	330	300	150	30	270	value	$V_{1N} = V_{3N} > V_{2N}$	$I_1 = I_2 = I_3$	P1	PO	Р3	P2	2K 2L Forward	1K 1L Forward	Forward	
		Delayed 86.6%				180	60	300	W ₁ =Negative value W ₂ =0 W ₃ =Positive value										
		Delayed 70.7%				195	75	315	W ₁ =Negative value W ₂ =Negative value W ₃ =Positive value										
		Forward 70.7%				45	285	165	W1=Positive value W2=Negative										Connection between P3 and P0 are reversed. And CT on side "1" and "2" are swapped.
		Forward 86.6%	1			60	300	180	value W3=Negative value										1 2 3 0 <u>K</u> L L L L L L L L L L L L L
	37	100.00%	o	60	30	90	330	210	W1=0 W2=0 W3=Negative value	$V_{1N} = V_{2N} > V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	PO	Р3	2K 2L Forward	1K 1L Forward	Forward	
		Delayed 86.6%				120	0	240	W1=Negative value							, ci ward	, or ward		
		Delayed 70.7%	1			135	15	255	w2=Positive value W3=Negative value										
ŀ		Forward 70.7%				135	15	255	W1=Negative value										Connection between P1 and P0 are reversed. And CT on side "2" and "3" are support
		Forward				150	30	270	W2=Positive value W3=Negative										
	38	100.00%	0	330	30	180	60	300	Value W1=Negative value W2=0	V _{1N} <v<sub>2N=V_{3N}</v<sub>	$I_1 = I_2 = I_3$	PO	P2	P3	P1	Forward	3K 3L	2K 2L	
		Delayed				210	90	330	W3=0 W1=Negative value		-						Forward	Forward	K
		86.6% Delayed				225	105	345	W2=Negative value W3=Positive										
		70.7%				225	105	545	value										

					A	At equi	libriun	n load(V _{1N} =V	2 _{N=} V	I_{3N} , $I_{1=}I_2 = I_3$)							Co	nnection	
No.	Power factor		Pha	ise ang	le disp	olay		Electric pov	ver	Voltage display	Current display		Vol	tage			Current		
	(input)	∠V _{1N}	∠V _{2N}	∠V _{3N}	$\angle I_1$	$\angle I_2$	$\angle I_3$	W ₁ W ₂ V	N3	V _{1N} V _{2N} V _{3N}	I ₁ I ₂ I ₃	1	2	3	0	CT (side"1"	CT (side"2"	CT (side"3"	Wiring
	Forward 70.7%				345	225	105	W ₁ =Positive val W ₂ =Negative va W ₃ =Negative va	lue Iue Iue										Connection between P2 and P0 are reversed. And CT on side "2" and "3" are swapped.
	Forward 86.6%				0	240	120	W ₁ =Positive val W ₂ =0 W ₃ =Negative va	lue Ilue								24	214	
39	100.00%	0	330	300	30	270	150	W1=Positiv	e	$V_{1N} = V_{3N} > V_{2N}$	$I_1 = I_2 = I_3$	P1	P0	Р3	P2	Forward	3K 3L Forward	2K 2L Forward	
	Delayed 86.6%	_			60	300	180	value W2=Positiv value W3=Negativ	re ve										
	Delayed 70.7%				75	315	195	value											
	Forward 70.7%				285	165	45	W1=Positiv	е										Connection between P3 and P0 are reversed. And CT on side "2" and "3" are swapped.
	Forward 86.6%				300	180	60	W2=Negativ value W3=Positiv	ve re								24	214	
40	100.00%	0	60	30	330	210	90	value		$V_{1N} = V_{2N} > V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	PO	P3	Forward	3K 3L Forward	2K 2L Forward	
	Delayed 86.6%	-			0	240	120	W ₁ =Positive va W ₂ =Negative va W ₃ =0	lue										
	Delayed 70.7%				15	255	135	W ₁ =Positive va W ₂ =Negative va W ₃ =Negative va	lue lue										Connection between P1 and P0
	Forward 70.7%	_			15	255	135	W1=Positiv value	e										are reversed. And CT on side "1" and "3" are swapped.
	Forward 86.6%				30	270	150	W2=Positiv value W3=Negativ	ve ve							ЗК		1K	
41	100.00%	0	330	30	60	300	180	W ₁ =0	_	$V_{1N} < V_{2N} = V_{3N}$	$I_1 = I_2 = I_3$	PO	P2	Р3	P1	3L Forward	Forward	1L Forward	
	86.6%	-			90	330	210	W ₂ =Positive va W ₃ =Negative va W ₁ =Negative va	lue lue lue										
	70.7% Forward				105	345	225	W2=Positive va W3=Negative va W1=Negativ	lue Ilue /e										Connection between P2 and P0
	70.7% Forward	-			225	105	0	value W2=Negativ value W3=Positiv	ve re										and "3" are swapped. 1^2 3 0 $\pm \frac{1}{2}$ $\frac{1}{2}$
42	86.6%	0	330	300	270	150	30	value W1=0 W2=Negative va	alue	V _{1N} =V _{3N} >V _{2N}	I ₁ =I ₂ =I ₃	P1	P0	P3	P2	3K 3L	Forward	1K 1L	
	Delayed	-			300	180	60	W3=0 W1=Positiv value	e							Forward		Forward	
	Delayed 70.7%	-			315	195	75	W2=Negativ value W3=Negativ value	/e /e										
	Forward 70.7%				165	45	285	W ₁ =Negative va W ₂ =Positive va	lue										Connection between P3 and P0 are reversed. And CT on side "1" and "3" are swapped.
	Forward 86.6%				180	60	300	W ₁ =Negative va W ₂ =Positive va W ₃ =0	lue										
43	100.00%	0	60	30	210	90	330	W1=Negativ	/e	$V_{1N} = V_{2N} > V_{3N}$	$I_1 = I_2 = I_3$	P1	P2	Р0	P3	3K 3L Forward	Forward	1K 1L Forward	
	Delayed 86.6%				240	120	0	value W2=Positiv value W3=Positiv	e										
	Delayed				255	135	15	value	~										

Warranty

Before using the product, please confirm the following product warranty details. If you have any questions or if there is a problem, contact our sales representative near you. (See back cover).

• Gratis warranty period and Gratis warranty extent

During the gratis warranty period, if the product has a failure or defect (hereinafter collectively referred to as "failure") that is the responsibility of our company, we will replace the product free of charge through the store where you purchased it or our service company.

However, if on-site repairs are required in Japan or overseas, the actual expenses required for dispatching engineers will be charged.

[Gratis warranty period]

The gratis warranty period for the product shall be 12 months from the date of purchase or delivery to the location designated by the customer.

However, we will limit the gratis warranty period to 18 months from the date of manufacture, with a maximum distribution period of 6 months after shipment of our products. In addition, the gratis warranty period for repaired products shall not exceed the gratis warranty period before repair.

[Gratis warranty extent]

- In principle, the customer is requested to perform the primary failure diagnosis. However, at the customer's request, the Company or the Company's service network can perform this work for a fee. In this case, if the cause of the failure is our company, the repair will be free of charge.
- (2) This is limited to cases where the usage conditions, usage method, usage environment, etc., are in a normal state in accordance with the conditions and precautions described in the instruction manual, the caution label on the product itself, etc.
- (3) Even within the gratis warranty period, repairs will be charged in the following cases. ①Failure caused by inappropriate storage or handling, carelessness, or negligence by the customer, or failure caused by the customer's hardware, selection, or other design details.
 - [©]Failure caused by the customer modifying the product without our consent.
 - ^③Failure that could have been avoided if the customer's device had been provided with a safety device based on legal regulations or a function, structure, etc. that should be provided according to the conventional wisdom of the industry, when our products are incorporated into your equipment and used.
 - ④Failure that could have been prevented if the maintenance described in the instruction manual, etc., had been performed.
 - ⑤Failure due to external factors such as fire, abnormal voltage, etc. and natural disasters such as earthquakes, lightning, wind and flood damage.
 - ©Failure due to reasons unforeseeable by the level of science and technology at the time of shipment from our company.
 - ⑦Any other failure that is beyond our responsibility or that the customer acknowledges is beyond our responsibility.

Note that the warranty here means the warranty for each delivered item, and we do not offer any free warranty for damages caused by failure of the delivered product.

Exclusion of warranty liability for opportunity loss, secondary loss, etc.

Regardless of whether it is within or outside the gratis warranty period, we will not be responsible for the following.

- (1) Failure caused by reasons not attributable to the company.
- (2) Opportunity loss and loss of profits due to failure of our products.
- (3) Damages, secondary damages, compensation for accidents, and damages to products other than our products caused by special circumstances, whether or not we have foreseen them.
- (4) Compensation for secondary costs such as replacement work by the customer, on-site work accompanying replacement, readjustment of on-site machinery and equipment, start-up test run, and other work.

Warranty

- Product application
- (1) For use of products described in this manual, they shall be used for a purpose which shall not lead to a material accident even when a failure or malfunction of the products occurs, and a backup or fail-safe function shall be implemented systematically at external of the device in the event of a failure or malfunction.
- (2) The products listed in this catalog are designed and manufactured as general-purpose products for general industrial use. Therefore, use for special applications such as the following devices and systems is exempt from application.
 - ①Applications that have a large impact on the public, such as nuclear power plants of electric power companies and other power plants.
 - ②Applications that require our company to build a special quality assurance system, such as railway companies and government offices.
 - ③Aerospace, medical, railroad, combustion/fuel systems, passenger vehicles, manned transport equipment, recreational equipment, safety equipment, servers and air conditioning equipment for cooling servers, etc., applications that are expected to have a large impact on life, human body and property.

In the unlikely event that the product is used, we will not be held responsible for the quality, performance, or safety (including, but not limited to, default liability, defect liability, quality assurance liability, tort liability, and product liability) of the product described in this catalog.

However, the product may be used for such purposes if the customer acknowledges that it should be used for limited purpose only, a backed up or fail-safe function by equipment and agrees not to require special quality. Please contact our sales office for details.

Others

We do not accept any compensation for damages caused by reprinting or duplicating part or all of the contents of this document.

Although every effort has been made to keep the contents of this manual up to date with software and hardware revisions, but in some cases synchronization may be unavoidable.
Trademarks of other companies

- MODBUS is a trademark of Schneider Electric USA Inc.
- Other company and product names herein are trademarks or registered trademarks of their respective owners.
- In the text, trademark symbols such as "TM" and "®" may not be written.

About license information for open-source software

This instrument contains open-source software programs (OSS) subject to the following license information. • The 3-Clause BSD License

URL:http://opensource.org/licenses/BSD-3-Clause

The instrument uses the following open-source software programs (OSS).

MSP430 Core Libraries

This product uses MSP430 Core Libraries, which are BSD licensed. The copyright notice and permission notice for the MSP430 Core Libraries are provided below: BSD-3-Clause

Copyright (C) 2010 Texas Instruments Incorporated - http://www.ti.com/

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of Texas Instruments Incorporated nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Energy Measuring Unit

Please refer to our website for service network. Our website address: https://www.mitsubishielectric.com/fa/

MITSUBISHI ELECTRIC CORPORATION HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN