


GX Configurator-ST Version 1.08J

Operating Manual

mitsubishi



MELSOFT
Integrated FA Software

SW1D5C-STPB-E

GX Configurator ST

© Mitsubishi Electric Corporation © 2003 - 2012, all rights reserved

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: May 2012

INTRODUCTION

Thank you for choosing the Mitsubishi MELSOFT Series Integrated FA software.
Read this manual and make sure you understand the functions and performance of MELSOFT series thoroughly in advance to ensure correct use.

CONTENTS

1 Introduction	6
1.1 Safety Precautions	7
1.2 Documentation layout	8
1.3 Terms and Abbreviations.....	14
1.4 What's new in version 1.08J?	19
1.5 Notes for upgrading users	20
2 Overview	22
2.1 Features	22
2.2 How do I ... ?.....	27
3 System Configuration	29
3.1 System Configuration.....	29
3.2 Operating Environment	30
4 Function list	32
4.1 Function list	32
4.2 Menu list	33
5 Operation Procedures	37
5.1 Precautions when using GX Configurator-ST.....	37
5.2 Edit mode operation procedure.....	38
5.3 Diagnosis mode operation procedure	38
6 Installation and uninstallation	40
6.1 Installation.....	40
6.1.1 Installation procedure	40
6.1.2 Installing GX Configurator-ST	41
6.2 Uninstallation.....	47
6.3 Starting GX Configurator-ST	49
6.4 Exiting GX Configurator-ST.....	51
7 Screen layout and display switching	53
7.1 Screen layout	53
7.2 Display switching and window rearranging operations	54
7.3 Details of toolbar.....	55
7.4 Details of module configuration window	56
7.4.1 Details of rack display	58
7.4.2 Details of module list	59

7.4.3 Details of wizard area	63
7.4.4 Details of information area	64

8 Project creation	67
---------------------------	-----------

8.1 Creating a new project.....	68
8.2 Opening an existing project.....	70
8.3 Closing the project.....	71
8.4 Saving the project	72
8.4.1 Save	72
8.4.2 Save as	73
8.5 Verifying the projects.....	74
8.5.1 n:n verify	74
8.5.2 Verify result	77
8.5.3 1:n verify	79
8.6 Printing the project data.....	82
8.6.1 Setting up the printer	86
8.6.2 Setting a page layout	88
8.6.3 Previewing a print image	92
8.6.4 Print Examples	94

9 Editing the project	96
------------------------------	-----------

9.1 Adding the module.....	96
9.1.1 Adding the module with the "Add module" screen	96
9.1.2 Adding the module with the "Wizard area"	100
9.2 Deleting a module	107
9.3 Deleting all modules	108
9.4 Copying the module information.....	109
9.5 Undo	111
9.6 Redo	112
9.7 Rearranging the modules	112
9.7.1 Rearranging the modules with the Rearrange dialog	112
9.7.2 Rearranging the modules with drag and drop	114
9.8 Parameter setting.....	117
9.8.1 "Parameter setting" screen displaying operation	118
9.8.2 Setting the parameters	119
9.8.3 Uploading/downloading the parameters or verifying the parameters being edited and parameters within module ..	121
9.8.4 Checking the parameters for errors	124
9.9 Option setting.....	126
9.10 Power distribution check.....	130
9.11 Change head module type.....	132
9.12 Change PROFIBUS-DP head module protocol version	134

10 Downloading and uploading the parameters	137
--	------------

10.1 Transfer setup.....	138
10.2 Get system	141
10.3 Get input / output data settings (PROFIBUS-DP only)	143
10.4 Parameter block write.....	144
10.5 Offset/Gain setting of intelligent function modules.....	146

11 Monitor, Test	149
-------------------------	------------

11.1 System Monitor	149
11.2 Module detail information	154
11.3 Input/Output monitor.....	160
11.4 Forced output test.....	165
11.5 Master station data communication monitor.....	169
11.5.1 Master station data communication monitor	169
11.5.2 Saving the communication data	174
11.6 PROFIBUS-DP Network Parameter Monitor (PROFIBUS DP only).....	175
11.6.1 PROFIBUS-DP Network parameter monitor	175
11.6.2 Saving the PROFIBUS-DP network parameter data	177

12 Online module operation	179
-----------------------------------	------------

12.1 Reset head module	179
12.2 Online module change.....	180
12.2.1 Precautions for online module change	180
12.2.2 Procedures for online module change	182
12.2.3 Online module change from GX Configurator-ST	183

13 Reference	190
---------------------	------------

13.1 Key operations list	190
13.2 Error messages	191
13.2.1 Communication errors	191
13.2.2 Diagnostic errors	193
13.2.3 File errors	196
13.2.4 Forced output / offset and gain errors	197
13.2.5 Module addition and copying errors	200
13.2.6 Module configuration errors	204
13.2.7 Module deletion errors	206
13.2.8 Module parameter errors	207
13.2.9 Module selection errors	209
13.2.10 Module verify (compare) errors	210
13.2.11 Online change errors	211
13.2.12 Printing errors	213
13.2.13 System errors	214

Index	219
--------------	------------


1 Introduction

GX Configurator-ST is used for the configuration and diagnosis of SLICE systems.

MELSEC-ST systems consist of a head module (ST1H-PB for PROFIBUS-DP systems or ST1H-BT for CC-Link systems) and a number of power supply or I/O modules assembled in a rack.

These systems provide an easy and modular way to add I/O to a PROFIBUS-DP or CC-Link system, without having to install separate wiring to many separate I/O modules. The I/O from each module is grouped into individual data input/output areas for transmission to/from the network master station.

GX Configurator-ST connects to the communication port of the ST1H-PB or ST1H-BT head module using an appropriate programming cable. The head module will independently act as a slave station on a PROFIBUS-DP or CC-Link network.




1.1 Safety Precautions

● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly. The precautions given in this manual are concerned with this product. Refer to the user's manual of the network system to use for a description of the network system safety precautions. These SAFETY PRECAUTIONS classify the safety precautions into two categories: "DANGER" and "CAUTION".



Depending on circumstances, procedures indicated by  CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.


[Design Instructions]

 DANGER
<ul style="list-style-type: none"> • For data change and status control made to the MELSEC-ST system which is running from a Personal computer, configure the interlock circuit externally so that the system safety is ensured. The action to be taken for the system at the occurrence of communication errors caused by such as loose cable connection must be determined for online operation of MELSEC-ST system from Personal computers.

 CAUTION
<ul style="list-style-type: none"> • Be sure to read the manual carefully and exercise an appropriate amount of caution connecting to MELSEC-ST system and performing online operations (head module resetting, forced output test, etc.) while the personal computer is operating. • When replacing the module online, make sure to observe the procedure specified for the module. For I/O module, refer to the chapter of online module change in the head module user's manual; for each intelligent function module, refer to the same chapter in the corresponding intelligent function module user's manual.

1.2 Documentation layout

Each topic is divided in sections as shown below.



In addition, there are also the following explanations.

 **HELPFUL OPERATION**

Describes application operation if there are multiple purposes and the basic operation and display/setting data do not provide enough information.



Provides information relevant to that page, e.g. the items you should be careful of and the functions you should know.

The following table lists the symbols used in this manual and their definitions.


Symbol	Description
[]	Represents the menu name of the menu bar. [] → [] indicates a drop-down menu. Example: [File] → [New] menu
()	Represents the tool button on the toolbar corresponding to the drop-down menu. Example: [File] → [Save] menu ()
" "	Represents the item name in the dialog box. Example: "File name"
	Represents a button. Example:  button
<< >>	Represents the tab in the dialog box. Example: <<Verify All Modules>> tab

How to read manual (For CC-Link)

In this manual, remote I/O, remote registers and message transmission areas for CC-Link are represented with Br, Wr, Cr, Bw, Ww, Cw.

(1) Data symbol

<Example : **Cr** Command result area>



Range
In the case of 1-word (16bit) data, this shows the corresponding range.
(0) : Shows 0 bit position.
(7-0) : Shows 0-7 bit range.

Detail data No.

Abbreviated data symbol

For details of data: 1 data No. and abbreviated data symbol, refer to (2) and (3)

(2) Head Module → Master Station

(a) Remote input (RX)

Data symbol	Area name	Unit	Detail data No. notation
Br Br.00 to Br.FF	Bit input area	1 bit / symbol	Hexadecimal

(b) Remote register (RWr)

Data symbol	Area name	Unit	Detail data No. notation
Wr Wr.00 to Wr.33	Word input area	1 word / symbol 	Hexadecimal

(c) Message transmission

Data symbol	Area name	Unit	Detail data No. notation
Cr	Command result area	1 word / symbol 	Decimal

(3) Master station → Head module

(a) Remote output (RY)

Data symbol		Area name	Unit	Detail data No. notation
Bw	Bw.00 to Bw.FF	Bit output area	1 bit / symbol	Hexadecimal

(b) Remote register (RWw)

Data symbol		Area name	Unit	Detail data No. notation
Ww	Ww.00 to Ww.33	Word output area	1 word / symbol 	Hexadecimal

(c) Message transmission


Data symbol		Area name	Unit	Detail data No. notation
Cw		Command execution area	1 word / symbol 	Decimal

How to read manual (For PROFIBUS-DP)

In this manual, remote I/O, remote registers and message transmission areas for PROFIBUS-DP are represented with Br, Wr, Cr, Bw, Ww, Cw.

(1) Data symbol

<Example : **Cr** Command result area>



Range
In the case of 1-word (16bit) data, this shows the corresponding range.
(0) : Shows 0 bit position.
(7-0) : Shows 0-7 bit range.

Detail data No.

Abbreviated data symbol

For details of data:1 data No. and abbreviated data symbol, refer to (2) and (3)

(2) Input send data

Data symbol		Area	Unit	Detail data No. notation
Br	Br.00 to Br.FF	Bit Input Area	1 bit / symbol	Hexadecimal
Er	Er.00 to Er.FF	Error Information Area	1 bit / symbol	Hexadecimal
Mr	Mr.0 to Mr.127	Module Status Area	1 bit / symbol	Decimal
Cr	*1	Command Result Area	1 word / symbol	Decimal
Wr	Wr.00 to Wr.33	Word Input Area	1 word / symbol	Hexadecimal

*1: The detailed area of the command result area uses the following symbols.

Data symbol		Area
Cr.0	Cr.0 (15-8)	Command Execution Result
	Cr.0 (7-0)	Start Slice No. of Execution Target
	Cr.1	Executed Command No.
	Cr.2	Response Data 1
	Cr.3	Response Data 2

(3) Output receive data

Data symbol		Area	Unit	Detail data No. notation
Bw	Bw.00 to Bw.FF	Bit Output Area	1 bit / symbol	Hexadecimal
Ew	Ew.00 to Ew.FF	Error Clear Area	1 bit / symbol	Hexadecimal
Sw	Sw.0 to Sw.7	System Area	1 word / symbol	Decimal
Cw	*1	Command Execution Area	1 word / symbol	Decimal
Ww	Ww.00 to Ww.33	Word Output Area	1 word / symbol	Hexadecimal

*1: Following shows the data symbols and the corresponding detail areas within the command execution area.

Data symbol	Area
Cw.0	Start Slice No. of Execution Target
Cw.1	Command No. to be executed
Cw.2	Argument 1
Cw.3	Argument 2

1.3 Terms and Abbreviations

Unless otherwise specified, this documentation uses the following terms and abbreviations to explain the head module.

Term/Abbreviation	Description
Head module	Generic term for the ST1H-PB MELSEC-ST PROFIBUS-DP head module, ST1H-BT MELSEC-ST CC-Link head module.
PROFIBUS-DP	Abbreviation for PROFIBUS-DP network.
CC-Link	Abbreviation for Control & Communication Link system.
Master module	Abbreviation for the QJ61BT11N used as a master station.
RDMSG	Generic term for G.RDMSG and GP.RDMSG.
Bus refreshing module	Module that distributes external system power and auxiliary power to the head module and slice modules.
Power feeding module	Module that distributes external auxiliary power to slice modules.
Power distribution module	Generic term for the bus refreshing module and power feeding module.
Base module	Generic term for a module that transfers data between the head module and slice modules, and between the slice modules and external devices (including wiring).
Input module	Generic term for modules that handle input data in units of bits.
Output module	Generic term for modules that handle output data in units of bits.
Intelligent function module	Generic term for modules that handle input/output data in units of words.
I/O module	Generic term for input modules and output modules.
Slice module	Generic term for power distribution modules, I/O modules, and intelligent function modules that can be mounted on base modules.
MELSEC-ST system	Generic term for a system that is that is composed of a head module, slice modules, an end plate and end brackets.
External power supply	Generic term for external system power and auxiliary power.
GX Configurator-ST	Generic product name for SWnD5C-STPB-E. ("n" denotes Version 1 or later.)
Configuration software	Software used to set slave parameters for head modules and slice modules in PROFIBUS-DP. (e.g. GX Configurator-DP).

Term definition for CC-Link

The following explains the meanings and definitions of the terms used in this documentation when using CC-Link.

Term/Abbreviation	Description
Cyclic transmission	A communication method by which remote I/O data and remote register data are transferred periodically.
Master station	This station controls the entire data link system. One master station is required for one system.
Local station	A station that has a programmable controller CPU and can communicate with the master station and other local stations.
Remote I/O station	A remote station that can only use bit data. (Input from or output to external devices) (AJ65BTB1-16D, AJ65SBTB1-16D or others).
Remote device station	A remote station that can use both bit and word data. (Input from or output to external devices, analog data conversion) (ST1H-BT, AJ65BT-64AD, AJ65BT-64DAV, AJ65BT-64DAI or others)
Remote station	Generic term for remote I/O stations and remote device stations. Controlled by the master station.
SB	Link special relay (for CC-Link). Bit data that indicate the module operating status and data link status of the master/local station.
SW	Link special register (for CC-Link). Data in units of 16 bits, which indicate the module operating status and data link status of master/local station.
RX	Remote input (for CC-Link). Bit data that are input from remote stations to the master station.
RY	Remote output (for CC-Link). Bit data that are output from the master station to remote stations.
RWr	Remote register (Read area for CC-Link). Data in units of 16 bits, which are input from remote device stations to the master stations.
RWw	Remote register (Write area for CC-Link). Data in units of 16 bits, which are output from the master station to remote device stations.
Remote net Ver. 1 mode	Select this mode when extended cyclic setting is not needed or when the QJ61BT11 is replaced with the QJ61BT11N.
Remote net Ver. 2 mode	Select this mode when creating a new system with extended cyclic setting.
I/O data	Data transferred between the head module and the master station.
Br.n Bit input area	Bit input data of each module. Input data are sent from the head module to the master station through remote input (RX).
Bw.n Bit output area	Bit output data of each module. Output data are received from the master station to the head module through remote output (RY).
Wr.n Word input area	Word (16-bit) input data of an intelligent function module. Input data are sent from the head module to the master station through remote register (RWr).
Ww.n Word output area	Word (16-bit) output data of an intelligent function module. Output data are received from the master station to the head module through remote register (RWw).
Cr.n Command result area	Information that indicates a command result. This information is stored in Setting data (area starting from (D1) + 1) of the RDMSG instruction of the master station.

Term/Abbreviation	Description
Cw.n Command execution area	Information for executing a command. This information is stored in Setting data (area starting from (S2) + 1) of the RDMSG instruction of the master station.
Number of occupied I/O points	The area, which is equivalent to the occupied I/O points, is occupied in Br Bit input area / Bw Bit output area.
Slice No.	The number assigned to every 2 occupied I/O points of each module. The numbers are assigned in ascending order, starting from "0" of the head module. (The maximum value is 127.) This is used for specifying a command execution target.
Slice position No.	The number that shows where the slice module is physically installed. The numbers are assigned in ascending order, starting from "0" of the head module. (The maximum value is 63.) This is used for specifying a command execution target.
Start slice No.	The start slice No. assigned to the head module and slice modules.
Command	Generic term for requests that are executed by the master station for reading each module's operation status, setting intelligent function module command parameters or various controls.
Command parameter	Generic term for parameter set in commands or GX Configurator-ST. All of the parameters set for the head module and slice modules are command parameters.
ST bus cycle time	Processing time for the head module to refresh the input or output status of each slice module.

Term definition for PROFIBUS-DP

The following explains the meanings and definitions of the terms used in this documentation when using PROFIBUS-DP.

Term/Abbreviation	Description
QJ71PB92V	Abbreviation for the QJ71PB92V PROFIBUS-DP master module.
QJ71PB92D	Abbreviation for the QJ71PB92D PROFIBUS-DP interface module.
A1SJ71PB92D	Abbreviation for the A1SJ71PB92D PROFIBUS-DP interface module.
AJ71PB92D	Abbreviation for the AJ71PB92D PROFIBUS-DP interface module.
PROFIBUS-DPV0	A basic version of PROFIBUS-DP. The following functions are executable: <ul style="list-style-type: none"> ▪ I/O data exchange ▪ Diagnostic information notification etc.
PROFIBUS-DPV1	A PROFIBUS-DP version for which the following functions have been added to the basic functionality of PROFIBUS-DPV0 <ul style="list-style-type: none"> ▪ Acyclic communication ▪ Alarm function etc.
PROFIBUS-DPV2	A PROFIBUS-DP version for which the following functions have been added to the PROFIBUS-DPV1 functionality <ul style="list-style-type: none"> ▪ Time stamping etc.
GX Configurator-DP	SWnD5C-PROFID-E type products. ("n" means version 4 or later.)
Master station	Class 1 master station that communicates I/O data with slave stations.
Slave station	A device that exchanges I/O data with a DP-Master (Class 1). (ST1H-PB, etc)
Repeater	Device that connects PROFIBUS-DP segments.
Bus terminator	Terminator that is connected to both ends of each PROFIBUS-DP segment
FDL address	Address assigned to the master station/slave station. The FDL address is set within the range from 0 to 99.
Extended diagnostic information	Diagnostic information specific to each DP-Slave Each of DP-Slaves notifies of it to the DP-Master when an error is detected.
Slave parameter	The slave station parameter (including user parameter) set by the master station. The setting items are described in the GSD file.
GSD file	The electronic file that includes description of the slave station parameter. The file is used when setting slave parameters by configuration software, which is supported by the master station.
Input data	Data sent from the head module to the master station. The data consists of the following areas. <ul style="list-style-type: none"> ▪ Br Bit Input Area (head module version A only) ▪ Information Area <ul style="list-style-type: none"> Er Error Information Area (head module version A only) Mr Module Status Area (head module version A only) Cr Command Result Area (head module version A only) ▪ Wr Word Input Area

Term/Abbreviation	Description
Output data	Data that the head module receives from the master station. The data consists of the following areas. <ul style="list-style-type: none"> ▪ Bw Bit Output Area (head module version A only) ▪ Request Area ▪ Ew Error Clear Area (head module version A only) ▪ Sw System Area (head module version A only) ▪ Cw Command Execution Area (head module version A only) ▪ Ww Word Output Area
I/O data	Data (input data, output data) transferred between the head module and the master station.
Global control	This function enables synchronization command transmission for I/O data from a DP-Master (Class 1) to DP-Slaves.
Br.n Bit input area	Bit input data of each module.
Bw.n Bit output area	Bit output data of each module
Wr.n Word input area	Word (16-bit) input data of an intelligent function module. In the case of analog input module, the digital output data value is stored.
Ww.n Word output area	Word (16-bit) output data of an intelligent function module. In the case of analog output module, the digital setting data value is stored.
Information area	Bit/Word input data for checking each module status and command execution results.
Request area	Bit/Word output data for requesting each module to clear errors/to execute commands.
Number of occupied I/O points	The area, that is equivalent to the occupied I/O points, is occupied in Br Bit Input Area/ Bw Bit Output Area.
Slice No.	No. assigned to every 2 occupied I/O points of each module. This numbering starts by assigning "0" to the head module and then proceeds in ascending order. (The maximum value No. is 127). The No. is used for specifying the execution target.
Command	Requesting from the master station in order to read the module status, to set/control the intelligent function module command parameters.
ST bus cycle time	Processing time for the head module to refresh the input/output status of each slice module.
Bus cycle time	PROFIBUS-DP processing time for the master station to perform cyclic transfer with each slave station.

1.4 What's new in version 1.08J?

Version 1.08J introduces a number of new features to improve the functionality and usability of GX Configurator-ST, such as:

- Support for Microsoft® Windows® 7 32-bit and 64-bit operating systems.

1.5 Notes for upgrading users

If you have upgraded from the previous version of GX Configurator-ST, you can still reuse the files that you created with the last version. These files can be opened normally, and will be upgraded automatically when they are saved.



Although PROFIBUS-DP files created in this version can be reopened in the last version of the software, it is generally advisable not to switch between versions of the software when configuring a file. After saving a file once in the current version of GX Configurator-ST, opening it in earlier versions is not recommended.



GX Configurator-ST 1.06G will only partially work with the new PROFIBUS-DP head module.

Head module set to PROFIBUS-DP version A:

If the head module is set to version A, there will be no problem as GX Configurator-ST 1.06G is fully compatible with this head module version.

Head module set to PROFIBUS-DP version B:

If the head module is set to version B, GX Configurator-ST 1.06G cannot communicate with the head module due to changes to the internal structure. Attempting to connect to the head module will display the error below.



The user interface is very similar to the versions that you have used before, but now when you start the application you will be taken through the first configuration steps with a 'wizard' interface. In the main configuration display, the module list from the previous version is now just the bottom left section of a larger 'module configuration' window, which also shows a graphical display of the configured system, a list of modules for addition and details of the module selected to be added.

To read more about these features, see the sections shown below:

Feature	PROFIBUS-DP description
First steps using the wizard	Creating a new project
The module configuration window	Screen layout and display switching

If you are stuck while using the application, press **F1** to show the relevant section of the help file.

2 Overview


GX Configurator-ST is the configuration software dedicated to the MELSEC-ST system.

2.1 Features

(1) Project creation of MELSEC-ST system


(a) Uploading module data to create project

A project can be created easily by uploading the system configuration and parameters from the MELSEC-ST system.



(b) Changing system configuration to edit project


A project can be edited by changing the system configuration, e.g. adding or rearranging modules.



(2) Monitoring MELSEC-ST system

(a) MELSEC-ST system status can be easily checked.


GX Configurator-ST provides an image to show the statuses of the head/slice modules that comprise the MELSEC-ST system on the "System Monitor" screen. Therefore, these module statuses can be checked easily.



(b) I/O module or intelligent function module can be changed online from GX Configurator-ST

By using online module change, the faulty I/O module or intelligent function module can be changed with normal module without the PROFIBUS-DP or CC-Link network being stopped.

GX Configurator-ST allows online module change to be made easily by screen-guided operation without operation of the head module switches.




(c) Output test can be done without affecting PROFIBUS-DP or CC-Link network

In a forced output test, outputs can be tested using the **Bw.n** Bit Output, **Ww.n** Word Output and **Ew.n** Error Clear of the head module or slice module.

The user can specify any **Bw.n** Bit Output, **Ww.n** Word Output and **Ew.n** Error Clear.

As only the **Bw.n** Bit Output, **Ww.n** Word Output and **Ew.n** Error Clear are used for the forced output test, output data not used in the test are not affected.

In the forced output test, therefore, an output test can be conducted without affecting the PROFIBUS-DP or CC-Link network.



(3) Parameter setting of slice module
 (a) Parameter setting of intelligent function module

The "Parameter Setting" screen displays a list of module parameters. Parameter setting can be made on this list.

As it includes functions to upload and verify data, and to check the setting errors, the parameters can be confirmed easily.

Parameter Setting No.3

Module Information

Slice No. : 5

Module Name : ST1AD21

Label Name :

Base Module : ST1B-4IR2

Online

Select Data

Target Memory: RAM

Select All Release All Upload Download Verify


Channel: CH1 Default Error Check

Select	Item	Setting Value
<input type="checkbox"/>	Input range setting	4 to 20 mA
<input type="checkbox"/>	Setting range	4 to 20 mA
<input type="checkbox"/>	Time/number of times specification	Number of times
<input type="checkbox"/>	Sampling process/averaging process setting	Sampling
<input type="checkbox"/>	Alarm output setting	Disable
<input type="checkbox"/>	Disconnection detection setting	Disable
<input type="checkbox"/>	A/D conversion enable/disable setting	Enable
<input type="checkbox"/>	50/60Hz notch filter specification	Disable
<input type="checkbox"/>	Average time/average number of times setting	4
<input type="checkbox"/>	Upper upper limit value	4000
<input type="checkbox"/>	Upper lower limit value	4000
<input type="checkbox"/>	Lower upper limit value	0
<input type="checkbox"/>	Lower lower limit value	0

(4) Power supply capacity check

A check can be made to see if the sum of 5VDC internal current consumption required by each module is within the 5VDC maximum rated output current of the bus refreshing module.

A power supply capacity check example is shown below.



No.	Supply Current(A)	Consumption(A)	Result
1	2.000	1.800	OK
16	2.000	2.280	ERROR
43	2.000	1.145	OK

- (a) The check result is "OK" since the sum 1.800A of 5VDC internal current consumption required by the head module No. 0 and slice modules No. 2 to 15 is not greater than the 5VDC maximum rated output current 2.000A of the bus refreshing module.
- (b) The check result is "ERROR" since the sum 2.280A of 5VDC internal current consumption required by the slice modules No. 17 to 42 is greater than the 5VDC maximum rated output current 2.000A of the bus refreshing module.
- (c) The check result is "OK" since the sum 1.145A of 5VDC internal current consumption required by the slice modules No. 44 and later is not greater than the 5VDC maximum rated output current 2.000A of the bus refreshing module.

(5) Byte pack check (PROFIBUS-DP head module version B only)

A byte pack check is automatically done with PROFIBUS-DP head module version B. This check ensures in offline mode that the configuration is correctly set up with byte packed modules.

2.2 How do I ... ?

This section will list things that you may wish to achieve with the software, and the different ways in which these can be done. There may be several ways to get the same result, for example modules can be added or deleted using several different methods.


How do I...?	Instructions
Create a new system	Creating a new project
Set up the communication port	Transfer setup dialog
Read the configuration from the SLICE hardware	Get system
Use the module configuration window	Details of module configuration window
Add modules to the configuration	Adding the module with the "Add module" screen Adding the module with the "Wizard area"
Delete modules from the configuration	Deleting a module Deleting all modules
Rearrange the modules in the configuration	Rearrange modules
Drag and drop modules	Drag and drop
Set module parameters	Parameter setting
Download parameters to several modules at once	Parameter block write
Compare parameter details with those stored in another project file	Verifying the projects
Compare parameter details with those on the SLICE hardware	Uploading / downloading the parameters
Copy modules from another configuration file	Copying the module information
Use GX Configurator-ST for diagnostics	System monitor
Show module details (address ranges)	Module detail information
View module input/output data	Input/Output monitor
Test / calibrate module outputs	Forced output test
Set offset/gain settings for a module	Offset/gain settings
Change the head module type after the system has been configured	Change head module type

How do I...?	Instructions
Swap modules while the system is running (Online module change)	Online module change
Set module options	Option setting
Change module labels	Option setting
Print the configuration	Printing the project data
Check the total power consumption	Power distribution check
Use the toolbar	Details of toolbar
Use the status bar	Status bar
Change to/from edit/online mode	Edit mode operation procedures / Diagnosis mode operation procedures
Reset the head module	Reset the head module
View the PROFIBUS-DP network parameters	PROFIBUS-DP network parameter monitor (PROFIBUS-DP only)
Read the point mode and 'without Wr' / 'without Ww' settings from a connected system	Reading input/output data settings (PROFIBUS-DP only)
Change the head module protocol version	Change PROFIBUS-DP head module protocol version (PROFIBUS-DP only)
View the master station data communication parameters / data area	Master station data communication monitor
Rearrange the open windows	Display switching and window rearranging operations
Find out what an error means	Error messages

3 System Configuration

3.1 System Configuration

The following shows the configuration where a personal computer is connected to the MELSEC-ST system.



*1 : Use either of the following cables as the RS-232 cable.

Manufacturer name	Model name
Mitsubishi Electric	QC30R2
Beijer ELECTRONICS	SC-Q QC30R2

3.2 Operating Environment

The operating environment of GX Configurator-ST is indicated below.

Item		Description
Computer main unit		Refer to the following table "Used operating system and performance required for personal computer".
	CPU	
	Required memory	
Hard disk free space		60MB or more
Disk drive		CD-ROM disk drive
Display		1024 × 768 dot or more resolution
Operating system		Microsoft® Windows® 2000 Professional Operating System (English version) Microsoft® Windows® XP Professional Operating System (English version) ^{*1, 2} Microsoft® Windows® XP Home Edition Operating System (English version) ^{*1, 2} Microsoft® Windows Vista® Home Basic Operating System (English version) ^{*2} Microsoft® Windows Vista® Home Premium Operating System (English version) ^{*2} Microsoft® Windows Vista® Business Operating System (English version) ^{*2} Microsoft® Windows Vista® Ultimate Operating System (English version) ^{*2} Microsoft® Windows Vista® Enterprise Operating System (English version) ^{*2} Microsoft® Windows® 7 Home Premium Operating System (English version) Microsoft® Windows® 7 Professional Operating System (English version) Microsoft® Windows® 7 Ultimate Operating System (English version) Microsoft® Windows® 7 Enterprise Operating System (English version)

*1: "XP compatibility mode" and "Fast user switching" are not supported.

*2: 64-bit OS for Windows® XP and Windows Vista® are not supported.

Used operating system and performance required for personal computer

Operating system		Performance Required for Personal Computer	
		CPU	Required memory
Windows® 2000 Professional		Pentium® 133MHz or more	64MB or more
Windows® XP Professional	"XP compatibility mode" and "Fast user switching" are not supported.	Pentium® 300MHz or more	128MB or more
Windows® XP Home Edition		Pentium® 300MHz or more	128MB or more
Windows Vista® Home Basic		Pentium® 1GHz or more	1GB or more
Windows Vista® Home Premium		Pentium® 1GHz or more	1GB or more
Windows Vista® Business		Pentium® 1GHz or more	1GB or more
Windows Vista® Ultimate		Pentium® 1GHz or more	1GB or more
Windows Vista® Enterprise		Pentium® 1GHz or more	1GB or more
Windows® 7 Home Premium		Pentium® 1GHz or more	1GB or more (32-bit) 2GB or more (64-bit)
Windows® 7 Professional		Pentium® 1GHz or more	1GB or more (32-bit) 2GB or more (64-bit)
Windows® 7 Ultimate		Pentium® 1GHz or more	1GB or more (32-bit) 2GB or more (64-bit)
Windows® 7 Enterprise		Pentium® 1GHz or more	1GB or more (32-bit) 2GB or more (64-bit)



- The following features are not available for use with Windows® XP, Windows Vista® and Windows® 7. If used, this product may not function normally.

- Application startup in Windows® compatibility mode
 - Fast user switching
 - Remote desktop
 - Large fonts (detailed setting in Screen properties)

- On Windows Vista® and Windows® 7 authority of USER or higher level must be used.

4 Function list

4.1 Function list

The functions of GX Configurator-ST are indicated below.

Function	Description	Reference Section
System configuration setting	Registers modules into the system by model name.	'Editing the project'
Parameter Setting	Sets the parameters to the intelligent function module.	'Parameter setting'
Option Settings	Sets the label name, base module etc. for the module.	'Option setting'
Power Distribution Check	Checks whether the 5VDC internal current consumption of the bus refreshing module is sufficient.	'Power distribution check'
System Monitor	Monitors the statuses of the head and slice modules.	'System monitor'
Module configuration, parameter upload/download	Uploads/downloads the module configuration and parameters.	'Downloading and uploading the parameters'
Input/Output Monitor	Monitors the input data and output data.	'Input/Output monitor'
Forced Output Test	Tests the Bw.n Bit Output, Ww.n Word Output and Ew.n Error Clear of the head module or slice module without stopping the PROFIBUS-DP or CC-Link network.	'Forced output test'
Offset/Gain Setting	Sets the offset and gain values of the intelligent function modules (ST1AD2-V, etc.).	'Offset/Gain setting of intelligent function modules'
Reset Head Module	Resets the head module.	'Reset head module'
Change head module type	Changes the head module type (in edit mode).	'Change head module type'
Change head module protocol version	Changes the head module protocol version (in edit mode) - PROFIBUS-DP only.	'Change PROFIBUS-DP head module protocol version'
Module Detail Information	Shows the module detail information and monitors the corresponding module error status.	'Module detail information'
Online Module Change	Changes the I/O module or intelligent function module online from GX Configurator-ST.	'Online module change'
PROFIBUS-DP Network Parameter Monitor	Monitors the slave parameters and PROFIBUS-DP network parameters sent from the master station of PROFIBUS-DP to the MELSEC-ST system to show the results for confirmation.	'PROFIBUS-DP network parameter monitor'
Master Station Data Communication Monitor	Monitors I/O data between the master station and head module.	'Master station data communication monitor'

4.2 Menu list

This section explains the menus of GX Configurator-ST.

 **Point**

The menu screens in this section are different from the actual ones. Actually, some menu items are not selectable depending on the operation status of GX Configurator-ST. For the purpose of explanation, all the menu items are shown as selectable.

[File] menu

File	
New...	Ctrl+N
Open...	Ctrl+O
Close	
Save	Ctrl+S
Save As...	

Verify...	
Copy...	

Print...	Ctrl+P

1 Sample.st	
2 Sample.st	
3 Sample.st	
4 Sample.st	

Exit	

The [File] menu includes project file operation, print and other functions. For more information, refer to the following sections:

- [New](#) - create a new project
- [Open](#) - open an existing project
- [Close](#) - close the project
- [Save](#) - save the project
- [Save as](#) - save the project with another name
- [Verify](#) - compare modules with another project
- [Copy](#) - copy module information from another project
- [Print](#) - print the project data
- Recent files - open a recently-used project
- [Exit](#) - close GX Configurator-ST

[Edit] menu

Edit	
<u>U</u> ndo	Ctrl+Z
<u>R</u> edo	Ctrl+Y

<u>A</u> dd...	Ctrl+Insert
Rearrange...	
<u>D</u> elete	Ctrl+Delete
All Delete	Shift+Del

<u>P</u> arameter Setting...	F9


<u>O</u> ption...	F10


Change <u>h</u> ead module	


Power Distribution <u>C</u> heck	

The [Edit] menu includes the functions for module configuration setting and parameter setting. For more information, refer to the following sections:

- [Undo](#) - reverse the last edit operation
- [Redo](#) - reverse the last undo operation
- [Add](#) - add a module to the configuration
- [Rearrange](#) - change the order of modules
- [Delete](#) - delete a module
- [All delete](#) - delete all modules
- [Parameter setting](#) - change module parameter settings
- [Option](#) - change module options
- [Change head module](#) - change head module type
- [Power distribution check](#) - test power consumption


[View] menu	
	<p>The [View] menu includes the function to display/hide each screen.</p> <p>Refer to 'Display switching and window rearranging operations' for details of each menu item.</p>

[Mode] menu	
	<p>The [Mode] menu includes the functions to switch between the edit mode and diagnosis mode.</p> <p>Refer to 'Edit mode operation procedure' for details of the [Edit] menu item.</p> <p>Refer to 'Diagnosis mode operation procedure' for details of the [Diagnosis] menu item.</p>

[Online] menu	
	<p>The [Online] menu includes the functions for connection to the head module and online operation of the head module. For more information, refer to the following sections:</p> <p>Transfer setup - select communication port to use</p> <p>Get system - read configuration from connected MELSEC-ST system</p> <p>Get input/output data settings - read input/output data settings from MELSEC-ST system (PROFIBUS-DP only)</p> <p>Input/Output monitor - monitor module input/output data</p> <p>Forced output test - test outputs / error clear</p> <p>Offset/Gain setting - change offset/gain settings</p> <p>Parameter block write - download parameters as a batch</p> <p>Reset the head module - restart the head module</p>

[Diagnostics] menu

<table border="1"> <tr> <td style="background-color: #cccccc;">Diagnostics</td> </tr> <tr> <td>Module Detail Information...</td> </tr> <tr> <td>Online Module Change...</td> </tr> <tr> <td>PROFIBUS-DP Network Parameter Monitor...</td> </tr> <tr> <td>Master Station Data Communication Monitor...</td> </tr> </table>	Diagnostics	Module Detail Information...	Online Module Change...	PROFIBUS-DP Network Parameter Monitor...	Master Station Data Communication Monitor...	<p>The [Diagnostics] menu includes the functions to diagnose the system. For more information, refer to the following sections:</p> <p>Module detail information - show more details of a module</p> <p>Online module change - swap out a module</p> <p>PROFIBUS-DP network parameter monitor - view or export network parameter data</p> <p>Master station data communication monitor - view head module data areas</p>
Diagnostics						
Module Detail Information...						
Online Module Change...						
PROFIBUS-DP Network Parameter Monitor...						
Master Station Data Communication Monitor...						

[Window] menu	
	<p>The [Window] menu includes the functions to change the screen layout of GX Configurator-ST.</p> <p>Refer to 'Display switching and window rearranging operations' for details of each menu item.</p>

[Help] menu							
	<p>The [Help] menu includes the functions to show the online help, operate the GX Configurator-ST keys and confirm the software version.</p> <table data-bbox="759 927 1433 1048"> <tr> <td><i>Contents</i></td> <td>Shows the help file starting at the co</td> </tr> <tr> <td><i>Key Operation List</i></td> <td>Shows the key operation list page.</td> </tr> <tr> <td><i>About</i></td> <td>Shows the version number, copyright information.</td> </tr> </table>	<i>Contents</i>	Shows the help file starting at the co	<i>Key Operation List</i>	Shows the key operation list page.	<i>About</i>	Shows the version number, copyright information.
<i>Contents</i>	Shows the help file starting at the co						
<i>Key Operation List</i>	Shows the key operation list page.						
<i>About</i>	Shows the version number, copyright information.						

5 Operation Procedures


5.1 Precautions when using GX Configurator-ST

This section provides precautions when using GX Configurator-ST.

- (1) A communication error may occur if communication is made with the MELSEC-ST system after setting of the resume function, suspend setting, power-saving function or standby mode of the personal computer.
For this reason, do not set any of these functions before starting communication with the MELSEC-ST system.

5.2 Edit mode operation procedure

Create a new project, and edit and download it to the MELSEC-ST system.




5.3 Diagnosis mode operation procedure

Confirm the error status and take corrective action, or perform the monitor/test, etc. of I/O data.

(1) Preparations for diagnosis mode

Make preparations for operation in the diagnosis mode.
 Perform the following operation before starting operation in the diagnosis mode.



(2) Diagnosis mode operation procedure

Perform the operation explained in the reference section for each purpose of use.
 Before starting the diagnosis mode operation, perform the operation in (1) of this section.


Purpose of use	Reference section
To monitor the MELSEC-ST system. To confirm the module where an error occurred.	'System monitor'
To confirm the error definition.	'Module detail information'
To set the offset and gain values.	'Offset/Gain setting of intelligent function modules'
To confirm the I/O data.	'Input/Output monitor'
To conduct the forced output test.	'Forced output test'
To monitor the master station data communication.	'Master station data communication monitor'
To monitor the PROFIBUS-DP Network Parameters.	'PROFIBUS-DP network parameter monitor'
To reset the head module.	'Reset head module'
To change the module online.	'Online module change'

6 Installation and uninstallation

This chapter explains how to install and uninstall GX Configurator-ST.

6.1 Installation

6.1.1 Installation procedure



6.1.2 Installing GX Configurator-ST


The following indicates how to install GX Configurator-ST.

Microsoft® Windows® XP Professional Operating System is used for explanation in this section.



- (1) Before starting installation, exit all other applications operating on Windows®.
- (2) The installer may not work normally because the update program of the operating system or another companies software such as Windows® Update and Java Update may start automatically. Please install the driver after changing the settings of the update program not to start automatically.
- (3) When installing GX Configurator-ST on any of the following operating systems, log on using an administrator account (computer manager).
 - Microsoft® Windows® 2000 Professional Operating System
 - Microsoft® Windows® XP Professional Operating System
 - Microsoft® Windows® XP Home Edition Operating System
 - Microsoft® Windows Vista® Home Basic Operating System
 - Microsoft® Windows Vista® Home Premium Operating System
 - Microsoft® Windows Vista® Business Operating System
 - Microsoft® Windows Vista® Ultimate Operating System
 - Microsoft® Windows Vista® Enterprise Operating System
 - Microsoft® Windows® 7 Home Premium Operating System
 - Microsoft® Windows® 7 Professional Operating System
 - Microsoft® Windows® 7 Ultimate Operating System
 - Microsoft® Windows® 7 Enterprise Operating System
- (4) Check whether or not GX Configurator-ST has been installed on the personal computer. If it has already been installed, uninstall it, restart the personal computer, and then install this software.

- (1) Installing GX Configurator-ST




(To the next page)

1) After powering on the personal computer, start Windows®.

2) Start Windows® Explorer and click the drive where the disk is inserted. Double-click "Setup.exe" (📄).

To display Windows® Explorer, choose [Start] → [All Programs] → [Windows Explorer].

(From the previous page)



3) (When using Windows Vista® or Windows® 7)
When the screen on the left is displayed, click "Allow".



4) On the left screen, click the **Next** button.




5) Read and agree to the licence terms.
Then, click the **Next** button.

Note: This dialog is only shown for European product versions.



(To the next page)


(From the previous page)



- 6) Enter a user name, company name and serial number (where applicable), then click the **Next** button.



- 7) Specify an installation destination folder. Then, click the **Next** button. The default is set to "C:\MELSEC\GX Configurator ST 1.**". ("**" represents a version number.) To change the default setting, click the **Change** button and specify a preferred drive and folder.




- 8) Clicking the **Install** button will start installation.



(To the next page)

(From the previous page)



9) The left screen indicates that the installation is completed.

Click the **Finish** button.

(Completion)

Installing GX Configurator-ST registers the icon as shown below.




REMARK

When any of the following operating systems is used, the registered icon is placed in the menu that appears by selecting [Start] → [Programs] → [MELSOFT Application].

- Microsoft® Windows® 2000 Professional Operating System
- Microsoft® Windows® XP Professional Operating System
- Microsoft® Windows® Vista Operating System
- Microsoft® Windows® 7 Enterprise Operating System

6.2 Uninstallation

This section explains the operation for removing GX Configurator-ST from the hard disk. The screens used for explanation in this section are those of Windows® XP Professional. Though they differ slightly from the screens of Windows® 2000 Professional or like, refer to **REMARKS** and perform installation.




- 1) Double-click "Add or Remove Programs" on the Control Panel.
To display the Control Panel, choose [Start] → [Control Panel].

REMARKS

When using any of the following operating systems, double-click "Add or Remove Programs". To display the control panel, choose [Start] → [Settings] → [Control Panel].

- Windows® 2000 Professional
- Windows® XP Professional

For Windows Vista® and Windows® 7, click "Uninstall a program" on the Control Panel. To display the Control Panel, select [Start] → [Control Panel].




- 2) Choose "Change or Remove Programs" and then "GX Configurator ST Version 1.***" (***) represents a version number).

After selection, click the **Remove** button.

(To the next page)


(From the previous page)



3) Confirm that the program should be uninstalled.

Clicking the **Yes** button starts uninstallation.

Clicking the **No** button stops uninstallation.



4) (When using Windows Vista® or Windows® 7)


When the screen on the left is displayed, click "Allow".



(Completion)

6.3 Starting GX Configurator-ST

This section explains how to start GX Configurator-ST from the start menu.



- 1) Move the cursor from [Start] → [All Programs *1] → [MELSOFT Application].

*1: [Programs] is displayed when any of the following operating systems is used.


- Windows® 2000 Professional
- Windows® XP Professional



- 2) Click [GX Configurator ST **] (** represents a version number).



- 3) GX Configurator-ST starts.



REMARK

Multiple GX Configurators-ST can be started to use.

Since different projects can be opened on multiple GX Configurators-ST, multiple projects can be browsed simultaneously.

The same project cannot be opened from multiple GX Configurators-ST.

When multiple GX Configurators-ST are started, GX Configurators-ST started second and later have the following restrictions.

1) The diagnosis mode cannot be used.

The [Mode] → [Diagnosis] menu () cannot be clicked.

2) Get System cannot be executed.

The [Online] → [Get System] menu () cannot be clicked.

3) Parameter Block Write cannot be executed.

The [Online] → [Parameter Block Write] menu cannot be clicked.

4) Parameter upload, download and verify cannot be executed on the Parameter Setting screen.

The **Upload**, **Download** and **Verify** buttons cannot be clicked.

GX Configurator-ST started first can perform the following operation since the above restrictions do not apply.


Even when GX Configurator-ST started first is exited, the above restrictions still apply to all GX Configurator-ST instances that have started.

To remove the restrictions, restart GX Configurator-ST after exiting all the remaining GX Configurator-ST instances.

6.4 Exiting GX Configurator-ST

This section describes how to exit GX Configurator-ST.

(1) From menu



Click the [File] → [Exit] menu.
GX Configurator-ST ends.

(2) From "Titlebar"



Click  and choose [Close].
Alternatively, click  at the right end of the "Titlebar".



- (1) While the [print preview](#) is displayed, GX Configurator-ST cannot be exited.
Exit GX Configurator-ST after closing the print preview.
- (2) Do not restart or shut down your personal computer during GX Configurator-ST operation.
Exit GX Configurator-ST before restarting or shutting down the personal computer.

REMARK

When a project is newly created, or modified but not yet saved, a dialog box appears asking whether the project will be saved or not.

When not saving it, click the **No** button.

When saving it, click the **Yes** button.

When saving a new project, name the project.


Refer to [Save as](#) for details.


7 Screen layout and display switching

This chapter explains the screen layout of GX Configurator-ST and the display switching of each area.

7.1 Screen layout

The screen layout of GX Configurator-ST is shown below.



Name	Description
Titlebar	<p>Displays the file name of the open project. When two or more GX Configurator-STs have been started, "Edit Mode only" is displayed before each file name of the second and later ones.</p>  <p>When "Window" on GX Configurator-ST is maximized, the name of that "Window" is displayed.</p> 
Menubar	<p>Clicking each menu opens the corresponding "Dropdown menu". Then clicking a "Dropdown menu" item will execute the corresponding function of GX Configurator-ST. Refer to Menu list for details.</p>
Dropdown menu	
Toolbar	<p>Click any of the buttons to execute the corresponding function of GX Configurator-ST. Refer to Details of toolbar for more information.</p>
Screen minimize button	<p>Click this button to minimize GX Configurator-ST.</p>

Name	Description
Screen maximize button	Click this button to maximize GX Configurator-ST.
Exits GX Configurator-ST	Click this button to exit GX Configurator-ST.
Module configuration window	This initially shows a configuration wizard. Once a configuration is being edited it will display a list of modules registered to the project, graphically and as a list. Double-click a module to set the parameters. Right-click the module to display the menu, and select a menu item to execute the corresponding function. Use 'drag and drop' in the graphical display to rearrange modules. Use the 'Wizard' area to add modules. Refer to ' Details of module configuration window ' for more information.
Window	Displays the "Parameter Setting" screen, "Result Verify" screen, etc. Use Ctrl + F6 to switch to the next window, or Shift + Ctrl + F6 to switch to the previous window.
Statusbar	When the mouse pointer is moved over each "Dropdown menu" item, the corresponding explanation is displayed. The following information is also displayed. <ul style="list-style-type: none"> • Current mode of GX Configurator-ST • Station number or FDL address of the connected head module in the diagnosis mode

Ready Diagnosis Mode FDL Address 42

7.2 Display switching and window rearranging operations

The following table shows how to display/hide bars and how to arrange windows.

Operation	Description
[View] → [Module Configuration Window]	Displays or hides the "Module Configuration Window" screen. This operation can be performed in the edit mode only.
[View] → [Initialize Module Configuration View Position]	Returns the display position of the "Module Configuration Window" screen to the initial status. This operation can be performed in the edit mode only.
[View] → [System Monitor]	Displays or hides the "System Monitor" screen. This operation can be performed in the diagnosis mode only.
[View] → [Toolbar]	Displays or hides the "Toolbar" .
[View] → [Statusbar]	Displays or hides the "Statusbar" .
[Window] → [Cascade]	Overlays multiple "Windows" opened on GX Configurator-ST.
[Window] → [Tile Vertically]	Displays multiple "Windows" vertically.
[Window] → [Tile Horizontally]	Displays multiple "Windows" horizontally.
[Window] → [Arrange Icons]	Arranges the icons to which windows have been minimized.
[Window] → [Close All Windows]	Closes all "Windows". When a "Window" is being edited, a confirmation message is displayed.

7.3 Details of toolbar


The buttons included in the Toolbar will be explained.



Button	Name	Description	Reference Section
	New	Creates a new project.	'Creating a new project'
	Open	Opens the existing project.	'Opening an existing project'
	Save	Saves the open project, whether it is new or existed previously.	'Save'
	Print	Prints the module configuration, module information list, and module detail information of the open project.	'Printing the project data'
	Undo	Restores to the status prior to the last operation.	'Undo'
	Redo	Restores to the status prior to the "Undo" operation.	'Redo'
	Add	Adds a slice module to the project.	'Adding the module'
	Delete	Deletes the slice module from the project.	'Deleting a module'
	All Delete	Deletes all slice modules from the project.	'Deleting all modules'
	Parameter Setting	Sets the parameters of the intelligent function module.	'Parameter setting'
	Edit	Switches to the edit mode.	—
	Diagnosis	Switches to the diagnosis mode.	—
	Get System	Uploads the system configuration and the parameters of each module from the head module.	'Get system'
	About	Displays the software version of GX Configurator-ST.	—


7.4 Details of module configuration window

The module configuration window provides a 'wizard' to guide the user through the system configuration. When GX Configurator-ST is first started, this will show the options for creating a system:



Creating a new configuration is described in ['Creating a new project'](#).

When the configuration is being edited, the window changes to show four separate panes:



Name	Description
Rack display	Displays a graphical representation of the assembled system. It can be used to edit module details or rearrange modules using drag and drop. The display items are described in 'Details of rack display' .
Module list	Shows the details of the modules, with the address ranges that they will use and any label names assigned to them. The display items are described in 'Details of module list' .
Wizard area	This is a continuation of the wizard screen shown when GX Configurator-ST first starts, and can be used to add or delete modules. For more information, see 'Details of wizard area' .
Information area	This shows the details of the module selected for addition in the wizard area. The display items are described in 'Details of information area' .

HELPFUL OPERATION


You can resize the areas by selecting the bars between them, and then clicking and dragging with the mouse. The size of each area will be saved when the application exits, and restored the next time the program starts. It can be reset from the 'View' menu ['Initialize module configuration view position'](#) item.

The following shortcut keys are available for use when the module configuration window is active:

Key	Description
Alt + 1	Switch to the rack display.
Alt + 2	Switch to the module list
Alt + 3	Switch to the wizard area
F6	Switch between panes, in the order: Rack display → Module list → Wizard area → Rack display
Shift + F6	Switch between panes in reverse order: Rack display → Wizard area → Module list → Rack display

7.4.1 Details of rack display

Displays a graphical representation of the assembled system. This can be useful to provide a quick visual check for errors, as the graphical display should look like the physical hardware.



DISPLAY/SETTING DATA


Item	Description
Modules	<p>The rack starts at the left side with the head module, which always occupies slot number zero. This should normally be followed by an ST1PSD bus refreshing module, which is always required to provide power to the head module and the first modules immediately after it.</p> <p>The graphic for each module is shown in two parts; the upper half depends on the module type, and the lower half shows the 'base module' which may be different depending on the type of wiring used.</p> <p>Left click on a module to select it. It will automatically be selected in the module list as well. Many actions in the [Edit] menu require a module to be selected first.</p> <p>Right click on a module to select it and show a menu similar to the [Edit] menu – refer to Editing the project for details of each menu item. If the module has a configuration error (such as consuming more power than the last power supply will provide), this will be shown at the top of the menu. Clicking on the item will show help on the error.</p>
Scroll bar	<p>If there are more modules in the configuration than the window can display, there will be a scrollbar under the rack which can be used to view the remaining modules</p>

7.4.2 Details of module list

This shows a list of modules in the configuration.


[CC-Link systems]

 **DISPLAY/SETTING SCREEN**



 **DISPLAY/SETTING DATA**

Item	Description
I/O Occupation Points (Bit)	The total number of bits used by all the modules in the configuration.
I/O Occupation Points (Word)	The total number of words used by all the modules in the configuration.
Max. Bit	The limit on the number of input/output bits with the current optimisation mode, extended cyclic and stations settings.
Max. Word	The limit on the number of input/output words with the current optimization mode, extended cyclic and stations settings.
Mode	This gives the optimization mode currently selected, either 'priority high speed' (use more stations so data is read faster) or 'priority min. stations' (reduce the number of stations used at the cost of reading the data more slowly). This can only be changed for the SLICE system by setting a DIP switch on the head module itself, although the selection can be changed here to see what the effect of switching mode would be. When you switch to diagnostics mode, the current DIP switch setting will be read from the SLICE hardware.
Configuration setting	This shows the configuration setting you will need to correctly configure the head module in GX Works2, GX Developer or GX IEC Developer.
Exp. cyclic setting	By increasing the number of cycles taken to read the data, the number of stations used can be reduced, however this means that the data will take longer to read in total. This value is calculated based on the optimization mode setting.


Item	Description
Excl. station count	The number of stations used for communications. Using more stations increases the speed at which data is read, but reduces the number of other devices that can be used on the CC-Link bus. This value is calculated based on the optimization mode setting.
List area	<p>This shows a list of modules in the configuration. Double click on a module to edit its parameter settings (see 'Parameter setting' for more details). Left click on a module to select it – the same module will automatically be selected in the rack display as well. Many actions in the [Edit] menu require a module to be selected first.</p> <p>Right click on a module to select it and show a menu similar to the [Edit] menu – refer to 'Editing the project' for details of each menu item. If the module has a configuration error (such as consuming more power than the last power supply will provide), this will be shown at the top of the menu. Clicking on the item will show help on the error.</p> <p>You can alter the widths of columns in the module list by moving the mouse pointer over the dividing line between two column headings:</p>  <p>When the cursor changes to a vertical double line with arrows on each side, click and hold the left mouse button, then drag the column divider to its new position and release the mouse button. The changes you make to the column widths will be remembered and reapplied each time the application is started.</p>
	No. the position number for the module, starting with the head module at position 0 and the first ST1PSD power supply at position 1.
	Slice The Slice position of the module. Some modules can occupy more than one slice, so this does not always match the number.
	Module Name The type of module, for example ST1PSD.
	Br(HEX) The input bit range used by the module
	Bw(HEX) The output bit range used by the module
	Wr(HEX) The input word range used by the module
	Ww(HEX) The output word range used by the module
	Label Name A user-defined label for the module. This can be useful to identify modules when there are several modules of the same type in the system. For example, two similar input/output modules could be labelled 'Cabinet 1 wiring' and 'Cabinet 2 wiring' to tell them apart.

Point

In CC-link systems, the address ranges are sometimes referred to differently. CCLink's 'RX' and 'RY' ranges are equivalent to the 'Br' and 'Bw' ranges shown in GX Configurator-ST and CC-link's 'RWr' and 'RWw' ranges are equivalent to 'Wr' and 'Ww'.


[PROFIBUS-DP systems]

 **DISPLAY/SETTING SCREEN**



 **DISPLAY/SETTING DATA**


Item	Description
I/O Occupation Points (Bit)	The total number of bits used by all the modules in the configuration. This cannot be more than the point mode limit (see 'Option setting').
I/O Occupation Points (Word)	The total number of words used by all the modules in the configuration. The limit on the number of words used varies depending on the point mode.
GSD version	This dropdown gives information about the protocol version the offline configuration is currently set to. By selecting a different value (Version A or B), the configuration can be changed.
Head module mode	PROFIBUS-DP version A: This gives the number of points read when communicating with the PROFIBUS-DP master station. Lower numbers mean that the data is read more frequently, but less data can be read in total. Larger numbers allow more data to be read, but not as often. PROFIBUS-DP version B: This controls whether the head station is used with or without commands.

Item	Description		
List area	<p>This shows a list of modules in the configuration. Double click on a module to edit its parameter settings (see 'Parameter setting' for more details). Left click on a module to select it – the same module will automatically be selected in the rack display as well. Many actions in the [Edit] menu require a module to be selected first. Right click on a module to select it and show a menu similar to the [Edit] menu – refer to 'Editing the project' for details of each menu item. If the module has a configuration error (such as consuming more power than the last power supply will provide), this will be shown at the top of the menu. Clicking on the item will show help on the error. You can alter the widths of columns in the module list by moving the mouse pointer over the dividing line between two column headings:</p>  <p>When the cursor changes to a vertical double line with arrows on each side, click and hold the left mouse button, then drag the column divider to its new position and release the mouse button. The changes you make to the column widths will be remembered and reapplied each time the application is started.</p>		
	<table border="1"> <tr> <td data-bbox="416 969 568 1032">No.</td> <td data-bbox="568 969 1430 1032">The position number for the module, starting with the head module at position 0 and the first ST1PSD power supply at position 1.</td> </tr> </table>	No.	The position number for the module, starting with the head module at position 0 and the first ST1PSD power supply at position 1.
No.	The position number for the module, starting with the head module at position 0 and the first ST1PSD power supply at position 1.		
	<table border="1"> <tr> <td data-bbox="416 1032 568 1099">Slice</td> <td data-bbox="568 1032 1430 1099">The Slice position of the module. Some modules can occupy more than one slice, so this does not always match the number.</td> </tr> </table>	Slice	The Slice position of the module. Some modules can occupy more than one slice, so this does not always match the number.
Slice	The Slice position of the module. Some modules can occupy more than one slice, so this does not always match the number.		
	<table border="1"> <tr> <td data-bbox="416 1099 568 1167">Module Name</td> <td data-bbox="568 1099 1430 1167">The type of module, for example ST1PSD.</td> </tr> </table>	Module Name	The type of module, for example ST1PSD.
Module Name	The type of module, for example ST1PSD.		
	<table border="1"> <tr> <td data-bbox="416 1167 568 1234">Unused bits</td> <td data-bbox="568 1167 1430 1234"><i>Head module version B only</i> The number of bits available to use with byte packing</td> </tr> </table>	Unused bits	<i>Head module version B only</i> The number of bits available to use with byte packing
Unused bits	<i>Head module version B only</i> The number of bits available to use with byte packing		
	<table border="1"> <tr> <td data-bbox="416 1234 568 1267">Br(HEX)</td> <td data-bbox="568 1234 1430 1267">The input bit range used by the module</td> </tr> </table>	Br(HEX)	The input bit range used by the module
Br(HEX)	The input bit range used by the module		
	<table border="1"> <tr> <td data-bbox="416 1267 568 1301">Bw(HEX)</td> <td data-bbox="568 1267 1430 1301">The output bit range used by the module</td> </tr> </table>	Bw(HEX)	The output bit range used by the module
Bw(HEX)	The output bit range used by the module		
	<table border="1"> <tr> <td data-bbox="416 1301 568 1335">Wr(HEX)</td> <td data-bbox="568 1301 1430 1335">The input word range used by the module</td> </tr> </table>	Wr(HEX)	The input word range used by the module
Wr(HEX)	The input word range used by the module		
	<table border="1"> <tr> <td data-bbox="416 1335 568 1379">Ww(HEX)</td> <td data-bbox="568 1335 1430 1379">The output word range used by the module</td> </tr> </table>	Ww(HEX)	The output word range used by the module
Ww(HEX)	The output word range used by the module		
	<table border="1"> <tr> <td data-bbox="416 1379 568 1509">Label Name</td> <td data-bbox="568 1379 1430 1509">A user-defined label for the module. This can be useful to identify modules when there are several modules of the same type in the system. For example, two similar input/output modules could be labelled 'Cabinet 1 wiring' and 'Cabinet 2 wiring' to tell them apart.</td> </tr> </table>	Label Name	A user-defined label for the module. This can be useful to identify modules when there are several modules of the same type in the system. For example, two similar input/output modules could be labelled 'Cabinet 1 wiring' and 'Cabinet 2 wiring' to tell them apart.
Label Name	A user-defined label for the module. This can be useful to identify modules when there are several modules of the same type in the system. For example, two similar input/output modules could be labelled 'Cabinet 1 wiring' and 'Cabinet 2 wiring' to tell them apart.		

7.4.3 Details of wizard area

The wizard area is a continuation of the wizard page which is shown when GX Configurator-ST first starts. It can be used to add or delete modules.

DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA


Item	Description
Information message	This shows advice on the current function of the buttons.
Module tree	This shows the available modules for addition, categorised by type. When a module is selected, its details are shown in the information area – see 'Details of information area' .
Add before	Select this if new modules should be added <i>before</i> the currently selected module in the rack display / module list.
Add after	Select this if new modules should be added <i>after</i> the currently selected module in the rack display / module list.
Back button [not shown]	If there are no modules left other than the head module and first bus refreshing module, the Back button will allow you to return to the head module selection page of the wizard.
Delete button	This can be used to delete the module which is currently selected in the module list / rack display.
Add button	Adds a module to the configuration.

7.4.4 Details of information area

When a module is selected for addition in the wizard area tree, the information area shows the details of the module.

[CC-Link systems]

DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Name	The module name (type)
Description	A readable description of the module - this can be useful to identify a module when two modules have similar names
The module graphic	A graphical representation of the top part of the module as it will appear in the rack
Slots	The number of slots that will be occupied by the module
Slices	The number of slices that will be occupied by the module
Br	The number of input bits occupied
Bw	The number of output bits occupied
Wr	The number of input words occupied
Ww	The number of output words occupied
Status bit detail	This gives more detailed information about the status bits used by the module




In CC-link systems, the address ranges are sometimes referred to differently. CClink's 'RX' and 'RY' ranges are equivalent to the 'Br' and 'Bw' ranges shown in GX Configurator-ST and CC-link's 'RWr' and 'RWw' ranges are equivalent to 'Wr' and 'Ww'.

[PROFIBUS-DP systems]



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Name	The module name (type)
Description	A readable description of the module - this can be useful to identify a module when two modules have similar names
The module graphic	A graphical representation of the top part of the module as it will appear in the rack
Slots	The number of slots that will be occupied by the module
Slices	The number of slices that will be occupied by the module
Br	The number of input bits occupied
Bw	The number of output bits occupied
Wr	The number of input words occupied
Ww	The number of output words occupied
Status bit detail	This gives more detailed information about the status bits used by the module

8 Project creation

This chapter explains how to create the project of GX Configurator-ST.

8.1 Creating a new project




PURPOSE

Creates a new project.




BASIC OPERATION

- (1) When GX Configurator-ST is first started, a 'wizard' page is shown automatically. If you have a configuration file open, you can also return to this page by clicking the [File] → [New] menu () or pressing the **Ctrl** + **N** keys on the keyboard.



- (2) Select 'Build the system configuration offline' and click **Next >>** to show the protocol selection page.



- (3) Select the protocol used by the head module (PROFIBUS-DP for the ST1H-PB module, or CC-Link for the ST1H-BT module). For PROFIBUS-DP the protocol version (A, B with command, B without command) can also be selected using radio buttons. After selecting the protocol and version, click **Next >>**.

This displays a new project on the "Module Configuration Window" screen.

8.2 Opening an existing project



PURPOSE

Reads a saved project.



BASIC OPERATION

(1) Either:

Click the [File] → [Open] menu () or press the **Ctrl** + **O** keys on the keyboard, or


At the first wizard page (normally shown when GX Configurator-ST starts), select

'Open an existing file' and click **Next >>**.

(2) On the opened screen, select the project to be opened, and click the **Open** button. This displays the selected project on the "Module Configuration Window" screen.



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Look in	Select the directory that stores the project to be opened.
File name	Set the file name of the project to be opened.
 button	Opens the project specified at "File name".
 button	Closes this screen without opening the project.

8.3 Closing the project



PURPOSE

Closes the currently open project.



BASIC OPERATION

- (1) Click the [File] → [Close] menu.
- (2) When closing a project that includes unsaved changes, i.e., newly created project or changed existing project, a screen appears asking whether the project will be saved or not.




When not saving it, click the **No** button.

When saving it, click the **Yes** button.

When saving a new project, name the project.

Refer to ['Save as'](#) for details.

- (3) When closing an unchanged existing screen, the following screen appears asking whether the project will be closed or not.



Click the **Yes** button to close the project.

8.4 Saving the project

8.4.1 Save



PURPOSE

Saves the open project, whether it is new or existed previously.



BASIC OPERATION

Click the [File] → [Save] menu () or press the **Ctrl** + **S** keys on the keyboard.
For a new project, name and save it.
Refer to ['Save as'](#) for details.


8.4.2 Save as

**PURPOSE**

To name and save the open project.

**BASIC OPERATION**

- (1) Click the [File] → [Save As] menu.
- (2) On the opened screen, select the destination directory, set the file name, and click the **Save** button.

**DISPLAY/SETTING SCREEN****DISPLAY/SETTING DATA**

Item	Description
Save in	Select the directory that stores the project.
File name	Set the file name of the project to be saved.
Save button	Saves the project with the file name specified at "File name".
Cancel button	Closes this screen without saving the project.

8.5 Verifying the projects

Verify two projects against each other to check whether the parameters are consistent or not.

There are the following two different verify methods.

(1) n:n verify

Verify all modules of the same No. between the open project and saved project.

Refer to ['n:n verify'](#) for details of the verify operation.

Refer to ['Verify result'](#) for details of the verify result.

(2) 1:n verify

Select one module from one of two projects, select multiple modules from the other project, and verify the one module of the former project against the multiple modules of the latter project.

Refer to ['1:n verify'](#) for details of the verify operation.

Refer to ['Verify result'](#) for details of the verify result.

8.5.1 n:n verify



PURPOSE

Verifies all modules of the same No. between the open project and saved project.



BASIC OPERATION

(1) Clicking the [File] → [Verify] menu displays the "Verify" screen.

(2) Open the <<Verify All Modules>> tab.

(3) Click the **Browse** button and specify the verification destination project.

(4) Clicking the **Execute** button starts verify, closes this screen, and displays the result.

Refer to ['Verify result'](#) for details.



DISPLAY/SETTING SCREEN

Verify Close

Verification Destination File

Drive/Path : C:\MELSEC\SLICE

File Name : VerifySample3b Browse...

Verify All Modules
Verify Selected Modules
Execute

Verify all modules tab

Verification Source

No.	Slice	Module Name
0	0	ST1H-BT
1	2	ST1PSD
2	3	ST1DA2-V
3	5	ST1RD2
4	7	ST1AD2-V
5	9	ST1SS1
6	11	ST1AD2-V
7	13	ST1AD2-V
8	15	ST1SS1
9	17	ST1DA2-V
10	19	ST1RD2
11	21	ST1DA2-V

Source modules (current file)

Verification Destination

No.	Slice	Module Name
0	0	ST1H-BT
1	2	ST1PSD
2	3	ST1DA2-V
3	5	ST1RD2
4	7	ST1AD2-V
5	9	ST1SS1
6	11	ST1AD2-V
7	13	ST1AD2-V
8	15	ST1SS1
9	17	ST1DA2-V
10	19	ST1RD2
11	21	ST1DA2-V

Destination modules (target file)



DISPLAY/SETTING DATA

Item	Description
Verification Destination File	Specify the verification destination project.
Drive/Path	Displays the drive and directory that stores the verification destination project specified with the Browse button.
File Name	Displays the file name of the verification destination project specified with the Browse button.
Browse button	Specifies the project. Operation is the same as opening the existing project. Refer to ' Opening an existing project ' for details.
Close button	Closes this screen without verifying the projects.
<<Verify All Modules>> tab	Performs n:n verify.
Execute button *1	Verifies the projects, closes this screen, and displays the verify result. Refer to ' Verify result ' for details of the verify result.
Verification Source *2	Displays a list of all modules of the open project.
Verification Destination *2	Displays a list of all modules of the verification destination project.

*1: The **Execute** button cannot be clicked if the open project and verification destination project differ in system configuration.

*2: As this verification is conducted to check parameter inconsistency, the module without parameters is grayed out and is not verified.
The module with uploadable parameters is verified, even if the parameters are not editable.

8.5.2 Verify result



PURPOSE

Confirms the verify result displayed by [n:n.verify](#) or [1:n.verify](#).



BASIC OPERATION

- (1) The module having inconsistent parameters in the verify result is displayed red in the verified module list.
To display the inconsistent parameters, click the module displayed red.
- (2) To change the parameters, double-click or select the corresponding module and click the **Parameter Setting** button.
- (3) To close this screen, click the  button.



DISPLAY/SETTING SCREEN

Result Verify 2

Verification Source File:

Verification Destination File:

No.(Src)	Module Name(Src)	No.(Dst)	Module Name(Dst)	Mismatch Items
5	ST1AD2V	2	ST1X16-DE1	----
5	ST1AD2V	3	ST1Y16-TPE3	----
5	ST1AD2V	5	ST1AD2V	5
5	ST1AD2V	6	ST1DA2V	----

Parameter Setting...

No.	Item	Verify Source Setting Value	Verify Destr
1	Average number	4	8
2	Upper upper limit value	4000	2000
3	Upper lower limit value	4000	2000
4	Lower upper limit value	-4000	-2000
5	Lower lower limit value	-4000	-2000

Verified module list

Inconsistent parameter list



DISPLAY/SETTING DATA

Item	Description
Verification Source File	Displays the file name of the verification source project. "Untitled" is displayed when a newly created and unsaved project has been set.
Verification Destination File	Displays the file name of the verification destination project.
Verified module list	Displays a list of modules verified. The module having inconsistent parameters is displayed red. Double-click that module to change its parameters. Refer to ' Parameter setting ' for details.
No. (Src)	Displays the No. of the verification source module.
Module Name (Src)	Displays the model name of the verification source module.
No. (Dst)	Displays the No. of the verification destination module.
Module Name (Dst)	Displays the model name of the verification destination module.
Mismatch Items	Displays the number of items whose verify result is inconsistent. "----" indicates that the "Module Name(Src)" and "Module Name(Dst)" are different modules.
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Parameter Setting</div> button	Changes the parameters of the module selected in the verified module list. Refer to ' Parameter setting ' for details. The target is an open project.
Inconsistent parameter list	Displays the parameters that were inconsistent as a result of verify in the module selected in the verified module list.
No.	Displays the serial number.
Item	Displays the parameter name.
Verify Source Setting Value	Displays the parameter value of the verification source module.
Verify Destination Setting Value	Displays the parameter value of the verification destination module.

8.5.3 1:n verify



PURPOSE

Selects one module from one of two projects, selects multiple modules from the other project, and verifies the one module of the former project against the multiple modules of the latter project.



BASIC OPERATION

- (1) Clicking the [File] → [Verify] menu displays the "Verify" screen.
- (2) Open the <<Verify Selected Modules>> tab.
- (3) With the **Browse** button, specify the verification destination project.
- (4) With the "Select Verification Source File" radio button, select the project that includes the verification source module.
- (5) With the **Add** button, select the verification source module.
- (6) With the **Add** / **Delete** button, select the verification target module.
- (7) Clicking the **Execute** button starts verify, closes this screen, and displays the result.
Refer to ['Verify result'](#) for details.



DISPLAY/SETTING SCREEN

The screenshot shows the 'Verify' dialog box with the following components and callouts:

- Verification Destination File:** Drive/Path: C:\MELSEC\SLICE. Callout: "Select verification source file".
- File Name:** VerifySample3b. Callout: "Verify selected modules tab".
- Buttons:** Close, Execute, Add, Delete, Browse...
- Select Verification Source File:** Radio buttons for "Opened File" (selected) and "Verification Target File". Callout: "Start comparison".
- Opened File Table:**

No.	Slice	Module Name
0	0	ST1H-PB
1	2	ST1PSD
2	3	ST1DA2-V
3	5	ST1RD2

 Callout: "Select which file to use as the source".
 Callout: "Modules in current file".
- Verification Source Module Table:**

No.	Slice	Module Name
6	11	ST1AD2-I

 Callout: "Selected source module to compare".
- Verification Target File Table:**

No.	Slice	Module Name
0	0	ST1H-PB
1	2	ST1PSD
2	3	ST1DA2-V
3	5	ST1RD2

 Callout: "Selected target module(s) to compare against".
 Callout: "Modules in destination file".



DISPLAY/SETTING DATA

Item	Description
Verification Destination File	Specify the verification destination project. Operation is the same as performing n:n verify. Refer to 'n:n verify' for details.
Close button	Closes this screen without verifying the projects.
<<Verify Selected Modules>> tab	Performs 1:n verify.
Select Verification Source File	Select the project that includes the verify source module. <ul style="list-style-type: none"> When "Opened File" is selected, select the verification source module from the open project. When "Verification Target File" is selected, select the verification source module from the project specified at "Verification Destination File".
Execute button	Verifies the projects, closes this screen, and displays the verify result. Refer to 'Verify result' for details of the verify result.
Opened File *1	Displays a list of all modules of the open project.
Add button	Adds the selected module to the "Verification Source Module" or "Verification Destination Module". The addition destination changes depending on the selection of "Select Verification Source File". <ul style="list-style-type: none"> When "Opened File" is selected, the selected module is added to "Verification Source Module". When "Verification Target File" is selected, the selected module is added to "Verification Destination Module".

*1: As this verification is conducted to check parameter inconsistency, the module without parameters is grayed out and is not verified.
The module with uploadable parameters is verified, even if the parameters are not editable.

Item	Description
Verify Selected Modules	—
Verification Target File *1	Displays a list of all modules of the verification destination project.
Add button	Adds the selected module to the "Verification Source Module" or "Verification Destination Module". The addition destination changes depending on the selection of "Select Verification Source File". <ul style="list-style-type: none"> When "Opened File" is selected, the selected module is added to "Verification Source Module". When "Verification Target File" is selected, the selected module is added to "Verification Destination Module".
Verification Source Module	Displays the module selected as the verification source. Only one module can be selected for this item.
Verification Destination Module	Displays the modules to be verified.
Delete button	Deletes the selected module.

*1: As this verification is conducted to check parameter inconsistency, the module without

parameters is grayed out and is not verified.

The module with uploadable parameters is verified, even if the parameters are not editable.

8.6 Printing the project data



PURPOSE

Prints the module configuration, module information list and module detail information of the open project.



BASIC OPERATION

- (1) Click the [File] → [Print] menu () or press the **Ctrl** + **P** keys on the keyboard.
- (2) Make settings on the opened screen, e.g. select the printing details (Module Configuration, Module Information List or Individual Module Information (Module Detail Information, Parameter)).
- (3) Click the **Print** button to start printing.
Refer to ['Print examples'](#) for the printing result.

DISPLAY/SETTING SCREEN

Print

Module Configuration

Module Turning Position: 16 modules

Alignment: Print the module name by columnar writing, Print the module name by horizontal writing

Module Information List

Individual Module Information (Module Detail Information, Parameter)

Print Range: All Modules, Selected Modules

No.	Slice	Module Name
0	0	ST1H-PB
1	2	ST1PSD
2	3	ST1DA2-V
3	5	ST1AD2-I
4	7	ST1DA1-I

Modules available to print

The module to print

No.	Slice	Module Name
0	0	ST1H-PB
1	0	ST1PSD

Buttons: Printer Setup, Page Setup, Print, Print Preview, Close

Print module configuration page

Print module information list

Print individual module

Modules to print - all or just selected

Modules per row

Print modules vertically / horizontally

Add module to print selection

Modules selected for printing

Remove module from print selection

Select / setup printer

Set up page / headings

Send to printer

Show preview

Cancel



DISPLAY/SETTING DATA

Item	Description						
Module Configuration	Check this item to print the module configuration.						
Module Turning Position	Set the number of modules to be arranged horizontally when the module configuration is to be printed. This item is available only when the "Module Configuration" is checked.						
Module Information List	Check this item to print the module information list.						
Individual Module Information (Module Detail Information, Parameter)	Check this item to print the detail information of the modules specified at "Print Range".						
Alignment	Select the print orientation for the module names.						
Print the module name by columnar writing	Prints the module names vertically. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>ST1H-PB</td> <td>ST1P5D</td> <td>ST1X16-DE1</td> </tr> </table>	0	1	2	ST1H-PB	ST1P5D	ST1X16-DE1
0	1	2					
ST1H-PB	ST1P5D	ST1X16-DE1					
Print the module name by horizontal writing	Prints the module names horizontally. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>ST1H-PB</td> <td>ST1P5D</td> <td>ST1X16-DE1</td> </tr> </table>	0	1	2	ST1H-PB	ST1P5D	ST1X16-DE1
0	1	2					
ST1H-PB	ST1P5D	ST1X16-DE1					
Print Range	Set the modules to be printed when the detail information of individual modules is to be printed. This item is available only when the "Individual Module Information" is checked.						
All Modules	Prints the detail information of all modules.						
Selected Modules	Prints the detail information of the modules displayed in "The module to print".						
 button	Adds the module selected in the left side list to the end of "The module to print" as the module to be printed.						
 button	Withdraws the module selected in "The module to print" from the modules to be printed, and deletes it from "The module to print".						
 button	Sets the printer. Refer to 'Setting up the printer' for details.						
 button	Sets the page layout. Refer to 'Setting a page layout' for details.						
 button	Starts printing.						
 button	Closes this screen and displays a print image. Refer to 'Previewing a print image' for details.						
 button	Closes this screen without printing.						

8.6.1 Setting up the printer



PURPOSE

Selects a printer for printing and sets the paper size, the printing orientation, and other printing format-related items.




BASIC OPERATION

- (1) Click the **Printer Setup** button on the "Print" screen to display this screen.
- (2) Select the printer for printing, and set the paper size, print orientation, etc.
- (3) To close this screen, click the **OK** button.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description
Printer	Selects a printer for printing.
 button	Clicking this button displays the properties dialog box. The printer property option is used to make the basic settings of the printer.
Paper	Sets the size of the paper for printing and the paper feed method of the printer. The setting range depends on the printer.
Orientation	—
Portrait	Characters will be printed along the paper feed direction.
Landscape	Characters will be printed across the paper feed direction.
 button	Click this button when connecting to the shared network folder. This item is displayed only when any of the following operating systems is used. <ul style="list-style-type: none"> • Microsoft® Windows® 2000 Professional Operating System • Microsoft® Windows® XP Professional Operating System • Microsoft® Windows® XP Home Edition Operating System • Microsoft® Windows Vista® Basic Premium Operating System • Microsoft® Windows Vista® Home Premium Operating System • Microsoft® Windows Vista® Business Operating System • Microsoft® Windows Vista® Ultimate Operating System • Microsoft® Windows Vista® Enterprise Operating System • Microsoft® Windows® 7 Home Premium Operating System • Microsoft® Windows® 7 Professional Operating System • Microsoft® Windows® 7 Ultimate Operating System • Microsoft® Windows® 7 Enterprise Operating System
 button	Click this button after the printer setting is completed.
 button	Cancels the settings and closes this screen.



For the property setting of the printer, please read the manual of the used printer carefully since the setting changes depending on the printer maker and model.

8.6.2 Setting a page layout



PURPOSE

Makes settings related paper, page number, header, and so on.




BASIC OPERATION

- (1) Click the **Page Setup** button on the "Print" screen to display this screen.
- (2) Set the paper, page number, header, etc.
- (3) To close this screen, click the **OK** button.





DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description						
Paper	Sets paper size and paper feed method.						
Print Orientation	Sets the orientation of printing on paper.						
Margins	Sets the margins of the page.						
Page No. Setting	Set the page number.						
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; padding: 5px;">Page No. Format</td> <td style="padding: 5px;"> Select the page number format. <ul style="list-style-type: none"> "-**-" "-**-**" Set "None" to print no page numbers. </td> </tr> <tr> <td style="padding: 5px;">No. Position</td> <td style="padding: 5px;">Sets the position of page numbers.</td> </tr> <tr> <td style="padding: 5px;">Initial Value</td> <td style="padding: 5px;">Sets the page number to be printed on the first page. This can be useful if you are printing the configuration as an appendix to another document.</td> </tr> </table>	Page No. Format	Select the page number format. <ul style="list-style-type: none"> "-**-" "-**-**" Set "None" to print no page numbers. 	No. Position	Sets the position of page numbers.	Initial Value	Sets the page number to be printed on the first page. This can be useful if you are printing the configuration as an appendix to another document.	
Page No. Format	Select the page number format. <ul style="list-style-type: none"> "-**-" "-**-**" Set "None" to print no page numbers. 						
No. Position	Sets the position of page numbers.						
Initial Value	Sets the page number to be printed on the first page. This can be useful if you are printing the configuration as an appendix to another document.						
<p>Common Header Setting/ Common Footer Setting</p>	<p>By checking the check box, a header will be printed on each page. Click the Edit header button, and the "Header Edit" dialog box as shown below will be displayed.</p> <div style="text-align: center;">  </div> <p>Alternatively, clicking the Edit header button displays the "Footer Edit" dialog box like the Header Edit dialog box. The header (or footer) can be edited within the range of 64 characters x seven lines. Lines and images cannot be edited, and characters cannot be decorated.</p>						
Preview	This shows a graphical representation of how the page will look using the current settings such as landscape / portrait, margins, etc.						
<p>OK button</p>	Click this button after the page setting is completed.						
<p>Cancel button</p>	Cancels the settings and closes this screen.						
<p>Printer Setup button</p>	<p>By clicking this button, the printer dialog box will be displayed. Select the printer for printing and click the OK button.</p> <div style="text-align: center;">  </div>						



- If the print characters are small, reduce the value of margin setting.
 - When the mouse button is clicked while the shape of the mouse pointer is , the window zooms in.
- When the mouse button is clicked while the shape of the mouse pointer is , the data is displayed in the standard scale.

8.6.3 Previewing a print image



PURPOSE

The image of the entire page when it is printed will be displayed.



BASIC OPERATION

- (1) Clicking the **Print Preview** button on the "Print" screen displays the print image of the entire page.
- (2) To return to the "Print" screen, click the **Print** button.
- (3) To end the image display, click the **Close** button.



DISPLAY/SETTING SCREEN

Module Information List

Input/Output Description: None

Module No.	I-Address	Q-Address	Module Name
0	ST10-00	00-03	ST10-00
1	ST1000	04-05	ST1000
2	ST1002	06-07	ST1002
3	ST1000-1	08-09	ST1000-1
4	ST1001-1	10-11	ST1001-1

Individual Module Information

Module Detail Information

Module Name: ST10-00
 Label Name: -
 Module No.: 0
 No.: 0
 Slave No.: 0
 Slave I/O: 00-03
 Slave Q/I: 00-03
 No Slave: -
 No Slave: -

Parameter

Name	Setting Value
Output status at module error	Stop
Set flag information	Enable
Dep. of Input/output data	Enable
Dep. of Set flag information	Enable
Resets when Slave is	Enable

Pages 1-2 Edit Mode



DISPLAY/SETTING DATA

Item	Description
Print button	Ends the image display and starts the print.
Zoom In button	The displayed image will be enlarged by clicking this button. Data will be displayed in three different scales.
Zoom Out button	The displayed image will be reduced by clicking this button.
Close button	Ends the image display.



When the mouse button is clicked while the shape of the mouse pointer is , the window zooms in.

When the mouse button is clicked while the shape of the mouse pointer is , the data is displayed in the standard scale.

8.6.4 Print Examples

Print examples are shown below.

(1) Module Configuration

(a) When "Print the module name by columnar writing" is set

Module Configuration

0	1	2	3	4
ST1H-PB	ST1PSD	ST1DA2-V	ST1AD2-I	ST1DA1-I

(b) When "Print the module name by horizontal writing" is set

Module Configuration

0	1	2	3	4
ST1H-PB	ST1PSD	ST1DA2-V	ST1AD2-I	ST1DA1-I

(2) Module Information List

Module Information List

Input/Output Occupation Points

Bit	50
Word	4

No.	Slice	Module Name	Br (HEX)	Bw (HEX)	Wr (HEX)	Ww (HEX)	Label Name
0	0	ST1H-PB	00-03	00-03	-	-	
1	2	ST1PSD	04-05	04-05	-	-	

(3) Individual Module Information

Module Detail Information


```
Module Name : ST1H-PB
Label Name  :
Base Module :
No.         : 0
Slice No.   : 0
Br(HEX)    : 00-03
Bw(HEX)    : 00-03
Mr(HEX)    : -
Mw(HEX)    : -
```

Parameter

Item	Setting Value
Output status at module error	Stop
Ext_Diag information	Enable
Swap of input/output data	Disable

9 Editing the project

This chapter explains how to edit the project of GX Configurator-ST.



9.1 Adding the module

9.1.1 Adding the module with the "Add module" screen



PURPOSE

Adds a slice module to the project.



BASIC OPERATION

- (1) Execute any of the following operations to display the "Add Module" screen.
 - Click the [Edit] → [Add] menu ().
 - Press the **Ctrl** + **Insert** keys on the keyboard.
 - In the "Module Configuration Window", right-click the list in the "Module list" or "rack display" area, and click [Add] from the menu.
- (2) Set the adding position and model name of the module on the "Add Module" screen, and click the **Add** button.
- (3) To close the "Add Module" screen, click the **Close** button.



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.




If adding the module would cause the power consumption to be exceeded for the power supply module which serves the new module, you will be shown a warning message which provides an opportunity to cancel the addition.

This warning is only shown once – it will not be shown if the power supply module was already overloaded before the module was added.



(PROFIBUS-DP protocol version B only)


If adding the module would use more unused bits than there are available, you will be shown a warning message which provides an opportunity to cancel the addition.



This warning is only shown once – it will not be shown if the available unused bits had been exceeded before the module was added.



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description																																																																																										
Insert Position	Set the position where the slice module will be inserted.																																																																																										
Last Position	<p>Sets the inserting position to the last line. Example: When the module is added to the last line.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Before addition</p> <table border="1" style="font-size: small;"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>W[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST10GDE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE2</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1AD2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> </tbody> </table> </div> <div style="font-size: 2em; margin: 0 10px;">→</div> <div style="text-align: center;"> <p>After addition</p> <table border="1" style="font-size: small;"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>W[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST10GDE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>26-26</td><td>26-26</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1AD2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> <tr><td>6</td><td>22</td><td>ST1AD2V</td><td>2C-2F</td><td>2C-2F</td><td>-</td></tr> </tbody> </table> </div> </div> <p style="text-align: right; margin-top: 10px;">Added to the last line.</p>	No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST10GDE1	06-15	06-15	-	3	11	ST1Y16-TPE2	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1AD2V	28-28	28-28	00-01	No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST10GDE1	06-15	06-15	-	3	11	ST1Y16-TPE3	26-26	26-26	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1AD2V	28-28	28-28	00-01	6	22	ST1AD2V	2C-2F	2C-2F	-
No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST10GDE1	06-15	06-15	-																																																																																						
3	11	ST1Y16-TPE2	16-25	16-25	-																																																																																						
4	19	ST1PDD	26-27	26-27	-																																																																																						
5	20	ST1AD2V	28-28	28-28	00-01																																																																																						
No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST10GDE1	06-15	06-15	-																																																																																						
3	11	ST1Y16-TPE3	26-26	26-26	-																																																																																						
4	19	ST1PDD	26-27	26-27	-																																																																																						
5	20	ST1AD2V	28-28	28-28	00-01																																																																																						
6	22	ST1AD2V	2C-2F	2C-2F	-																																																																																						
No.	<p>Select the "No." radio button and select the inserting position from the list. Example: When the module (ST1Y16-TPE3) is added to No. 3</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Before addition</p> <table border="1" style="font-size: small;"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>W[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST10GDE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1PDD</td><td>16-17</td><td>16-17</td><td>-</td></tr> <tr><td>4</td><td>12</td><td>ST1AD2V</td><td>18-18</td><td>18-18</td><td>00-01</td></tr> <tr><td>5</td><td>14</td><td>ST1AD2V</td><td>1C-1F</td><td>1C-1F</td><td>-</td></tr> </tbody> </table> </div> <div style="font-size: 2em; margin: 0 10px;">→</div> <div style="text-align: center;"> <p>After addition</p> <table border="1" style="font-size: small;"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>W[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST10GDE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1AD2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> <tr><td>6</td><td>22</td><td>ST1AD2V</td><td>2C-2F</td><td>2C-2F</td><td>-</td></tr> </tbody> </table> </div> </div> <p style="text-align: right; margin-top: 10px;">With this addition, the module No.3 or later will be incremented by 1.</p>	No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST10GDE1	06-15	06-15	-	3	11	ST1PDD	16-17	16-17	-	4	12	ST1AD2V	18-18	18-18	00-01	5	14	ST1AD2V	1C-1F	1C-1F	-	No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST10GDE1	06-15	06-15	-	3	11	ST1Y16-TPE3	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1AD2V	28-28	28-28	00-01	6	22	ST1AD2V	2C-2F	2C-2F	-
No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST10GDE1	06-15	06-15	-																																																																																						
3	11	ST1PDD	16-17	16-17	-																																																																																						
4	12	ST1AD2V	18-18	18-18	00-01																																																																																						
5	14	ST1AD2V	1C-1F	1C-1F	-																																																																																						
No.	Slice	Module Name	B[HEX]	W[HEX]	W[HEX]																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST10GDE1	06-15	06-15	-																																																																																						
3	11	ST1Y16-TPE3	16-25	16-25	-																																																																																						
4	19	ST1PDD	26-27	26-27	-																																																																																						
5	20	ST1AD2V	28-28	28-28	00-01																																																																																						
6	22	ST1AD2V	2C-2F	2C-2F	-																																																																																						
Select Module	Select the model name of the slice module to be added in the pull-down menu.																																																																																										
Input/Output Module	Displays the input/output modules in the pull-down menu to enable selection.																																																																																										
Intelligent Module	Displays the intelligent function modules in the pull-down menu to enable selection.																																																																																										
Power Distribution Module	Displays the power distribution modules in the pull-down menu to enable selection.																																																																																										
Reserved (PROFIBUS-DP version B only)	Displays the reserved byte modules in the pull-down menu to enable selection.																																																																																										
Add button *1	Adds the slice module to the project.																																																																																										
Close button	Closes this screen without adding the slice module.																																																																																										

*1: The slice module cannot be added in excess of the Maximum Input/Output points of the head module.
Refer to [Option setting](#) for the Maximum Input/Output points.

9.1.2 Adding the module with the "Wizard area"



PURPOSE

Adds a slice module to the project.



BASIC OPERATION

- (1) Ensure that a module has been selected in the "rack display" / "module list" area – left clicking on a module will select it.
- (2) Select the type of module to be added from the tree in the "wizard area" of the "Module Configuration Window" screen. When you have selected a module, its details will be shown in the "information area" of the "Module configuration window".
- (3) Select either "Add before" or "Add after" to determine where the module will be inserted relative to the selected module.
- (4) Click the **Add** button in the "wizard area".



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.



If adding the module would cause the power consumption to be exceeded for the power supply module which serves the new module, you will be shown a warning message which provides an opportunity to cancel the addition.

This warning is only shown once – it will not be shown if the power supply module was already overloaded before the module was added.

[CC-Link systems]



DISPLAY/SETTING SCREEN

To add a module before or after the current position, select it from the list and click 'Add'.
To remove the current module, select 'Delete'.

ST1X1616-DE1-S1-F/L

[-] Intelligent modules

- ST1AD2-I
- ST1AD2-V
- ST1DA1-I
- ST1DA1-I-F01
- ST1DA2-V**
- ST1DA2-V-F01

Add before Add after



DISPLAY/SETTING DATA

Item	Description																																																																														
Insert Position	Set the position where the slice module will be inserted.																																																																														
Add before	<p>Inserts just before the currently selected module (to the <i>left</i> in the rack display). Example: When the module ST1Y16-TPE3 is added <i>before</i> slot No. 4.</p> <div style="display: flex; align-items: center;"> <table border="1" style="margin-right: 20px;"> <caption>Before addition</caption> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>Bw[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-02</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1PDD</td><td>16-17</td><td>16-17</td><td>-</td></tr> <tr><td>4</td><td>12</td><td>ST1A2V</td><td>18-18</td><td>18-18</td><td>00-01</td></tr> <tr><td>5</td><td>14</td><td>ST1DA2V</td><td>1C-1F</td><td>1C-1F</td><td>-</td></tr> </tbody> </table> <table border="1" style="margin-left: 20px;"> <caption>After addition</caption> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>Bw[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-02</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1A2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> <tr><td>6</td><td>22</td><td>ST1DA2V</td><td>2C-2F</td><td>2C-2F</td><td>-</td></tr> </tbody> </table> <div style="border: 1px solid black; padding: 5px; margin-left: 20px;"> <p>With this addition, the module No.3 or later will be incremented by 1.</p> </div> </div> <p>Note: You cannot insert a module before the head module. A valid configuration must always start with a head module followed by an ST1PSD bus refreshing module.</p>	No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]	1	2	ST1PSD	04-02	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1PDD	16-17	16-17	-	4	12	ST1A2V	18-18	18-18	00-01	5	14	ST1DA2V	1C-1F	1C-1F	-	No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]	1	2	ST1PSD	04-02	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1Y16-TPE3	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1A2V	28-28	28-28	00-01	6	22	ST1DA2V	2C-2F	2C-2F	-
No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]																																																																										
1	2	ST1PSD	04-02	04-05	-																																																																										
2	3	ST1Y16-DE1	06-15	06-15	-																																																																										
3	11	ST1PDD	16-17	16-17	-																																																																										
4	12	ST1A2V	18-18	18-18	00-01																																																																										
5	14	ST1DA2V	1C-1F	1C-1F	-																																																																										
No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]																																																																										
1	2	ST1PSD	04-02	04-05	-																																																																										
2	3	ST1Y16-DE1	06-15	06-15	-																																																																										
3	11	ST1Y16-TPE3	16-25	16-25	-																																																																										
4	19	ST1PDD	26-27	26-27	-																																																																										
5	20	ST1A2V	28-28	28-28	00-01																																																																										
6	22	ST1DA2V	2C-2F	2C-2F	-																																																																										
Add after	<p>Inserts just after the currently selected module (to the <i>right</i> in the rack display). Example: When the module (ST1Y16-TPE3) is added <i>after</i> slot No. 2.</p> <div style="display: flex; align-items: center;"> <table border="1" style="margin-right: 20px;"> <caption>Before addition</caption> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>Bw[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-02</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1PDD</td><td>16-17</td><td>16-17</td><td>-</td></tr> <tr><td>4</td><td>12</td><td>ST1A2V</td><td>18-18</td><td>18-18</td><td>00-01</td></tr> <tr><td>5</td><td>14</td><td>ST1DA2V</td><td>1C-1F</td><td>1C-1F</td><td>-</td></tr> </tbody> </table> <table border="1" style="margin-left: 20px;"> <caption>After addition</caption> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>B[HEX]</th> <th>Bw[HEX]</th> <th>W[HEX]</th> </tr> </thead> <tbody> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-02</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1A2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> <tr><td>6</td><td>22</td><td>ST1DA2V</td><td>2C-2F</td><td>2C-2F</td><td>-</td></tr> </tbody> </table> <div style="border: 1px solid black; padding: 5px; margin-left: 20px;"> <p>With this addition, the module No.3 or later will be incremented by 1.</p> </div> </div>	No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]	1	2	ST1PSD	04-02	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1PDD	16-17	16-17	-	4	12	ST1A2V	18-18	18-18	00-01	5	14	ST1DA2V	1C-1F	1C-1F	-	No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]	1	2	ST1PSD	04-02	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1Y16-TPE3	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1A2V	28-28	28-28	00-01	6	22	ST1DA2V	2C-2F	2C-2F	-
No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]																																																																										
1	2	ST1PSD	04-02	04-05	-																																																																										
2	3	ST1Y16-DE1	06-15	06-15	-																																																																										
3	11	ST1PDD	16-17	16-17	-																																																																										
4	12	ST1A2V	18-18	18-18	00-01																																																																										
5	14	ST1DA2V	1C-1F	1C-1F	-																																																																										
No.	Slice	Module Name	B[HEX]	Bw[HEX]	W[HEX]																																																																										
1	2	ST1PSD	04-02	04-05	-																																																																										
2	3	ST1Y16-DE1	06-15	06-15	-																																																																										
3	11	ST1Y16-TPE3	16-25	16-25	-																																																																										
4	19	ST1PDD	26-27	26-27	-																																																																										
5	20	ST1A2V	28-28	28-28	00-01																																																																										
6	22	ST1DA2V	2C-2F	2C-2F	-																																																																										
Select Module	Select the model name of the slice module to be added from the tree.																																																																														
I/O module	Expand this heading to show input/output modules.																																																																														
Intelligent module	Expand this heading to display the intelligent function modules in the tree.																																																																														
Power module	Expand this heading to display the power distribution modules to enable selection.																																																																														
Add button *1	Adds the slice module to the project.																																																																														


*1: The slice module cannot be added in excess of the Maximum Input/Output points of the head module.

Refer to ['Option setting'](#) for the Maximum Input/Output points.

[PROFIBUS-DP systems]



DISPLAY/SETTING SCREEN





DISPLAY/SETTING DATA

Item	Description																																																																																										
Insert Position	Set the position where the slice module will be inserted.																																																																																										
Add before	<p>Inserts just before the currently selected module (to the <i>left</i> in the rack display). Example: When the module ST1Y16-TPE3 is added <i>before</i> slot No. 4.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Before addition</p> <table border="1"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>BjHEQ</th> <th>EnjHEQ</th> <th>WjHEQ</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1A2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> </tbody> </table> </div> <div style="font-size: 2em; margin: 0 10px;">→</div> <div style="text-align: center;"> <p>After addition</p> <table border="1"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>BjHEQ</th> <th>EnjHEQ</th> <th>WjHEQ</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1A2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> <tr><td>6</td><td>22</td><td>ST1A2V</td><td>2C-2F</td><td>2C-2F</td><td>-</td></tr> </tbody> </table> </div> <div style="border: 1px solid black; padding: 2px; font-weight: bold; font-size: 0.8em;"> Added to the last line. </div> </div> <p>Note: You cannot insert a module before the head module. A valid configuration must always start with a head module followed by an ST1PSD bus refreshing module.</p>	No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1Y16-TPE3	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1A2V	28-28	28-28	00-01	No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1Y16-TPE3	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1A2V	28-28	28-28	00-01	6	22	ST1A2V	2C-2F	2C-2F	-
	No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ																																																																																					
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST1Y16-DE1	06-15	06-15	-																																																																																						
3	11	ST1Y16-TPE3	16-25	16-25	-																																																																																						
4	19	ST1PDD	26-27	26-27	-																																																																																						
5	20	ST1A2V	28-28	28-28	00-01																																																																																						
No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST1Y16-DE1	06-15	06-15	-																																																																																						
3	11	ST1Y16-TPE3	16-25	16-25	-																																																																																						
4	19	ST1PDD	26-27	26-27	-																																																																																						
5	20	ST1A2V	28-28	28-28	00-01																																																																																						
6	22	ST1A2V	2C-2F	2C-2F	-																																																																																						
Add after	<p>Inserts just after the currently selected module (to the <i>right</i> in the rack display). Example: When the module (ST1Y16-TPE3) is added <i>after</i> slot No. 2.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Before addition</p> <table border="1"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>BjHEQ</th> <th>EnjHEQ</th> <th>WjHEQ</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1PDD</td><td>16-17</td><td>16-17</td><td>-</td></tr> <tr><td>4</td><td>12</td><td>ST1A2V</td><td>18-18</td><td>18-18</td><td>00-01</td></tr> <tr><td>5</td><td>14</td><td>ST1A2V</td><td>1C-1F</td><td>1C-1F</td><td>-</td></tr> </tbody> </table> </div> <div style="font-size: 2em; margin: 0 10px;">→</div> <div style="text-align: center;"> <p>After addition</p> <table border="1"> <thead> <tr> <th>No.</th> <th>Slice</th> <th>Module Name</th> <th>BjHEQ</th> <th>EnjHEQ</th> <th>WjHEQ</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>ST1HFB</td><td>00-03</td><td>00-03</td><td>-</td></tr> <tr><td>1</td><td>2</td><td>ST1PSD</td><td>04-05</td><td>04-05</td><td>-</td></tr> <tr><td>2</td><td>3</td><td>ST1Y16-DE1</td><td>06-15</td><td>06-15</td><td>-</td></tr> <tr><td>3</td><td>11</td><td>ST1Y16-TPE3</td><td>16-25</td><td>16-25</td><td>-</td></tr> <tr><td>4</td><td>19</td><td>ST1PDD</td><td>26-27</td><td>26-27</td><td>-</td></tr> <tr><td>5</td><td>20</td><td>ST1A2V</td><td>28-28</td><td>28-28</td><td>00-01</td></tr> <tr><td>6</td><td>22</td><td>ST1A2V</td><td>2C-2F</td><td>2C-2F</td><td>-</td></tr> </tbody> </table> </div> <div style="border: 1px solid black; padding: 2px; font-weight: bold; font-size: 0.8em;"> With this addition, the module No.3 or later will be incremented by 1. </div> </div>	No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1PDD	16-17	16-17	-	4	12	ST1A2V	18-18	18-18	00-01	5	14	ST1A2V	1C-1F	1C-1F	-	No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ	0	0	ST1HFB	00-03	00-03	-	1	2	ST1PSD	04-05	04-05	-	2	3	ST1Y16-DE1	06-15	06-15	-	3	11	ST1Y16-TPE3	16-25	16-25	-	4	19	ST1PDD	26-27	26-27	-	5	20	ST1A2V	28-28	28-28	00-01	6	22	ST1A2V	2C-2F	2C-2F	-
No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST1Y16-DE1	06-15	06-15	-																																																																																						
3	11	ST1PDD	16-17	16-17	-																																																																																						
4	12	ST1A2V	18-18	18-18	00-01																																																																																						
5	14	ST1A2V	1C-1F	1C-1F	-																																																																																						
No.	Slice	Module Name	BjHEQ	EnjHEQ	WjHEQ																																																																																						
0	0	ST1HFB	00-03	00-03	-																																																																																						
1	2	ST1PSD	04-05	04-05	-																																																																																						
2	3	ST1Y16-DE1	06-15	06-15	-																																																																																						
3	11	ST1Y16-TPE3	16-25	16-25	-																																																																																						
4	19	ST1PDD	26-27	26-27	-																																																																																						
5	20	ST1A2V	28-28	28-28	00-01																																																																																						
6	22	ST1A2V	2C-2F	2C-2F	-																																																																																						
Select Module	Select the model name of the slice module to be added from the tree.																																																																																										
<div style="border: 1px solid black; padding: 2px; width: 40px; display: inline-block; font-weight: bold;">Add</div> button *1	I/O module	Expand this heading to show input/output modules.																																																																																									
	Intelligent module	Expand this heading to display the intelligent function modules in the tree. In PROFIBUS-DP systems, some intelligent modules can be selected with the 'Wr' or 'Ww' range switched off. These modules will have an extra entry followed by either "without Wr" or "without Ww".																																																																																									
	Power module	Expand this heading to display the power distribution modules to enable selection.																																																																																									
	Reserved (PROFIBUS-DP version B only)	Expand this heading to display the reserved byte modules.																																																																																									
<div style="border: 1px solid black; padding: 2px; width: 40px; display: inline-block; font-weight: bold;">Add</div> button *1		Adds the slice module to the project.																																																																																									

*1: The slice module cannot be added in excess of the Maximum Input/Output points of the head module.
Refer to ['Option setting'](#) for the Maximum Input/Output points.

Point

If the module cannot be added because the resulting number of I/O bits, words or intelligent modules would exceed the limits of the current point mode, the system will check if there is another mode that would be suitable. For example, if more than 32 input/output bits are used in 32-point mode, it might still be possible to add the module by switching to 64-point mode. If there is another suitable mode, a warning will be shown:



Answer **Yes** to switch to the recommended mode and add the module, or **No** to cancel the addition of the module.

Point

Maximum I/O point mode only applies to a head module with protocol version A. For head module protocol version B (with or without commands) this value is automatically adjusted more flexibly.



(PROFIBUS-DP protocol version B only)

If adding the module would use more unused bits than there are available, you will be shown a warning message which provides an opportunity to cancel the addition.



This warning is only shown once – it will not be shown if the available unused bits had been exceeded before the module was added.

9.2 Deleting a module



PURPOSE


Deletes the selected slice module from the project.




BASIC OPERATION

- (1) Select the module to be deleted on the "Module Information List" screen.
- (2) Execute any of the following operations.


- Click the [Edit] → [Delete] menu ().
- Press the **Ctrl** + **Delete** keys on the keyboard.
- Right-click the module to be deleted on the "Module Configuration Window" screen "Module list" or "Rack display", and click [Delete] from the menu:



- Click the **Delete** button in the "wizard area":



- (3) On the opened screen, confirm the slice module to be deleted, and click the **Yes** button. This deletes the module.
The module Nos. greater than the deleted module No. are decremented by 1.



9.3 Deleting all modules




PURPOSE

Deletes all slice modules from the project.



BASIC OPERATION

- (1) Execute any of the following operations.
 - Click the [Edit] → [All Delete] menu (.
 - Press the **Shift** + **Delete** keys on the keyboard.
 - Right-click the list of the "Module Information List" screen, and click [All Delete] from the menu.
- (2) On the opened screen, click the **Yes** button.



9.4 Copying the module information



PURPOSE

Copies the slice module from the saved project to the open project.
At this time, the parameters are also copied to the copied slice module.



BASIC OPERATION

- (1) Click the [File] → [Copy] menu.
- (2) Specify the copy source project with the **Browse** button.
- (3) Select the slice module to be copied, set the inserting position at the "Insert Position" section, and click the **Add** button.
- (4) To close this screen, click the **Close** button.



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.



DISPLAY/SETTING SCREEN

No.	Slice	Module Name	Label Name
0	0	ST1H-PB	
1	2	ST1PSD	
2	3	ST1X16-DE1	
3	11	ST1Y16-TPE3	
4	19	ST1PDD	
5	20	ST1AD2-V	
6	22	ST1DA2-V	

Copy source project
corresponding module list



DISPLAY/SETTING DATA

Item	Description						
Copy Source File	Specify the copy source project.						
<table border="1"> <tr> <td>Drive/Path</td> <td>Displays the drive and directory of the project.</td> </tr> <tr> <td>File Name</td> <td>Displays the file name of the project.</td> </tr> <tr> <td> <input type="button" value="Browse"/> button </td> <td> Specifies the project. The operation is the same as opening the existing project. Refer to 'Opening an existing project' for details. When the project is specified, the modules of the copy source project are displayed in the "Copy source project corresponding module list". </td> </tr> </table>	Drive/Path	Displays the drive and directory of the project.	File Name	Displays the file name of the project.	<input type="button" value="Browse"/> button	Specifies the project. The operation is the same as opening the existing project. Refer to 'Opening an existing project' for details. When the project is specified, the modules of the copy source project are displayed in the "Copy source project corresponding module list".	
Drive/Path	Displays the drive and directory of the project.						
File Name	Displays the file name of the project.						
<input type="button" value="Browse"/> button	Specifies the project. The operation is the same as opening the existing project. Refer to 'Opening an existing project' for details. When the project is specified, the modules of the copy source project are displayed in the "Copy source project corresponding module list".						
Insert Position	Set the position where the slice module will be inserted into the open project.						
<table border="1"> <tr> <td>Last Position</td> <td>Sets the inserting position to the last line.</td> </tr> <tr> <td>No.</td> <td>Select the "No." radio button and then select the insert position from the list.</td> </tr> </table>	Last Position	Sets the inserting position to the last line.	No.	Select the "No." radio button and then select the insert position from the list.			
Last Position	Sets the inserting position to the last line.						
No.	Select the "No." radio button and then select the insert position from the list.						
<input type="button" value="Add"/> button	Copies the slice module selected in the "Copy source project corresponding module list". Copy is not executed when no slice module is selected.						
<input type="button" value="Close"/> button	Closes this screen.						
Copy source project corresponding module list	Select the slice module to be copied.						


9.5 Undo



PURPOSE

Returns the following operations to the status prior to execution.

- Adding the module
- Deleting the module
- Deleting all modules
- Copying the module information
- Get System



BASIC OPERATION

Executing any of the following operations returns to the status prior to the last operation.

- Click the [Edit] → [Undo] menu (.
- Press the **Ctrl** + **Z** keys on the keyboard.
- Right-click the list of the "Module list" or "Rack display" areas of the "Module Configuration Window", and click [Undo] from the menu.

Repeating this operation returns to the status of up to the tenth preceding operation.



- Perform the operation with the "Module Configuration Window" screen displayed. The "Module Configuration Window" screen is displayed when the [View] → [Module Configuration] menu is selected.
- The operation history is erased when the project is closed. When the project is closed, the operation performed before closing the project cannot be returned to the previous status.

9.6 Redo



PURPOSE

Returns to the status prior to the "Undo" processing in ['Undo'](#).



BASIC OPERATION

Execute any of the following operations.

- Click the [Edit] → [Redo] menu (.
- Press the **Ctrl** + **Y** keys on the keyboard.
- Right-click the list of the "Module list" or "Rack display" areas of the "Module Configuration Window", and click [Redo] from the menu.



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.

9.7 Rearranging the modules

9.7.1 Rearranging the modules with the Rearrange dialog



PURPOSE

Rearranges the slice modules of the project.



The head module cannot be rearranged.



BASIC OPERATION

- (1) Execute either of the following operations.
 - Click the [Edit] → [Rearrange] menu.
 - Right-click the list of the "Module Configuration Window" screen "Rack display" or "Module list" area, and click [Rearrange] from the menu.
- (2) On the opened screen, select the slice module to be moved from among the slice modules displayed in the list, and move it using the / button.
- (3) To close this screen, click the button.



Perform the operation with the "Module Configuration Window" screen open.
 To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.



A valid system will always have an ST1PSD module immediately after the head module. If the modules are rearranged in such a way as to leave another module type in the slot after the head module, you will be prompted to rearrange the modules again.



DISPLAY/SETTING SCREEN

After Rearr.	Current No.	Module Name
1	1	ST1PSD
2	5	ST1Y16-TE2
3	2	ST1Y16-TE2
4	7	ST1X16-DE1
5	3	ST1Y2-R2
6	4	ST1X2-DE1
7	8	ST1Y16-TPE3



DISPLAY/SETTING DATA

Item	Description
After Rearr.	Displays the No. of the slice module after rearrangement.
Current No.	Displays the No. of the slice module before rearrangement.
Module Name	Displays the product model name of the slice module after rearrangement.
 button	Changes the positions of the selected slice module with the one above that. When the selected slice module is at the top of the list, its position is not changed.
 button	Changes the positions of the selected slice module with the one below that. When the selected slice module is at the bottom of the list, its position is not changed.
 button	Validates the rearrangement and closes this screen.
 button	Cancels the rearrangement and closes this screen.

9.7.2 Rearranging the modules with drag and drop

In addition to the rearrange dialog, modules can be rearranged by dragging and dropping them directly from the “Rack display” area of the “Module Configuration Window”.



PURPOSE

Rearranges the slice modules of the project. Using this method allows several modules to be moved at once.




The head module cannot be rearranged.




BASIC OPERATION

1. Click on the first module to be moved. If more than one module needs to be moved, keep the left button held down.




2. If you want to move a block of modules, keep the left mouse button held down and drag to the last module in the block.

The number field is highlighted to show the range of modules that are currently selected.




3. Now all the modules are selected, they can be moved. Move the mouse pointer over one of the borders of the selected modules, so that the mouse pointer changes to a picture of a rack with an arrow underneath it, as shown.

Click and hold the left mouse button - the arrow will disappear.




4. With the left mouse button still held down, drag the modules to their new position. An outline border is drawn around the position where the modules will be placed.

If the target position is not visible, you can drag the mouse pointer near to the left or right edge of the rack display to scroll the display.



5. When the left mouse button is released, the modules will be moved to the new position.

They will be automatically selected again, so that if the target position was 'missed', they can be quickly dragged again into the right position.



Point

If you try to drag one or more modules to the left of the the head module or first power supply module, the drag action will automatically be cancelled. A valid system must always start with a head module and a power supply module.

Point

(PROFIBUS-DP head module version B only)
Reserved bytes can only be rearranged in the configuration using the [rearrange dialog](#).

9.8 Parameter setting

The following table shows the reference section for each parameter-related operation.

The operation can be performed on the "Parameter Setting" screen.

Refer to "["Parameter setting" screen](#)" for the operation to display the "Parameter Setting" screen.

Operation	Reference Section
To set the parameters.	'Setting the parameters'
To upload the parameters. To download the parameters. To verify the parameters being edited and the parameters within the module.	'Uploading / downloading / verifying'
To check the parameters being edited for errors and identify the parameter errors.	'Checking the parameters'

9.8.1 "Parameter setting" screen displaying operation



BASIC OPERATION

The "Parameter Setting" screen displaying operation differs among the following (1) to (3).

(1) In the edit mode

- (a) When the "Module Configuration Window" screen is not displayed, choose the [View] → [Module Configuration] menu to display the "Module Configuration Window" screen.
- (b) On the "Module Configuration Window" screen "Rack display" or "Module list" area, select the module whose parameters will be set.
- (c) Execute any of the following operations to display the "Parameter Setting" screen.
 - Click the [Edit] → [Parameter Setting] menu (.
 - Press the **F9** key on the keyboard.
 - On the "Module Configuration Window" screen "Rack display" or "Module list" area, right-click the module whose parameters will be set, and click [Parameter Setting] from the menu.
 - On the "Module Configuration Window" screen "Rack display" or "Module list" area, double-click the module whose parameters will be set.

(2) In the diagnosis mode

- (a) When the "System Monitor" screen is not displayed, choose the [View] → [System Monitor] menu to display the "System Monitor" screen.
- (b) On the "System Monitor" screen, select the module whose parameters will be set.
- (c) Execute any of the following operations to display the "Parameter Setting" screen.
 - Click the [Edit] → [Parameter Setting] menu (.
 - Press the **F9** key on the keyboard.
 - On the "System Monitor" screen, right-click the module whose parameters will be set, and click [Parameter Setting] from the menu.
 - On the "System Monitor" screen, select the module whose parameters will be set, and click the **Parameter Setting** button.

(3) When the "Result Verify" screen is open after project verify

Execute either of the following operations to display the "Parameter Setting" screen.

- On the "Result Verify" screen, double-click the module whose parameters will be set.
- On the "Result Verify" screen, select the module whose parameters will be set, and click the **Parameter Setting** button.

9.8.2 Setting the parameters



PURPOSE

Sets the parameters of the intelligent function module.



BASIC OPERATION

- (1) When the module has the same parameters on multiple channels, select the channel whose parameters will be set at "Channel".
- (2) Set the parameters in the "Parameter list".
- (3) Click the **OK** button to close this screen.



DISPLAY/SETTING SCREEN

Parameter Setting No. 5

Module Information

Slice No. : 9
 Module Name : ST1AD2V
 Label Name :
 Base Module : ST1B*4IR2

Online

Select Data: [Select All] [Release All] Target Memory: RAM

[Upload] [Download] [Verify]

Channel: CH1 [Parameter list] [Set to defaults] [Default] [Error Check]

Select	Item	Setting Value
<input type="checkbox"/>	Input range setting	-10 to 10 V
<input type="checkbox"/>	Setting range	-10 to 10 V
<input type="checkbox"/>	Time/number of times specification	Number of times
<input type="checkbox"/>	Sampling process/averaging process setting	Sampling
<input type="checkbox"/>	Alarm output setting	Disable
<input type="checkbox"/>	Disconnection detection setting	Disable
<input type="checkbox"/>	A/D conversion enable/disable setting	Enable
<input type="checkbox"/>	50/60Hz notch filter specification	Disable
<input type="checkbox"/>	Average time/average number of times setting	4
<input type="checkbox"/>	Upper upper limit value	4000
<input type="checkbox"/>	Upper lower limit value	4000
<input type="checkbox"/>	Lower upper limit value	-4000
<input type="checkbox"/>	Lower lower limit value	-4000



DISPLAY/SETTING DATA

Item	Description
Module Information	Displays the information (start slice No., module name, label name, base module name) of the target intelligent function module.
<input type="button" value="OK"/> button	Validates the settings and closes this screen.
<input type="button" value="Cancel"/> button	Cancels the settings and closes this screen.
Channel	Specify the channel of the parameters to be displayed in the parameter list. Only when the intelligent function module has the same parameters on multiple channels, this item is available.
<input type="button" value="Default"/> button	Returns the parameters in the "Parameter list" to the default values. Only when the module has the parameters that can be changed, this item is available.
Parameter list	A list of the parameters of the intelligent function module is displayed and can be edited. For the types and applications of the parameters of the module, refer to the manual of the corresponding intelligent function module.
Item	Displays the parameter name.
Setting Value	Edit the parameter. The parameter that cannot be edited is grayed out.

9.8.3 Uploading/downloading the parameters or verifying the parameters being edited and parameters within module



PURPOSE

Uploads/downloads the parameters, or verifies the parameters being edited and parameters within module.



BASIC OPERATION

- (1) When the module has the same parameters on multiple channels, select the channel, whose parameters will be uploaded, downloaded or verified, at "Channel".
- (2) Select the parameters to be uploaded, downloaded or verified.
To make selection, mark the "Select" check box in the "Parameter list":

Channel	Parameter list	Select	Value
	D/A conversion	<input type="checkbox"/>	
	disable setting	<input checked="" type="checkbox"/>	Disable
	Preset value	<input checked="" type="checkbox"/>	0

- (3) At "Target Memory", select the memory as the target of upload, download or verify.
- (4) To upload the parameters, click the **Upload** button.
- (5) To download the parameters, click the **Download** button.
- (6) To verify the parameters, click the **Verify** button.
- (7) Click the **OK** button to close this screen.



DISPLAY/SETTING SCREEN

Parameter Setting No. 5

Module Information

Slice No. : 9
 Module Name : ST1AD2V
 Label Name :
 Base Module : ST1B-4IR2

Online

Select Data: [Select All] [Release All] Target Memory: RAM

Channel: CH1

Buttons: [Upload] [Download] [Verify] [Default] [Error Check]

Table:

Select	Item	Setting Value
<input type="checkbox"/>	Input range setting	-10 to 10 V
<input type="checkbox"/>	Setting range	-10 to 10 V
<input type="checkbox"/>	Time/number of times specification	Number of times
<input type="checkbox"/>	Sampling process/averaging process setting	Sampling
<input type="checkbox"/>	Alarm output setting	Disable
<input type="checkbox"/>	Disconnection detection setting	Disable
<input type="checkbox"/>	A/D conversion enable/disable setting	Enable
<input type="checkbox"/>	50/60Hz notch filter specification	Disable
<input type="checkbox"/>	Average time/average number of times setting	4
<input type="checkbox"/>	Upper upper limit value	4000
<input type="checkbox"/>	Upper lower limit value	4000
<input type="checkbox"/>	Lower upper limit value	-4000
<input type="checkbox"/>	Lower lower limit value	-4000



DISPLAY/SETTING DATA

Item	Description
Module Information	Displays the information (start slice No., module name, label name, base module name) of the target module.
<input type="button" value="OK"/> button	Closes this screen.
Online	Perform operation for the target module.
Select Data	Select the parameters to be uploaded, downloaded or verified.
<input type="button" value="Select All"/> button	Checks all "Select" check boxes in the "Parameter list".
<input type="button" value="Release All"/> button	Unchecks all "Select" check boxes in the "Parameter list".
Target Memory	Select the memory as the target of upload, download or verify.
<input type="button" value="Upload"/> button	Uploads the parameters of the target module from the memory selected at "Target Memory". When the module has the same parameters on multiple channels, the parameters of the channel selected at "Channel" are uploaded. The uploaded parameters are displayed in the "Parameter list".
<input type="button" value="Download"/> button	Checks the parameters for incorrect settings, and when they are correct, downloads the parameters to the memory selected at "Target Memory". When the module has the same parameters on multiple channels, the parameters of the channel selected at "Channel" are downloaded. If any parameter is incorrect, that parameter is not downloaded, and its name under "Item" is displayed red in the "Parameter list".
<input type="button" value="Verify"/> button	Verifies the parameters of the memory selected at "Target Memory" and those in the "Parameter List". When the module has the same parameters on multiple channels, the parameters of the channel selected at "Channel" are verified. If any parameter is judged as inconsistent as a result of verify, its name under "Item" is displayed red in the "Parameter list".
Channel	Specify the channel for which parameters will be uploaded, downloaded or verified. Only when the module has the same parameters on multiple channels, this item is available.
Parameter list	Displays a list of the parameters of the module. For the types and applications of the parameters of the module, refer to the manual of the corresponding module.
Select	Select the parameters used for the operation performed at "Online".
Item	Displays the parameter name. This item may be displayed red depending on the result of clicking the <input type="button" value="Download"/> or <input type="button" value="Verify"/> button. For details, refer to the description of the corresponding button.
Setting Value	Displays the parameter value. Downloading is not allowed to the items displayed in gray, however, uploading and verification is available.

9.8.4 Checking the parameters for errors



PURPOSE

Checks the parameters for errors and identifies the parameter errors.



BASIC OPERATION

- (1) When the module has the same parameters on multiple channels, select the channel, whose parameters will be checked for errors, at "Channel".
- (2) Click the **Error Check** button to start an error check.
- (3) Click the **OK** button to close this screen.



DISPLAY/SETTING SCREEN

Parameter Setting No. 5

Module Information

Slice No. : 9
 Module Name : ST1AD2-V
 Label Name :
 Base Module : ST1B-*4IR2

Online

Select Data: [Select All] [Release All] Target Memory: [RAM]


[Upload] [Download] [Verify]

Channel: [CH1] [Parameter list] [Set to defaults] [Default] [Error Check]

Select	Item	Setting Value
<input type="checkbox"/>	Input range setting	-10 to 10 V
<input type="checkbox"/>	Setting range	-10 to 10 V
<input type="checkbox"/>	Time/number of times specification	Number of times
<input type="checkbox"/>	Sampling process/averaging process setting	Sampling
<input type="checkbox"/>	Alarm output setting	Disable
<input type="checkbox"/>	Disconnection detection setting	Disable
<input type="checkbox"/>	A/D conversion enable/disable setting	Enable
<input type="checkbox"/>	50/60Hz notch filter specification	Disable
<input type="checkbox"/>	Average time/average number of times setting	4
<input type="checkbox"/>	Upper upper limit value	4000
<input type="checkbox"/>	Upper lower limit value	4000
<input type="checkbox"/>	Lower upper limit value	-4000
<input type="checkbox"/>	Lower lower limit value	-4000



DISPLAY/SETTING DATA

Item	Description								
Module Information	Displays the information (start slice No., module name, label name, base module name) of the target module.								
<div style="border: 1px solid black; padding: 2px; display: inline-block;">OK</div> button	Closes this screen.								
Channel	Specify the channel of the parameters to be checked for errors. Only when the module has the same parameters on multiple channels, this item is available.								
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Error Check</div> button	<p>Checks the parameters for incorrect settings. If any parameter has an incorrect setting, its name under "Item" is displayed red in the "Parameter list", as in the example below.</p>  <table border="1" style="margin-left: 20px; margin-top: 10px;"> <thead> <tr> <th>Parameter Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Clock/initial/reset setting</td> <td>Clock</td> </tr> <tr> <td>D/A conversion enable/disable setting</td> <td>Disable</td> </tr> <tr style="background-color: red;"> <td>Preset value</td> <td>999999999</td> </tr> </tbody> </table>	Parameter Name	Value	Clock/initial/reset setting	Clock	D/A conversion enable/disable setting	Disable	Preset value	999999999
Parameter Name	Value								
Clock/initial/reset setting	Clock								
D/A conversion enable/disable setting	Disable								
Preset value	999999999								
Parameter list	Displays a list of the parameters of the module. For the types and applications of the parameters of the module, refer to the manual of the corresponding module.								
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Item</div>	<p>Displays the parameter name. This item may be displayed red depending on the result of clicking the <div style="border: 1px solid black; padding: 2px; display: inline-block;">Error Check</div> button.</p> <p>For details, refer to the description of the <div style="border: 1px solid black; padding: 2px; display: inline-block;">Error Check</div> button.</p>								

9.9 Option setting



PURPOSE

Sets the label name, base module, etc.



BASIC OPERATION

- (1) Execute any of the following operations.
 - Click the [Edit] → [Option] menu.
 - Press the **F10** key on the keyboard.
 - On the "Module Configuration Window" screen "Rack display" or "Module list" area, right-click the module, where option settings will be made, and click [Option] from the menu.
- (2) On the opened screen, make option settings and click the **OK** button.



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.

[CC-Link systems]



DISPLAY/SETTING SCREEN

For head module

For slice module



DISPLAY/SETTING DATA

Item	Description
Model Name	Displays the product model name of the module for which option settings will be made.
Label Name	Enter any character string within 32 alphanumeric characters. As the label name is displayed on the "Module Configuration Window" screen or is output for printing, it is useful for module management, etc.
Base Module *1	Select the base module for the slice module. GX Configurator-ST does not distinguish between spring clamp (S) and screw (E) wiring types in the base module.
Use Word Input Data	When the module has Wr.n word input, this box will be checked. If the Wr.n word input data is optional for a module, it will automatically be unchecked in CC-Link systems.
Use Word Output Data	When the module has Ww.n word output, this box will be checked. If the Ww.n word output data is optional for a module, it will automatically be unchecked in CC-Link systems.
OK button	Validates the settings and closes this screen.
Cancel button	Cancels the settings and closes this screen.

*1: For applicable base modules, refer to the manual of the module used.



Unlike PROFIBUS-DP systems, there is no selectable 'maximum input/output points' setting for CC-Link systems. The maximum number of input / output points is always fixed at 252 for CC-Link systems.

[PROFIBUS-DP systems]



DISPLAY/SETTING SCREEN

For head module

For slice module



DISPLAY/SETTING DATA

Item	Description
Model Name	Displays the product model name of the module for which option settings will be made.
Label Name	Enter any character string within 32 alphanumeric characters. As the label name is displayed on the "Module Configuration Window" screen or is output for printing, it is useful for module management, etc.
Base Module *1	Select the base module for the slice module. GX Configurator-ST does not distinguish between spring clamp (S) and screw (E) wiring types in the base module.
Maximum Input/Output Points	Head module version A: Set the Maximum Input/Output points for the head module. Head module version B: This input is not available as it is calculated automatically.
Use Word Input Data	When the module has Wr.n word input, check this check box to use the Wr.n word input.
Use Word Output Data	When the module has Ww.n word output, check this check box to use the Ww.n word output.
OK button	Validates the settings and closes this screen.
Cancel button	Cancels the settings and closes this screen.

*1: For applicable base modules, refer to the manual of the module used.

9.10 Power distribution check




PURPOSE

Checks whether the sum of 5VDC internal current consumption required by the modules is within the 5VDC maximum rated output current of the bus refreshing module.



For details of the calculation method used for this function, refer to the MELSEC-ST System User's Manual.



BASIC OPERATION


- (1) Execute any of the following operations.
 - Click the [Edit] → [Power Distribution Check] menu.
 - On the "Module Configuration Window" screen "Rack display" or "Module list" area, right-click a menu and click [Power Distribution Check] from the menu.
- (2) On the opened screen, confirm the check result.
- (3) Click the button to close this screen.



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
No.	Displays the mounting position of the bus refreshing module.
Supply Current (A)	Displays the 5VDC maximum rated output current of the bus refreshing module.
Consumption (A)	Displays the sum of 5VDC internal current consumption of the modules powered by the bus refreshing module.
Result	Displays the check result. "OK" : The sum of 5VDC internal current consumption is not greater than the 5VDC maximum rated output current of the bus refreshing module. "ERROR" : The sum of 5VDC internal current consumption is greater than the 5VDC maximum rated output current of the bus refreshing module.
<input type="button" value="Close"/>	Closes this screen.



To find the exact slot where the power consumption was exceeded (i.e. the slot which needs another power supply module installed just before it), look at the [module list](#), where the module will be highlighted in red.

9.11 Change head module type



PURPOSE

Changes the head module type, i.e. from PROFIBUS-DP to CC-Link, or from CC-Link to PROFIBUS-DP. This is not the same as 'online module change', and cannot be used to change the head module while the system is live. It only changes the configuration that is being edited.




An alternative way to perform this change is to simply connect to a MELSEC-ST system where the head module has already been replaced. If GX Configurator-ST detects that the connected system is identical except for the head module, you will be prompted to read the head module details from the system and continue.



BASIC OPERATION

- (1) Execute any of the following operations.
 - Click the [Edit] → [Change head module] menu.
 - On the "Module Configuration Window" screen "Rack display" or "Module list" area, right-click a menu and click [Change head module] from the menu.
- (2) In the confirmation dialog, select the new head module type from the list and then click the **Change** button.



- (3) A warning will be shown about the Wr and Ww ranges. Read this carefully and then select either **Yes** to continue or **No** to cancel.



When you change from a PROFIBUS-DP head module to a CC-Link head module, the parameter settings will be reset to defaults and all the modifiable 'without Wr' and 'without Ww' settings for intelligent modules will be reset to 'without' (as this feature is not used on CC-Link systems). This change is not reversible, so if you change back to a PROFIBUS-DP head module later, you will need to re-enter these settings.



When you change from CC-Link to PROFIBUS-DP, the PROFIBUS head module version is automatically set to protocol "Version B without command".



Perform the operation with the "Module Configuration Window" screen open.
To display the "Module Configuration Window" screen, choose the [View] → [Module Configuration] menu.

9.12 Change PROFIBUS-DP head module protocol version

[PROFIBUS-DP systems]

This functionality applies to PROFIBUS-DP systems only.



PURPOSE

The head module protocol version can be changed to have old configurations reset to newer ones.



To switch the ST-series head module from protocol version A to version B, an applicable head module has to be used, and the configuration needs to be set up via a GSD file and has to be downloaded to the PROFIBUS-DP master station.



BASIC OPERATION

Select a head module protocol version from the combo box in the module list.



DISPLAY/SETTING SCREEN

No.	Slice	Module Name	Unused Bits	Br(HEX)	Bw(HEX)	Wr(HEX)	Ww(HEX)	Label Name
0	0	ST1H-PB	-	-	-	00.0 - 12.F	00.0 - 12.F	
1	2	ST1PSD	-	-	-	-	-	
2	3	ST1X2-DE1	6	13.0 - 13.1	-	-	-	
3	4	ST1X16-DE1	-	13.8 - 14.7	-	-	-	
4	12	ST1Y2-R2	6	-	13.0 - 13.1	-	-	
5	13	ST1Y2-R2	6	-	13.8 - 13.9	-	-	
6	14	ST1AD2I	-	-	-	14.8 - 17.7	14.0 - 14.F	
7	16	ST1DA2V	-	-	-	17.8 - 18.7	16.0 - 18.F	
8	18	ST1DA1H	-	-	-	18.8 - 19.7	1A.0 - 1C.F	
9	20	ST1SS1	-	-	-	19.8 - 1C.7	1E.0 - 1E.F	



DISPLAY/SETTING DATA

Item	Description
GSD version	Displays the actual head module version. The setting can be changed to either A or B.
Head module mode	<p>For PROFIBUS-DP head module version A: With this combo box the actual point mode is shown or set (for offline configuration).</p> <p>For PROFIBUS-DP head module version B: With this combo box the actual mode (with or without command) is shown or set (for offline configuration).</p>



If the head module is changed from version B to version A, all modules that are not supported in version A (for example, reserved byte modules) will be removed from the configuration. When changing to version A, a warning message will be shown giving you the chance to cancel the change.

After changing the head module version to B, the conversion dialog will be shown:



PURPOSE

When changing from head module version A to B, reserved bytes and byte packed modules can automatically be inserted into the module configuration.



These options are only available when switching from head module version A to B.




BASIC OPERATION

Check the required options, then click OK.



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Reserved Byte	Inserts reserved bytes ahead of intelligent modules to ensure their address word is aligned.
Byte Pack	Inserts a byte pack module whenever possible to save memory.

10 Downloading and uploading the parameters

This chapter explains how to download or upload the parameters of each module.

10.1 Transfer setup



PURPOSE

Sets the connection with the head module.




BASIC OPERATION

- (1) Click the [Online] → [Transfer Setup] menu.
- (2) Make setting and click the **OK** button.



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
COM Port	Select the COM port connected with the head module. (Setting range: COM1 to COM10, default *1: COM1)
Transmission Speed	Select the transmission speed. (Setting range: 9.6kbps, 19.2kbps, 38.4kbps, 57.6kbps, default *1: 9.6kbps)
Timeout *2	When the external power supply of the MELSEC-ST system is switched off or the head module is reset during communication with the head module, it will take some time before a communication error is displayed. The monitor displays Executing until the error is displayed. The maximum time until the error is displayed can be found by the following expression. (Specified "Timeout" period) x 4 For example, when 5s was specified for "Timeout", (5s) x 4 = 20s and the error is displayed in a maximum of 20s. (Setting range: 1 to 9, default *1: 2)
 button	Validates the settings and closes this screen.
 button	Closes this screen without making settings.

- *1: When this screen is used the second or later time after installation of GX Configurator-ST, the default is the value set when this screen was used the last time.
- *2: If a communication error occurs during write to the ROM of each module, a maximum of 30s is required before the error is displayed.



When a transmission speed of 19.2kbps or higher is set to "Transmission Speed", some personal computers may be unstable, fail the communication and display the following screen.
In this case, set a lower transmission speed.





GX Configurator-ST 1.06G will only partially work with the new PROFIBUS-DP head module.

Head module set to PROFIBUS-DP version A:

If the head module is set to version A, there will be no problem as GX Configurator-ST 1.06G is fully compatible with this head module version.

Head module set to PROFIBUS-DP version B:

If the head module is set to version B, GX Configurator-ST 1.06G cannot communicate with the head module due to changes to the internal structure. Attempting to connect to the head module will display the error below.



This setting only applies to communications between GX Configurator-ST and the communication port on the head module. It is independent from the transmission speed used for communications between the master device and the PROFIBUS-DP or CC-Link communication port on the head module.

10.2 Get system



PURPOSE

Uploads the module configuration and the parameters from each module. This can be useful if you have a configured SLICE system, but do not have the configuration file that was originally used to build it.




BASIC OPERATION

- (1) Either:
 - Click the [Online] → [Get System] menu () , or
 - On the first wizard page (shown when GX Configurator-ST is started or after selecting [File] → [New]), select "Read the system configuration from the communication port" then click the button.
- (2) When the project is open, uploading the module configuration and the parameters of each module erases the project information uploaded previously. Hence, a screen appears asking whether data will be uploaded or not.
 - Click the button to display the "Get System" screen. In this case, the project information uploaded previously is erased.
 - Click the button to stop processing.
- (3) Set the data to be uploaded on the "Get System" screen, and click the button to upload the module configuration and the parameters of each module.
- (4) When upload is completed, the "Completed" message is displayed. Click the button.



DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Read Parameter	Check this check box to upload the parameters of each module. The module configuration is uploaded regardless of the setting of this item.
RAM	Uploads the parameters from the RAM of each module. This item is available only when the "Read Parameter" check box is checked.
ROM	Uploads the parameters from the ROM of each module. When the target module does not have the ROM, the parameters are uploaded from the RAM. This item is available only when the "Read Parameter" check box is marked.
button	Validates the settings and closes this screen. On completion, the new configuration will be available for editing.
button	Closes this screen without making settings.

10.3 Get input / output data settings (PROFIBUS-DP only)



PURPOSE

Uploads the input/output data settings made using GX Configurator-ST from each module.

The following two different input/output data settings are uploaded.

- Maximum Input/Output points of the head module
- Setting of whether the Wr.n word input/ Ww.n word output of the intelligent function module are used or not



BASIC OPERATION

- (1) Click the [Online] → [Get Input/Output Data Settings] menu.
- (2) A screen appears asking whether the settings will be uploaded or not.
Click the OK button to upload the input/output data settings.
- (3) When upload is completed, the "Completed" message is displayed.
Click the OK button.

10.4 Parameter block write



PURPOSE

Downloads the parameters to the modules in a block.




BASIC OPERATION

- (1) Click the [Online] → [Parameter Block Write] menu to display the "Parameter Block Write" screen.
- (2) Select the target memory and parameters, and click the **Download** button.
- (3) When download is completed, the "Download Completed" message is displayed.
Click the **OK** button.
- (4) To close this screen, click the **Close** button.




DISPLAY/SETTING SCREEN


Preparing to download



Downloading



 **DISPLAY/SETTING DATA**

Item	Description
Select Data	Batch-select the modules whose the parameters will be downloaded.
 button	Selects all modules.
 button	Deselects all modules.
Target Memory	Select the memory where the parameters will be downloaded. <ul style="list-style-type: none"> • When "RAM" is selected, the parameters are downloaded to the RAM of each module. • When "ROM" is selected, the parameters are downloaded to the ROM of each module. • When "RAM/ROM" is selected, the parameters are downloaded to both RAM and ROM of each module.
 button	Downloads the parameters of the module specified at "Select". While the parameters are downloaded, this button cannot be clicked.
 button	Stops download. Only while the parameters are downloaded, this button can be clicked.
Select *1	Select the module whose parameters will be downloaded, by clicking on the 'Select' button to the left of the module name, so that it appears checked: <div style="text-align: center;">  </div>
No. *1	Displays the module No.
Module Name *1	Displays the module name.
Status *1	Displays the download execution status. Refer to (1) in this section for details of the execution status.
 button	Closes this screen. While the parameters are downloaded, this button cannot be clicked.

*1: For the module whose parameters cannot be edited, this item is grayed out and is not available, as parameter download is not necessary.

(1) Download execution status

Details of the download execution status are described below.

Display	Description
—	Indicates the module that does not have parameters or to which parameters are not downloaded.
Wait	Indicates the status prior to download.
Writing...	Indicates that download is in progress.
Complete	Indicates that download is completed.
Error	Indicates a failure in download.

10.5 Offset/Gain setting of intelligent function modules



For details of this function, refer to the manual of the used intelligent function module.



PURPOSE

Sets the offset value or gain value of the intelligent function module*1.

*1: The following gives the examples of the intelligent function modules to which the offset or gain value can be set.

• ST1AD2-V	• ST1AD2-I
• ST1DA2-V	• ST1DA1-I
• ST1DA2-V-F01	• ST1DA1-I-F01

For details, refer to the manual of the used intelligent function module.




BASIC OPERATION

- (1) On the "System Monitor" screen, select the intelligent function module for which the setting will be made.
- (2) On the "System Monitor" screen, click the **ON** button of "Forced Output Test Mode" to change the MELSEC-ST system to the forced output test mode. When the MELSEC-ST system is changed to the forced output test mode, the RUN LED of the head module flickers.
- (3) Execute any of the following operations.
 - Click the [Online] → [Offset/Gain Setting] menu.
 - Right-click the module selected in (1), and click **Offset/Gain Setting** from the menu.
 - Click the [Offset/Gain Setting] button on the "System Monitor" screen.
- (4) The dialog box appears asking whether or not the MELSEC-ST system will be changed to the offset/gain setting mode. Click the **OK** button to change the system to the offset/gain setting mode. When the system changes to the offset/gain setting mode, the RUN LED of the target intelligent function module flickers (at 0.5s intervals) and the module's operation is stopped.
- (5) Select the channel to be set at "Select Channel", choose the wiring method of the base module at "Connection Method", and select the value to be set from "Offset" or "Gain".
- (6) Set the offset or gain value adjustment amount, and click the **Set** button. Repeat the operation in Step (6) until the desired value is reached.

- (7) Click the **Save** button to download the offset or gain value to that intelligent function module.
- (8) To close this screen, click the **Close** button.
- (9) The dialog box appears asking whether or not the MELSEC-ST system will be released from the offset/gain setting mode.
Click the **Yes** button to release the system from the offset/gain setting mode.

REMARK

- (a) If the MELSEC-ST system is not in the forced output test mode after the operation in Step (3) is performed, the dialog box appears asking whether or not the MELSEC-ST system will be changed to the forced output test mode.
Click the **OK** button to change the system to the forced output test mode.
- (b) If the MELSEC-ST system is changed to the forced output test mode in (a), the dialog box appears asking whether or not the MELSEC-ST system will be released from the forced output test mode after the operation in Step (9) is performed.
Click the **Yes** button when releasing the system from the forced output test mode.
Click the **No** button when not releasing the system from the forced output test mode.

**DISPLAY/SETTING SCREEN**



DISPLAY/SETTING DATA

Item	Description
Module Information	Displays the information (No., start slice No., module name, label name, base module) of the target intelligent function module.
Select Channel	Select the channel to which the offset or gain value will be set. When multiple channels are checked, the offset or gain values will be set to all the corresponding channels. The channels displayed in this item change depending on the module of the setting target. For details, refer to the manual of the used intelligent function module.
Offset	Set the offset value adjustment amount. This item is available only when the "Offset" radio button is selected. For details, refer to the manual of the used intelligent function module.
Gain	Set the gain value adjustment amount. This item is available only when the "Gain" radio button is selected. For details, refer to the manual of the used intelligent function module.
<input type="button" value="Error Clear"/> button	Turns ON the <input type="button" value="Ew.n"/> Error Clear to clear the error of the intelligent function module.
<input type="button" value="Set"/> button	Applies the set value to the target module.
<input type="button" value="Save"/> button	Validates the value set with the <input type="button" value="Set"/> button.
<input type="button" value="Close"/> button	Closes this screen and releases the system from the offset/gain setting mode. Releases the MELSEC-ST system from the forced output test mode if it was not in the forced output test mode when this screen was opened.

11 Monitor, Test

This chapter explains how to monitor and test the modules.




If during monitoring the PROFIBUS head module receives new configuration data (e.g. it is switched from version A to version B), all monitoring must be stopped and the monitoring windows must be closed and reopened / restarted to avoid indication errors.

11.1 System Monitor



PURPOSE

Monitors the statuses of the head module and slice modules.



BASIC OPERATION

- (1) When the "System Monitor" screen is not displayed, click the [View] → [System Monitor] menu to display the "System Monitor" screen.
This menu item is only available when the system is in "Diagnosis" mode. To switch to "Diagnosis" mode, [Mode] → [Diagnosis].
- (2) Monitor starts as soon as the "System Monitor" screen is displayed.
- (3) To close this screen, click the button.



The "System Monitor" screen is not displayed if the module configuration of the MELSEC-ST system connected to the personal computer differs from that of the project.

There is one exception to this - if the configurations are identical except for the head module type, a message is shown giving the option to copy the head module details from the live system and continue. This is intended to make it easier to reuse configuration projects when changing the protocol type for a MELSEC-ST system.


Display the "System Monitor" screen after confirming that their module configurations are the same.

HELPFUL OPERATION

To identify the module where an error has occurred, execute the following operation on the "System Monitor" screen.



- (1) At "Select Module", confirm the area displayed red or yellow.
- (2) Click the **Display Position** button corresponding to the area confirmed in (1).
- (3) The module whose "Module Status" in the "Module display" is displayed red or yellow is where the error occurred.
 Scroll the "Module display" to identify the module whose "Module Status" in the "Module display" is displayed red or yellow.

DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Module Information	Displays the information (module name, label name, base module) of the module selected in the "Module display".

Item	Description
Communication Status With Master Station	Indicates the status of communication between the head module and master station. "Communicating" : Communicating with the master station "Communication suspended" : Communication with the master station suspended (Interruption) "No communication" : Communication with the master station stopped (No communication)
Module Status	Displays the samples of the colors displayed under "Select Modules" and under "Module Status" in the "Module display". ■ Red : System error ■ Yellow : Warning ■ Purple : Module being changed online
Module display	Displays the illustrative image of the MELSEC-ST system being monitored. When using the function specific to a certain module, click and select the module from this item. At "Module Status" above the module, the operating status of the slice module is displayed. Refer to (1) in this section for details of the module status.
Selected module	The currently selected module is shown with the slot number coloured in grey. Click on a module to select it.
Select Module Range	The numerals indicate the module Nos., and the color shows the statuses of the modules in that range. The modules displayed in the "Module display" can be changed. Refer to (1) in this section for details of the module status.
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Display Position</div> button	The numerals on the left of this button indicates the module Nos., and the corresponding modules are displayed in the "Module display".
Monitor Switch	Starts/stops monitor.
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Start</div> button	Starts monitor. This button is usable only while monitor is at a stop. While monitor is executed, " * " flickers on the left side of this button. 
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Stop</div> button	Stops monitor. This button is usable only while monitor is executed.
Forced Output Test Mode	Sets/releases the MELSEC-ST system to/from the forced output test mode, and displays the current mode status. 
<div style="border: 1px solid black; padding: 2px; display: inline-block;">ON</div> button	Sets the MELSEC-ST system to the forced output test mode.

Item	Description
<input type="checkbox"/> OFF button	Releases the MELSEC-ST system from the forced output test mode.
<input type="checkbox"/> Input/Output Monitor button	Monitors the input data and output data of the module selected in the "Module display". Refer to 'Input/Output monitor' for details. When no module has been selected, the error message is displayed and monitor cannot be executed.
<input type="checkbox"/> Forced Output Test button	Runs a forced output test on the head module, output module or intelligent function module selected in the "Module display". Refer to 'Forced output test' for details. When no module has been selected, the error message is displayed and the forced output test cannot be executed.
<input type="checkbox"/> Offset/Gain Setting button	Sets the offset or gain value to the target intelligent function module which is selected in the "Module display". Refer to 'Offset/Gain setting of intelligent function modules' for details. When no module has been selected, the error message is displayed and the offset or gain value cannot be set.
<input type="checkbox"/> Module Detail Information button	Monitors the detail information and error status of the module selected in the "Module display". Refer to 'Module detail information' for details. When no module has been selected, the error message is displayed and monitor cannot be executed.
<input type="checkbox"/> Online Module Change button	Performs the online change of the I/O module or intelligent function module selected in the "Module display". Refer to 'Online module change' for details. When no module has been selected, the error message is displayed and online module change cannot be executed.
<input type="checkbox"/> Parameter Setting button	Sets the parameters to the head module, I/O module or intelligent function module selected in the "Module display". Refer to Section 'Parameter setting' for details. When no module has been selected, the error message is displayed and parameter setting cannot be executed.
<input type="checkbox"/> Close button	Closes this screen.

(1) Module status

Details of the module status are described below.

Display	Description
<input checked="" type="checkbox"/> Red	System error occurred. For details of the error, refer to the manual of the corresponding module.
<input checked="" type="checkbox"/> Yellow	Warning occurred. For details of the warning, refer to the manual of the corresponding module.
<input checked="" type="checkbox"/> Purple	Module being changed online
<input type="checkbox"/> Gray	Module not mounted Gray is displayed for "Select Module" only.
<input type="checkbox"/> White	Operating normally



If the slice module is changed for another type of module during a monitor stop on this screen and the monitor is then resumed, the items corresponding to the new module and modules of the following Nos. are displayed red in the "Module Status" section.

11.2 Module detail information



PURPOSE

Shows the module detail information, and monitors the corresponding module operation status and error status.



BASIC OPERATION

- (1) On the "System Monitor" screen, select the module to be monitored.
- (2) Execute any of the following operations to display the "Module Detail Information" screen and start monitor.
 - Click the [Diagnostics] → [Module Detail Information] menu.
 - Right-click the module selected in (1), and click [Module Detail Information] from the menu.
 - Click the **Module Detail Information** button on the "System Monitor" screen.
- (3) To update the operation status or error status, click the **Refresh** button.
- (4) To close this screen, click the **Close** button.

[CC-Link systems]



DISPLAY/SETTING SCREEN

For head module

Module Detail Information

Module Detail Information
 Module Name : ST1H-BT
 Label Name :
 Station no. : 1
 Excl. station count : 1
 Exp. cyclic setting : Double
 Version : ZJJ
 Mode : Priority min. stations
 Communication Baud Rate : 5Mbps

Current Error/Status

No.(HEX)	Current Error/Status
0000	No error

Buttons: Refresh, Close

Error/Status Log

No.(HEX)	Error/Status Log

Buttons: Clear Log

Callouts: Module information, Active error, Update information, Clear error history, Error history

For power distribution module, I/O module or intelligent function module

Module Detail Information

Module Detail Information
 Slice No. : 7
 Module Name : ST1DA1-I
 Label Name :
 Base Module : ST1B-4IR2
 Version : B A A
 Br(HEX) : 0E - 11
 Bw(HEX) : 0E - 11
 Wr(HEX) : -
 Ww(HEX) : 02 - 03

Current Error

No.(HEX)	Current Error
0000	No error

Buttons: Refresh, Close

Callouts: Module details, Address range, Active error, Update information



DISPLAY/SETTING DATA

Item	Description
Module Detail Information	<p>Displays the information of the module to be monitored. This item includes the following information.</p> <ul style="list-style-type: none"> • Start slice No. *1 • Module name • Label name • Station No. *2 "---" is displayed if the Station No. set with the address setting switches of the head module is outside the setting range. For details, refer to "Current Error/Status" or "Error/Status Log" on this screen. • Base module name *1 • Excl. station count*2 - the number of stations used for communications. • Exp. cyclic setting*2 - the number of cycles taken to read the data. • Version The module version is displayed. If a module does not support this, "- -" is displayed instead. • Mode *2 • Communication baud rate *2 "--" is shown if the MELSEC-ST system is not communicating with the master station. • <input type="text" value="Br.n"/> Bit Input *1/ <input type="text" value="Bw.n"/> Bit Output *1/ <input type="text" value="Wr.n"/> Word Input *1' *3/ <input type="text" value="Ww.n"/> Word Output *1' *3
Current Error/Status *2, *4	Displays the current operation status or error information of the head module.
<input type="text" value="No. (HEX)"/>	Displays the error code in hexadecimal.
<input type="text" value="Current Error/Status"/>	Displays the operation status or error definition.
Current Error *1, *4	Displays the current operation status or error information of the target module.
<input type="text" value="No. (HEX)"/>	Displays the error code in hexadecimal.
<input type="text" value="Current Error/Status"/>	Displays the operation status or error definition.
Error/Status Log *2, *4	<p>Displays the operation status or error history of the head module. The latest log is displayed in the top line (descending order). This item displays up to five status or error logs. When information is added as the sixth status or error, the information is deleted in the order from the oldest to the newest. Switching off the external power of the MELSEC-ST system or resetting the head module erases the data of this item.</p>
<input type="text" value="No. (HEX)"/>	Displays the error code in hexadecimal.
<input type="text" value="Error/Status Log"/>	Displays the operation status or error definition.
<input type="button" value="Refresh"/>	Updates the data of "Current Error/Status" and "Error/Status Log".
<input type="button" value="Close"/>	Closes this screen.
<input type="button" value="Clear Log"/>	Erases the data of "Error/Status Log". The data of "Current Error/Status" are not erased.

- *1: This item is available for the power distribution module, I/O module or intelligent function module. GX Configurator-ST does not distinguish between spring clamp (S) and screw (E) wiring types in the base module.
- *2: This item is available for the head module.
- *3: “-” is displayed for the **Br.n** Bit Input / **Bw.n** Bit Output / **Wr.n** Word Input / **Ww.n** Word Output when the target module does not occupy the corresponding area.
- *4: For details of the errors, refer to the manual of the corresponding module.



In CC-link systems, the address ranges are sometimes referred to differently. CClink's 'RX' and 'RY' ranges are equivalent to the 'Br' and 'Bw' ranges shown in GX Configurator-ST and CC-link's 'RWi' and 'RWw' ranges are equivalent to 'Wr' and 'Ww'.

[PROFIBUS-DP systems]

DISPLAY/SETTING SCREEN

For head module

Module Detail Information

Module Detail Information
 Module Name : ST1H-PB
 Label Name :
 FDL Address : 42
 Version : A A A
 Maximum Input/Output Points : 256-pt mode Transmission Speed : -

Current Error/Status

No. (HEX)	Current Error/Status
0000	No error

Error/Status Log

No. (HEX)	Error/Status Log

Buttons: Refresh, Close, Clear Log

Callouts: Module information, Update information, Active error, Clear error history

For power distribution module, I/O module or intelligent function module

Module Detail Information

Module Detail Information
 Slice No. : 7
 Module Name : ST1DA1H
 Label Name :
 Base Module : ST1B-*4IR2
 Version : B A A
 Br(HEX) : 0E-11
 Bw(HEX) : 0E-11
 Wr(HEX) : -
 Ww(HEX) : 02-03

Current Error

No. (HEX)	Current Error
0000	No error

Buttons: Refresh, Close

Callouts: Module details, Address range, Update information



DISPLAY/SETTING DATA

Item	Description
Module Detail Information	<p>Displays the information of the module to be monitored. This item includes the following information.</p> <ul style="list-style-type: none"> • Start slice No. *1 • Module name • Label name • FDL Address *2 "---" is displayed if the FDL address set with the FDL address setting switches of the head module is outside the setting range (100 or later). For details, refer to "Current Error/Status" or "Error/Status Log" on this screen. • Base module name *1 • Version The module version is displayed. If a module does not support this, " - - " is displayed instead. • Maximum Input/Output points *2 • Transmission speed *2 "- " is displayed when the MELSEC-ST system is not communicating with the master station. • <input type="text" value="Br.n"/> Bit Input *1/ <input type="text" value="Bw.n"/> Bit Output *1/ <input type="text" value="Wr.n"/> Word Input *1, *3/ <input type="text" value="Ww.n"/> Word Output *1, *3
Current Error/Status *2, *4	Displays the current operation status or error information of the head module.
<input type="text" value="No. (HEX)"/>	Displays the error code in hexadecimal.
<input type="text" value="Current Error/Status"/>	Displays the operation status or error definition.
Current Error *1, *4	Displays the current operation status or error information of the target module.
<input type="text" value="No. (HEX)"/>	Displays the error code in hexadecimal.
<input type="text" value="Current Error/Status"/>	Displays the operation status or error definition.
Error/Status Log *2, *4	<p>Displays the operation status or error history of the head module. The latest log is displayed in the top line (descending order). This item displays up to five status or error logs. When information is added as the sixth status or error, the information is deleted in the order from the oldest to the newest. Switching off the external power of the MELSEC-ST system or resetting the head module erases the data of this item.</p>
<input type="text" value="No. (HEX)"/>	Displays the error code in hexadecimal.
<input type="text" value="Error/Status Log"/>	Displays the operation status or error definition.
<input type="button" value="Refresh"/>	Updates the data of "Current Error/Status" and "Error/Status Log".
<input type="button" value="Close"/>	Closes this screen.
<input type="button" value="Clear Log"/>	Erases the data of "Error/Status Log". The data of "Current Error/Status" are not erased.

*1: This item is available for the power distribution module, I/O module or intelligent function module.
GX Configurator-ST does not distinguish between spring clamp (S) and screw (E) wiring types in the base module.

*2: This item is available for the head module.

*3: For the **Wr.n** Word Input/ **Ww.n** Word Output, "-" is displayed when the target module does not occupy the corresponding area.

*4: For details of the errors, refer to the manual of the corresponding module.

11.3 Input/Output monitor



PURPOSE

Monitors the input data and output data of the module.



BASIC OPERATION

- (1) On the "System Monitor" screen, select the module to be monitored.
- (2) Execute any of the following operations to display the "Input/Output Monitor" screen and start monitor.
 - Click the [Online] → [Input/Output Monitor] menu.
 - Right-click the module selected in (1), and click [Input/Output Monitor] from the menu.
 - Click the **Input/Output Monitor** button on the "System Monitor" screen.
- (3) To close this screen, click the **Close** button.



In CC-Link systems, the following areas are not available for I/O monitoring:

- **Ew.n** Error Clear area
- **Wr.n** Word Input area of intelligent output modules
- **Ww.n** Word Output area of intelligent input modules



DISPLAY/SETTING SCREEN

Input/Output Monitor No.4

Monitor Switch
 Start Stop Start / stop monitoring

Module Information
 Slice No. : 7
 Module Name : ST1DA1H Module details
 Label Name :

Bit Data

Output Data	Item	Value	Input Data	Item
Bit Output Area	Convert setting request	No request	Bit Input Area	Module ready
	CH1 output enable/disable flag	Disable		Convert setting completed fl
Error Clear Area	Error clear request	No request	Error Information Area	CH1 error information

Bit input / output data

Word Data

DEC HEX


Output Data	Item	Value	Input Data	Item	Value
Word Output Area	CH1 digital value setting	0	Word Input Area	CH1 digital value	0

Word input / output data



DISPLAY/SETTING DATA

Item	Description
Monitor Switch	Starts/stops monitor.
Start button	Starts monitor. This button is usable only while monitor is at a stop. While monitor is executed, " * " flickers on the left side of this button.
Stop button	Stops monitor. This button is usable only while monitor is executed.
Close button	Closes this screen.
Module Information	Displays the information (start slice No., module name, label name) of the module to be monitored.
Bit Data *1	Displays the input/output data of the target module in bit unit.
Word Data *1	When the target module is the intelligent function module, displays the Wr.n Word Input values and Ww.n Word Output values. Selecting the DEC or HEX radio button displays the values displayed under "Value" in decimal or hexadecimal. DEC: Decimal HEX: Hexadecimal



*1: For details of each data, refer to the manual of the corresponding module.

*2: When the MELSEC-ST system is in the forced output mode, the values entered on the "Forced Output Test" screen are displayed.



The rate at which values are updated on the "Input / Output Monitor" screen depends on the following conditions:

- Transmission speed (refer to [Transfer Setup](#))
- The number of open input/output monitor windows
- The status of the system monitor

To get the best input/output monitor performance:

- Do not open several input/output monitor windows
- Stop the system monitor

The following refers to PROFIBUS-DP head module version B only



DISPLAY/SETTING SCREEN

Input/Output Monitor No.4

Monitor Switch: *Start / Stop monitoring*

Module Information:

Slice No. : 5
 Module Name : ST1DA2V *Module details*
 Label Name :

Input/Output Data: DEC HEX

Output Data	Item	Value	Input Data	Item	Value
Bit Output Area	Convert setting request	No request	Bit Input Area	Module ready	Ready
	CH1 output enable/disable flag	Disable		Convert setting completed flag	No request
	CH2 output enable/disable flag	Disable	Word Input Area	CH1 digital value	0
Word Output Area	CH1 digital value setting	0		CH2 digital value	0
	CH2 digital value setting	0			

Input / Output data

Error Data:

Output Data	Item	Value	Input Data	Item	Value
Error Clear Area	Error clear request	No request	Error Information Area	CH1 error information	No error
				CH2 error information	No error

Error data



DISPLAY/SETTING DATA

Item	Description
Monitor Switch	Starts/stops monitor.
<div style="border: 1px solid black; padding: 5px; display: inline-block; margin-bottom: 5px;">Start</div> button	Starts monitor. This button is usable only while monitor is at a stop. While monitor is executed, " * " flickers on the left side of this button. <div style="text-align: center; margin-top: 10px;"> </div>
<div style="border: 1px solid black; padding: 5px; display: inline-block; margin-bottom: 5px;">Stop</div> button	Stops monitor. This button is usable only while monitor is executed.
<div style="border: 1px solid black; padding: 5px; display: inline-block; margin-bottom: 5px;">Close</div> button	Closes this screen.
Module Information	Displays the information (start slice No., module name, label name) of the module to be monitored.
I/O data *1 *2 *3	Displays the input/output data of the target module. When the target module is the intelligent function module, displays the Wr.n Word Input values and Ww.n Word Output values. Selecting the DEC or HEX radio button displays the values displayed under "Value" in decimal or hexadecimal. DEC: Decimal HEX: Hexadecimal
Error Data *1	Displays error data of the target module

*1: For details of each data, refer to the manual of the corresponding module.

*2: When the MELSEC-ST system is in the forced output mode, the values entered on the "Forced Output Test" screen are displayed.

*3: In the case of an intelligent module which does not have an input sending area, output data will be displayed in the input area / fields for troubleshooting. For example, if the output data values are not being sent correctly, this display can be used to confirm that the output data reached the intelligent module.

11.4 Forced output test



PURPOSE

Runs an output test on the Bit Output, Word Output and Error Clear bits of the head module and slice modules without stopping the PROFIBUS-DP or CC-Link network.



BASIC OPERATION

- (1) On the "System Monitor" screen, select the module to be monitored.
- (2) On the "System Monitor" screen, click the button of "Forced Output Test Mode". This displays a screen asking whether or not the MELSEC-ST system will be changed to the forced output test mode.
 - Click the button to change the MELSEC-ST system to the forced output test mode.
 - When the MELSEC-ST system is changed to the forced output test mode, the RUN LED of the head module flickers.
- (3) Execute any of the following operations to display the "Forced Output Test" screen.
 - Click the [Online] → [Forced Output Test] menu.
 - Right-click the module selected in (1), and click [Forced Output Test] from the menu.
 - Click the button on the "System Monitor" screen.
- (4) On the "Forced Output Test" screen, select the forced output test item and set data, and click the button to start the forced output test.
- (5) When the forced output test is completed, the "Completed" message is displayed.
 - Click the button.
- (6) To close this screen, click the button.
- (7) On the "System Monitor" screen, click the button of "Forced Output Test Mode" to release the MELSEC-ST system from the forced output test mode.



- (1) If any of **Bw.n+1** Convert setting request, **Bw.n+3**, **Bw.n+2** CH□ output permission ON/OFF, and **Ww.n**, **Ww.n+1** CH□ digital value setting is changed in the forced output test, fully ensure safety before starting the test as the analog output will change.
- (2) When the communication between the MELSEC-ST system and master station is disconnected, changing the **Bw.n+1** Convert setting request of the intelligent function module, whose CH□ CLEAR/HOLD/PRESET setting is set to HOLD, from ON to OFF in the forced output test turns the **Ww.n** Word Output value to 0. In this case, the **Ww.n** Word Output value will not return to the held value if the forced output test mode is canceled.



In CC-Link systems, the following areas are not available for forced output tests:

- **Ww.n** Word Output area of intelligent input modules

REMARK

- (a) If the MELSEC-ST system is not in the forced output test mode when the **Set** button is clicked in (4), a screen appears asking whether or not the MELSEC-ST system will be changed to the forced output test mode. Click the **OK** button to change the system to the forced output test mode and start the forced output test.
- (b) When the MELSEC-ST system was changed to the forced output test mode in (a), a screen appears asking whether or not the system will be released from the forced output test mode after the operation in Step (6) is performed. Click the **Yes** button when releasing the system from the forced output test mode. Click the **No** button when not releasing the system from the forced output test mode.



DISPLAY/SETTING SCREEN

■ Forced Output Test No.4
_ □ ×

Select /
deselect all
items

Module Information

Slice No. : 5

Module Name : ST1DA2V

Label Name :

Bit Data

Output Data	Select	Item Name	Value
Bit Output Area	<input type="checkbox"/>	Convert setting request	No request
	<input type="checkbox"/>	CH1 output enable/disable flag	Disable
	<input type="checkbox"/>	CH2 output enable/disable flag	Disable

Word Data

DEC HEX

Output Data	Select	Item Name	Value
Word Output Area	<input type="checkbox"/>	CH1 digital value setting	0
	<input type="checkbox"/>	CH2 digital value setting	0

Error Clear Data

Output Data	Select	Item Name	Value
Error Clear Area	<input type="checkbox"/>	Error clear request	No request

167



DISPLAY/SETTING DATA

Item	Description
<p>Select All button</p>	<p>Checks all "Select" check boxes of "Bit Data" and "Word Data". A 'tick' is shown to indicate that the parameter is selected, as shown in the picture below.</p> 
<p>Release All button</p>	<p>Unchecks all "Select" check boxes of "Bit Data" and "Word Data".</p>
<p>Set button</p>	<p>Runs a forced output test on the Bw.n Bit Output, Ww.n Word Output*2 and (in PROFIBUS-DP only) Ew.n Error Clear whose "Select" check boxes are checked. (Ew.n Error Clear bits are available for PROFIBUS-DP only) When the forced output test is completed, the "Completed" message is displayed.</p>
<p>Close button</p>	<p>Closes this screen. The screen to release the MELSEC-ST system from the forced output test mode is displayed if the system was not in the forced output test mode when this screen was opened.</p>
<p>Module Information</p>	<p>Displays the information (start slice No., module name, label name) of the module on which a forced output test will be conducted.</p>
<p>Bit Data *1</p>	<p>Select the bit data on which a forced output test will be conducted by checking the corresponding "Select" check box, and set the bit value to be output at "Value".</p>
<p>Word Data *1 *2</p>	<p>Select the word data on which a forced output test will be conducted by checking the corresponding "Select" check box, and set the word value to be output at "Value". Selecting the DEC or HEX radio button changes the input format of "Value" to decimal or hexadecimal. DEC: Decimal HEX: Hexadecimal</p>
<p>Error clear data</p>	<p>Select the error clear data on which a forced output test will be conducted by checking the corresponding "Select" check box, and set the word value to be output at "Request".</p>

*1: For details of each data, refer to the manual of the corresponding module.

*2: In CC-Link systems, word output data is not available for intelligent input modules.

11.5 Master station data communication monitor

11.5.1 Master station data communication monitor



PURPOSE

Monitors the input/output data between the master station and head module of the PROFIBUS-DP or CC-Link system.



BASIC OPERATION

- (1) Click the [Diagnostics] → [Master Station Data Communication Monitor] menu to display the "Master Station Data Communication Monitor" screen and start monitor.
- (2) At "Select Area", select the I/O data to be displayed in the "Data display".
- (3) To save the monitored data into a text file, click the **Stop** button to stop monitor, and click the **Copy to File** button.
Refer to ['Saving the communication data'](#) for details.
- (4) To close this screen, click the **Close** button.



DISPLAY/SETTING SCREEN


The screenshot shows the 'Master Station Data Communication Monitor' window. It includes a 'Select Area' dropdown set to 'Bit Input Area', 'Word Data' format options (DEC(signed), DEC(unsigned), and selected HEX), and 'Copy to File', 'Close', 'Start', and 'Stop' buttons. A data table displays bit patterns and word data (e.g., H4440, H0000).

Address	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	Word Data
0	0	1	0	0	0	1	0	0	0	1	0	0	0	0	0	0	H4440
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
6	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
C	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
D	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
E	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000
F	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	H0000

[CC-Link systems]



DISPLAY/SETTING DATA


Item	Description
Select Area *1	From among the following items, select the I/O data to be displayed in the "Data display". Bit Output Area : Bw Bit Output Area Word Output Area : Ww Word Output Area Bit Input Area : Br Bit Input Area Word Input Area : Wr Word Input Area
<input type="button" value="Copy to File"/> button	Saves the monitored data into a text file. Refer to ' Saving the communication data ' for details. While monitor is executed, this button is not usable. Save the data after clicking the <input type="button" value="Stop"/> button to stop monitor.
<input type="button" value="Close"/> button	Closes this screen.
Word Data	Changes the representation of the word values in the text file to be saved with the <input type="button" value="Copy to File"/> button and in the "Data display".
DEC(signed)	Displays the values in signed decimal.
DEC(unsigned)	Displays the values in unsigned decimal.
HEX	Displays the values in hexadecimal headed by "H".
Monitor	Starts/stops monitor.
<input type="button" value="Start"/> button	Starts monitor. This button is usable only while monitor is at a stop. While monitor is executed, " * " flickers on the left side of this button. 
<input type="button" value="Stop"/> button	Stops monitor. This button is usable only while monitor is executed.
Data display *1	Displays the data in the data range selected at "Select Area". "Address" is the offset address of the data selected at "Select Area", with Address 0 set as the start address.

*1: For details of the I/O data, refer to the Head Module Manual.

[PROFIBUS-DP systems]



DISPLAY/SETTING DATA

Item	Description
Select Area *1	<p>From among the following items, select the I/O data to be displayed in the "Data display".</p> <p>PROFIBUS-DP version A:</p> <p>All Area : All I/O data Bit Output Area : Bw Bit Output Area Error Clear Area : Ew Error Clear Area System Area : Sw System Area Command Execution Area : Cw Command Execution Area Word Output Area : Ww Word Output Area Bit Input Area : Br Bit Input Area Error Information Area : Er Error Information Area Module Status Area : Mr Module Status Area Command Result Area : Cr Command Result Area Word Input Area : Wr Word Input Area</p> <p>PROFIBUS-DP version B:</p> <p>All Area : All I/O data Output Area : Output Area only *2 Input Area : Input Area only *2</p>
Copy to File button	<p>Saves the monitored data into a text file. Refer to 'Saving the communication data' for details. While monitor is executed, this button is not usable. Save the data after clicking the Stop button to stop monitor.</p>
Close button	Closes this screen.
Word data	<p>Changes the representation of the word values in the text file to be saved with the Copy to File button and in the "Data display".</p>
DEC(signed)	Displays the values in signed decimal.
DEC(unsigned)	Displays the values in unsigned decimal.
HEX	Displays the values in hexadecimal headed by "H".
Monitor	Starts/stops monitor.
Start button	<p>Starts monitor. This button is usable only while monitor is at a stop. While monitor is executed, "x" flickers on the left side of this button.</p> 
Stop button	<p>Stops monitor. This button is usable only while monitor is executed.</p>
Data display *1	<p>Displays the data in the data range selected at "Select Area". "Address" is the offset address of the data selected at "Select Area", with Address 0 set as the start address.</p>

*1: For details of the I/O data, refer to the Head Module Manual.

*2: In PROFIBUS-DP version B systems, the input/output area layout depends on the configuration details (for example, byte packing).

REMARK

When confirming the data for each module, use the "Input/Output Monitor" screen.
Refer to ['Input/Output monitor'](#) for details.

11.5.2 Saving the communication data



PURPOSE

Saves the I/O data, which were monitored on the "Master Station Data Communication Monitor" screen in ['Master station data communication monitor'](#), into a text file.




BASIC OPERATION

- (1) On the "Master Station Data Communication Monitor" screen, click the **Stop** button to stop monitor, and then click the **Copy to File** button.
- (2) Set the destination directory and file name, and click the **Save** button to save the monitored data into a text file and close this screen.



DISPLAY/SETTING SCREEN




DISPLAY/SETTING DATA

Item	Description
Save in	Select the directory that stores the monitored data.
File name	Set the file name of the monitored data.
Save button	Saves the project with the file name specified at "File name".
Cancel button	Closes this screen without saving the project.

(1) Example of text file for saving data

The following shows an example of the text file for saving data.



```

GX Configurator-ST Master Station Data Communication Monitor
Monitor Data : All Area
0000 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 : H0000
0001 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 : H0000
0002 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 : H0000
0003 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 : H0000
0004 : 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 : H0000

```

11.6 PROFIBUS-DP Network Parameter Monitor (PROFIBUS DP only)

11.6.1 PROFIBUS-DP Network parameter monitor



PURPOSE


Confirms of the slave parameters and PROFIBUS-DP network parameters sent from the master station of PROFIBUS-DP to the MELSEC-ST system.



BASIC OPERATION

- (1) Click the [Diagnostics] → [PROFIBUS-DP Network Parameter Monitor] menu to display the "PROFIBUS-DP Network Parameter Monitor" screen and start monitor.
- (2) To save the monitored data into a text file, click the **Stop** button to stop monitor, and click the **Copy to File** button.
Refer to '[Saving the PROFIBUS-DP network parameter data](#)' for details.
- (3) To close this screen, click the **Close** button.

DISPLAY/SETTING SCREEN



DISPLAY/SETTING DATA

Item	Description
Monitor	Starts/stops monitor.
Start button	Starts monitor. This button is usable only while monitor is at a stop. While monitor is executed, " * " flickers on the left side of this button.
Stop button	Stops monitor. This button is usable only while monitor is executed.
Copy to File button	Saves the monitored data into a text file. Refer to 'Saving the PROFIBUS-DP network parameter data' for details. While monitor is executed, this button is not usable. Save the data after clicking the Stop button to stop monitor.
Close button	Closes this screen.
Data display *1	Displays the slice module parameters and PROFIBUS-DP parameters sent from the master station of PROFIBUS-DP to the MELSEC-ST system. "Address" is the offset address of the monitored parameter, with Address 0 set as the start address.

*1: For details of the data, refer to the manual of the used master station or configuration software.

11.6.2 Saving the PROFIBUS-DP network parameter data



PURPOSE

Saves the data, which were monitored on the "PROFIBUS-DP Network Parameter Monitor" screen in ['PROFIBUS-DP network parameter monitor'](#) into a text file.




BASIC OPERATION

- (1) On the "PROFIBUS-DP Network Parameter Monitor" screen, click the **Stop** button to stop monitor, and then click the **Copy to File** button.
- (2) Set the destination directory and file name, and click the **Save** button to save the monitored data into a text file and close this screen.



DISPLAY/SETTING SCREEN




DISPLAY/SETTING DATA

Item	Description
Save in	Select the directory that stores the monitored data.
File name	Set the file name of the monitored data.
Save button	Saves the project with the file name specified at "File name".
Cancel button	Closes this screen without saving the project.

(1) Example of text file for saving data

The following shows an example of the text file for saving data.



```
ProfibusDPnetParamMonitor.txt - Notepad
File Edit Format View Help
Configurator-ST PROFIBUS-DP Network Parameter Monitor
0000 : 00 00 00 00 00 00 00 00 00 12 00 00 00 00 00 00
0001 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0002 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0003 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0004 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0005 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0006 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0007 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0008 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0009 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000A : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000B : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
000C : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```

12 Online module operation

This chapter explains the functions for operating each module from GX Configurator-ST in the online mode (where the MELSEC-ST system and personal computer are connected).

12.1 Reset head module



PURPOSE

Resets the head module from GX Configurator-ST.



BASIC OPERATION

- (1) Click the [Online] → [Reset Head Module] menu.
- (2) When there is a window being monitored, a screen appears asking whether monitor will be stopped or not.
Click the button to stop monitor.
- (3) A screen appears asking whether the head module will be reset or not.
Click the button to reset the head module, and check the LED status (on/off) to see if the head module has been reset.
While the head module is reset, all LEDs are off. When reset is completed, the LEDs turn on again.
Confirm that all LEDs turn on after they have turned off once.
- (4) A screen appears asking whether a reset request has been issued to the head module or not.
Click the button.
- (5) When monitor is stopped in Step (2), a message appears asking whether monitor will be resumed or not.
Click the button to resume monitor.
Click the button to keep monitor stopped.

12.2 Online module change

(1) Online module change function

The I/O modules (except ST1X1616-DE1-S1) and intelligent function modules can be replaced without stopping the MELSEC-ST system.

An online module change can be executed by operation of the head module buttons or from GX Configurator-ST.

This section explains how to perform an online module change from GX Configurator-ST.

12.2.1 Precautions for online module change

The precautions for the online module change are given below.

- (1) To perform the online module change, the system configuration must be appropriate for execution of the online module change.

For details, refer to the MELSEC-ST System User's Manual, "3.4 Precautions for System Configuration".

Executing the online module change in an inappropriate system configuration may result in malfunction or failure.

In such a system configuration, shut off all phases of the external power supply for the MELSEC-ST system to replace a slice module.

- (2) Be sure to perform an online module change in the procedure given in ['Procedures for online module change'](#).

Failure to do so can cause a malfunction or failure.

- (3) Before starting an online module change, confirm that the external device connected with the slice module to be removed will not malfunction.

It is recommended to set 0 (OFF) to **Bw.n** Bit output and **Ww.n** Word output of the slice module to be replaced in advance.

- (4) Only the slice modules of the same model name can be replaced online.

It is not possible to replace with/add the slice module of different model name.

- (5) Only one slice module can be replaced in a single online module change.

To replace multiple slice modules, perform an online module change for each module.

- (6) This function is available for I/O module (except ST1X1616-DE1-S1) and intelligent function module; not available for power distribution module and base module.

Shut off all phases of the external power supply before installing or removing the power distribution module and/or the base module.

Failure to do so may result in damage to all devices of the MELSEC-ST system.

- (7) While an online module change is in execution (while the head module's REL. LED is on), no command can be executed to the slice module being replaced online.

If a command is executed to such a slice module, an error will occur.

- (8) To change parameters of a slice module that is in execution of online module change (while the head module's REL. LED is on), wait until the online module change is completed.

If any parameter setting is changed during online module change, upon completion of the online module change, the modified setting is overwritten with the parameters saved into the head module and does not take effect.


- (9) During an online module change, the ERR. LED of the head module turns on only when an error related to the online module change occurs.

It will not turn on or flicker when any other error occurs.

- (10) While an online module change is being executed (while the REL. LED of the head module is on), the following data of the slice module being replaced online all turn to 0 (OFF).
- **Br.n** Bit Input
 - **Er.n** Error Information (PROFIBUS-DP only)
 - **Mr.n** Module Status (PROFIBUS-DP only)
 - **Wr.n** Word Input
- (11) When the communication with the master station is disconnected, replacing the output module online, whose CLEAR/HOLD setting is set to HOLD, turns the **Bw.n** Bit Output value to 0 (OFF).
- After the online module change is finished, the **Bw.n** Bit Output value will not return to the held value.
- (12) When the forced output test is executed on the slice module being replaced online, only **Ew.n** Error Clear can be tested (**Ew.n** Error Clear bits are available for PROFIBUS-DP only).
- Bw.n** Bit Output and **Ww.n** Word Output cannot be tested.

12.2.2 Procedures for online module change

This section explains the procedures for the online module change. Replace a module online as shown below.



*1: Refer to the MELSEC-ST System User's Manual, "3.4 Precautions for System Configuration".

*2: Refer to "Preparations for online module change" in the corresponding slice module manual.

*3: Refer to "External device connection and disconnection procedures for online module change".

12.2.3 Online module change from GX Configurator-ST


Here is an explanation of how to replace a module online from GX Configurator-ST.

Point

If a slice module different from the target one is selected by mistake, restart the operation as instructed below.


- (1) To restart the operation at step 3)
 - Click the **Cancel** button on the screen to terminate online module change.
- (2) To restart the operation at step 4)
 - Click the **Next** button without executing online module change, continue to step 10) and then terminate online module change.
- (3) To restart the operation at step 8)
 - Mount the removed slice module again, click the **Next** button, continue to step 10) and then terminate online module change.

Preparation for replacing slice module



- 1) Select the slice module to be replaced online on the "System Monitor" screen.





(To the next page)


- 2) Click the **Online Module Change** button on the "System Monitor" screen.
Then, confirm that the RUN LED of the selected slice module is flashing at 0.25s intervals.

REMARKS

In addition to above, the following operations are also available.

- Select [Diagnostics] → [Online Module Change].
- Right-click the slice module selected at step 1), and click **Online Module Change** on the menu.

(From the previous page)



3) Confirm that the slice module displayed as "Target Module" is the slice module to be replaced and click the **Next** button.

(a) Clicking the **Next** button validates the settings and the following will be performed.

- Puts the head module into the online module change mode.
- Saves the parameters of the target slice module into the head module.

(b) After clicking the **Next** button, confirm the following module statuses.

- The REL. LED of the head module is on.
- The RUN LED of the target slice module is off.
- The "Module Status" indicator of the target module has turned purple (■). This applies only when monitoring from the "System Monitor" screen.

(c) If the parameters cannot be read from the slice module, the REL. LED and ERR. LEDs of the head module will turn on, and an error message will appear on the screen at step 8). In this case, confirm the error details and take corrective action. For how to read error codes and error code details, refer to the Head Module Manual.

When not executing online module change, click the **Cancel** button.

(a) Clicking the **Cancel** button causes the screen to show that online module change is cancelled.

Clicking the **Exit** button returns to the step 1).




(To the next page)

(From the previous page)




Disconnection from external device




- 4) When the left screen appears, disconnect the external device from the slice module to be replaced online.
For details, refer to "External device connection and disconnection procedures for online module change" in the corresponding slice module manual.



If the disconnection procedure given in the relev slice module manual cannot be executed, shut phases of the external power supply for the ME ST system to replace the slice module.



Replacing slice module




- 5) Remove the slice module to be replaced from the base module.
- 6) Mount a new slice module with the same model name as the one of the removed.

(To the next page)

(From the previous page)



Connection to external device after replacement



- 7) After mounting a new slice module, connect it to the external device.
For details, refer to "External device connection and disconnection procedures for online module change".

Operations after external device connection

- 8) After connecting the external device, click the **Next** button on the screen in step 4).


- (a) Clicking the **Next** button performs the following.

- Checks whether the module name of the newly mounted slice module is the same as that of the removed one.
- Writes the parameters saved into the head module (at step 3)) to the newly mounted slice module.

- (b) After clicking the **Next** button, confirm the following module statuses.

- The REL. LED of the head module is flashing.
- The RUN LED of the newly mounted slice module is flashing (at 0.25s intervals).

Clicking the **Cancel** button, i.e., interrupting online module change returns to step 1). In this case, select the same slice module as selected before, and complete online module change. Note that selecting different one causes an error.




(To the next page)

If the parameters could not be read from the removed slice module in step 3), the REL. and ERR. LEDs of the head module will turn on and the left screen will appear in GX Configurator-ST. In this case, confirm the error details and take corrective action.

For how to read error codes and error code details, refer to the Head Module Manual.

When step 10) has completed in this status, the intelligent function module starts its operation with the command parameters set as default.

(From the previous page)



9) Clicking the **Next** button releases the head module from the online module change mode.

(a) Clicking the **Next** button performs the following.

- Releases the head module from the online module change mode.
- Restarts refreshing the I/O data, etc.

(b) After clicking the **Next** button, confirm the following module statuses.


- The REL. LED of the head module is off.
- The RUN LED of the newly mounted slice module is on.
- The "Module Status" indicator of the target slice module has turned white (□). This applies only when monitoring from the "System Monitor" screen.

(c) If the head module cannot be released from the online module change mode, both REL. LED and ERR. LED of the head module turn on. In this case, confirm the error details and take corrective action.

For how to read error codes and error code details, refer to the Head Module Manual.

When interrupting online module exchange, click the **Cancel** button.

(a) Clicking the **Cancel** button, i.e., interrupting online module change returns to step 1). In this case, select the same slice module as selected before, and complete online module change. Note that selecting different one causes an error.



(Completion)

10) The left screen appears showing that online module change has been completed.

Click the **Finish** button.

13 Reference

13.1 Key operations list

Some of the commonly-used menu items are also available on shortcut keys, listed below.

File

Operation Contents	Key operation
New	Ctrl + N
Open	Ctrl + O
Save	Ctrl + S
Print	Ctrl + P

Edit

Operation Contents	Key operation
Undo	Ctrl + Z
Redo	Ctrl + Y
Add	Ctrl + Insert
Delete	Ctrl + Delete
All Delete	Shift + Del
Parameter Setting	F9
Option	F10

Mode

Operation Contents	Key operation
Edit	F2
Diagnosis	F3

13.2 Error messages

This section will list the error messages that can be shown by the program, with advice on how to prevent or fix the errors.

13.2.1 Communication errors

These errors are shown when GX Configurator-ST has problems communicating with the SLICE hardware.

<i>Message</i>	Cannot communicate with Head module for one of the following reasons: <ul style="list-style-type: none"> • Communications timeout. • The preparation of communication environment is bad. • Cable error. • Cannot communicate with the transmission speed set up now. To fix this, try: <ul style="list-style-type: none"> • Checking the cable and selected port number • Setting transmission speed to a lower value. • Closing other communication software applications and trying again.
<i>Description</i>	This message occurs when it is not possible to make a connection to the SLICE hardware.
<i>Causes and actions</i>	This message will be shown if the connection to the SLICE hardware cannot be opened. This could be due to a hardware or software problem: <ul style="list-style-type: none"> • Hardware issues may include power failure to the SLICE hardware, the cable becoming disconnected, the wrong type of cable being used, or the cable being plugged into the wrong device. • Software issues may include another program using the communication port where the cable is connected.

<i>Message</i>	Cannot communicate with PLC.
<i>Description</i>	There was a problem communicating with the SLICE hardware.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This message may be shown if the SLICE hardware does not respond within a reasonable time. Check that the SLICE hardware is powered on and that the correct cable is connected to the correct port on the intended device.

<i>Message</i>	<p>Cannot communicate with Head module for one of the following reasons:</p> <ul style="list-style-type: none"> • Bad connection to the head module. • The preparation of communication environment is bad. <p>To fix this, try:</p> <ul style="list-style-type: none"> • Checking the connection to the head module • Closing other communication software applications and trying again.
<i>Description</i>	There was an error when sending / receiving data to or from the SLICE hardware.
<i>Causes and actions</i>	<p>This message will be shown if the connection to the SLICE hardware cannot be opened. This could be due to a hardware or software problem:</p> <ul style="list-style-type: none"> • Hardware issues may include power failure to the SLICE hardware, the cable becoming disconnected, the wrong type of cable being used, or the cable being plugged into the wrong device. • This error message will also be shown if you use an earlier version of GX Configurator-ST (such as 1.06G) to connect to a head module configured for PROFIBUS-DP version B. This does not work due to changes to the internal structure. • Software issues may include another program using the communication port where the cable is connected.

<i>Message</i>	Set data exceeds the range. Execute again after confirming set data. The range that can be set is 1 - 9.
<i>Description</i>	This message is shown on the 'Transfer setup' dialog, when a timeout value outside the range 1-9 is set.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Change the timeout value to a number from 1 to 9, and try again.

<i>Message</i>	Cannot process because of monitoring. Please stop all monitoring and execute again.
<i>Description</i>	Some online operations are not possible while monitoring is in progress. This message is shown if one of these operations is initiated while monitoring is in progress.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Stop monitoring for the duration of the operation, and restart it afterwards.

13.2.2 Diagnostic errors

The errors in this section can occur when the system is in diagnosis mode.

<i>Message</i>	This feature cannot be executed during monitoring. Please execute again after stop monitoring.
<i>Description</i>	This message is shown when the 'Copy to file' button is selected on the PROFIBUS-DP Network parameter monitor or Master station data communications dialog , but monitoring is still active.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Stop monitoring before saving the data to a file. Monitoring can be restarted after the file has been saved.

<i>Message</i>	The module for the setting has not been selected. Please select the module that is to be set in the System Monitor.
<i>Description</i>	This error is shown on the system monitor screen, when an action is selected (such as module detail information) without any module selected for it to work on.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select the module to use for the action, then try again.

<i>Message</i>	There is no monitor data to write to the file.
<i>Description</i>	This error occurs when the 'Copy to file' button is selected on the PROFIBUS-DP Network parameter monitor or Master station data communications dialog , but there is no data available to save to the file.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Try again when there is some data available to write.

<i>Message</i>	Cannot monitor the Input/Output Data of the specified module.
<i>Description</i>	I/O monitoring was selected for a module, but the module does not support it.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The selected module may not have any I/O to monitor. Check that the correct module has been selected, then try again.

<i>Message</i>	The module for the setting has not been selected. Please select the module that is to be set in the System Monitor.
<i>Description</i>	An attempt was made to start I/O monitoring without first selecting a module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that the correct module is selected by clicking on it in the system monitor display, then try again.

<i>Message</i>	The head module does not match, but the other modules are correct. Copy the head module details from the live system and continue?
<i>Description</i>	When attempting to switch to diagnostics mode, it was discovered that the head module type of the live system does not match the head module type in the configuration, although the remaining modules do match. This could happen if (for example) the head module in an existing SLICE system was replaced with a different type of head module.
<i>Causes and actions</i>	<p>You can either:</p> <ul style="list-style-type: none"> • Answer 'Yes' at the prompt, in which case the system will copy the head module details from the live system and continue - if you have replaced the head module but wish to reuse the module parameters in an old configuration file, this is the correct option. • Answer 'No' at the prompt, if (for example) a connection has been made to the wrong SLICE hardware. The 'wrong system configuration' error will be shown (as below).

<i>Message</i>	The module configuration differs from the mounting state. Please check the module configuration and execute again. Module No.
<i>Description</i>	This message is shown when switching to diagnostics mode, if the configuration of the attached SLICE hardware does not match the configuration being edited. The message shows the first module number which is different.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Check that the communication cable is connected to the right serial port and the right SLICE hardware - there may be a connection to a different system. 'Transfer setup' can be used to change the serial port used. • Make sure that the configuration file is up to date, in case new modules have been added since the last time it was saved. • If you do not need to keep any parameters in the local file, use 'Get system' to read the details of the connected system from the port.

<i>Message</i>	The configuration has changed. Please close all monitoring windows before reactivating. Otherwise several indication errors could occur.
<i>Description</i>	This error occurs if the configuration of the ST-series head module is changed while monitoring is active (e.g. switched protocol from Version A to B) and the changed configuration was loaded into GX Configurator-ST.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Close all monitoring dialogs and start monitoring again.

<i>Message</i>	This will start monitoring of the Input/Output Monitor?
<i>Description</i>	When you switch from edit mode to diagnostics mode, and there are I/O monitor windows open from a previous diagnostics mode session, you will be prompted to restart monitoring.
<i>Causes and actions</i>	<p>Either answer:</p> <ul style="list-style-type: none"> • 'Yes' - to restart monitoring in these windows, or • 'No' - in which case monitoring will not be switched on in the open I/O monitor windows.

<i>Message</i>	This will stop monitoring of the Input/Output Monitor.
<i>Description</i>	This is a warning shown when switching from diagnostics mode to edit mode while there is an I/O monitor active.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • There is no action to take - when you click 'OK', the active I/O monitors will stop monitoring.

<i>Message</i>	Module Detail Information cannot be executed in the specified module.
<i>Description</i>	This error can appear on the system monitor dialog when an attempt is made to start the 'module detail information' dialog for a module whose details cannot be shown.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that the right module is selected, by clicking on it in the system monitor dialog, then try again.

13.2.3 File errors

These errors may occur when there are problems opening or reading from a file.

<i>Message</i>	The file cannot be opened because the selected file is damaged.
<i>Description</i>	An attempt was made to open a file which appears to be corrupted.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • There may be a problem reading the file from a network drive, or the file may have become corrupted. • If you have a recent backup of the file, check if the backup is readable.

<i>Message</i>	This file has been created in latest version of application. Cannot process it in this application.
<i>Description</i>	This message may be shown if you have created a file in a newer version of GX Configurator-ST than this one (1.08J), and attempted to load it into this version.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Open the file with the version of GX Configurator-ST in which it was created.

<i>Message</i>	The file cannot be opened because the selected file is damaged.
<i>Description</i>	The file was found and opened, but discovered to be corrupt.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • It will not be possible to read the file - load a backup copy if you have one, or if you have access to the SLICE hardware, use the 'Get system' feature to read the configuration from the hardware.

<i>Message</i>	The following error occurred during processing of the file. ...
<i>Description</i>	While processing the file, the operating system reported an error. The error description returned by the operating system is shown at the end of the message.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The message should show what the problem was, and from this it should be possible to work out the correct action to take.

<i>Message</i>	Cannot use the specified file because it is being write protected. Please check the attribute and try again.
<i>Description</i>	Permission was denied to use the file.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that the file has not been opened elsewhere • Check that the file is not write protected - files can sometimes be left write protected when (for example) they are copied from a backup CD.

<i>Message</i>	Cannot find the file.
<i>Description</i>	The file to be opened was not found.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that the file exists, and is not (for example) on an inaccessible network drive.

<i>Message</i>	Cannot use the specified file because it is being used by some other application.
<i>Description</i>	Another application has the file open, so GX Configurator-ST cannot use it.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Look for other files that may be using the file, then switch to the other application and close the file. • If the file still appears to be locked and there is no application apparently using it, rebooting the PC may fix the problem.

<i>Message</i>	The allowable No. of characters has been exceeded. Set to less than 150 characters.
<i>Description</i>	A file name was selected which is too long to use.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Enter a shorter file name, then try again.

13.2.4 Forced output / offset and gain errors

These errors can occur when using the forced output / offset and gain settings dialogs. For more information, see ['Forced output test'](#) and ['Offset/Gain setting of intelligent function module'](#).

<i>Message</i>	The module for the setting has not been selected. Please select the module that is to be set in the System Monitor.
<i>Description</i>	An attempt was made to start the forced output test dialog without first selecting a module whose outputs are to be written.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that a module is selected by clicking on it in the system monitor dialog, then try again.

<i>Message</i>	The selected module cannot execute the Forced Output Test function.
<i>Description</i>	An attempt was made to start the forced output test dialog for a module that does not support forced output tests (e.g. because it has no suitable outputs).
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select a module which does support forced output tests, by clicking on it in the system monitor dialog, then try again.

<i>Message</i>	<p>Cannot change into the Forced Output Test Mode because the communication error has occurred. Please execute again.</p> <p>If selecting the "Cancel" button, please reset the head module because the last value may be outputted when you next execute the Forced Output Test function.</p>
<i>Description</i>	This message is shown when trying to switch on the 'forced output test' mode, if there is a communication error before the operation can be completed. Pressing 'OK' will retry the connection, or pressing 'Cancel' will abandon the attempt.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Check the connections and try again. As the message suggests, if you select 'Cancel' it is advisable to reset the head module to make sure that there are no 'left over' output values the next time you switch to forced output test mode.

<i>Message</i>	Head module is in the status of the Forced Output Test Mode. Do you want to release the Forced Output Test Mode?
<i>Description</i>	This message is shown when the operating mode is about to be switched from 'diagnostics mode' to 'edit mode', while the 'forced output test' mode is active.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This is a warning message - if you wish to continue using forced output mode, cancel the change.

<i>Message</i>	This will release the Forced Output Test Mode. Is it OK?
<i>Description</i>	This prompt is shown when closing a forced output test dialog window while the test is active.
<i>Causes and actions</i>	<p>Either answer:</p> <ul style="list-style-type: none"> • 'Yes' - to switch off forced output test mode before returning, or • 'No' - to leave the forced output test mode active

<i>Message</i>	Mode setting is in the Forced Output Test Mode. Do you want to close in the Forced Output Test Mode?
<i>Description</i>	This message is shown when the project file is about to be closed, but the 'forced output test' mode is active.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This is just a warning message - if you wish to continue using forced output mode, use the 'cancel' option.

<i>Message</i>	It is possible to set Offset/Gain only during the Forced Output Test Mode. Change into the Forced Output Test Mode?
<i>Description</i>	This message is shown when trying to set the offset and gain settings for a module, when the system is not in forced output test mode.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Offset/gain settings can only be set in forced output mode. Answer 'Yes' at the prompt to switch to forced output test mode, or 'No' to cancel the operation.

<i>Message</i>	The selected module cannot set Offset/Gain.
<i>Description</i>	An attempt was made to change the offset/gain settings of a module which does not have offset/gain settings to change (such as the head module or a power supply module).
<i>Causes and actions</i>	<ul style="list-style-type: none"> • It is likely that the wrong module is selected - make sure that the correct module (one which has offset/gain settings) is selected, and then try again.

<i>Message</i>	The module to be set has not been selected. Please select a module to be set in the System Monitor.
<i>Description</i>	This message is shown when attempting to show the offset/gain settings dialog without first selecting a module for which the offset/gain settings should be changed.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that a module has been selected by clicking on it in the 'system monitor' dialog, then try again.

<i>Message</i>	The Window is closed during Offset/Gain Setting Mode. Please open the Offset/Gain Setting and close again.
<i>Description</i>	The offset/gain dialog window was closed unexpectedly while setting offset/gain settings.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Open the offset/gain settings window and try the operation again.

<i>Message</i>	Channel has not been selected. Please select a channel.
<i>Description</i>	This error is shown on the offset/gain settings dialog, when trying to write the settings without first selecting one or more channels.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select the channel(s) to which the new setting values should be applied,

<i>Message</i>	Please set the Offset/Gain Value.
<i>Description</i>	On the offset/gain settings dialog, the 'Set' button was used without entering a valid value.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that a valid number has been entered for the new offset/gain value, then try again.

<i>Message</i>	Value input is out of range.
<i>Description</i>	The value entered for the offset or gain setting is out of range, i.e. it is below the lower limit for values, or above the upper limit for values.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Enter a value which is within the limits, then try again.

<i>Message</i>	Please select an Output Data.
<i>Description</i>	On the forced output test dialog, the 'settings' button was clicked without first selecting one or more outputs.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that at least one output is selected (checked) and try again.

<i>Message</i>	The value besides the range is set as the setting value.
<i>Description</i>	This error is shown on the forced output dialog, if the output value selected is not permitted. The value may be lower than the minimum permitted, higher than the maximum permitted, or too large for the data type (e.g. when trying to store a 32-bit value in a 16-bit setting).
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Enter a value within the permitted ranges, then try again.

13.2.5 Module addition and copying errors

These errors may be shown when new modules are being added to the system, or copied from another file.

<i>Message</i>	Cannot add the module. Modules can be added to the maximum of
<i>Description</i>	No more modules can be added to the system - the limit on the number of modules in a SLICE system has been reached.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • You may be able to reduce the number of modules needed by using different types of modules. • If there is no way to reduce the number of modules needed, the only solution is to install an additional SLICE system in a new rack with a separate head module.

<i>Message</i>	Cannot add the module. Bit Input/Output range exceeds ... points.
<i>Description</i>	It is not possible to add the module, because the total number of bit I/O points in the system would exceed the limit.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • In a PROFIBUS-DP system, the point mode is selectable, so you may be able to change to a higher point mode and continue. • If there is no way to reduce the number of bit input/output points used, the only solution is to install an additional SLICE system in a new rack with a separate head module.

<i>Message</i>	Cannot add the module. Word Input/Output range exceeds ... points.
<i>Description</i>	It is not possible to add the module, because the total number of word I/O points in the system would exceed the limit.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • In a PROFIBUS-DP system, you may sometimes be able to switch to a lower point mode to increase the number of word I/O items that can be used. • If there is no way to reduce the number of word input/output items used, the only solution is to install an additional SLICE system in a new rack with a separate head module.

<i>Message</i>	Cannot add the module. Intelligent modules can be added to the maximum of ...
<i>Description</i>	It is not possible to add the module, because the maximum number of intelligent modules has already been reached.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • In a PROFIBUS-DP system, the number of intelligent modules permitted is affected by the point mode selected. You may be able to change the point mode to allow more intelligent modules to be used. • You may be able to install different types of intelligent modules in the system to get the same results with a lower number of modules. • You may be able to install one or more non-intelligent modules in the system to get the same results. • If more intelligent modules are still needed, the only solution is to install an additional SLICE system in a new rack with a separate head module.

<i>Message</i>	The module could not be recognized. Module:... No...
<i>Description</i>	GX Configurator-ST does not recognise the module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This message should not normally be shown. Uninstalling and reinstalling the application may solve the problem.

<i>Message</i>	The module isn't selected. Please select the module.
<i>Description</i>	In the 'Add module' dialog, 'add' was pressed before a module was selected.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select a module from the drop-down list, then try again.

<i>Message</i>	It cannot add the module in the specified position.
<i>Description</i>	In the 'Add module' or 'Copy module' dialog, an attempt was made to add a module at an invalid slot number.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Correct the slot number and try the action again. The slot number should not be before or at the head module slot, or beyond the end of the rack.

<i>Message</i>	A missing number will be made. Is it OK to change the No. to ...?
<i>Description</i>	In the 'add module' or 'copy modules' dialog, an attempt was made to add a module after the end of the rack. For example, if the last module in the rack is in slot 8, an attempt to add a new module in slot 10 would cause this error.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Either select 'Yes' to accept the suggested alternative (normally the slot number just after the right hand end of the rack), or 'No' to cancel the addition and re-enter the slot number manually.

<i>Message</i>	Warning - after adding this module, the supply current is not sufficient. Supply current : ... mA, Consumption : ... mA. Select 'OK' to add the module anyway.
<i>Description</i>	This message is shown after adding a module in the wizard area, if there was previously sufficient power supply to the modules in the configuration, but adding the new module would cause more current to be drawn than is being supplied.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select 'OK' to add the module anyway and fix the power supply issue later, or • Select 'Cancel' to prevent the addition, so that another power supply module (e.g. ST1PSD) can be added in the correct place.

<i>Message</i>	Warning - there are not enough unused bits available. Unused bits available : ..., Required : Select 'OK' to add the module anyway.
<i>Description</i>	This message is shown after adding a module in the wizard area, if the unused bits had not previously been exceeded, but adding the new module would require the use of more unused bits than there are available.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select 'OK' to add the module anyway and fix the problem later, or • Select 'Cancel' to prevent the addition, so that the marked module or the module to the left of it can be changed to a standard module. Depending on your configuration, you may be able to rearrange the other modules to make better use of the unused bits to be able to use them for byte packing.

<i>Message</i>	There is no file path settings. Please check it again.
<i>Description</i>	This occurs when trying to use the 'Add' button on the 'Copy' dialog without having selected a valid path for the source file.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select the source file to copy from using the 'Browse' button. There are further instructions available in 'Copying the module information'.

<i>Message</i>	Cannot add the module. Maximum configuration reached.
<i>Description</i>	No more modules can be added to the system - the limit on the number of modules in a SLICE system has been reached.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Use a larger I/O module instead of smaller ones. • You may be able to reduce the number of modules needed by using different types of modules. If there is no way to reduce the number of modules needed, the only solution is to install an additional SLICE system in a new rack with a separate head module.

<i>Message</i>	Cannot add the head module. Please select the other module.
<i>Description</i>	This error is shown when adding to use the 'Copy' dialog to copy the head module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The wrong module may have been accidentally selected, in which case select the correct module to copy. • The head module cannot be directly copied - however you can obtain the same result by entering items such as the label name and parameters manually.

13.2.6 Module configuration errors

If a problem is detected with the module configuration, the affected module will be highlighted in red in the module list. When the context menu is shown (e.g. by clicking on the module with the right mouse button), the descriptions of the module errors will appear at the top of the context menu.

The possible errors are:

<i>Message</i>	Slot 1 should always contain a '...' module
<i>Description</i>	In a valid configuration, the first slot after the head module should always contain a power supply module of the type shown in the message. This provides power to the head module itself, as well as to the remaining modules.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The power supply module is either missing, or in the wrong place. Either move an existing power supply module to the slot immediately after the head module, or install a new power supply module after the head module.

<i>Message</i>	The power supply module in slot 1 should have an 'H-SET' base type
<i>Description</i>	The first power supply module has the wrong base type selected - for the first power supply after the head module, the base type should always be 'H-SET'. The remaining power supply modules have 'R-SET' base types.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Ensure that a power supply with 'H-SET' base type is installed immediately after the head module. You can change the base module type by right clicking on the slot and selecting 'Option' from the pop-up menu. For more information see 'Option setting'.

<i>Message</i>	The power supply module in this slot should have an 'R-SET' base type
<i>Description</i>	The power supply module in this slot has the wrong base type selected - for power supply modules other than the first power supply after the head module, the base type should always be 'R-SET'.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Ensure that a power supply with 'R-SET' base type is used in this slot. You can change the base module type by right clicking on the slot and selecting 'Option' from the pop-up menu. For more information see 'Option setting'.

<i>Message</i>	Power consumption exceeds supply from power supply module in slot '...'
<i>Description</i>	With the current configuration, there is not enough power being supplied to the module. The message shows the number of the slot containing the power supply which feeds this module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • There may not be enough power supply modules in the system. To fix this, you will need to install an additional power supply just before the first module that reports this error. • Depending on your configuration, you may be able to rearrange the other modules to make better use of the existing power supplies.

<i>Message</i>	ST1X1616-DE1-S1-L module required after this module
<i>Description</i>	The ST1X1616-DE-S1 module is presented in the software as two modules, ST1X1616-DE1-S1-F and ST1X1616-DE1-S1-L. These modules are one physical unit and so they must always appear as a pair with the ST1X1616-DE1-S1-F module followed by the ST1X1616-DE1-S1-L module. This message appears when there is a ST1X1616-DE1-S1-F module which is not followed by a ST1X1616-DE1-S1-L module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Either add an ST1X1616-DE1-S1-L module if it is missing, or rearrange the existing modules so that the two modules are adjacent with the ST1X1616-DE1-S1-F module followed by the ST1X1616-DE1-S1-L module.

<i>Message</i>	ST1X1616-DE1-S1-F module required before this module
<i>Description</i>	The ST1X1616-DE-S1 module is presented in the software as two modules, ST1X1616-DE1-S1-F and ST1X1616-DE1-S1-L. These modules are one physical unit and so they must always appear as a pair with the ST1X1616-DE1-S1-F module followed by the ST1X1616-DE1-S1-L module. This message appears when there is a ST1X1616-DE1-S1-L module which does not have a ST1X1616-DE1-S1-F module before it.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Either add an ST1X1616-DE1-S1-F module if it is missing, or rearrange the existing modules so that the two modules are adjacent with the ST1X1616-DE1-S1-F module followed by the ST1X1616-DE1-S1-L module.

<i>Message</i>	Byte pack consumption exceeds unused bits
<i>Description</i>	A byte pack module cannot be used here because there are not enough unused bits left.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • There are not enough unused bits left to use byte packing. To fix this, the marked module or the module to the left of it must be a standard module. Depending on your configuration, you may be able to rearrange the other modules to make better use of the unused bits to be able to use them for byte packing.

13.2.7 Module deletion errors

These errors can occur when deleting modules. For more information, see ['Deleting a module'](#) or ['Deleting all modules'](#).

<i>Message</i>	Cannot delete head module.
<i>Description</i>	An attempt was made to delete the head module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The head module cannot be deleted - all valid systems must have a head module in the first slot. If you wish to start again and reconfigure the system with a different head module, select 'File -> New'. Alternatively, use the 'Edit' menu item 'Change head module' to select another head module type while leaving the remaining modules in place.

<i>Message</i>	The module to be deleted has not been selected. Please select the module to delete in the Module Information List.
<i>Description</i>	The 'Delete module' action was selected, but there is no module selected for deletion.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select a module by clicking on it, then try again.

13.2.8 Module parameter errors

These errors can occur when setting or reading parameter values.

<i>Message</i>	<p>There are some errors. The following reasons may be responsible:</p> <ul style="list-style-type: none"> • The invalid setting value is selected. • The value besides the range is set as the setting value.
<i>Description</i>	<p>When checking the parameter settings for errors on the parameter settings screen, some of the parameters were not valid.</p> <p>For more information about parameter settings, see 'Checking the parameters for errors'.</p>
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The most likely cause is that the parameter value is out of range. For example, a number has been entered which is below the lower limit for the parameter value or above the upper limit for the parameter value.

<i>Message</i>	The parameter item for the corresponding Read/Write/Verify has not been selected. Please select the parameter item.
<i>Description</i>	In the parameter settings dialog, an action (such as upload / download / verify) was selected without first selecting the parameters to work on.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • To prevent this happening, select one or more parameters from the list before selecting an action. For more information, see 'Parameter setting' or 'Uploading/Downloading the parameters'.

<i>Message</i>	The setting value that cannot be changed is read only. The setting value for the read only cannot be downloaded.
<i>Description</i>	In the parameter settings dialog, an attempt was made to download an item which is read only.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Read only items cannot be downloaded by GX Configurator-ST. If there are other parameters to download which are not read only, deselect the read only item and try again. • In some cases, it may be possible to change the parameter by sending a command from the master station.

<i>Message</i>	The module differs from the mounted module.
<i>Description</i>	This error can occur when trying to download parameters to a module in a given slot using the parameter settings dialog. The problem is that the module in that slot in the connected SLICE system is not the same type as the module in that slot in the configuration file. For more information, see ' Parameter setting '.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This normally means that there is a mismatch between the configuration file and the connected hardware. Check that the PC is connected to the right hardware, i.e. that the cable is not in the wrong port on the computer or connected to a different SLICE system. • The configuration file may be out of date. If the connected system was expected to match, it may be easier to use 'Get system' to read the details from the connected hardware, and then try again.

<i>Message</i>	Cannot set the parameter of the specified module.
<i>Description</i>	An attempt was made to show the parameter settings of a module which does not have parameters (such as a power supply module).
<i>Causes and actions</i>	<ul style="list-style-type: none"> • There are no parameters for the type of module selected. • If you were expecting the module to have parameters, please check that the right module is selected.

<i>Message</i>	The module to be set has not been selected. Please select the module to be set in the Module Information List or the System Monitor.
<i>Description</i>	An attempt was made to show the parameter settings dialog without first selecting the module to view.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select a module, and then try again.

<i>Message</i>	Please select modules
<i>Description</i>	When performing a parameter block write, no modules have been selected for download.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select the modules whose parameters should be downloaded to the SLICE system by clicking in the 'Select' column, then try again.

<i>Message</i>	Download canceled.
<i>Description</i>	This message is shown when a parameter block write is canceled before the parameters have been downloaded for all modules.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • To continue with the download, make sure that all the required modules are selected (modules whose status is marked as 'completed' have already been downloaded in full and can be deselected) and try again.

13.2.9 Module selection errors

These errors can occur when it is not possible to tell which module was selected.

<i>Message</i>	The Module Information List is not displayed. Please activate the Module Information List in the menu.
<i>Description</i>	This error is shown in edit mode when an attempt is made to use a feature that needs a selected module, but the module configuration window is not shown, or no module is selected. The module configuration window must be visible to allow modules to be selected.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Use the 'View' menu 'Module configuration' item to show the window, then click on a module in the module list or rack display to select it, and try again.

<i>Message</i>	The module to be set has not been selected. Please select the module to be set in the Module Information List.
<i>Description</i>	An attempt was made to show the module option dialog without first selecting a module to work with.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that a module has been selected in the module list or rack display by clicking on it, then try again.

13.2.10 Module verify (compare) errors

These errors can occur while verifying (comparing) modules against another configuration file. For more information about this feature, see the ['Verifying the projects'](#) section.

<i>Message</i>	The system configuration of the file opened for verification and the file under editing is different. Cannot execute verification for all the selected modules.
<i>Description</i>	This error can be shown when the destination file is first opened in the verify dialog, when the 'Verify all modules' tab is active. When 'Verify all modules' is used, the source and target systems are expected to be very similar, with the same number and type of modules, and this is not the case for the selected file.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • If you do not intend to use the 'Verify all modules' feature, you can ignore this message and activate the 'Verify selected modules' tab instead, as this will still work even if the configurations are different. • If you were expecting the two configurations to be comparable, check that you have opened the correct file.

<i>Message</i>	Is it OK to clear the selected module?
<i>Description</i>	This message is shown when using the 'Verify selected modules' tab to set up the list(s) of modules to compare. It appears when the source is changed after some modules have been selected, and is a warning that all the module selections will be reset if the source is changed.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Either confirm the prompt, in which case the selections will be cleared and you will have to enter them again, or • Cancel, in which case the source will not be changed.

<i>Message</i>	Module at the verification source has not been selected.
<i>Description</i>	With the 'Verify selected modules' tab active, an attempt was made to start the comparison before selecting a source module.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • One source module needs to be selected before starting the comparison. This module will be compared against each of the destination modules in turn.

<i>Message</i>	Module at the verification destination has not been selected.
<i>Description</i>	With the 'Verify selected modules' tab active, an attempt was made to start the comparison before selecting any destination modules.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • One or more destination modules need to be selected before starting the comparison. Each of these will be compared against the source module.

<i>Message</i>	The specified module does not exist.
<i>Description</i>	In the verify results dialog, after trying to edit the parameter settings by double clicking a module row or pressing the 'Parameter settings' button, GX Configurator-ST could not find the module whose settings should be edited.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Make sure that a valid row is selected. • Make sure that the module at the selected row has editable parameters. • Try closing the results dialog and using the module list or rack display to edit the parameters of the module instead.

13.2.11 Online change errors

These errors can occur during online module change. For more information about the online change procedure, see the head module documentation and the sections '[Online module change](#)' and '[Online module change from GX Configurator-ST](#)'.

<i>Message</i>	The module for the setting has not been selected. Please select the module that is to be set in the System Monitor.
<i>Description</i>	The 'online change' feature was started without first selecting the module to be changed.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select a module to change by clicking on it in the system monitor dialog, then try again.

<i>Message</i>	The selected module cannot execute Online Module Change.
<i>Description</i>	This message is shown when an attempt is made to use the online change feature on a module which does not support online change. For example, the head module and power supply modules cannot be exchanged while the system is running.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select a module which supports online changes and try again. If you do need to replace a module that does not support online change, the only safe way is to power down the system and replace the module while the whole system is switched off.

<i>Message</i>	Online Module Change was stopped. This module does not operate. Please execute "Online Module Change" again.
<i>Description</i>	This message is shown if the online change procedure is cancelled part way through the exchange. It indicates that the selected module is not operating as a result of stopping the exchange procedure.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Go through the online change procedure again for the same module (it does not actually have to be replaced). If you try to select a different module, an error will be shown.

<i>Message</i>	There is some other module that is performing Online Module Change. Please execute Online Module Change for one module of at a time.
<i>Description</i>	An attempt was made to start an online change operation, but there is already a module part way through the online change process. This can occur if a previous online change (either from GX Configurator-ST or using the buttons on the front of the head module) has not fully completed or was cancelled part way through.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select the module that is part way through online change (the module will have a purple (■) status colour in the system monitor), and complete its online change procedure first. Online change can only be used for one module at a time.

13.2.12 Printing errors

The errors in this section can occur during printing. For more information, see '[Printing the project data](#)'.

<i>Message</i>	Please close GX Configurator-ST after closing Print Preview.
<i>Description</i>	If the print preview dialog is open, it must be closed before trying to close GX Configurator-ST.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Close the print preview dialog, then select the 'File' menu 'Exit' item to quit.

<i>Message</i>	Please select one or more modules.
<i>Description</i>	This message is shown on the print dialog, if the print range is 'selected modules' but no modules have been selected.
<i>Causes and actions</i>	<p>Either:</p> <ul style="list-style-type: none"> • Select some modules by clicking on them in the list on the left, then using the '->' button to add them to the list of modules to print, or • Select the 'All modules' option for the print range instead, in which case all the modules will be included in the printout.

<i>Message</i>	Please specify the print item.
<i>Description</i>	<p>The print dialog has three options for sections that can be included in the printout:</p> <ul style="list-style-type: none"> • Module configuration • Module information list • Individual module information <p>This error message is shown when all three options have been deselected, and there is nothing remaining to print.</p>
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Select at least one section to be printed. If you do not want to print anything, cancel the dialog.

<i>Message</i>	Please set the Module Turning Position within the range of 1-99.
<i>Description</i>	The module turning position gives the number of modules printed per row on the module configuration page of the printout. It must be a number from 1-99.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Enter a number from 1-99 for this value, then try again.

<i>Message</i>	The initial page value is outside the range.\n\nThe initial page value should be set within the range 1-32767.
<i>Description</i>	This error is shown on the page setup dialog, if the first page number is not within the range 1-32767.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • Enter an initial page number from 1-32767 and try again.



13.2.13 System errors

These errors occur when there are other issues with the system, or problems with the installation.

<i>Message</i>	Insufficient memory. Please close other applications to increase memory.
<i>Description</i>	There is not enough free memory available to complete the current activity.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • If possible, try to close other applications which you are not using, to release memory. • You may also be able to increase the amount of memory available by increasing the size of the page file, or by installing additional memory in the computer.

<i>Message</i>	There is not enough memory, so the GX Configurator-ST cannot be activated. Quit other applications, then activate the GX Configurator-ST.
<i>Description</i>	There is not enough free memory available to start the application.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • If possible, try to close other applications which you are not using, to release memory. • You may also be able to increase the amount of memory available by increasing the size of the page file, or by installing additional memory in the computer.

<i>Message</i>	Some of the necessary files for running the application are not found. Please reinstall.
<i>Description</i>	This message normally means that GX Configurator-ST did not install correctly, or some of the application files or registry settings have been damaged.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • A file is missing, or part of the application failed to load or initialise. • In general, uninstalling the program (from 'Control Panel -> Add or remove programs') and then reinstalling should fix the problem.

<i>Message</i>	Failed to read the registry data. There is some possibility for some error in the operating environment of the application. Please do reinstall. Administrator authorization is required in case of using Windows® 2000, Windows® XP, Windows Vista® and Windows® 7.
<i>Description</i>	The application was unable to read settings from the system registry.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • The currently logged-on user may not have Administrator rights. Log back on as a user with Administrator access. • The application may not be correctly installed, in which case it should be uninstalled (from 'Control Panel -> Add or remove programs') and then reinstalled.

<i>Message</i>	Cannot execute online operations in this application. Online operation is possible only in the application that started in the beginning.
<i>Description</i>	The system cannot make connections to the device hardware, as the connection is already in use.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This message will be shown if GX Configurator-ST is run twice. Use the instance that was started first for online operations.

<i>Message</i>	Failed to open the database. Please reinstall.
<i>Description</i>	This message normally means that GX Configurator-ST did not install correctly, or some of the application files or registry settings have been damaged.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • A file is missing, or part of the application failed to load or initialise. • In general, uninstalling the program (from 'Control Panel -> Add or remove programs') and then reinstalling should fix the problem.

<i>Message</i>	Cannot access the database, The database may be damaged or old. Please update to the latest database.
<i>Description</i>	This message normally means that GX Configurator-ST did not install correctly, or some of the application files or registry settings have been damaged.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • A file is missing, or part of the application failed to load or initialise. • If restarting the application or rebooting the PC does not help, uninstalling the program (from 'Control Panel -> Add or remove programs') and then reinstalling it may fix the problem.

<i>Message</i>	Failed to access some necessary information from database. The database may be damaged or old. Please update to the latest database.
<i>Description</i>	This message normally means that GX Configurator-ST did not install correctly, or some of the application files or registry settings have been damaged.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • A file is missing, or part of the application failed to load or initialise. • If restarting the application or rebooting the PC does not help, uninstalling the program (from 'Control Panel -> Add or remove programs') and then reinstalling it may fix the problem.

<i>Message</i>	Cannot read the database because it is of an old version. Please renew the database.
<i>Description</i>	This message normally means that GX Configurator-ST did not install correctly, or some of the application files or registry settings have been damaged.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • A file is missing, or part of the application failed to load or initialise. • In general, uninstalling the program (from 'Control Panel -> Add or remove programs') and then reinstalling should fix the problem.

<i>Message</i>	Cannot read the database because it is of a new version. Please update the application.
<i>Description</i>	This message normally means that GX Configurator-ST did not install correctly, or some of the application files or registry settings have been damaged.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • In addition to trying to uninstall and reinstall GX Configurator-ST, check that there is only one version installed on the computer. This error could occur if two versions of the software are installed into the same directory.

<i>Message</i>	Application becomes unstable. Please restart.
<i>Description</i>	This message may be shown if the application is not able to load a key file.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • If the message is only shown when opening a particular file, the file may be corrupt, have an invalid path, or could have been created by a much earlier or much later version of GX Configurator-ST. • If this message is shown regularly, try uninstalling and reinstalling the application.

<i>Message</i>	A MELSOFT application error has occurred. Please restart.
<i>Description</i>	This message may be shown if an unknown error occurs, i.e. an error which does not have its own error message. This is normally related to online operations or data communications.
<i>Causes and actions</i>	<ul style="list-style-type: none"> • This message may just be an unusual communications error. Make sure that the communication link is correct, and that you are connected to the right SLICE system. • Check that the configuration being edited does actually match the SLICE hardware. • Restarting the application may fix the problem. • If this message is shown regularly, try uninstalling and reinstalling the application.

Index

- 1 -

1:n verify 74, 79

- A -

A1SJ71PB92D 17
 Abbreviations 14
 About (Help menu) 36
 Access denied error (file) 196
 Add (Edit menu) 96
 Add button 63
 Add module dialog 96
 Add modules 96, 100
 Add modules using the wizard area 100
 Adding modules 96, 100
 Adding modules with "Add module" 96
 AJ65BT-64AD 15
 AJ65BT-64DAI 15
 AJ65BT-64DAV 15
 AJ65BTB1-16D 15
 AJ65SBTB1-16D 15
 AJ71PB92D 17
 Alignment 82, 86
 All delete 108
 All delete (Edit menu) 108
 Already running error 215
 Another module is performing online change error 212
 Application error 217
 Application unstable error 217
 Areas
 Information 18
 Request 18
 Arrange icons (Window menu) 54

- B -

Base module 14, 58, 127, 129, 155, 158, 180, 183
 Batch write cancelled error 209
 Baud rate 138
 Bit I/O range limit exceeded error 201
 Bit input area 10, 11, 15, 17, 18
 Bit inputs 160
 Bit output area 10, 11, 15, 18
 Bit output data 165
 Bit outputs 160

Block download of parameters 144
 Block write - no module selected error 209
 Block write cancelled error 209
 Br 10, 11, 17, 59, 61, 64, 66, 170, 171
 Br.n 155, 158, 180
 Br.n bit input area 15, 18
 Bus cycle time 18
 Bus refreshing module 14
 Bus terminator 17
 Buttons
 Add 63
 Delete 63
 Toolbar 55
 Bw 10, 11, 18, 59, 61, 64, 66, 165, 170, 171
 Bw.n 22, 155, 158, 165, 180
 Bw.n bit output area 15, 18
 Bw.n+1 165
 Bw.n+2 165
 Bw.n+3 165
 Byte pack 136, 206
 Byte pack check 26
 Byte packing 203

- C -

Cable 29
 Cancel download 144
 Cancel forced output test mode error 198
 Cannot access database error 216
 Cannot add more modules error 201
 Cannot add the head module 204
 Cannot delete head module error 206
 Cannot execute while monitoring active error 192
 Cannot set parameters of this module error 208
 Cannot show detail of module error 195
 Cascade (Window menu) 54
 CC-Link 14, 59, 132
 Change head module (Edit menu) 132
 Change head module type 132
 Change PROFIBUS-DP head module protocol version 134
 Change to diagnosis mode 149
 Changing modules online 180, 182, 183
 Channel 119, 121, 124, 146
 Channel not selected error (offset/gain) 200
 Check parameters 117, 124
 Check power distribution 130
 Checking the parameters for errors 124
 Clear 165, 180
 Clear log 156, 159
 Close 51
 Close (File menu) 71

- Close all (Window menu) 54
 - Close file while forced output test mode active error 199
 - Closing the program 51
 - Closing the project 71
 - Columnar writing 82, 94
 - COM port 138
 - Command 16, 18
 - Command execution area 10, 11, 16, 18
 - Command execution result 11
 - Command parameter 16
 - Command result area 10, 11, 15, 17
 - Communication baud rate 155
 - Communication error 37, 191, 192
 - Communication errors 191
 - Communication port 141
 - Communications
 - Errors 191
 - Setting up 138
 - Communications setup 138
 - Compare 74
 - Compare module errors 210
 - Compare projects 74
 - Comparing two configurations 74
 - Compatibility with earlier versions 20
 - Configuration
 - Printing 82
 - System 29
 - Configuration does not match error (verify) 210
 - Configuration errors 58, 59, 61
 - Configuration has changed error 195
 - Configuration mismatch error 194
 - Configuration setting 59
 - Configuration software 14
 - Configurations
 - Comparing 74
 - Creating CC-Link 68
 - Creating PROFIBUS-DP 68
 - Consumption 130
 - Contents (Help menu) 36
 - Control panel 47
 - Conversion 135, 136
 - Copy 109
 - Copy (File menu) 109
 - Copy to file (master station data communication monitor) 174
 - Copy to file (network parameter monitor) 177
 - Copying module information 109
 - Copying modules from another file 109
 - CPU 30
 - Cr 10, 11, 17, 171
 - Cr.n Command result area 15
 - Creating a new CC-Link configuration 68
 - Creating a new PROFIBUS-DP configuration 68
 - Creating a new project 68
 - Creating projects 67
 - Cw 10, 11, 18, 171
 - Cw.n Command execution area 16
 - Cycle time
 - Bus 18
 - STbus 16, 18
 - Cyclic transmission 15
- D -**
- Damaged file error 196
 - Data
 - I/O 18
 - Input 17
 - Output 18
 - Data link status 15
 - Database error 215
 - Database version error 216
 - Default parameters 120
 - Delete (Edit menu) 107
 - Delete all (Edit menu) 108
 - Delete all modules 108
 - Delete button 63
 - Deleting a module 107
 - Deleting all modules 108
 - Deleting modules 107, 206
 - Destination directory 73
 - Destination folder 41
 - Destination module not selected error (verify) 211
 - Details of information area 64
 - Details of module configuration window 56
 - Details of module list 59
 - Details of rack display 58
 - Details of toolbar 55
 - Details of wizard area 63
 - Diagnosis (Menu mode) 38
 - Diagnosis mode 38, 49, 118, 149
 - Diagnosis mode operation procedure 38
 - Diagnostics 149
 - Errors 193
 - Forced output test 165
 - I/O monitoring 160
 - Input/Output monitor 160
 - Master station data communication monitor 169, 174
 - Module detail information 154
 - Module detail information (head module) 155, 158

- Diagnostics 149
 - Module detail information (other modules) 155, 158
 - Monitoring 149, 160, 169, 174, 175, 177
 - Offset/gain settings 146
 - PROFIBUS-DP network parameter monitor 175, 177
 - Saving communication data 174
 - Saving PROFIBUS-DP network parameter monitor data 177
 - System monitor 149
 - Diagnostics errors 193
 - Diagnostics menu 34
 - Master station data communication monitor 169
 - Module detail information 154
 - Online module change 180
 - Profibus-DP network parameter monitor 175
 - Different head module type error 194
 - Different module configuration error 194
 - Display position 149
 - Display switching 53, 54
 - Documentation layout 8
 - Download 49
 - Download cancelled error 209
 - Download parameters 117
 - Download parameters as a block 144
 - Downloading a read only item error 208
 - Downloading and uploading the parameters 137
 - Downloading parameters 121
 - Drag and drop 114
 - Drop down menu 53
- E -**
- Edit (Mode menu) 38
 - Edit footer 88
 - Edit header 88
 - Edit menu 33
 - Add 96
 - All delete 108
 - Change head module 132
 - Delete 107
 - Delete all 108
 - Option 126
 - Parameter setting 117, 118
 - Power distribution check 130
 - Rearrange 112
 - Redo 112
 - Undo 111
 - Edit mode 38, 118
 - Edit mode only 53
 - Edit mode operation procedure 38
 - Editing the project 96
 - Environment of MELSOFT 41
 - Er 17, 171
 - Er.n 180
 - Error check (parameters) 124
 - Error clear area 11, 18
 - Error information area 11, 17
 - Error messages 191
 - Errors 198
 - 0180840b 139, 191
 - 0x0180840b 139, 191
 - A missing number will be made 203
 - Access denied (file) 196
 - Already running 215
 - Another module is performing online change 212
 - Application error 217
 - Application unstable 217
 - Batch write cancelled 209
 - Bit I/O range limit exceeded 201
 - Block write - no module selected 209
 - Block write cancelled 209
 - Byte pack consumption exceeds unused bits 206
 - Cancel forced output test mode 198
 - Cannot access database 216
 - Cannot add more modules 201
 - Cannot add the head module 204
 - Cannot communicate with head module 20, 140, 192
 - Cannot delete head module 206
 - Cannot execute while monitoring active 192
 - Cannot set parameters of this module 208
 - Cannot show detail of module 195
 - Channel not selected (offset/gain) 200
 - Clear log 156, 159
 - Close file while forced output test mode active 199
 - Communication 191
 - Configuration does not match (verify) 210
 - Configuration has changed 195
 - Configuration mismatch 194
 - Damaged file 196
 - Database 215
 - Database version 216
 - Destination module not selected (verify) 211
 - Diagnostics 193
 - Different head module type 194
 - Different module configuration 194
 - Download cancelled 209
 - Downloading a read only item 208

- Errors 198
- ES:10000002 20, 140, 192
 - Failed to read database 216
 - File 196
 - File name too long 197
 - File not found 197
 - File sharing violation 197
 - File version 196
 - Forced output 197
 - I/O monitor will be started 195
 - Initial page no. out of range 214
 - Insufficient memory 214
 - Intelligent module limit exceeded 202
 - Invalid forced output value 200
 - Maximum configuration reached 204
 - Memory 214
 - Messages 191
 - Missing files 215
 - Missing power supply module 204
 - Module addition 200
 - Module cannot be added at position 202
 - Module change already in progress 212
 - Module configuration 204
 - Module configuration not shown 209
 - Module copy 200
 - Module deletion 206
 - Module different from mounted module 208
 - Module does not support forced output test 198
 - Module does not support I/O monitoring 193
 - Module isn't selected 202
 - Module limit exceeded 201
 - Module parameters 207
 - Module selection 209
 - Module to delete is not selected 207
 - Module turning position out of range 213
 - Module verify (compare) 210
 - Monitoring will be stopped 195
 - Multiple instances 215
 - Must close print preview before exiting 213
 - Must switch to forced output test mode 199
 - No file path setting 203
 - No module selected 193, 208
 - No module selected (forced output test) 197
 - No module selected (I/O monitoring) 194
 - No module selected (offset/gain settings) 199
 - No module selected (online change) 211
 - No module selected (options) 209
 - No module selected (printing) 213
 - No monitor data to write 193
 - No output selected (forced output test) 200
 - No parameters selected 207
 - No power supply module in slot 1 204
 - No print item selected 213
 - Not enough memory 214
 - Offset and gain 197
 - Offset/gain input error 200
 - Offset/gain settings not supported 199
 - Offset/gain value out of range 200
 - Online change 211
 - Online change not supported 212
 - Online module change stopped 212
 - Parameter 207
 - Power consumption error 205
 - Power consumption exceeded after adding module 203
 - Power supply in slot 1 should have 'H-SET' base type 205
 - Power supply in this slot should have 'R-SET' base type 205
 - Printing 213
 - Registry 215
 - Restart application 217
 - Send / receive error 192
 - Source module not selected (verify) 210
 - Specified module does not exist (verify) 211
 - ST1X1616-DE1-S1-F required before ST1X1616-DE1-S1-L 206
 - ST1X1616-DE1-S1-L required before ST1X1616-DE1-S1-F 205
 - Stop monitoring before save 193
 - Switch mode while forced output test active 198
 - System 214
 - Timeout range error (transfer setup) 192
 - Unknown module 202
 - Unused bits exceeded after adding module 203
 - W I/O range limit exceeded 201
 - Window closed during offset/gain setting 199
 - Word I/O range limit exceeded 201
 - Wrong head module type 194
 - X/Y I/O range limit exceeded 201
- Ew 18, 171
- Ew.n 22, 146, 160, 165, 180
- Example printouts 94
- Exit (File menu) 51, 71
- Exiting GX Configurator-ST 51
- Extended cyclic 155
- Extended cyclic setting 59
- Extended diagnostic information 17
- External power supply 14
- F -**
- F1 help 20, 58, 59, 61
- Failed to read database error 216

Fast user switching 30
 FDL address 17, 54, 158
 Features 22
 File compatibility 20
 File errors 196
 File menu 33
 Close 71
 Copy 109
 Exit 51, 71
 New 68
 Open 70
 Print 82
 Recent files 33
 Save 72
 Save as 73
 Verify 74, 79
 File name 70, 73
 File name too long error 197
 File not found error 197
 File sharing violation error 197
 File version error 196
 Footer 88
 Forced output errors 197
 Forced output test 7
 Forced output test (diagnostics) 165
 Forced output test (Online menu) 165
 Function list 32

- G -

G.RDMSG 14
 Gain 146
 Get input / output data settings 143
 Get input/output data settings (online menu) 143
 Get system 49, 141
 Get system (online menu) 141
 Global control 18
 Glossary 14
 GP.RDMSG 14
 GSD file 17, 134
 GSD version 61, 134
 GX Configurator-DP 17
 GX Configurator-ST 14

- H -

Hard drive space 30
 Head module 7, 14, 58, 68, 114, 134, 149, 155,
 158, 169, 179, 180, 182, 183
 Cannot communicate 192
 Change type 132

Changing to CC-Link 132
 Changing to PROFIBUS-DP 132
 Mode 61, 134
 Protocol version 61, 134
 Resetting 179
 Head module mode 61, 134
 Head module protocol version 61
 Header 88
 Help menu 36
 About 36
 Contents 36
 Key operation list 190
 Hold 165, 180
 Horizontal writing 82, 94
 How do I... 27
 How to 27

- I -

I/O data 15, 18
 I/O module 7, 14
 I/O monitor will be started error 195
 I/O monitoring 160
 I/O occupation points 59, 61
 Information area 18, 56, 64
 Initial page no. out of range error 214
 Initialize Module Configuration View Position (view
 menu) 54, 56
 Input data 17
 Input module 14
 Input/output module 155, 158
 Input/Output monitor 160
 Input/Output monitor (online menu) 160
 Insert position 96
 Installation 40, 41
 Installation procedure 40
 Installing GX Configurator-ST 41
 Insufficient memory error 214
 Intelligent function module 14, 155, 158
 Intelligent module limit exceeded error 202
 Intelligent modules 146
 Interface modules
 A1SJ71PB92D 17
 AJ71PB92D 17
 QJ71PB92D 17
 Introduction 6
 Invalid forced output value error 200

- K -

Key operation list (Help menu) 190

Key operations list 190
Keyboard shortcuts 190

- L -

Label name 59, 61, 127, 129
Labels 127, 129
Landscape 82, 86, 88
Layout 8, 53
Link special relay 15
List of modules 59, 61
Local station 15

- M -

Master module 14
Master modules
 QJ71PB92V 17
Master station 15, 17, 134, 136
Master station data communication monitor 169, 174
Master station data communication monitor (Diagnostics menu) 169
Maximize 53
Maximum configuration reached error 204
Maximum input/output points 96, 129, 158
MELSEC-ST system 14
Memory 30
Memory errors 214
Menu bar 53
Menu list 33
Menus
 Diagnostics 34
 Edit 33
 File 33
 Help 36
 Mode 34
 Online 34
 View 34
 Window 36
Message transmission 10
Minimize 53
Missing files error 215
Missing number will be made error 203
Missing power supply module error 204
Mode 59
Mode menu 34
 Diagnosis 38
 Edit 38
Module 200, 204, 206, 207, 210
 Labels 126
 Options 126
 Module addition 200
 Module addition errors 200
 Module cannot be added at position error 202
 Module change already in progress error 212
 Module compare 210
 Module configuration 204
 Module configuration (View menu) 54
 Module configuration errors 204
 Module configuration not shown error 209
 Module configuration window 53, 54, 56, 68, 96, 107, 108
 Module copy errors 200
 Module copying 200
 Module deletion errors 206
 Module detail information (Diagnostics menu) 154
 Module different from mounted module error 208
 Module does not support forced output test error 198
 Module does not support I/O monitoring error 193
 Module graphic 64, 66
 Module isn't selected error 202
 Module limit exceeded error 201
 Module list 56, 59, 96, 107
 Module operating status 15
 Module options 126
 Module parameter errors 207
 Module selection errors 209
 Module status 149, 183
 Module status area 11, 17
 Module to delete is not selected error 207
 Module turning position 82
 Module turning position out of range error 213
 Module verification 210
 Module verify (compare) errors 210
 Modules 7, 200, 204, 206, 207, 210
 A1SJ71PB92D 17
 Add dialog 96
 Adding 96, 100
 Adding using the wizard area 100
 Adding with "Add module" 96
 Adding with wizard 100
 AJ71PB92D 17
 Base module 180, 183
 Changing online 180, 182, 183
 Changing order 112, 114
 Checking parameters 124
 Copying 109
 Copying from another file 109
 Deleting 107
 Deleting all 108
 Downloading parameters 121

Modules 7, 200, 204, 206, 207, 210
 Drag and drop 114
 Head 7, 14, 58
 Head module 114, 149, 155, 158, 169, 179, 180, 183
 I/O 7
 Input/Output 96, 100
 Input/output module 155, 158
 Intelligent 96, 100, 119, 146, 155, 158
 Master 14
 Online change 180, 183
 Online change precautions 180
 Online change procedures 182
 Parameters 117, 118, 121, 124
 Power distribution 96, 100, 130, 180
 Power distribution module 155, 158
 Power supply 58, 96
 Power supply module 114
 QJ61BT11N 14
 QJ71PB92D 17
 QJ71PB92V 17
 Rearranging 112, 114
 Rearranging with drag and drop 114
 Rearranging with the rearrange dialog 112
 Reorder 112, 114
 Replacing 183
 Setting parameters 117, 118, 121
 ST1AD2-I 146
 ST1AD2-V 146
 ST1DA1-I 146
 ST1DA1-I-F01 146
 ST1DA2-V 146
 ST1DA2-V-F01 146
 ST1H-BT 68
 ST1H-PB 68
 ST1PSD 58, 112, 130, 203
 ST1X1616-DE1-S1 180
 ST1X1616-DE1-S1-F 205
 ST1X1616-DE1-S1-L 206
 Uploading parameters 121
 Verifying parameters 121
 Monitor 149
 Monitor and test 149
 Monitoring 149, 169, 174
 Monitoring the system 149
 Monitoring will be stopped error 195
 Mr 17, 171
 Mr.n 180
 Multiple configurators 49, 53
 Multiple instances 49, 53
 Multiple instances running 215
 Must close print preview before exiting error 213

Must switch to forced output test mode error 199

- N -

n:n verify 74
 Network parameter monitor (PROFIBUS-DP) 175
 Network parameters 175
 New (File menu) 68
 New features 19
 Next window 53
 No file path setting error 203
 No module selected error 193, 208
 No module selected error (forced output test) 197
 No module selected error (I/O monitoring) 194
 No module selected error (offset/gain settings) 199
 No module selected error (online change) 211
 No module selected error (options) 209
 No module selected error (printing) 213
 No monitor data to write error 193
 No output selected error (forced output test) 200
 No parameters selected error 207
 No power supply module in slot 1 error 204
 No print item selected error 213
 No. of stations 59, 155
 Not enough memory error 214
 Notes for upgrading users 20
 Number of occupied I/O points 16, 18
 Number of stations 59, 155

- O -

Occupied I/O points 16, 18
 Occupied stations 155
 Offset 146
 Offset / gain settings 146
 Offset and gain errors 197
 Offset/gain input error 200
 Offset/Gain setting (Online menu) 146
 Offset/gain settings not supported error 199
 Offset/gain value out of range error 200
 Online change errors 211
 Online change not supported error 212
 Online menu 34
 Forced output test 165
 Get input/output data settings 143
 Get system 141
 Input/Output monitor 160
 Offset/Gain setting 146
 Parameter block write 144
 Reset head module 179
 Transfer setup 138

- Online module change 7, 180, 183
 - Connection to external device after replacement 187
 - Disconnect external device 186
 - Operations after external device connection 187
 - Preparation for replacing slice module 183
 - Replacing slice module 186
 - Online module change (Diagnostics menu) 180
 - Online module change precautions 180
 - Online module change procedures 182
 - Online module change stopped error 212
 - Online module operation 179
 - Open (File menu) 70
 - Opening an existing project 70
 - Opening projects 70
 - Operating environment 30, 41
 - Operating systems 41, 47, 49
 - Supported 30
 - Operation history 111, 112
 - Operation procedures 37
 - Option (Edit menu) 126
 - Option setting 126
 - Options 126
 - Orientation 82, 86, 88
 - Output data 18
 - Output module 14
 - Overview 22
- P -
- Page layout (printing) 88
 - Page number format 88
 - Parameter block write 49, 144
 - Parameter block write (Online menu) 144
 - Parameter error check 124
 - Parameter errors 207
 - Parameter setting 118
 - Parameter setting (Edit menu) 117, 118
 - Parameter settings 117, 118, 121, 124, 207
 - Parameter settings dialog 119
 - Parameters 74, 77, 79, 109
 - Block download 144
 - Block write 144
 - Checking 117
 - Checking for errors 124
 - Download as a block 144
 - Downloading 117, 121, 137
 - Error check 124
 - Network 175
 - Read from device 141
 - Reset to default 120
 - Setting 117, 118, 119
 - Slave 175
 - Uploading 117, 121, 137
 - Verifying 117
 - Verifying edited parameters 121
 - Point mode 105, 129, 143
 - Point mode change warning 105
 - Portrait 82, 86, 88
 - Power consumption 96, 100, 130
 - Power consumption error 205
 - Power consumption exceeded after adding module error 203
 - Power distribution check 26, 130
 - Power distribution check (Edit menu) 130
 - Power distribution module 14, 96, 155, 158, 180
 - Power feeding module 14
 - Power saving function 37
 - Power supply 130
 - External 14
 - Power supply module 58, 96, 100, 114
 - Power supply modules 130
 - Precautions 7, 37
 - Precautions for online module change 180
 - Preset 165
 - Preview printing 92
 - Previous versions 20
 - Previous window 53
 - Print (File menu) 82
 - Print examples 94
 - Print orientation 82, 86, 88
 - Print preview 51, 92, 213
 - Printer setup 86, 88
 - Printing 82
 - Examples 94
 - Page layout 88
 - Previewing 92
 - Printing errors 213
 - Printing the configuration 82
 - Procedures for online module change 182
 - PROFIBUS-DP 14, 61, 103, 132, 134, 143, 175, 177
 - PROFIBUS-DP network parameter (diagnostics) 175, 177
 - PROFIBUS-DPV0 17
 - PROFIBUS-DPV1 17
 - PROFIBUS-DPV2 17
 - Project
 - Editing 96
 - Printing 82
 - Project creation 67
 - Projects
 - Closing 71
 - Comparing 74

Projects
 Creating 67, 68
 Opening 70
 Saving 72
 Saving with a different name 73
 Verifying 74
 Protocol 68
 Protocol version 20, 61, 68, 103, 133, 134, 135, 136, 140, 149, 163, 171, 192, 195

- Q -

QJ61BT11 15
 QJ61BT11N 14, 15
 QJ71PB92D 17
 QJ71PB92V 17

- R -

rack display 56, 58, 96, 107, 114
 RAM 121, 124, 141, 144
 RDMSG 14
 Read configuration from device 141
 Read only 208
 Read parameters 141
 Rearrange (Edit menu) 112
 Rearrange dialog 112, 114
 Rearranging modules 112, 114
 Rearranging modules with drag and drop 114
 Rearranging modules with the rearrange dialog 112
 Recent files (File menu) 33
 Recommended speed 138
 Redo 112
 Redo (Edit menu) 112
 Registry error 215
 Release all 121, 144, 165
 Remote desktop 30
 Remote device station 15
 Remote I/O station 15
 Remote input 10, 15
 Remote net Ver. 1 mode 15
 Remote net Ver. 2 mode 15
 Remote output 10, 15
 Remote register 10, 15
 Remote station 15
 Removing GX Configurator-ST 47
 Reordering modules 112, 114
 Repeater 17
 Replacing modules online 183
 Request area 18
 Reserved byte 96, 103, 135, 136, 203

Reset head module 7
 Reset head module (Online menu) 179
 Reset the head module 179
 Resize 56, 59, 61
 Resolution 30
 Restart application error 217
 Resume 37
 ROM 121, 124, 138, 141, 144
 RS232 29
 RS232 cable 29
 RWr 10, 59, 64, 155
 RWw 10, 59, 64, 155
 RX 10, 59, 64, 155
 RY 10, 59, 64, 155

- S -

Safety precautions 7
 Save (File menu) 72
 Save as 51
 Save as (File menu) 73
 Save changes 71, 72
 Save project with a different name 73
 Save the project 72
 Saving communication data 174
 Saving network parameter monitor PROFIBUS-DP) 177
 Saving PROFIBUS-DP network parameter monitor data 177
 Screen layout 53
 Scroll bar 58
 Segments 17
 Select all 121, 144, 165
 Select base module 127, 129
 Send / receive error 192
 Serial port 138
 Setting a page layout 88
 Setting gain 146
 Setting module parameters 117, 118
 Setting offset 146
 Setting parameters 117, 118, 119
 Setting up communications 138
 Setting up the printer 86
 Setup
 Printer 86
 Shared files 47
 Slave parameter 17
 Slave parameters 175
 Slave station 17
 Slice module 14
 Slice No. 16, 18
 Slice number 16, 18

Slice position number 16
 Slices 64, 66
 Slots 64, 66
 Software licence 41
 Source module not selected error (verify) 210
 Specified module does not exist error (verify) 211
 ST bus cycle time 16, 18
 ST1H-BT 19, 68
 ST1H-PB 68
 ST1PSD 58, 112, 130, 203
 ST1X1616-DE1-S1 module 180
 Standby mode 37
 Start menu 41, 49
 Start more than once 49, 53
 Start slice No. 16
 Starting GX Configurator-ST 49
 Station address 54
 Station number 155
 Stations 59, 155
 Local 15
 Master 15
 Remote 15
 Remote device 15
 Remote I/O 15
 Status bar 54
 Status bar (View menu) 54
 Status bit detail 64
 Stop monitoring before save error 193
 Supply check 130
 Supply current 130
 Supported Operating Systems 30
 Suspend 37
 Sw 18, 171
 Switch mode while forced output test active error 198
 Switch to diagnosis mode 149
 Switch windows 53
 SWnD5C-PROFID-E 17
 SWnD5C-STPB-E 14
 Symbols used 9
 System
 Read from device 141
 System area 11, 18
 System Configuration 29
 System errors 214
 System monitor 54, 149
 System monitor (View menu) 54, 149
 System monitoring 149

- T -

Target memory 124, 144

Terminator 17
 Terms 14
 Terms and abbreviations 14
 Test 149
 Tile horizontally (Window menu) 54
 Tile vertically (Window menu) 54
 Timeout 138
 Timeout range error (transfer setup) 192
 Titlebar 51, 53
 Toolbar 53, 54, 55
 Toolbar (View menu) 54
 Toolbar buttons 55
 Toolbar icons 55
 Topic layout 8
 Transfer setup 138, 192
 Transfer setup (Online menu) 138
 Transmission
 Cyclic 15
 Transmission speed 158
 Turning position 82

- U -

Undo 111
 Undo (Edit menu) 111
 Uninstallation 40, 47
 Uninstalling GX Configurator-ST 47
 Unknown module error 202
 Unused bits 61, 96, 103, 203, 206
 Unused bits exceeded after adding module error 203
 Upgrading 20
 Upload 49
 Upload parameters 117
 Uploading parameters 121
 Use word input data 96, 103, 129, 132
 Use word output data 96, 103, 129, 132
 Using the status bar 54
 Using the toolbar 55

- V -

Verify 49, 74
 1:n 74, 79
 n:n 74
 Projects 74
 Result 77
 Verify (File menu) 74, 79
 Verify all modules 74, 210
 Verify parameters 117
 Verify result 77

Verify results 77, 118
 Verify selected modules 79, 210
 Verifying parameters 121
 Verifying projects 74
 Verifying the parameters being edited 121
 View menu 34, 54
 Initialize module configuration view position 54, 56
 Module configuration 54
 Status bar 54
 System monitor 54, 149
 Toolbar 54

- X -

XY I/O range limit exceeded error 201

- Z -

Zoom in 92
 Zoom out 92

- W -

W I/O range limit exceeded error 201
 What's new 19
 Window 53
 Window closed during offset/gain setting error 199
 Window menu 36, 54
 Arrange icons 54
 Cascade 54
 Close all 54
 Tile horizontally 54
 Tile vertically 54
 Window rearranging 54
 Windows
 Module configuration 56
 Wiring types
 Screw (E) 126, 154
 Spring clamp (S) 126, 154
 Without Wr 96, 103, 127, 129, 132, 143
 Without Ww 96, 103, 127, 129, 132, 143
 wizard area 56, 63, 100
 Word I/O range limit exceeded 201
 Word input area 10, 11, 15, 17, 18
 Word inputs 160
 Word output area 10, 11, 15, 18
 Word output data 165
 Word outputs 160
 Wr 10, 11, 17, 59, 61, 64, 66, 170, 171
 Wr.n 127, 129, 143, 155, 158, 160, 180
 Wr.n word input area 15, 18
 Wrong head module type error 194
 Ww 10, 11, 18, 59, 61, 64, 66, 165, 170, 171
 Ww.n 22, 127, 129, 143, 155, 158, 160, 165, 180
 Ww.n word output area 15, 18
 Ww.n+1 165

Microsoft, Windows, Windows XP, Windows Vista and Windows 7 are registered trademarks of Microsoft Corporation in the United States and other countries.
Pentium is a registered trademark of Intel Corporation in the United States and other countries.
Other company and product names herein are either trademarks or registered trademarks of their respective owners.
SPREAD
Copyright(C) 1998 Far Point Technologies, Inc.
Xtreme Toolkit Pro Copyright(C) 1998-2007 Code lock software

GX Configurator-ST Version 1.08J

Operating Manual

MODEL	SW1D5C-STPB-E-O-E
MODEL CODE	13JU47
SH(NA)-080439ENG-F(1205)MEE	



mitsubishi electric corporation

HEAD OFFICE : 1-8-12, OFFICE TOWER Z 14F HARUMI CHUO-KU 104-6212, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.