


MELSOFT MT Works2

Installation Instructions

Before Using the Product

Please read this document before use. Keep the document in a safe place for future reference. Make sure that the end users read the document.

For the precautions on using MELSOFT MT Works2, refer to the following manual.

 MELSOFT MT Works2 Setup Guidance

Notice

- Reprinting or reproducing the part or all of the contents of this document in any form for any purpose without the permission of Mitsubishi Electric Corporation is strictly forbidden.
- Although we have made the utmost effort to follow the revisions of the software and hardware, in some cases, unsynchronized matter may occur.
- The information in this document may be subject to change without notice.


Operating Environment

Item	Contents	
Personal computer	A personal computer on which Windows® operates	
CPU	Desktop PC: Intel® Celeron® Processor	2.8GHz or more recommended
	Laptop PC: Intel® Pentium® M Processor	1.7GHz or more recommended
Required memory	Windows® 7, Windows® 8, Windows® 8.1, Windows® 10 (64-bit edition)	2GB or more recommended
	Windows® 7, Windows® 8, Windows® 8.1, Windows® 10 (32-bit edition)	1GB or more recommended
	Windows Vista®	
	Windows® XP	
Available hard disk capacity	For installation: 13GB or more free hard disk capacity For operation: 512MB or more free virtual memory capacity	
Disk drive	3.5 inch (1.44MB) floppy disk drive (Note-1) DVD-ROM supported disk drive	
Monitor	Resolution 1024 x 768 pixels or higher	
OS (English version)	<ul style="list-style-type: none"> • Microsoft® Windows® 10 Home Operating System • Microsoft® Windows® 10 Pro Operating System • Microsoft® Windows® 10 Enterprise Operating System • Microsoft® Windows® 10 Education Operating System • Microsoft® Windows® 8.1 Operating System • Microsoft® Windows® 8.1 Pro Operating System • Microsoft® Windows® 8.1 Enterprise Operating System • Microsoft® Windows® 8 Operating System • Microsoft® Windows® 8 Pro Operating System • Microsoft® Windows® 8 Enterprise Operating System • Microsoft® Windows® 7 Starter Operating System • Microsoft® Windows® 7 Home Premium Operating System • Microsoft® Windows® 7 Professional Operating System • Microsoft® Windows® 7 Ultimate Operating System • Microsoft® Windows® 7 Enterprise Operating System • Microsoft® Windows Vista® Home Basic Operating System (Note-2) • Microsoft® Windows Vista® Home Premium Operating System (Note-2) • Microsoft® Windows Vista® Business Operating System (Note-2) • Microsoft® Windows Vista® Ultimate Operating System (Note-2) • Microsoft® Windows Vista® Enterprise Operating System (Note-2) • Microsoft® Windows® XP Professional Operating System SP3 (Note-2) • Microsoft® Windows® XP Home Edition Operating System SP3 (Note-2) 	
Communication interface (When a CPU module is directly connected.)	RS-232 port, USB port, Ethernet port, SSC I/F card (A30CD-PCF) (Note-3), SSC I/F board (A10BD-PCF) (Note-3)	

(Note-1): Required when installing the operating system software from a floppy disk.

(Note-2): 64-bit version is not supported.

(Note-3): The 64-bit edition of Windows® 7/Windows® 8 is not supported.
The 32-bit/64-bit edition of Windows® 8.1/Windows® 10 is not supported.

- For Windows® 7, Windows® 8, Windows® 8.1 and Windows® 10, if .NET Framework 3.5 (including .NET 2.0 and 3.0) is invalid, it needs to be valid.
- The following functions cannot be used. This product may not perform properly, when these functions are used.
 - Activating the application with Windows® compatible mode.
 - Simplified user switch-over
 - Remote desktop
 - Font sizes other than small font sizes (Advanced setting of Display Properties)
 - DPI setting other than 100% (set the size of text and illustration other than [smaller-100%])
 - Windows XP Mode
 - Windows Touch or Touch
 - Modern UI
 - Client Hyper-V
 - Tablet mode
 - Virtual Desktops
- In the following cases, the screen of this product may not work properly.
 - The size of the text and/or other items on the screen are other than default (such as 96 DPI, 100%, and 9pt).
For details, refer to the following manual.
 MELSOFT MT Works2 Setup Guidance
 - The resolution of the screen is changed in operation
 - The multi-display is set
- Use the product as a user having a privilege higher than 'Standard user' or 'Administrator' for Windows Vista®, Windows® 7, Windows® 8, Windows® 8.1 and Windows® 10. Otherwise, you should have the administrator level to link to SoftGOT.
- If the Windows firewall setting is enabled, the "Find Module function" and "Direct connection function" may not operate correctly. Disable the Windows firewall setting.

Installation

■ Confirm before installation

- Log on to the personal computer as a user having the Administrator authority.
- Close all the applications running under Microsoft® Windows® Operating System before installation. If the product is installed while other applications are running, it may not operate normally.

1. Insert the MELSOFT MT Works2 DVD-ROM to the DVD-ROM drive.
Double-click the "setup.exe" on the DVD-ROM.
2. Select or enter the necessary information by following the on-screen instructions. (Note-1)
(Note-1): Product ID is written on the "License certificate" included with the product. Enter the 12-digit number divided into 3 and 9 digits.

Packing List

Model name	Product name	Quantity
SW1DND-MTW2[J]-E (English version package) (Standard license product)	MELSOFT MT Works2 DVD-ROM	1
	MITSUBISHI ELECTRIC FA Library DVD-ROM	2
	Installation Instructions (This document)	1
	End-user software license agreement	1
	Software registration notice	1
	License certificate	1
SW1DND-MTW2-EA (English version package) (Volume license product)	MELSOFT MT Works2 DVD-ROM	1
	MITSUBISHI ELECTRIC FA Library DVD-ROM	2
	Installation Instructions (This document)	1
	End-user software license agreement	1
	Software registration notice	1
	License certificate	n (Note-1)
	MITSUBISHI ELECTRIC FA Library Guide	1

(Note-1): Number of licenses.

■ Acknowledgements

- We do not guarantee those commercially available Microsoft® Windows® Operating System products that are introduced in this manual.
- This software's copyright is owned by Mitsubishi Electric Corporation.
- This product (including manual) can be used under the Software License Agreement only.
- We do not take any responsibilities for the consequences of operating this product (including manual).


Uninstallation

Uninstall MELSOFT MT Works2 from the control panel of Windows®.

Installation of USB/SSCNET driver

In order to communicate with a CPU module via USB/SSCNET, a USB/SSCNET driver needs to be installed.

For a USB/SSCNET driver installation procedure, refer to the following manual.

 MELSOFT MT Works2 Setup Guidance

Microsoft, Windows, Windows Vista, Windows NT, Windows XP, Windows Server, Visio, Excel, PowerPoint, Visual Basic, Visual C++, Access, and DirectX® are registered trademarks of Microsoft Corporation in the United States, Japan and other countries.
Adobe® and Adobe® Reader® are registered trademarks of Adobe Systems Incorporated.
Intel, Pentium and Celeron are trademarks of Intel Corporation in the United States and other countries.
Ethernet is registered trademark of FUJI Xerox company in Japan.
Unicode is the registered trademark or trademark of Unicode, Inc. in the United States and other countries.
Generally, the names like company names, system names and product names mentioned herein are the registered trademarks or trademarks of their respective owners.
The trademark symbols (™, ®) mentioned herein maybe unspecified.
Setup Guidance in the DVD-ROM is a PDF file.
To view the PDF file, Adobe Reader is required. Download from the Adobe Systems website.