FX3U SERIES PROGRAMMABLE CONTROLLERS

**MITSUBISHI** 



O. 1	OHITKOLLLIKO			
HARDWARE MANUA				
	Manual Number	JY997D50301		
1	Revision	G		

This manual describes the part names, dimensions, mounting, cabling and specifications for the product. This manual is extracted from FXsU Series User's Manual - Hardware Edition. Refer to FXsU Series User's Manual - Hardware Edition for more details. Before use, read this manual and manuals of relevant products fully to acquire proficiency in the handling and operating the product. Make sure to learn all the product information, safety information, and precautions.
And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user. Registration
The company name and the product name to be described in this manual are the registered trademarks or trademarks of each

Safety Precaution (Read these precautions before use.) If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be **∆warning** and **∆caution**.

	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

ACAUTION may also cause severe injury. It is important to follow all precautions for po

М	TARTUP AND AINTENANCE RECAUTIONS	ΔN	/ARNING	
	Do not touch any t	erminal whi	le the PLC's nov	wer is on

N	TARTUP AND IAINTENANCE MARNING RECAUTIONS
•	Before cleaning or retightening terminals, cut off all ph the power supply externally. Failure to do so may cause electric shock.
•	Before modifying or disrupting the program in oper running the PLC, carefully read through this manual associated manuals and ensure the safety of the opera An operation error may damage the machinery o

JY997D50301G

Do not change the program in the PLC from two or more peripheral equipment devices at the same time. (i.e. from a programming tool and a GOT)
Doing so may cause destruction or malfunction of the PLC program. Use the battery for memory backup correctly in FX3U Serie User's Manual - Hardware Edition

User's Manual - Hardware Edition

- Use the battery only for the specified purpose.
- Connect the battery correctly
- Do not charge, disassemble, heat, put in fire, short-circuit,
connect reversely, weld, swallow or burn the battery, or apply
excessive forces (wibration, impact, drop, etc.) to the battery.
- Do not store or use the battery at high temperatures or
expose to direct sunlight.
- Do not spose to water, bring near fire or touch liquid
leakage or other contents directly,
- Incorrect handling of the battery may cause heat excessive leakage or other contents directly.

Incorrect handling of the battery may cause heat excessive generation, brusting, ignition, liquid leakage or deformation and lead to injury, fire or failures and malfunctions of facilities.

and other equipment.
When replacing the battery, make sure to use our specified product (FX3u-32BL).
When a battery error occurs ("BATT" LED is lit in red), follor When a battery error occurs ("BATT" LED is lit in red), follow the description in FX3U Series User's Manual - Hardware Edition.

M.	AINTENANCE AUTION RECAUTIONS
•	Turn off the power to the PLC before attaching or detaching memory cassette. If the memory cassette is attached detached while the PLC's power is on, the data in the mem may be destroyed, or the memory cassette may be damage.
•	Do not disassemble or modify the PLC.  Doing so may cause fire, equipment failures, or malfunctions  For repair, contact your local Mitsubishi Electric distributor.
•	Turn off the power to the PLC before connecting disconnecting any extension cable. Failure to do so may cause equipment failures or malfunctio
•	Turn off the power to the PLC before attaching or detaching following devices.

following devices.
Failure to do so may cause equipment failures or malfunctions.
- Display module, peripheral devices, expansion boards, and
special adapters
<ul> <li>Connector conversion adapter, extension blocks, and FX</li> </ul>
Series terminal blocks
- Battery and memory cassette
<ul> <li>Do not use the chemicals for cleaning.</li> </ul>
· If there is the possibility of touching the PLC inside a control
panel in maintenance, make sure to discharge to avoid the influence of static electricity.
· Since there are risks such as burn injuries, please do not touch
the surface of the equipment with bare hands when it is
operating in an environment which exceeds ambient
tomporature of EO°C

DISPOSAL PRECAUTIONS	<b>∴</b> CAUTION
for the environmen device.	ertified electronic waste disposal compar stally safe recycling and disposal of you batteries, separate them from other was agulations.
TRANSPORTATION AND STORAGE PRECAUTIONS	<b> ∴</b> CAUTION

Before transporting the PLC, turn on the power to the PLC

ı		check that the BATT LED is off.
ı		If the PLC is transported with the BATT LED on or the battery
ı		exhausted, the battery-backed data may be unst
ı		able during transportation.
ı	٠	The PLC is a precision instrument. During transportation, avoid
ı		impacts larger than those specified in Section 2.1 by using
ı		dedicated packaging boxes and shock-absorbing palettes.
ı		Failure to do so may cause failures in the PLC.
ı		After transportation, verify operation of the PLC and check for
ı		damage of the mounting part, etc.
ı	•	When transporting lithium batteries, follow required
ı		transportation regulations.
ı		(For details of the regulated products, refer to FX3U Series
ı		Hear's Manual - Hardware Edition )

Associated manuals	

2

1

	How to obtain manuals
For the	ne necessary product manuals or documents, consult with ocal Mitsubishi Electric representative.
Assoc	iated manuals
FX3U manua	Series PLC (main unit) comes with this document (hardwar il).
inform	detailed explanation of the FX3U Series hardware an ation on instructions for PLC programming and special ion unit/block, refer to the relevant documents.

Manual name	Manual No.	Description	
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains FX3U Series PLC specification details for I/O, wiring, installation, and maintenance.	
FX3s/FX3G/FX3GC/ FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/ applied instructions STL/ SFC programming and devices.	
MELSEC-Q/L/F Structured Programming Manual (Fundamentals)	SH-080782 MODEL CODE: 13JW06	Programming methods, specifications, functions, etc. required to create structured programs.	
FXCPU Structured Programming Manual [Device & Common]	JY997D26001 MODEL CODE: 09R925	Devices, parameters, etc. provided in structured projects of GX Works2.	
EYCDI I Structured			

		ı
lo.	Description	
801 DDE:	Application functions provided in structured projects of GX Works2.	T d
	Explains N:N link, parallel	C

Programming Manual [Application Functions]	MODEL CODE: 09R927	provided in structured projects of GX Works2.
FX Series User's Manual - Data Communication Edition	JY997D16901 MODEL CODE: 09R715	Explains N:N link, parall link, computer link, no protocol communication by RS instructions/FX2N 232IF.
FX3s/FX3G/FX3GC/ FX3U/FX3UC Series User's Manual - Analog Control Edition	JY997D16701 MODEL CODE: 09R619	Describes specifications for analog control and programming methods f FX3s/FX3G/FX3GC/FX3L FX3UC Series PLC.
FX3S/FX3G/FX3GC/ FX3U/FX3UC Series User's Manual - Positioning Control	JY997D16801 MODEL CODE: 09R620	Explains the specification for positioning control of FX3S/FX3G/FX3GC/FX3U FX3UC Series and

Marine standard

Manual name Manual

FX3U series main units, FX3U series special adapters and FX2N series input/output extension units/blocks supporting UL, cUL series input/output exte standards are as follows: UL, cUL file number: E95239
Models: MELSEC FX3U series manufactured
FX3U-+\*MR/ES(-A) FX3U-\*\*MT/ES(-A)
FX3U-+\*MT/FESS
Where +\* indicates: 16, 32, 48, 64, 80, 128

FX3U- \* \* MT/DS FX3U-\*\*MT/DSS FX3U-\* \*MT/IDSS
Where \*\* indicates: 16, 32, 48, 64, 80
FX3U-\* \*MR/IDA1 FX3U-\* \*MS/ES
Where \*\* indicates: 32, 64
FX3U-32ADP/-(MB) FX3U-4BADP(-MB)
FX3U-4DA-DP FX3U-4DA-DP FX3U-3A-ADP FX3U-4AD-PT-ADP FX3U-4AD-PTVV-AD-FX3U-4AD-TC-ADP FX3U-4HSX-ADP FX3U-2HSY-ADP FX3U-ENET-ADP FX3U-4AD-PTW-ADP FX3U-4AD-PNK-ADF

MELSEC FXDN series manufactured

FX2N-\* \*ER-ES/UL FX2N-\* \*ET-ESS/UL
Where \*\* indicates: 32, 48
FX2N-48ER-DS FX2N-48ET-DSS

FX2N-48ER-UAI/UL
FX2N-8ER-ES/UL FX2N-8EX-ES/UL
FX2N-8ER-ES/UL FX2N-8EX-ES/UL
FX2N-8ER-ES/UL FX2N-8EX-ES/UL FX2N-48ER-UA1/IUL FX2N-8ES-SÜLL FX2N-8EY-ES/UL FX2N-8EYT-ESS/UL FX2N-8EX-UA1/IUL FX2N-16EX-SÜLL FX2N-16EYR-ES/UL FX2N-16EYR-ES/UL FX2N-16EYR-ES/UL

### 3 ompliance with EC directive (CE Marking)

is product complies with EC directive, however, this document es not guarantee that a mechanical system including this product Caution for compliance with EC Directive

Please use the FX3U Series programmable controllers while installed in conductive shielded control panels under a general

industrial environment.

Programmable controllers are open-type devices that must be installed and used within conductive control panels. Please secure the control box lid to the control box (for conduction). Installation within a control box greatly affects the safety of the system and aids in shielding noise from the programmable controller.

For the control panel, use the product having sufficient strength, fire protectiveness and shielding property to an installation

24 V DC of the power supply must be supplied from the circuit double/reinforced insulated from the main power supply (MAINS) Caution for compliance with the Low Voltage Directive (LVD) (EN61010-2-201:2013) (\*1)

separated from a dangerous voltage by a double/reinforced insulation.

Between the commons having the adjacent relay output terminals, if an external power supply is higher than 120 V AC, the insulation is basic. Therefore, when using 120 V AC or higher external power supply and 50 V DC/AC or lower external power and the power of the control of the

Place the cutoff device so that it can be operated easily. Specify that the cutoff device is for this equipment (\*1) For the time of compliance with the Low Voltage Directive (LVD) (EN61010-2-201:2013), refer to FX3U Series User's Manual - Hardware Edition.

to make the following points:

As analog devices are sensitive by nature, their use should be considered carefully. For users of proprietary cables (integral with sensors or actuators), these users should follow those manufacturers installation requirements. manufacturers installation requirements.
Mitsubishi Electric recommend that shielded cables should be used.
If NO other EMC protection is provided, then users may experience
temporary induced errors not exceeding +10 %/-10 % in very heavy

Into other Environmental Survivous, uner tasers in survey experience temporary induced errors not exceeding +10 %-10 % in very heavy However. Mitsubishi Electric suggest that if adequate EMC precautions are followed with general good EMC practice for the users complete control system, users should expect normal errors as specified in this manual.

Sensitive analog cable should not be laid in the same trunking or cable conduit as high voltage cabling. Where possible users should run analog cables separately.

Good cable shelding should be used. When terminating the shield at Earth - ensure that no earth loops are accidentally created.

orealted. When reading analog values, EMC induced errors can be smoothed out by averaging the readings. This can be achieved either through functions on the analog special adapter/block or through a users program in the FX3u Series PLC main unit.

Compliance with UKCA marking The requirements for compliance with UKCA marking are the same as that with EC directive (CE marking).

Incorporated	l Items	
Check if the follow	ring product and items are included in	he packag
	Included Items	
■ Main units		
FX3U-16M□ to	Product	1 unit
	Dust proof protection sheet	1 sheet
FA30-120M	Manuals [Japanese (*1)/English]	1 manua
■ Input/output e	extension units	

Product Extension cable 1 cable ■ Input/output extension blocks

FX2N-8E□, FX2N-16E□

### 4

1. C	Outline
1.1	Part names
[1] [2] [3] [4] [5] [6]	[9] [10] [11] [11] [12] [13]
No.	Name
[1]	Top cover
[2]	Battery cover

[3] Special adapter connecting hooks (2 places)

[4] Expansion board dummy cover [6] Peripheral device connecting connecte

Model name (abbre Input display LEDs (Red)
 Terminal block covers [11] Extension device connecting connector cover


[12] RUN Green On while the PLC is running.

RUN Green On while the PLC is running.

RATT Red Lights when the battery voltage drops.

RROR Red Flashing when a program error occurs.

[13] Output display LEDs (Red) Nameplate printing [14]  $\triangle$  is a mark that instructs to use the cable with an appropriate temperature rating (80°C or more) for wiring.



(except FX3U-32MR/UA1 4- \phi4.5-diam mounting holes: FX3U-48M□, FX3U-64M□ FX3U-32MR/UA1

FX3U-32MR/UA1 FX3U-32MD (except FX3U-32MR/UA1) do not have the (*)-marked mounting holes.				
Model name	W: mm (inches)	W1: mm (inches) Direct mounting hole pitches	MASS (Weight): kg (lbs)	
FX3U-16M□	130 (5.12")	103 (4.06")	0.6 (1.32lbs)	
FX3U-32M□ (*2)	150 (5.91")	123 (4.85")	0.65 (1.43lbs)	
FX3U-48M□	182 (7.17")	155 (6.11")	0.85 (1.87lbs)	
FX3U-64M□ (*3)	220 (8.67")	193 (7.6")	1.00 (2.2lbs)	
FX3U-80M□	285 (11.23")	258 (10.16")	1.20 (2.64lbs)	

(\*2) FX3U-32MR/UA1 is equivalent to FX3U-48M□. (\*3) FX3U-64MR/UA1 is equivalent to FX3U-80M□. Installation

35-mm-wide DIN rail or Direct (screw) mounting (M4)

## 5

### 2. Installation (general specifications) As for installation of the input/output extension units/blocks, special adapters and expansion boards, refer to FX3U Series User's Manual

INSTALLATION PRECAUTIONS **∆**CAUTION Use the product within the generic environment specification described in section 2.1 of this manual. Never use the product in areas with excessive dust, oily smoke conductive dusts, corrosive gas (salt air, Cl2, H2S, SO2 o NO2), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire malfunctions, deterioration or damage may occur.

maturactions, detenoration or aimage may occur.

Do not touch the conductive parts of the product directly. Doing so may cause device failure or maffunctions.

Install the product securely using a DIN rail or mounting screws.

Install the product on a flat surface.

If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformities.

INSTALLATION ACAUTION

When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits.
Failure to do so may cause fire, equipment failures or malfunctions.

Be sure to remove the dust proof sheet from the PLC's ventilation port when installation work is completed. Failure to do so may cause fire, equipment failures or malfunctions.

Connect the extension cables, peripheral device cables, inputy output cables and battery connecting cable securely to their designated connectors.

Lose connections may cause malfunctions.

Turn off the power to the PLC before attaching or detaching the following devices.
Failure to do so may cause device failures or malfunctions.

Peripheral devices, display modules, expansion boards and special adapters

Extension units/blocks and the FX Series terminal block

Battery and memory cassette

Notes

When a dust proof sheet is supplied with an unit, keep the sheet applied to the ventilation silts during installation and wiring work.

To prevent temperature rise, do not install the PLC on a floor, a ceiling or a vertical surface.
Install it horizontally on a wall as shown in section 2.2.

Keep a space of 50 mm (1.97") or more between the unit main body and another device or structure (part A), Install the unit as far away as possible from high-voltage lines, high-voltage devices and power equipment.

devices and power equipment. Failure to do so may cause fire, equipment failures WIRING PRECAUTIONS **<u></u> MARNING** Cut off all phases of the power supply externally before installation or wiring work in order to avoid damage to the product or electric shock.

Item		·	Specifica	ation	
Ambient temperature	0 to 55 °C (32 to 131 °F) when operating and -25 to 75 °C (-13 to 167 °F) when stored				
Ambient humidity	5 to 95 %	RH (no co	ondensatio	n) when o	perating
		Fre- quency (Hz)	Accele- ration (m/s2)	Half amplitude (mm)	Sweep Cour
Vibration	When	10 to 57	-	0.035	for X, Y, Z: 10
resistance (*1)	installed on DIN rail	57 to 150	4.9	-	times (80 min in each
	When	10 to 57	-	0.075	direction)
	installed directly	57 to 150	9.8	-	
Shock resistance (*1)	147 m/s <sup>2</sup> Acceleration, Action time: 11 ms, 3 times by half-sine pulse in each direction X, Y, and Z				
Noise resistance	By noise simulator at noise voltage of 1,000 Vp-p, noise width of 1 $\mu s$ , rise time of 1 ns and period of 30 to 100 Hz				
Dielectric withstand	1.5 kV At minute	C for one			
voltage (*2)	500 V AC minute	for one	Between each terminals and ground terminal		
Insulation resistance (*2)	5 MΩ or higher by 500 V DC insulation resistance tester				
Grounding	Class D grounding (grounding resistance: $100 \Omega$ or less) <common a="" allowed.="" electrical="" grounding="" heavy="" is="" not="" system="" with=""> (*3)</common>				

<2000 m (\*4)

II or less

2 or less

Inside a control panel (\*5)

2.1 Generic specifications

Free from corrosive or flammable gas and excessive conductive dusts


■ Expansion boards, Special adapters, Special function units/blocks


6

<ul><li>*1) The criterion is shown in IEC</li><li>*2) Dielectric withstand voltage shown in the following table.</li></ul>	e and insulation	on resistance are	
Terminal	Dielectric strength	Insulation resistance	
■ Main units, Input/output exte	nsion units/ble	ocks	
Between power supply terminal (AC power) and ground terminal	1.5 kV AC for one minute		
Between power supply terminal (DC power) and ground terminal	500 V AC for one minute		
Between 24 V DC service power supply connected to input terminal (24 V DC) and ground terminal	500 V AC for one minute	5 MΩ or higher by 500 V DC insulation	
Between input terminal (100 V AC) and ground terminal	1.5 kV AC for one minute	resistance tester	
Between output terminal (relay) and ground terminal	1.5 kV AC for one minute		
Between output terminal (transistor) and ground terminal	500 V AC for one minute		
Between output terminal (triac)	1.5 kV AC for		

Between terminal of special adapter and ground terminal 500 V AC for 1 min 5 MΩ or higher by 500 V DC insulation resistance tester For dielectric with stand voltage test and insulation test of each product, refer to the following manual.

Install the PLC in an environment conforming to the generic specifications (section 2.1), installation precautions and notes. For more details, refer to FX3U Series User's Manual - Hardware





2.2.1 Affixing the dust proof sheet inning the installation and thinking in the instructions on the dust proof sheet.

→ For the affixing procedure, refer to the instructions on the dust proof sheet. Be sure to remove the dust proof sheet when the insta wiring work is completed.

Refer to FX3U Series

DC power 24 V DC +20 %, -30 %

AC power 24 V DC +10 %, -10 %

DC power 24 V DC +20 %, -30 %

3.9 kΩ

3.3 kΩ

4.3 kΩ

7 mA/24 V DC

5 mA/24 V DC

X000 to 6 mA/24 V DC

X000 to X005 3.5 mA or more

X006, X007

X010 or more

X006, X007

X010 or more

nit/block

unit/block

Specification

rdware Edition AC power 24 V DC +10 %, -10 %

4.3 kΩ (Does not apply to FX3U-16M□.)

3.5 mA or more/24 V DC

sink input:
No-voltage contact input
NPN open
collector transistor
Source input:
No-voltage contact input
PNP open
collector transistor

LED on panel lights when

Y000 to Y002 5 μs or less/10 mA or more (5-24 V DC)

Y003 or 0.2 ms or less/200 m/

more or more (at 24 V DC) 0.2 ms or less/200 ma or more (at 24 V DC)

Y000 to Y002 5 μs or less/10 mA or more (5-24 V DC

Y003 or more 0.2 ms or less/200 m/ or more (at 24 V DC)

(\*1) The total load current of resistance loads per commor

8 output points/common terminal: 1.6 A or less
As for the number of outputs per common terminal, refer to
"Chapter 4 interpretation of partition" and the following mar

(\*2) The total load current of resistance loads per common

(\*3) The total load current of resistance loads per commor

terminal should be the following value.

→ Refer to FX3U Series User's Manual - Hardware Edition

4 output points/common terminal: 2 A or less
 As for the number of outputs per common terminal, refer to the

→ Refer to FX3∪ Series User's Manual - Hardware Edition.

reminal should be the following value.

- 16 output point/common terminal: 1.6 A or less
As for the number of outputs per common terminal, refer to the

Illowing manual.

→ Refer to FX3u Series User's Manual - Hardware Edition
he total of inductive loads per common terminal should be

The total of inductive loads per common terminal should be the following value.

1 output point/common terminal: 12 W or less/24 V DC.

4 output points/common terminal: 13.9 W or less/24 V DC.

8 output points/common terminal: 38.4 W or less/24 V DC.

As for the number of outputs per common terminal, refer to "Chapter 4 interpretation of partition" and the following manual.

→ Refer to FX3U Series User's Manual - Hardware Edition.

- 4 output points/common terminal: 48 W or less/24 V DC As for the number of outputs per common terminal, refer to the

lowing manual.

• Refer to FX3U Series User's Manual - Hardware Edition

e total of inductive loads per common terminal should be

the following value.

- 16 output points/common terminal: 38.4 W or less
As for the number of outputs per common terminal, refer to the

(\*7) The response time is as follows in the FX2N-8EYT-h OFF→ON: 0.2 ms or less/1 A

erminal should be the following value.

- 1 output point/common terminal: 0.5 A or less
- 4 output points/common terminal: 0.8 A or less

or more (at 24 V DC)

LED on panel lights when photocoupler is driven.

.5 mA or less

pprox. 10 ms

Another ed

Input connecting type

Input signal current

OFF input

Input response time

Input circuit insulation


Output operation display

# 7


### 2.3 Procedures for installing to and detaching from DIN rail

The products can be installed on a DIN46277 rail [35 mm (1.38") wide]. This section explains the installations of the main units. For the input/output extension units/blocks and special adapters, refer to the following manual. Refer to FX3U Series User's Manual - Hardware Edition. 2.3.1 Installation

Connect the expansion boards and special adapters to the main unit



Fit the upper edge of the DIN rail mounting groove (right fig.B) onto the DIN rail.



2.4 Procedures for installing directly (with M4 screws)

The product can be installed directly on the panel (with screws).

This section explains the installation of the main units.

As for the details of the installation/detaching for input extension units/blocks and special adapters, refer to the following manual.

Refer to FXsu Series User's Manual - Hardware Edition. 2.4.1 Mounting hole pitches Refer to the External Dimensions (section 1.2) for the products mounting hole pitch information.

As for the details of the mounting hole pitches for extension unit block and special adapters, refer to the following manual.

Refer to FX3U Series User's Manual - Hardware Edition.

 Fit the main unit (A in the right figure) based on the holes, and secure it with M4 screws (B in the right figure) the right figure).
The mounting hole pitches and number of screws depend on the product. Refer to the external dimensions diagram.

### 3. Power supply/input/output specifications and examples of external wiring

As for the details of the power supply wiring and input/output wiring, refer to FX3∪ Series User's Manual - Hardware Edition.

Make sure to have the following safety circuits outside of the PLC to ensure safe system operation even during external power supply problems or PLC failure.

1) Most importantly, have the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit (to prevent damage to the equipment at the upper and lower positioning limits). 2) Note that when the PLC CPU detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off, Also, when an error that cannot be detected by the PLC CPU occurs in an input/output control block, output control may be disabled.

External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

3) Note that the output current of the 24 V DC service power supply varies depending on the model and the absence/ presence of extension blocks. If an overload occurs, the voltage automatically drops, inputs in the PLC are disabled, and all outputs are turned off.

External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

4) Note that when an error occurs in a relay, triac or transistor output device, the output could be held either on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

DESIGN CAUTION Do not bundle the control line together with or lay it close to to main circuit or power line. As a guideline, lay the control line least 100 mm (3.94") or more away from the main circuit

Install module so that excessive force will not be applied

peripheral device connectors. Failure to do so may result in wire damage/breakage or PL

power line. Noise may cause malfunctions.

## 8

Notes Simultaneously turn on and off the power supplies of the munit and extension devices Even if the AC power supply causes an instantaneous po ailure for less than 10 ms, the PLC can continue to operate Even if the DC power supply causes an instantaneous po failure for less than 5ms, the PLC can continue to operate. If a long-time power failure or an abnormal voltage drop occur the PLC stops, and output is turned off. When the pow supply is restored, it will automatically restart (when the RL input is on).

WIRING MECAUTIONS WARNING Make sure to cut off all phases of the power supply externs before installation or wiring work.
Failure to do so may cause electric shock or damage to the conduct. The temperature rating of the cable should be 80°C or more

WIRING ACAUTION Connect the AC power supply to the dedicated to described in this manual. described in this manual. If an AC power supply is connected to a DC input/outp terminal or DC power supply terminal, the PLC will burn out. Do not wire vacant terminals externally. Doing so may damage the product. Perform class D grounding (grounding resistance:  $100 \Omega c$  less) to the grounding terminal on the FX3U PLC main unit will a wire 2 mm² or thicker.

a wire 2 mm² or thicker.
Do not use common grounding with heavy electrical systems (refer to section 3.3).
When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation silts.
Failure to do so may cause fire, equipment failures or maffunctions. Make sure to properly wire to the terminal in accordance wit the following precautions. Failure to do so may cause electric shock, equipment failures, short-circuit, wire breakage, malfunctions, or damage to the

dimensions described in the manual.


Tightening torque should follow the specifications in the manual. Input/output wiring 50 to 100 m (1641" to 328"1") long vicause almost no problems of noise, but, generally, the writingth should be less than 20 m (65"7) to ensure the safety. Extension cables are easily affected by noise. Lay the cable at a distance of at least 30 to 50 mm (1.19" to 1.9") away for the PLC output and other power lines.

roduct. The disposal size of the cable end should follow the

3.1 Wiring

3.1.1 Cable end treatment and tightening torque For the terminals of FX3U series PLC, M3 screws are used

For the airminus of T-AU senters V, Ms Screws are used. The electric wire ends should be treated as shown below. Tighten the screws to a torque of 0.5 to 0.8 Nrm. Do not tighten terminal screws with a torque outside the above-mentioned range. Failure to do so may cause equipment failures or malfunctions.



	-			
Reference>				
Terminal manufacturer	Type No.	Applicable cable	Certification	Pressure bonding tool
.S.T. Mfg. Co.,	FV1.25-B3A	AWG22 to 16	UL Listed	YA-1 (J.S.T. Mfg. Co., Ltd.)
iu.	FV2-MS3	AWG16 to 14		
When two wires are connected to one terminal(*1)				
ø3.2 (0.13")				

6.2 mm (0.24") or less 6.3 mm (0.25")
or more 6.2 mm (0.24") or less 6.3 mm (0.25") or more

Terminal manufacturer Type No. Applicable cable Certification bonding tool J.S.T. Mfg. Co., Ltd. FV1.25-B3A AWG22 to 16 UL Listed YA-1 (J.S.T. Mfg. Co., Ltd.) (\*1) To adapt the Low Voltage Directive (LVD) (EN61010-2-201:2013) of the EC directive, avoid the wiring with two wires to the built-in terminal, and take an appropriate action such as

adding an external terminal.

For the time of compliance with the Low Voltage Directive
(LVD) (EN61010-2-201:2013), refer to FX3U Series User's
Manual - Hardware Edition. 3.1.2 Removal and installation of quick-release terminal block

3.4.6 Examples of 100V AC input wiring

 Bemoval
 Unscrew the terminal block mounting screw [both right and left screws] evenly, and remove the terminal block.

Installation Place the terminal block in the specified position, and lighten the terminal block mounting screw evenly [both right and left screws].

Tightening lorque 0.4 to 0.5 N-m
Do not tighten the terminal block mounting screws exceeding with a torque outside the above-mentioned range. range.
Failure to do so may cause equipment failures or malfunctions.

(\*) Pay attention so that the center of the terminal block

100 to 240 V AC

### 3.2 Power supply specifications and example of s for the details of the power supply specifications and example of ternal wiring, refer to the following manual.

Power supply specifications
[Main unit, Input/output extension units]

→ Refer to FX3U Series User's Manual - Hardware Edition.

AC power type -30%, +20% (\*5) Voltage fluctuation range Main unit

FX2N-32E□, FX2N-48E□ 5%, +10% Rated frequency FX3U-16M□ to 32M□ (\*7) 250 V 3.15 A FX3U-48M□ to 250 V 5 A X2N-32E□ 250 V 3.15 A 250 V 5 A FX2N-48E□ 250 V 5 A 30 A max. 5 ms or less/100 V AC 65 A max. 5 ms or less/200 V AC 40 A max. 5 ms FX2N-32E□, FX2N-48E□ or less/100 V AC 60 A max. 5 ms or less/200 V AC FX3U-16M□ 30 W FX3U-32M□ 35 W 30 W FX3U-48M□ 40 W FX3U-64M□ 45 W 40 W FX3U-128M□ 65 W FX2N-32E□ 30 W FX2N-48E□ 35 W

# special extension units, and of the extension blocks/special extension blocks connected to those units. For the power (current) consumed by the extension units/ Hardware Edition. For the power consumed by the special extension units/ blocks, refer to the appropriate manual.

(\*2) When input/output extension blocks are connected, the 24 V OC service power supply is consumed by the blocks, and the current value to be used by the main unit is reduced. The AC power (AC input) type and DC power type do not have a service power supply. (\*3) Cannot be used to supply power to an external destination. The power is supplied to input/output extension blocks, special extension blocks, special adapters and expansion


Doards.

The following manual shows further information.


→ Refer to FX3U Series User's Manual - Hardware Edition. (\*4) When the supply voltage is 200 V AC, the time can be changed to 10 to 100 ms by editing the user program. (\*5) When supply voltage is 16.8-19.2 V DC, the connectable extension equipment decreases. The following manual shows further information.

mer information. → Refer to FX3U Series User's Manual - Hardware Edition. (\*6) When attaching high-speed input/output special adapter (FX3u-4HSX-ADP, FX3u-ZHSY-ADP) and special function block (FX0n-3A, FX2n-2AD, FX2n-2DA), the number of connectable modules to the main unit is limited, due to the current consumption (internal 24 V DC) at startup. The following manual shows further information.

— Refer to FX3u Series User's Manual - Hardware Edition. (\*7) 250 V 5 A is specified for the power fuse of FX3U-32MR/UA1.




## 10



Ground the PLC independently if possible.


If it cannot be grounded independently, ground it jointly as show ndependent grounding Shared grounding Common ground (Best condition) (Good condition) (Not allowed)

3.4 Input specifications and external wiring Specification Item points (8 points) (\*1) FX2N-8ER□



Perform class D grounding. (Grounding resistance: 100  $\Omega$  or less)


As for the details of the input specifications and external wiring, refer 3.4.1 Input specifications (24 V DC input type)




PLC Another equipment PLC Another equipment Use ground wires thicker than AWG14 (2 mm2). Position the grounding point as close to the PLC as possible to decrease the length of the ground wire.

FX3U-32M□ FX2N-16EX□ FX2N-32E□ FX3U-48M 24 points FX3U-64M□ 32 points

## 11



[1]: Main unit, Input/output extension unit (Common to both sink and source inputs) [2]: Input/output extension block (Common to both sink and source inputs)



since they are not available



Also make sure that the input current is over the input-sensing evel while the switches are ON. Sink input OV S/S LED X 14 24V S/S LED 0V

 $Rb \le \frac{4Rp}{15-Rp} (k\Omega)$ Sink input 24V Rb OV Rt ×-----× 15 kΩ or more


# 12

Use a two-wire proximity switch whose leakage current, I\(\mathbf{1}\), is 1.5 m\(\mathbf{A}\) or less when the switch is off.

When the current is larger than 1.5 m\(\mathbf{A}\), connect a bleeder  $Rb \leq \frac{6}{1\ell - 1.5} (k\Omega)$ 

0V 24V 3.4.5 Input specifications (100 V AC input type)

	FX2N-8EX-UA1/UL	8 points	
Number of input	FX3U-32MR/UA1	16 points	
points	FX2N-48ER-UA1/UL	24 points	
	FX3U-64MR/UA1	32 points	
Input conne	cting type	Refer to FX3U Series User	
Input form		Manual - Hardware Edition	
Input signal	voltage	100 to 120 V AC +10 %, -15 % 50/60 Hz	
Input impedance		Approx. 21 kΩ/50 Hz Approx. 18 kΩ/60 Hz	
Input signal current		4.7 mA/100 V AC 50 Hz 6.2 mA/110 V AC 60 Hz (70 % or less when turned simultaneously)	
ON input se	ensitivity current	3.8 mA or more	
OFF input s	ensitivity current	1.7 mA or less	
Input response time		30 ms or less (A high speed receiving is improper)	
Input signal	form	Contact input	
Innest ainestit	innulation	Dheteecunies inculation	



[2]: Input extension block (100 V AC input type) Relay output specifications and example of external wiring As for the details of Instructions for connecting input devices, refer to → Refer to FX3∪ Series User's Manual - Hardware Edition Relay output specifications

### Item Specificatio FX2N-8ER□ 4 points (8 points) (\*1) FX3U-16MR□, FX2N-8EYR□ FX3U-32MR/□, FX2N-32ER□, FX2N-16EYR□ FX3U-48MR□, FX2N-48ER□ 24 points FX3U-64MR/□ 32 points FX3U-128MR/ES 64 points Output connecting type Output form s ("250 V AC or less" f not a CE, UL, cUL comp 2 A/point (\*2) Max. load Resistance load 2 A/poi Min. load 5 V DC. 2 mA (reference value) Response OFF→ON time ON→OFF

overleaf, this chemical symbol means that the battery or accumulator contains a heavy metal at a certain concer This will be indicated as follows:

Batteries to be built in modules (spare parts and optional parts)

Lithium Manganese Dioxide Battery

Hg: mercury(0.0005%) Cd: cadmium(0.002%)

FX3U Series main unit FX3U-32BL

FX3U-32BL

Series name/ product name Used battery name

LED on panel lights when power is

Battery type

80 VA

13 (\*1) Each value inside ( ) indicates the number of occupied points (\*2) The total load current of resistance loads per common terminal should be the following value.

- 1 output point/common terminal: 2 A or less
- 4 output points/common terminal: 8 A or less

FX3U-16M□ to 400 mA or less

FX2N-48E□ 460 mA

5 V DC Main unit 500 mA or less

builtin power supply (\*3) FX2N-48E 690 mA or less

FX2N-32E 250 mA

→ Refer to FX3U Series User's Manual - Hardware Edition. 3.5.2 Life of relay output contact The product life of relay contacts considerably varies depending or the load type used. Take care that loads generating reverse electromotive force or usik current may cause poor contact of deposition of contacts which may lead to considerable reduction of the contact product life.

8 output points/common terminal: 8 A or less
As for the number of outputs per common terminal, refer to
"Chapter 4 interpretation of partition" and the following man
"The provided in the second of the second

Inductive loads generate large reverse electromotive force between contacts at shutdown which may cause arcing. At a fixed current consumption, as the power factor (phase between current and voltage) gets smaller, the arc energy gets larger. The standard life of the contact used for Inductive loads, such as contactors and solenoid valves, is 500 thousand operations at 20 M.A. 20 VA.
The following table shows the approximate life of the relay based on the results of our operation life test. Test condition: 1 sec.ON / 1 sec.OFF. 
 Load capacity
 Contact life

 20 VA
 0.2 A/100 V AC

 0.1 A/200 V AC
 3 million times
 35 VA 0.35 A/100 V AC 0.17 A/200 V AC 1 million times

0.8 A/100 V AC 2 hundred thousand times 2 The product life of relay contacts becomes considerably shorter than the above conditions when the rush overcurrent is shut down.

→ For countermeasures while using inductive loads, refer to Subsection 3.5.4.

Some types of inductive loads generate rush current 5 to 15 times the stationary current at activation. Make sure that the rush current does not exceed the current corresponding to the maximum specified resistance load.

 Lamp load
 Lamp loads generally generate rush current 10 to 15 times the stationary current. Make sure that the rush current does not exceed the current corresponding to the maximum specified resistance load. Capacitive load
 Capacitive loads can generate rush current 20 to 40 times the stationary current. Make sure that the rush current does not exceed the current corresponding to the maximum specified resistance load. Capacitive loads such as capacitors may be

present in electronic circuit loads including inverters.

→ For the maximum specified resistance load, refer to Subsection 3.5.1.

### 3.6 Transistor output specifications and example of external wiring As for the details of the transistor output specifications and external wiring, refer to the following manual.

3.5.4 Cautions in external wiring For cautions in external wiring, refer to the following manual.

→ Refer to FX3∪ Series User's Manual - Hardware Edition.

Protection circuit for load short-circuiting
When a load connected to the output termin
printed circuit board may be burnt out. Fit a p Protection circuit of contact when inductive load is used
An internal protection circuit for the relays is not provided for the relay output circuit. It is recommended to use inductive loads with built-in protection circuits. When using loads without built-in protection circuits, insent an external contact protection circuit, etc. to reduce noise and extend the product life. ) DC circuit Connect a diode in parallel with the load. Use a diode (for commutation) having the following

Item Standard
verse voltage 5 to 10 times the load voltage AC circuit
Connect the surge absorber (combined CR components such as a surge killer and spark killer, etc.) parallel to the load.
Select the rated voltage of the surge absorber suitable to the output used. Refer to the table below for other specifications.

Interiors

Loads, such as contactors for normal and reverse rotations, that
must not be turned on simultaneously should have an interlock in the
PLC program and an external interlock.

Common mode
Use output contacts of the PLC in the common mode.

# 14

FX3U-128M□

Exter

$\rightarrow$	Refer to	o FX3U Series User's M	lanual - Hardware Edition.		
	Transis	stor output specifica	tions		
		Item	Specification		
		16MT/□, BEYT□	8 points		
oer	FX2N-3	32MT/□, 32ET□, 16EYT□	16 points		
ıt s		48MT/□, 48ET□	24 points		
	FX3U-6	64MT/□	32 points		
	FX3U-8	B0MT/□	40 points		
	FX3U-	128MT/ES(S)	64 points		
ut connecting type		ng type	Refer to FX3U Series User's Manual - Hardware Edition		
ut	FX3U-□□MT/□S(-A), FX2N-□ET, FX2N-48ET-D, FX2N-□EYT, FX2N-8EYT-H		Transistor (Sink)		
	FX3U-□□MT/□SS, FX2N-□ET-ESS/UL, FX2N-48ET-DSS, FX2N-□EYT-ESS/UL		Transistor (Source)		
nal	power s	supply	5-30 V DC		
	Resis tance load	FX3U-□MT/□, FX2N-□ET, FX2N-□ET-□, FX2N-□EYT, FX2N-□EYT-ESS/UL	0.5 A/point (*1)		
	ioau	FX2N-8EYT-H	1 A/point (*2)		
		FX2N-16EYT-C	0.3 A/point (*3)		
	Induc tive	FX3U-□MT/□, FX2N-□ET, FX2N-□ET-□, FX2N-□EYT, FX2N-□EYT-ESS/UL	12 W/24 V DC (*4)		
	load	FX2N-8EYT-H	24 W/24 V DC (*5)		
		FX2N-16EYT-C	7.2 W/24 V DC (*6)		
oac			-		

64 points

M	0161	
	Specification	
16MT/□, BEYT□	8 points	
32MT/□, 32ET□, 16EYT□	16 points	
18MT/□, 18ET□	24 points	
64MT/□	32 points	
BOMT/□	40 points	
128MT/ES(S)	64 points	
ng type	Refer to FX3U Series User's Manual - Hardware Edition	
□□MT/□S(-A), □ET, 48ET-D, □EYT, BEYT-H	Transistor (Sink)	
□□MT/□SS, □ET-ESS/UL, 48ET-DSS, □EYT-ESS/UL	Transistor (Source)	
supply	5-30 V DC	
FX3U-□MT/□, FX2N-□ET, FX2N-□ET-□, FX2N-□EYT, FX2N-□EYT-ESS/UL	0.5 A/point (*1)	
FX2N-8EYT-H	1 A/point (*2)	
FX2N-16EYT-C	0.3 A/point (*3)	
FX3U-□MT/□, FX2N-□ET, FX2N-□ET-□, FX2N-□EYT, FX2N-□EYT-ESS/UL	12 W/24 V DC (*4)	
FX2N-8EYT-H	24 W/24 V DC (*5)	
FX2N-16EYT-C	7.2 W/24 V DC (*6)	
	22MT/C), 22ETC), 82ETC), 88MT/C), 88MT/C), 88MT/C  90MT/C  228MT/ES(S) 228MT/E	

0.1 mA or less/30 V DC

15

3.6.2 External wiring of transistor output 1. External wiring of sink output type 2. External wiring of sou ce output type

24 V DC

Fuse 24 V DC 2  $\bigcirc$ 3.6.3 Cautions in external wiring utions in external wiring, refer to the following manual. → Refer to FX₃∪ Series User's Manual - Hardware Edition.

Protection circuit for load short-circuits
A short-circuit at a load connected to an output terminal could cause
burnout at the output element or the PCB. To prevent this, a
protection fuse should be inserted at the output.
Use a load power supply capacity that is at least 2 times larger than
the total rated fuse capacity. Contact protection circuit for inductive loads
When an inductive load is connected, connect a diode (for commutation) in parallel with the load as necessary. The diode (for commutation) must comply with the following Item Guide 5 to 10 times of the load voltage

Interlock
Loads, such as contactors for normal and reverse rotations, that must not be turned on simultaneously should PLC program and an external interlock.

3.7 Triac output specifications and example of external wiring As for the details of the triac output specifications and external wiring, refer to the following manual. refer to the following manual. → <mark>Refer to FX3∪ Series User's Manual - Hardware Edition.</mark> 3.7.1 Triac output specifications

	Item	Specification
Number of output points	FX3U-32MS/ES, FX2N-16EYS, FX2N-32ES	16 points
points	FX3U-64MS/ES	32 points
Output conr	necting type	Refer to FX3U Series User's Manual - Hardware Edition
Output forn	n	Triac (SSR)
External power supply		85 to 242 V AC
	Resistance load	0.3 A/point (*1)
Max. load	Inductive load	15 VA/100 V AC, 30 VA/200 V AC
Min. load		0.4 VA/100 V AC, 1.6 VA/200 V AC
Open circuit leakage current		1 mA/100 V AC, 2 mA/200 V AC
Response	OFF→ON	1 ms or less
time	ON→OFF	10 ms or less
Output circu	it insulation	Photo-thyristor insulation

(\*1) The total load current of resistance loads per comm terminal should be the following value.

4 output points/common terminal: 0.8 A or less

8 output points/common terminal: 0.8 A or less

8 output points/common terminal: 0.8 A or less

As for the number of outputs per common terminal, refer to

"Chapter 4 interpretation of partition" and the following manual.

→ Refer to FX3∪ Series User's Manual - Hardware Edition.

3.7.2 External wiring of triac output AC power 2001 ... U

## 16

3.7.3 Cautions in external wiring For cautions in external wiring, refer to the following manual.

→ Refer to FX3∪ Series User's Manual - Hardware Edition. Protection circuit for load short-circuits
A short-circuit at a load connected to an output terminal could cause burnout at the output lement or the PCB. To prevent this, a protection fuse should be inserted at the output.

LED on panel lights when photocoupler is driven.

Micro current load

The PLC's internal Triac output circuit is equipped with a turn-off C.R absorber. When connecting a very low current load of "0.4 VA/100 V.A Cor less", please connect a surge absorber parallel to the load.

Select the rated voltage of a surge absorber that is suitable for the load being used. Refer to the table below for other specifications. acity Approx. 0.1 μF Interlock
Loads, such as contactors for normal and reverse rotations, that
must not be turned on simultaneously should have an interlock in the
PLC program and an external interlock.

Interpretation of partition
The partition of the output terminals (see following figure) indicates the range of the output connected to the same common.

Example: FX3U-48MT/ES 
 Y0
 Y2
 Y4
 ...

 COM1
 Y1
 Y3
 COM2
 ...

ails on the terminal block layout, refer to the following manual → Refer to FX3∪ Series User's Manual - Hardware Edition

Handling of Batteries and/or Devices with Built-in Batteries in EU Member States



contents noted in this manual. regalures of use and a compensation to:

(1) Damages caused by any cause found not to be the responsibility of Mistubishunity, lost profits incurred to the user by Failures of Missubstit products.

3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products so ther than Mitsubishi products.

4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

for safe use

MITSUBISHI ELECTRIC CORPORATION

(2) \*1 This symbol to the left is specified as below:

separately initi other sketosis (666/E/E) and the EU Battery The EU Battery The EU Battery The EU Battery Regulation (EU 2023/1542) requires the following when marketing or exporting batteries and/or devices with built-in batteries to EU member states.

To print the symbol on batteries, if can not, on their manual and

product has been manufactured as a general-purpose part for eral industries, and has not been designed or manufactured to acorporated in a device or system used in purposes related to be incorporated in a device or system used in purposes related to human life. Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric. This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup c falisate functions in the system.