

## Before Using the Product

Please read this document before use. Keep this for future reference and make sure that end users will read this.

### ■ Related manuals

Before using the product, please read "Safety Guidelines" that is included with the CPU module or base unit.

Confirm the following descriptions:


- SAFETY PRECAUTIONS
- CONDITIONS OF USE FOR THE PRODUCT
- EMC AND LOW VOLTAGE DIRECTIVES
- WARRANTY

### ■ Packing list

Check that the following items are included in the package.

Item	Quantity
SD memory card	1
"Before Using the Product" (this document)	1
Supplementary document to the manual Compliant with Chinese RoHS ( (产品名)IC 卡的基于「电子信息产品污染控制标识要求」的表示)	1

### ■ Part names



No.	Name	Application
1)	Write protect switch	A switch that disables deleting data from or overwriting data to the SD memory card (Set the switch to the LOCK position.)

### ■ Specifications

Item	L1MEM-2GBSD	L1MEM-4GBSD
SD memory card type	SD memory card	SDHC memory card
Memory capacity	2GB	4GB
External dimensions	H	32mm
	W	24mm
	D	2.1mm
Weight	2g	

### ■ Operating ambient temperature

Use the product within the range from 0°C to 55°C.

### ■ Information and services

For further information and services, please consult your local Mitsubishi representative.