


MELSOFT MR Configurator2

Installation Instructions

Before Using the Product

Please read this document before use. Keep the document in a safe place for future reference. Make sure that the end users read the document.

For the precautions on using MR Configurator2, refer to the following manual.

 MR Configurator2 SW1DNC-MRC2_ Installation Guide

Notice

- Reprinting or reproducing the part or all of the contents of this document in any form for any purpose without the permission of Mitsubishi Electric Corporation is strictly forbidden.
- Although we have made the utmost effort to follow the revisions of the software and hardware, in some cases, unsynchronized matter may occur.
- The information in this document may be subject to change without notice.


Operating Environment

Item	Contents	
Personal computer	A personal computer on which Windows® operates	
CPU	Desktop PC: Intel® Celeron® Processor	2.8GHz or more recommended
	Laptop PC: Intel® Pentium® M Processor	1.7GHz or more recommended
Required memory	Windows® 7 or later (64-bit edition)	1GB or more recommended
	Windows® 7 or later (32-bit edition)	512MB or more recommended
	Windows Vista®	
	Windows® XP	
Available hard disk capacity	1GB or more	
Disk drive	CD-ROM supported disk drive	
Monitor	Resolution 1024 x 768 pixels or higher	
OS (English version)	<ul style="list-style-type: none"> • Microsoft® Windows® 10 Home Operating System • Microsoft® Windows® 10 Pro Operating System • Microsoft® Windows® 10 Enterprise Operating System • Microsoft® Windows® 10 Education Operating System • Microsoft® Windows® 10 IoT Enterprise 2016 LTSC Operating System (Note-1) • Microsoft® Windows® 8.1 Operating System • Microsoft® Windows® 8.1 Pro Operating System • Microsoft® Windows® 8.1 Enterprise Operating System • Microsoft® Windows® 8 Operating System • Microsoft® Windows® 8 Pro Operating System • Microsoft® Windows® 8 Enterprise Operating System • Microsoft® Windows® 7 Starter Operating System • Microsoft® Windows® 7 Home Premium Operating System • Microsoft® Windows® 7 Professional Operating System • Microsoft® Windows® 7 Ultimate Operating System • Microsoft® Windows® 7 Enterprise Operating System • Microsoft® Windows® Vista® Home Basic Operating System (Note-2) • Microsoft® Windows® Vista® Home Premium Operating System (Note-2) • Microsoft® Windows® Vista® Business Operating System (Note-2) • Microsoft® Windows® Vista® Ultimate Operating System (Note-2) • Microsoft® Windows® Vista® Enterprise Operating System (Note-2) • Microsoft® Windows® XP Professional Operating System SP3 (Note-2) • Microsoft® Windows® XP Home Edition Operating System SP3 (Note-2) 	
Communication interface	RS-232 port, USB port, Ethernet port	

(Note-1):32-bit version is not supported.

(Note-2):64-bit version is not supported.

- If .NET Framework 3.5 (including .NET 2.0 and 3.0) have been disabled in Windows® 7 or later, it is necessary to enable it.
- If any of the following functions is used, this product may not operate normally.
 - Start of application in Windows® compatible mode
 - Fast user switching
 - Remote desktop
 - Windows XP Mode
 - Windows Touch or Touch
 - Modern UI
 - Client Hyper-V
 - Tablet Mode
 - Virtual desktop
- The screen of this product may not operate normally in the following occasions:
 - The size of the text or other items on the screen is other than the default value (96DPI, 100%, 9pt, etc.)
 For details, refer to the following manual.

 MR Configurator2 SW1DNC-MRC2_ Installation Guide

 - Changed the resolution of the screen during operating
 - Multi-display is set
- Please use by "Standard User", "Administrator" in Windows Vista® or later.

Installation

■ Confirm before installation

- Log on to the personal computer as a user having the Administrator authority.
- Close all the applications running under Microsoft® Windows® Operating System before installation. If the product is installed while other applications are running, it may not operate normally.

1. Insert the MELSOFT MR Configurator2 CD-ROM to the CD-ROM drive. Double-click the "setup.exe" on the CD-ROM.

2. Select or enter the necessary information by following the on-screen instructions. (Note-1)

(Note-1):Product ID is written on the "License certificate" included with the product. Enter the 12-digit number divided into 3 and 9 digits.

Packing List

Model name	Product name	Quantity
SW1DNC-MRC2-E (English version package)	MELSOFT MR Configurator2 product (1 license product) CD-ROM	1
	Installation Instructions (This document)	1
	End-user software license agreement	1
	License Certificate	1

■ Acknowledgements

- We do not guarantee those commercially available Microsoft® Windows® Operating System products that are introduced in this manual.
- This software's copyright is owned by Mitsubishi Electric Corporation.
- This software requires one license per computer to be purchased.
- This product (including manual) can be used under the Software License Agreement only.
- We do not take any responsibilities for the consequences of operating this product (including manual).


Uninstallation

Uninstall MELSOFT MR Configurator2 from the control panel of Windows®.

Installing the USB driver

In order to communicate with a servo amplifier via USB, a USB driver needs to be installed.

For a USB driver installation procedure, refer to the following manual.

 MR Configurator2 SW1DNC-MRC2_ Installation Guide

Microsoft, Windows, Windows Vista and Windows XP are registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.

Intel, Pentium and Celeron are trademarks of Intel Corporation in the United States and other countries.

Installation Guide in the CD-ROM is a PDF file.

To view the PDF file, Adobe Reader is required.

Download from the Adobe Systems website.

Adobe and Adobe Reader are registered trademarks of Adobe Systems Incorporated.

Ethernet is a registered trademark of Fuji Xerox Co., Ltd. in Japan.

Generally, the company names, system names and product names, etc. mentioned herein are registered trademarks or trademarks of their respective companies.

The trademark symbols (™, ®) mentioned herein may be unspecified.