



FX3U-8AV-BD

USER'S MANUAL

Manual Number	JY997D40901
Revision	A
Date	August 2010

This manual describes the part names, dimensions, mounting, and specifications of the product. Before use, read this manual and the manuals of all relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions. Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user.

Registration: The company and product name described in this manual are registered trademarks or the trademarks of their respective companies.

Effective August 2010
Specifications are subject to change without notice.

© 2010 Mitsubishi Electric Corporation

Safety Precaution (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

⚠ DANGER and **⚠ CAUTION**.

⚠ DANGER	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
⚠ CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on the circumstances, procedures indicated by **⚠ CAUTION** may also cause severe injury. It is important to follow all precautions for personal safety.

Associated Manuals

Manual name	Manual No.	Description
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains the FX3U Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3UC Series User's Manual - Hardware Edition	JY997D28701 MODEL CODE: 09R519	Explains the FX3UC Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3G/FX3U/FX3UC Series Programming Manual - Basic&Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions and devices.

How to obtain manuals

For product manuals or documents, consult with the Mitsubishi Electric dealer from who you purchased your product.

Compliance with EC directive (CE Marking)

This note does not guarantee that an entire mechanical module produced in accordance with the contents of this note will comply with the following standards. Compliance to EMC directive and LVD directive for the entire mechanical module should be checked by the user/manufacturer. For more information please consult with your nearest Mitsubishi product provider. Regarding the standards that comply with the main unit, please refer to either the FX series product catalog or consult with your nearest Mitsubishi product provider.

Requirement for Compliance with EMC directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2004/108/EC) when used as directed by the appropriate documentation.

Attention

- This product is designed for use in industrial applications.

Note

- Manufactured by: Mitsubishi Electric Corporation 2-7-3 Marunouchi, Chiyoda-ku, Tokyo, 100-8310 Japan
- Manufactured at: Mitsubishi Electric Corporation Himeji Works 840 Chiyoda-machi, Himeji, Hyogo, 670-8677 Japan
- Authorized Representative in the European Community: Mitsubishi Electric Europe B.V. Gothaer Str. 8, 40880 Ratingen, Germany

Type: Programmable Controller (Open Type Equipment)
Models: MELSEC FX3U series manufactured from August 1st, 2010 FX3U-8AV-BD

Standard	Remark
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. EMI • Radiated Emissions • Conducted Emissions EMS • Radiated electromagnetic field • Fast Transient burst • Electrostatic discharge • High-energy surge • Voltage drops and interruptions • Conducted RF • Power frequency magnetic field

1. Introduction


The FX3U-8AV-BD is an expansion board equipped with eight analog set points which can be used as an analog timer.

1.1 Incorporated Items


Check to ensure the following product and items are included in the package

Included Item	
FX3U-8AV-BD	1 unit
Trimmer layout label	1 sheet
M3 tapping screws for installation	2 pcs
Manuals (Japanese version, English version)	1 manual each

1.2 External Dimensions and Part Names




Special adapter connector cover is removed



MASS(Weight): 20g(0.05lbs)

- [1] Mounting holes(2-φ3.2 (0.13\"))
- [2] Special adapter connector cover
- [3] Analog volume
- [4] Main unit connector
- [5] Special adapter connector

1.3 Trimmer Layout



2. Installation

INSTALLATION PRECAUTIONS **⚠ DANGER**

- Make sure to shut down all phases of the power supply externally before installing. Failure to do so may cause electric shock or damage to the product.

INSTALLATION PRECAUTIONS **⚠ CAUTION**


- Use the product within the generic environment specifications described in PLC main unit manual (Hardware Edition). Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂, or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.
- Use screwdrivers carefully when performing installation work, thus avoiding accident or product damage.
- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Do not touch the conductive parts of the product directly. Doing so may cause device failures or malfunctions.
- Connect the extension board securely to their designated connectors. Loose connections may cause malfunctions.

2.1 Installation Method


The following section describes the installation method to the FX3U/FX3UC-32MT-LT(-2) Series PLC.

2.1.1 FX3U Series PLC

- Power off the PLC. Disconnect all the cables connected to the PLC. Demount the PLC from the DIN rail.
- Using a flat head screwdriver as shown in the figure on the right, lift the dummy expansion board cover (fig. A) making sure not to damage the circuit board or electronic parts.
- Remove the dummy expansion board cover (fig. A) perpendicularly away from the main unit.




- Make sure the expansion board (fig. B) is in parallel with the main unit (fig. C) and attach it to the expansion board connector.
- Fix the expansion board (fig. B) to the main unit (fig. C) using the provided M3 tapping screws (fig. D). Tightening torque: 0.3 to 0.6 N·m




2.1.2 FX3UC-32MT-LT(-2) Series PLC

- Power off the PLC. Disconnect all the cables connected to the PLC. Demount the PLC from the DIN rail.
- Using a flat head screwdriver as shown in the figure on the right, lift the dummy expansion board cover (fig. A) making sure not to damage the circuit board or electronic parts.
- Remove the dummy expansion board cover (fig. A) perpendicularly away from the main unit.



- Make sure the expansion board (fig. B) is in parallel with the main unit (fig. C) and attach it to the expansion board connector.
- Fix the expansion board (fig. B) to the main unit (fig. C) using the provided M3 tapping screws (fig. D). Tightening torque: 0.3 to 0.6 N·m



3. Specification

STARTUP AND MAINTENANCE PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. * For repair, contact your local Mitsubishi Electric distributor. Do not drop the product or exert strong impact to it. Doing so may cause damage. 	

DISPOSAL PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device. 	

TRANSPORT AND STORAGE PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> The product is a precision instrument. During transportation, avoid any impacts. Failure to do so may cause failures in the product. After transportation, verify the operations of the product. 	

3.1 Applicable PLC

Model name	Applicability
FX3U Series PLC	Ver. 2.70 and later
FX3UC-32MT-LT(-2) PLC	Ver. 2.70 and later

3.2 General Specifications

Items other than the following are equivalent to those of the PLC main unit. For general specifications, refer to the manual of the PLC main unit.

- Refer to the **FX3U Series User's Manual - Hardware Edition**.
- Refer to the **FX3UC Series User's Manual - Hardware Edition**.

3.3 Power Supply Specification

Item	Specification
5V DC power supply (mA)	20mA (5V DC power is supplied internally from the main unit.)


3.4 Performance Specification

Item	Specification
Analog volume points	8 points
Instruction	VRRD(FNC 85) Volume Read VRSC(FNC 86) Volume Scale
Digital conversion value	VRRD instruction: 0 to 255 VRSC instruction: 0 to 10

4. Program Example


For details on the VRRD and VRSC instruction, refer to the following manuals.
→ Refer to the **FX3G/FX3U/FX3UC Series Programming Manual**.

- Example in which the read analog value is used as the set value of an analog timer. (VRRD instruction)
The analog value of the variable analog potentiometer No.0 is converted into binary 8-bit data, and the value in the range from 0 to 255 is transferred to D0. The value of D0 is used as the set value of a timer



When a value larger than 255 is required as the set value of a timer, the read value multiplied by a constant by the FNC22 (MUL) instruction can be set indirectly as the timer constant.


- Example in which the scale value is used as a rotary switch. (VRSC instruction)
Either one among auxiliary relays M0 to M10 turns ON in accordance with the scale value in the range from 0 to 10 of the specified variable analog potentiometer.




5. Trimmer Layout Label

The trimmer layout label is adhere it in a position where it can be seen easily for quick reference (as shown in the figure below).

- In the case of FX3U Series PLC



- In the case of FX3UC-32MT-LT(-2) PLC



6. Caution On Use

- Only one analog volume expansion board can be used per main unit.
- The communication function is not available at ch1 when VRRD or VRSC instruction is used in the program in FX3U/FX3UC PLCs.

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
HIMEJI WORKS : 840, CHIYODA CHO, HIMEJI, JAPAN

MITSUBISHI *Changes for the Better*
 PROGRAMMABLE CONTROLLERS
MELSEC-F
FX3U-8AV-BD
USER'S MANUAL

Manual Number	JY997D40901
Revision	A
Date	August 2010

This manual describes the part names, dimensions, mounting, and specifications of the product. Before use, read this manual and the manuals of all relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions. Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user. Registration: The company and product name described in this manual are registered trademarks or the trademarks of their respective companies. Effective August 2010. Specifications are subject to change without notice. © 2010 Mitsubishi Electric Corporation

Safety Precaution (Read these precautions before use.)
 This manual classifies the safety precautions into two categories:
 ⚠DANGER and ⚠CAUTION.

DANGER	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on the circumstances, procedures indicated by ⚠CAUTION may also cause severe injury. It is important to follow all precautions for personal safety.

Associated Manuals

Manual name	Manual No.	Description
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains the FX3U Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3UC Series User's Manual - Hardware Edition	JY997D28701 MODEL CODE: 09R519	Explains the FX3UC Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3G/FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions and devices.

How to obtain manuals
 For product manuals or documents, consult with the Mitsubishi Electric dealer from who you purchased your product.

Compliance with EC directive (CE Marking)

This note does not guarantee that an entire mechanical module produced in accordance with the contents of this note will comply with the following standards. Compliance to EMC directive and LVD directive for the entire mechanical module should be checked by the user/manufacturer. For more information please consult with your nearest Mitsubishi product provider. Regarding the standards that comply with the main unit, please refer to either the FX series product catalog or consult with your nearest Mitsubishi product provider.

Requirement for Compliance with EMC directive
 The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2004/108/EC) when used as directed by the appropriate documentation.

- Attention**
- This product is designed for use in industrial applications.
 - Note**
 - Manufactured by: Mitsubishi Electric Corporation, 2-7-3 Marunouchi, Chiyoda-ku, Tokyo, 100-8310 Japan
 - Manufactured at: Mitsubishi Electric Corporation Himeji Works, 840 Chiyoda-machi, Himeji, Hyogo, 670-8677 Japan
 - Authorized Representative in the European Community: Mitsubishi Electric Europe B.V., Gothaer Str. 8, 40880 Ratingen, Germany

Type: Programmable Controller (Open Type Equipment)
 Models: MELSEC FX3U series manufactured from August 1st, 2010 FX3U-8AV-BD



Standard	Remark
EN61131-2:2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard.
	EMI
	• Radiated Emissions
	• Conducted Emissions
	EMS
	• Radiated electromagnetic field
	• Fast Transient burst
	• Electrostatic discharge
	• High-energy surge
	• Voltage drops and interruptions
	• Conducted RF
	• Power frequency magnetic field

1. Introduction
 The FX3U-8AV-BD is an expansion board equipped with eight analog set points which can be used as an analog timer.

1.1 Incorporated Items
 Check to ensure the following product and items are included in the package

Included Item	
FX3U-8AV-BD	1 unit
Trimmer layout label	1 sheet
M3 tapping screws for installation	2 pcs
Manuals (Japanese version, English version)	1 manual each

1.2 External Dimensions and Part Names



- [1] Mounting holes(2-φ3.2 (0.13"))
- [2] Special adapter connector cover
- [3] Analog volume
- [4] Main unit connector
- [5] Special adapter connector

1.3 Trimmer Layout

VR0	VR1
VR2	VR3
VR4	VR5
VR6	VR7

2. Installation

INSTALLATION PRECAUTIONS ⚠DANGER

- Make sure to shut down all phases of the power supply externally before installing. Failure to do so may cause electric shock or damage to the product.

INSTALLATION PRECAUTIONS ⚠CAUTION


- Use the product within the generic environment specifications described in PLC main unit manual (Hardware Edition). Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂, or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.
- Use screwdrivers carefully when performing installation work, thus avoiding accident or product damage.
- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Do not touch the conductive parts of the product directly. Doing so may cause device failures or malfunctions.
- Connect the extension board securely to their designated connectors. Loose connections may cause malfunctions.

2.1 Installation Method


The following section describes the installation method to the FX3U/FX3UC-32MT-LT(-2) Series PLC.

2.1.1 FX3U Series PLC

- Power off the PLC. Disconnect all the cables connected to the PLC. Demount the PLC from the DIN rail.
- Using a flat head screwdriver as shown in the figure on the right, lift the dummy expansion board cover (fig. A) making sure not to damage the circuit board or electronic parts.
- Remove the dummy expansion board cover (fig. A) perpendicularly away from the main unit.




- Make sure the expansion board (fig. B) is in parallel with the main unit (fig. C) and attach it to the expansion board connector.
- Fix the expansion board (fig. B) to the main unit (fig. C) using the provided M3 tapping screws (fig. D). Tightening torque: 0.3 to 0.6 N·m




2.1.2 FX3UC-32MT-LT(-2) Series PLC

- Power off the PLC. Disconnect all the cables connected to the PLC. Demount the PLC from the DIN rail.
- Using a flat head screwdriver as shown in the figure on the right, lift the dummy expansion board cover (fig. A) making sure not to damage the circuit board or electronic parts.
- Remove the dummy expansion board cover (fig. A) perpendicularly away from the main unit.



- Make sure the expansion board (fig. B) is in parallel with the main unit (fig. C) and attach it to the expansion board connector.
- Fix the expansion board (fig. B) to the main unit (fig. C) using the provided M3 tapping screws (fig. D). Tightening torque: 0.3 to 0.6 N·m



3. Specification

STARTUP AND MAINTENANCE PRECAUTIONS ⚠CAUTION

- Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. * For repair, contact your local Mitsubishi Electric distributor.
- Do not drop the product or exert strong impact to it. Doing so may cause damage.

DISPOSAL PRECAUTIONS ⚠CAUTION

- Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device.

TRANSPORT AND STORAGE PRECAUTIONS ⚠CAUTION

- The product is a precision instrument. During transportation, avoid any impacts. Failure to do so may cause failures in the product. After transportation, verify the operations of the product.

3.1 Applicable PLC

Model name	Applicability
FX3U Series PLC	Ver. 2.70 and later
FX3UC-32MT-LT(-2) PLC	Ver. 2.70 and later

3.2 General Specifications
 Items other than the following are equivalent to those of the PLC main unit. For general specifications, refer to the manual of the PLC main unit.
 → Refer to the FX3U Series User's Manual - Hardware Edition.
 → Refer to the FX3UC Series User's Manual - Hardware Edition.

3.3 Power Supply Specification

Item	Specification
5V DC power supply (mA)	20mA (5V DC power is supplied internally from the main unit.)


3.4 Performance Specification

Item	Specification
Analog volume points	8 points
Instruction	VRRD(FNC 85) Volume Read VRSC(FNC 86) Volume Scale
Digital conversion value	VRRD instruction: 0 to 255 VRSC instruction: 0 to 10

4. Program Example


For details on the VRRD and VRSC instruction, refer to the following manuals.
 → Refer to the FX3G/FX3U/FX3UC Series Programming Manual.

- Example in which the read analog value is used as the set value of an analog timer. (VRRD instruction)
 The analog value of the variable analog potentiometer No.0 is converted into binary 8-bit data, and the value in the range from 0 to 255 is transferred to D0. The value of D0 is used as the set value of a timer




When a value larger than 255 is required as the set value of a timer, the read value multiplied by a constant by the FNC22 (MUL) instruction can be set indirectly as the timer constant.

- Example in which the scale value is used as a rotary switch. (VRSC instruction)
 Either one among auxiliary relays M0 to M10 turns ON in accordance with the scale value in the range from 0 to 10 of the specified variable analog potentiometer.




5. Trimmer Layout Label

The trimmer layout label is adhere it in a position where it can be seen easily for quick reference (as shown in the figure below).
 • In the case of FX3U Series PLC



- In the case of FX3UC-32MT-LT(-2) PLC



6. Caution On Use

- Only one analog volume expansion board can be used per main unit.
- The communication function is not available at ch1 when VRRD or VRSC instruction is used in the program in FX3U/FX3UC PLCs.

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty
 Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

⚠ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.