

MELSOFT MX OPC Server DA

Installation Instructions

Before Using the Product

Please read this document before use. Keep the document in a safe place for future reference. Make sure that the end users read the document.

For the precautions on using MELSOFT MX OPC Server DA, refer to the following manual.

 MELSOFT MX OPC Server DA Version 7 Operating Manual [SH-081860ENG]

Notice

- Reprinting or reproducing the part or all of the contents of this document in any form for any purpose without the permission of Mitsubishi Electric Corporation is strictly forbidden.
- Although we have made the utmost effort to follow the revisions of the software and hardware, in some cases, unsynchronized matter may occur.
- The information in this document may be subject to change without notice.

Operating Environment

Item	Contents
Personal computer	A personal computer on which Microsoft® Windows® operates
CPU	Intel® Core™ 2 Duo Processor 2GHz or more recommended
Required memory	64-bit OS: Recommended 2GB or more 32-bit OS: Recommended 1GB or more
Available hard disk capacity	When installing MELSOFT MX OPC Server DA: 1.7GB or more When operating MELSOFT MX OPC Server DA: 512MB or more
Monitor	Resolution 1024 × 768 pixels or higher
OS (English version, Japanese version)	<ul style="list-style-type: none"> • Windows 10 IoT Enterprise 2016 LTSB^{1,2,3} • Windows 10 (Home, Pro, Enterprise², Education²) • Windows 8.1, Windows 8.1 (Pro, Enterprise) • Windows 8, Windows 8 (Pro, Enterprise) • Windows 7 (Home Basic SP1, Home Premium SP1, Professional SP1, Ultimate SP1, Enterprise SP1) • Windows Server 2012, Windows Server 2012 R2 (Standard, Datacenter)³ • Windows Server 2008 R2 (Standard SP1, Enterprise SP1, Datacenter SP1)³

¹ Only an operating system with MELIPC Edge Computing Model is supported.

² Unified Write Filter (UWF) is not supported.

³ 32-bit version is not supported.

- If .NET Framework 2.0, .NET Framework 4.0 and Windows Installer 3.0 are not installed to the personal computer to which MELSOFT MX OPC Server DA is to be installed, approximately 500MB of memory is required in the system drive to install them.
- For Windows 10, if .NET Framework 3.5 (including .NET 2.0 and 3.0) or .NET Framework 4.6 Advanced Services is invalid, it needs to be valid. Refer to TECHNICAL BULLETIN No. FA-A-0207.
- For Windows 8 and Windows 8.1, if .NET Framework 3.5 (including .NET 2.0 and 3.0) or .NET Framework 4.5 Advanced Services is invalid, it needs to be valid. Refer to TECHNICAL BULLETIN No. FA-A-0153.
- For Windows 7, if .NET Framework 3.5 (including .NET 2.0 and 3.0) is invalid, it needs to be valid.
- When the following functions are used, this product may not run properly.
 - Application start-up in Windows compatibility mode
 - Fast user switching
 - Remote desktop
 - Windows XP Mode
 - Windows Touch or Touch
 - Modern UI
 - Client Hyper-V
 - Tablet mode
 - Virtual Desktops
- In the following cases, the screen of this product may not work properly.
 - The size of the text and/or other items on the screen are changed to values other than default values (such as 96 DPI, 100%, and 9 pt).
 - The resolution of the screen is changed in operation.
 - The multi-display is set.
- Use the product as a standard user or an administrator for Windows 10, Windows 8.1, Windows 8 and Windows 7.
- In this product, the period (.) is used as the symbol of the decimal point. Regardless of the setting of "Decimal symbol" on the control panel, use the period when enter the decimal point.

Installation

■ Confirm before installation

- Log on to the personal computer as an administrator.
- Close all running applications before installation. If the product is installed while other applications are running, it may not operate normally.

1. Insert the MELSOFT MX OPC Server DA DVD-ROM to the DVD-ROM drive. Double-click the "setup.exe" in the DVD-ROM.
2. Select or enter the necessary information by following the on-screen instructions.^{*1}

^{*1} Product ID is written on the "License certificate" included with the product. Enter the 12-digit number divided into 3 and 9 digits.

Packing List

Model name	Product name	Quantity
SW7DND-OPCDAS-E (English version package) (Standard license product)	MELSOFT MX OPC Server DA DVD-ROM	1
	Installation Instructions (This document)	1
	End-user software license agreement	1
	Software registration notice	1
	License certificate	1
SW7DND-OPCDAS-EA (English version package) (Volume license product)	MELSOFT MX OPC Server DA DVD-ROM	1
	Installation Instructions (This document)	1
	End-user software license agreement	1
	Software registration notice	1
	License certificate	n ^{*1}
SW7DND-OPCDAS-EAZ (English version package) (Additional license product)	End-user software license agreement	1
	Software registration notice	1
	License certificate	n ^{*1}

^{*1} Number of licenses.

■ Acknowledgements

- Do not shift to the power save mode (standby, hibernate, sleep) while installing software.
- We do not guarantee those commercially available Microsoft Windows Operating System products that are introduced in this manual.
- This software's copyright is owned by Mitsubishi Electric Corporation.
- This product (including manual) can be used under the Software License Agreement only.
- We do not take any responsibilities for the consequences of operating this product (including manual).

Uninstallation

Uninstall MELSOFT MX OPC Server DA from the control panel of Windows.

Installation of USB driver

In order to communicate with a CPU module via USB, a USB driver needs to be installed. When a CPU module can not communicate via USB, refer to the following manual to install a USB driver.

 MELSOFT MX OPC Server DA Version 7 Operating Manual [SH-081860ENG]

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Intel is either registered trademarks or trademarks of Intel Corporation in the United States and/or other countries.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.